

Example Response	<pre> {   "response_code":0,   "group_id":"9A237BF5AB80ED3C7251DFF49825CA42",   "group_name":"[Link] Living Room",   "role":"server",   "status":" working ",   "server_zone":"main",   "client_list":[     {       "ip_address":"192.168.0.5",       "data_type":"base"     },     {       "ip_address":"192.168.0.11",       "data_type":"base"     },     {       "ip_address":"192.168.0.22",       "data_type":"ext"     }   ]   "build_disable":[     {       "role":"client",       "reasons":[         "unknown"       ]     }   ]   "audio_dropout":false, }</pre>
------------------	---

## 5.2. setServerInfo

For setting a Link distribution server (Link master)

### Request Parameters

Name	type	required	description
group_id	string	yes	Specify Group ID in 32-digit hex. Specify "" (empty text) here to cancel a Device being the Link distribution server. Group ID will be initialized ("000...") after the cancel operation
Zone	string	no	Specifies which target Zone ID to be the Link distribution server. If nothing is specified, current setting is kept. Zone ID to be the Link distribution server is confirmable using system/getFeatures server_zone_list. Values: "main" / "zone2" / "zone3" / "zone4"