

Response Parameters

name	type	description
response_code	integer	0: Successful request / Others: Error Refer to “Response Code List” for details
status	string	Returns Stereo Pair status Values : "none" / "master_left" / "master_right" / "slave_left" / "slave_right"
pair_info	object	Returns the other side device (Stereo Pair) information
- alive	boolean	Returns whether or not the other side device is alive
- ip_address	string	Returns IP Address
- mac_address	string	Returns MAC Address (Wireless Direct 12 digit ASCII)

Example Response	<pre>{ "response_code":0, "status":"master_left", "pair_info":{ "alive":true, "ip_address":"192.168.0.10", "mac_address":"00A0DE012345" } }</pre>
------------------	-----------------------------------------------------------------------------------------------------------------------------------------------------------------------

4.35. sendIrCode

For sending specific remote IR code. A Device is operated same as remote IR code reception. But continuous IR code cannot be used in this command. Refer to each Device's IR code list for details

Request Parameters

name	type	required	description
code	string	yes	Specifies IR code in 8-digit hex

URI	<BaseURL>/v1/system/sendIrCode?code=<code>
Method	GET
Example Request	http://{host}/YamahaExtendedControl/v1/system/sendIrCode?code=7F016C13

Response Parameters

name	type	description
response_code	integer	0: Successful request / Others: Error Refer to “Response Code List” for details

Example Response	<pre>{ "response_code":0 }</pre>
------------------	------------------------------------