

Type	string	no	Specifies a type of adding or removing clients. Not necessary to specify when canceling the Link master status. Values: "add" / "remove"
client_list	string array	no	Specifies IP addresses of adding/removing clients. Specifiable up to 9 clients

URI	<BaseURL>/v1/dist/setServerInfo		
Method	POST		
Example Request (URI)	http://{host}/YamahaExtendedControl/v1/dist/setServerInfo		
Example Request (json)	<pre>{ "group_id":"9A237BF5AB80ED3C7251DFF49825CA42", "zone":"main", "type":"add", "client_list":["192.168.0.5", "192.168.0.11"] }</pre>		

Response Parameters

name	type	description
response_code	integer	0: Successful request / Others: Error Refer to " Response Code List " for details

Example Response	<pre>{ "response_code":0 }</pre>
------------------	------------------------------------

5.3. setClientInfo

For setting Link distributed clients. If a Device is already setup as Link distribution server, this client setup is denied by that Device: use this API after canceling a Device's Link distribution server setup using setServerInfo, then confirming that the target Device's role is changed to other values than "server" using getDistributionInfo.

Request Parameters

name	type	required	description
group_id	string	yes	Specifies Group ID in 32-digit hex. Specify "" (empty text) here to cancel a Device being a Link distributed client. Group ID will be initialized ("000...") after the cancel operation
zone	string array	no	Specifies which target Zone ID to be a Link distributed client. Not necessary to specify when cancelling a client status. Values: "main" / "zone2" / "zone3" / "zone4"
server_ip_address	string	no	Specifies the IP Address of the Link distribution server