

9.1.3. Removing a client from the Group

Here shows how to remove DeviceC from the Group

1. Clear GroupID and target Zone of the removing client(s) by “setClientInfo”.
*Set Group ID with empty text ””.

Request (URI)

http://{Device C}/ YamahaExtendedControl/v1/dist/setClientInfo

Request (json)

```
{
    "group_id": "",
    "zone": [
        "main"
    ]
}
```

Response

```
{
    "response_code": 0
}
```

2. Setup the master with GroupID and removing client list by “setServerInfo (remove)”.
*If all clients are to be remove, set empty text ”” to GroupID in setServerInfo

Request (URI)

http://{Device B}/ YamahaExtendedControl/v1/dist/setServerInfo

Request (json)

```
{
    "group_id": "9A237BF5AB80ED3C7251DFF49825CA42",
    "zone": "main",
    "type": "remove",
    "client_list": [
        "192.168.0.6" ← Device C   IP address
    ]
}
```

Response

```
{
    "response_code": 0
}
```

3. Reflect current all system distribution number to the master by “startDistribution”.

Request (URI)

http://{Device B}/ YamahaExtendedControl/v1/dist/startDistribution?num=2

Response

```
{
    "response_code": 0
}
```