

Bit number				31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0		
ID																				A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A
Reset 0x00000000				0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
ID	R/W	Field	Value ID	Value				Description																													
A	RW	MAXCNT		[1..0xffff]				Maximum number of bytes in channel buffer																													

### 8.20.7.34 DMA.TX.AMOUNT

Address offset: 0x744

Number of bytes transferred in the last transaction, updated after the END event.

Also updated after each MATCH event.

Bit number				31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0																															
ID				A A A A A A A A A A A A A A A A A A A A A A A A A A A A																															
Reset 0x00000000				0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0																															
ID	R/W	Field	Value ID	Value				Description																											
A	R	AMOUNT		[1..0xffff]				Number of bytes transferred in the last transaction. In case of NACK error, includes the NACK'ed byte.																											

### 8.20.7.35 DMA.TX.TERMINATEONBUSERROR

Address offset: 0x754

Terminate the transaction if a BUSERROR event is detected.

Bit number				31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0																															
ID				A																															
Reset 0x00000000				0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0																															
ID	R/W	Field	Value ID	Value				Description																											
A	RW	ENABLE																																	
			Disabled	0				Disable																											
			Enabled	1				Enable																											

### 8.20.7.36 DMA.TX.BUSERRORADDRESS

Address offset: 0x758

Address of transaction that generated the last BUSERROR event.

Bit number				31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
ID				A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A
Reset 0x00000000				0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
ID	R/W	Field	Value ID	Value				Description																											
A	R	ADDRESS																																	

## 8.21 TEMP — Temperature sensor

The temperature sensor peripheral (TEMP) measures die temperature over the temperature range of the device. Linearity compensation can be implemented if required by the application.

The main features of TEMP are the following:

- Temperature range is greater than or equal to operating temperature of the device