


- Mount cam lever clip **9**.



## 18.4.29 Disassembling the antihopping clutch




- Clamp clutch **1** into a vise.


Guideline

Use soft jaws.

- Carefully loosen special tool **2** in steps and remove it.



- Take the clutch out of the vise and place it on a clean workbench with the outside inner clutch hub **5** facing downward.
- Remove inner clutch hub **3** and release springs **4** from the outer clutch hub **5**.




- Take off the clutch facing discs **6** from the inner clutch hub.
- Remove pretension ring **7** and support ring **8**.
- Clean all parts well.
- Check the clutch. (📖 p. 229)



## 18.4.30 Checking the clutch

### Preparatory work

- Disassemble the antihopping clutch. (📖 p. 229)



Main work

- Check clutch throw-out 1 for damage and wear.
    - » If there is damage or wear:
      - Change the clutch push rod.
  - Check axial bearing 2 for damage and wear.
    - » If there is damage or wear:
      - Change the axial bearing.
  - Place the clutch push rod 3 on a flat surface and check for run-out.
    - » If there is run-out:
      - Change the clutch push rod.
  - Check the length of clutch springs 4.
- |                        |                                      |
|------------------------|--------------------------------------|
| Clutch spring - length | 31.5 ... 33.5 mm (1.24 ... 1.319 in) |
|------------------------|--------------------------------------|
- » If the clutch spring length is shorter than specified:
    - Change all clutch springs.
  - Check the contact surface of clutch pressure cap 5 for damage and wear.
    - » If there is damage or wear:
      - Change the clutch pressure cap.
  - Check the thrust surfaces of the clutch facing discs in clutch basket 6 for wear.
- |  |                      |
|--|----------------------|
| Clutch basket - contact surface of clutch facing discs | ≤ 0.5 mm (≤ 0.02 in) |
|--|----------------------|
- » If the thrust surface exhibits excessive wear:
    - Change the clutch facing discs and the clutch basket.
  - Check needle bearing 7 and supporting plate 8 for damage and wear.
    - » If there is damage or wear:
      - Change the needle bearing and supporting plate.
  - Check intermediate clutch discs 9 for damage and wear.



- » If the intermediate clutch discs are not level and are pitted:
  - Change all intermediate clutch discs.
- Check clutch facing discs 10 for discoloration and scoring.
  - » If there is discoloration or scoring:
    - Change all clutch facing discs.
- Check the thickness of clutch facing discs 10.

Clutch facing disc - thickness	≥ 2.5 mm (≥ 0.098 in)
--------------------------------	-----------------------


- » If the clutch facing disc does not meet specifications:
  - Change all clutch facing discs.
- Check stepped washer 11 for damage and wear.
  - » If there is damage or wear:
    - Change the stepped washer.
- Check half washers 12 for damage and wear.
  - » If there is damage or wear:
    - Change the half washers.
- Check inner clutch hub 13 for damage and wear.
  - » If there is damage or wear:
    - Change the inner clutch hub.
- Check outer clutch hub 14 for damage and wear.
  - » If there is damage or wear:
    - Change the outer clutch hub.

#### Finishing work

- Preassemble the antihopping clutch. (📖 p. 231)



#### 18.4.31 Preassembling the antihopping clutch




- Thoroughly oil the clutch facing discs.
- Push the support ring 1 and the pretension ring 2 on to the outer clutch hub.




#### Info

The pretension ring must be installed so that it is flush with the inner edge A on the support ring.



- Position the trimmed clutch facing disc with the recess for the pretension ring on the outer clutch hub.
- Beginning with the coated intermediate clutch disc, position all further clutch facing discs and intermediate clutch discs alternately.
- Position the release springs 3.






- Push on the outer clutch hub **4** and pay attention to the markings.
  - ✓ The arrow **6** of the outer clutch hub must point to the notch **5** of the inner clutch hub.
- Tightly press both inner clutch hubs together and have an assistant screw in the special tool.

Assembly screws (75029033000) (p. 387)

## **i** Info

Apply the special tool by hand only; do not use another tool.  
Only tighten the special tool to the point where the clutch facing discs cannot be shifted relative to each other; they will need to be aligned when they are mounted in the clutch basket.


### 18.4.32 Checking the shift mechanism



B05770-10

- Check shift forks **1** on plate **A** for damage and wear (visual check).
  - » If there is damage or wear:
    - Change the shift fork and gear wheel pair.
- Check shift grooves **B** of shift drum **2** for wear.
  - » If the shift groove is worn:
    - Change the shift drum.
- Check the seat of the shift drum in bearings **3**.
  - » If the shift drum is not seated correctly:
    - Change the shift drum and/or the bearing.
- Check bearing **3** for stiffness and wear.

- » If the bearings are stiff or are worn:
  - Change the bearings.
- Check needle bushing **4** for stiffness and wear.
  - » If the needle bushing does not move freely or is worn:
    - Change the needle bushing.
- Check shift rail **5** for run-out on a flat surface.
  - » If there is run-out:
    - Change the shift rail.
- Check the shift rails for scoring, wear and smooth operation in the shift forks.
  - » If there is scoring or corrosion, or if the shift fork is stiff:
    - Change the shift rail.
- Check sliding plate **6** in contact areas **C** for wear.
  - » If the sliding plate is worn:
    - Change the sliding plate.
- Check return surface **D** on the sliding plate for wear.
  - » If deep notches are present:
    - Change the sliding plate.
- Check guide pin **E** for looseness and wear.
  - » If the guide pin is loose and/or worn:
    - Change the sliding plate.
- Preassemble the shift shaft. (p. 233)




- Check clearance **F** between the sliding plate and the shift quadrant.

Shift shaft - play in sliding plate/shift quadrant	0.40 ... 0.80 mm (0.0157 ... 0.0315 in)
--	---

- » If the measured value does not meet specifications:
  - Change the sliding plate.

#### 18.4.33 Preassembling the shift shaft




- Fix the short end of the shift shaft in a vise.
 

Guideline  
Use soft jaws.
- Mount sliding plate **1** with the guide pin facing down and attach the guide pin to the shift quadrant.
- Mount pressure spring **2**.
- Push on spring guide **3**, push return spring **4** over the spring guide with the offset end facing upward and lift the offset end over abutment bolt **5**.
- Mount stop disk **6**.



## 18.4.34 Disassembling the main shaft



- Secure the main shaft with the toothed end facing downward in the vise.

### Guideline

Use soft jaws.

- Remove stop disk **1** and second-gear fixed gear **2**.
- Remove sixth-gear idler gear **3**.
- Remove needle bearing **4** and stop disk **5**.
- Remove lock ring **6**.




### Info

Open the lock ring with a screwdriver and twist it off the transmission shaft with pliers.

- Remove third/fourth-gear sliding gear **7**.
- Remove lock ring **8**.
- Remove stop disk **9** and fifth-gear idler gear **10**.
- Remove needle bearing **11**.

### 18.4.35 Disassembling the countershaft



311920-10

- Secure the countershaft in the bench vise with the toothed end facing downward.

#### Guideline

Use soft jaws.

- Remove stop disk ① and first-gear idler gear ②.
- Remove needle bearing ③ and stop disk ④.
- Remove fifth-gear sliding gear ⑤ and lock ring ⑥.



#### Info

Open the lock ring with a screwdriver and twist it off the transmission shaft with pliers.


- Remove stop disk ⑦ and third-gear idler gear ⑧.
- Remove needle bearing ⑨ and fourth-gear idler gear ⑩.
- Remove needle bearing ⑪ and stop disk ⑫.
- Remove lock ring ⑬ and sixth-gear sliding gear ⑭.
- Remove lock ring ⑮ and stop disk ⑯.
- Remove second-gear idler gear ⑰ and needle bearing ⑱.

### 18.4.36 Checking the transmission

#### Condition

The transmission has been disassembled.





311921-10

- Check needle bearings **1** for damage and wear.
  - » If there is damage or wear:
    - Change the needle bearing.
- Check the pivot points of main shaft **2** and countershaft **3** for damage and wear.
  - » If there is damage or wear:
    - Change the main shaft and/or countershaft.
- Check the tooth profiles of main shaft **2** and countershaft **3** for damage and wear.
  - » If there is damage or wear:
    - Change the main shaft and/or countershaft.
- Check the pivot points of idler gears **4** for damage and wear.
  - » If there is damage or wear:
    - Change the gear wheel pair.
- Check the shift dogs of idler gears **4**, sliding gears **5**, and fixed gear **6** for damage and wear.
  - » If there is damage or wear:
    - Change the gear wheel pair.
- Check the tooth faces of idler gears **4**, sliding gears **5**, and fixed gear **6** for damage and wear.
  - » If there is damage or wear:
    - Change the gear wheel pair.
- Check the tooth profiles of sliding gears **5** for damage and wear.
  - » If there is damage or wear:
    - Change the gear wheel pair.
- Check sliding gears **5** for smooth operation in the profile of main shaft **2**.
  - » If the sliding gear does not move freely:
    - Change the sliding gear or the main shaft.
- Check sliding gears **5** for smooth operation in the profile of countershaft **3**.
  - » If the fixed gear does not move freely:
    - Change the sliding gear or the countershaft.



- Check stop disks **7** for damage and wear.
  - » If there is damage or wear:
    - Change the stop disks.
- Use new lock rings **8** with every repair.

## 18.4.37 Assembling the main shaft




### Info

Use new lock rings with every repair.

### Preparatory work

- Lubricate all parts carefully before assembling.
- Check the transmission. (p. 235)



311922-10

### Main work

- Secure the main shaft in the vise with the gear teeth facing downward.

Guideline

Use soft jaws.

- Mount needle bearing **1**.
- Push on fifth-gear idler gear **2** with the shift dogs facing upward.
- Mount stop disk **3**.
- Position special tool **A** on the transmission shaft.
- Mounting tool for lock ring (76629032000) (p. 391)
- Position lock ring **4** on special tool **A** and push down with sleeve **B**.
  - ✓ The lock ring engages in the groove of the transmission shaft.
- Push on third/fourth-gear sliding gear **5** with the small gear wheel facing downward.



- Position special tool **A** on the transmission shaft.

Mounting tool for lock ring (76629032000) (📖 p. 391)

- Position lock ring **6** on special tool **A** and push down with sleeve **B**.  
✓ The lock ring engages in the groove of the transmission shaft.
- Attach stop disk **7** and needle bearing **8**.
- Push on sixth-gear idler gear **9** with the shift dogs facing downward.
- Push on second-gear fixed gear **10** with the collar facing downward and attach stop disk **11**.
- Finally, check all the gear wheels for smooth operation.

## 18.4.38 Assembling the countershaft




### Info

Use new lock rings with every repair.

### Preparatory work

- Lubricate all parts carefully before assembling.
- Check the transmission. (📖 p. 235)



311923-10

### Main work

- Secure the countershaft in the bench vise with the toothed end facing downward.

Guideline

Use soft jaws.

- Mount needle bearing **1** and second-gear idler gear **2** onto the countershaft with the protruding collar facing downward.
- Mount stop disk **3**.
- Position special tool **A** on the transmission shaft.