

## 29.1 Additional information

Any further work that results from the compulsory work or from the recommended work must be ordered separately and invoiced separately.

Different service intervals may apply in your country, depending on the local operating conditions.

Individual service intervals and scopes may change in the course of technical developments. The most up-to-date service schedule can always be found on Husqvarna Motorcycles Dealer.net. Your authorized Husqvarna Motorcycles dealer will be glad to advise you.

## 29.2 Required work

	Every two years				
	Every year				
	every 20,000 km (12,400 mi)				
	every 10,000 km (6,200 mi)				
	after 1,000 km (620 mi)				
Read out the fault memory using the Husqvarna Motorcycles diagnostics tool.	○	●	●	●	●
Check that the electrical system is functioning properly.	○	●	●	●	●
Change the engine oil and oil filter and clean the oil screens. (📖 p. 293)	○	●	●	●	●
Check the front brake linings. (📖 p. 153)	○	●	●	●	●
Check the rear brake linings. (📖 p. 159)	○	●	●	●	●
Check the brake discs. (📖 p. 112)	○	●	●	●	●
Check the brake lines for damage and leakage.	○	●	●	●	●
Change the front brake fluid. (📖 p. 157)					●
Change the rear brake fluid. (📖 p. 164)					●
Change the hydraulic clutch fluid. (📖 p. 269)					●
Check the rear brake fluid level. (📖 p. 162)	○	●	●	●	
Check the front brake fluid level. (📖 p. 155)	○	●	●	●	
Check/correct the fluid level of the hydraulic clutch. (📖 p. 268)		●	●	●	
Check the free travel of the foot brake lever. (📖 p. 161)	○	●	●	●	●
Check the shock absorber and fork for leaks. Perform a fork service and shock absorber service as needed and depending on how the vehicle is used.	○	●	●	●	●
Clean the dust boots of the fork legs. (📖 p. 19)		●	●		
Check steering head bearing play. (📖 p. 31)	○	●	●	●	●
Check the tire condition. (📖 p. 110)	○	●	●	●	●
Check tire pressure. (📖 p. 110)	○	●	●	●	●
Check the spoke tension. (📖 p. 112)	○	●	●	●	●
Check the rim run-out. (📖 p. 113)	○	●	●	●	●
Check the chain, rear sprocket, engine sprocket, and chain guide. (📖 p. 131)		●	●	●	●
Check the chain tension. (📖 p. 130)	○	●	●	●	●
Change the fuel screen. (📖 p. 100)	○	●	●	●	●
Change the spark plugs. (📖 p. 301)			●		
Check the valve clearance. (📖 p. 303)		●	●		
Check the antifreeze and coolant level. (📖 p. 283)	○	●	●	●	●
Check the cables for damage and routing without sharp bends.		●	●	●	●
Change the air filter. Clean the air filter box. (📖 p. 91)		●	●		
Check the fuel pressure. (📖 p. 98)		●	●	●	●
Check the headlight setting. (📖 p. 169)	○	●	●		

	Every two years				
	Every year				
	every 20,000 km (12,400 mi)				
	every 10,000 km (6,200 mi)				
	after 1,000 km (620 mi)				
Check that the radiator fan is functioning properly.	○	●	●	●	●
Final check: Check the vehicle for roadworthiness and take a test ride.	○	●	●	●	●
Read out the fault memory after the test ride using the Husqvarna Motorcycles diagnostics tool.	○	●	●	●	●
Make the service entry in <b>Husqvarna Motorcycles Dealer.net</b> and in the Service & Manufacturer Warranty Booklet.	○	●	●	●	●


- One-time interval
- Periodic interval

## 29.3 Recommended work

	Every four years				
	Every year				
	every 30,000 km (18,600 mi)				
	every 10,000 km (6,200 mi)				
	after 1,000 km (620 mi)				
Check the frame. (📖 p. 44)			●		
Check the link fork. (📖 p. 75)			●		
Check the fork bearing for play. (📖 p. 75)		●	●		
Check the wheel bearing for play. (📖 p. 111)		●	●		
Empty the drainage hoses.	○	●	●	●	●
Grease all moving parts (e.g., side stand, hand lever, chain, ...) and check for smooth operation.	○	●	●	●	●
Check all hoses (e.g. fuel, coolant, bleeder, drainage, etc.) and sleeves for cracking, leaks, and incorrect routing.		●	●	●	●
Check the screws and nuts for tightness.	○	●	●	●	●
Change the coolant. (📖 p. 285)					●

- One-time interval
- Periodic interval






**Components:**


A11	Engine electronics control unit
F7	Fuse
G10	12-V battery
G20	Alternator
K10	Starter relay with main fuse
K11	Start auxiliary relay
M10	Electric starter system
T20	Voltage regulator
X291	Connector for accessory ground (terminal 31) <b>ACC 1</b> (not assigned)
X292	Connector for accessory plus (terminal 30) <b>ACC 1</b> (not assigned)





**Components:**

A11	Engine electronics control unit
F1	Fuse
F3	Fuse
K12	Light relay
K30	Power relay
K40	Fuel pump relay
M13	Fuel pump
S11	Ignition and steering lock
S23	Emergency OFF switch, tip switch





**Components:**

E13	Low beam, high beam
F5	Fuse
F6	Fuse
P10	Combination instrument
P15	Horn
P35	Parking light
S24	Light switch, horn button, high beam flasher button, turn signal switch

