

CabinetSense Wiki

- [Home](#)
- [32mm System](#)
- [Build History](#)
- [Closet Systems](#)
- [CNC](#)
- [Common Attributes](#)
- [Component Library](#)
- [Components](#)
- [Construction Templates](#)
- [Cutlist Plus Integration](#)
- [Dynamic User Components](#)
- [Elevation and Plan Dimensions](#)
- [Frequently Asked Questions](#)
- [CNC](#)
- [Known Issues](#)
- [Menus](#)
- [Plugins, Programs, and Links](#)
- [Scene and Layer Management](#)
- [Shop and Submittal Drawings](#)
- [Sketchup Tutorials](#)
- [Tips and Tricks](#)
- [Troubleshooting](#)
- [Tutorials](#)
- [Videos](#)

[CabinetSense Wiki](#)

CNC

Can I Control the Label Size in the DXF Export?

Yes, by setting the [Label Height](#) in the CNC Preferences Dialog.

Can I turn off Labels in the DXF Export?

Yes, by setting the [CNC Labels](#) attribute to "No" in the CNC Preferences Dialog

Is there a way to keep the label within the perimeter of the DXF part?

Unfortunately not. CabinetSense exports the DXF information but is not in control of how or where the 3rd party software places it.