

CM47130 MUK Rev 1

morphy richards®

nesta Filter Coffee Maker



For competitions, product hints and tips
and more join us at



www.homeofthehouseproud.com



www.facebook.com/morphyrichardsuk




www.twitter.com/loveyourmorphy

www.morphyrichards.com

* Register online for your 2 year guarantee. See back of this instruction book for details. (UK and Ireland customers only)


Product overview




Features

- | | |
|---------------------------|----------------------|
| 1 Lid | 11 LCD Display |
| 2 Coffee Filter | 12 On/Off Button |
| 3 Filter Basket | 13 Brew Mode Button |
| 4 Coffee Tank | 14 Hour Button |
| 5 Coffee Tank Level | 15 Minute Button |
| 6 Water Tank | 16 Start Time Button |
| 7 Keep Warm Plate | 17 Keep Warm Button |
| 8 Control Panel | 18 Water Gauge |
| 9 Coffee Dispenser Button | |
| 10 Drip Tray | |


Using your coffee maker




Fill the Coffee Tank (4) with cold water.




Pour the water into the Water Tank (6). Do not fill above the max line.




Place the Coffee Tank Assembly into the Main Unit.




Place the Coffee Filter (2) and Filter Basket (3) into the Coffee Tank.




Fill the Coffee Filter (2) with coffee grinds. As a rough guide use 1 tbsp per cup, (max 12 tbsp.)



Select the keep warm time (0, 1, 2, 3 or 4 hours, default setting is 4 hours) by pressing the Keep Warm Button (17). Press the On/Off Button (12).




The coffee maker will brew the coffee. When brewed there will be an audible beep. The coffee maker will switch to keep warm.





Push the Coffee Dispenser Button (9) with your mug to fill with hot coffee.


Making iced coffee




Fill the Coffee Tank (4) with cold water. Do not fill past the 6 cup mark.





Pour the water into the Water Tank (6). Do not exceed the 6 cup level.




Fill the Coffee Tank with ice to the 10 cup level.




Place the Coffee Filter (2) and Filter Basket (3) into the Coffee Tank. Place the assembly into the main body.




Set the Keep Warm time to 0 hours by pressing the button (17). Press the On/Off button (12).



Fill the Coffee Filter with coffee grinds. As a rough guide use 2 tbsp per cup, (max 12 tbsp.)



The coffee maker will brew the coffee. When brewed there will be an audible beep.



Push the Coffee Dispense Button (9) with your glass to fill with iced coffee.

WARNING

BURN HAZARD: Never use the Coffee Tank to pour or carry hot coffee.

- Handle the Coffee Tank only when holding cold water for filling the Water Tanks and for cleaning after the coffee maker has been shut off and the coffee has cooled.
- If the coffee maker overflows unplug the unit. Allow the unit, coffee and grinds to cool before cleaning.

Before first use

Wash the Coffee Tank, Filter Basket, and Drip Tray with hot, soapy water. Do not put the Coffee Tank in the dishwasher.

Programme mode

You can set the coffee maker to begin brewing at a desired time in a 24 hour period.

- 1 Plug the coffee maker in.
 - 2 Set the clock using the Hour and Minute Buttons (14),(15).
 - 3 Press and hold the Start Time Button (16) until 'Start Time' appears in the display.
 - 4 Holding the Start Time Button, use the Hour and Minute Buttons to select the desired brewing start time.
 - 5 Press and release the Start Time Button to activate the automatic brewing mode. A green light will signal the coffee maker is in programme mode.
- The coffee maker will begin brewing at the desired time.

Coffee grinds

As a rule of thumb use 1 level tablespoon of coffee grinds per cup of hot brewed coffee, up to a maximum of 12 tablespoons.

Reheating coffee

Press and hold the On / Off Button (12) for 3 seconds. This will reset the timer and keep coffee warm for selected number of hours (1, 2, 3, or 4).

Brew mode

In addition to the regular setting, the coffee maker has 2 optional brewing settings to help deliver a better taste of your coffee. 'Bold' and '1-4 cups.' To use one of these additional brewing modes instead of the standard setting, select the desired brewing mode before pressing the On/Off Button (12).

For a stronger flavoured coffee press the Brew Mode Button (13) until Bold appears on the LCD Display (11). If you are brewing less than 4 cups of coffee, press the Brew Mode button until 1-4 Cups is shown on the display.

'Bold' and '1-4 Cups' brewing modes will require additional time to complete a brewing cycle. A brew mode must be selected prior to pressing the ON button. The setting cannot be changed during brewing. If a brew mode is not selected, the coffee maker will automatically brew on the regular setting.

Cleaning your coffee maker

WARNING: Burn Hazard. Do not immerse cord, plug, or main unit in any liquid.

Remove the Filter, Filter Basket and Coffee Tank and wash by hand with warm, soapy water. The Filter Basket may also be cleaned in top rack of dishwasher.

Wipe the outside of the coffee maker with a soft cloth and warm, soapy water. Do not use abrasive cleaners, as they will scratch the finish of the product.

Cleaning the coffee maker with vinegar

Clean coffee maker with vinegar at least once a month (once a week in hard water areas).

- 1 Pour 1 pint (2 cups/500ml) vinegar into the Water Tank.
- 2 Press the On/Off button. Press again after 20 seconds and leave product for 30 minutes. Press the On/Off button to begin the brewing process. Turn the coffee maker off when finished.

When cool, dispense several cups before emptying and rinsing the Coffee Tank and Water Tank.

- NOTE: The coffee maker will remind you it is time for cleaning in one of two ways:

Built-in cycle timer—Every 30 cycles, CLEAN will flash in display and stay illuminated for 2 cycles.

Built-in residue sensor—CLEAN will appear in display when unit senses residue buildup and

Troubleshooting

Problem	Reason	Solution
• Coffee leaks from the dispenser	• Coffee grounds trapped in the Coffee Tank dispensing mechanism under seal in Coffee Tank	• See 'Cleaning with vinegar'
• CLEAN appears in display	• This is a reminder to clean the coffee maker	• See 'Cleaning with vinegar'
• Coffee tastes bad	<ul style="list-style-type: none"> • Coffee maker needs cleaning • Coffee ground too coarsely or too finely • Coffee-to-water ratio unbalanced • Poor water quality 	<ul style="list-style-type: none"> • See 'Cleaning with vinegar' • Set coffee grinder to automatic drip grind • Adjust for personal preference
• Coffee not brewing or stops brewing/unit will not turn on	<ul style="list-style-type: none"> • Mineral deposits have built up • Water reservoir is empty • Unit is unplugged • Power outage or power surge 	<ul style="list-style-type: none"> • See 'Cleaning with vinegar' • Fill with water • Plug in • If surge, unplug; then plug back in
• Coffee brews slowly	<ul style="list-style-type: none"> • The coffee maker needs cleaning • The coffee maker is in the '1-4 Cups' or 'Bold' modes 	<ul style="list-style-type: none"> • Clean at least every 30 days to maintain proper performance • Press Brew Mode button until no lights appear
• Coffee overflows basket	<ul style="list-style-type: none"> • Excessive amounts of coffee grinds • Coffee ground too finely 	<ul style="list-style-type: none"> • Do not exceed 12 tbsp of coffee grinds • Set coffee grinder to automatic drip grind
• Unit beeps continuously/ will not brew and/or 'Pour Water' appears in display	• No water in the Water Tank	• Fill the Water Tank
• Coffee is cold when dispensed	• Selected Keep Warm Hours have elapsed and coffee maker has automatically shut off	• See 'Reheat coffee' or brew a new pot

remain illuminated until the unit has been cleaned.

Contact us

Helpline

If you are having a problem with your appliance, please call our Helpline, as we are more likely to be able to help than the store you purchased the item from.

Please have the product name, model number and serial number to hand when you call to help us deal with your enquiry quicker.

UK Helpline: 0844 871 0960

IRE Helpline: 1800 409 119

Spares: 0844 873 0726

Talk To Us

If you have any questions or comments, or want some great tips or recipe ideas to help you get the most out of your products, join us online:

Blog: www.homeofthehouseproud.com

Facebook: www.facebook.com/morphyrichardsuk

Twitter: www.twitter.com/loveyourmorphy

Website: www.morphyrichards.com

Health and Safety

The use of any electrical appliance requires the following common sense safety rules.

Primarily there is danger of injury or death and secondly the danger of damage to the appliance. These are indicated in the text by the following two conventions:

WARNING: Danger to the person!

IMPORTANT: Damage to the appliance!

In addition, we offer the following safety advice.

Location

- This appliance is intended to be used in household and similar applications such as:
farm houses;
by clients in hotels, motels and other residential type environments;
bed and breakfast type environments.
It is not suitable for use in staff kitchen areas in shops, offices and other working environments.
- Remove all the packaging and retain for future reference.
- Ensure the coffee maker is used on a firm, flat surface.
- Do not use the coffee maker outdoors or near water.
- Do not place the coffee maker on a highly polished wooden surface as damage may occur to the surface.
- Do not place the coffee maker on or near hot surfaces such as a hot plate, radiant rings or near a naked flame.
- **WARNING:** Do not place the coffee maker onto a metal tray or metal surface whilst in use.

Mains cable

- Do not let the mains cable hang over the edge of the worktop where a child could reach it.
- Do not let the mains cable run across an open space e.g. between a low socket and a table.
- Do not let the mains cable run across a cooker or other hot area which might damage the cable.
- The mains cable should reach from the socket to the base unit without straining the connections.
- If the mains cable is damaged, it must be replaced by the manufacturer, it's service agent or similarly qualified person in order to avoid a hazard.
- Make sure the mains cable does not touch the hot parts of the machine.
- Do not wind the mains cable around the hot appliance or store the appliance until it has fully cooled down.

Personal safety

- Do not fill above the capacity mark of the water level gauge marked on the Water Tank.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning the use of the appliance by a person responsible for their safety.

- Do not move when switched on.
- Never use warm or hot water to fill the Water Tank.
- Do not overfill the Water Tank and Coffee Tank.
- Do not open the Coffee Tank Lid whilst brewing.

Children

- Children do not understand the dangers associated with operating electrical appliances. Never allow children to use this appliance.
- Children should be supervised to ensure that they do not play with the appliance.

Treating scalds

- Run cold water over the affected area immediately. Do not stop to remove clothing, get medical help quickly.

Other safety considerations

- Disconnect the coffee maker from the mains supply when filling, cleaning or not in use.
- When unplugging, turn any control to 'off', then remove the plug from the wall outlet.
- Keep the outside of the coffee maker area clean and dry at all times.
- Do not touch hot surfaces. Always use handles or knobs.
- Do not immerse the coffee maker itself in water and always ensure the electrical connections are kept dry.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner. Ring the helpline number for advice on examination and repair.
- The use of attachments or tools not recommended or sold by Morphy Richards may cause fire, electric shock or injury.
- Do not use the coffee maker for anything other than it's intended purpose.
- **CAUTION:** To prevent damage to the appliance, do not use alkaline cleaning agents when cleaning. Use a soft cloth and mild detergent.

Electrical requirements

Check that the voltage on the rating plate of your appliance corresponds with your house electricity supply which must be A.C. (Alternating Current).

If the socket outlets in your home are not suitable for the plug supplied with this appliance, the plug should be removed and the appropriate one fitted.

WARNING : The plug removed from the mains lead, if severed, must be destroyed, as a plug with a bared flexible cord is hazardous if engaged into a live socket outlet.

Should the fuse in the 13 amp plug require changing, a 13 amp BS1362 fuse must be fitted.

WARNING: This appliance must be earthed.

CM47130 MUK Rev 1 07/11

Registering your 2 year guarantee

Your standard one year guarantee is extended for an additional 12 months when you register the product within 28 days of purchase with Morphy Richards. If you do not register the product with Morphy Richards within 28 days, your product is guaranteed for 1 year. To validate your 2 year guarantee register with us online at www.morphyrichards.co.uk

Or call our customer registration line

UK 0844 871 0962

IRE 1800 409 119

N.B. Each qualifying product needs to be registered with Morphy Richards individually.

Please note that the 2 year guarantee is only available in the UK and Ireland. Please refer to the one year guarantee for more information.

Your 1 year guarantee

It is important to retain the retailer's receipt as proof of purchase. Staple your receipt to this back cover for future reference.

Please quote the following information if the product develops a fault. These numbers can be found on the base of the product.

Model no.

Serial no.

All Morphy Richards products are individually tested before leaving the factory. In the unlikely event of any appliance proving to be faulty within 28 days of purchase, it should be returned to the place of purchase for it to be replaced.

If the fault develops after 28 days and within 12 months of original purchase, you should contact the Helpline number quoting Model number and Serial number on the product, or write to Morphy Richards at the address shown.

You may be asked to return a copy of proof of purchase.

Subject to the exclusions set out below (see Exclusions), the faulty appliance will then be repaired or replaced as appropriate and dispatched usually within 7 working days of receipt.

If, for any reason, this item is replaced or repaired during the 1 year guarantee period, the guarantee on the new item will be calculated from original purchase date. Therefore it is vital to retain your original till receipt or invoice to indicate the date of initial purchase.

To qualify for the 1 year guarantee, the appliance must have been used according to the instructions supplied. For example, crumb trays should have been emptied regularly.

Exclusions

Morphy Richards shall not be liable to replace or repair the goods under the terms of the guarantee where:

- 1 The fault has been caused or is attributable to accidental use, misuse, negligent use or used contrary to the manufacturer's recommendations or where the fault has been caused by power surges or damage caused in transit.
 - 2 The appliance has been used on a voltage supply other than that stamped on the products.
 - 3 Repairs have been attempted by persons other than our service staff (or authorised dealer).
 - 4 The appliance has been used for hire purposes or non domestic use.
 - 5 The appliance is second hand.
 - 6 Morphy Richards reserves the right not to carry out any type of servicing under the guarantee at its discretion
 - 7 Plastic filters for all Morphy Richards kettles and coffee makers are not covered by the guarantee.
 - 8 Batteries and damage from leakage are not covered by the guarantee.
- This guarantee does not confer any rights other than those expressly set out above and does not cover any claims for consequential loss or damage. This guarantee is offered as an additional benefit and does not affect your statutory rights as a consumer. Morphy Richards products are intended for household use only. See usage limitations within the location safety instructions.

Disclaimer

Morphy Richards has a policy of continuous improvement in product quality and design. The company, therefore reserves the right to change the specification of its models at any time.



For electrical products sold within the European Community. At the end of the electrical products useful life, it should not be disposed of with household waste.

Please recycle where facilities exist. Check with your Local Authority or retailer for recycling advice in your country

**IF YOU ARE HAVING A PROBLEM
WITH ONE OF OUR PRODUCTS, CALL
OUR HELPLINE:**

**UK: 0844 871 0960
EIRE: 1800 409 119
SPARES: 0844 873 0726**

morphy richards

The After Sales Division
Morphy Richards Ltd
Mexborough, South Yorkshire,
England, S64 8AJ

Helplines (office hours)
UK 0844 871 0960
Spare Parts 0844 873 0726
Republic of Ireland 1800 409 119
www.morphyrichards.com

