



AmebaD Amazon FreeRTOS Getting Started Guide



Realtek Semiconductor Corp.

No. 2, Innovation Road II, Hsinchu Science Park, Hsinchu 300, Taiwan

Tel.: +886-3-578-0211. Fax: +886-3-577-6047

www.realtek.com

COPYRIGHT

©2019 Realtek Semiconductor Corp. All rights reserved. No part of this document may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language in any form or by any means without the written permission of Realtek Semiconductor Corp.

DISCLAIMER

Please Read Carefully:

Realtek Semiconductor Corp., (Realtek) reserves the right to make corrections, enhancements, improvements and other changes to its products and services. Buyers should obtain the latest relevant information before placing orders and should verify that such information is current and complete.

Reproduction of significant portions in Realtek data sheets is permissible only if reproduction is without alteration and is accompanied by all associated warranties, conditions, limitations, and notices. Realtek is not responsible or liable for such reproduced documentation. Information of third parties may be subject to additional restrictions.

Buyers and others who are developing systems that incorporate Realtek products (collectively, "Customers") understand and agree that Customers remain responsible for using their independent analysis, evaluation and judgment in designing their applications and that Customers have full and exclusive responsibility to assure the safety of Customers' applications and compliance of their applications (and of all Realtek products used in or for Customers' applications) with all applicable regulations, laws and other applicable requirements. Designer represents that, with respect to their applications, Customer has all the necessary expertise to create and implement safeguards that (1) anticipate dangerous consequences of failures, (2) monitor failures and their consequences, and (3) lessen the likelihood of failures that might cause harm and take appropriate actions. Customer agrees that prior to using or distributing any applications that include Realtek products, Customer will thoroughly test such applications and the functionality of such Realtek products as used in such applications.

Realtek's provision of technical, application or other design advice, quality characterization, reliability data or other services or information, including, but not limited to, reference designs and materials relating to evaluation kits, (collectively, "Resources") are intended to assist designers who are developing applications that incorporate Realtek products; by downloading, accessing or using Realtek's Resources in any way, Customer (individually or, if Customer is acting on behalf of a company, Customer's company) agrees to use any particular Realtek Resources solely for this purpose and subject to the terms of this Notice.

Realtek's provision of Realtek Resources does not expand or otherwise alter Realtek's applicable published warranties or warranty disclaimers for Realtek's products, and no additional obligations or liabilities arise from Realtek providing such Realtek Resources. Realtek reserves the right to make corrections, enhancements, improvements and other changes to its Realtek Resources. Realtek has not conducted any testing other than that specifically described in the published documentation for a particular Realtek Resource.

Customer is authorized to use, copy and modify any individual Realtek Resource only in connection with the development of applications that include the Realtek product(s) identified in such Realtek Resource. No other license, express or implied, by estoppel or otherwise to any other Realtek intellectual property right, and no license to any technology or intellectual property right of Realtek or any third party is granted herein, including but not limited to any patent right, copyright, mask work right, or other intellectual property right relating to any combination, machine, or process in which Realtek products or services are used. Information regarding or referencing third-party products or services does not constitute a license to use such products or services, or a warranty or endorsement thereof. Use of Realtek Resources may require a license from a third party under the patents or other intellectual property of the third party, or a license from Realtek under the patents or other Realtek's intellectual property.

Realtek's Resources are provided "as is" and with all faults. Realtek disclaims all other warranties or representations, express or implied, regarding resources or use thereof, including but not limited to accuracy or completeness, title, any epidemic failure warranty and any implied warranties of merchantability, fitness for a particular purpose, and non-infringement of any third party intellectual property rights.

Realtek shall not be liable for and shall not defend or indemnify Customer against any claim, including but not limited to any infringement claim that related to or is based on any combination of products even if described in Realtek Resources or otherwise. In no event shall Realtek be liable for any actual, direct, special, collateral, indirect, punitive, incidental, consequential or exemplary damages in connection with or arising out of Realtek's Resources or use thereof, and regardless of whether Realtek has been advised of the possibility of such damages. Realtek is not responsible for any failure to meet such industry standard requirements.

Where Realtek specifically promotes products as facilitating functional safety or as compliant with industry functional safety standards, such products are intended to help enable customers to design and create their own applications that meet applicable functional safety standards and requirements. Using products in an application does not by itself establish any safety features in the application. Customers must ensure compliance with safety-related requirements and standards applicable to their applications. Designer may not use any Realtek products in life-critical medical equipment unless authorized officers of the parties have executed a special contract specifically governing such use. Life-critical medical equipment is medical equipment where failure of such equipment would cause serious bodily injury or death. Such equipment includes, without limitation, all medical devices identified by the U.S.FDA as Class III devices and equivalent classifications outside the U.S.

Customers agree that it has the necessary expertise to select the product with the appropriate qualification designation for their applications and that proper product selection is at Customers' own risk. Customers are solely responsible for compliance with all legal and regulatory requirements in connection with such selection.

Customer will fully indemnify Realtek and its representatives against any damages, costs, losses, and/or liabilities arising out of Designer's non-compliance with the terms and provisions of this Notice.

TRADEMARKS

Realtek is a trademark of Realtek Semiconductor Corporation. Other names mentioned in this document are trademarks/registered trademarks of their respective owners.


USING THIS DOCUMENT


Though every effort has been made to ensure that this document is current and accurate, more information may have become available subsequent to the production of this guide.

1 Configure AWS IoT Core

1.1 Create a New Device

To create a new device, navigate to Manage -> Things in the left-hand navigation menu. Then click “Register a thing”.





Creating AWS IoT things

An IoT thing is a representation and record of your physical device in the cloud. Any physical device needs a thing record in order to work with AWS IoT. [Learn more.](#)

Register a single AWS IoT thing
Create a thing in your registry


Create a single thing

Bulk register many AWS IoT things
Create things in your registry for a large number of devices already using AWS IoT, or register devices so they are ready to connect to AWS IoT.

Create many things

Cancel **Create a single thing**

Then, name the new device. This example uses the name TestDevice.



CREATE A THING STEP 1/5

Add your device to the thing registry

This step creates an entry in the thing registry and a thing shadow for your device.

Name
TestDevice

Apply a type to this thing
Using a thing type simplifies device management by providing consistent registry data for things that share a type. Types provide things with a common set of attributes, which describe the identity and capabilities of your device, and a description.

Thing Type
No type selected **Create a type**

Add this thing to a group
Adding your thing to a group allows you to manage devices remotely using Jobs.

Thing Group
Groups / **Create group** **Change**

Set searchable thing attributes (optional)
Enter a value for one or more of these attributes so that you can search for your things in the registry.


Attribute key
Provide an attribute key, e.g. Manufacturer

Value
Provide an attribute value, e.g. Acme-Corporatio **Clear**


Add another

Show thing shadow

Cancel **Back** **Next**




Download the certificate, public key, and private key for the device by clicking Download. Once all the certificate and keys have been downloaded, click Activate. Finally, click Done




1.2 Create a policy

A policy defines a device's access permissions to IoT Core. To create a policy, navigate to Secure -> Policies. Then click "Create a policy"




This policy should be used for testing only. A policy used in production should only allow topics required by the application.






1.3 Attach Policy to Test Device

The last step to configuring the device is attaching a policy. To attach a policy to new device, navigate to Manage -> Things. Then click on the device which was created.



Click Security, then click the certificate create in previous step.






2 Configure AmebaD Amazon FreeRTOS

2.1 Download Source Code from github

Open source link: https://github.com/ambiot/ambd_amazon-freertos



ambiot/ambd_amazon-freertos

Watch 2 Star 0 Fork 0

Code Issues Pull requests Actions Projects Security Insights

Join GitHub today

GitHub is home to over 50 million developers working together to host and review code, manage projects, and build software together.

Sign up

master 1 branch 0 tags

Go to file Code

hank.su Update Getting Started Guide 98afb29 10 days ago 12 commits

File/Folder	Description	Last Commit
demos	Support amazon-freertos with AmebaD RTL8722DM	last month
doc	Support amazon-freertos with AmebaD RTL8722DM	last month
freertos_kernel	Support amazon-freertos with AmebaD RTL8722DM	last month
libraries	Support amazon-freertos with AmebaD RTL8722DM	last month
projects/realtek/amebaD/IAR	Refine sample_device_tester_configs	20 days ago
tests	Support amazon-freertos with AmebaD RTL8722DM	last month
tools	Support amazon-freertos with AmebaD RTL8722DM	last month
vendors	Refine sample_device_tester_configs	20 days ago
.gitignore	Support amazon-freertos with AmebaD RTL8722DM	last month
AmebaD_Amazon_FreeRTOS_Getting_...	Update Getting Started Guide	10 days ago
CHANGELOG.md	Support amazon-freertos with AmebaD RTL8722DM	last month
CMakeLists.txt	Support amazon-freertos with AmebaD RTL8722DM	last month
CODE_OF_CONDUCT.md	Support amazon-freertos with AmebaD RTL8722DM	last month

About

Support amazon-freertos with AmebaD RTL8722DM

Readme

MIT License


Releases

No releases published

Languages

C 75.8% C++ 13.5% Objective-C 3.8% Assembly 3.0% Python 2.6% CMake 0.8% Other 0.5%

2.2 Get Broker Endpoint by AWS IoT Core



Settings

Custom endpoint ENABLED

This is your custom endpoint that allows you to connect to AWS IoT. Each of your Things has a REST API available at this endpoint. This is also an important property to insert when using an MQTT client or the [AWS IoT Device SDK](#). Your endpoint is provisioned and ready to use. You can now start to publish and subscribe to topics.

Endpoint: **Broker Endpoint**

Logs DISABLED

You can enable AWS IoT to log helpful information to CloudWatch Logs. As messages from your devices pass through the message broker and the rules engine, AWS IoT logs process events which can be helpful in troubleshooting.

Role

Level of verbosity
Disabled


[Edit](#)

Event-based messages DISABLED

AWS IoT can send event-based messages to pre-determined MQTT topics when specific service events occur.

Event	Publish to MQTT	MQTT topic	Subscribe all
Job: completed, canceled	Disabled	Copy topic	Subscribe
Job execution: success, failed, rejected, canceled, removed	Disabled	Copy topic	Subscribe
Thing: created, updated, deleted	Disabled	Copy topic	Subscribe
Thing group: created, updated, deleted	Disabled	Copy topic	Subscribe
Thing group membership: added, removed	Disabled	Copy topic	Subscribe

2.3 Get Thing Name



Things

Search things [Fleet Indexing](#)

TestDevice **Thing Name**
NO TYPE

2.4 Setup IoT Core Information with AmebaD Amazon FreeRTOS

Setup BROKER_ENDPOINT, THING_NAME, WIFI_SSID, PASSWORD in “amdb_amazon-freertos/blob/master/demos/include/aws_clientcredential.h”

```

#define clientcredentialMQTT_BROKER_ENDPOINT      "xxxxxxxxxxxxx.amazonaws.com"
/*
 * @brief Host name.
 * @todo Set this to the unique name of your IoT Thing.
 */
#define clientcredentialIOT_THING_NAME           "TestDevice"
/*
 * @brief Port number the MQTT broker is using.
 */
#define clientcredentialMQTT_BROKER_PORT         8883
/*
 * @brief Port number the Green Grass Discovery use for JSON retrieval from cloud is using.
 */
#define clientcredentialGREENGRASS_DISCOVERY_PORT 8443
/*
 * @brief Wi-Fi network to join.
 * @todo If you are using Wi-Fi, set this to your network name.
 */
#define clientcredentialWIFI_SSID                "TestAP"
/*
 * @brief Password needed to join Wi-Fi network.
 * @todo If you are using WPA, set this to your network password.
 */
#define clientcredentialWIFI_PASSWORD            "password"
/*
 * @brief Wi-Fi network security type.
 *
 * @see WIFISecurity_t.
 *
 * @note Possible values are eWiFiSecurityOpen, eWiFiSecurityWEP, eWiFiSecurityWPA,
 * eWiFiSecurityWPA2 (depending on the support of your device Wi-Fi radio).
 */
#define clientcredentialWIFI_SECURITY            eWiFiSecurityWPA2
#endif /* ifndef __AWS_CLIENTCREDENTIAL_H__ */

```

2.4.1 Setup Thing's Private Key and Certificate

Filled keyCLIENT_CERTIFICATE_PEM and keyCLIENT_PRIVATE_KEY_PEM in “amdb_amazon-freertos/blob/master/demos/include/aws_clientcredential_keys.h” by xxxxxxxx-certifiacte.pem and xxxxxxxx-private.pem.key.

Certificate created!

Download these files and save them in a safe place. Certificates can be retrieved at any time, but the private and public keys cannot be retrieved after you close this page.

In order to connect a device, you need to download the following:

A certificate for this thing	<u>28f51b14e8.cert.pem</u>	Download
A public key	28f51b14e8.public.key	Download
A private key	<u>28f51b14e8.private.key</u>	Download

You also need to download a root CA for AWS IoT:
A root CA for AWS IoT [Download](#)

[Activate](#)

It can done by amdb_amazon-freertos/tools/certificate_configuration/CertificateConfigurator.html

Certificate Configuration Tool

FreeRTOS Developer Demos

Provide client certificate and private key PEM files downloaded from the AWS IoT Console.

Certificate PEM file:

選擇檔案 未選擇任何檔案

Private Key PEM file:

選擇檔案 未選擇任何檔案

⬇️ Generate and save `aws_clientcredential_keys.h`

 Save the generated header file to the `demos/common/include` folder of the demo project.

Copyright (C) 2017 Amazon.com, Inc. or its affiliates. All Rights Reserved.

Final aws_clientcredential_keys.h overview.

[illegible]

2.4.2 Enable FreeRTOS demo on AmebaD

Find platform_opts.h in ambd_amazon-freertos\vendors\realtek\boards\amebaD\aws_demos\config_files and enable **CONFIG_EXAMPLE_AMAZON_FREERTOS**

```
/* For Amazon FreeRTOS SDK example */
#define CONFIG_EXAMPLE_AMAZON_FREERTOS 1
```

Find aws_demo_config.h in ambd_amazon-freertos\vendors\realtek\boards\amebaD\aws_demos\config_files and add **CONFIG_MQTT_DEMO_ENABLED**

```
/* To run a particular demo you need to define one of these.
 * Only one demo can be configured at a time
 *
 * CONFIG_MQTT_DEMO_ENABLED
 * CONFIG_SHADOW_DEMO_ENABLED
 * CONFIG_OTA_UPDATE_DEMO_ENABLED
 *
 * These defines are used in iot_demo_runner.h for demo selection */
#define CONFIG_MQTT_DEMO_ENABLED
```

Now you can start to compile AmebaD Amazon FreeRTOS

3 Compile AmebaD Amazon FreeRTOS

3.1 IAR Build Environment Setup

Currently the amazon-freertos of AmebaD supported by the IAR Embedded workbench ver.8.30.1. For windows operating system only. This chapter illustrates how to setup IAR development environment for Realtek Ameba-D SDK, including building projects and downloading images.

3.2 Pre-Requisite

- Required source code. (https://github.com/ambiot/ambd_amazon-freertos)
- AmebaD Demo board
- Realtek Image Tool
- IAR Embedded Workbench ver.8.30.1

IAR provides an IDE environment for code building, downloading, and debugging. Check “IAR Embedded Workbench” on <http://www.iar.com/>, and a trial version is available for 30 days.

Note: To support ARMv8-M with Security Extension (Ameba-D HS CPU, also called KM4), IAR version must be 8.30 or higher.

3.3 How to Use IAR SDK

3.3.1 IAR Project Introduction

Because Ameba-D is a dual-core CPU platform, two workspaces provided to build for each core in **ambd_amazon-freertos\projects\realtek\amebaD\IAR\aws_demos**

- Project_lp_release.eww (KM0 workspace) contains the following projects:
 - km0_bootloader
 - km0_application
- Project_hp_release.eww (KM4 workspace) contains the following projects:
 - km4_bootloader
 - km4_application

3.3.2 IAR Build

When building SDK for the first time, you should build both KM0 project and KM4 project. Other times, you only need to rebuild the modified project.

3.3.2.1 Building KM0 Project

The following steps show how to build KM0 project:

- (1) Open **ambd_amazon-freertos\projects\realtek\amebaD\IAR\aws_demos\Project_lp_release.eww**.
- (2) Make sure km0_bootloader and km0_application are in Workspace. Click **Project > Options, General Options > Target > Processor Variant > Core**, verify the CPU configurations according to Fig 3-1.
- (3) Right click the project and choose “Rebuild All”, as Fig 3-2 shows. The km0_bootloader and km0_application should compile in order.




Fig 3-1 KM0 processor options




Fig 3-2 Building KM0 project

Note: After building each project, IAR will pop up a command prompt window to execute post-build action to generate images from executable files. This may takes several seconds. Do not stop it while it is in progress. After post-build action is completed, the window would disappear automatically.

```

C:\Windows\System32\cmd.exe
D:\Code\AmebaD\03_0903\project\realtek_amebaD_va0_example\EWARM-RELEASE>cmd /c
""D:\Code\AmebaD\03_0903\project\realtek_amebaD_va0_example\EWARM-RELEASE""\..\
..\component\soc\realtek\amebaD_misc\iar_utility\common\tools\nm Debug/Exe/km0
_image/km0_application.axf ! "D:\Code\AmebaD\03_0903\project\realtek_amebaD_va0
_example\EWARM-RELEASE""\..\..\component\soc\realtek\amebaD_misc\iar_utility\c
ommon\tools\sort > Debug/Exe/km0_image/km0_application.map"

D:\Code\AmebaD\03_0903\project\realtek_amebaD_va0_example\EWARM-RELEASE>cmd /c
""D:\Code\AmebaD\03_0903\project\realtek_amebaD_va0_example\EWARM-RELEASE""\..\
..\component\soc\realtek\amebaD_misc\iar_utility\common\tools\objdump -d Debug
/Exe/km0_image/km0_application.axf > Debug/Exe/km0_image/km0_application.asm"

D:\Code\AmebaD\03_0903\project\realtek_amebaD_va0_example\EWARM-RELEASE>for /P
"delims=" %i in ('cmd /c ""D:\Code\AmebaD\03_0903\project\realtek_amebaD_va0_ex
ample\EWARM-RELEASE""\..\..\component\soc\realtek\amebaD_misc\iar_utility\comm
on\tools\grep IMAGE2 Debug/Exe/km0_image/km0_application.map ! "D:\Code\AmebaD\0
3_0903\project\realtek_amebaD_va0_example\EWARM-RELEASE""\..\..\component\soc
\realtek\amebaD_misc\iar_utility\common\tools\grep Base ! "D:\Code\AmebaD\03_09
03\project\realtek_amebaD_va0_example\EWARM-RELEASE""\..\..\component\soc\real
tek\amebaD_misc\iar_utility\common\tools\gawk '{print $1}'"') do set ran2_start=
%xi

```

- (4) After compile, the images km0_boot_all.bin and km0_image2_all.bin can be find in **amdb_amazon-freertos\projects\realtek\amebaD\IAR\aws_demos\Debug\Exe\km0_image**.

3.3.2.2 Building KM4 Project

The following steps show how to build KM4 project:

- (1) Open **amdb_amazon-freertos\projects\realtek\amebaD\IAR\aws_demos\Project_hp_release.eww**.
- (2) Refer to 3.3.1 and choose the build configurations for each project according to your application.
- (3) Click **Project > Options, General Options > Target > Processor Variant > Core**, verify the CPU configurations according to Fig 3-3.




Fig 3-3 KM4 processor options

- (4) Right click the project and choose "Rebuild All", as Fig 3-4 shows. The km4_bootloader, km4_application should compile in order.





Fig 3-4 Building KM4 project

Note:

- After building each project, IAR will pop up a command prompt window shown in bellow to execute post-build action to generate images from executable files. This may takes several seconds. Do not stop it while it is in progress. After post-build action is completed, the window would disappear automatically.



- After compile, the images km4_boot_all.bin and km0_km4_image2.bin can be find in **ambd_amazon-freertos\projects\realtek\amebaD\IAR\aws_demos\Debug\Exe\km4_image**.
- The generated images can be downloaded to flash by ImageTool:

4 ImageTool

The tool can be find in ambd_amazon-freertos\vendors\realtek\tools\ameba-image-Tool-v2.4.1\

4.1 Introduction

This chapter introduces how to use ImageTool to encrypt, generate and download images. As show in Fig 4-1, ImageTool has four tabpages.

- Download: used as image download server to transmit images to Ameba through UART.




Fig 4-1 ImageTool UI

4.2 Environment Setup

4.2.1 Hardware Setup

The hardware setup is shown in Fig 4-2.

Note: If using external UART to download images, FT232 USB to UART dongle must be used.




Fig 4-2 Hardware setup

4.2.2 Software Setup

- Environment Requirements: EX. WinXP, Win 7 Above, Microsoft .NET Framework 3.5
- ImageTool.exe Location: **vendors\realtek\tools\ameba-image-Tool-v2.4.1\ImageTool.exe**

Name	Date modified	Type	Size
ChangeLog.txt	7/29/2019 11:52 AM	Text Document	4 KB
Download.ini	11/4/2019 5:44 PM	Configuration sett...	2 KB
Encrypt.ini	11/4/2019 5:44 PM	Configuration sett...	1 KB
ImageTool.exe	7/29/2019 11:52 AM	Application	282 KB
ImageTool.pdb	7/29/2019 11:52 AM	VisualStudio.pdb....	178 KB
ImageTool.vshost.exe	8/20/2018 1:41 PM	Application	14 KB
ImageTool.vshost.exe.manifest	8/20/2018 1:41 PM	MANIFEST File	1 KB
imgtool_flashloader_amebad.bin	6/6/2019 3:15 PM	BIN File	5 KB
imgtool_flashloader_amebaz.bin	6/6/2019 3:15 PM	BIN File	6 KB
SB.exe	8/20/2018 1:41 PM	Application	189 KB
system.bin	8/6/2019 9:53 AM	BIN File	4 KB
TestListView.dll	8/20/2018 1:41 PM	Application extens...	5 KB
TestListView.pdb	8/20/2018 1:41 PM	VisualStudio.pdb....	14 KB

4.3 Download

4.3.1 Image Download

Assuming that the ImageTool on PC is a server, it sends images files to Ameba (client) through UART. There are two ways to download images to board.

4.3.1.1 Based on Hardware Reset

The way based on hardware reset is a manual method to download images, and it is the primary and recommended method.

- Enter into UART_DOWNLOAD mode.
 - Push the **UART DOWNLOAD** button and keep it pressed.
 - Re-power on the board or press the **Reset** button.
 - Release the **UART DOWNLOAD** button.

Now, Ameba board gets into UART_DOWNLOAD mode and is ready to receive data.
- Click **Chip Select** (in red) on UI and select chip (AmebaD).
- Select the corresponding serial port and transmission baud rate. The default baud rate is 1.5Mbps (recommended).
- Click the **Browse** button to select the images (**km0_boot_all.bin/km4_boot_all.bin/km0_km4_image2.bin**) to be programmed and input addresses.
 - The image path is located in **{path}\projects\realtek\amebaD\IAR\aws_demos\Debug\Exe\km0_image** and **{path}\projects\realtek\amebaD\IAR\aws_demos\Debug\Exe\km4_image**, where **{path}** is the location of the project on your own computer.
 - The default target address is the SDK default image address, you can use it directly.

- (5) Click **Download** button to start. The progress bar will show the transmit progress of each image. You can also get the message of operation successfully or errors from the log window.




Fig 4-3 ImageTool 'Download' tabpage setting

5 MQTT Demo

5.1 Get Device Log

Install Tera Term to get device log





Fig 5-1 Hardware setup

The serial port is same with ImageTool that get from 3.3.1.1 step (3).



5.2 Run MQTT Demo

Default setting of SDK are enable MQTT demo. Once the AmebaD EVB has rebooted, the application will automatically start run MQTT demo and communicate to IoT Core.

```

COM6 - Tera Term VT
File Edit Setup Control Window Help
#calibration_ok:[2:19:11]
#interface 0 is initialized
interface 1 is initialized

Initializing WIFI ...
WIFI is not running
WIFI initialized

init_thread(58), Available heap 0x24ac0
0 56 [example_a] Wi-Fi module initialized. Connecting to AP...
WIFI is already running
Joining BSS by SSID RealEZ-2.4G...

RTL8721D[Driver]: set ssid [RealEZ-2.4G]

RTL8721D[Driver]: rtw_set_wpa_ie[1136]: AuthKeyMgmt = 0x2

RTL8721D[Driver]: rtw_restruct_sec_ie[3763]: no pmksa cached

RTL8721D[Driver]: start auth to 80:2a:a8:d4:93:c4

RTL8721D[Driver]: auth alg = 2

RTL8721D[Driver]:
OnAuthClient:alghth = 0, seq = 2, status = 0, sae_msg_len = 0

RTL8721D[Driver]: auth success, start assoc

RTL8721D[Driver]: association success(res=4)
wlan1: 1 DL RSVD page success! DLBcnCount:01, poll:00000001

RTL8721D[Driver]: ClientSendEAPOL[1522]: no use cache pmksa

RTL8721D[Driver]: set pairwise key to hw: alg:4(WEP40-1 WEP104-5 TKIP-2 AES-4)

RTL8721D[Driver]: set group key to hw: alg:4(WEP40-1 WEP104-5 TKIP-2 AES-4) keyid:2

1 8000 [example_a] Wi-Fi Connected to AP. Creating tasks which use network...
2 8007 [example_a] IP Address acquired 192.168.89.151
3 8019 [example_a] Write certificate...
4 8080 [iot_threa] [INFO ][DEMO][8079] -----STARTING DEMO-----
5 8086 [iot_threa] [INFO ][INIT][8086] SDK successfully initialized.

```

```

6 15504 [iot_threa] [INFO ][DEMO][15504] Successfully initialized the demo. Network type for the demo: 1
7 15513 [iot_threa] [INFO ][MQTT][15513] MQTT library successfully initialized.
8 15522 [iot_threa] [INFO ][DEMO][15522] MQTT demo client identifier is ameba-ota (length 9).
9 17272 [iot_threa] [INFO ][MQTT][17272] Establishing new MQTT connection.
Interface 0 IP address : 192.168.89.15110 17283 [iot_threa] [INFO ][MQTT][17283] Anonymous metrics (SDK language, SDK version) will be provided to AWS IoT. Reconnil
e with AWS_IOT_MQTT_ENABLE_METRICS set to 0 to disable.
11 17302 [iot_threa] [INFO ][MQTT][17302] (MQTT connection 100337e0, CONNECT operation 100339a0) Waiting for operation completion.
12 17421 [iot_threa] [INFO ][MQTT][17421] (MQTT connection 100337e0, CONNECT operation 100339a0) Wait complete with result SUCCESS.
13 17433 [iot_threa] [INFO ][MQTT][17433] New MQTT connection 100381d0 established.
14 17443 [iot_threa] [INFO ][MQTT][17443] (MQTT connection 100337e0) SUBSCRIBE operation scheduled.
15 17452 [iot_threa] [INFO ][MQTT][17452] (MQTT connection 100337e0, SUBSCRIBE operation 100339e0) Waiting for operation completion.
16 17612 [iot_threa] [INFO ][MQTT][17612] (MQTT connection 100337e0, SUBSCRIBE operation 100339e0) Wait complete with result SUCCESS.
17 17624 [iot_threa] [INFO ][DEMO][17624] All demo topic filter subscriptions accepted.
18 17632 [iot_threa] [INFO ][DEMO][17632] Publishing messages 0 to 1.
19 17640 [iot_threa] [INFO ][MQTT][17640] (MQTT connection 100337e0) MQTT PUBLISH operation queued.
20 17650 [iot_threa] [INFO ][MQTT][17650] (MQTT connection 100337e0) MQTT PUBLISH operation queued.
21 17659 [iot_threa] [INFO ][DEMO][17659] Waiting for 2 publishes to be received.
22 17752 [iot_threa] [INFO ][DEMO][17752] MQTT PUBLISH 0 successfully sent.
23 17784 [iot_threa] [INFO ][DEMO][17784] Incoming PUBLISH received:
Subscription topic filter: iotdemo/topic/1
Publish topic name: iotdemo/topic/1
Publish retain flag: 0
Publish QoS: 1
Publish payload: Hello world 0!
24 17804 [iot_threa] [INFO ][MQTT][17804] (MQTT connection 100337e0) MQTT PUBLISH operation queued.
25 17814 [iot_threa] [INFO ][DEMO][17814] Acknowledgment message for PUBLISH 0 will be sent.
26 17825 [iot_threa] [INFO ][DEMO][17825] MQTT PUBLISH 1 successfully sent.
27 17841 [iot_threa] [INFO ][DEMO][17840] Incoming PUBLISH received:
Subscription topic filter: iotdemo/topic/2
Publish topic name: iotdemo/topic/2
Publish retain flag: 0
Publish QoS: 1
Publish payload: Hello world 1!
28 17861 [iot_threa] [INFO ][MQTT][17861] (MQTT connection 100337e0) MQTT PUBLISH operation queued.
29 17870 [iot_threa] [INFO ][DEMO][17870] Acknowledgment message for PUBLISH 1 will be sent.
30 17883 [iot_threa] [INFO ][DEMO][17883] 2 publishes received.
31 17889 [iot_threa] [INFO ][DEMO][17889] Publishing messages 2 to 3.
32 17897 [iot_threa] [INFO ][MQTT][17897] (MQTT connection 100337e0) MQTT PUBLISH operation queued.
33 17907 [iot_threa] [INFO ][MQTT][17907] (MQTT connection 100337e0) MQTT PUBLISH operation queued.
34 17916 [iot_threa] [INFO ][DEMO][17916] Waiting for 2 publishes to be received.
35 18021 [iot_threa] [INFO ][DEMO][18021] MQTT PUBLISH 3 successfully sent.
36 18030 [iot_threa] [INFO ][DEMO][18029] MQTT PUBLISH 2 successfully sent.
37 18039 [iot_threa] [INFO ][DEMO][18038] Incoming PUBLISH received:
Subscription topic filter: iotdemo/topic/4
Publish topic name: iotdemo/topic/4

```



```

Publish payload: Hello world 16!
132 19827 [iot_threa] [INFO][MQTT][19827] (MQTT connection 100337e0) MQTT PUBLISH operation queued.
133 19837 [iot_threa] [INFO][DEMO][19837] Acknowledgment message for PUBLISH 16 will be sent.
134 19851 [iot_threa] [INFO][DEMO][19851] 2 publishes received.
135 19857 [iot_threa] [INFO][DEMO][19857] Publishing messages 18 to 19.
136 19865 [iot_threa] [INFO][MQTT][19865] (MQTT connection 100337e0) MQTT PUBLISH operation queued.
137 19876 [iot_threa] [INFO][MQTT][19876] (MQTT connection 100337e0) MQTT PUBLISH operation queued.
138 19885 [iot_threa] [INFO][DEMO][19885] Waiting for 2 publishes to be received.
139 19953 [iot_threa] [INFO][DEMO][19953] MQTT PUBLISH 18 successfully sent.
140 19980 [iot_threa] [INFO][DEMO][19980] Incoming PUBLISH received:
Subscription topic filter: iotdemo/topic/3
Publish topic name: iotdemo/topic/3
Publish retain flag: 0
Publish QoS: 1
Publish payload: Hello world 18!
141 20001 [iot_threa] [INFO][MQTT][20001] (MQTT connection 100337e0) MQTT PUBLISH operation queued.
142 20011 [iot_threa] [INFO][DEMO][20011] Acknowledgment message for PUBLISH 18 will be sent.
143 20053 [iot_threa] [INFO][DEMO][20053] MQTT PUBLISH 19 successfully sent.
144 20069 [iot_threa] [INFO][DEMO][20069] Incoming PUBLISH received:
Subscription topic filter: iotdemo/topic/4
Publish topic name: iotdemo/topic/4
Publish retain flag: 0
Publish QoS: 1
Publish payload: Hello world 19!
145 20089 [iot_threa] [INFO][MQTT][20089] (MQTT connection 100337e0) MQTT PUBLISH operation queued.
146 20099 [iot_threa] [INFO][DEMO][20099] Acknowledgment message for PUBLISH 19 will be sent.
147 20108 [iot_threa] [INFO][DEMO][20108] 2 publishes received.
148 20116 [iot_threa] [INFO][MQTT][20116] (MQTT connection 100337e0) UNSUBSCRIBE operation scheduled.
149 20129 [iot_threa] [INFO][MQTT][20128] (MQTT connection 100337e0, UNSUBSCRIBE operation 100339e0) Waiting for operation completion.
150 20322 [iot_threa] [INFO][MQTT][20321] (MQTT connection 100337e0, UNSUBSCRIBE operation 100339e0) Wait complete with result SUCCESS.
151 20335 [iot_threa] [INFO][MQTT][20335] (MQTT connection 100337e0) Disconnecting connection.
152 20347 [iot_threa] [INFO][MQTT][20347] (MQTT connection 100337e0, DISCONNECT operation 100339e0) Waiting for operation completion.
153 20359 [iot_threa] [INFO][MQTT][20359] (MQTT connection 100337e0, DISCONNECT operation 100339e0) Wait complete with result SUCCESS.
154 20371 [iot_threa] [INFO][MQTT][20371] (MQTT connection 100337e0) Connection disconnected.
155 20380 [iot_threa] [INFO][MQTT][20380] (MQTT connection 100337e0) Network connection closed.
156 21622 [iot_threa] [INFO][MQTT][21622] (MQTT connection 100337e0) Network connection destroyed.
157 21631 [iot_threa] [INFO][MQTT][21631] MQTT library cleanup done.
158 21637 [iot_threa] [INFO][DEMO][21637] Demo completed successfully.

lwIP_DHCP: dhcp stop.
Deinitializing WIFI ...
159 21772 [iot_threa] [INFO][INIT][21772] SDK cleanup done.
160 21777 [iot_threa] [INFO][DEMO][21777] -----DEMO FINISHED-----

```

Monitor connection summary.

5.3 Monitoring MQTT messages on the cloud

To subscribe to the MQTT topic with the AWS IoT MQTT client

1. Sign in to the AWS IoT console.
2. In the navigation pane, choose Test to open the MQTT client.
3. In Subscription topic, enter iotdemo/#, and then choose Subscribe to topic.

AWS IoT

Monitor

Onboard

Manage

Greengrass

Secure

Defend

Act

Rules

Destinations

Test

Software

Settings

Learn

MQTT client Info

Connected as iotconsole-1597037785600-0

Subscriptions

Subscribe to a topic

Publish to a topic

Subscribe

Devices publish MQTT messages on topics. You can use this client to subscribe to a topic and receive these messages.

Subscription topic

iotdemo/#

Subscribe to topic

Max message capture Info

100

Quality of Service Info

0 - This client will not acknowledge to the Device Gateway that messages are received

1 - This client will acknowledge to the Device Gateway that messages are received

MQTT payload display

Auto-format JSON payloads (improves readability)

Display payloads as strings (more accurate)

Display raw payloads (in hexadecimal)

Publish

Specify a topic and a message to publish with a QoS of 0.

Specify a topic to publish to, e.g. myTopic/1

Publish to topic

```

1 {
2   "message": "Hello from AWS IoT console"
3 }
```

Getting Started Guide

All information provided in this document is subject to legal disclaimers.

© REALTEK 2020. All rights reserved.

25

AWS IoT

Monitor

Onboard

Manage

Greengrass

Secure

Defend

Act

Rules

Destinations

Test

Software

Settings

Learn

Subscriptions

Subscribe to a topic

Publish to a topic

iotdemo/#

iotdemo/#

1 {

2 "message": "Hello from AWS IoT console"

3 }

iotdemo/acknowledgements

August 10, 2020, 13:41:07 (UTC+0800)

Export Hide

We cannot display the message as JSON, and are instead displaying it as UTF-8 String.

Client has received PUBLISH 6 from server.

iotdemo/acknowledgements

August 10, 2020, 13:41:07 (UTC+0800)

Export Hide

We cannot display the message as JSON, and are instead displaying it as UTF-8 String.

Client has received PUBLISH 7 from server.

iotdemo/topic/2

August 10, 2020, 13:41:07 (UTC+0800)

Export Hide

We cannot display the message as JSON, and are instead displaying it as UTF-8 String.

Hello world 9!

iotdemo/topic/1

August 10, 2020, 13:41:07 (UTC+0800)

Export Hide

6 Demo Board

6.1 AmebaD EVB

Ameba Demo board home page: <https://www.amebaiot.com/amebad/>

Ameba RTL8722DM Board (AMB 21)



[Manual](#) / [Schematic](#) / [Layout](#)

Buy it 

CPU

- 32-bit Arm®Cortex®-M4, up to 200MHz
- 32-bit Arm®Cortex®-M0, up to 20MHz

Memory

- 512KB SRAM + 4MB PSRAM

Key Features

- Integrated 802.11a/n Wi-Fi SoC
- Trustzone-M Security
- Hardware SSL Engine
- Root Trust Secure Boot
- USB Host/Device
- SD Host
- BLE5.0
- Codec
- LCDC
- Key Matrix

Other Features

- 1 PCM interface
- 4 UART interface
- 1 I2S Interface
- 2 I2C interface
- 7 ADC
- 17 PWM
- Max 54 GPIO

6.2 PCB Layout Overview

The PCB layout of 2D and 3D are shown in Fig 6-1 and Fig 6-2.




Fig 6-1 Demo board – PCB layout (2D)




Fig 6-2 Demo board – PCB layout (3D)

6.3 Pin Out

The pin out board is shown in Fig 6-3.




Fig 6-3 Demo board – pin out

There are four rows of pins on the board.

- The pins in the red box are used for Arduino REF.
- The pins in the blue box are all the GPIO pins.

6.4 DC Power Supply

The 3.3V/1.8V power supply board is shown in Fig 6-4.

- Jump JP1 is used to select 3.3V or 1.8V power supply
- Jump J38 is for current test. You can test the current power after taking off the R43.




Fig 6-4 Demo board – 3.3V/1.8V power supply

When you select power supply, refer to Table 6-1.

Table 6-1 3.3V/1.8V power supply selection

6.5 USB Interface Configuration

Diagram illustrating a 7x7 grid with a path of 10 squares highlighted in black. The path starts at (1,1), goes right to (1,3), then down to (3,3), then right to (3,5), then down to (5,5), then right to (5,7), then down to (7,7), then left to (7,5), and finally up to (6,5). The squares (1,1), (1,3), (3,3), (3,5), (5,5), (5,7), (7,7), (7,5), and (6,5) are black. All other squares are white.

For normal GPIO usage by default, R72/R75/R77 on mother board will part on with 0 Ohm resistors, R5 on module board needs to take off. For USB usage, you need to take off R77, part on R73&R74 with 0 Ohm resistors on mother board and part on R5 on module board with a 12K Ohm 1% precision resistor.

6.6 LOGUART

[illegible]

LOGUART Select	JP1
FT232	1-2 connected
DAP	2-3 connected

6.7 SWD

The SWD board is shown in Fig 6-8.




Fig 6-8 Demo board – SWD

Note: For 1V0 board, there is an issue, you should use CLK as DATA, and use DATA as CLK.

6.8 VBAT ADC

The VBAT ADC board is shown in Fig 6-9. J1 is used to test VBAT ADC.



Fig 6-9 Demo board – VBAT ADC