

1. build package

- copy source to the ROS source folder (~/.catkin_ws/src/)
- build

```
cd ~/.catkin_ws
catkin_make
```

2. launch roscore

```
roscore
```

3. set parameters of serial node “rft_sensor_serial”

- set the port, baudrate, force/torque divider value
- ROS parameters of the node should be set to the same value as the set value of the sensor.
(Refer to the sensor's manual for the setting value.)
- If not set, the following values are set as defaults while the node is running. If the default value and the value to be set are the same, there is no need to set the corresponding parameter.
- Parameters and Default value

Parameter	Description	Default value
/RFT_COM_PORT	Name of serial device	/dev/ttyUSB0
/RFT_COM_BAUD	Baud-rate of serial port	115200
/RFT_FORCE_DIVIDER	Force divider	50
/RFT_TORQUE_DIVIDER	Torque divider	2000

-For example, to set the serial port to “/dev/ttyUSB1” and the torque divider to 1000, use the ROS command as follows.

```
rosparam set /RFT_COM_PORT /dev/ttyUSB0
rosparam set /RFT_TORQUE_DIVIDER 1000
```

4. start to run serial node “rft_sensor_serial”

```
roslaunch rft_sensor_serial rft_sensor_serial
```

5. A service caller is needed to send an action command to the sensor. The following is an example of using “rqt_service_caller”.


```
roslaunch rqt_service_caller rqt_service_caller
```

-After setting the command(opType) and parameter values(param1, param2, param3) by referring to the manual, you can control the operation and setting of the sensor by pressing the call button.

- For example,

Command	opType	param1	param2	param3
Start F/T data out	11	DC	DC	DC
Stop F/T data out	12	DC	DC	DC
Set bias	17	1	DC	DC
Set un-biased	17	0	DC	DC

(Note) DC means “Don’t care” → Any value doesn't matter.



6. you can see the force/torque data using `rqt_plot`

```
rqt_plot /RFT_FORCE/wrench/force  
rqt_plot /RFT_FORCE/wrench/torque
```