

### Atmel AT02985: User's Guide for USB-CAN Demo on SAM4E-EK

#### Atmel AVR 32-bit Microcontroller

#### Features

- USB-CAN gateway
  - USB CDC class (virtual serial port) provides low level data stream
  - Customized frame-based USB-CAN communication protocol
- Two-node CAN network on one SAM4E-EK
  - CAN0 node connected to PC utility tool with USB-CAN communication
  - CAN1 node data flow displayed on the on-board touch screen
- PC utility tool monitors CAN bus/node status through CAN0 node
- The touch screen acts as data sink to CAN1 node


#### Description

SAM4E provides two CAN controllers; CAN0 and CAN1, which are fully compliant with CAN 2.0A and 2.0B specification. This demo is developed on SAM4E-EK, using both CAN controllers to establish a simple two-node CAN network on one SAM4E-EK board.

SAM4E-EK acts as the USB-CAN gateway, CAN0 is connected to CAN1 and communicates in CAN protocol and the data transferred/received in CAN0 will be monitored by USB-CAN PC Utility through USB on SAM4E with CDC class (virtual serial port). The PC Utility works together with SAM4E-EK to act as a CAN-bus monitor.

The data transfer in CAN1 is displayed and controlled by the simple UI with the on-board LCD touch screen.

**Figure 1. USB-CAN Demo Functional Diagram.**



# Table of Contents

1. Overview .....	3
1.1 USB-CAN Firmware .....	3
1.1.1 USB-CAN Conversion.....	3
1.1.2 CAN0 Node.....	3
1.1.3 CAN1 Node.....	3
1.2 USB-CAN PC Utility .....	3
2. Demo Setup Procedure .....	6
2.1 Programming Procedure .....	6
2.2 Demo Setup Procedure.....	6
3. USB-CAN Communication Protocol.....	7
4. Revision History .....	9

## 1. Overview

This USB-CAN demo implements a simple USB-CAN gateway and CAN-bus monitor based on SAM4E-EK. A simple two-node CAN network is established to demonstrate how the SAM4E CAN module works. Some simple CAN-bus monitor and control functions are provided by this demo. It can also be used as a PC side debugging tool which will ease CAN-bus based application development.

In this USB-CAN demo, both USB-CAN firmware and USB-CAN PC Utility are provided.

The firmware implements USB-CAN data conversion, CAN0 node, CAN1 node, data sink on the touch screen (with CAN1 node).

The PC Utility implements USB-CAN control/configuration, data sending and status monitor.

### 1.1 USB-CAN Firmware

The USB-CAN firmware is developed based on Atmel® Software Framework (ASF), using USB stack with CDC class, CAN driver, LCD driver, Touch Screen driver etc. The firmware includes USB-CAN data conversion, CAN0 node, CAN1 node (including data sink on the touch screen).

#### 1.1.1 USB-CAN Conversion

USB-CAN conversion is based on SAM4E USB2.0 Full-Speed USB device controller.

A simple customized USB-CAN communication protocol is designed based on the stream data provided by USB CDC class (virtual serial port). About the USB-CAN communication protocol, refer to [Chapter 3 USB-CAN Communication Protocol](#). The transmission speed (baud rate) is mostly determined by USB2.0 Full-Speed.

#### 1.1.2 CAN0 Node

CAN0 node uses CAN0 controller on SAM4E. The node provides the following functions:

- Respond to the command from the PC Utility
- CAN standard frame (CAN 2.0A) transmit and receive
- CAN extended frame (CAN 2.0B) transmit and receive
- CAN0 node and CAN bus error status report

The data transmit on CAN0 node is launched by the PC Utility. The message ID and data are configured by PC Utility. If CAN0 node receives data from CAN1, it reports the received data from CAN1 to the PC Utility.

#### 1.1.3 CAN1 Node

CAN1 node uses CAN1 controller on SAM4E. The node provides the following functions:

- CAN standard frame (CAN 2.0A) transmit and receive
- CAN extended frame (CAN 2.0B) transmit and receive

The data transmit on CAN1 node is launched by the UI on the on-board LCD touch screen of SAM4E-EK.

When the button “STD FRM Tx” or “EXT FRM Tx” button is pressed on the screen, the corresponding standard or extended frame will be sent by CAN1. The message ID and data are pre-determined in SAM4E firmware.

When CAN1 node receives data, the receive counter will be updated on the LCD screen.

### 1.2 USB-CAN PC Utility


The PC software runs in Windows® OS with Microsoft® .NET framework 3.5 or up.

The PC software includes the following functions:

- USB CDC communication with SAM4E-EK

- Start/Stop control of SAM4E CAN0 node
- CAN bus communication configuration: baud rate, receive filter (SAM4E CAN0 node configuration)
- CAN data send (through SAM4E CAN0 node): single send, repeated send
- Monitor CAN bus connected to SAM4E CAN0

**Figure 1-1. USB-CAN PC Utility.**



The tool bar in top lists basic configuration for the USB-CAN demo: COM Port for USB virtual serial port (CommPort), CAN baud rate, and CAN0 node receive filter ID.

- For the “CommPort”, the user should select the COM No. corresponding to the USB CDC virtual serial port. The COM No. can be found in “device manager” in Window OS after PC driver is successfully installed for the SAM4E-EK programmed with USB-CAN firmware
- The CAN baud rate has the unit of kbps, represented by the value with “K” or “k” ending. The Default value is 1000k
- For receive filter, the default is 0x00000000, which can receive any message on the CAN bus

In “Send Data” area,

- Frame Type includes Data Frame and Remote Frame for CAN0 node transmit. In current version, only Data Frame is supported
- Frame Format includes Standard Frame and Extended Frame
- Message ID is the message identifier, 32bit hex unsigned integer. For Standard Frame, MessageID is 11 bits, located at bit28-bit18; for extended frame, MessageID is 29-bits, located at bit28-bit0. Message ID is used in message filtering process by receivers, to determine whether the message should be received
- For single send, set “Send Times” to 1 and “Send Interval” to 0. For repeated send, set “Send Times” and “Send Interval” to the expected times and interval
- In Data textbox, the data that will be sent are displayed here. The data should be in hex format with space between bytes as separator. The send data length is fixed to 8, which is also the maximum possible data length for a CAN frame. If the data count in the Data textbox is less than 8, “00” will be appendixes to make 8 bytes

The list view lists all CAN data transaction through USB-CAN. The information includes transmit/receive (T/R), time stamp, message ID, data, frame type, frame format etc. If the data transmit fails, the corresponding failing data line shows in red and the corresponding CAN bus error label on the left also shows in red.

The CAN bus error includes CRC error, Bit-stuffing error, Bit error, Form error, Acknowledgement error. When error is detected, the corresponding label is highlighted in red.

The CAN0 node error mode including Error Active (ERRA), Error Passive (ERRP), WARN, Bus Off (BOFF), located below the CAN bus error labels. The present mode of CAN0 mode is highlighted in red.

## 2. Demo Setup Procedure

This chapter describes how to program the binary file without recompile the source code and basic operation procedure with the demo.

### 2.1 Programming Procedure

1. Update Segger driver to 4.58. (If the Segger driver version is 4.58 or higher, this step can be over passed.)
2. Install SAM-BA<sup>®</sup> 2.12 or above. Install SAM-BA 2.12 patchsam4e. Copy JLinkARM.dll in the SAM-BA directory.
  - Win 7 C:\Program Files (x86)\Atmel\sam-ba\_2.12\drv
  - Win XP C:\Program Files\Atmel\sam-ba\_2.12\drv
3. Erase chip using jumper JP7 (labeled ERASE) for 15 seconds:
  - a. Unplug the SAM-ICE™.
  - b. Unplug the board power cable.
  - c. Set jumper JP7.
  - d. Plug the board power cable.
  - e. Wait 15s.
  - f. Unplug the board power cable.
  - g. Remove jumper JP7.
4. Connect a SAM-ICE between PC and SAM4E-EK.
5. Plug the board power cable.
6. Open a DOS Shell and run prog\_flash.bat.
7. After programming, unplug the board power cable.


### 2.2 Demo Setup Procedure

1. Connect CAN0 and CAN1 connectors (J13, J14) by a RJ21 cable.
2. Connect USB cable between J11 and a PC USB port.
3. Power up the SAM4E-EK.
4. Install PC driver for SAM4E-EK as a USB CDC device (virtual serial port).
5. Find the COM No. of the virtual serial port in “Device Manager” of Windows OS.
6. Open the USB\_CAN\_Utility\_vx.x.exe.
7. Select the right COM port corresponding to the USB virtual serial port.
8. Select or input CAN bus baud rate.
9. Press confirm button.
10. Press Start button to enable CAN node.
11. Press Send button to send a frame with default frame property and frame data.
12. Check the LCD to see that receive counter increases and received data shows up.
13. Press “EXT FRM Tx” button in the touch LCD to send an extended frame.
14. Check the PC Utility to see an extended frame is received.

### 3. USB-CAN Communication Protocol

USB-CAN demo uses USB CDC class (virtual serial port) to communicate between PC utility and SAM4E-EK. Based on USB CDC data stream, the communication frame format is designed for data transfer and interpreting. The communication is duplex: PC can send commands/data to EK and vice versa.

**Figure 3-1. USB-CAN Communication Frame Format.**



**F\_ID:** Frame Identifier, 1 byte. It has fixed value, 0xFF.

**CMD:** Command code, 1 byte. Its MSB bit (bit 7) stands for transfer direction: 0 means PC to SAM4E-EK; 1 means SAM4E-EK to PC. The command set is listed in later section.

**Data0 – N:** Data area, (N+1) bytes. For different command, the N is possibly different. The parameters necessary to the command can be placed in this data area. In order to simplify the SAM4E command parsing process, the commands from PC to SAM4E-EK have the same data length. Note the (N+1)-byte data length does not includes F\_ID, CMD and CRC field.

**CRC:** CRC8 from F\_ID to Data7. CRC8 generating polynomial is  $X^8+X^5+X^4+1$ . CRC check is not implemented in the current version.

**Table 3-1. USB-CAN Command Set.**

	Name	CMD Code	Data Length (N+1)*	Data	Comment
1	Start CAN	0x01	13		PC -> SAM4E-EK
2	Stop CAN	0x02	13		PC -> SAM4E-EK
3	Baud Rate setting	0x03	13	Data0-1: baud rate Data0: High byte Data1: Low byte	PC -> SAM4E-EK
4	Receive Filter ID setting	0x04	13	Data0-4: Message ID (high byte to low byte)	PC -> SAM4E-EK
5	Send data	0x05	13	Data0-[bit7]: frame format 0 standard frame, 1 extended frame Data0-[bit6]: frame type 0 data frame, (transmit mailbox) 1 remote frame (producer mailbox) Data0- [bit5-0], Data1-3: Message ID Data4-11: CAN send data	PC -> SAM4E-EK
6	Status request	0x06	13		PC -> SAM4E-EK
7	Status data report	0x81	12	Data0-3: active mailbox status (CAN_MSR register) Data4-7: CAN0 status code (CAN_SR register) Data8-11: Error counter (CAN_ECR register)	SAM4E-EK -> PC
8	Data sent notification	0x82	12	Data0-3: active mailbox status (CAN_MSR register) Data4-7: CAN0 status code (CAN_SR register) Data8-11: Error counter (CAN_ECR register)	SAM4E-EK -> PC

	Name	CMD Code	Data Length (N+1)*	Data	Comment
9	Data received report	0x83	14	Data0-[bit7]: frame format 0 standard frame, 1extended frame Data0-[bit6]: frame type 0 data frame (transmitt mailbox), 1 remote frame (producer mailbox) Data0- [bit5-0],Data1-3: Message ID Data4-11: CAN received data Data12-13: Time Stamp	SAM4E-EK -> PC

Note:    \*The data length does not include F\_ID, CMD and CRC.



## 4. Revision History

Doc. Rev.	Date	Comments
32208A	07/2013	Initial document release

**Atmel Corporation**

1600 Technology Drive  
San Jose, CA 95110  
USA

**Tel:** (+1)(408) 441-0311

**Fax:** (+1)(408) 487-2600

[www.atmel.com](http://www.atmel.com)

**Atmel Asia Limited**

Unit 01-5 & 16, 19F  
BEA Tower, Millennium City 5  
418 Kwun Tong Road  
Kwun Tong, Kowloon  
HONG KONG

**Tel:** (+852) 2245-6100

**Fax:** (+852) 2722-1369

**Atmel Munich GmbH**

Business Campus  
Parking 4  
D-85748 Garching b. Munich  
GERMANY

**Tel:** (+49) 89-31970-0

**Fax:** (+49) 89-3194621

**Atmel Japan G.K.**

16F Shin-Osaki Kangyo Building  
1-6-4 Osaki, Shinagawa-ku  
Tokyo 141-0032  
JAPAN

**Tel:** (+81)(3) 6417-0300

**Fax:** (+81)(3) 6417-0370

© 2013 Atmel Corporation. All rights reserved. / Rev.: 32208A-AVR-07/2013

Atmel®, Atmel logo and combinations thereof, AVR®, Enabling Unlimited Possibilities®, SAM-BA®, and others are registered trademarks or trademarks of Atmel Corporation or its subsidiaries. Windows® is a registered trademark of Microsoft Corporation in U.S. and/or other countries. Other terms and product names may be trademarks of others.

Disclaimer: The information in this document is provided in connection with Atmel products. No license, express or implied, by estoppel or otherwise, to any intellectual property right is granted by this document or in connection with the sale of Atmel products. EXCEPT AS SET FORTH IN THE ATMEL TERMS AND CONDITIONS OF SALES LOCATED ON THE ATMEL WEBSITE, ATMEL ASSUMES NO LIABILITY WHATSOEVER AND DISCLAIMS ANY EXPRESS, IMPLIED OR STATUTORY WARRANTY RELATING TO ITS PRODUCTS INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, OR NON-INFRINGEMENT. IN NO EVENT SHALL ATMEL BE LIABLE FOR ANY DIRECT, INDIRECT, CONSEQUENTIAL, PUNITIVE, SPECIAL OR INCIDENTAL DAMAGES (INCLUDING, WITHOUT LIMITATION, DAMAGES FOR LOSS AND PROFITS, BUSINESS INTERRUPTION, OR LOSS OF INFORMATION) ARISING OUT OF THE USE OR INABILITY TO USE THIS DOCUMENT, EVEN IF ATMEL HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. Atmel makes no representations or warranties with respect to the accuracy or completeness of the contents of this document and reserves the right to make changes to specifications and products descriptions at any time without notice. Atmel does not make any commitment to update the information contained herein. Unless specifically provided otherwise, Atmel products are not suitable for, and shall not be used in, automotive applications. Atmel products are not intended, authorized, or warranted for use as components in applications intended to support or sustain life.