

Web iSite User Guide

iDirect® e150 and X1, X7, and X7-ER Satellite Routers

iDX Release 3.3

September 21, 2015



Copyright © 2015, VT iDirect Inc. All rights reserved. Reproduction in whole or in part without permission is prohibited. Information contained herein is subject to change without notice. The specifications and information regarding the products in this document are subject to change without notice. All statements, information and recommendations in this document are believed to be accurate, but are presented without warranty of any kind, express, or implied. Users must take full responsibility for their application of any products. Trademarks, brand names and products mentioned in this document are the property of their respective owners. All such references are used strictly in an editorial fashion with no intent to convey any affiliation with the name or the product's rightful owner.



iDirect®, a subsidiary of VT Systems, is a global leader in IP-based satellite communications providing technology that enables our partners to optimize their networks, differentiate and expand their businesses. The iDirect Intelligent Platform™ allows our partners to run their entire business operations more efficiently via a single, unified IP-based satellite architecture, whether it's providing core IP applications to the enterprise or specialized services to any number of diverse vertical markets. iDirect is the #1 name in global satellite communications in key industries including maritime, military/government, and oil and gas.

Company web site: <http://www.idirect.net> ~ Main Phone: 703.648.8000

TAC Contact Information: Phone: 703.648.8151 ~ Email: tac@idirect.net ~ Web site: <http://tac.idirect.net>



iDirect Government™, created in 2007, is a wholly owned subsidiary of iDirect and was formed to better serve the U.S. government and defense communities.

Company web site: <http://www.idirectgov.com> ~ Main Phone: 703.648.8118

TAC Contact Information: Phone: 703.648.8111 ~ Email: tac@idirectgov.com ~ Web site: <http://tac.idirectgov.com>

Document Name: UG_Web_iSite_User_Guide iDX 3.3_Rev_C.pdf

Document Part Number: T0000607

Revision History

The following table shows all revisions for this document. To determine if this is the latest revision, check the TAC Web. Refer to for [Getting Help on page xiv](#) TAC access information.

Revision	Date	Updates
A	07/31/2014	First release of document for iDX Release 3.3
B, C	09/21/2015	Added X7-ER support for iDX Release 3.3.3.1

Contents

Revision History	iii
Figures	ix
Tables	xii
Chapter 1 Web iSite Overview	1
1.1 Web iSite Overview	1
1.1.1 Web iSite Features	1
1.1.2 Before Accessing the Router	2
1.2 Starting a Web iSite Session	5
1.3 Web iSite User Interface	6
1.3.1 Web iSite Browser Window	7
1.3.2 Navigation Bar	7
1.3.3 Left Navigation Bar	8
1.3.4 Page	8
Chapter 2 Dashboard	15
2.1 Remote Information	16
2.2 Equipment Details	16
2.3 Real-Time Remote Events	18
2.3.1 Real-Time Event Messages	19
Chapter 3 Status Pages	21
3.1 Overview	21

3.2	Modem Status Page	21
3.2.1	Modem Information	22
3.2.2	Modem State	23
3.2.3	Rx State	24
3.2.4	Tx State	25
3.2.5	Geo Location	25
3.3	Ethernet Status Page	25
3.3.1	VLAN Assignments	26
3.3.2	Connection.	27
3.3.3	Transmitter	27
3.3.4	Receiver	28
3.4	IP Configuration Page	28
3.4.1	Eth Interface	30
3.4.2	Sat Interface	30
3.4.3	DHCP	30
3.4.4	DNS	31
3.4.5	Routing	32
3.4.6	Static Routes	32
3.4.7	Multicast Groups	33
3.4.8	Port Forwarding	33
3.5	ODU Status Page	34
3.5.1	Rx Status	34
3.5.2	Tx Status	35
3.6	Real-Time Remote Events Page	35
3.7	Satcom Graphs Page	36
3.7.1	Rx SNR	36
3.7.2	Tx Power	37
3.7.3	Tx Frequency Offset	37
3.7.4	Clock Deviation.	38
Chapter 4	Commissioning Pages	39
4.1	Overview	39

4.2	Downstream Configuration	40
4.2.1	Manual Configuration	40
4.2.2	Configuration From File	42
4.3	Geo Location.	43
4.4	Angle Calculator Page.	44
4.4.1	Remote Location	44
4.4.2	Spacecraft Position	45
4.4.3	Elevation	45
4.4.4	Gross Antenna Pointing.	45
4.5	Antenna Pointing Page	46
4.6	Cross Polarization Test Page	48
4.6.1	Transmit Frequency	49
4.6.2	Transmit Power.	50
4.6.3	Modulator	50
Chapter 5 Admin Pages		51
5.1	Overview	51
5.2	File Management Page	51
5.2.1	Software Loaded	52
5.2.2	Load Package	53
5.2.3	Load Options File	53
5.2.4	Retrieve Options File	54
5.2.5	Restart Device	56
5.2.6	Load Package	56
5.2.7	Load Options File	57
Appendix A Remote Locking for X1 and e150 Satellite Routers		59
A.1	Locking an X1 or e150 Overview	60
A.2	Configuring the Network Key	60
A.3	Performing an Temporary Lock.	60
A.4	Performing a Soft Lock	65
A.5	Performing a Hard Lock.	70
A.6	Non-Warranty RMA Required to Remove Remote Locks	74

Index	75
-------------	----

Figures

Figure 1-1.	Local Area Connection Status Dialog Box	3
Figure 1-2.	Local Area Connection Properties Dialog Box	3
Figure 1-3.	Internet Protocol (TCP/IP) Dialog Box	4
Figure 1-4.	Web iSite Login Dialog	5
Figure 1-5.	Web iSite Default Page	6
Figure 1-6.	Web iSite Browser Tab	7
Figure 1-7.	Main Console Buttons	7
Figure 1-8.	Typical Web iSite Page	8
Figure 1-9.	Modem Status Page with Tx Section Open.	10
Figure 1-10.	Web iSite X1 LED Indicators	11
Figure 1-11.	Web iSite X7 or X7-ER LED Indicators.	12
Figure 2-1.	Dashboard Page	15
Figure 2-2.	Remote Information	16
Figure 2-3.	Equipment Details	17
Figure 2-4.	Real-Time Remote Events	18
Figure 3-1.	Left Navigation Bar Status Page Group.	21
Figure 3-2.	Modem Status	22
Figure 3-3.	Modem Information	22
Figure 3-4.	Modem State.	23
Figure 3-5.	Rx State.	24
Figure 3-6.	Tx State	25
Figure 3-7.	Geo Location	25
Figure 3-8.	Ethernet Status Page (e150 and X1).	26
Figure 3-9.	Ethernet Status Page (X7 or X7-ER)	26
Figure 3-10.	VLAN Assignments	26
Figure 3-11.	Connection	27
Figure 3-12.	Transmitter	27
Figure 3-13.	Receiver	28
Figure 3-14.	IP Configuration Page (e150 and X1)	29
Figure 3-15.	IP Configuration Page (X7 or X7-ER).	29
Figure 3-16.	Eth Interface	30
Figure 3-17.	Sat Interface.	30
Figure 3-18.	DHCP Mode (Disabled)	31
Figure 3-19.	DHCP (Server Mode)	31
Figure 3-20.	DNS (Mode Disabled).	31
Figure 3-21.	DNS (Mode Enabled)	32
Figure 3-22.	Routing	32
Figure 3-23.	Static Routes	33

Figure 3-24.	Multicast Groups	33
Figure 3-25.	Port Forwarding	33
Figure 3-26.	ODU Status	34
Figure 3-27.	Rx Status	34
Figure 3-28.	Tx Status	35
Figure 3-29.	Real-Time Remote Events	35
Figure 3-30.	Satcom Graphs	36
Figure 3-31.	Receiver SNR	37
Figure 3-32.	Tx Power	37
Figure 3-33.	Tx Frequency Offset	37
Figure 3-34.	Clock Deviation	38
Figure 4-1.	Left Navigation Bar Showing Commissioning Page Group	39
Figure 4-2.	Downstream Configuration (Default)	40
Figure 4-3.	Manual Configuration	41
Figure 4-4.	Configuration From File	42
Figure 4-5.	Geo Location	43
Figure 4-6.	Angle Calculator	44
Figure 4-7.	Remote Location	44
Figure 4-8.	Spacecraft Position	45
Figure 4-9.	Elevation	45
Figure 4-10.	Gross Antenna Pointing	46
Figure 4-11.	Antenna Pointing Graph	47
Figure 4-12.	Volts DC and Antenna Status	48
Figure 4-13.	Cross Polarization Test	48
Figure 4-14.	Transmit Frequency (e150 and X1)	49
Figure 4-15.	Transmit Frequency (X7 or X7-ER)	49
Figure 4-16.	Transmit Power	50
Figure 4-17.	Modulator	50
Figure 5-1.	Left Navigation Bar Showing Admin Page Group	51
Figure 5-2.	File Management	52
Figure 5-3.	Software Loaded	53
Figure 5-4.	Load Package	53
Figure 5-5.	Load Options File	54
Figure 5-6.	Retrieve Options File	54
Figure 5-7.	Excerpt from Sample Options File	55
Figure 5-8.	Restart Device	56
Figure 5-9.	Locating the Package File	56
Figure 5-10.	Load Button	56
Figure 5-11.	Load Package Success Message	57
Figure 5-12.	Selecting the Options File	57
Figure 5-13.	Load Button	58

Figure 5-14.	Options file Success Message	58
Figure 5-15.	Restart Button.	58
Figure 5-16.	Restart Prompt	58
Figure A-1.	X1 and e150 Web iSite Login Page.	61
Figure A-2.	Network Lock Page.	61
Figure A-3.	Entering Network Key	62
Figure A-4.	Lock Remote Section	63
Figure A-5.	Entering the Confirmation Word	64
Figure A-6.	Temporarily Locked State	64
Figure A-7.	File Management Default Page	65
Figure A-8.	Restart Dialog Box	65
Figure A-9.	X1 and e150 Web iSite Login Page.	65
Figure A-10.	Network Lock Page.	66
Figure A-11.	Entering Network Key	67
Figure A-12.	Lock Remote Section	68
Figure A-13.	Entering the Confirmation Word	69
Figure A-14.	Soft Locked State	69
Figure A-15.	File Management Default Page	70
Figure A-16.	Restart Dialog Box	70
Figure A-17.	X1 and e150 Web iSite Login Page.	71
Figure A-18.	Network Lock Page.	71
Figure A-19.	Entering the Network Key	72
Figure A-20.	Confirmation Word Text Box	73
Figure A-21.	Lock Status.	74

Tables

Table 1-1.	X1 Router LED Status Indicators	11
Table 1-2.	X7 or X7-ER Router LED Status Indicators	12

About

Purpose

The *Web iSite User Guide* provides instructions for using the Web Interface to the e150 Satellite Router Board (e150), the X1, X7, and X7-ER Remote Satellite Routers.

For information on configuring the e150, X1, X7, and X7-ER Satellite Routers, see the *iBuilder User Guide*. For information on installing and commissioning the e150, X1, X7, and X7-ER Satellite Routers, see the *iDirect Satellite Router Installation and Commissioning Guide*.

Intended Audience

The *Web iSite User Guide* is for iDirect network operators or installers who need to connect directly to an X7-ER, X7, X1 or e150 Satellite Router. This may include installers responsible for remote commissioning; network operators connecting remotely; customers who want to lock their remotes to a network; or on-site personnel working with iDirect to troubleshoot network problems.

Contents of This Guide

This document contains the following major sections:

- [*Web iSite Overview*](#)
- [*Dashboard*](#)
- [*Status Pages*](#)
- [*Commissioning Pages*](#)
- [*Admin Pages*](#)
- [*Remote Locking for X1 and e150 Satellite Routers*](#)

Document Conventions

This section illustrates and describes the conventions used throughout this document.

Convention	Description	Example
Command	Used when the user is required to type a command at a command line prompt or in a console.	Type the command: <code>cd /etc/snmp/</code>
Terminal Output	Used when showing resulting output from a command that was entered at a command line or on a console.	<code>crc report all</code> 8350.3235 : DATA CRC [1] 8350.3502 : DATA CRC [5818] 8350.4382 : DATA CRC [20]
Screen Reference	Used when referring to text that appears on the screen on a Graphical User Interface (GUI). Used when specifying names of commands, menus, folders, tabs, dialogs, list boxes, and options.	1. To add a remote to an inroute group, right-click the Inroute Group and select Add Remote . The Remote dialog box has a number of user-selectable tabs across the top. The Information tab is visible when the dialog box opens.
Hyperlink	Used to show all hyperlinked text within a document or external links such as web page URLs.	For instructions on adding a line card to the network tree, see Adding a Line Card on page 108 .



WARNING: A warning highlights an essential operating or maintenance procedure, practice, condition, or statement which, if not strictly observed, could result in injury, death, or long term health hazards.



CAUTION: A caution highlights an essential operating or maintenance procedure, practice, condition, or statement which, if not strictly observed, could result in damage to, or destruction of, equipment or a condition that adversely affects system operation.



NOTE: A note is a statement or other notification that adds, emphasizes, or clarifies essential information of special importance or interest.

Getting Help

The iDirect Technical Assistance Center (TAC) is available to provide assistance 24 hours a day, 365 days a year. Software user guides, installation procedures, FAQs, and other documents that support iDirect products are available on the TAC Web site. Access the TAC Web site at <http://tac.idirect.net>.

The TAC may also be contacted by telephone or e-mail.

- Telephone: (703) 648-8151
- E-mail: tac@idirect.net

For sales or product purchasing information contact iDirect Corporate Sales at the following telephone number or e-mail address:

- Telephone: (703) 648-8000
- E-mail: sales@idirect.net
- iDirect produces documentation that is technically accurate, easy to use, and helpful to our customers. Please assist us in improving this document by providing feedback. Send comments to techpubs@idirect.net.

Related Documents

The following iDirect documents are available at <http://tac.idirect.net> and may also contain information relevant to this release. Please consult these documents for information about installing and using iDirect's satellite network software and equipment.

- *iBuilder User Guide*
- *iDX Release Notes*
- *iDX Software Installation Guide or Network Upgrade Procedure Guide*
- *iDX iMonitor User Guide*
- *iDX Technical Reference Guide*
- *iDX Installation and Commissioning Guide for Remote Satellite Routers*
- *iDX Features and Chassis Licensing Guide*
- *iDX Software Installation Checklist/Software Upgrade Survey*
- *iDX Link Budget Analysis Guide*
- *X7 Satellite Router Installation, Support, and Maintenance Guide*
- *X1 Satellite Router Installation, Support, and Maintenance Guide*
- *X7-ER Satellite Router Installation, Support, and Maintenance Guide*
- *Evolution® e8350 Satellite Router Installation, Support, and Maintenance Guide*
- *e150 Satellite Router Integration Guide*

1 Web iSite Overview

This chapter provides an introduction of the Web iSite tool for working with iDirect e150, X1, X7, and X7-ER Satellite Routers. It contains the following sections:

- [Web iSite Overview on page 1](#)
- [Starting a Web iSite Session on page 5](#)
- [Web iSite User Interface on page 6](#)

1.1 Web iSite Overview

The Web iSite interface provides users with the means to commission new sites and to monitor TDMA satellite routers from the local area network (LAN) side.

Web iSite also provides configuration and real-time status and statistical information about the e150, X1, X7, or X7-ER Satellite Router units. Web iSite provides interaction with the satellite router, enabling configuration, commissioning, and monitoring without a direct connection with the iDirect NMS. The level of functionality available to the user is determined by the login access (admin or user). iVantage clients and NMS access are required in order to view satellite router historical data. See the *Satellite Router Installation and Commissioning Guide* for specific instructions on commissioning satellite routers.

1.1.1 Web iSite Features

Web iSite provides the following features:

- Real-time satellite router light emitting diode (LED) status indicators
- A dashboard view of high-level satellite router information (for example, if a satellite router is in network or locked to the satellite)
- Status and monitoring views of real-time modem information and events, Ethernet receive and transmit connections, and Internet Protocol (IP) configuration and information
- Satellite router commissioning tools, including tools for lookup angle calculation, antenna pointing, and cross polarization
- Administration tools for loading software packages and options files
- Remote locking for X1 and e150 Satellite Routers
- Downstream configuration for e150, X1, X7, and X7-ER Satellite Routers

1.1.2 Before Accessing the Router

Web iSite may be used at any time to access the e150, X1, X7, or X7-ER Satellite Routers. All that is necessary is the IP address assigned to the satellite router and a physical Ethernet connection to the LAN port.

The default IP address for an e150, X1, X7, or X7-ER Satellite Router is set to 192.168.0.1 when shipped from the factory or when booted into Factory Default Mode; otherwise, the IP address is based on the iBuilder generated options file that was last uploaded to the device. Connection to the e150, X1, X7, or X7-ER Satellite Routers is not possible using the iVantage iSite client.



NOTE: For the X1 and e150, when booting into Factory Default Mode, neither the user software package nor the options files are deleted; however, they are ignored temporarily. When booting back into normal operational mode, the user software package will run and use the setting in the options files. However, for the X7 and X7-ER it is necessary to re-install the software package and the options file.

Default factory settings for the e150, X1, X7, or X7-ER Satellite Routers are shown below:

- LAN IP address: 192.168.0.1
- Subnet mask: 255.255.255.0
- DHCP server: Enabled
- Two configured user accounts: **admin** and **user** (*iDirect* is the password)



NOTE: After an options file has been loaded on the router, the **admin** and **user** passwords, and DHCP configuration change to the values in the options file.

When shipped, the X1, X7, X7-ER, and e150 DHCP servers are enabled to provide a single DHCP address to a computer without modifying the IP address on the local PC. If DHCP is disabled on the satellite router, or if the local PC uses static IP addressing, follow the steps below to reconfigure the local PC's IP settings.

1.1.2.1 Local Area Connection

To connect using the LAN port, the local PC must be in the same subnet as the satellite router. This is done by modifying the TCP properties of the Local Area Connection on the local PC. The following section uses the Windows 7 operating system to illustrate the procedure.

To modify the Local Area Connection:

1. In Control Panel, click on Network Sharing Center.
2. Double-click Local Area Connection to display the Status dialog box.




Figure 1-1. Local Area Connection Status Dialog Box

3. Click on **Properties** to display the **Properties** dialog box.




Figure 1-2. Local Area Connection Properties Dialog Box

4. Highlight **Internet Protocol Version 4 (TCP/IPv4)** as shown in [Figure 1-2](#), and click **Properties**. The properties dialog will appear.




Figure 1-3. Internet Protocol (TCP/IP) Dialog Box

5. Select **Use the following IP address**. Type an IP address that is inside the range specified by the satellite router's IP address and subnet mask. See [Figure 1-3](#).
6. Click in the **Subnet mask** data entry field. The Windows 7 default value will appear automatically. If the satellite router subnet mask is known to be different, type in the correct values.
7. Type the satellite router IP address in the **Default Gateway** field.
8. For a local connection, DNS server addresses are not required. Leave the fields blank.
9. Click **OK** to save the changes.

The local connection is now configured to connect to the satellite router using iSite.

To confirm connectivity:

1. Confirm that power is applied to the satellite router.
2. Connect a LAN cable between the **LAN A** port of the satellite router and the LAN port of the local PC.
3. Open the command prompt on the local PC.
4. Ping the satellite router by entering the following command:
`ping <ip address>`
5. Verify that packets are returned without error.

The local PC is now configured to use iSite for communication over the LAN port.

1.2 Starting a Web iSite Session

Web iSite supports the following browsers:

- Internet Explorer (Version 7 and later)
- Mozilla Firefox (Version 8 and later)
- Google Chrome (Version 16 and later)

Initially, Web iSite has two default user accounts:

- **admin**: Provides full access to Web iSite functionality
- **user**: Provides restricted access to Web iSite functionality

By default, the **admin** and **user** accounts both have the same password: *iDirect*. A user can change account names and passwords using the NMS iBuilder application. For information on configuring satellite routers, see the *iBuilder User Guide*.

To launch Web iSite, perform the following:

1. Connect the personal computer (PC) LAN port to the satellite router local area network (LAN) port using an Ethernet cable.
2. Launch the Web browser of choice.
3. Enter the IP address of the e150, X1, X7, or X7-ER satellite routers into the address field, as shown in the following example:

<https://196.168.0.1> (the default factory LAN IP address is shown here)



NOTE: If a connection is not established using the default IP address then the IP address from the options file must be used. If a connection is not established using the options file, it may be necessary to reset the satellite router. See the appropriate *Satellite Router Installation and Commissioning Guide* or *Integration Guide* for reset information.

4. Enter a User name and Password at the Login dialog box.

The image shows a web browser window displaying a login dialog. The dialog has a title bar with the word "Login" in a serif font. Below the title bar is a white rectangular area containing the login form. The form has two labels: "User:" and "Password:". The "User:" label is followed by a text input field containing the text "admin". The "Password:" label is followed by a password input field containing seven dots ".....". At the bottom right of the white area is a button labeled "Login".

Figure 1-4. Web iSite Login Dialog

5. Click **Login** to complete the login process.

The Web iSite Dashboard appears.

1.3 Web iSite User Interface

Figure 1-5 shows the Dashboard page for the X1; this is the default page for Web iSite. The page elements shown are typical of the other pages that comprise Web iSite, including those for the e150, X7, and X7-ER. The sections that follow describe these elements.




Figure 1-5. Web iSite Default Page

1.3.1 Web iSite Browser Window

After connecting to the e150, X1, X7, or X7-ER Satellite Router, the browser window appears at the top of the default page. In [Figure 1-6](#), the IP address of the satellite router with an established connection appears in the Address bar. The browser window may appear slightly different, based on the Internet browser.



Figure 1-6. Web iSite Browser Tab

1.3.2 Navigation Bar

[Figure 1-7](#) shows the navigation bar that spans the top of each Web iSite page. The navigation bar provides the four main console buttons that appear on each Web iSite page.




Figure 1-7. Main Console Buttons

Clicking on a button opens the default page for the associated page group. For example, clicking the **Status** opens the **Modem Status** page in the **Status** page group. See [Figure 1-8](#). This is the default page for the **Status** page group.




Figure 1-8. Typical Web iSite Page

1.3.3 Left Navigation Bar

The left side of a Web iSite page contains the left navigation bar. See [Figure 1-8](#). This panel contains links to additional Web iSite pages in the current page group. Click the page link to navigate to the selected page.

1.3.4 Page

A screen in Web iSite is referred to as a page. The entire application comprises several pages that either present satellite router information, or support interaction with the satellite router. The contents of a page may provide static or real-time information about the satellite router. A page may also provide interactive tools that support a Web iSite operation.

1.3.4.1 Main Default Pages

To work with one of the main Web iSite page groups, select and click one of the main page buttons. This opens the default page for the selected page group.

For example, as previously described, clicking on the **Status** button on the main console bar opens the default page for the **Status** group, that is, the **Modem Status** page shown in [Figure 1-8](#).

1.3.4.2 Sub-Pages

In addition to the main default page, each Web iSite page group contains a number of sub-pages that show different content. Users can access the pages of the group from the default page as well as from the other pages within the group. The **Ethernet Status** page, for example, is a sub-page of the **Status** page group shown in [Figure 1-8](#).

1.3.4.3 Sections

Each Web iSite page normally comprises two or more sections. A section contains a grouping of information fields (or elements) for performing an operation (for example, file uploading). A section title identifies the specific information grouping. For example, in [Figure 1-8](#), the **Modem Status** page contains the following sections:

- Modem Information
- Modem State
- Rx State
- Tx State
- Geo Location

1.3.4.4 Information Fields

Sections contain static or dynamic information fields with labels that indicate the field content. Some data fields are for viewing or monitoring purposes only; other data fields allow users to modify the data. In [Figure 1-8](#), the **Modem Information** section contains the following information fields:

- Model Type
- Serial Number
- MAC Address
- Software Version

1.3.4.5 Hiding and Displaying a Page Section

In Web iSite, it is possible to hide and unhide page sections by clicking on the section title. In [Figure 1-8](#), for example, **Modem Information** and **Modem State** sections are open, and the **RX State**, **TX State**, and **Geo Location** sections are closed. Clicking on **Tx State** opens the **Tx State** section. See [Figure 1-9](#).




Figure 1-9. Modem Status Page with Tx Section Open

1.3.4.6 X1 Satellite Routers Status Indicators

Figure 1-10 shows the four LED status indicators that are visible below the Navigation Bar on each Web iSite page when using Web iSite with an X1. These are the same LEDs that appear on the front panel of the X1 indoor satellite router. Various combinations of the LEDs indicate different satellite router states. Table 1-1 describes the indicators.



NOTE: The X1 Outdoor Satellite Router and the e150 Satellite Router simulate the LED status indicators of the X1 indoor Satellite Router.




Figure 1-10. Web iSite X1 LED Indicators

After establishing a connection with an X1 Satellite Router, the real-time status of each LED indicator of that satellite router appears on each Web iSite page.

Table 1-1. X1 Router LED Status Indicators

Label	Signal Color/Type	Definition
RX		Provides downstream receive status
	Off	Receiver off or not configured
	Yellow	Downstream carrier configured, demodulator not yet locked
	1 second flashing Yellow	Downstream carrier configured, demodulator locked to downstream carrier, Network Clock Reference (NCR) not yet locked
	1 second flashing Green	DRAM test failed
	Green	Downstream carrier configured, demodulator and NCR locked to downstream carrier
TX	Flashing Red	All LEDs simultaneously flashing red indicates a software exception or bad options file
		Indicates the state of the transmitter
	Off	Transmitter is off
	Yellow	Transmitter enabled, mute ON
	1 second flashing Green	DRAM test failed
NET	Green	Transmitter enabled, mute OFF
	Flashing Red	All LEDs simultaneously flashing red indicates a software exception or bad options file
		Indicates the state of the satellite network connection
	Off	Router off or in sleep mode if TX LED is yellow (mute ON)
	Yellow	Demodulator is not locked on the primary downstream carrier
	1 second flashing Yellow	Demodulator locked on primary downstream carrier, NCR not yet locked
	2 second flashing Green	Demodulator locked on the primary downstream, NCR locked
	1 second flashing Green	DRAM test failed if RX and TX are also flashing green
	1 second flashing Green	Network acquisition and authentication in progress

Table 1-1. X1 Router LED Status Indicators (continued)

Label	Signal Color/Type	Definition
	Green	Network acquired and authenticated; if TX LED is OFF, then router is in Rx only mode
	Flashing Red	All LEDs simultaneously flashing red indicates a software exception or bad options file
POWER		Indicates power supply status and any power-related problems
	Off	No or low power input
	Green	Valid power input detected
	Flashing Red	All LEDs simultaneously flashing red indicates a software exception or bad options file

1.3.4.7 X7 or X7-ER Satellite Routers LED Indicators

Figure 1-11 shows the eight LED status indicators that are visible below the Navigation Bar on each Web iSite page when using Web iSite with an X7 or X7-ER. These are the same indicators that appear on the front panel of the X7 or X7-ER Satellite Router. Various combinations of the LEDs indicate different satellite router states. Table 1-2 describes these indicators.



Figure 1-11. Web iSite X7 or X7-ER LED Indicators

After establishing a connection with an X7 or X7-ER Satellite Router, the real-time status of each LED indicator of that satellite router appears on each Web iSite page.

Table 1-2. X7 or X7-ER Router LED Status Indicators

Label	Signal Color/Type	Definition
POWER		Indicates power supply status and any power-related problems
	Off	No or low power input
	Green	Valid power input detected
	Yellow	Problem with BUC voltage selection

Table 1-2. X7 or X7-ER Router LED Status Indicators (continued)

Label	Signal Color/Type	Definition
STATUS		Indicates basic operational state and problems with core hardware
	Off	Powered off or going through initial Power-on Self-test (POST)
	1 second flashing Green	Initial POST failed
	Green	HW operation is normal (all self-tests passed)
	Red	Fault: hardware, software, one or more self-test failures, or configuration error
FAN		Provides fan status
	Green	All fans working
	Red	Failure of one or more fans
TEMP		Indicates problems with the current operating temperature
	Off	Router OFF or booting if STATUS LED is not Green
	Green	Normal operating temperature
	Yellow	Operating temperature is nearing the over-temp or under-temp threshold
	Red	Operating temperature has exceeded the over-temp or under-temp threshold
RX1 and RX2		Provides downstream receive status
	Off	Receiver off or not configured
	Yellow	Downstream carrier configured, demodulator not yet locked
	1 second flashing Yellow	Downstream carrier configured, demodulator locked to downstream carrier, Network Clock Reference (NCR) not yet locked
	Green	Downstream carrier configured, demodulator and NCR locked to downstream carrier
TX		Indicates the state of the transmitter
	Off	Transmitter is off: if STATUS LED is green, then transmission disabled by configuration
	Yellow	Transmitter enabled, mute ON
	Green	Transmitter enabled, mute OFF

Table 1-2. X7 or X7-ER Router LED Status Indicators (continued)

Label	Signal Color/Type	Definition
NET		Indicates the state of the satellite network connection
	Off	Router off or in sleep mode if TX LED is yellow (mute ON)
	Yellow	Demodulator is not locked on the primary downstream carrier
	1 second flashing Yellow	Demodulator locked on primary downstream carrier, NCR not yet locked
	2 second flashing Green	Demodulator locked on the primary downstream, NCR locked
	1 second flashing Green	Network acquisition and authentication in progress
	Green	Network acquired and authenticated; if TX LED is OFF, then router is in Rx (receive) only mode
	Red	Authentication failed

2 Dashboard

This chapter describes the Web iSite Dashboard. It contains the following sections:

- [Remote Information on page 16](#)
- [Equipment Details on page 16](#)
- [Real-Time Remote Events on page 18](#)

The **Dashboard** page provides key information about any e150, X1, X7, or X7-ER Remote Satellite Routers that have an established connection.

The **Dashboard** page is the default landing page and opens whenever Web iSite is launched. Clicking on the **Dashboard** button from another page causes the left navigation bar to display the Dashboard page group. It also causes the **Dashboard** page to open. See [Figure 2-1](#).




Figure 2-1. Dashboard Page

The Dashboard page provides access to basic information (for example, the IP address of the remote satellite router, whether the satellite router is in network, or if it is locked to the satellite), and real-time remote events.



NOTE: Because the Dashboard is a central point for viewing the modem's key identifiers, operating parameters, and real-time events, information that appears on the Dashboard may also appear on other Web iSite pages.

2.1 Remote Information

Figure 2-2 shows the Remote Information section of the Web iSite Dashboard page.

▼ Remote Information	
Model Type:	X1
Serial Number:	742
Provisioning Key:	BYAAFZVZL7ABY==
Login Name:	admin
Software Version:	IDS 15.0.0.0 Build 34
LAN IP Address:	192.168.0.1
LAN Subnet Mask:	255.255.255.0
▶ Equipment Details	
▼ Real-Time Remote Events	
No events to show.	

Figure 2-2. Remote Information

The Remote Information section provides key identifier information for the satellite routers including:

- **Model Type:** The type of remote satellite router
- **Serial Number:** The serial number of the remote satellite router
- **Provisioning Key:** For future use
- **Login Name:** The login for the current Web iSite session
- **Software Version:** The software version number and build
- **LAN IP Address:** The LAN IP address of the satellite router
- **LAN Subnet Mask:** The LAN subnet mask of the remote satellite router

2.2 Equipment Details

Figure 2-3 shows the Equipment Details section of the Web iSite Dashboard page.

Equipment Details	
Network:	Waiting for Rx Lock
Network Uptime:	00:00:00
Data Link:	N/A
Satellite Rx:	Waiting for Demod Lock
Satellite Tx:	Off
Tx Power:	-25 dBm
Temperature:	44 °C
Up Time:	1 day, 00:57:16

Figure 2-3. Equipment Details

The Equipment Details section provides the following real-time network information for the satellite router:

- **Network:** Shows one of the following:
 - **Wait for Rx Lock:** Waiting to receive the outbound carrier
 - **Wait for Acquisition:** The remote is locked to the outbound carrier and is waiting for an invitation from the Protocol Processor (PP) to join the network
 - **Detected:** The remote has received an invitation from the PP received and is actively trying to join the network
 - **In Network:** The remote has joined the network and is operational (the PP saw an ACQ burst from this remote; does not mean that any data will pass)
- **Network Uptime:** The time since the remote was last acquired into network
- **Data Link:** Shows one of the following:
 - **Opening:** Data link is opening (no user data passes)
 - **Established:** Data link is established (user data passes)
 - **Closing:** Data link is closing (no user data passes)
 - **Rx Only:** Data link can receive but not transmit
- **Satellite Rx:** Shows one of the following:
 - **Wait Tuner:** Waiting for tuner lock
 - **Wait Demod Lock:** Waiting for demodulator lock
 - **Wait NCR:** Waiting for network clock reference (NCR) lock
 - **Locked:** Receiver is locked
- **Satellite Tx:** Shows one of the following:
 - **On:** Transmit mode on
 - **Off:** Receive only mode
 - **CW:** Continuous wave (CW) is output because modulator is on; pseudo-noise (PN) is output if modulator is off

- **Antenna Pointing:** Tx IF port is being used for antenna pointing in response to Commissioning→Antenna Pointing (see [Antenna Pointing Page on page 46](#))
- **Tx Power:** Transmit power
- **Temperature:** Operating temperature
- **Up Time:** Time since Web iSite boot or restart

2.3 Real-Time Remote Events

Figure 2-4 shows the Real-Time Remote Events section of the Web iSite Dashboard.



NOTE: The Real-Time Remote Events section of the Web iSite Dashboard only shows the last 10 events. Go to [Real-Time Remote Events Page on page 35](#) to see all events.

▼ Real-Time Remote Events			
Up Time	Network Time	Level	Description
00:00:58.160	2014-07-08 17:22:05.077	NMS	TCP Connection terminated on socket: 14
00:00:55.609	2014-07-08 17:22:02.526	NMS	TCP Connection successful from addr: 172.17.165.10, assigned socket: 14
00:00:48.072	2014-07-08 17:21:54.989	NMS	REMOTE HELLO (revision: 15.0.0.0)

Figure 2-4. Real-Time Remote Events

After the software package and options file have been loaded and the satellite router is reset and restarted, the **Real-Time Remote Events** section shows the most recent events that have occurred on the remote satellite router.

This section is primarily a monitoring tool to aid in resolving any issues with the satellite router. An iDirect TAC representative can use the information in this section to trace events in the satellite router and perform an investigation and analysis of any problems that exist.

The **Real-Time Remote Events** section provides the following information:

- **Up Time:** Time since Web iSite boot or restart
- **Network Time:** Time and date issued by the protocol processor at ten-minute intervals that a listening remote can use to update its time of day



NOTE: The **Network Time** column does not appear if the network time is unknown. The remote does not have a real-time clock and becomes aware of the network time only after entering and remaining in the network for 10 minutes.

- **Level:** Show level as:
 - Informational
 - Warning
 - Error
 - Fatal

- NMS
- **Description:** Details about the event

2.3.1 Real-Time Event Messages

Typical real-time remote event messages available on the Dashboard include items such as TCP connection assigned or terminated; TX power setting; flash firmware completed; modem configuration written; or Remote Hello, upon being reset.

In general, Dashboard real-time remote events include the following:

- REMOTE HELLO: Generated on first acquisition into the network after reset
- TLS client connection/disconnection
- Package and options upload
- CrossPolTestMsg
- PanicMsg
- ResetMsg
- RxODUMsg
- TxODUMsg
- StopTxMsg
- TxPowerMsg

3 Status Pages

This chapter describes the Web iSite Status pages. It contains the following sections:

- [Overview on page 21](#)
- [Modem Status Page on page 21](#)
- [Ethernet Status Page on page 25](#)
- [IP Configuration Page on page 28](#)
- [ODU Status Page on page 34](#)
- [Real-Time Remote Events Page on page 35](#)
- [Satcom Graphs Page on page 36](#)

3.1 Overview

Clicking on the **Status** button causes the left navigation bar to show the **Status** page group. See [Figure 3-1](#).




Figure 3-1. Left Navigation Bar Status Page Group

It also causes the **Modem Status** page (the default page for the **Status** page group) to open. See [Figure 3-2](#).

The **Status** page group provides a monitoring window into satellite router real-time status. The **Status** pages provide a view of some of the satellite router key operating parameters and access to graphs for satellite router network traffic.

3.2 Modem Status Page

The **Modem Status** page is the default page of the **Status** page group. See [Figure 3-2](#).




Figure 3-2. Modem Status

The **Modem Status** page contains the following sections that are described in the paragraphs that follow:

- Modem Information
- Modem State
- Rx State
- Tx State
- Geo Location

3.2.1 Modem Information

Figure 3-3 shows the Modem Information section of the Modem Status page.




Figure 3-3. Modem Information

The **Modem Information** section provides the following key identifying information for the satellite router:

- **Model Type:** The satellite router model type
- **Serial Number:** The serial number
- **Provisioning Key:** For future use
- **MAC Address:** The Media Access Control address (MAC address)
- **Software Version:** The current software version and build numbers

3.2.2 Modem State

Figure 3-4 shows the Modem State section of the Modem Status page.




Figure 3-4. Modem State


The Modem State section provides information about the following modem state parameters:

- **Network:** Shows one of the following:
 - **Waiting for Rx Lock:** The demodulator is configured and waiting to lock to the downstream carrier
 - **Waiting for Acquisition:** The remote is locked to the outbound carrier and is waiting for an invitation from the Protocol Processor (PP) to join the network
 - **In Acquisition:** The remote is receiving time plans but has not been invited to join the network
 - **Detected:** The remote has received an invitation from the PP and is actively trying to join the network
 - **In Network:** The remote has joined the network and is operational (the PP saw an ACQ burst from this remote; does not mean that any data will pass)
 - **Wrong Network:** The network-locked remote has entered the wrong network
- **Network Uptime:** The time since the remote was last acquired into network
- **Data Link:** Shows one of the following:
 - **Closed:** Data link is closed (no user data passes)
 - **Opening:** Data link is opening (no user data passes)
 - **Established:** Data link is established (user data passes)
 - **Closing:** Data link is closing (no user data passes)
 - **Rx-Only:** Data link can receive but not transmit
- **Satellite Rx:** Shows one of the following:
 - **Waiting for Tuner Lock:** Waiting for the RF tuner to configure and lock to programmed frequency
 - **Waiting for Demod Lock:** Waiting for the DVB-S2 demodulator to lock to the received signal

- **Waiting for NCR Lock:** Waiting for the remote Network Clock Recovery circuit to lock to the downstream timing
- **Locked:** Both Demod and NCR lock achieved; this is the desired state to allow the satellite router to transmit and enter the network
- **Satellite Tx: On/Off**
 - **On:** Transmit mode on
 - **Off:** Receive only mode
- **CPU Load:** The current operating load on the satellite router CPU
- **Temperature:** The current board temperature of the satellite router

3.2.3 Rx State

Figure 3-5 shows the Rx State section.



Rx State	
Downlink Center Freq:	1,027 MHz
Symbol Rate:	44,999.999 ksym/s
Rolloff:	20%
Role:	Main
Beam ID:	N/A
Beam Type:	N/A
Rx Composite Power:	-100.0 dBm
Rx SNR:	1.3 dB
CRC 8:	0
CRC 32:	0

Figure 3-5. Rx State

The Rx State section indicates the following receive operational parameters for the modem:

- **Downlink Center Freq:** The downlink center frequency as configured in the satellite router options file
- **Symbol Rate:** The symbol rate as configured in the satellite router options file
- **Rolloff:** Shows the roll-off factor: 5%/10%/15%/20%
- **Role:** Main or Auxiliary
- **Beam ID:** An integer that identifies a beam
- **Beam Type:** May be one of:
 - Primary
 - Alternate
- **Rx Composite Power:** The Rx composite power within the symbol rate and centered on the configured Rx frequency

- Rx SNR: The current Rx Signal-to-Noise Ratio (SNR) (assuming the demodulator is locked)
- CRC 8: The number of downstream DVB-S2 8-bit Cyclic Redundancy Check (CRC) 8 errors
- CRC 32: The number of downstream DVB-S2 32-bit CRC errors

3.2.4 Tx State

Figure 3-6 shows the Tx State section.



Tx State	
Tx Power:	-25 dBm
Max Tx Power:	-11 dBm
Initial Tx Power:	-25 dBm


Figure 3-6. Tx State

The Tx State section indicates the following modem transmission parameters:

- Tx Power: The current Tx power related to the nominal carrier
- Max Tx Power: The *never exceed* power determined during commissioning, configured in iBuilder, and stored in the options file for the modem
- Initial Tx Power: The power used for acquisition bursts determined during commissioning, configured in iBuilder, and stored in the options file for the modem

3.2.5 Geo Location

Figure 3-7 shows the Geo Location section.



Geo Location	
Latitude:	0.0000 deg. North
Longitude:	0.0000 deg. East

Figure 3-7. Geo Location

The Geo Location section indicates the following:

- Latitude: The remote site latitude in decimal degrees North or South
- Longitude: The remote site longitude in decimal degrees East or West

3.3 Ethernet Status Page

The Ethernet Status page provides key Ethernet connection information for the local LAN subnet of the satellite router.

Because the X7 has eight Ethernet ports and the e150 and X1 each have one Ethernet port, the Ethernet Status page for the e150 and X1 differs from the X7. See Figure 3-8 and Figure 3-9. The X7 Ethernet Status page shows the eight ports (that is, port 1 through port 8).



Figure 3-8. Ethernet Status Page (e150 and X1)




Figure 3-9. Ethernet Status Page (X7 or X7-ER)

The **Ethernet Status** pages for the X1 and the X7 both contain the following sections that are described in the paragraphs that follow:

- VLAN Assignments
- Connection
- Transmitter
- Receiver

3.3.1 VLAN Assignments

Figure 3-10 shows the VLAN Assignments section.




Figure 3-10. VLAN Assignments

The **VLAN Assignments** section provides the following information about Virtual LAN (VLAN) assignments:


- **VLAN ID:** A specific VLAN
- **Packet Tagging:** Whether a packet header includes a tag that identifies the VLAN it belongs to



NOTE: Packet tagging permits connecting to the Ethernet side of the default LAN from a hub PC.

3.3.2 Connection

Figure 3-11 shows the Connection section of the Ethernet Status page.



▼ Connection	
Status:	Connected
Speed:	100 Mbit/s
Duplex mode:	Full duplex
IP Address:	192.168.0.1
Subnet Mask:	255.255.255.0
MAC Address:	00:60:43:61:b6:59

Figure 3-11. Connection


The **Connection** section provides the following information about the local LAN subnet that connects to the satellite router:

- **Status:** The connection status as either **Connected** or **Disconnected**
- **Speed:** The connection speed established at **10 Mbit/s** or **100 Mbit/s**; if there is no connection, indicates **Not Available**
- **Duplex Mode:** The **Full Duplex**, **Half Duplex**, or **Not Available**
- **IP Address:** The IP address of the untagged VLAN (i.e., the default VLAN) of the port; if there is no untagged VLAN, displays **No default VLAN**
- **Subnet Mask:** The satellite router subnet mask; if there is no untagged VLAN, displays **N/A**
- **MAC Address:** The satellite router MAC address

3.3.3 Transmitter

The **Transmitter** section shows statistical information that provides a key measure of the stability of the Ethernet transmitter.

Figure 3-12 shows the Transmitter section of the Ethernet Status page.



▼ Transmitter	
Bytes:	24832065
Frames:	188520
Dropped Frames:	0
Error Frames:	0

Figure 3-12. Transmitter

The Transmitter section provides the following information:

- **Bytes:** The total number of bytes that the satellite router has transmitted from the Ethernet interface
- **Frames:** The total number of Ethernet frames that the satellite router has transmitted from the Ethernet interface
- **Dropped Frames:** The number of dropped frames since the satellite router was restarted
- **Error Frames:** The number of error frames since the satellite router was restarted

3.3.4 Receiver

The Receiver section shows statistical information that provides a key measure of the stability of the Ethernet receiver characteristics.

Figure 3-13 shows the Receiver section of the Ethernet Status page.




Figure 3-13. Receiver

The Receiver section provides the following information:

- **Bytes:** The total number of bytes received at the Ethernet interface
- **Frames:** The total number of Ethernet frames received at the Ethernet interface
- **Dropped Frames:** The number of dropped frames since the satellite router was restarted
- **Error Frames:** The number of error frames since the satellite router was restarted

3.4 IP Configuration Page

The IP Configuration page provides important configuration information about the network that connects to the satellite router.

Figure 3-14 shows the e150 and X1 IP Configuration page, and Figure 3-15 shows the X7 or X7-ER IP Configuration page.




Figure 3-14. IP Configuration Page (e150 and X1)




Figure 3-15. IP Configuration Page (X7 or X7-ER)

Note that both contain the sections below with the exception that the X7 or X7-ER contains a Routing section.

- Eth Interface
- Sat Interface
- DHCP
- DNS
- Routing (X7 or X7-ER only)
- Static Routes

- Multicast Groups
- Port Forwarding

By default, VLAN1 or eth0 is the management VLAN and the remaining VLANs (or Eths) are user VLANs.

3.4.1 Eth Interface

Figure 3-16 shows the Eth Interface section of the IP Configuration page.




Figure 3-16. Eth Interface

In an iDirect network, the Eth (that is, the LAN) Interface refers to the IP address through which the satellite router communicates with the LAN network behind the satellite router. The Eth Interface contains the following fields:

- **IP Address:** The IP address of the satellite router on the user VLAN on which it is configured
- **Netmask:** The associated subnet mask for the satellite router

3.4.2 Sat Interface

Figure 3-17 shows the SAT Interface section of the IP Configuration page.




Figure 3-17. Sat Interface

In an iDirect network, the Sat Interface refers to the hub side of the network. Therefore, the Sat Interface IP Address represents the virtual interface of the satellite router on the default VLAN. The Sat Interface section contains the following fields:

- **IP Address:** The IP address of the satellite router on the user VLAN on which it is configured
- **Netmask:** The associated subnet mask for the satellite router


3.4.3 DHCP

The DHCP (Dynamic Host Configuration Protocol) section of the IP Configuration page displays the current modem DHCP configuration in one of three modes:

- **Disabled:** DHCP Mode is disabled
- **Server:** The satellite router is acting as the DHCP Server

- **Relay:** There is an existing or separate DHCP server at the hub location


Figure 3-18 shows the Disabled mode where only the DHCP Mode field appears.



A screenshot of a web interface showing the DHCP configuration section. The section is titled "DHCP" with a dropdown arrow. Below the title, there is a label "DHCP Mode:" followed by a text input field containing the word "Disabled".

Figure 3-18. DHCP Mode (Disabled)

Figure 3-19 shows the DHCP section of the IP Configuration page with Server mode selected.



A screenshot of a web interface showing the DHCP configuration section. The section is titled "DHCP" with a dropdown arrow. Below the title, there are several configuration fields: "DHCP Mode:" set to "Server", "Lease Range:" set to "10.168.248.20-10.168.248.30", "Lease Time:" set to "12 hours", "Primary DNS:" set to "1.2.3.4", "Secondary DNS:" set to "1.2.3.5", and "Default Gateway:" set to "10.168.100.1".


Figure 3-19. DHCP (Server Mode)

In the Server or Relay modes, the following fields are available:

- **Lease Range:** The IP address range to be used by DHCP clients
- **Lease Time:** The lease time for DHCP clients
- **Primary DNS:** The primary DNS server IP address
- **Secondary DNS:** The secondary DNS server IP address
- **Default Gateway:** The IP address of the default gateway

3.4.4 DNS


Figure 3-20 shows the DNS (Domain Name System) section of the IP Config page. If the DNS mode is Disabled, only the DNS Mode field appears.



A screenshot of a web interface showing the DNS configuration section. The section is titled "DNS" with a dropdown arrow. Below the title, there is a label "DNS Mode:" followed by a text input field containing the word "Disabled".

Figure 3-20. DNS (Mode Disabled)

Figure 3-21 shows the DNS mode enabled.



▼ DNS	
DNS Mode:	Cache
Primary DNS Name:	ns1
Primary IP Address:	1.2.3.6
Secondary DNS Name:	ns2
Secondary IP Address:	1.2.3.7
Cache Size:	100
Forward Queue Size:	1000
Forward Timeout:	2000


Figure 3-21. DNS (Mode Enabled)

If the DNS mode is **Enabled**, the following fields appear:

- **DNS Mode:** The DNS mode is **Cache** or **Disabled**
- **Primary DNS Name:** The primary DNS name server
- **Primary IP Address:** The primary DNS server IP address
- **Secondary DNS Name:** The secondary DNS name server
- **Secondary IP Address:** The secondary DNS server IP address
- **Cache Size:** The number of entries the DNS cache can hold
- **Forward Queue Size:** The maximum size of the DNS forward queue
- **Forward Timeout:** The expiration time for elements in the DNS forward queue (ms)

3.4.5 Routing

Figure 3-22 shows the **Routing** section of the **IP Configuration** page for the X7 or X7-ER.



▼ Routing	
Eth RIPv2:	Disabled
Sat RIPv2:	Disabled

Figure 3-22. Routing

The **Routing** section contains the following fields:

- **Eth RIPv2:** Whether the RIPv2 protocol is enabled or disabled for the LAN Interface
- **Sat RIPv2:** Whether the RIPv2 protocol is enabled or disabled for the Sat Interface (The Sat Interface is called the management interface when referring to the default VLAN.)

3.4.6 Static Routes

Figure 3-23 shows the **Static Routes** section of the **IP Configuration** page.

▼ Static Routes			
Interface	IP Address	Subnet Mask	Gateway
eth	8.8.8.0	255.255.255.0	0.0.0.0
sat	0.0.0.0	0.0.0.0	0.0.0.0

Figure 3-23. Static Routes

The **Static Routes** section shows the list of IP addresses configured in iBuilder as static routes for the satellite router.

3.4.7 Multicast Groups

Figure 3-24 shows the Multicast Groups section of the IP Configuration page.

▼ Multicast Groups	
Direction	IP Address
Sat to Mgmt	239.192.0.0
Sat to Eth	239.192.10.0
Sat to Eth	239.192.20.0
Eth to Sat	239.100.10.1
Eth to Sat	239.100.10.2
Eth to Sat	239.100.10.64

Figure 3-24. Multicast Groups

The Multicast Groups section provides the following information:

- **Direction:** The flow of traffic of the listed multicast groups
- **IP Address:** The IP addresses of the persistent Multicast Groups where the satellite router is a member

3.4.8 Port Forwarding

Figure 3-25 shows the Port Forwarding section of the IP Configuration page.

▼ Port Forwarding		
Protocol	Port(s)	IP Address
TCP	2020	10.168.248.30
UDP	2021-2029	10.168.248.30

Figure 3-25. Port Forwarding

The **Port Forwarding Group** section provides the following information:

- **Protocol:** The protocol of the forwarded packets

- Port(s): The port or port range of the IP packets to be forwarded
- IP Address: The destination IP address

3.5 ODU Status Page

Figure 3-26 shows the ODU (outdoor unit) Status page.




Figure 3-26. ODU Status

The ODU Status page indicates the following key operating parameters of the Block Up Converter (BUC) and the Low-Noise Block (LNB) Downconverter amplifier devices associated with the satellite router:

The ODU Status page contains the following sections that are described in the paragraphs that follow:

- Rx Status
- Tx Status

3.5.1 Rx Status

Figure 3-27 shows the Rx Status section.





Figure 3-27. Rx Status

The Rx Status section provides the following information:

- **Downlink Center Freq:** The downlink center frequency of the DVB-S2 downstream carrier as configured in iBuilder
- **Rx L-Band Freq:** The output of the LNB (the downconverted IF frequency); the router receiver tunes to this frequency
- **LNB Local Oscillator Freq:** The frequency of the downconverter local oscillator
- **LNB Spectral Inversion:** Normal or Inverted

3.5.2 Tx Status

Figure 3-28 shows the Tx Status section.



▼ Tx Status

BUC Local Oscillator Freq: 0 MHz

BUC Spectral Inversion: Normal

Figure 3-28. Tx Status

The Tx Status section provides the following information:

- BUC Local Oscillator Freq: The frequency of the upconverter local oscillator
- BUC Spectral Inversion: Normal or Inverted

3.6 Real-Time Remote Events Page

Figure 3-29 shows the Real-Time Remote Events page.



NOTE: The Real-Time Remote Events section of the Web iSite Dashboard shows similar information but is limited to ten events. This page shows all events.

Real-Time Remote Events				
Up Time	Network Time	Level	Description	
00:00:49.840	2013-05-20 11:46:28.010	Nms	TCP Connection terminated on socket: 27	
00:00:49.610	2013-05-20 11:46:27.780	Nms	TCP Connection successful from addr: 172.17.105.10, assigned socket: 27	
00:00:49.420	2013-05-20 11:46:27.590	Nms	TCP Connection successful from addr: 172.17.105.10, assigned socket: 27	
00:00:42.320	2013-05-20 11:46:20.490	Nms	REMOTE HELLO (revision: 14.0.0.0)	
00:00:42.320	2013-05-20 11:46:20.490	Nms	REMOTE HELLO (revision: 14.0.0.0)	
00:00:18.010	2013-05-20 11:45:56.180	Information	t:15567 Remote Received First Timeplan	
00:00:18.010	2013-05-20 11:45:56.180	Information	t:15567 Remote Received First Timeplan	
00:00:08.350	2013-05-20 11:45:46.520	Nms	Remote exits from RxOnly Mode	

Figure 3-29. Real-Time Remote Events

The Real-Time Remote Events page shows the most recent events that have occurred on the remote satellite router.

This page is primarily a monitoring tool to aid in resolving any issues with the satellite router. An iDirect TAC representative can use the information in this section to trace events in the satellite router and perform an investigation and analysis of any problems that exist.

This page provides the following real-time remote events information for the satellite router:

- **Up Time:** Total time the satellite router has been active since last modem restart
- **Network Time:** Time and date that the protocol processor provides at ten-minute intervals



NOTE: The **Network Time** column does not appear if the network time is unknown. The remote does not have a real-time clock and becomes aware of the network time only after entering and remaining in the network for 10 minutes.

- **Level:** Show level as:
 - Informational
 - Warning
 - Error
 - Fatal
 - NMS
- **Description:** Describes the type of real-time remote event

3.7 Satcom Graphs Page

Figure 3-30 shows the Satcom Graphs page.




Figure 3-30. Satcom Graphs

The **Satcom Graphs** page contains the following sections that are described in the paragraphs that follow:

- Rx SNR
- Tx Power
- Tx Frequency Offset
- Clock Deviation

3.7.1 Rx SNR

Figure 3-31 shows the Rx SNR section.




Figure 3-31. Receiver SNR

The Rx SNR section is a graph of the downstream signal-to-noise ratio in decibels (dB) as seen by the satellite router over time. The receive SNR varies over time depending upon propagation conditions and noise levels.

3.7.2 Tx Power

Figure 3-32 shows the Tx Power section.




Figure 3-32. Tx Power

The Tx Power section is a graph of the satellite router transmitter IF output power over time.

3.7.3 Tx Frequency Offset

Figure 3-33 shows the Tx Frequency Offset section.




Figure 3-33. Tx Frequency Offset

The **Tx Frequency Offset** section is a graph of the satellite router transmit frequency offset over time. The data indicates the frequency offsets that the Protocol Processor (PP) applies to the satellite router determined by the uplink control process (UCP).

3.7.4 Clock Deviation

Figure 3-34 shows the Clock Deviation section.




Figure 3-34. Clock Deviation

The **Clock Deviation** section is a graph that plots the difference between the satellite router 10 MHz reference clock and the Network Clock Reference (NCR) over time.

4 Commissioning Pages

This chapter describes the Web iSite Commissioning pages. It contains the following sections:

- [Overview on page 39](#)
- [Downstream Configuration on page 40](#)
- [Geo Location on page 43](#)
- [Angle Calculator Page on page 44](#)
- [Antenna Pointing Page on page 46](#)
- [Cross Polarization Test Page on page 48](#)

This chapter only describes the various pages of this page group, and the tools found on these pages. For full information and specific details on installing and commissioning the e150, X1, X7, and X7-ER Satellite Routers, refer to the *iDirect Satellite Routers Installation and Commissioning Guide*.



NOTE: Commissioning pages are only available to **admin** accounts. The Commissioning pages are not available to **user** accounts.

4.1 Overview

Clicking on the **Commissioning** button causes the left navigation bar to display the **Commission** page group. See [Figure 4-1](#).




Figure 4-1. Left Navigation Bar Showing Commissioning Page Group

It also causes the **Downstream Configuration** page (the default page for the **Commissioning** page group) to open.

This page group (which may be familiar to users of the iVantage iSite client) provides the functionality required for satellite router installation and commissioning tasks.

4.2 Downstream Configuration

The **Downstream Configuration** page provides the means to enter the minimum parameters to receive the downstream carrier. After the remote has acquired the downstream carrier, the network operator can push the options file to the satellite router over the air in order to load the full configuration.



NOTE: Downstream Configuration is a commissioning option typically used for large fleets. For more information, see the *iDX Installation and Commissioning Guide for Remote Satellite Routers*.

Figure 4-2 shows the Downstream Configuration page.




Figure 4-2. Downstream Configuration (Default)

The **Downstream Configuration** page contains the following sections that are described in the paragraphs that follow:

- Manual Configuration
- Configuration from File

4.2.1 Manual Configuration

Figure 4-3 shows the Manual Configuration section of the Downstream Configuration page.

The screenshot shows a 'Manual Configuration' window with three sections: Downlink, LNB, and Package Multicast. The Downlink section has fields for RF Center Frequency (1,500 MHz), Symbol Rate (10,000 ksym/s), and Rolloff (20%). The LNB section has fields for DC Voltage (Disabled), 22kHz Tone (Disabled), Spectral Inversion (Normal), LO Frequency (0 MHz), and L-Band Frequency (1,500 MHz (computed)). The Package Multicast section has fields for IP Address (239.192.0.0), Port Number (9,000), and Credentials (1). An 'Apply' button is at the bottom left.

Manual Configuration	
Downlink	
RF Center Frequency:	1,500 MHz
Symbol Rate:	10,000 ksym/s
Rolloff:	20%
LNB	
DC Voltage:	Disabled
22kHz Tone:	Disabled
Spectral Inversion:	Normal
LO Frequency:	0 MHz
L-Band Frequency:	1,500 MHz (computed)
Package Multicast	
IP Address:	239.192.0.0
Port Number:	9,000
Credentials:	1
<input type="button" value="Apply"/>	

Figure 4-3. Manual Configuration

Use the **Manual Configuration** section to manually configure the downstream reception parameters. After making changes, use the **Apply** button to confirm.

4.2.1.1 Downlink

The **Downlink** section contains the following fields:

- **RF Downlink Center Frequency:** The RF downlink center frequency for the downstream carrier
- **Symbol Rate:** The symbol rate of the downstream carrier in kilosymbols per second
- **Rolloff:** Pull-down menu to select roll-off factor: 5%/10%/15%/20%

4.2.1.2 LNB

The **LNB** section contains the following fields:

- **DC Voltage:** Pull-down menu to select LNB DC input voltage:
 - X7 or X7-ER choices are: **Disable/13V/14V/18V/19V**
 - e150 and X1 choices are: **Disable/24V**
- **22kHz Tone:** Pull-down menu to select: **Enabled/Disabled**
- **Spectral Inversion:** Pull-down menu to select: **Normal/Inverted**

- **LO Frequency:** The LNB local oscillator frequency
- **L-Band Frequency:** The LNB L-band IF output frequency (computed and entered automatically)

4.2.1.3 Package Multicast

The **Package Multicast** section contains the following fields:

- **IP Address:** The multicast group IP address
- **Port Numbers:** The port number receiving the multicast
- **Credentials:** The number used for multicast firmware image download



NOTE: The above fields must match the iBuilder multicast package or options file download dialog boxes. If they do not match, the package or options download will fail.

4.2.2 Configuration From File

Figure 4-4 shows the Configuration From File section of the Downstream Configuration page.

▼ Configuration From File

Please select a Downstream Configuration file (*.json):

→ C:\DS Config\rx_template.json

Figure 4-4. Configuration From File

Use this section to select a **Downstream Configuration** file. For example, a JSON (JavaScript Object Notation) file as shown below:

```
{
  "frequency": 12000.5678,
  "symbolRate": 1000.123,
  "rolloff": 0.20,
  "lnb": {
    "dcVoltage": 0,
    "toneEnabled": false,
    "spectralInversion": false,
    "translation": 10600.1234
  },
  "multicast": {
```

```

    "address": "239.192.0.0",
    "port": 9000,
    "credentials": 1
  }
}

```

After making a selection, use the **Apply** button to load the file.

4.3 Geo Location

Figure 4-5 shows the Geo Location section of the Commissioning page.

The screenshot shows a web interface titled "Geo Location". Below the title is a tab labeled "Remote". Under this tab, there are two rows of controls. The first row is for "Latitude", showing a numerical input field with "0.000000", a set of up/down arrows, and a dropdown menu currently set to "Deg. North". The second row is for "Longitude", showing a numerical input field with "0.000000", a set of up/down arrows, and a dropdown menu currently set to "Deg. East". Below these controls is a button labeled "Set Location".

Figure 4-5. Geo Location

The Geo Location section contains the following fields:

- **Latitude:** Use the arrows to increment or decrement the numerical latitude of the satellite router in degrees north or south
- **Longitude:** Use the arrows to increment or decrement the numerical longitude of the satellite router in degrees east or west
- **Deg. North or Deg. South:** Use the arrow to select a latitude of north or south in relation to the equator
- **Deg. East or Deg. West:** Use the arrow to select a longitude of east or west in relation to the Prime (Greenwich) Meridian




NOTE: This page operates differently depending on the mode selection at the Remote Geo Location Tab in iBuilder.

- In **Stationary** mode, it shows the configuration from the options file from iBuilder
- In **Mobile → Manual** mode, it allows the user to enter a value (Mobile mode applies only to the X7)
- In **Mobile → Antenna** or **Mobile → Serial** mode, an external GPS receiver updates the fields automatically with the latitude and longitude
- If **Mobile Security** is checked, the fields show nothing to protect the terminals geo-location information

4.4 Angle Calculator Page

The Web iSite Angle Calculator page assists with preliminary antenna pointing. See [Figure 4-6](#).



The screenshot shows a web interface titled "Angle Calculator". It contains four expandable sections, each with a right-pointing arrow icon: "Remote Location", "Spacecraft Position", "Elevation", and "Gross Antenna Pointing".

Figure 4-6. Angle Calculator

Given the appropriate values, the Angle Calculator determines the **Polarization Offset**, **Azimuth True**, and **Elevation Actual**.


The modifiable fields contain values derived from the options file for the satellite router. If an options file has not been loaded, the fields have an initial value of 0.0. All other fields will be blank.

The **Angle Calculator** page contains the following sections that are described in the paragraphs that follow:

- Remote Location
- Spacecraft Position
- Elevation
- Gross Antenna Pointing

4.4.1 Remote Location

[Figure 4-7](#) shows the Remote Location section of the Angle Calculator page.



The screenshot shows the "Remote Location" section of the Angle Calculator. It has a title bar with a downward arrow. Below the title bar, there are two rows of input fields. The first row is labeled "Latitude:" and contains a text box with the value "45.2892", a small up/down arrow button, and a dropdown menu currently set to "Deg. North". The second row is labeled "Longitude:" and contains a text box with the value "104.1570", a small up/down arrow button, and a dropdown menu currently set to "Deg. East".

Figure 4-7. Remote Location

The **Remote Location** section contains the following fields:

- **Latitude:** Use the arrows to increment or decrement the numerical latitude of the satellite router in degrees north or south
- **Longitude:** Use the arrows to increment or decrement the numerical longitude of the satellite router in degrees east or west

- **Deg. North or Deg. South:** Use the arrow to select a latitude of north or south in relation to the equator
- **Deg. East or Deg. West:** Use the arrow to select a longitude of east or west in relation to the Prime (Greenwich) Meridian



NOTE: The data in this section differs from the data in the **Geo Location** section in that this data is used for computing look angles.

4.4.2 Spacecraft Position

Figure 4-8 shows the **Spacecraft Position** section of the **Angle Calculator** page.

▼ Spacecraft Position

Longitude: 85.9877 Deg. West

Figure 4-8. Spacecraft Position

The **Spacecraft Position** section contains the following fields:

- **Longitude:** Use the arrows to increment or decrement the numerical longitude of the satellite router in degrees east or west
- **Deg. East or Deg. West:** Use the arrows to select a longitude of east or west in relation to the Prime (Greenwich) Meridian

4.4.3 Elevation

Figure 4-9 shows the **Elevation** section of the **Angle Calculator** page.

▼ Elevation

Elevation True: -49.5 deg. Horizontal = 0 deg. Straight up = +90 deg.

Elevation Offset: 17.1 deg.

Figure 4-9. Elevation

The **Elevation** section contains the following fields:

- **Elevation True:** The angle to the spacecraft if the antenna had no offset at all. This value is derived from the site geo-coordinates and the spacecraft longitude. It does not include antenna offset.
- **Elevation Offset:** The offset angle of the antenna (i.e., the degree to which the mechanical axis of the antenna feed is different from the optical axis).

4.4.4 Gross Antenna Pointing

Figure 4-10 shows the **Gross Antenna Pointing** section of the **Angle Calculator** page.

▼ Gross Antenna Pointing		
Elevation Actual:	<input type="text" value="-66.6"/> deg.	Actual = True - Offset
Azimuth True:	<input type="text" value="194.1"/> deg.	Geographic north = 0 deg.
Polarization Offset:	<input type="text" value="-9.9"/> deg.	Polarization Angle Sense

Figure 4-10. Gross Antenna Pointing

The Gross Antenna Pointing section contains the following fields:

- **Elevation Actual:** The calculated elevation of the mechanical axis of the antenna reflector
- **Azimuth True:** The calculated true azimuth to the spacecraft, referenced to geographic North (does not include magnetic variation)
- **Polarization Offset:** The calculated polarization skew angle

4.5 Antenna Pointing Page

Figure 4-11 shows the graph portion of the Antenna Pointing page that assists with antenna pointing.




Figure 4-11. Antenna Pointing Graph

The tool itself is a color-coded graphical voltage display that simplifies the task of locking on to the downstream carrier.

As the user manipulates the antenna azimuth plane in a slow sweeping motion, the graph displays a voltage reading in the range of 0 to 20 VDC. The display indicates the signal strength as well as when the remote satellite router is successfully locked onto the satellite and downstream carrier.

Higher levels indicate more energy in the configured frequency and symbol rate (higher numbers are better). The SNR value will only be reported if the demodulator has locked to the signal (voltage is in the 10-20 VDC range).

Figure 4-12 shows how Volts DC relates to available Antenna Status.

Volts DC	Antenna Status
0 - 2	Not in pointing mode, hardware problem, or off satellite
2 - 8	Detecting RF energy, but not locked on the downstream carrier
10 - 20	Locked on the downstream carrier

Figure 4-12. Volts DC and Antenna Status

The graphical display of the voltage range is color-coded as follows:

- 0-2 VDC is RED
- 2-10 VDC is YELLOW
- 10-20 VDC is GREEN

As the signal strength increases, the graph turns RED, then YELLOW, and then GREEN as the antenna locks on the downstream carrier.



NOTE: For full information and specific details on installing and commissioning the X1, X7, and X7-ER Satellite Routers, refer to the *iDirect Satellite Routers Installation and Commissioning Guide*.

4.6 Cross Polarization Test Page

Figure 4-13 shows the Cross Polarization Test page.

Cross Polarization Test

Transmit Frequency

Transmit Power

Modulator

Start

Stop

WARNING!

Do not click the Start button until instructed to do so by the satellite provider.

When you do click Start, this Satellite Modem will start transmitting a Continuous Wave (CW).

Figure 4-13. Cross Polarization Test



NOTE: Refer to the *Satellite Router Installation and Commissioning Guide* for complete instructions on commissioning the Satellite Router including the performance of the cross polarization test.

The **Cross Polarization Test** page supports the transmission of a modulated or unmodulated continuous wave (CW) as part of the test. The cross polarization test is performed under the direction of the satellite access control center.

The three sections of this page include:

- Transmit Frequency
- Transmit Power
- Modulator

4.6.1 Transmit Frequency

Figure 4-14 shows the Transmit Frequency section of the Cross Polarization page.

The screenshot shows a web interface titled "Transmit Frequency" with a dropdown arrow. It contains three input fields and associated text:

- RF uplink frequency:** A text box containing "950" followed by "MHz". To the right, red text says "Attention! Obtain this test frequency from the satellite provider."
- BUC LO frequency:** A text box containing "0" followed by "MHz". To the right, text lists frequency bands: "Extended Ku-Band = 12,800 MHz", "Ku-Band = 13,050 MHz", and "C-Band = 4,900 MHz".
- L-Band TX frequency: (absolute value):** A text box containing "950" followed by "MHz". To the right, red text says "Attention! Verify the L-Band TX Frequency with the network help desk operator. Range is from 950 MHz to 1,700 MHz."

Figure 4-14. Transmit Frequency (e150 and X1)

The screenshot shows a web interface titled "Cross Polarization Test" with a dropdown arrow for "Transmit Frequency". It contains three input fields and associated text:

- RF Uplink Frequency:** A text box containing "950" followed by "MHz". To the right, red text says "Attention! Obtain this test frequency from the satellite provider."
- BUC LO Frequency:** A text box containing "0" followed by "MHz". To the right, text lists frequency bands: "Extended Ku-Band = 12,800 MHz", "Ku-Band = 13,050 MHz", and "C-Band = 4,900 MHz".
- L-Band TX Frequency: (absolute value):** A text box containing "950" followed by "MHz". To the right, red text says "Attention! Verify the L-Band TX Frequency with the network help desk operator. Range is from 950 MHz to 1,950 MHz."

Figure 4-15. Transmit Frequency (X7 or X7-ER)

The fields in this section provide the setup for the cross-polarization test:

- **RF Uplink Frequency:** This is the over-the-air test frequency obtained from the satellite provider and entered by the user
- **BUC LO (local oscillator) Frequency:** Typically populated from the options file for the satellite router; user can change by entering new frequency in this field
- **L-Band Tx Frequency:** Automatically calculated and displayed

Frequency, BUC LO Frequency, and L-Band TX Frequency field values should fall within the following ranges:


- RF Uplink Frequency — 950 MHz minimum

- BUC LO Frequency — 0 MHz minimum
- L-Band TX Frequency — 950 MHz to 1,700 MHz for the e150 and X1 and 950 MHz to 1,950 MHz for the X7

If a field value exceeds the expected range, a red exclamation mark appears beside the field.

4.6.2 Transmit Power

Figure 4-16 shows the Transmit Power section of the Cross Polarization page.



▼ Transmit Power

Adjust Transmit Power: dBm


Figure 4-16. Transmit Power

The installer adjusts the **Adjust Transmit Power** field under the direction of the satellite access control center when performing the 1 db compression test while monitoring the Carrier Wave (CW).

After the test starts, the installer typically adjusts the value in 1 db increments for the X1 or 0.5 dB increments for the X7 under the guidance of the satellite access controller.

4.6.3 Modulator

Figure 4-17 shows the Modulator section of the Cross Polarization page.



▼ Modulator

Modulation:

Symbol Rate: ksym/s

Figure 4-17. Modulator

The cross polarization test supports the testing of a satellite router by transmitting either a modulated or unmodulated carrier at a specific uplink frequency.

The unmodulated carrier is the CW. The modulated carrier is **BSPK 128ksym/s** and cannot be changed.

Using the **Modulation** option button, a user can switch between continuous-wave or modulated emission. Switch modulation **On** only after receiving clearance to do so by the satellite access control center.

5 Admin Pages

This chapter describes the Admin pages. It contains the following sections:

- [Overview on page 51](#)
- [File Management Page on page 51](#)

5.1 Overview

Clicking on the **Admin** button causes the left navigation bar to display the **Admin** page group. See [Figure 5-1](#).




Figure 5-1. Left Navigation Bar Showing Admin Page Group

This also causes the **File Management** page (the default page for the **Admin** page group) to open. See [Figure 5-2](#). This page provides additional tools for troubleshooting or commissioning of the remote.



NOTE: Access to the **Admin** page group is available only when logged-in as **Admin**.

5.2 File Management Page

[Figure 5-2](#) shows the **File Management** page.




Figure 5-2. File Management

Use the **File Management** page to load the required software during the commissioning process.

The topics in this section describe how to use the **File Management** page sections. For complete instructions on performing installation and commissioning tasks, see the *Satellite Router Installation and Commissioning Guide*.

This page contains the following sections that are described in the paragraphs that follow:

- Software Loaded
- Load Package
- Load Options File
- Retrieve Options File
- Restart Device



WARNING: Use of Web iSite for loading of the remote package file and options file is typically performed only during commissioning or troubleshooting. Both files are loaded at this time. After the commissioning, the package and options file are generally downloaded from the network over-the-air

5.2.1 Software Loaded

Figure 5-3 shows the **Software Loaded** section.

▼ Software Loaded		
Software	Information	
Factory	Name:	evo_x7_factory-14.0.0.0.pkg
	Description:	Factory ROOTFS Install
	Version:	IDS-14.0.0.0-Build-650
	Timestamp:	Tue Apr 2, 2013, 17:04:36
Version 1 (current)	Name:	evo_x7_rmt-14.0.0.0.pkg
	Description:	Applications and Images
	Version:	IDS-14.0.0.0-Build-738
	Timestamp:	Thu May 9, 2013, 19:17:40
Version 2	Name:	evo_x7_rmt-14.0.0.0.pkg
	Description:	Applications and Images
	Version:	IDS-14.0.0.0-Build-711
	Timestamp:	Tue Apr 30, 2013, 08:15:01

Figure 5-3. Software Loaded

5.2.2 Load Package

Figure 5-4 shows the Load Package section.




Figure 5-4. Load Package

Use the Load Package section to load the model-specific software image, referred to as the *package* file.

5.2.3 Load Options File

Figure 5-5 shows the Load Options File section.




Figure 5-5. Load Options File

Use the **Load Options File** section to load the iBuilder configured options for a specific remote site.

5.2.4 Retrieve Options File

Figure 5-6 shows the Retrieve Options File section.




Figure 5-6. Retrieve Options File

Click **View** to open the active options file. Figure 5-7 shows part of a sample options file. Click **Download** to save the active options file to the local PC or laptop.

Options File

[Download](#)

```
[BTP]
    device_mode = tdma
    device_name = btp
    device_path = /dev

[BTP_REQ]
    device_mode = tdma
    device_name = btp_req
    device_path = /dev

[COMPRESSION]
    Threshold = 90

[DEBUG]
    cpu_util_test_enabled = 0

[DVBS2]
    frame_length = 125.000000
    frame_size = short
    mode = acm
    ncr_interval = 3375000
    pilot = 1
    rc_roll_off = 0.200000

[ENC]
    auth_level_required = 0
    enc_enabled = 0
    enc_layer_enabled = 0
    enc_mode = 0
    peer_mode = 1

[ETH0]
    interface = eth0
    phy_count = 8

[ETH0_1]
    address = 192.168.0.1
    netmask = 255.255.255.0
    rip_enabled = 0
```

Figure 5-7. Excerpt from Sample Options File

5.2.5 Restart Device

Figure 5-8 shows the Restart Device section.




Figure 5-8. Restart Device

Click **Restart** to re-initialize the remote. (This action is equivalent to a power-on reset.)

5.2.6 Load Package



NOTE: Loading a package can be done locally using Web iSite or over-the-air using the DS Configuration Template with iBuilder. This procedure shows how to load the package with Web iSite. For information on using the DS Configuration Template, see the *Installation and Commissioning Guide*.

It may be necessary to load the satellite router with the appropriate package file for the specific iDX release. The package file is available from the iDirect TAC Web site at <http://tac.idirect.net> for storage on a local PC.

To load a Package file on the satellite router, perform the following steps:

1. Click the **Browse** button in the **Load Package** section of the **File Management** page, to locate the appropriate package file. See Figure 5-9.




Figure 5-9. Locating the Package File

2. With the package file selected, click the **Load** button. See Figure 5-10.




Figure 5-10. Load Button

- Wait until the **Load Package** prompt message indicates that the package was successfully saved to the remote. See [Figure 5-11](#).



NOTE: This step may take several minutes to complete.




Figure 5-11. Load Package Success Message

- Close the message dialog and continue with the following steps under **Load Options File** to load the options file to the satellite router.

5.2.7 Load Options File



NOTE: Loading an options file can be done locally using Web iSite or over-the-air using the DS Configuration Template with iBuilder. This procedure shows how to load the options file with Web iSite. For information on using the DS Configuration Template, see the *Installation and Commissioning Guide*.

It is necessary to load a satellite router with the site-specific options file created in iBuilder. The options file must be available for loading to the satellite router from the local PC. The Network Operator provides the options file. For more information, see the *iBuilder User Guide*.

To load an options file on the satellite router, perform the following steps:

- Click the **Browse** button in the **Load Options File** section of the File Management page, to locate and select the appropriate options file. See [Figure 5-12](#).




Figure 5-12. Selecting the Options File

- With the options file selected, click the **Load** button. See [Figure 5-13](#).




Figure 5-13. Load Button

3. Wait until the **Load Options File** prompt message indicates that the options file was successfully saved. See [Figure 5-14](#).




Figure 5-14. Options file Success Message

4. Close the message dialog.
5. Click the **Restart** button in the **Restart Device** section. See [Figure 5-15](#).




Figure 5-15. Restart Button

6. Wait until the **Restart** prompt message appears. See [Figure 5-16](#).




Figure 5-16. Restart Prompt

7. Click the **Restart** button or choose the **Cancel** button.
8. After clicking **Restart**, the current Web iSite session logs out. Wait until the power-on self test (POST) has completed. The IP connection is subsequently re-established and the **Login** page appears.

Appendix A Remote Locking for X1 and e150 Satellite Routers

Remote soft, temporary, and hard locking for an X1 or e150 uses a unique Locking Key for each satellite router in combination with a Network Key and a randomly generated Confirmation Word to securely lock satellite routers to a network.

An X1 or e150 can be configured with a hard (permanent) lock. However, during the configuration of a hard lock, the network operator may choose to create a temporary lock. This is to allow a network operator to test the locking of the first X1 or e150, to verify operation, and to record the Netkey Fingerprint that is returned.

A hard locked satellite router cannot be unlocked; it must be returned to iDirect for a Non-Warranty RMA hardware replacement. A Netkey Fingerprint can help to avoid errors when locking the satellite router. The fingerprint identifies the network for the satellite router without revealing the Network Key on the satellite router.

A remote locked with a Soft Lock can be unlocked. A Soft Lock is removed by entering the Confirmation Word provided when the lock was performed. If the Confirmation Word is lost, the soft lock cannot be disengaged. In order to unlock the remote, it must be returned to iDirect for a Non-Warranty RMA hardware replacement.

Remote locking is performed at the operator's own risk. Non-Warranty RMA charges (plus all shipping) apply to all satellite routers returned to iDirect for the purpose of removing a network lock.



WARNING: It is possible to remove a soft lock or temporary lock with Web iSite. However, it is not possible to remove a hard lock with Web iSite. Removing a hard lock requires returning the satellite router to iDirect for a Non-Warranty RMA hardware replacement.



NOTE: Non-Warranty RMA and shipping charges apply to all satellite routers returned to iDirect for the purpose of removing a network lock.

This appendix contains the following sections:

- [Locking an X1 or e150 Overview on page 60](#)
- [Configuring the Network Key on page 60](#)
- [Performing an Temporary Lock on page 60](#)
- [Performing a Soft Lock on page 65](#)

- [Performing a Hard Lock on page 70](#)
- [Non-Warranty RMA Required to Remove Remote Locks on page 74](#)

A.1 Locking an X1 or e150 Overview

Temporary, Soft, and/or Hard locking an X1 or e150 requires the following:

1. Creating the Network Key, at the network level, in iBuilder, and applying the changes. See [Configuring the Network Key on page 60](#).
2. Connecting to the satellite router to be locked and entering the Network Key.
3. Generating the Netkey Fingerprint and Confirmation Word, and recording their values.
4. Entering the Confirmation Word and locking the remote.

A.2 Configuring the Network Key

Remote Locking, whether soft, temporary, or hard, requires the creation of a Network Key before locking the satellite routers to a network. Create the Network Key by configuring the following custom key on the Custom tab for the network in iBuilder:

```
[NETWORK_DEFINITION]
net_key = <Network Key>
```

where <Network Key> is a string of between 5 and 64 alphanumeric characters.

After configuring the custom key in iBuilder, propagate the key to all satellite routers in the network by applying the changes to the network.

During operation, if a locked satellite router receives a Network Key message containing a Network Key that is different from the key set on the satellite router, the satellite router immediately stops sending upstream messages.

A.3 Performing an Temporary Lock

Performing a Temporary Lock is optional. A Temporary Lock allows a network operator to test the locking of the first X1 or e150, to verify operation, and to record the Netkey Fingerprint that is returned. Perform the following steps to temporarily lock the first X1 or e150 to a network.

1. Using a Web browser, connect to the satellite router to be locked and log on as admin. See [Figure A-1](#).

Figure A-1. X1 and e150 Web iSite Login Page



NOTE: Locking a satellite router requires an admin login.

2. Click **Admin** at the top of the Web page.
3. In the browser address bar, type **/#admin-netlock** to the right of the IP address. For example:

<https://192.168.0.1/#admin-netlock>

The Network Lock page appears. See [Figure A-2](#).



NOTE: If the satellite router is locked, only the **Lock Status** section of the page appears.

Figure A-2. Network Lock Page

4. In the **Lock Status** section, verify **State** displays **Unlocked**.
5. In the **Netkey** field, enter the Network Key obtained at [Configuring the Network Key on page 60](#). See [Figure A-3](#).

Network Lock

▼ Lock Status

State:

▼ Lock Remote

Lock type: • A temporary lock is used for testing and is removed after a reboot.
• A soft lock can be removed with a confirmation word.
• A hard lock can never be undone.

Netkey: The Netkey identifies a specific network.

By pressing the Lock button above you will perform the first step of a two-step process of locking this remote to a specific network.

Figure A-3. Entering Network Key

6. Click Lock. The Lock Remote section expands to show the following fields:

- Netkey
- Netkey Fingerprint
- Confirmation Word

See [Figure A-4](#).



NOTE: When locking the satellite router, use the Netkey Fingerprint to catch typographical errors and prevent accidentally locking the satellite router to the wrong network. Record the Netkey Fingerprint value returned when locking the first satellite router to a network. When locking subsequent satellite routers, verify that the Netkey Fingerprint has the same value before confirming the lock.

The screenshot displays the 'Network Lock' interface. It is divided into two main sections: 'Lock Status' and 'Lock Remote'. The 'Lock Status' section shows the current state as 'Temporary lock in progress', with a Netkey of '789jkl' and a Netkey Fingerprint of 'ZzjkLQ'. The 'Lock Remote' section allows for configuring a new lock. It includes fields for 'Lock type' (set to 'temporary'), 'Netkey' (789jkl), and 'Netkey Fingerprint' (ZzjkLQ). A 'Confirmation Word' field is also present, with a hint 'Enter: hf1cM1QFC'. To the right of these fields, there are explanatory bullet points: 'A temporary lock is used for testing and is removed after a reboot.', 'A soft lock can be removed with the Confirmation Word.', and 'A hard lock can never be undone.' Below the fields are 'Confirm' and 'Cancel' buttons. At the bottom, a message states: 'Please verify that the Netkey and Netkey Fingerprint values are correct. You have 60 seconds to confirm.'

Network Lock

▼ Lock Status

State: Temporary lock in progress

Netkey: 789jkl

Netkey Fingerprint: ZzjkLQ

▼ Lock Remote

Lock type: temporary

- A temporary lock is used for testing and is removed after a reboot.
- A soft lock can be removed with the Confirmation Word.
- A hard lock can never be undone.

Netkey: 789jkl

The Netkey identifies a specific network.

Netkey Fingerprint: ZzjkLQ

Verify that this value is correct.

Confirmation Word:

Enter: hf1cM1QFC

Confirm Cancel

Please verify that the Netkey and Netkey Fingerprint values are correct.
You have 60 seconds to confirm.

Figure A-4. Lock Remote Section

7. Perform the following actions:
 - a. Verify the **Netkey**.
 - b. Record the value of the **Netkey Fingerprint**.
 - c. Enter the Confirmation Word in the designated area.

See [Figure A-5](#).

Network Lock

▼ Lock Status

State: Temporary lock in progress

Netkey: 789jkl

Netkey Fingerprint: ZzjklQ

▼ Lock Remote

Lock type: temporary

- A temporary lock is used for testing and is removed after a reboot.
- A soft lock can be removed with the Confirmation Word.
- A hard lock can never be undone.

Netkey: 789jkl

The Netkey identifies a specific network.

Netkey Fingerprint: ZzjklQ

Verify that this value is correct.

Confirmation Word: 1pxxBxuc1

Enter: 1pxxBxuc1

Please verify that the Netkey and Netkey Fingerprint values are correct.
You have 60 seconds to confirm.

Figure A-5. Entering the Confirmation Word

8. Click **Confirm**. The Lock Status section shows the State is Temporarily locked. See [Figure A-6](#).

Network Lock

▼ Lock Status

State: Temporarily locked

Netkey Fingerprint: ZzjklQ

▼ Unlock Remote

Confirmation Word:

This remotod can be unlocked from the network with the correct Confirmation Word.

Figure A-6. Temporarily Locked State

9. Click **Admin** to open the File Management default page. See [Figure A-7](#).




Figure A-7. File Management Default Page

10. Click Restart to reboot. The Restart dialog box appears. See [Figure A-8](#).




Figure A-8. Restart Dialog Box

11. Click Restart.

A.4 Performing a Soft Lock

Perform the following steps to soft lock the first X1 or e150 to a network.

1. Using a Web browser, connect to the satellite router to lock and log on as admin. See [Figure A-9](#).




Figure A-9. X1 and e150 Web iSite Login Page



NOTE: Locking a satellite router requires an admin login.

2. Click **Admin** at the top of the Web page.
3. In the browser address bar, type `/#admin-netlock` to the right of the IP address. For example:

<https://192.168.0.1/#admin-netlock>

This Network Lock page appears. See [Figure A-10](#).



NOTE: If the satellite router is locked, only the Lock Status section of the page appears.

Network Lock

▼ Lock Status

State:

▼ Lock Remote

Lock type:

- A temporary lock is used for testing and is removed after a reboot.
- A soft lock can be removed with a confirmation word.
- A hard lock can never be undone.

Netkey:


The Netkey identifies a specific network.

Lock...

By pressing the Lock button above you will perform the first step of a two-step process of locking this remote to a specific network.

Figure A-10. Network Lock Page

4. In the Lock Status section, verify State displays Unlocked.
5. In the Lock Remote section, select **Soft** from the Lock type drop-down list.
6. In the Netkey field, enter the Network key obtained at [Configuring the Network Key on page 60](#). See [Figure A-11](#).



Network Lock

▼ Lock Status

State:

▼ Lock Remote

Lock type: ▼

- A temporary lock is used for testing and is removed after a reboot.
- A soft lock can be removed with a confirmation word.
- A hard lock can never be undone.

Netkey:

The Netkey identifies a specific network.

By pressing the Lock button above you will perform the first step of a two-step process of locking this remote to a specific network.

Figure A-11. Entering Network Key

7. Click Lock. The Lock Remote section expands to show the following fields:

- Netkey
- Netkey Fingerprint
- Confirmation Word

See [Figure A-12](#).



NOTE: When locking the satellite router, use the Network Key Fingerprint to catch typographical errors and prevent accidentally locking the satellite router to the wrong network. Record the Network Key Fingerprint value returned when locking the first satellite router to a network. When locking subsequent satellite routers, verify that the Network Key Fingerprint has the same value before confirming the lock.

Network Lock

▼ Lock Status

State:

Soft lock in progress

Netkey:

789JKI

Netkey Fingerprint:

ZzJkLQ

▼ Lock Remote

Lock type:

soft

- A temporary lock is used for testing and is removed after a reboot.
- A soft lock can be removed with the Confirmation Word.
- A hard lock can never be undone.

Netkey:

789JKI

The Netkey identifies a specific network.

Netkey Fingerprint:

ZzJkLQ

Verify that this value is correct.

Confirmation Word:

Enter: ED6kiKvsB

Confirm

Cancel

Please verify that the Netkey and Netkey Fingerprint values are correct.

You have 60 seconds to confirm.

WARNING!

This remote will be soft locked to the specified network.

You must record the Confirmation Word in order to unlock the remote later.

Without the Confirmation Word, the unit will have to be returned to iDirect under Non-Warranty Repair.

Figure A-12. Lock Remote Section

8. Perform the following actions:
 - a. Note the warning at the bottom of the page
 - b. Verify the Netkey.
 - c. Verify the value of the Netkey Fingerprint matches the value recorded in [Section A3, Step 7.b.](#)
 - d. Record the Confirmation Word.

WARNING: Recording the Confirmation Word is critical. Without the Confirmation Word, the unit will have to be returned to iDirect under Non-Warranty RMA repair.

NOTE: Each remote has a unique Confirmation Word. It may necessary to maintain and table/database of each remote model, serial number, and Confirmation Word.

- e. Enter the Confirmation Word in the designated area.

See [Figure A-13.](#)

68

Web iSite User Guide
iDX Release 3.3

Network Lock

▼ Lock Status

State:

Netkey:

Netkey Fingerprint:

▼ Lock Remote

Lock type:

- A temporary lock is used for testing and is removed after a reboot.
- A soft lock can be removed with the Confirmation Word.
- A hard lock can never be undone.

Netkey: The Netkey identifies a specific network.

Netkey Fingerprint: Verify that this value is correct.

Confirmation Word: Enter: ED6kiKvsB

Please verify that the Netkey and Netkey Fingerprint values are correct.
You have 60 seconds to confirm.

WARNING!

This remote will be soft locked to the specified network.
You must record the Confirmation Word in order to unlock the remote later.
Without the Confirmation Word, the unit will have to be returned to iDirect under Non-Warranty Repair.

Figure A-13. Entering the Confirmation Word

9. Click **Confirm**. The **Lock Status** section shows the **State** is Soft locked. See [Figure A-6](#).

Network Lock

▼ Lock Status

State:

Netkey Fingerprint:

▼ Unlock Remote

Confirmation Word:

This remotecan be unlocked from the network with the correct Confirmation Word.

Figure A-14. Soft Locked State

10. Click **Admin** to open the **File Management** page. See [Figure A-7](#).




Figure A-15. File Management Default Page

11. Click Restart to reboot. The Restart dialog box appears. See [Figure A-8](#).




Figure A-16. Restart Dialog Box

12. Click Restart.

A.5 Performing a Hard Lock

A hard lock permanently burns the Locking Key into the remote hardware using the generated Confirmation Word.



WARNING: It is possible to remove a soft lock or temporary lock with Web iSite. However, it is not possible to remove a hard lock with Web iSite. Removing a hard lock requires returning the satellite router to iDirect for a Non-Warranty RMA hardware replacement.

To hard lock a remote into the network, do the following:

1. At a Web browser, connect to the satellite router to lock and log on as admin at the Web iSite Login Page. See [Figure A-17](#).

Figure A-17. X1 and e150 Web iSite Login Page



NOTE: Locking a satellite router requires an admin login.

2. Click Admin at the top of the Web page.
3. In the browser address bar, type `/#admin-netlock` to the right of the IP address. For example:

<https://192.168.0.1/#admin-netlock>

This Network Lock appears. See Figure A-18.




NOTE: If the satellite router is locked, only the **Lock Status** section of the page appears.

Figure A-18. Network Lock Page

4. In the **Lock Status** section, verify State displays Unlocked.
5. In the Remote Lock section, select Hard from the Lock type drop-down list.

6. At the Netkey field, enter the Network Key obtained in [Locking an X1 or e150 Overview](#) on page 60. See [Figure A-19](#).



The screenshot shows a web interface titled "Network Lock". It has two main sections: "Lock Status" and "Lock Remote".

- Lock Status:** Contains a "State:" label and a text input field with the value "Unlocked".
- Lock Remote:** Contains:
 - Lock type:** A dropdown menu with "hard" selected. To its right are three bullet points:
 - A temporary lock is used for testing and is removed after a reboot.
 - A soft lock can be removed with a confirmation word.
 - A hard lock can never be undone.
 - Netkey:** A text input field with the value "789jkl". To its right is the text "The Netkey identifies a specific network."
 - A "Lock..." button.

At the bottom of the "Lock Remote" section, there is a note: "By pressing the Lock button above you will perform the first step of a two-step process of locking this remote to a specific network."

Figure A-19. Entering the Network Key

7. Click Lock. The Lock Status section expands to display the following fields:

- Netkey
- Netkey Fingerprint
- Confirmation Word

See [Figure A-20](#).



NOTE: When locking the satellite router, use the Network Key Fingerprint to catch typographical errors and prevent accidentally locking the satellite router to the wrong network. Record the Network Key Fingerprint value returned when locking the first satellite router to a network. When locking subsequent satellite routers, verify that the Network Key Fingerprint has the same value before confirming the lock.

Network Lock

▼ Lock Status

State:

Hard lock in progress

Netkey:

789jkl

Netkey Fingerprint:

ZzjklQ

▼ Lock Remote

Lock type:

hard

- A temporary lock is used for testing and is removed after a reboot.
- A soft lock can be removed with the Confirmation Word.
- A hard lock can never be undone.

Netkey:

789jkl

The Netkey identifies a specific network.

Netkey Fingerprint:

ZzjklQ

Verify that this value is correct.

Confirmation Word:

Enter: r82tZGvPr

Confirm

Cancel

Please verify that the Netkey and Netkey Fingerprint values are correct.

You have 60 seconds to confirm.

WARNING!

This remote will be permanently locked to the specified network.

This lock cannot be changed or removed.

In order to unlock the remote, the unit will have to be returned to iDirect under Non-Warranty Repair.

Figure A-20. Confirmation Word Text Box

8. Perform the following actions:
 - a. Note the warning at the bottom of the page
 - b. Verify the Netkey.
 - c. Verify the value of the Netkey Fingerprint matches the value recorded in [Section A3, Step 7.b.](#)
 - d. Enter the Confirmation Word in the designated area.

See [Figure A-5.](#)

Web iSite User Guide
iDX Release 3.3

73



WARNING: The following step will permanently lock the satellite router to the network. Only a hardware replacement can reverse this lock.

9. Click Confirm. A window opens showing the lock status of the satellite router. See [Figure A-21](#).




Figure A-21. Lock Status



NOTE: Repeat these procedures to lock additional remotes.

A.6 Non-Warranty RMA Required to Remove Remote Locks

It is not possible to change or remove a lock on an Evolution X1 or e150. In order to unlock the satellite router, return it to iDirect for a Non-Warranty RMA hardware replacement.



NOTE: RMA and shipping charges apply to all satellite routers returned to iDirect for the purpose of removing a network lock.

Index

A

- admin account 5
- angle calculator page 44
 - elevation section 45
 - gross antenna pointing section 45- 46
 - remote location section 44
 - spacecraft position section 45
- antenna pointing page 46

B

- browser tab 7

C

- clock adjustment section 38
- commissioning page 39
- commissioning pages
 - antenna pointing page 46
 - cross polarization page 48
- composite power 24
- connection
 - information 27
 - status 27
- CRC 32 25
- CRC 8 25
- cross polarization test page 48
 - modulator section 50
 - transmit frequency section 49
 - transmit power section 50

D

- dashboard page 15
 - equipment details section 16- 17
 - real-time remote events section 18, 35
 - remote information section 16
- data link 17
- default factory settings 2
- default IP address 2
- DHCP mode 31
- DNS section 31
- documents, related xv
- DS Configuration Template 56- 57

E

- elevation offset 45
- equipment details section 16- 17
- Ethernet status page
 - connection section 27
 - receiver section 28
 - transmitter section 27
- ethernet status page 25

F

- factory settings
 - default 2

fields

- 22kHz tone 41
- adjust transmit power 50
- azimuth true 46
- beam ID 24
- beam type 24
- BUC LO frequency 49
- BUC local oscillator freq 35
- BUC spectral inversion 35
- bytes 28
- cache size 32
- CPU load 24
- CRC 32 25
- CRC 8 25
- credentials 42
- data link 17, 23
- DC voltage 41
- default gateway 31
- deg. east or deg. west 45
- deg. north or deg. south 45
- direction 33
- disabled 30
- DNS mode 32
- downlink center freq 34
- downlink center frequency 24
- dropped frames 28
- duplex mode 27
- elevation actual 46
- elevation true 45
- error frames 28
- eth RIPv2 32
- forward queue size 32
- forward timeout 32
- frames 28
- initial Tx Power 25
- IP address 27, 30, 33, 42
- LAN IP address 16
- LAN subnet mask 16
- latitude 25, 44
- L-band IF frequency 42
- L-band Tx frequency 49
- lease range 31
- lease time 31
- LNB local oscillator freq 34
- LNB spectral inversion 34
- login name 16
- longitude 25, 44- 45
- MAC address 22, 27
- max Tx power 25
- model type 16, 22
- netmask 30
- network 17, 23
- network uptime 17, 23
- packet tagging 26
- polarization offset 46

- port numbers 42
- primary DNS 31
- primary DNS name 32
- primary IP address 32
- provisioning key 16, 22
- relay 31
- RF downlink center frequency 41
- RF uplink frequency 49
- role 24
- rolloff 24, 41
- Rx composite power 24
- Rx L-band freq 34
- Rx SNR 25
- sat RIPv2 32
- satellite Rx 17, 23
- satellite Tx 17, 24
- secondary DNS 31
- secondary DNS name 32
- secondary IP address 32
- serial number 16, 22
- server 30
- software version 16, 22
- spectral inversion
 - 41
- speed 27
- status 27
- subnet mask 27
- symbol rate 24, 41
- temperature 24
- Tx power 25
- VLAN ID 26

file management page 51

- restart section 58

frames

- dropped 28
- error 28
- Ethernet 28

frequency

- BUC local oscillator 49
- L-band Tx 49

G

gross antenna pointing section 45- 46

H

hard lock 59

I

information fields 9

initial Tx power 25

IP address

 default 2

IP configuration page

 DHCP section 31

 DNS section 31

 eth interface section 30

 multicast groups 33

 multicast groups section 33

 port forwarding section 33

 port forwarding section 33

 port forwarding 33

 routing 32

 sat interface 30

 static routes 32

 static routes section 32- 33

L

LAN interface section 30

LAN IP address 16

LAN subnet mask 16

latitude 43- 44

LED status indicatorsX1 10, 12

load option file section 57

load package section 56

load, CPU 24

lock

 temporary 60, 65

lock status 61, 66, 74

locking 59- 60

 overview 60

locking key 59

logging in

 passwords 5

login name 16

longitude 43- 44

M

MAC address 22

model type 22

modem information 22

modem information section 22

modem state 22

 modem state parameters 23

modem state section 23

modem status page 21- 22

 modem information section 22

 modem state section 23

 Rx state section 24

 Tx state section 25

modulator section 50

multicast groups section 33

N

navigation bar

 left 8

 top 7

Netkey Fingerprint 62

netkey fingerprint 63, 68, 73

network key 60, 62, 67

 creation 60

 entering 72

network key fingerprint 67, 72

network lock

 removing 74

network reference clock (NCR) 38

O

ODU status page 34

 Rx status section 34

 Tx status section 35

ODU status section 34

P

page

 description 8

 main defaults 9

 sub-page 9

page elements

- browser tab 7
- information fields 9
- left navigation bar 8
- main default pages 9
- page 8
- sections 9
- sub-pages 9
- top navigation bar 7

pages

- angle calculator page 44
- antenna pointing page 46
- commissioning page 15, 21, 39, 51
- dashboard page 15
- modem status page 22
- Satcom graphs page 36

password

- default 5

passwords 5

permanent lock 59

power

- max Tx 25

provisioning key 16, 22

R

real-time remote events page 35

real-time remote events section 18

receiver

- information 28

remote location section 44

remote locking 59

Rx SNR section 37

Rx state 22

- operational parameters 24

Rx state section 24

S

Satcom graphs page 36

- clock adjustment section 38
- Rx SNR section 36
- Tx frequency offset section 37
- Tx power section 37

satellite router

- locking 59
- unlocking 74

section 9

- hiding and unhiding 9

sections

- clock adjustment section 38
- connection section 27
- DNS section 32
- elevation section 45
- equipment details section 16
- gross antenna pointing section 45
- LAN interface section 30
- load options file section 57
- load package section 56
- modulator section 50
- multicast groups section 33
- ODU status section 34
- real-time remote events section 18
- receiver section 28
- remote information section 16
- restart device section 58
- Rx SNR section 37
- Rx state section 24
- static routes section 33
- transmit frequency section 49
- transmit power section 50
- transmitter section 27
- Tx frequency offset section 38
- Tx power section 37
- Tx state section 25

serial number 16, 22

software version 16

speed, connection 27

static routes section 33

status pages

Ethernet status page 26

modem status page 21

Satcom graphs page 36

status, connection 27

subnet mask 30

T

temperature, operating 18

transmit frequency section 49

transmit power section 50

transmitter 27

- information 28

Tx frequency offset section 38

Tx power 25

Tx power section 37

Tx state 22

- transmission parameters 25

Tx state section 25

V

U

voltage range 48

W

up time 35
user account 5
user accounts
 default 5

Web iSite
 features 1
 user interface 6

iDirect

13861 Sunrise Valley Drive, Suite 300

Herndon, VA 20171-6126

+1 703.648.8000

+1 866.345.0983

www.idirect.net

Advancing a Connected World