

# Holy City Audio Forum

Former Home of SpinCAD Designer

[Skip to content](#)

Search...	Search
Advanced search	

[ Moderator Control Panel ]

## Using SpinCAD Designer 04 - Control Panels

Post a reply

Search this topic...	Search
----------------------	--------

1 post • Page **1** of **1**

- [Edit post](#) (./posting.php?mode=edit&f=32&p=1225).
- [Delete post](#) (./posting.php?mode=delete&f=32&p=1225).
- [Report this post](#) (./report.php?f=32&p=1225).
- [Information](#) (./mcp.php?i=main&mode=post\_details&f=32&p=1225&sid=befaf904784df501ab581b011c284453).
- [Reply with quote](#) (./posting.php?mode=quote&f=32&p=1225).

### Using SpinCAD Designer 04 - Control Panels (#p1225)

by **Digital Larry** » Sun May 05, 2013 11:52 am

The 3 sliders along the top edge correspond to Pots 0, 1, and 2 when you use the simulator. These let you control up to 3 parameters in real time. Some of the SpinCADBlocks are designed to let you easily change some aspect of that block (such as a delay line total length, coarse tuning of a ring modulator LFO, filter frequency, etc.) but NOT in real time.

To open a SpinCADBlock's control panel, right-click in the middle of the block.

To hear the effect of the change you made, just run the simulator again. You will not hear any changes you make here while the simulator is running. Just stop and restart to hear the effect.

Top

Post a reply

1 post • Page **1** of **1**

[Return to Installing and Using SpinCAD Designer](#)

Jump to:	Installing and Using SpinCAD Designer	Go
----------	---------------------------------------	----

Quick-mod tools:	Lock topic	Go
------------------	------------	----

## Who is online

Users browsing this forum: **Digital Larry** and 0 guests

Powered by phpBB® Forum Software © phpBB Group

**Administration Control Panel**