

## Holy City Audio Forum

Former Home of SpinCAD Designer

[Skip to content](#)

Search...

[Advanced search](#)

[\[ Moderator Control Panel \]](#)

### Using SpinCAD Designer 02 - moving and deleting blocks

Post a reply

Search this topic...

1 post • Page **1** of **1**

- [Edit post](#) (./posting.php?mode=edit&f=32&p=1210)
- [Delete post](#) (./posting.php?mode=delete&f=32&p=1210)
- [Report this post](#) (./report.php?f=32&p=1210)
- [Information](#) (./mcp.php?i=main&mode=post\_details&f=32&p=1210&sid=020ce5cde84f10b251dd20b61e021a39)
- [Reply with quote](#) (./posting.php?mode=quote&f=32&p=1210)

#### Using SpinCAD Designer 02 - moving and deleting blocks (#p1210)

by **Digital Larry** » Sat May 04, 2013 7:31 am

To move a block, left-click in the middle of the block (where the block name is). The image below shows a little square at the upper left of the block, but this is now gone.

[Image](http://imageshack.us/photo/my-images/441/spincadhandle.png/) (<http://imageshack.us/photo/my-images/441/spincadhandle.png/>)

Now you can drag it to a new location on the screen. Left click again to drop it in place.

To delete a block, select "Edit - Delete" from the menu, then left-click in the middle of the block. The block and its connections are deleted. You have to re-select the delete mode for each block you wish to delete. This is a little dorky. If someone can suggest a better way, I'm interested.

Image uploaded with [ImageShack.us](http://imageshack.us) (<http://imageshack.us>)

[Top](#)

[Post a reply](#)

1 post • Page **1** of **1**

[Return to Installing and Using SpinCAD Designer](#)

Jump to:

Quick-mod tools:

#### Who is online

Users browsing this forum: **Digital Larry** and 0 guests

Powered by [phpBB® Forum Software](#) © [phpBB Group](#)

[Administration Control Panel](#)