

Holy City Audio Forum

Former Home of SpinCAD Designer

Skip to content

Search...

Advanced search

[Moderator Control Panel]

Multiplying two signals with the Volume Block

Post a reply

Search this topic...

1 post • Page **1** of **1**

- [Edit post](#) (./posting.php?mode=edit&f=32&p=1687)
- [Delete post](#) (./posting.php?mode=delete&f=32&p=1687)
- [Report this post](#) (./report.php?f=32&p=1687)
- [Information](#) (./mcp.php?i=main&mode=post_details&f=32&p=1687&sid=90615c931909e0633cbcd2a3573379b1)
- [Reply with quote](#) (./posting.php?mode=quote&f=32&p=1687)

Multiplying two signals with the Volume Block (#p1687)

by **Digital Larry** » Fri Jul 11, 2014 11:35 am

The single Volume block, under the I/O - **Mix** menu, performs a multiply between the "audio" input and the "control" input. In reality, either input could be audio or control. So, you can use this block with a Pot connected at the control input and a different control signal at the "audio" input, to scale that other control signal. If you connect the same signal to both inputs, the output will be the square of that signal.

Top

Post a reply

1 post • Page **1** of **1**

Return to Installing and Using SpinCAD Designer

Jump to:

Quick-mod tools:

Who is online

Users browsing this forum: **Digital Larry** and 0 guests

Powered by phpBB® Forum Software © phpBB Group

Administration Control Panel