

Save Custom Material Settings

Modified on: Wed, 28 Nov, 2018 at 10:41 AM

You can save your own material settings within Mr Beam II.

(Required software versions: MrBeam Plugin 0.1.52 or higher.)

What does it do?

It saves the values of the current laser parameters like laser intensity, speed and number of passes for the engraving and cutting job. These values are what we call material settings because they are very dependent of the kind of material you use. When you use the same material at some point later, you can simply select your pre-saved material settings and are good to go.

How can I use it?

- In the laser parameters screen select a material, color and thickness which is most similar to the one you're using.
- As soon as you modify one of the settings in the lower part, new buttons appear next to your material selection:
- Click **Save custom material** to open a little dialog to save your current intensity, speed and passes values of the engraving and the first cutting job. Before you hit save give it a good name and set the thickness and color values to make your material settings easy to find again once you need it.
- To load these settings any time later simply open the laser parameters screen. You will find a new material with your name in the overview of all materials. Simply select your material, color and thickness and the laser parameters are pre-filled with your values.

Material

ⓘ The below presets are only a guidance, you might need to adjust them to your own material.

Material

Color

Thickness

Kraftplex


0.8 mm

Info ▾

Parameter assignment

Skip

Drag colors on this row to skip them.



Engraving

Laser intensity range


Engraving speed range

0

2000

35

850



Cutting Job 1

Laser Intensity

Laser Speed

Passes

100

225

2

%

mm/min

x

+ Drag colors here for another job +

☐ show advanced settings

Abbruch

Start

Hints and useful Details:

- These values are saved in your custom material settings:
 - Engraving Job: Laser intensity range (values for black and white), Engraving speed range (values for black and white) as well as from advanced settings: Pierce Time and Dithering.
 - Cutting Job: Laser intensity, laser speed, passes and pierce time (advanced settings).
In case you have more than one cutting job in the moment of saving, Mr Beam II automatically chooses the one with the strongest settings assuming that this is the one intended to cut your material all the way through.
- If you choose a thickness value of 0 (zero) in the saving dialog, it's interpreted as "engrave only". This makes sense for a material which you know can not be cut.
- If you enter a custom material name which already exists but a different color or thickness, these new values are simply added to your existing material. If all three values are the same (name, color and thickness), your existing setting is updated/overwritten.
- To delete a custom material settings, click "Manage materials" on the materials overview then click on the trash bin icon which appears on all custom materials. This deletes all settings saved under this name. It's not possible to delete pre-defined material settings.
- If you did not save your material settings and found that they worked great with your material, you can still save them once your laser job has finished by going to the laser parameters screen again as if you were about to do the same job again. If you have not reloaded the page in your browser or turned Mr Beam II off, you still have your settings right there. Just click **Save custom material** and save them.
- At the moment it is not possible to export, import or backup custom material settings.

<https://mr-beam.freshdesk.com/en/support/solutions/articles/43000431865-save-custom-material-settings>

2/3

