



---

# Voyager3-1Z Developers Firmware Guide

*Version 0.3*

---

Created:	6/4/2020
Author:	Sharkey, Tom
Last Modified:	7/1/2021
Modified by:	Sharkey, Tom

---

## 1 Overview

This guide serves as a companion document to the Voyager 1Z Firmware guide. It explains the operation of the Voyager 1Z in a greater level of detail than the original firmware guide, and is aimed towards helping developers who may seek to make changes to the operation of the mote and manager system, and to understand the system of communication between the two in a greater level of detail.

It is advised that the reader has already explored the basic documentation for the Voyager 1Z.

- WCBM-01 Firmware Guide
- CBM\_Setup

These documents are available on the [Voyager-1Z Wiki](#).

## Contents

1 Overview.....	2
2. Header.....	3
2.1 Framing.....	3
2.2 Format of Header.....	4
2.2.1 Axis.....	5
2.2.2 Version.....	5
3. Downstream communication.....	6
3.1 Sampling Frequency.....	6
3.2 Alarm Triggered.....	7
3.3 Axis Received.....	8
3.4 Updating Parameters.....	10

## 2. Header

### 2.1 Framing

Normal operation from mote to manager results in a constant stream of acceleration data, separated into raw data and fft data. In order to create complete “frames”, such that streamed data can be easily interpreted by the GUI, the data must be prepended with a header which contains information about the data contained within the frame. SmartMesh places a limit on the size of the data that can be sent to 90 byte packets. Each individual piece of raw data is a 16-bit integer, corresponding to a reading from the on board ADC.

A header byte is attached to the beginning of a frame which contains information about the frame and creates a separation between frames, as demonstrated in Figure 1.




Figure 1: Forming a correct Data Frame

These checks are reflected in the code for the Python GUI, as shown in Figure 2. Here, `_rx_cnt` is a variable which counts the number of bytes that have been received. This process takes place in the `_handle_bytes` function within the Mote class. If any of the conditions are met which indicate that the frame is not the correct size, `_rx_cnt` is reset to 0.

```
if self._rx_cnt + data_len > len(cur_data): # Restart if we get more data in a frame than expected
    print("[{} {}] Restarting after data overflow".format(id(self), self._rx_cnt))
    self._rx_cnt = 0


if self._rx_cnt > 0 and msb_set: # Restart if we get an alignment bit in the middle of a frame
    print("[{} {}] Restarting after partial frame".format(id(self)))
    self._rx_cnt = 0

if self._rx_cnt == 0 and not msb_set: # Align to the start of a new frame
    print("[{} {}] Waiting for start of new frame".format(id(self)))
    return # Continue count until full frame is reached
```

Figure 2: Forming correct Data Frame (GUI)

## 2.2 Format of Header

The header is broken into 3 parts: The pattern marking the beginning of the header; the pattern which marks the axis of the current data; and the pattern which marks the version of the firmware.



### Sample headers

Header (Hex)	Binary	Interpretation
0xFF93	0b 1111 1111 1001 0011	Header frame, x-axis, version x.03
0xFFA4	0b 1111 1111 1010 0100	Header frame, y-axis, version x.04

Table 1: Sample Headers

As the unique all-1's pattern of the top 8 bits is used to signify a header, if this pattern occurs in a non-header packet, a partial frame error will occur. However, this value will only occur in the data if the accelerometer reads a value above 99.6% of its maximum value.

### 2.2.1 Axis

- 0x0090 → 0000 0000 1001 0000
- 0x00A0 → 0000 0000 1010 0000 -
- 0x00C0 → 0000 0000 1100 0000




Figure 4: Axis Selection to control Plotting

The top 4-bits of the lower byte in the header signify the axis to which the data belongs, as the accelerometer records data in 3 axes. This information can be used by GUI to choose where to plot the relevant raw and FFT data. Importantly, the GUI allows for the sending of specific axes of data.

### 2.2.2 Version

#### Examples

- 0x0000 0000 0000 0002
- 0x0000 0000 0000 0003

The final 4 bits of the header are reserved for the version number of the currently running firmware. This is used as a means of confirming correct operation between firmware and GUI, which must be updated in tandem for the correct operation of the system. This version system is simplistic in order to communicate the version of the program in the least number of bits possible, and so keep the header overhead small. The version number sent is simply the two numbers after the decimal point for the version (1.03). As only four bits are available, this version number must not exceed .15.

N.B. The version of the firmware and the GUI must be updated as changes are made to the system. Both versions are constants defined at the top of the GUI and in the SmartMesh\_RF\_Cog.h file of the firmware respectively. If the versions of GUI and firmware do not match, an error is issued to the user in the GUI command window.

### 3. Downstream communication

In order to control the operation of individual motes, a command packet must be sent to each mote from the GUI. This command packet is used whenever the sampling frequency must be updated for FFT calculation, when an alarm must be triggered, and to communicate which axis information the GUI wants to receive.

Any update to mote operation is sent in the form of a command message, which triggers a specific callback in the motes firmware, as shown in Figure 5.

```
case CMDID_RECEIVE:                                     /* Packet Received notifications */
/* Packet Received notifications are handled here */
/*Setting pointer to payload*/
dn_ipmt_receive_notif = (dn_ipmt_receive_nt*)app_vars.notifBuf;
/*Filling parameter arrays with received values*/
for(int i=0; i<8; i++)
{
    sampFrequencyArray[i] = dn_ipmt_receive_notif->payload[i];
    alarmArray[i]         = dn_ipmt_receive_notif->payload[i+8];
    axisArray[i]          = dn_ipmt_receive_notif->payload[i+16];
}

/*Convert char arrays to long int (32) format*/
samp_frequency = (uint32_t)atol(sampFrequencyArray);
alarm          = (uint8_t)atol(alarmArray);
axis_info      = (uint8_t)atol(axisArray);
```

Figure 5: Mote Command Received

#### 3.1 Sampling Frequency

The variable sampling frequency is updated by the user and used to control the number of timeouts, which controls the time between FFT acquisitions. The updated sampling frequency sent by the user is used to adjust a timer controlling FFT readings. This timer has a timeout of 50us. The number of timeouts needed to create a specific time between ADC readings is calculated based on the sampling frequency.

##### Examples

FFT Sampling Frequency ( $f_s = 1000\text{Hz}$ )

Base Timeout ( $t_B = 10\mu\text{s}$ )

$$\text{Acquisition Time } (t) = \frac{1}{f_s}$$
$$\text{Timeouts Required} = \frac{t}{t_B}$$

##### Example

Sampling Frequency = 1000Hz → 100 timeouts (1000us)

= 2000Hz → 50 timeouts (500us)

### 3.2 Alarm Triggered

The first check that occurs after a command has been received in the firmware is to see if the alarm variable has been set. An alarm command is sent from the GUI to the Mote that triggered it, if a Mote value such as “Peak” acceleration exceeds a user-set value. The LED used is the same green LED that blinks to indicate a successful network has been developed between a mote and a manager. The green LED is disabled on Port 1, Pin 12, and the red LED is enabled on Port 1, Pin 13, as shown in Figure 6.

```
/* Toggle Red LED if alarm has been set, disable Green LED */  
if (alarm)  
{  
    adi_gpio_SetHigh(ADI_GPIO_PORT1, ADI_GPIO_PIN_12);  
    adi_gpio_OutputEnable(ADI_GPIO_PORT1, ADI_GPIO_PIN_12, false);  
    adi_gpio_OutputEnable(ADI_GPIO_PORT1, ADI_GPIO_PIN_13, true);  
    adi_gpio_SetLow(ADI_GPIO_PORT1, ADI_GPIO_PIN_13);  
}
```

*Figure 6: Setting Red LED (Smartmesh\_RF\_Cog.c)*



*Figure 7: Alarm Triggered*

If the alarm variable is not set, the green LED returns to normal operation, blinking if a network still exists between mote and manager.

### 3.3 Axis Received

Based on the axis that the user is interested in, only specific data is communicated by each mote. This can be any combination of the X, Y and Z axes. As normal operation for the mote is to send all 3 axes in order, changing which axis are sent simply adjusts the pointer to the data, as shown in Figure 8.




Figure 8: Sending User Defined Axes

As normal operation for the mote is to send all three axis in the order  $X \rightarrow Y \rightarrow Z$ , variations to this operation simply control the buffer to begin at, and the buffers to exclude, as shown in Figure 9. When all buffers have been sent, the variable txRun is set to 0 signalling the end of transmission to the data handling state machine.

```
switch(axis_info)
{
case XYZ:
case XY:
case XZ:
case X:
case 0:
    pByteBuf = (uint8_t*) adcDataX;
    break;
case YZ:
case Y:
    pByteBuf = (uint8_t*) adcDataY;
    break;
case Z:
    pByteBuf = (uint8_t*) adcDataZ;
    break;
default:
    pByteBuf = (uint8_t*) adcDataX;
}

numBytesLeft = ADC_DATA_SIZE;
txRun = 1;
```

Figure 9: Select Axis Buffer to Begin Sending



```

if (numBytesLeft <= 0)
{
    numBytesLeft = ADC_DATA_SIZE;

    switch(axis_info)
    {
        case XYZ:
        case YZ:
            if(pByteBuf == (uint8_t*)adcDataZ+ADC_DATA_SIZE)
            {
                txRun = 0;
            }
            break;
        case XY:
            if(pByteBuf == (uint8_t*)adcDataY+ADC_DATA_SIZE)
            {
                txRun = 0;
            }
            break;
        case XZ:
            if(pByteBuf == (uint8_t*)adcDataY)
            {
                pByteBuf = (uint8_t*)adcDataZ;
            }
            else
            {
                txRun = 0;
            }
            break;
    }
}

```

*Figure 10: Selecting Axis Buffers to Exclude*

### 3.4 Updating Parameters

Mote variables such as sampling frequency are updated within the “NEW\_PARAMS” state of the data handling state machine in `main_prog.c`. This prevents errors that can occur when a firmware variable is updated instantly upon receiving a downstream command. By defining a specific state for updating these variables, the time at which these updates occur is known to the user, preventing timing-related errors.

As the red LED that signals an alarm (e.g. the mote exceeding a certain value peak acceleration) can be updated at any time, the check for this alarm flag occurs directly after the setting of downstream variables in `SmartMesh_RF_cog.c`.