

Data definition SubCAN FD Airbag

MQB37(W) E/E Architecture Baseline

INTERNAL
—
INTERN

Status: 19.08.2022
Version: V14.08.02
Status: Draft
File: MQBw_Baseline_Airbag_SUBCANFD_KMatrix_Module_V14.08.02E_20220819_MH.xlsx

Author: Michael Hoppmann
ESEK3, mailbox 1681
38436 Wolfsburg
0 536144004
Michael.Hoppmann@volkswagen.de

Reviewer: _____

Author: _____
Michael Hoppmann (ESEK3)

Marco Baade (ESEK3)

Release: _____
Klaus-Dieter Schrader (ESEK)

Nils Feyerabend (ESEK3)

Legend

S Signal is sent from the designated control unit (signal active).
S* Signal is routed by the designated control unit from another bus segment and is supported by at least one control unit or control unit class in the respective vehicle or platform. Please contact the corresponding SG responsible person(s)!
0 Signal cannot be actively operated in the vehicle or the platform and is therefore sent with "0" or init value. Observe bit theory and coordinate with the original transmitter(s)!
0* Signal is routed by the designated control unit from another bus segment, but cannot be actively operated in the respective vehicle or platform and is consequently sent with "0" or init value.
E Signal is received and evaluated by the designated control unit (possibly also routed with gateway functionality) E* signal is routed by the designated control unit to another bus segment (no internal use).
FD In the column "Protocol" "FD" means message in CAN FD frame format, "Classical" means standard CAN 2.0 frame format

Note

In the db editor of Vector the counting method of the bytes is shown starting with start byte 0 (dbc file) and thus different from the xls format (in Excel byte counting method starting with 1, bit counting method starting with 0).



Changes compared to V14.07F of 30.03.2022

New compared to V14.07F of 30.03.2022