

# Integration Manual

for S32K1 UART Driver

Document Number: IM2UARTASR4.4 Rev0000R1.0.1 Rev. 1.0

|   |           |
|---|-----------|
| <b>1 Revision History</b>   | <b>2</b>  |
| <b>2 Introduction</b>   | <b>3</b>  |
| 2.1 Supported Derivatives . . . . .   | 3         |
| 2.2 Overview . . . . .  | 4         |
| 2.3 About This Manual . . . . .   | 4         |
| 2.4 Acronyms and Definitions . . . . .  | 5         |
| 2.5 Reference List . . . . .  | 5         |
| <b>3 Building the driver</b>  | <b>6</b>  |
| 3.1 Build Options . . . . .   | 6         |
| 3.1.1 GCC Compiler/Assembler/Linker Options . . . . .   | 6         |
| 3.1.2 GHS Compiler/Assembler/Linker Options . . . . .   | 9         |
| 3.1.3 IAR Compiler/Assembler/Linker Options . . . . .   | 12        |
| 3.2 Files required for compilation . . . . .  | 14        |
| 3.2.1 Uart Driver Files: . . . . .  | 14        |
| 3.2.2 Uart Driver Generated Files (must be generated by the user using a configuration tool): . . . . . | 15        |
| 3.2.3 Base Files: . . . . .   | 15        |
| 3.2.4 DET Files: . . . . .  | 16        |
| 3.2.5 MCL Files(When DMA or Flexio is used): . . . . .  | 16        |
| 3.2.6 RTE Files: . . . . .  | 16        |
| 3.3 Setting up the plugins . . . . .  | 16        |
| 3.3.1 Location of various files inside the Uart module folder: . . . . .                                | 17        |
| 3.3.2 Steps to generate the configuration: . . . . .  | 17        |
| <b>4 Function calls to module</b>   | <b>18</b> |
| 4.1 Function Calls during Start-up . . . . .  | 18        |
| 4.2 Function Calls during Shutdown . . . . .  | 18        |
| 4.3 Function Calls during Wake-up . . . . .   | 18        |
| <b>5 Module requirements</b>  | <b>19</b> |
| 5.1 Exclusive areas to be defined in BSW scheduler . . . . .  | 19        |
| 5.2 Exclusive areas not available on this platform . . . . .  | 21        |
| 5.3 Peripheral Hardware Requirements . . . . .  | 21        |
| 5.4 ISR to configure within AutosarOS - dependencies . . . . .  | 21        |
| 5.5 ISR Macro . . . . .   | 22        |
| 5.5.1 Without an Operating System . . . . .   | 22        |
| 5.5.2 With an Operating System . . . . .  | 22        |
| 5.6 Other AUTOSAR modules - dependencies . . . . .  | 23        |
| 5.7 Data Cache Restrictions . . . . .   | 23        |
| 5.8 User Mode support . . . . .   | 23        |

|  |           |
|--|-----------|
| 5.8.1 User Mode configuration in the module . . . . .              | 23        |
| 5.8.2 User Mode configuration in AutosarOS . . . . .               | 24        |
| 5.9 Multicore support . . . . .                                    | 24        |
| <b>6 Main API Requirements</b>                                     | <b>25</b> |
| 6.1 Main function calls within BSW scheduler . . . . .             | 25        |
| 6.2 API Requirements . . . . .                                     | 25        |
| 6.3 Calls to Notification Functions, Callbacks, Callouts . . . . . | 25        |
| <b>7 Memory allocation</b>   | <b>30</b> |
| 7.1 Sections to be defined in Uart_MemMap.h . . . . .              | 30        |
| 7.2 Linker command file . . . . .                                  | 31        |
| <b>8 Integration Steps</b>   | <b>32</b> |
| <b>9 External assumptions for driver</b>                           | <b>33</b> |



## Chapter 1

### Revision History

| Revision | Date       | Author       | Description                                  |
|----------|------------|--------------|--|
| 1.0      | 24.02.2022 | NXP RTD Team | Prepared for release RTD S32K1 Version 1.0.1 |

## Chapter 2

### Introduction

- [Supported Derivatives](#)
- [Overview](#)
- [About This Manual](#)
- [Acronyms and Definitions](#)
- [Reference List](#)

This integration manual describes the integration requirements for Uart Driver for S32K1XX microcontrollers.

### 2.1 Supported Derivatives

The software described in this document is intended to be used with the following microcontroller devices of NXP Semiconductors:

- s32k116\_qfn32
- s32k116\_lqfp48
- s32k118\_lqfp48
- s32k118\_lqfp64
- s32k142\_lqfp48
- s32k142\_lqfp64
- s32k142\_lqfp100
- s32k142w\_lqfp48
- s32k142w\_lqfp64
- s32k144\_lqfp48
- s32k144\_lqfp64
- s32k144\_lqfp100

- s32k144\_mapbga100
- s32k144w\_lqfp48
- s32k144w\_lqfp64
- s32k146\_lqfp64
- s32k146\_lqfp100
- s32k146\_mapbga100
- s32k146\_lqfp144
- s32k148\_lqfp100
- s32k148\_mapbga100
- s32k148\_lqfp144
- s32k148\_lqfp176

All of the above microcontroller devices are collectively named as S32K1.

## 2.2 Overview

**AUTOSAR (AUTomotive Open System ARchitecture)** is an industry partnership working to establish standards for software interfaces and software modules for automobile electronic control systems.

AUTOSAR:

- paves the way for innovative electronic systems that further improve performance, safety and environmental friendliness.
- is a strong global partnership that creates one common standard: "Cooperate on standards, compete on implementation".
- is a key enabling technology to manage the growing electrics/electronics complexity. It aims to be prepared for the upcoming technologies and to improve cost-efficiency without making any compromise with respect to quality.
- facilitates the exchange and update of software and hardware over the service life of the vehicle.

## 2.3 About This Manual

This Technical Reference employs the following typographical conventions:

- **Boldface** style: Used for important terms, notes and warnings.
- *Italic* style: Used for code snippets in the text. Note that C language modifiers such "const" or "volatile" are sometimes omitted to improve readability of the presented code.

Notes and warnings are shown as below:

Note

This is a note.

Warning

This is a warning

## 2.4 Acronyms and Definitions

| Term       | Definition                                  |
|------------|---|
| API        | Application Programming Interface           |
| AUTOSAR    | Automotive Open System Architecture         |
| BSMI       | Basic Software Make file Interface          |
| DEM        | Diagnostic Event Manager                    |
| DET        | Development Error Tracer                    |
| DMA        | Direct Memory Access                        |
| ECU        | Electronic Control Unit                     |
| FIFO       | First In First Out                          |
| LSB        | Least Significant Bit                       |
| MCU        | Micro Controller Unit                       |
| MIDE       | Multi Integrated Development Environment    |
| MSB        | Most Significant Bit                        |
| N/A        | Not Applicable                              |
| RAM        | Random Access Memory                        |
| SIU        | Systems Integration Unit                    |
| SWS        | Software Specification                      |
| UART       | Universal asynchronous receiver-transmitter |
| XML        | Extensible Markup Language                  |
| BSW        | Basic Software                              |
| ISR        | Interrupt Service Routine                   |
| OS         | Operating System                            |
| GUI        | Graphical User Interface                    |
| PB Variant | Post Build Variant                          |
| PC Variant | Pre Compile Variant                         |
| LT Variant | Link Time Variant                           |

## 2.5 Reference List

| # | Title                    | Version   |
|---|--------------------------|---|
| 1 | S32K1XX Reference Manual | S32K1xx Series Reference Manual, Rev. 14, 09/2021 |
| 2 | Errata                   | S32K116_0N96V Rev. 22/OCT/2021                    |
|   |                          | S32K118_0N97V Rev. 22/OCT/2021                    |
|   |                          | S32K142_0N33V Rev. 22/OCT/2021                    |
|   |                          | S32K144_0N57U Rev. 22/OCT/2021                    |
|   |                          | S32K144W_0P64A Rev. 22/OCT/2021                   |
|   |                          | S32K146_0N73V Rev. 22/OCT/2021                    |
|   |                          | S32K148_0N20V Rev. 22/OCT/2021                    |
| 3 | Datasheet                | S32K1xx Data Sheet, Rev. 14, 08/2021              |

## Chapter 3

### Building the driver

- [Build Options](#)
- [Files required for compilation](#)
- [Setting up the plugins](#)

This section describes the source files and various compilers, linker options used for building the driver. It also explains the EB Tresos Studio plugin setup procedure.

#### 3.1 Build Options

- [GCC Compiler/Assembler/Linker Options](#)
- [GHS Compiler/Assembler/Linker Options](#)
- [IAR Compiler/Assembler/Linker Options](#)

The RTD driver files are compiled using:

- NXP GCC 9.2.0 20190812 (Build 1649 Revision gaf57174)
- IAR ANSI C/C++ Compiler V8.40.3.228/W32 for ARM Functional Safety
- Green Hills Multi 7.1.6d / Compiler 2020.1.4

The compiler, assembler, and linker flags used for building the driver are explained below.

The TS\_T40D2M10I1R0 part of the plugin name is composed as follows:

- T = Target\_Id (e.g. T40 identifies Cortex-M architecture)
- D = Derivative\_Id (e.g. D2 identifies S32K1 platform)
- M = SW\_Version\_Major and SW\_Version\_Minor
- I = SW\_Version\_Patch
- R = Reserved

##### 3.1.1 GCC Compiler/Assembler/Linker Options

###### 3.1.1.1 GCC Compiler Options



| Compiler Option                       | Description  |
|---------------------------------------|--|
| -mcpu=cortex-m4                       | Targeted ARM processor for which GCC should tune the performance of the code (for S32K14x devices)   |
| -mcpu=cortex-m0plus                   | Targeted ARM processor for which GCC should tune the performance of the code (for S32K11x devices)   |
| -mthumb                               | Generates code that executes in Thumb state  |
| -mlittle-endian                       | Generate code for a processor running in little-endian mode  |
| -mfpv4-sp-d16                         | Specifies the floating-point hardware available on the target (for S32K14x devices)  |
| -mfloat-abi=hard                      | Specifies the floating-point ABI to use. "hard" allows generation of floating-point instructions and uses FPU-specific calling conventions (for S32K14x devices)   |
| -mfpv4-sp-d16                         | Specifies the floating-point hardware available on the target (for S32K11x devices)  |
| -mfloat-abi=soft                      | Specifies the floating-point ABI to use. Specifying "soft" causes GCC to generate output containing library calls for floating-point operations (for S32K11x devices)  |
| -std=c99                              | Specifies the ISO C99 base standard  |
| -Os                                   | Optimize for size. Enables all -O2 optimizations except those that often increase code size  |
| -ggdb3                                | Produce debugging information for use by GDB using the most expressive format available, including GDB extensions if at all possible. Level 3 includes extra information, such as all the macro definitions present in the program |
| -Wall                                 | Enables all the warnings about constructions that some users consider questionable, and that are easy to avoid (or modify to prevent the warning), even in conjunction with macros   |
| -Wextra                               | This enables some extra warning flags that are not enabled by -Wall  |
| -pedantic                             | Issue all the warnings demanded by strict ISO C. Reject all programs that use forbidden extensions. Follows the version of the ISO C standard specified by the aforementioned -std option  |
| -Wstrict-prototypes                   | Warn if a function is declared or defined without specifying the argument types  |
| -Wundef                               | Warn if an undefined identifier is evaluated in an #if directive. Such identifiers are replaced with zero  |
| -Wunused                              | Warn whenever a function, variable, label, value, macro is unused  |
| -Werror=implicit-function-declaration | Make the specified warning into an error. This option throws an error when a function is used before being declared  |
| -Wsign-compare                        | Warn when a comparison between signed and unsigned values could produce an incorrect result when the signed value is converted to unsigned.  |
| -Wdouble-promotion                    | Give a warning when a value of type float is implicitly promoted to double   |
| -fno-short-enums                      | Specifies that the size of an enumeration type is at least 32 bits regardless of the size of the enumerator values.  |

| Compiler Option                 | Description   |
|---------------------------------|---|
| -funsigned-char                 | Let the type char be unsigned by default, when the declaration does not use either signed or unsigned   |
| -funsigned-bitfields            | Let a bit-field be unsigned by default, when the declaration does not use either signed or unsigned   |
| -fomit-frame-pointer            | Omit the frame pointer in functions that don't need one. This avoids the instructions to save, set up and restore the frame pointer; on many targets it also makes an extra register available.   |
| -fno-common                     | Makes the compiler place uninitialized global variables in the BSS section of the object file. This inhibits the merging of tentative definitions by the linker so you get a multiple-definition error if the same variable is accidentally defined in more than one compilation unit |
| -fstack-usage                   | Makes the compiler output stack usage information for the program, on a per-function basis  |
| -fdump-ipa-all                  | Enables all inter-procedural analysis dumps   |
| -c                              | Stop after assembly and produce an object file for each source file   |
| -DS32K1XX                       | Predefine S32K1XX as a macro, with definition 1   |
| -DS32K148                       | Predefine S32K148 as a macro, with definition 1   |
| -DGCC                           | Predefine GCC as a macro, with definition 1   |
| -DUSE_SW_VECTOR_MODE            | Predefine USE_SW_VECTOR_MODE as a macro, with definition 1. By default, the drivers are compiled to handle interrupts in Software Vector Mode   |
| -DI_CACHE_ENABLE                | Predefine I_CACHE_ENABLE as a macro, with definition 1. Enables instruction cache initialization in source file system.c under the Platform driver (for S32K14x devices)  |
| -DENABLE_FPU                    | Predefine ENABLE_FPU as a macro, with definition 1. Enables FPU initialization in source file system.c under the Platform driver (for S32K14x devices)  |
| -DMCAL_ENABLE_USER_MODE_SUPPORT | Predefine MCAL_ENABLE_USER_MODE_SUPPORT as a macro, with definition 1. Allows drivers to be configured in user mode.  |

### 3.1.1.2 GCC Assembler Options

| Assembler Option     | Description  |
|----------------------|--|
| -xassembler-with-cpp | Specifies the language for the following input files (rather than letting the compiler choose a default based on the file name suffix) |
| -mcpu=cortex-m4      | Targeted ARM processor for which GCC should tune the performance of the code (for S32K14x devices)                                     |
| -mcpu=cortex-m0plus  | Targeted ARM processor for which GCC should tune the performance of the code (for S32K11x devices)                                     |
| -mthumb              | Generates code that executes in Thumb state  |
| -c                   | Stop after assembly and produce an object file for each source file  |

### 3.1.1.3 GCC Linker Options

| Linker Option        | Description  |
|----------------------|--|
| -Wl,-Map,filename    | Produces a map file  |
| -T linkerfile        | Use linkerfile as the linker script. This script replaces the default linker script (rather than adding to it)   |
| -entry=Reset_Handler | Specifies that the program entry point is Reset_Handler  |
| -nostartfiles        | Do not use the standard system startup files when linking  |
| -mcpu=cortex-m4      | Targeted ARM processor for which GCC should tune the performance of the code (for S32K14x devices)   |
| -mcpu=cortex-m0plus  | Targeted ARM processor for which GCC should tune the performance of the code (for S32K11x devices)   |
| -mthumb              | Generates code that executes in Thumb state  |
| -mfpu=fpv4-sp-d16    | Specifies the floating-point hardware available on the target (for S32K14x devices)  |
| -mfloat-abi=hard     | Specifies the floating-point ABI to use. "hard" allows generation of floating-point instructions and uses FPU-specific calling conventions (for S32K14x devices)   |
| -mfpu=auto           | Specifies the floating-point hardware available on the target (for S32K11x devices)  |
| -mfloat-abi=soft     | Specifies the floating-point ABI to use. Specifying "soft" causes GCC to generate output containing library calls for floating-point operations (for S32K11x devices)  |
| -mlittle-endian      | Generate code for a processor running in little-endian mode  |
| -ggdb3               | Produce debugging information for use by GDB using the most expressive format available, including GDB extensions if at all possible. Level 3 includes extra information, such as all the macro definitions present in the program |
| -lc                  | Link with the C library  |
| -lm                  | Link with the Math library   |
| -lgcc                | Link with the GCC library  |
| -n                   | Turn off page alignment of sections, and disable linking against shared libraries  |

### 3.1.2 GHS Compiler/Assembler/Linker Options

#### 3.1.2.1 GHS Compiler Options

| Compiler Option   | Description  |
|-------------------|--|
| -cpu=cortexm4     | Selects target processor: Arm Cortex M4 (for S32K14x devices)  |
| -cpu=cortexm0plus | Selects target processor: Arm Cortex M0+ (for S32K11x devices)   |
| -thumb            | Selects generating code that executes in Thumb state   |
| -fpu=vfpv4_d16    | Specifies hardware floating-point using the v4 version of the VFP instruction set, with 16 double-precision floating-point registers (for S32K14x devices) |
| -fsingle          | Use hardware single-precision, software double-precision FP instructions (for S32K14x devices)   |

| Compiler Option            | Description  |
|----------------------------|--|
| -fsoft                     | Specifies software floating-point (SFP) mode. This setting causes your target to use integer registers to hold floating-point data and use library subroutine calls to emulate floating-point operations (for S32K11x devices) |
| -C99                       | Use (strict ISO) C99 standard (without extensions)   |
| -ghstd=last                | Use the most recent version of Green Hills Standard mode (which enables warnings and errors that enforce a stricter coding standard than regular C and C++)  |
| -Osize                     | Optimize for size  |
| -gnu_asm                   | Enables GNU extended asm syntax support  |
| -dual_debug                | Generate DWARF 2.0 debug information   |
| -G                         | Generate debug information   |
| -keeptempfiles             | Prevents the deletion of temporary files after they are used. If an assembly language file is created by the compiler, this option will place it in the current directory instead of the temporary directory                   |
| -Wimplicit-int             | Produce warnings if functions are assumed to return int  |
| -Wshadow                   | Produce warnings if variables are shadowed   |
| -Wtrigraphs                | Produce warnings if trigraphs are detected   |
| -Wundef                    | Produce a warning if undefined identifiers are used in #if preprocessor statements   |
| -unsigned_chars            | Let the type char be unsigned, like unsigned char  |
| -unsigned_fields           | Bitfields declared with an integer type are unsigned   |
| -no_commons                | Allocates uninitialized global variables to a section and initializes them to zero at program startup  |
| -no_exceptions             | Disables C++ support for exception handling  |
| -no_slash_comment          | C++ style // comments are not accepted and generate errors   |
| -prototype_errors          | Controls the treatment of functions referenced or called when no prototype has been provided   |
| -incorrect_pragma_warnings | Controls the treatment of valid #pragma directives that use the wrong syntax   |
| -c                         | Stop after assembly and produce an object file for each source file  |
| -DS32K1XX                  | Predefine S32K1XX as a macro, with definition 1  |
| -DS32K148                  | Predefine S32K148 as a macro, with definition 1  |
| -DGHS                      | Predefine GHS as a macro, with definition 1  |
| -DUSE_SW_VECTOR_MODE       | Predefine USE_SW_VECTOR_MODE as a macro, with definition 1. By default, the drivers are compiled to handle interrupts in Software Vector Mode  |
| -DI_CACHE_ENABLE           | Predefine I_CACHE_ENABLE as a macro, with definition 1. Enables instruction cache initialization in source file system.c under the Platform driver (for S32K14x devices)   |
| -DENABLE_FPU               | Predefine ENABLE_FPU as a macro, with definition 1. Enables FPU initialization in source file system.c under the Platform driver (for S32K14x devices)   |

| Compiler Option                 | Description   |
|---------------------------------|---|
| -DMCAL_ENABLE_USER_MODE_SUPPORT | Predefine MCAL_ENABLE_USER_MODE_SUPPORT as a macro, with definition 1. Allows drivers to be configured in user mode |

### 3.1.2.2 GHS Assembler Options

| Assembler Option           | Description   |
|----------------------------|---|
| -cpu=cortexm4              | Selects target processor: Arm Cortex M4 (for S32K14x devices)                                 |
| -cpu=cortexm0plus          | Selects target processor: Arm Cortex M0+ (for S32K11x devices)                                |
| -preprocess_assembly_files | Controls whether assembly files with standard extensions such as .s and .asm are preprocessed |
| -list                      | Creates a listing by using the name and directory of the object file with the .lst extension  |
| -c                         | Stop after assembly and produce an object file for each source file                           |

### 3.1.2.3 GHS Linker Options

| Linker Option            | Description  |
|--------------------------|--|
| -e Reset_Handler         | Make the symbol Reset_Handler be treated as a root symbol and the start label of the application   |
| -T linker_script_file.ld | Use linker_script_file.ld as the linker script. This script replaces the default linker script (rather than adding to it)  |
| -map                     | Produce a map file   |
| -keepmap                 | Controls the retention of the map file in the event of a link error  |
| -Mn                      | Generates a listing of symbols sorted alphabetically/numerically by address  |
| -delete                  | Instructs the linker to remove functions that are not referenced in the final executable. The linker iterates to find functions that do not have relocations pointing to them and eliminates them  |
| -ignore_debug_references | Ignores relocations from DWARF debug sections when using -delete. DWARF debug information will contain references to deleted functions that may break some third-party debuggers   |
| -Llibrary_path           | Points to library_path (the libraries location) for thumb2 to be used for linking  |
| -larch                   | Link architecture specific library   |
| -lstartup                | Link run-time environment startup routines. The source code for the modules in this library is provided in the src/libstartup directory  |
| -lind_sd                 | Link language-independent library, containing support routines for features such as software floating point, run-time error checking, C99 complex numbers, and some general purpose routines of the ANSI C library (for S32K14x devices) |
| -lind_sf                 | Link language-independent library, containing support routines for features such as software floating point, run-time error checking, C99 complex numbers, and some general purpose routines of the ANSI C library (for S32K11x devices) |
| -v                       | Prints verbose information about the activities of the linker, including the libraries it searches to resolve undefined symbols  |
| -keep=C40_Ip_AccessCode  | Avoid linker remove function C40_Ip_AccessCode from Fls module because it is not referenced explicitly   |

| Linker Option | Description   |
|---------------|---|
| -nostartfiles | Controls the start files to be linked into the executable |

### 3.1.3 IAR Compiler/Assembler/Linker Options

#### 3.1.3.1 IAR Compiler Options

| Compiler Option       | Description  |
|-----------------------|--|
| -cpu=Cortex-M4        | Targeted ARM processor for which IAR should tune the performance of the code (for S32K14x devices)   |
| -cpu=Cortex-M0+       | Targeted ARM processor for which IAR should tune the performance of the code (for S32K11x devices)   |
| -cpu_mode=thumb       | Generates code that executes in Thumb state  |
| -endian=little        | Generate code for a processor running in little-endian mode  |
| -fpu=FPv4-SP          | Use this option to generate code that performs floating-point operations using a Floating Point Unit (FPU). Single-precision variant. (for S32K14x devices)  |
| -fpu=none             | Use this option to generate code that performs floating-point operations using a Floating Point Unit (FPU). No FPU. (for S32K11x devices)  |
| -e                    | Enables all IAR C language extensions  |
| -Ohz                  | Optimize for size. the compiler will emit AEABI attributes indicating the requested optimization goal. This information can be used by the linker to select smaller or faster variants of DLIB library functions |
| -debug                | Makes the compiler include debugging information in the object modules. Including debug information will make the object files larger  |
| -no_clustering        | Disables static clustering optimizations. Static and global variables defined within the same module will not be arranged so that variables that are accessed in the same function are close to each other       |
| -no_mem_idioms        | Makes the compiler not optimize certain memory access patterns   |
| -no_explicit_zero_opt | Do not treat explicit initializations to zero of static variables as zero initializations  |
| -require_prototypes   | Force the compiler to verify that all functions have proper prototypes. Generates an error otherwise   |
| -no_wrap_diagnostics  | Does not wrap long lines in diagnostic messages  |
| -diag_suppress=Pa050  | Suppresses diagnostic message Pa050  |
| -DS32K1XX             | Predefine S32K1XX as a macro, with definition 1  |
| -DS32K148             | Predefine S32K148 as a macro, with definition 1  |
| -DIAR                 | Predefine IAR as a macro, with definition 1  |
| -DUSE_SW_VECTOR_MODE  | Predefine USE_SW_VECTOR_MODE as a macro, with definition 1. By default, the drivers are compiled to handle interrupts in Software Vector Mode.   |

| Compiler Option                 | Description  |
|---------------------------------|--|
| -DI_CACHE_ENABLE                | Predefine I_CACHE_ENABLE as a macro, with definition 1. Enables instruction cache initialization in source file system.c under the Platform driver (for S32K14x devices) |
| -DENABLE_FPU                    | Predefine ENABLE_FPU as a macro, with definition 1. Enables FPU initialization in source file system.c under the Platform driver (for S32K14x devices)                   |
| -DMCAL_ENABLE_USER_MODE_SUPPORT | Predefine MCAL_ENABLE_USER_MODE_SUPPORT as a macro, with definition 1. Allows drivers to be configured in user mode.   |

### 3.1.3.2 IAR Assembler Options

| Assembler Option | Description  |
|------------------|--|
| -cpu=Cortex-M4   | Targeted ARM processor for which IAR should tune the performance of the code (for S32K14x devices) |
| -cpu=Cortex-M0+  | Targeted ARM processor for which IAR should tune the performance of the code (for S32K11x devices) |
| -cpu_mode thumb  | Selects the thumb mode for the assembler directive CODE  |
| -g               | Disables the automatic search for system include files   |
| -r               | Generates debug information  |

### 3.1.3.3 IAR Linker Options

| Linker Option                | Description  |
|------------------------------|--|
| -map filename                | Produces a map file  |
| -config linkerfile           | Use linkerfile as the linker script. This script replaces the default linker script (rather than adding to it)   |
| -cpu=Cortex-M4               | Targeted ARM processor for which IAR should tune the performance of the code (for S32K14x devices)   |
| -cpu=Cortex-M0+              | Targeted ARM processor for which IAR should tune the performance of the code (for S32K11x devices)   |
| -fpu=FPv4-SP                 | Use this option to generate code that performs floating-point operations using a Floating Point Unit (FPU). Single-precision variant. (for S32K14x devices)  |
| -fpu=none                    | Use this option to generate code that performs floating-point operations using a Floating Point Unit (FPU). No FPU. (for S32K11x devices)                    |
| -entry _start                | Treats _start as a root symbol and start label   |
| -enable_stack_usage          | Enables stack usage analysis. If a linker map file is produced, a stack usage chapter is included in the map file  |
| -skip_dynamic_initialization | Dynamic initialization (typically initialization of C++ objects with static storage duration) will not be performed automatically during application startup |
| -no_wrap_diagnostics         | Does not wrap long lines in diagnostic messages  |

### 3.2 Files required for compilation

This section describes the include files required to compile, assemble and link the CDD Uart Driver for S32K1XX microcontrollers.

To avoid integration of incompatible files, all the include files from other modules shall have the same AR\_MAJOR\_VERSION and AR\_MINOR\_VERSION, i.e. only files with the same AUTOSAR major and minor versions can be compiled.

#### 3.2.1 Uart Driver Files:

- Uart\_TS\_T40D2M10I1R0\src\Uart.c
- Uart\_TS\_T40D2M10I1R0\src\Uart\_Ipw.c
- Uart\_TS\_T40D2M10I1R0\src\Lpuart\_Uart\_Ip.c
- Uart\_TS\_T40D2M10I1R0\src\Lpuart\_Uart\_Ip\_Irq.c
- Uart\_TS\_T40D2M10I1R0\src\Flexio\_Uart\_Ip.c
- Uart\_TS\_T40D2M10I1R0\src\Flexio\_Uart\_Ip\_Irq.c
- Uart\_TS\_T40D2M10I1R0\inc\Uart.h
- Uart\_TS\_T40D2M10I1R0\inc\Uart\_Types.h
- Uart\_TS\_T40D2M10I1R0\inc\Uart\_Ipw.h
- Uart\_TS\_T40D2M10I1R0\inc\Uart\_Ipw\_Types.h
- Uart\_TS\_T40D2M10I1R0\inc\Lpuart\_Uart\_Ip.h
- Uart\_TS\_T40D2M10I1R0\inc\Lpuart\_Uart\_Ip\_HwAccess.h
- Uart\_TS\_T40D2M10I1R0\inc\Lpuart\_Uart\_Ip\_Irq.h
- Uart\_TS\_T40D2M10I1R0\inc\Lpuart\_Uart\_Ip\_Types.h
- Uart\_TS\_T40D2M10I1R0\inc\Flexio\_Uart\_Ip.h
- Uart\_TS\_T40D2M10I1R0\inc\Flexio\_Uart\_Ip\_HwAccess.h
- Uart\_TS\_T40D2M10I1R0\inc\Flexio\_Uart\_Ip\_Irq.h
- Uart\_TS\_T40D2M10I1R0\inc\Flexio\_Uart\_Ip\_Types.h



### 3.2.2 Uart Driver Generated Files (must be generated by the user using a configuration tool):

- Uart\_[VariantName]\_PBcfg.c(For PB Variant)
- Uart\_Ipw\_[VariantName]\_PBcfg.c
- Lpuart\_Uart\_Ip\_[VariantName]\_PBcfg.c
- Flexio\_Uart\_Ip\_[VariantName]\_PBcfg.c
- Uart\_[VariantName]\_PBcfg.h
- Uart\_Cfg.h
- Uart\_Defines.h
- Uart\_Ipw\_[VariantName]\_PBcfg.h
- Uart\_Ipw\_Cfg.h
- Lpuart\_Uart\_Ip\_[VariantName]\_PBcfg.h
- Lpuart\_Uart\_Ip\_Cfg.h
- Lpuart\_Uart\_Ip\_Defines.h
- Flexio\_Uart\_Ip\_[VariantName]\_PBcfg.h
- Flexio\_Uart\_Ip\_Cfg.h
- Flexio\_Uart\_Ip\_CfgDefines.h

#### Note

As a deviation from standard:

- Uart\_[VariantName]\_PBcfg.c, Uart\_Ipw\_[VariantName]\_PBcfg.c, Lpuart\_Uart\_Ip\_[VariantName]\_PBcfg.c, Flexio\_Uart\_Ip\_[VariantName]\_PBcfg.c - This file will contain the definition for all parameters that are variant aware, independent of the configuration class that will be selected (PC, LT, PB).

### 3.2.3 Base Files:

- Base\_TS\_T40D2M10I1R0\include\Compiler.h
- Base\_TS\_T40D2M10I1R0\include\Compiler\_Cfg.h
- Base\_TS\_T40D2M10I1R0\include\Mcal.h
- Base\_TS\_T40D2M10I1R0\include\Uart\_MemMap.h
- Base\_TS\_T40D2M10I1R0\include\Platform\_Types.h
- Base\_TS\_T40D2M10I1R0\include\Reg\_eSys.h
- Base\_TS\_T40D2M10I1R0\include\RegLockMacros.h
- Base\_TS\_T40D2M10I1R0\include\Soc\_Ips.h
- Base\_TS\_T40D2M10I1R0\include\StandardTypes.h
- Base\_TS\_T40D2M10I1R0\include\OsIf.h
- Base\_TS\_T40D2M10I1R0\include\Devassert.h
- Base\_TS\_T40D2M10I1R0\header\S32K1XX\_UART.h

### 3.2.4 DET Files:

- Det\_TS\_T40D2M10I1R0\include\Det.h
- Det\_TS\_T40D2M10I1R0\src\Det.c

### 3.2.5 MCL Files(When DMA or Flexio is used):

- Mcl\_TS\_T40D2M10I1R0\include\CDD\_Mcl.h
- Mcl\_TS\_T40D2M10I1R0\src\CDD\_Mcl.c
- Mcl\_TS\_T40D2M10I1R0\include\CDD\_Mcl\_Cfg.h
- Mcl\_TS\_T40D2M10I1R0\src\CDD\_Mcl\_Cfg.c

**Note:** These are the files used for Flexio. In the application, all files in MCL Files must be added.

#### 1. Flexio MCL Driver Files:

- Mcl\_TS\_T40D2M10I1R0\include\Mcl.h
- Mcl\_TS\_T40D2M10I1R0\include\Flexio\_Mcl\_Ip\_HwAccess.h
- Mcl\_TS\_T40D2M10I1R0\include\Flexio\_Mcl\_Ip\_Types.h
- Mcl\_TS\_T40D2M10I1R0\include\Flexio\_Mcl\_Ip.h
- Mcl\_TS\_T40D2M10I1R0\src\Mcl.c
- Mcl\_TS\_T40D2M10I1R0\src\Flexio\_Mcl\_Ip\_HwAccess.c
- Mcl\_TS\_T40D2M10I1R0\src\Flexio\_Mcl\_Ip\_Types.c
- Mcl\_TS\_T40D2M10I1R0\src\Flexio\_Mcl\_Ip.c
- Mcl\_TS\_T40D2M10I1R0\src\Flexio\_Mcl\_Ip\_Irq.c

#### 2. Flexio MCL Driver Generated Files (must be generated by the user using a configuration tool):

- Mcl\_TS\_T40D2M10I1R0\generate\_PC\include\Flexio\_Mcl\_Ip\_Cfg.h
- Mcl\_TS\_T40D2M10I1R0\generate\_PC\include\Flexio\_Mcl\_Ip\_CfgDefines.h
- Mcl\_TS\_T40D2M10I1R0\generate\_PC\include\Flexio\_Mcl\_Ip\_Definitions.h
- Mcl\_TS\_T40D2M10I1R0\generate\_PB\include\Flexio\_Mcl\_Ip\_PBcfg.h
- Mcl\_TS\_T40D2M10I1R0\generate\_PB\include\Flexio\_Mcl\_Ip\_PBcfg.c

### 3.2.6 RTE Files:

- Rte\_TS\_T40D2M10I1R0\include\SchM\_Uart.h
- Rte\_TS\_T40D2M10I1R0\src\SchM\_Uart.c

## 3.3 Setting up the plugins

The Uart Driver was designed to be configured by using the EB Tresos Studio (version 27.1.0 b200625-0900 or later)

### 3.3.1 Location of various files inside the Uart module folder:

- VSMD (Vendor Specific Module Definition) file in EB Tresos Studio XDM format:
  - Uart\_TS\_T40D2M10I1R0\config\Uart.xdm
- VSMD (Vendor Specific Module Definition) file(s) in AUTOSAR compliant EPD format:
  - Uart\_TS\_T40D2M10I1R0\autosar\Uart\_<subderivative\_name>.epd
- Code Generation Templates for variant aware parameters:
  - Uart\_TS\_T40D2M10I1R0\generate\_PB\include\Uart\_PBcfg.h
  - Uart\_TS\_T40D2M10I1R0\generate\_PB\include\Lpuart\_Uart\_Ip\_PBcfg.h
  - Uart\_TS\_T40D2M10I1R0\generate\_PB\include\Flexio\_Uart\_Ip\_PBcfg.h
  - Uart\_TS\_T40D2M10I1R0\generate\_PB\include\Uart\_Ipw\_PBcfg.h
  - Uart\_TS\_T40D2M10I1R0\generate\_PB\src\Uart\_Ipw\_PBcfg.c
  - Uart\_TS\_T40D2M10I1R0\generate\_PB\src\Lpuart\_Uart\_Ip\_PBcfg.c
  - Uart\_TS\_T40D2M10I1R0\generate\_PB\src\Flexio\_Uart\_Ip\_PBcfg.c
  - Uart\_TS\_T40D2M10I1R0\generate\_PB\src\Uart\_PBcfg.c
- Code Generation Templates for parameters without variation points:
  - Uart\_TS\_T40D2M10I1R0\generate\_PC\include\Uart\_Ipw\_Cfg.h
  - Uart\_TS\_T40D2M10I1R0\generate\_PC\include\Uart\_Cfg.h
  - Uart\_TS\_T40D2M10I1R0\generate\_PC\include\Uart\_Defines.h
  - Uart\_TS\_T40D2M10I1R0\generate\_PC\include\Lpuart\_Uart\_Ip\_Cfg.h
  - Uart\_TS\_T40D2M10I1R0\generate\_PC\include\Lpuart\_Uart\_Ip\_Defines.h
  - Uart\_TS\_T40D2M10I1R0\generate\_PC\include\Flexio\_Uart\_Ip\_Cfg.h
  - Uart\_TS\_T40D2M10I1R0\generate\_PC\include\Flexio\_Uart\_Ip\_Defines.h

### 3.3.2 Steps to generate the configuration:

1. Copy the following module folders into the Tresos plugins folder:
  - Base\_TS\_T40D2M10I1R0
  - Det\_TS\_T40D2M10I1R0
  - EcuC\_TS\_T40D2M10I1R0
  - Rte\_TS\_T40D2M10I1R0
  - Resource\_TS\_T40D2M10I1R0
  - Mcu\_TS\_T40D2M10I1R0
  - Uart\_TS\_T40D2M10I1R0
  - Mcl\_TS\_T40D2M10I1R0
  - Os\_TS\_T40D2M10I1R0
2. Set the desired Tresos Output location folder for the generated sources and header files.
3. Use the EB Tresos Studio GUI to modify ECU configuration parameters values.
4. Generate the configuration files

dma\_config

## Chapter 4

### Function calls to module

- [Function Calls during Start-up](#)
- [Function Calls during Shutdown](#)
- [Function Calls during Wake-up](#)

#### 4.1 Function Calls during Start-up

If the Uart peripheral is used, the Uart driver must be initialized before.

The API to be called for the initialization of the driver during STARTUP is

**Uart\_Init(<&Uart\_Configuration>).**

After the Uart module is initialized, each Uart channel has to be initialized as well before using it.

This is also done by the **Uart\_Init(<&Uart\_Configuration>)** service.

The MCU module should be initialized before the Uart driver is initialized.

The PORT and MCL modules (if the DMA option and Flexio module are used) shall be initialized before Uart driver is initialized.

#### 4.2 Function Calls during Shutdown

Uart module can be silenced by calling `Uart_DeInit()`. Note: Ensure that all the hw channels are not in transmission progress. If not, DeInit function will finish unsuccessfully, driver will report the runtime error for channel in the case user enables Det Runtime Report in configuration tools.

#### 4.3 Function Calls during Wake-up

N/A

## Chapter 5

### Module requirements

- Exclusive areas to be defined in BSW scheduler
- Exclusive areas not available on this platform
- Peripheral Hardware Requirements
- ISR to configure within AutosarOS - dependencies
- ISR Macro
- Other AUTOSAR modules - dependencies
- Data Cache Restrictions
- User Mode support
- Multicore support

#### 5.1 Exclusive areas to be defined in BSW scheduler

In the current implementation, UART is using the services of Schedule Manager (SchM) for entering and exiting the critical regions, to preserve a resource. SchM implementation is done by the integrators of the MCAL using OS or non-OS services. For testing the UART, stubs are used for SchM. The following critical regions are used in the UART driver:

**UART\_EXCLUSIVE\_AREA\_00** is used in function `Uart_SyncSend` to protect the `UartState->IsTxBusy` variable from read/modify/write.

**UART\_EXCLUSIVE\_AREA\_01** is used in function `Uart_AsyncSend` to protect the `UartState->IsTxBusy` variable from read/modify/write.

**UART\_EXCLUSIVE\_AREA\_02** is used in function `Uart_SyncReceive` to protect the `UartState->IsRxBusy` variable from read/modify/write.

**UART\_EXCLUSIVE\_AREA\_03** is used in function `Uart_AsyncReceive` to protect the `UartState->IsRxBusy` variable from read/modify/write.

**UART\_EXCLUSIVE\_AREA\_04** is used in function `Uart_AsyncSend` to protect the `UartState->DriverIdle` variable from read/modify/write.

## Module requirements

**UART\_EXCLUSIVE\_AREA\_05** is used in function `Uart_SyncSend` to protect the `UartState->DriverIdle` variable from read/modify/write.

**UART\_EXCLUSIVE\_AREA\_06** is used in function `Uart_AsyncReceive` to protect the `UartState->DriverIdle` variable from read/modify/write.

**UART\_EXCLUSIVE\_AREA\_07** is used in function `Uart_SyncReceive` to protect the `UartState->DriverIdle` variable from read/modify/write.

### Exclusive Areas implemented in Low level driver layer (IPL)

**UART\_EXCLUSIVE\_AREA\_00** is used in function `Lpuart_Uart_Ip_SyncSend` to protect the `UartState->IsTxBusy` variable during the read/write action.

**UART\_EXCLUSIVE\_AREA\_01** is used in function `Lpuart_Uart_Ip_AsyncSend` to protect the `UartState->IsTxBusy` variable during the read/write action.

**UART\_EXCLUSIVE\_AREA\_02** is used in function `Lpuart_Uart_Ip_SyncReceive` to protect the `UartState->IsRxBusy` variable during the read/write action.

**UART\_EXCLUSIVE\_AREA\_03** is used in function `Lpuart_Uart_Ip_AsyncReceive` to protect the `UartState->IsRxBusy` variable during the read/write action.

**UART\_EXCLUSIVE\_AREA\_04** is used in function `Flexio_Uart_Ip_AsyncSend` to protect the `UartState->DriverIdle` variable during the read/write action.

**UART\_EXCLUSIVE\_AREA\_05** is used in function `Flexio_Uart_Ip_SyncSend` to protect the `UartState->DriverIdle` variable during the read/write action.

**UART\_EXCLUSIVE\_AREA\_06** is used in function `Flexio_Uart_Ip_AsyncReceive` to protect the `UartState->DriverIdle` variable during the read/write action.

**UART\_EXCLUSIVE\_AREA\_07** is used in function `Flexio_Uart_Ip_SyncReceive` to protect the `UartState->DriverIdle` variable during the read/write action.

Below is the table depicting the exclusivity between different critical region IDs from the UART driver. If there is an "X" in a table, it means that those 2 critical regions cannot interrupt each other.

**Table 5.1 Exclusive Areas**

| #           | ARE↔<br>A_00 | ARE↔<br>A_01 | ARE↔<br>A_02 | ARE↔<br>A_03 | ARE↔<br>A_04 | ARE↔<br>A_05 | ARE↔<br>A_06 | ARE↔<br>A_07 |
|-------------|--------------|--------------|--------------|--------------|--------------|--------------|--------------|--------------|
| ARE↔<br>_00 | X            | X            |              |              |              |              |              |              |
| ARE↔<br>_01 | X            | X            |              |              |              |              |              |              |
| ARE↔<br>_02 |              |              | X            | X            |              |              |              |              |
| ARE↔<br>_03 |              |              | X            | X            |              |              |              |              |

| #            | ARE↔<br>A_00 | ARE↔<br>A_01 | ARE↔<br>A_02 | ARE↔<br>A_03 | ARE↔<br>A_04 | ARE↔<br>A_05 | ARE↔<br>A_06 | ARE↔<br>A_07 |
|--------------|--------------|--------------|--------------|--------------|--------------|--------------|--------------|--------------|
| AREA↔<br>_04 |              |              |              |              | X            | X            | X            | X            |
| AREA↔<br>_05 |              |              |              |              | X            | X            | X            | X            |
| AREA↔<br>_06 |              |              |              |              | X            | X            | X            | X            |
| AREA↔<br>_07 |              |              |              |              | X            | X            | X            | X            |

## 5.2 Exclusive areas not available on this platform

List of exclusive areas which are not available on this platform (or blank if they're all available).

## 5.3 Peripheral Hardware Requirements

N/A

## 5.4 ISR to configure within AutosarOS - dependencies

*S32K11X derivatives:*

| ISR Name                    | IRQ Number |
|-----------------------------|------------|
| LPUART_UART_IP_0_IRQHandler | 31         |
| LPUART_UART_IP_1_IRQHandler | 30         |
| MCL_FLEXIO_ISR              | 25         |

*S32K14X derivatives(except S32K142):*

| ISR Name                    | IRQ Number |
|-----------------------------|------------|
| LPUART_UART_IP_0_IRQHandler | 31         |
| LPUART_UART_IP_1_IRQHandler | 33         |
| LPUART_UART_IP_2_IRQHandler | 35         |
| MCL_FLEXIO_ISR              | 69         |

*S32K142 derivative:*

| ISR Name                    | IRQ Number |
|-----------------------------|------------|
| LPUART_UART_IP_0_IRQHandler | 31         |

| ISR Name                    | IRQ Number |
|-----------------------------|------------|
| LPUART_UART_IP_1_IRQHandler | 33         |
| MCL_FLEXIO_ISR              | 69         |

## 5.5 ISR Macro

RTD drivers use the ISR macro to define the functions that will process hardware interrupts. Depending on whether the OS is used or not, this macro can have different definitions.

**5.5.1 Without an Operating System** The macro *USING\_OS\_AUTOSAROS* must not be defined.

### 5.5.1.1 Using Software Vector Mode

The macro *USE\_SW\_VECTOR\_MODE* must be defined and the ISR macro is defined as:

```
#define ISR(IsrName) void IsrName(void)
```

In this case, the drivers' interrupt handlers are normal C functions and their prologue/epilogue will handle the context save and restore.

### 5.5.1.2 Using Hardware Vector Mode

The macro *USE\_SW\_VECTOR\_MODE* must not be defined and the ISR macro is defined as:

```
#define ISR(IsrName) INTERRUPT_FUNC void IsrName(void)
```

In this case, the drivers' interrupt handlers must also handle the context save and restore.

**5.5.2 With an Operating System** Please refer to your OS documentation for description of the ISR macro.



## 5.6 Other AUTOSAR modules - dependencies

- **BASE**: The BASE module contains the common files/definitions needed by all MCAL modules.
- **RESOURCE**: Resource module is used to select microcontroller's derivatives.
- **RTE**: The RTE module is needed for implementing data consistency of exclusive areas that are used by UART module.
- **DET**: The DET module is used for enabling Default Error Tracer detection. The API functions used are `Det_ReportError()` and `Det_ReportRuntimeError()`. The activation / deactivation of Default Error Tracer detection is configurable using the "UARTDevErrorDetect" configuration parameter.
- **ECUC**: The ECUC module is used for ECU configuration. MCAL modules need ECUC to retrieve the variant information.
- **PORT**: The PORT module is used to configure the port pins with the needed modes, before they are used by the UART module. For each UART, the SCK, SOUT, SIN and CSx\_y signals need to be configured. In the S32K1XX Reference manual there is an example of the pin configuration. Please refer to the Reference List.
- **MCU**: The MCU driver provides services for basic microcontroller initialization, power down functionality, reset and microcontroller specific functions required by other MCAL software modules. The clocks need to be initialized prior to using the UART driver. The UART reference clock is provided by MCU plugin. The clock frequency may affect the Baudrate, Timing between clock and chip select, Timing between chip select and clock, Timing between chip select assertions. The reference is specified by the parameter `UARTGeneral\UARTClockRef`.
- **MCL**: For each UART in use, a transmit and a receive DMA channel need to be defined and routed through the DMA Multiplexer using MCL plugin. switch to DMA mode.  
For using Flexio Uart. Flexio module need to be configured Flexio Channel and Flexio Pin in MCL.  
In two cases using Flexio or Dma. MCL should be initialized before UART.

## 5.7 Data Cache Restrictions

In the DMA transfer mode, DMA transfers may have cache coherency problems. To avoid possible coherency issues when **D-CACHE** is enabled, the user shall ensure that the buffers used as TCD source and destination are allocated in the **NON-CACHEABLE** area (by means of `Uart_Memmap`). Otherwise, the Uart driver has some dependencies. User must to put all variables, which were used for transmitter and receiver, in the **NON CACHEABLE** memory section in the RAM zone by the definition `UART_START_SEC_VAR_<INIT_POLICY>_<ALIGNMENT>_NO_CACHEABLE` and `UART_STOP_SEC_VAR_<INIT_POLICY>_<ALIGNMENT>_NO_CACHEABLE`.

## 5.8 User Mode support

- [User Mode configuration in the module](#)
- [User Mode configuration in AutosarOS](#)

**5.8.1 User Mode configuration in the module** No special measures need to be taken to run UART module from user mode. The UART driver code can be executed at any time from both supervisor and user mode.

## 5.8.2 User Mode configuration in AutosarOS

When User mode is enabled, the driver may have the functions that need to be called as trusted functions in AutosarOS context. Those functions are already defined in driver and declared in the header `<IpName>_Ip_TrustedFunctions.h`. This header also included all headers files that contains all types definition used by parameters or return types of those functions. Refer the chapter [User Mode configuration in the module](#) for more detail about those functions and the name of header files they are declared inside. Those functions will be called indirectly with the naming convention below in order to AutosarOS can call them as trusted functions.

`Call_<Function_Name>_TRUSTED(parameter1,parameter2,...)`

That is the result of macro expansion `OsIf_Trusted_Call` in driver code:

```
#define OsIf_Trusted_Call[1-6params](name,param1,...,param6) Call_##name##_TRUSTED(param1,...,param6)
```

So, the following steps need to be done in AutosarOS:

- Ensure `MCAL_ENABLE_USER_MODE_SUPPORT` macro is defined in the build system or somewhere global.
- Define and declare all functions that need to call as trusted functions follow the naming convention above in Integration/User code. They need to be visible in `Os.h` for the driver to call them. They will do the marshalling of the parameters and call `CallTrustedFunction()` in OS specific manner.
- `CallTrustedFunction()` will switch to privileged mode and call `TRUSTED_<Function_Name>()`.
- `TRUSTED_<Function_Name>()` function is also defined and declared in Integration/User code. It will un-marshalling of the parameters to call `<Function_Name>()` of driver. The `<Function_Name>()` functions are already defined in driver and declared in `<IpName>_Ip_TrustedFunctions.h`. This header should be included in OS for OS call and indexing these functions.

See the sequence chart below for an example calling `Linflexd_Uart_Ip_Init_Privileged()` as a trusted function.




Figure 5.1 Example sequence chart for calling `Linflexd_Uart_Ip_Init_Privileged` as trusted function

## 5.9 Multicore support

S32K1 family is single core MCUs, so this feature is not available on this kind of platform.

## Chapter 6

### Main API Requirements

- [Main function calls within BSW scheduler](#)
- [API Requirements](#)
- [Calls to Notification Functions, Callbacks, Callouts](#)

#### 6.1 Main function calls within BSW scheduler

N/A

#### 6.2 API Requirements

N/A

#### 6.3 Calls to Notification Functions, Callbacks, Callouts

**Call-back Notifications:** The driver provides callback notifications for asynchronous transfers. The driver gives possibility to configure callbacks for each channel to be called at the end of a transmission.

##### **AUTOSAR Mode:**

*Callback for Receive mode:* In interrupt mode, the callback is called twice. First time is when the Rx buffer is full, giving the opportunity for user to call `Uart_SetBuffer()` in order to provide a new buffer for a continuous reception. If a new buffer is not provided in the first call, a second call is performed for ending a reception. The event parameter in the callback signature is used to distinguish between the two calls. In case of the first one, the parameter is `UART_EVENT_RX_FULL`, while for the second one, the callback parameter is `UART_EVENT←_END_TRANSFER`.

*Callback for Transmit mode:* In case of the Tx callback, the same approach is used. There are also two calls of it during a transmission. In the first call, the event parameter is `UART_EVENT_TX_EMPTY` and indicates that all the bytes from the provided buffer have been sent. In this call, `Uart_SetBuffer()` can be called in order to

## Main API Requirements

change the buffer and transfer more data. In case of the end of transmission (all data has been transferred), a second call is executed with `UART_EVENT_END_TRANSFER` parameter.

*Callback for Error occurred:* The driver treats the following errors: rx overrun, noise error and framing errors. In case of an error detected during an ongoing reception, the transfer is aborted and the callback is called with `UART_EVENT_ERROR` parameter.

-How to config Uart Callback Function:

LPUART: The Uart Callback Function can be configured in the UI in the UartCallback field.

FLEXIO: The Uart Callback Function can be configured in the UI in the Flexio Callback Function field.

### Non-Autosar(Ip) Mode:

*LPUART:*

*\_Lpuart Callback Function:* Lpuart Callback can be configured in the UartCallback field in the Design Studio configurator for the callback functions below:

*Callback for Receive mode:* In interrupt mode, the callback is called twice. First time is when the Rx buffer is full, giving the opportunity for user to call `Lpuart_Uart_Ip_SetRxBuffer()` in order to provide a new buffer for a continuous reception. If a new buffer is not provided in the first call, a second call is performed for ending a reception. The event parameter in the callback signature is used to distinguish between the two calls. In case of the first one, the parameter is `LPUART_UART_IP_EVENT_RX_FULL`, while for the second one, the callback parameter is `LPUART_UART_IP_EVENT_END_TRANSFER`.

*Callback for Transmit mode:* In case of the Tx callback, the same approach is used. There are also two calls of it during a transmission. In the first call, the event parameter is `LPUART_UART_IP_EVENT_TX_EMPTY` and indicates that all the bytes from the provided buffer have been sent. In this call, `Lpuart_Uart_Ip_SetTxBuffer()` can be called in order to change the buffer and transfer more data. In case of the end of transmission (all data has been transferred), a second call is executed with `LPUART_UART_IP_EVENT_END_TRANSFER` parameter.

*Callback for Error occurred:* The driver treats the following errors: rx overrun, noise error and framing errors. In case of an error detected during an ongoing reception, the transfer is aborted and the callback is called with `LPUART_UART_IP_EVENT_ERROR` parameter.

*Parameter for Uart Callback:*

Callback for all peripherals which support UART features

```
typedef void (*Lpuart_Uart_Ip_CallbackType)(const uint8 HwInstance, const Lpuart_Uart_Ip_EventType Event, void *UserData);
```

HwChannel: Lpuart Hardware Channel.

Event: Lpuart Uart event which can trigger UART callback.

UserData: User data passing onto callback function. It is a variable which can be used by the application. If UserData is not desired, the appropriate Param for Uart Callback field shall be left blank.

The screenshot shows the 'UartGlobalConfig' configuration window. The 'UartChannel' section is expanded, showing 'UartChannel\_0'. The 'DetailModuleConfiguration' section is also expanded, showing various configuration parameters. The 'UartCallback' and 'Parameter for Uart Callback' fields are highlighted with yellow boxes.

Figure 6.1 Lpuart Callback Param

**FLEXIO UART:**

- Flexio Callback Function: Flexio Callback can be configured in the Flexio Callback Function field in the Design Studio configurator for the callback functions below:

*Callback for Receive mode:* In interrupt mode, the callback is called twice. First time is when the Rx buffer is full, giving the opportunity for user to call `Flexio_Uart_Ip_SetRxBuffer()` in order to provide a new buffer for a continuous reception. If a new buffer is not provided in the first call, a second call is performed for ending a reception. The event parameter in the callback signature is used to distinguish between the two calls. In case of the first one, the parameter is `FLEXIO_UART_IP_EVENT_RX_FULL`, while for the second one, the callback parameter is `FLEXIO_UART_IP_EVENT_END_TRANSFER`.

*Callback for Transmit mode:* In case of the Tx callback, the same approach is used. There are also two calls of it during a transmission. In the first call, the event parameter is `FLEXIO_UART_IP_EVENT_TX_EMPTY` and indicates that all the bytes from the provided buffer have been sent. In this call, `Flexio_Uart_Ip_SetTxBuffer()` can be called in order to change the buffer and transfer more data. In case of the end of transmission (all data has been transferred), a second call is executed with `FLEXIO_UART_IP_EVENT_END_TRANSFER` parameter.

## Main API Requirements

*Callback for Error occurred:* The driver treats the following errors: rx overrun, noise error and framing errors. In case of an error detected during an ongoing reception, the transfer is aborted and the callback is called with FLEXIO\_UART\_IP\_EVENT\_ERROR parameter.

### Parameter for Callback Function:

Callback for all peripherals which support UART features

```
typedef void (*Flexio_Uart_Ip_CallbackType)(const uint32 HwChannel, const Flexio_Uart_Ip_EventType Event, void *UserData);
```

HwChannel: Flexio Hardware Channel.

Event: Flexio Uart event which can trigger UART callback.

UserData: User data passing onto callback function. It is a variable which can be used by the application. If UserData is not desired, the appropriate Parameter for Transfer Callback field shall be left blank.




Figure 6.2 Flexio Callback Param

**DMA Call-back Notifications:** The DMA Tx/Rx notification must be enabled for the specified Tx/Rx DMA channel. The name of the function to be used as a notification is Lpuart\_X\_Uart\_Ip\_DmaTxCompleteCallback for Tx or Lpuart\_X\_Uart\_Ip\_DmaRxCompleteCallback for Rx in LPUART module, where X is the number of Uart unit used and Flexio\_Y\_Uart\_Ip\_DmaTxCompleteCallback for Tx or Flexio\_Y\_Uart\_Ip\_DmaRxCompleteCallback for Rx in FLEXIO module, where Y is number of FLEXIO channel.

This notification function is filled on both "Interrupt Callback" and "Error Interrupt Callback" field in dma config, refer the Figure 3.17 and Figure 3.19 in User Manual document. The user can perform error checking of the DMA module in the function which is filled in "Error Interrupt Callback" field.

Table 6.1 UART DMA Notification

| Physical Unit | UART TX DMA Notification Name               | UART RX DMA Notification Name               |
|---------------|---|---|
| LPUART_0      | Lpuart_0_Uart_Ip_DmaTxComplete↔<br>Callback | Lpuart_0_Uart_Ip_DmaRxComplete↔<br>Callback |
| LPUART_1      | Lpuart_1_Uart_Ip_DmaTxComplete↔<br>Callback | Lpuart_1_Uart_Ip_DmaRxComplete↔<br>Callback |
| LPUART_2      | Lpuart_2_Uart_Ip_DmaTxComplete↔<br>Callback | Lpuart_2_Uart_Ip_DmaRxComplete↔<br>Callback |
| FLEXIO_0      | Flexio_0_Uart_Ip_DmaTxComplete↔<br>Callback | Flexio_0_Uart_Ip_DmaRxComplete↔<br>Callback |
| FLEXIO_1      | Flexio_1_Uart_Ip_DmaTxComplete↔<br>Callback | Flexio_1_Uart_Ip_DmaRxComplete↔<br>Callback |
| FLEXIO_2      | Flexio_2_Uart_Ip_DmaTxComplete↔<br>Callback | Flexio_2_Uart_Ip_DmaRxComplete↔<br>Callback |
| FLEXIO_3      | Flexio_3_Uart_Ip_DmaTxComplete↔<br>Callback | Flexio_3_Uart_Ip_DmaRxComplete↔<br>Callback |

## Chapter 7

### Memory allocation

- [Sections to be defined in Uart\\_MemMap.h](#)
- [Linker command file](#)

#### 7.1 Sections to be defined in Uart\_MemMap.h

| Section name                                | Type of section    | Description   |
|---|--------------------|---|
| UART_START_SEC_CONFIG_↔<br>DATA_UNSPECIFIED | Configuration Data | Start of the Memory Section for Config Data when the SIZE (alignment) does not fit the criteria of 8,16 or 32 bit.  |
| UART_STOP_SEC_CONFIG_↔<br>DATA_UNSPECIFIED  | Configuration Data | End of the Memory Section for Config Data   |
| UART_START_SEC_CODE                         | Code               | Start of the memory Section for Code  |
| UART_STOP_SEC_CODE                          | Code               | End of the memory Section for Code  |
| UART_START_SEC_VAR_INIT_↔<br>_8             | Variables          | Used for variables, structures, arrays when the SIZE (alignment) fit the criteria of 8 bit.   |
| UART_STOP_SEC_VAR_INIT_↔<br>_8              | Variables          | End of the above section.   |
| UART_START_SEC_VAR_CLEARED_↔<br>UNSPECIFIED | Variables          | Used for variables, structures, arrays when the SIZE (alignment) does not fit the criteria of 8,16 or 32 bit. These variables are cleared to zero by start-up code. |
| UART_STOP_SEC_VAR_CLEARED_↔<br>UNSPECIFIED  | Variables          | End of the above section.   |
| UART_START_SEC_CONST_BOOLEAN                | Configuration Data | Start of the Memory Section for constant data which have to be aligned to boolean type (1 bit).   |
| UART_STOP_SEC_CONST_BOOLEAN                 | Configuration Data | End of the Memory Section for constant data.  |
| UART_START_SEC_CONST_↔<br>UNSPECIFIED       | Configuration Data | Start of Memory Section for constant data when the SIZE (alignment) does not fit the criteria of 8,16 or 32 bit.  |



| Section name  | Type of section                 | Description  |
|---|---------------------------------|--|
| UART_STOP_SEC_CONST_UNSPECIFIED                     | Configuration Data              | End of Memory Section for constant data.   |
| UART_START_SEC_VAR_CLEARED_32                       | Variables                       | Used for variables which have to be aligned to 32 bit. For instance used for variables of size 32 bit or used for composite data types: arrays, structures containing elements of maximum 32 bits. These variables are cleared to zero by start-up code. |
| UART_STOP_SEC_VAR_CLEARED_32                        | Variables End of above section. | End of above section.  |
| UART_START_SEC_VAR_CLEARED_UNSPECIFIED_NO_CACHEABLE | Variables                       | Used for variables, structures, arrays when the SIZE (alignment) does not fit the criteria of 8,16 or 32 bit, and that have to be stored in a non-cacheable memory section. These variables are cleared to zero by start-up code.                        |
| UART_STOP_SEC_VAR_CLEARED_UNSPECIFIED_NO_CACHEABLE  | Variables                       | End of above section.  |

## 7.2 Linker command file

Memory shall be allocated for every section defined in the driver's "<Module>\_MemMap.h.



## Chapter 8

### Integration Steps

This section gives a brief overview of the steps needed for integrating this module:

1. Generate the required module configuration(s). For more details refer to section [Files Required for Compilation](#)
2. Allocate the proper memory sections in the driver's memory map header file ("`<Module>_MemMap.h`") and linker command file. For more details refer to section [Sections to be defined in `<Module>\_MemMap.h`](#)
3. Compile & build the module with all the dependent modules. For more details refer to section [Building the Driver](#)

## Chapter 9

### External assumptions for driver

The section presents requirements that must be complied with when integrating the UART driver into the application.

| External Assumption Req ID | External Assumption Text  |
|----------------------------|---|
| EA_RTD_00071               | If interrupts are locked, a centralized function pair to lock and unlock interrupts shall be used.  |
| EA_RTD_00081               | The integrator shall assure that <MSN>_Init() and <MSN>_DeInit() functions do not interrupt each other.   |
| EA_RTD_00082               | When caches are enabled and data buffers are allocated in cacheable memory regions the buffers involved in DMA transfer shall be aligned with both start and end to cache line size. Note: <b>Rationale:</b> This ensures that no other buffers/variables compete for the same cache lines. |
| EA_RTD_00106               | Standalone IP configuration and HL configuration of the same driver shall be done in the same project   |
| EA_RTD_00107               | The integrator shall use the IP interface only for hardware resources that were configured for standalone IP usage. Note: The integrator shall not directly use the IP interface for hardware resources that were allocated to be used in HL context.                                       |
| EA_RTD_00108               | The integrator shall use the IP interface to build a CDD, therefore the BSWMD will not contain reference to the IP interface  |

**How to Reach Us:**

**Home Page:**

[nxp.com](http://nxp.com)

**Web Support:**

[nxp.com/support](http://nxp.com/support)

Information in this document is provided solely to enable system and software implementers to use NXP products. There are no express or implied copyright licenses granted hereunder to design or fabricate any integrated circuits based on the information in this document. NXP reserves the right to make changes without further notice to any products herein.

NXP makes no warranty, representation, or guarantee regarding the suitability of its products for any particular purpose, nor does NXP assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any and all liability, including without limitation consequential or incidental damages. "Typical" parameters that may be provided in NXP data sheets and/or specifications can and do vary in different applications, and actual performance may vary over time. All operating parameters, including "typicals," must be validated for each customer application by customer's technical experts. NXP does not convey any license under its patent rights nor the rights of others. NXP sells products pursuant to standard terms and conditions of sale, which can be found at the following address: [nxp.com/SalesTermsandConditions](http://nxp.com/SalesTermsandConditions).

NXP, the NXP logo, NXP SECURE CONNECTIONS FOR A SMARTER WORLD, COOLFLUX, EMBRACE, GREENCHIP, HITAG, I2C BUS, ICODE, JCOP, LIFE VIBES, MIFARE, MIFARE CLASSIC, MIFARE DESFire, MIFARE PLUS, MIFARE FLEX, MANTIS, MIFARE ULTRALIGHT, MIFARE4MOBILE, MIGLO, NTAG, ROADLINK, SMARTLX, SMARTMX, STARPLUG, TOPFET, TRENCHMOS, UCODE, Freescale, the Freescale logo, Altivec, C-5, CodeTEST, CodeWarrior, ColdFire, ColdFire+, C-Ware, the Energy Efficient Solutions logo, Kinetis, Layerscape, MagniV, mobileGT, PEG, PowerQUICC, Processor Expert, QorIQ, QorIQ Qonverge, Ready Play, SafeAssure, the SafeAssure logo, StarCore, Symphony, VortiQa, Vybrid, Airfast, BeeKit, BeeStack, CoreNet, Flexis, MXC, Platform in a Package, QUICC Engine, SMARTMOS, Tower, TurboLink, and UMEMS are trademarks of NXP B.V. All other product or service names are the property of their respective owners. ARM, AMBA, ARM Powered, Artisan, Cortex, Jazelle, Keil, SecurCore, Thumb, TrustZone, and Vision are registered trademarks of ARM Limited (or its subsidiaries) in the EU and/or elsewhere. ARM7, ARM9, ARM11, big.LITTLE, CoreLink, CoreSight, DesignStart, Mali, mbed, NEON, POP, Sensinode, Socrates, ULINK and Versatile are trademarks of ARM Limited (or its subsidiaries) in the EU and/or elsewhere. All rights reserved. Oracle and Java are registered trademarks of Oracle and/or its affiliates. The Power Architecture and Power.org word marks and the Power and Power.org logos and related marks are trademarks and service marks licensed by Power.org.

© 2022 NXP B.V.

