

Land Rover Defender

1: General Information

100: Service Information

100-00: General Information

100-01: Identification Codes

100-02: Jacking and Lifting

100-03: Maintenance Schedules

How To Use This Manual

Copyright Statement

Copyright.© Land Rover Ltd., 2005

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system or transmitted in any form, electronic, mechanical, photocopying, recording or other means, without prior written permission of Land Rover Ltd., Banbury Road, Lighthorne, Warwick, CV35 0RG

How to use This Manual

This manual covers all aspects necessary in order to service the vehicle effectively.

The manual is structured into five main sections, General Information, Chassis, Powertrain, Electrical and Body and Paint with each section dealing with a specific part of a vehicle system.

Each of the five main sections contain sub-sections dealing with items which form a part of that specific system.

Pages at the start of the manual list all sections available. Each section has a contents list detailing, where applicable, Specifications, Description and Operation, Diagnosis and Testing, General Procedures and Repair Procedures.

Where components need to be removed or disassembled in sequence, each operation in the sequence will be identified numerically and also graphically in an accompanying illustration.

NOTE:

Dimensions quoted are to design engineering specifications with service limits quoted, where applicable.

Workshop Manual Organization

The five main sections, together with the areas which they cover are given below:

- **Section 1** - General Information.
- **Section 2** - Chassis.
- **Section 3** - Powertrain.
- **Section 4** - Electrical.
- **Section 5** - Body and Paint.

Sub-section numbers appear after the initial section number, for example, **Section 412-03** covers air conditioning, which is part of the electrical section.

In the number given above, the first digit of the number '**4**' indicates the section **i.e. Electrical**.

The second and third digits '**12**' of the number indicate the vehicle system **i.e. Air Conditioning**.

The last two digits of the number '**03**' indicate the part of the system covered by the sub-section **i.e. Air Conditioning Compressor**.

Important Safety Instructions

Safety Notice

Appropriate service methods and correct repair procedures are essential for the safe, reliable operation of all motor vehicles, as well as the safety of the person doing the work. This manual provides general directions for accomplishing service and repair work with tested effective techniques. Following them will help assure reliability.

There are numerous variations in procedures, techniques, tools, and parts for servicing vehicles, as well as in the skill of the person doing the work. This manual cannot possibly anticipate all such variations and provide advice or cautions as to each. Accordingly, anyone who departs from the instructions provided in the manual must first establish that neither personal safety or vehicle integrity is compromised from choices of methods, tools or parts.

General Service Information

Introduction

This manual has been written in a format that is designed to meet the needs of Land Rover technicians worldwide and to assist them in the efficient repair and maintenance of Land Rover vehicles.

This manual provides descriptions and methods for accomplishing adjustment, service and repair work using tested and effective procedures. Following these procedures will help ensure product reliability.

Special Tools

The Special Tool(s) Table provided at the beginning of each procedure lists the special tool(s) required to carry out repair operations within that specific procedure. Wherever possible, illustrations are provided which will assist technicians in identifying the special tool(s) required and also showing such tool(s) in use.

Special tools may be obtained from the manufacturer, SPX Tools, the addresses of their branches will be found in the Special Tools Glossary contained within this Section.

Important Safety Instructions

Appropriate service methods and correct repair procedures are essential for the safe and reliable operation of all motor vehicles as well as ensuring the personal safety of the individual carrying out the work.

This manual cannot possibly anticipate all such variations and provide advice or cautions as to each. Any person who departs from the instructions provided in this manual must first establish that they compromise neither their personal safety nor the vehicle integrity by their choice of methods, tools or parts.

Individuals who undertake their own repairs should have some skill or training and limit repairs to components which could not affect the safety of the vehicle or its passengers. Any repairs required to safety critical items such as steering, brakes, suspension or supplemental restraint system should be carried out by a Land Rover Dealer. Repairs to such items should NEVER be attempted by untrained individuals.

Warnings, Cautions and Notes which appear in this manual

As you read through this manual, you will come across Warnings, Cautions and Notes. A Warning, Caution or Note is placed at the beginning of a series of steps. If the warning, caution or note only applies to one step, it is placed at the beginning of the specific step after the step number.

Warnings, Cautions and Notes have the following meanings:

Warning: Procedures which must be followed to avoid the possibility of personal injury.

Caution: Calls attention to procedures which must be followed to avoid damage to components.

Note: Gives helpful information.

References

References to the Left Hand (LH) or Right Hand (RH) side given in this manual are made when viewing the vehicle or unit from the rear.

Fault Diagnostic Equipment

The vehicle is equipped with a number of electronic control systems to provide optimum performance of the vehicle's systems.

Diagnostic Equipment (T4) is available and must be used where specified. The use of this equipment will assist with the fault diagnostic abilities of the Dealer workshop. In particular, the equipment can be used to interrogate the electronic systems for diagnosis of faults which may become evident during the life of the vehicle.

This manual is produced as a reference source to supplement T4.

Features of the equipment include:

- a. Fully upgradeable support for the technician
- b. Structured diagnostics to accommodate all skill levels
- c. Direct print-out of screen information and test results

Testing the vehicle

Operations covered in this manual do not include reference to testing the vehicle after repair. It is essential that work is inspected and tested after completion and if necessary, a road test of the vehicle is carried out, particularly where safety related items are concerned.

Repairs and Replacement Parts

Land Rover parts are manufactured to the same exacting standards as the original factory fitted components. For this reason, it is essential that only genuine Land Rover parts are used during maintenance or repair.

Attention is particularly drawn to the following points concerning repairs and the fitting of replacement parts and accessories.

Safety features and corrosion prevention treatments embodied in the vehicle may be impaired if other than Land Rover recommended parts are fitted. In certain territories, legislation prohibits the fitting of parts not to manufacturer's specification. Torque wrench setting figures, where given, must be adhered to and locking devices, where specified must be used. If the efficiency of a locking device is impaired during removal it must be replaced.

Owners purchasing accessories whilst travelling abroad must ensure that the accessory and its fitted location on the vehicle conform to legal requirements.

The terms of the vehicle warranty may be invalidated by the fitting of parts other than those recommended by Land Rover.

NOTE:

The fitting of non-approved Land Rover parts and accessories or the carrying out of non-approved alterations or conversions may be dangerous. Any of the foregoing could affect the safety of the vehicle and occupants; also, the terms and conditions of the vehicle warranty may also be invalidated .

All Land Rover recommended parts have the full backing of the vehicle warranty.

Land Rover Dealers are obliged to supply only Land Rover recommended parts.

Specifications

Land Rover are constantly seeking to improve the specification, design and production of their vehicles and alterations take place accordingly. Whilst every effort is made to ensure the accuracy of this Manual, it should not be regarded as an infallible guide to current specifications of any particular vehicle.

This Manual does not constitute an offer for sale of any particular vehicle. Land Rover dealers are not agents of Land Rover and have no authority to bind the manufacturer by any expressed or implied undertaking or representation.

Standard Workshop Practices

Vehicle in Workshop

When working on a vehicle in the workshop always make sure that:

- Where practicable, the parking brake is applied and the wheels are securely chocked to prevent the vehicle moving forwards or backwards.
- Whenever possible, the ignition key is removed before any work is carried out on the vehicle.
- If the engine is to be run, there is adequate ventilation, or an extraction hose is used to remove exhaust fumes.
- There is adequate room to raise the vehicle and remove the wheels, if necessary.
- Fender covers are always installed if any work is to be carried out in the engine compartment.
- Where practicable, the battery is disconnected if working on the engine, underneath the vehicle, or if the vehicle is raised.



CAUTION: When electric arc welding on a vehicle, always disconnect the generator wiring to prevent the possibility of a surge of current causing damage to the internal components of the generator.

- If using welding equipment on the vehicle, a suitable fire extinguisher is readily available.

Battery - General



WARNING: It is essential that a period of 10 minutes elapses after the battery is disconnected before any work is undertaken on any part of the SRS system.



CAUTION: Prior to carrying out any procedures which involve disconnecting/ or connecting the battery, refer to the Electrical Section of this manual - Battery disconnection/connection. For additional information, refer to [Battery](#) (414-01 Battery, Mounting and Cables)



CAUTION: A discharged battery condition may have been caused by an electrical short circuit. If this condition exists there will be an apparently live circuit on the vehicle even when all normal circuits are switched off. This can cause arcing when the jumper cables are connected.

Jump Starting a Vehicle



CAUTION: While it is not recommended that a vehicle is jump started, it is recognized that this may occasionally be the only practical way to mobilize a vehicle. Reference should be made to the following.



CAUTION: It is advisable not to use starter/charger sets for jump starting but if this is unavoidable, make sure that the sets are not used in the 'START' mode.

- Always make sure that the jumper cables are adequate for the task.
- Always make sure that the slave battery is of the same voltage (12 volts) as the vehicle battery. The batteries must be connected in parallel.
- Make sure that the battery terminals of both batteries are fully tightened.
- Where another vehicle is used to jump start a disabled vehicle, make sure that the two vehicles are not

touching.

- It is advisable that the engine of the donor vehicle is switched off during jump starting; take care to make sure that the battery of the donor vehicle does not also become discharged.
- Always make sure that switchable electric circuits are OFF before connecting jump cables. This reduces the risk of arcing occurring when the final connection is made.

Following jump starting of a disabled vehicle, the discharged battery must be checked for serviceability and recharged as soon as possible to avoid permanent damage.

Do not rely on the generator to restore a discharged battery. For a generator to recharge a battery, it would take in excess of eight hours continuous driving with no additional loads placed on the battery.

Trickle charging (defined as voltages <16 volts) may be carried out with the battery connected. Make sure that the battery terminals are fully tightened prior to trickle charging.



CAUTION: Boost charging may only be carried out with the battery disconnected from the vehicle.

Towing the Vehicle



CAUTION: The vehicle has permanent four-wheel drive. The following towing instructions must be adhered to:



CAUTION: The brake servo and power assisted steering system will not be functional without the engine running. Greater pedal pressure will be required to apply the brakes and the steering system will require greater effort to turn the front road wheels. The vehicle tow connection should be used only in normal conditions, 'snatch' recovery should be avoided.

Towing the vehicle on all four wheels with driver operating steering and brakes.

Turn ignition key to position 1 to release steering lock.

Select neutral in main gearbox and transfer box.

Secure tow rope, chain or cable to front towing eyes.

Release the parking brake.

Rear suspended tow by breakdown vehicle



CAUTION: The steering wheel and/or linkage must be secured in the straight ahead position. Do not use the steering lock mechanism for this purpose.

If the front axle is to be trailed turn ignition key to position 1 to release steering lock.

Select neutral in main gearbox and transfer box.

Transporting the vehicle by trailer



CAUTION: Underbody components must not be used as lashing points.

Lashing/towing eyes are provided on front and rear of the chassis side members to facilitate the securing of the vehicle to a trailer or other means of transportation.

Position vehicle on trailer and apply the parking brake. Select neutral in main gearbox.

General installation Instructions

Component removal

Whenever possible, clean components and the surrounding area before removal.

- Blank off openings exposed by component removal.
- Following disconnection, seal fuel, oil or hydraulic lines immediately using suitable blanking plugs or caps.
- Seal open ends of exposed oilways using suitable tapered hardwood plugs or conspicuous plastic plugs.
- Immediately a component is removed, place it in a suitable container; use a separate container for each component and its associated parts.
- Clean bench and provide marking materials, labels and containers before disassembling components.

Disassembling

Observe scrupulous cleanliness when disassembling components, particularly when brake, fuel, air suspension or hydraulic system parts are disassembled. A particle of dirt or cloth fragment could cause a serious malfunction if trapped in these systems.

- Blow out all tapped holes, crevices, oilways and fluid passages with dry, compressed air.



WARNING: Suitable eye protection must be worn.

- Use suitable marker ink to identify mating parts, do not use a scribe or centre punch as they could initiate cracks or distortion.
- Wire or tape mating parts together where necessary to prevent accidental interchange.
- Suitably identify parts which are to be renewed and to those parts requiring further inspection. Keep these parts separate.
- To make sure that the correct replacement part has been obtained, do not discard a part due for renewal until after comparing it with the new part.

Cleaning components

Always use cleaning agents which are suitable for the work being undertaken and the components being cleaned. NEVER use gasoline (petrol) as a cleaning agent (degreaser). Always make sure that the component being cleaned is compatible with the cleaning agent.

Always follow the manufacturer's instructions regarding the use of cleaning agents and make sure that the environment in which the work is being undertaken is suitable. See Health and Safety Precautions for further information regarding cleaning.

General inspection of components

All components should be inspected for wear or damage before reassembling.

- Always make sure that component to be inspected is clean and free from oil or grease.
- When a component is to be checked dimensionally against design specified values, use the appropriate measuring equipment i.e. micrometers, verniers, surface plates, dial test indicators (DTI).
- Always make sure that all measuring equipment is correctly calibrated before use.
- Reject a component which is not within specified values/limits or if it appears to be damaged.
- A component may be re-installed if dimensions obtained during checking are at the maximum tolerance limit and it is in an undamaged condition.
- Bearing journal clearances should be checked where necessary using Plastigage.
- Gaskets, seals and O-ring seals are to be re-used unless damaged.

Joints and Joint Faces

All gaskets should be installed dry unless stated otherwise. Always apply the specified lubricant to O-rings and install O-rings using the fingers only.

Use gasket removal spray and/or plastic scrapers to remove traces of old gasket.



CAUTION: DO NOT use metal scrapers or emery cloth as these may damage the sealing surfaces.

Many joints use sealants instead of gaskets as the sealing medium. Where this is the case, the sealant together with its part number will be found listed in the relevant repair operation and also in the sealants table.



CAUTION: Always remove all traces of the old sealant prior to reassembly. Use plastic scrapers, specified solvents where available or dry, lint free cloth. **DO NOT** use metal scrapers or emery cloth as these may damage the sealing surfaces. Make sure that sealing surfaces are free from oil or grease as sealants will not adhere properly to contaminated surfaces.

Do not allow sealant to enter tapped holes or oilways.

Locking Devices

Always replace locking devices with one of the same design and of the correct size.

Tab washers

Always release locking tabs before loosening fixings, do not re-use tab washers.

Locknuts

Always use a backing spanner when loosening and tightening locknuts, brake and fuel pipe unions.

Roll pins

Always install new roll pins of the correct size.

Circlips

Always install new circlips ensuring that they are of the correct size for the groove.

Woodruff keys

Woodruff keys may be re-used provided there is no indication of wear or distortion.

Remove any burrs from edges of keyways using a fine file.

Split pins

Never attempt to straighten and re-use a split pin, always make sure that replacement pins are of the correct size for the hole in which they are to be installed.

Screw Threads

- Damaged nuts, bolts and screws must always be discarded. Attempting to recut or repair damaged threads with a tap or die impairs the strength and install of the threads and is not recommended.

NOTE:

During certain repair operations, it may be necessary to remove traces of thread locking agents using a tap. Where this is necessary, the instruction to do so will appear in the relevant operation and it is essential that a tap of the correct size and thread is used.

- Some bolts are coated with a thread locking agent and unless stated otherwise, they must not be re-used. New bolts having the same part number as the original must always be installed. When nuts or bolts are to be discarded, the repair operation and relevant torque chart will include an instruction to that effect. Do not use proprietary thread locking agents as they may not meet the specification required. See also Encapsulated ('Patched') Bolts and Screws.
- Always make sure that replacement nuts and bolts are at least equal in strength to those that they are replacing. Castellated nuts must not be loosened to accept a split pin except in recommended cases when this forms part of an adjustment.

- Do not allow oil or grease to enter blind holes, the hydraulic action resulting from tightening the bolt or stud can split the housing and also give a false torque reading.
- Always tighten a nut, bolt or screw to the specified torque figure, damaged or corroded threads can give a false torque reading.
- Nut and bolt loosening and tightening sequences, where given, must ALWAYS be followed. Distortion of components or faulty sealing of joints will result if the sequences are not followed. Where an instruction is given to tighten in stages, these stages must be adhered to; do not attempt to combine stages particularly where certain stages involve tightening by degrees.
- To check or re-tighten a fixing to a specified torque, first loosen a quarter of a turn, then retighten to the specified torque figure.
- Unless instructed otherwise, do not lubricate bolt or nut threads prior to installing.

Where it is stated that bolts and screws may be re-used, the following procedures must be carried out:


- Check that threads are undamaged.
- Remove all traces of locking agent from the threads.



CAUTION: DO NOT use a wire brush; take care that threads are not damaged.

- Make sure that threads are clean and free from oil or grease.
- Apply the specified locking agent to the bolt threads.

Bolt and Nut Identification



E48627

An ISO metric bolt or screw made of steel and larger than 6 mm in diameter can be identified by either of the symbols ISO M or M embossed or indented on top of the bolt head.

In addition to marks identifying the manufacturer, the top of the bolt head is also marked with symbols indicating the strength grade e.g. 8.8, 10.9, 12.9, 14.9. Alternatively, some bolts and screws have the M and strength grade symbol stamped on the flats of the hexagon.


Encapsulated ('Patched') bolts and screws



E48628

Encapsulated ('patched') bolts and screws have a thread locking agent applied to the threads during manufacture. Most thread locking agents are coloured, the band of colour extending for 360° around the thread. Some locking agents however, are neutral in colour and may not be so easily identified apart from a slightly darker area of thread where the locking agent has been applied. The locking agent is released and activated by the tightening process and is then chemically cured to provide the locking action.

Self-locking bolts and screws



E48629

Unless stated in a specific repair procedure, self-locking bolts and screws i.e. nylon patched or trilobular thread can be re-used provided that resistance is felt when the locking portion enters the female thread.

Nylon patched bolts and screws have a locking agent either applied to, or inserted in the threaded portion. They are identified by the presence of a coloured section of thread extending approximately 180° around the thread or by a coloured plug inserted into the bolt.


Trilobular bolts have a special thread form which creates a slight interference with the thread of the hole or nut into which it is screwed.



CAUTION: Do Not re-use self-locking fasteners in critical locations e.g. drive plates/flywheel or engine bearings. Do not install non self-locking fasteners where a self-locking fastener is specified.

Trilobular bolts should not be used as a substitute for patched bolts.

Nut identification



E48630

A nut with an ISO metric thread is marked on one face or one of the hexagonal flats with the strength grade symbol 8, 12, 14. Some nuts with the strength grade 4, 5 or 6 are also marked and some have the metric symbol M on the hexagonal flat opposite the strength grade marking.

A clock face system is sometimes used as an alternative method of indicating the strength grade. The external chamfers or a face of the nut is marked in a position relative to the appropriate hour mark on a clock face to indicate the strength grade.

A dot is used to locate the 12 o'clock position and a dash to indicate the strength grade. If the grade is above 12, two dots identify the 12 o'clock position.

When tightening a slotted or castellated nut, never loosen it to insert a split pin except where specified as part of an adjustment procedure. If difficulty is experienced in correctly positioning the slot, alternative washers or nuts should be selected.

Where a nut is tightened to adjust or maintain bearing pre-load, the tightening procedure must be adhered to.

Self-locking nuts

Unless stated otherwise, self-locking nuts once removed must be discarded and new nuts of the same type and strength grade installed.


Ball and Roller Bearings

When removing and installing bearings, make sure that the following practices are observed to make sure component serviceability:



CAUTION: Service tools have been developed for removing the majority of bearings; these must always be used where specified.

- Remove all traces from bearing under inspection by cleaning with a suitable degreasant; maintain absolute cleanliness throughout operations.
- Conduct a visual inspection for markings on rolling elements, raceways, outer surfaces of outer or inner surfaces of inner rings. Reject any bearings found to be marked since marking in these areas indicates onset of wear.
- Hold inner race of bearing between finger and thumb of one hand and rotate outer race to check that it revolves absolutely smoothly. Repeat holding outer race and rotating inner race. DO NOT spin the bearing.
- Rotate outer ring gently using a reciprocating movement whilst holding inner ring; feel for any check or obstruction to rotation. Reject bearing if movement is not absolutely smooth.
- Check bearing for blueing or signs of overheating.
- Lubricate bearing with the specified lubricant.
- Inspect bearing surface of shaft and bearing housing for discolouration or other markings which indicate overheating of bearing or movement between bearing and seating.
- Before installing bearing, make sure that shaft and bearing housing are clean and free from burrs.
- If one bearing of a pair shows signs of wear, overheating etc., it is advisable to replace bearings as a pair unless it is suspected that one bearing may have been faulty when installed, was installed incorrectly or the fault arose due to oil seal failure.
- Never reinstall a bearing unless it is in a fully serviceable condition.



E48560

- When installing a bearing to a shaft, only apply force to the inner ring of the bearing. When installing a bearing into a housing, only apply force to the outer ring of the bearing.



CAUTION: Service tools have been developed for installing the majority of bearings; these must always be used where specified.

- In the case of grease lubricated bearings, fill the space between the bearing and outer seal with the recommended grade of grease before installing the seal.



CAUTION: When a waxed oil seal (installed dry) type of oil seal is to be installed, take great care that grease does not contaminate the running surface of the seal.

- Always make suitable reference marks between the components of separable bearings e.g. taper roller bearings when disassembling to make sure correct location of components when assembling. Never install new rollers in an outer ring, always install a new bearing assembly.

Brake Pads and Linings

Always install the correct grade and specification of brake pads and linings. When replacing these items, always replace as complete axle sets.

Brake Hydraulics

Always observe the following recommendations when working on the braking system:



WARNING: Do not intermix brake fluid of different specifications.

- Always use two spanners when loosening or tightening brake pipes or hose connections.
- Make sure that hoses run in a natural curve and are not kinked or twisted.
- Install brake pipes and hoses securely in their retaining clips and make sure that they cannot contact a potential chafing point.
- Containers used for brake fluid must be kept absolutely clean.
- Do not store brake fluid in unsealed containers, the fluid will absorb water which will lower the boiling point of the fluid.
- Do not allow brake fluid to be contaminated with other fluids such as mineral oil and do not put brake fluid in a container which has previously been used for storing other fluids.
- Do not re-use brake fluid which has been bled from the system.
- Always use brake fluid or a suitable brake cleaning fluid to clean hydraulic components.
- Unless stated otherwise, use only clean brake fluid to lubricate hydraulic seals and components.
- Always install blanking plugs to hoses, pipes or components immediately after disconnection.
- Check thread compatibility of original equipment with replacement components.
- Observe absolute cleanliness when working with hydraulic components.

Pipes and Hoses

When removing or installing flexible hydraulic pipes and hoses, make sure that the following procedures are observed to make sure component serviceability:

- Prior to removal, clean area around hose or pipe end which is to be disconnected.
- Obtain appropriate blanking plugs or caps before disconnecting hose or pipe end fittings in order that connections can be plugged immediately following disconnection.
- Always install blanking plugs or caps to pipes and unions immediately following disconnection.
- Clean hose or pipe and blow through with an air line.



WARNING: Suitable eye protection must be worn.

- Check hoses externally for cracks, separation of plies, security of end fittings and external damage; replace faulty hoses.
- Check pipes for signs of corrosion and chafing, replace as necessary.



CAUTION: If pipes are found to be chafed, rectify clips, mounting points etc., to prevent further problems in service.

- When installing hoses, make sure that no unnecessary bends are introduced and that hoses are not kinked, twisted or positioned close to potential chafing points.
- When installing pipes, make sure that pipes are positioned and clipped clear of potential chafing points.
- Always replace sealing washers installed to banjo bolts, sealing plugs etc.
- Always use a backing spanner when tightening unions and do not overtighten union nuts or banjo bolts.
- After engagement of 'quick-fit' connection hoses, perform a 'tug' test to make sure connection is securely installed.
- After any work on hydraulic systems, always check for fluid leaks whilst a second operator applies working pressure to the brake pedal or operates the system that has been worked on.

Fuel system hoses

Some fuel hoses are made up of two laminations, an armoured rubber outer sleeve and an inner viton core. Whenever a hose is removed, make sure that the inner bore is inspected to check that the viton lining has not become separated from the outer sleeve.



WARNING: Never attempt to repair fuel hoses or rectify leaking 'quick-fit' connectors. The fuel hose and connectors must be replaced as an assembly.

Fuel system hose clips



E48636

Certain fuel system hose clips are of the 'break-off head' type where a slot in the screw head shears off when the clip is tightened to a specific torque. These clips may be removed using a screwdriver and must be replaced with new clips on reassembly. Clips must be tightened until the portion of the slot shears off. Do not attempt to tighten clips by any other method, do not install any other type of clip.

'Quick-fit' connections are also installed to certain fuel hoses. After engagement of 'quick-fit' connections, perform a 'tug' test to make sure connection is securely installed.

Other fuel system hose clips are of the 'Jubilee' type and there may be a tamper proof cover installed over the screw head. These cover must be carefully removed before slackening the clip and should be replaced after final tightening, ensuring that the internal hexagon on the cover is correctly located on the clip screw.


Cooling system hoses



CAUTION: The following precautions must be observed to make sure that the integrity of the cooling system hoses and their connection to the system is maintained.

Hose orientation and connection


Correct orientation of cooling system hoses is important to make sure that hoses do not become fatigued or damaged through contact with adjacent components.



E48633

Where orientation marks are provided on the hose and corresponding component, the marks must be aligned when the hose is installed. Hoses must be installed fully on to their connection points, usually a moulded form on a pipe provides a positive indicator.

Hose clips



Markings are usually provided on the hose to indicate the correct clip position. If no markings are provided, position the clip directly behind the retaining lip at the end of the stub pipe. Worm drive clips should be orientated with the crimped side of the drive housing facing towards the end of the hose or the hose may become pinched between the clip and the stub pipe retaining lip. Unless otherwise stated, worm drive clips should be tightened to 3 Nm (2 lb-ft). Make sure that hose clips do not foul adjacent components.



Oetiker clips may be removed by bending the tag (arrowed) and releasing the free end of the clip. Clips must not be re-used. When installing new clips, make sure clip is positioned on hose before tightening and make sure that when clip is tightened, the tag is located in the longitudinal slot in the free end of the clip (arrowed in illustration).

'Quick-fit' connections are also installed to certain hoses/pipes. Inspect 'quick-fit' connections for damage, prior to connection. Replace if damaged. After engagement of 'quick-fit' connections, perform a 'tug' test to make sure connection is securely installed.

Heat protection

Always make sure that heat shields and protective sheathing are in good condition; replace if damage is evident. Particular care must be taken when routing hoses close to hot engine components such as the exhaust manifolds and exhaust gas recirculation (EGR) pipes. Hoses will relax and deflect slightly when hot, make sure this movement is taken into account when routing and securing hoses.

Electrical Precautions

General

The following guidelines are intended to make sure the safety of the operator whilst preventing damage to the electrical and electronic components of this vehicle.

Equipment

Prior to commencing any test procedure on the vehicle, make sure that the relevant test equipment is working correctly and that any harness or connectors are in good condition. It is particularly important to check the condition of all plugs and leads of mains operated equipment.

Polarity

Never reverse connect the vehicle battery and always make sure the correct polarity when connecting test equipment.

High voltage circuits

Whenever disconnecting live ht circuits, always use insulated pliers and never allow the open end of the ht lead to contact other components, particularly ECU's.

Connectors and harnesses

The engine compartment of a vehicle is a particularly hostile environment for electrical components and connectors. Always observe the following:

- Make sure electrically related items are dry and oil free before disconnecting/connecting test equipment.
- Make sure that disconnected multiplugs and sensors are protected from any possible oil, coolant or other liquid contamination. Any such contamination could impair performance or lead to component failure.
- Never force connectors apart or pull on the wiring harness.
- Always make sure locking tabs are disengaged before disconnecting multiplugs etc. and make sure that correct orientation is achieved before connection.
- Make sure that any protection covers, insulation etc. are replaced if disturbed.

Having confirmed that a component is faulty, carry out the following:

- Switch off the ignition and disconnect the battery.
- Remove the component and support the disconnected harness.
- When replacing electrical components, keep oily hands away from electrical connections and make sure that locking tabs on connectors are fully engaged.

Battery Disconnection/Connection

Always refer to the Electrical Section of this manual - Battery Connection/Disconnection prior to attempting to connect or disconnect the battery. For additional information, refer to [Battery](#) (414-01 Battery, Mounting and Cables)

Fuel Handling Precautions

The following information lists basic precautions which must be observed if fuel is to be handled safely. It also outlines other areas of risk which must not be ignored. As this information is issued for basic guidance only, consult your local Fire Department where any doubt as to personal and environmental safety exists - See also Health and Safety Precautions.

General precautions

Always have the correct type of fire extinguisher containing Foam, CO2, Gas or powder accessible when handling or draining fuel or dismantling fuel systems. Fire extinguishers must also be located in areas where fuel is stored.

Make sure that suitable warning signs are exhibited.

Keep all sources of ignition well away from areas where fuel is being handled.

Make sure that any leadlamps are flameproof and kept clear of spillage.



WARNING: Do not disassemble or reassemble fuel system components whilst vehicle is over a pit.



WARNING: No one should be permitted to repair components associated with fuel without first having specialist training.

Always disconnect the vehicle battery before carrying out disassembly, reassembly or draining work on a fuel system.

Fuel tank and system draining

Draining must be carried out in accordance with the procedures given in the relevant Fuel System section of this manual.



WARNING: Never drain fuel or work on a fuel system while the vehicle is over a pit. Extraction or draining of fuel must be carried out in a well ventilated area.



WARNING: Never switch on or operate mobile (cellular) phones in the vicinity of vehicles when operations are being carried out on the fuel system.



WARNING: Always attach fuel vapour warning labels to fuel tanks immediately after draining.



WARNING: Containers used for storing fuel must be clearly marked with the contents and placed in a safe storage area which meets the requirements of the local authority.



CAUTION: Some fuel lines are now installed with 'quick release' connectors. If a connector is damaged, no attempt must be made to repair the connector, a new fuel line and connector(s) assembly must be installed.

Always release pipe clips fully before attempting to disconnect fuel pipes.

Fuel tank repairs




CAUTION: No attempt should be made to repair a fuel tank. If the structure of the tank is damaged, a new tank must be installed.


Oil seals

Never use a seal which has been improperly stored or handled.

- Take great care when removing old seals that the sealing surfaces and seal housing are not damaged.
- Carefully examine seal before installing to make sure that it is clean and undamaged.
- Make sure that the surface on which the seal is to run and also the seal housing is clean and free from burrs or scratches. Renew the component if the sealing surface cannot be restored.
- Special tools and protection sleeves are provided for installing the majority of seals and must be used when specified.
- Many seals are now coated with a protective wax and DO NOT need to be lubricated prior to installing. Always check the relevant repair procedure which will state if a seal must be installed dry. Never touch these seals with oily hands as the oil will contaminate the protective coating and affect the sealing properties of the seal; also, make sure that installing tools and protection sleeves are free from oil and grease. Seals which must be lubricated prior to installing should have the recommended lubricant applied to the areas specified in the repair procedure.
- Make sure that a seal is installed the correct way round. For example, the lip of the seal must face towards the lubricant which it is sealing.
- When installing an oil seal, make sure that it is positioned square to shaft and housing. Where the seal is to be installed to a housing prior to installing over a shaft, take care not to allow the weight of an unsupported shaft to rest on the seal.



- Always use the recommended special tool and protection sleeve to install an oil seal. If no tool is specified, use a suitable mandrel approximately 0.4 mm (0.015 in) smaller than the outside diameter of the seal. Use adhesive tape on the shaft to protect the sealing lip of the seal.



- Press or drift the seal in to the depth of its housing if the housing is shouldered or flush with the face of the housing where no shoulder is provided. Make sure that the seal is not tilted in the housing when it is installed.

(A/C) System Precautions

The A/C system contains fluids and components which could be potentially hazardous to the service engineer or the environment if not serviced and handled correctly. The following guidelines are intended to alert the service engineer to potential sources of danger and emphasise the importance of ensuring the integrity of the A/C operating conditions and components installed to the vehicle.

Where necessary, additional specific precautions are detailed in the relevant sections of this Manual and also in the Health and Safety Section. These precautions must be referred to prior to commencing repair operations.

The refrigerant used in the A/C system is HC-134a (Hydro fluorocarbon) R134a.



WARNING: Servicing must only be carried out by personnel familiar with both the vehicle system and the charging and testing equipment. All operations must be carried out in a well ventilated area away from open flame and heat sources.



WARNING: R134a is a hazardous liquid and when handled incorrectly can cause serious injury. Suitable protective clothing, consisting of face protection, heat proof gloves, rubber boots and rubber apron or waterproof overalls, must be worn when carrying out operations on the A/C system.

Remedial actions



WARNING: Due to its low evaporating temperature, R134a must be handled with care. R134a splashed on any part of the body will cause immediate freezing of that area. Also, refrigerant cylinders and replenishment trolleys when discharging will freeze skin to them if contact is made.

If an accident involving R134a should occur, conduct the following remedial actions:

- If liquid R134a enters the eye, do not rub it. Gently run large quantities of eye wash over affected eye to raise the temperature. If an eye wash is not available, cool, clean water may be used to flush the eye. After rinsing, cover the eye with a clean pad and seek immediate medical attention.
- If liquid R134a is splashed onto the skin, run large quantities of water over the affected area to raise the temperature. Implement the same action if the skin comes in contact with discharging cylinders. Wrap the contaminated body parts in blankets (or similar materials) and seek immediate medical attention.
- If the debilitating effects of inhalation of R134a vapour are suspected, seek fresh air. If the affected person is unconscious, move them away from the contaminated area to fresh air and apply artificial respiration and/or oxygen and seek immediate medical attention.

Service precautions

Observe the following precautions when handling components used in the system:

- A/C units must not be lifted by their hoses, pipes or capillary lines.
- Hoses and lines must not be subjected to any twist or stress; the efficiency of the system will be impaired by kinks or restrictions. Make sure that hoses are correctly positioned before tightening couplings, and make sure that all clips and supports are utilised.
- Flexible hoses should not be positioned closer than 100 mm (4.0 in) to the exhaust manifold unless protected by heat shielding.
- Completed assemblies must be checked for refrigeration lines touching metal panels. Any direct contact of components and panels may transmit noise and so must be eliminated.
- The appropriate torque wrench must be used when tightening refrigerant connections to the stipulated value. An additional spanner must be used to hold the union to prevent twisting of the pipe when tightening connections.
- Before connecting any hose or pipe, make sure that refrigerant oil is applied to the seat of the new O-rings, **BUT NOT** to the threads of the connection.
- All protective plugs or caps must remain in place in the component until immediately prior to connection.
- Make sure components are at room temperature before uncapping/unplugging, to prevent condensation of moisture from the air that enters it.
- When disconnecting, immediately plug or cap all pipes to prevent ingress of dirt and moisture into the system.
- Components must not remain uncapped/unplugged, if a system has been left uncapped/unplugged for 24 hours or longer, a new receiver/drier must be installed.
- The receiver/drier contains desiccant which absorbs moisture. It must be positively sealed at all times. A receiver/drier that has been left uncapped for longer than 24 hours must not be used; install a new unit.
- The receiver/drier should be the last component connected to the system to make sure optimum dehydration and maximum moisture protection of the system.
- Whenever a component of the refrigeration system is replaced, it will also be necessary to install a new receiver/drier unit.
- Use alcohol and a clean lint-free cloth to clean dirty connections.
- Make sure that all new parts installed are marked for use with R134a.
- When a major repair has been completed, a leak test should be conducted; refer to the Repairs Section of this manual for the correct procedure.

Refrigerant oil



CAUTION: Refrigerant oil (ND-8 PAG) easily absorbs water and must not be stored for long periods. Do not pour unused refrigerant oil back into the container. Always use an approved refrigerant oil.

When replacing components in the system, drain the refrigerant oil from the component being replaced into a graduated container. On assembly, add the quantity of refrigerant oil drained to the new component - See Compressor Replacement in this Section.

A/C Compressor

A new compressor is sealed and pressurised with Nitrogen gas. When installing a new compressor, slowly release the sealing cap; gas pressure should be heard to vent as the seal is broken.



CAUTION: A new compressor should always be sealed and could be pressurised with nitrogen gas. To avoid possible oil loss, release the sealing cap(s) slowly. Do not remove the cap(s) until immediately prior to connecting the pipes to the compressor.

Rapid refrigerant discharge

If the A/C system is damaged as a result of an accident and the system is punctured, the refrigerant will discharge rapidly. The rapid discharge of refrigerant will also result in the loss of most of the oil from the system. The compressor must be removed and all the remaining oil in the compressor drained and refilled as instructed in the air conditioning section of this manual.

Precautions for refrigerant recovery, recycling and recharging

When the A/C system is recharged, any existing refrigerant is first recovered from the system and recycled. The system is then charged with the required weight of refrigerant and volume of refrigerant oil.



WARNING: Refrigerant must always be recycled before re-use to make sure that the purity of the refrigerant is high enough for safe use in the system. Recycling should always be carried out with equipment which is design certified by Underwriter Laboratory Inc. for compliance with SAE J1991. Other equipment may not recycle refrigerant to the required level of purity.



CAUTION: A R134a Refrigerant Recovery Recycling Recharging Station must not be used with any other type of refrigerant. Refrigerant R134a from domestic and commercial sources must not be used in motor vehicle systems.



CAUTION: The system must be evacuated immediately before recharging commences. Delay between evacuation and recharging is not permitted.

A/C Compressor Replacement

A new compressor is supplied filled with a full charge (X cm³) of refrigerant oil.

A calculated quantity of oil must be drained from the new compressor before installing. To calculate the quantity of oil to be drained:

- Remove the drain plug from the old compressor.
- Invert the compressor and gravity drain the oil into a calibrated measuring cylinder. Rotate the compressor clutch to make sure the compressor is completely drained.
- Note the quantity of oil drained (Y cm³).
- Calculate the quantity of oil to be drained from the new compressor using the following formula: $X \text{ cm}^3 - (Y \text{ cm}^3 + 20 \text{ cm}^3) = Q \text{ cm}^3$
- Remove the drain plug from the new compressor and drain Q cm³ of oil. Install and tighten the compressor drain plug.

Vehicle Weights up to 07/2001

When loading a vehicle to its maximum (Gross Vehicle Weight) consideration must be taken of the unladen vehicle weight and distribution of the payload to make sure that axle loadings do not exceed the permitted maximum values.

It is the customer's responsibility to limit the vehicle's payload in an appropriate manner such that neither maximum axle loads nor Gross Vehicle Weight are exceeded.

NOTE:

Axle weights are not accumulative. The individual maximum axle weights and gross vehicle weights must not be exceeded.

NOTE:

EEC Kerb weight = Unladen weight + full fuel tank + 75 Kg (165lb).

90 Models

Vehicle axle weights -	Standard	Standard	High load	High load
Front axle	1200 Kg	2645 lb	1200 Kg	2645 lb
Rear axle	1380 Kg	3042 lb	1500 Kg	3307 lb
Maximum Gross Vehicle Weight (GVW) -	2400 Kg	5291 lb	2550	5622 lb
EEC Vehicle kerb weights				
Soft top	1695 Kg	3736 lb	1699 Kg	3745 lb
Pick-up	1694 Kg	3734 lb	1698 Kg	3743 lb
Hard top	1746 Kg	3849 lb	1750 Kg	3858 lb
Station wagon	1793 Kg	3952 lb	1797 Kg	3961 lb

110 Models

Vehicle axle weights -	Levelled	Levelled	Unlevelled	Unlevelled
Front axle	1200 Kg	2645 lb	1200 Kg	2645 lb
Rear axle	1750 Kg	3858 lb	1850 Kg	4078 lb
Maximum Gross Vehicle Weight (GVW) -	2950 Kg	6503 lb	3050 Kg	6724 lb
EEC Vehicle kerb weights				
Soft top	1872 Kg	4127 lb	1882 Kg	4149 lb
Pick-up	1880 Kg	4144 lb	1890 Kg	4166 lb
High capacity Pick-up	1917 Kg	4226 lb	1927 Kg	4248 lb
Hard top	1913 Kg	4217 lb	1923 Kg	4239 lb
Station wagon	2018 Kg	4448 lb	2018 Kg	4470 lb
County station wagon	2054 Kg	4528 lb	2054 Kg	455 lb

130 Models

Vehicle axle weights - 130 models		
Front axle	1580 kg	3483 lb
Rear axle	2200 Kg	4850 lb
Maximum Gross Vehicle Weight (GVW) -	3500 kg	7716 lb
EEC Vehicle kerb weights		
Crew cab and high capacity pick-up	2086 Kg	4598 lb

Vehicle Weights From 07/2001

90 Models

Vehicle axle weights - 90 models	Station wagon	Station wagon	Utility	Utility
Front axle	1200 Kg	2645 lb	1200 Kg	2645 lb
Rear axle	1500 Kg	3307 lb	1500 Kg	3307 lb
Maximum Gross Vehicle Weight (GVW) -	2550 Kg	5622 lb	2400	5291 lb
EEC Vehicle kerb weights				
Soft top	1770 Kg	3402 lb	1993 Kg	4393 lb

Pick -up	1770 Kg	3402 lb	1993 Kg	4393 lb
Hard top	1815 Kg	4001 lb	1987 Kg	4380 lb
Station wagon	1870- 1885 Kg	4122 - 4155 lb	1989 - 1998 Kg	4385 - 4404 lb

110 Models - Non Japanese specification

Vehicle axle weights -	Station wagon	Station wagon	Utility	Utility
Front axle	1200 Kg	2645 lb	1200 Kg	2645 lb
Rear axle	1750 Kg	3858 lb	1850 Kg	4078 lb
Maximum Gross Vehicle Weight (GVW) -	2950 Kg	6503 lb	3050 Kg	6724 lb
EEC Vehicle kerb weights	Standard	Standard	Heavy duty	Heavy duty
Soft top	1885 Kg	4155 lb	2080 KG	4585 lb
High capacity Pick-up	1920 Kg	4232 lb	2122 Kg	4678 lb
Hard top	1920 Kg	4232 lb	2110 Kg	4651 lb
Station wagon	2055 Kg	4530 lb	2229 Kg	4914 lb

110 Models - Japanese specification

Vehicle axle weights -	Metric	Imperial
Front axle	1115 Kg	2457 lb
Rear axle	2180 Kg	4805 lb
Maximum Gross Vehicle Weight (GVW) -	3295 Kg	7262 lb

130 Models

Vehicle axle weights	Metric	Imperial
Front axle	1580 kg	3483 lb
Rear axle	2200 Kg	4850 lb
Maximum Gross Vehicle Weight (GVW) -	3500 kg	7716 lb
EEC Vehicle kerb weights	Heavy duty	Heavy duty
Crew cab and high capacity pick-up	2177 - 2286 Kg	4667 - 5039 lb

Towing weights

NOTE:

* Only applies to vehicles modified to accept coupled brakes.

NOTE:

All weight figures are subject to local restrictions

Towing weights	On-road	On-road	Off-road	Off-road
Unbraked trailers	750 Kg	1653 lb	500 Kg	1102 lb
Trailers with overrun brakes	3500 Kg	7716 lb	1000 Kg	2204lb
4 wheel Trailers with coupled brakes *	4000 Kg	8818 lb	1000 Kg	2204lb

Off Road Performance

90 Models

NOTE:

Departure angles do not account for the addition of a tow hitch.

Item	Metric	Imperial
Max. gradient (EEC Kerb weight)	45°	
Approach angle		
Soft Top and Pick-up (EEC Kerb weight)	48°	
Hard top and Station wagon (EEC Kerb weight)	51.5°	
Departure angle		
Soft Top and Pick-up (EEC Kerb weight)	49°	
Hard top and Station wagon (EEC Kerb weight)	53°	
Wading depth	500 mm	20 in
Min. ground clearance (unladen)		
Soft Top and Pick-up (EEC Kerb weight)	191 mm	7.5 in
Hard top and Station wagon (EEC Kerb weight)	229 mm	9.0 in

110 and 130 Models

NOTE:

Departure angles do not account for the addition of a tow hitch.

Item	Metric	Imperial
Max. gradient (EEC Kerb weight)	45°	
Approach angle	50°	
Departure angle		
110 Models	35°	
130 Models	34°	
Wading depth	500 mm	20 in
Min. ground clearance (unladen)	215 mm	8.5 in

Vehicle dimensions

90 Models

Item	Metric	Imperial
Overall length		
Soft top and Pick-up	3722 mm	146.5 in
Hard top and Station wagon	3883 mm	152.9 in
Overall width	1790 mm	70.5
Overall height		
Soft top and Pick-up	1965 mm	77.4 in
Pick-up and Station wagon	1963 mm	77.3 in
Hardtop	1972 mm	77.6 in
Wheelbase	2360 mm	92.9 in
Track front/rear	1486 mm	58.5 in
Width between wheel boxes	925 mm	36.4 in

110 Models

Item	Metric	Imperial
Overall length		
Soft top and Pick-up	4438 mm	175 in
Hard capacity pick-up	4631 mm	182 in

Hardtop/station and county	4599 mm	181 in
Overall width	1790 mm	70.5 in
Overall height -		
Non Japanese specification	2035 mm	80.1 in
Japanese specification	2060 mm	81.1 in
Wheelbase	2794 mm	110 in
Track front/rear	1486 mm	58.5 in
Width between wheel boxes		
High capacity pick-up	1090 mm	43 in
All other models	925 mm	36.4 in

130 Models

Item	Metric	Imperial
Overall length	5132 mm	202 in
Overall width	1790 mm	70.5 in
Overall height	2035 mm	80.1 in
Wheelbase	3266 mm	127 in
Track front/rear	1486 mm	58.5 in
Width between wheel boxes	1090 mm	43 in

V8 Models

Item	Metric	Imperial
Overall length	4072 mm	160.5 in
Overall width	1790 mm	70.5 in
Overall height	2037 mm	80.2 in
Wheelbase	2360 mm	92.9 in
Track front/rear	1486 mm	58.5 in
Width between wheel boxes	925 mm	36.4 in
Turning circle	12.65 m	41 ft 6 in

Health and Safety Precautions

Introduction

Modern vehicles contain many materials and liquids which if not handled with care can be hazardous to both personal health and the environment. Also, many of the procedures associated with vehicle maintenance and repair involve physical hazards or other risks to health.

This subsection lists some of these hazardous operations and the materials and equipment associated with them. Precautions necessary to avoid these hazards are identified.

The list is not exhaustive and all operations and procedures and the handling of materials, should be carried out with health and safety in mind.

Before using any product the Materials Safety Data Sheet supplied by the manufacturer or supplier should be consulted.



WARNING: Many liquids and other substances used in motor vehicles are poisonous and should under no circumstances be consumed and should, as far as possible, be kept from contact with the skin. These liquids and substances include acid, anti-freeze, brake fluid, fuel, windscreen washer additives, lubricants, refrigerants and various adhesives.

Acids and Alkalis

For example - alkalis such as caustic soda used in cleaning materials; acids such as sulphuric acid used in batteries.

Both alkalis and acids are irritant and corrosive to the skin, eyes, nose and throat. They cause burns and can destroy ordinary protective clothing.

Avoid splashes to the skin, eyes and clothing. Wear suitable protective impervious apron, gloves and goggles. Do not breath mists.

Make sure access to eye wash bottles, shower and soap are readily available for splashing accidents.

Display Eye Hazard sign.

Air Bags

Highly flammable, explosive – observe No Smoking policy.

Used within the vehicle as safety restraints.

The inflator contains a high-energy propellant which, when ignited, produces a VERY HOT GAS (2500°C).

The gas inflator (generator) used in air bags is Sodium Azide. This material is hermetically sealed in each air bag module and is completely consumed during deployment. No attempt should be made to open an air bag inflator as this will lead to the risk of exposure to Sodium Azide. If a gas generator is ruptured, full protective clothing should be worn when dealing with the spillage.

After normal deployment, gloves and safety goggles should be worn during the handling process.

Deployed air bags should be disposed of in a plastic bag in accordance with local regulations at an approved chemical waste site.

Following any direct contact with Sodium Azide:

- Wash affected areas thoroughly with water.
- **SEEK IMMEDIATE MEDICAL ASSISTANCE.**

Air Bags - Do's

- Do store modules in an upright position.
- Do keep modules dry.
- Do carry modules with the cover side pointing away from the body.
- Do place modules with their cover side upwards.
- Do carefully inspect modules for damage.
- Do stand to one side when connecting modules.
- Do make sure all test equipment is properly calibrated and maintained.
- Do wash hands after handling deployed air bags.

Air Bags - Do Not

- Do Not store highly flammable material together with modules or gas generators.
- Do Not store gas generators at temperatures exceeding 80°C.
- Do Not store modules upside down.
- Do Not attempt to open a gas generator housing.
- Do Not expose gas generators to open flame or sources of heat.
- Do Not place anything on top of a module cover.
- Do Not use damaged modules.
- Do Not touch a fired module or gas generator for at least 10 minutes after firing.
- Do Not use any electrical probes on the wiring circuit.

Air Suspension

Whenever work is being undertaken on the air suspension system, suitable eye protection must be worn.

Air Conditioning Refrigerant

Highly flammable, combustible – observe No Smoking policy.

Skin contact may result in frostbite.

Instructions given by the manufacturer must be followed. Avoid naked lights, wear suitable protective gloves and goggles.

If refrigerant comes into contact with the skin or eyes, rinse the affected areas with water immediately. Eyes should also be rinsed with an appropriate irrigation solution such as a solution of 9% Sodium Chloride and Purified Water.
DO NOT RUB THE EYES AND SEEK IMMEDIATE MEDICAL ATTENTION.

Air Conditioning Refrigerant

Do Not

- Do Not expose refrigerant bottles to sunlight or heat.
- Do Not expose refrigerant bottles to frost.
- Do Not drop refrigerant bottles.
- Do Not vent refrigerant to atmosphere under any circumstance.
- Do Not mix refrigerants.

Adhesives and Sealants

Many adhesives and sealants are highly flammable – **OBSERVE NO SMOKING POLICY**. These items, should be stored in flameproof cabinets in No Smoking areas. Cleanliness and tidiness in use should be observed, for example disposable paper covering benches. All adhesives and sealants should be dispensed from applicators where possible; containers, including secondary containers, should be labelled appropriately.

Anaerobic, Cyanoacrylate (super-glues) and other Acrylic Adhesives

Many are irritant, sensitizing or harmful to the skin and respiratory tract. Some are eye irritants.

Skin and eye contact should be avoided and the manufacturer's instructions followed.

Cyanoacrylate adhesives (super-glues) **MUST NOT** contact the skin or eyes. If skin or eye tissue is bonded, cover with a clean moist pad and **SEEK IMMEDIATE MEDICAL ATTENTION**. Do not attempt to pull skin tissue apart. Use in well ventilated areas as vapors can cause irritation to the nose and eyes.

For two-pack systems see Resin-based and Isocyanate Adhesives/Sealers.

Solvent-based Adhesives/Sealers - See Solvents

Follow manufacturers instructions.

Water-based Adhesives/Sealers

Those based on polymer emulsions and rubber/latex may contain small amounts of volatile, toxic and harmful chemicals. Skin and eye contact should be avoided and adequate ventilation provided during use.

Hot Melt Adhesives

In the solid state, they are safe. In the molten state they may cause burns and health hazards may arise from the inhalation of toxic fumes.

Use appropriate protective clothing and a thermostatically controlled heater with a thermal cut-out and adequate extraction.

Resin-based Adhesives/Sealers, for example Epoxide and Formaldehyde Resin-based

Mixing should be carried out in well ventilated areas as harmful or toxic volatile chemicals may be released.

Skin contact with uncured resins and hardeners can result in irritation, dermatitis, and absorption of toxic or harmful chemicals through the skin. Splashes can damage the eyes.

Provide adequate ventilation and avoid skin and eye contact.

Isocyanate (Polyurethane) Adhesives/Sealers

See also Resin-based Adhesives

Individuals suffering from asthma or respiratory allergies should not work with or near these materials as sensitivity reactions can occur.

Over exposure is irritating to the eyes and respiratory system. Excessive concentrations may produce effects on the nervous system including drowsiness. In extreme cases, loss of consciousness may result. Long term exposure to vapour concentrations may result in adverse health effects.

Prolonged contact with the skin may lead to skin irritation and in some cases, dermatitis.

Splashes entering the eye will cause discomfort and possible damage.

Any spraying should preferably be carried out in ventilated booths which incorporate facilities for removing vapors and spray droplets from the breathing zone.

Wear appropriate gloves, eye and respiratory protection.

Antifreeze

May be flammable when undiluted.

Vapors may be given off from coolant antifreeze when heated. Avoid breathing these vapors.

Antifreeze may be absorbed through the skin in toxic or harmful quantities. Antifreeze, if swallowed, can be fatal;
SEEK IMMEDIATE MEDICAL ATTENTION.

Battery Acids

See also Alkalis and Acids.

Gases released during battery charging are explosive. Always remove the battery from the vehicle prior to charging. Never use naked flames or allow sparks near charging or recently charged batteries. NEVER add acid to a battery, the chemical reaction produced will be violent and explosive. In cases of eye contact, wash affected area with

copious amounts of water and **SEEK IMMEDIATE MEDICAL ATTENTION.**

Make sure there is adequate ventilation during battery charging, observe NO SMOKING POLICY.

Brake Pads and Linings

Always fit the correct grade and specification of brake pads and linings. When renewing pads and linings, always replace as complete axle sets.

Brake and Clutch Fluid

Splashes to the skin and eyes are irritating and in the long term can be damaging, avoid prolonged skin contact. In cases of eye contact, wash affected area with copious amounts of water and **SEEK IMMEDIATE MEDICAL ATTENTION.**

Chemical Materials

All chemical materials should always be used with caution and stored and handled with care. They may be toxic, harmful, corrosive, irritant or highly flammable and give rise to hazardous fumes and dusts.

The effects of excessive exposure to chemicals may be immediate or delayed; briefly experienced or permanent; cumulative; superficial; life threatening; or may reduce life expectancy.

Chemical Materials - Do's

- Do carefully read and observe hazard and precaution warnings given on material containers (labels) and in any accompanying leaflets, posters or other instructions. Material health and safety data sheets can be obtained from manufacturers.
- Do remove chemical materials from the skin and clothing as soon as practicable after soiling. Change heavily soiled clothing and have it cleaned.
- Do organise work practices and protective clothing to avoid soiling of the skin and eyes.
- Do avoid breathing vapors, aerosols, dusts or fumes; inadequate container labelling; fire and explosion hazards.
- Do wash before job breaks, before eating, smoking, drinking or using toilet facilities when handling chemical materials.
- Do keep work areas clean, uncluttered and free of spills.
- Do store chemical materials according to national and local regulations.
- Do keep chemical materials out of the reach of children.

Chemical Materials - Do Not

- Do Not mix chemical materials except under the manufacturers instructions; some chemicals can form other toxic or harmful chemicals, give off toxic or harmful fumes or become explosive when mixed together.
- Do Not spray chemical materials, particularly those based on solvents, in confined spaces, for example when people are inside a vehicle.
- Do Not apply heat or flame to chemical materials except under the manufacturers instructions. Some are highly flammable and some may release toxic or harmful fumes.
- Do Not leave containers open. Fumes given off can build up to toxic, harmful or explosive concentrations. Some fumes are heavier than air and will accumulate in confined areas such as pits.
- Do Not transfer chemical materials to unlabelled containers.
- Do Not clean hands or clothing with chemicals. Chemicals, particularly solvents and fuels, will dry skin and may cause irritation leading to dermatitis or be absorbed through the skin in toxic or harmful quantities.
- Do Not use emptied containers for other materials except when they have been cleaned under supervised conditions.
- Do Not sniff or smell chemical materials, even brief exposure to high concentrations of fumes can be toxic or harmful.

Corrosion Protection Materials

Some corrosion protection materials are highly flammable – observe NO SMOKING POLICY.

These materials are varied and the manufacturers instructions must always be followed. The materials may contain solvents, resins or petroleum products. Skin and eye contact should be avoided. They should only be sprayed in conditions of adequate ventilation and not in confined spaces.

Dust

Dust or powder produced during repair operations may be irritant, harmful or toxic. Avoid breathing dusts from powdery chemical materials or those arising from dry abrasion operations. Wear respiratory protection if ventilation is inadequate.

Fine dusts of combustible material can present an explosion hazard. Avoid explosive limits and sources of ignition.

Electrical Equipment

Electric shock can result from the use of faulty electrical equipment or from the misuse of equipment in good condition.

Make sure that electrical equipment is maintained in good condition and frequently tested. Faulty equipment should be labelled and preferably removed from the work station.

Make sure that flexes, cables, plugs and sockets are not frayed, kinked, cut, cracked or otherwise damaged. If using cable reel extension equipment, ALWAYS ensure that the cable is fully unwound from the reel.

Make sure that electrical equipment and flexes do not come into contact with water.

Make sure that electrical equipment is protected by the correct rated fuse.

Never misuse electrical equipment and never use equipment which is in any way faulty. The results could be fatal.

Make sure that the cables of mobile electrical equipment cannot get trapped and damaged, such as in a vehicle hoist.

Make sure that the designated electrical workers are trained in basic First Aid.

In cases of electrocution:

- Switch off the power supply before approaching the victim.
- If this is not possible, **DO NOT TOUCH THE VICTIM** but push or drag the person from the source of electricity using dry, non-conductive material.
- Commence resuscitation if trained to do so.
- **SEEK IMMEDIATE MEDICAL ATTENTION.**

Exhaust Fumes

These contain asphyxiating, harmful and toxic chemicals and particles such as carbon oxides, nitrogen oxides, aldehydes, lead and aromatic hydrocarbons. Engines should be run only under conditions of adequate exhaust extraction or general ventilation and not in confined spaces.

Gasoline (Petrol) engine

There may not be adequate warning of odour or of irritation before toxic or harmful effects arise. These may be immediate or delayed.

Gas Oil (Diesel engine)

Soot, discomfort and irritation usually give adequate warning of hazardous fume concentrations.

Fibre Insulation

The fibrous nature of surfaces and cut edges can cause skin irritation. This is usually a physical and not a chemical effect.

Precautions should be taken to avoid excessive skin contact through careful organization of work practices and the use of gloves.

Fire

Many of the materials found on or associated with the repair of vehicles are highly flammable. Some give off toxic or harmful fumes if burnt; others such as fluoroelastomers when burnt or damaged by excessive heat can break down and produce highly corrosive hydrofluoric acid - See Fluoroelastomers.

Should any material be in a burnt or overheated condition, handle with extreme caution and wear protective clothing when handling such items. Dispose of such material in accordance with local regulations.

Decontaminate and dispose of protective clothing immediately after use.

Observe strict fire safety when storing and handling flammable materials or solvents, particularly near electrical equipment or welding processes.

Make sure, before using electrical or welding equipment, that there is no fire hazard present.

Have a suitable fire extinguisher available when using welding or heating equipment.

First Aid

Apart from meeting any legal requirements it is desirable for someone in the workshop to be trained in First Aid procedures.

Splashes in the eye should be flushed carefully with clean water for at least ten minutes.

Soiled skin should be washed with soap and water.

In case of cold burns, from alternative fuels, place affected area in cool to cold water.

Individuals affected by inhalation of gases and fumes should be removed to fresh air immediately. If effects persist, consult a doctor.

If liquids are swallowed inadvertently, consult a doctor giving him the information on the container or label. Do not induce vomiting unless this action is indicated on the label.

Fluoroelastomers (Synthetic Rubber)

Many 'O' rings, seals, hoses, flexible pipes and other similar which appear to be manufactured from natural rubber are, in fact, made of synthetic materials called Fluoroelastomers.

Under normal operating conditions, these materials are safe and do not constitute a health hazard. However, if the materials are damaged by burning or exposure to excessive heat, they can break down and produce highly corrosive hydrofluoric acid.



WARNING: Contact with hydrofluoric acid can cause serious burns on contact with the skin. If skin contact does occur, carry out the following steps immediately: Remove any contaminated clothing. SEEK IMMEDIATE MEDICAL ATTENTION Irrigate affected area of skin with copious amounts of cold water or limewater for 15 to 60 minutes.

Foams - Polyurethane

Used in sound and noise insulation. Cured foams used in seat and trim cushioning.

Unreacted components are irritating and may be harmful to the skin and eyes. Wear gloves and goggles.

Individuals with chronic respiratory diseases, asthma, bronchial medical problems, or histories of allergic diseases should not work in or near uncured materials.

The components, vapors or spray mists can cause direct irritation, sensitivity reactions and may be toxic or harmful.

Vapors and spray mists must not be inhaled. These materials must be applied with adequate ventilation and respiratory protection. Do not remove the respirator immediately after spraying, wait until the vapour/mists have cleared.

Burning of the uncured components and the cured foams can generate toxic and harmful fumes. Smoking, naked flames or the use of electrical equipment during foaming operations and until vapors/mists have cleared should not be allowed. Any heat cutting of cured foams or partially cured foams should be carried out in areas having suitable fume extraction equipment.

Fuels

Avoid skin contact with fuel where possible. Should contact occur, wash the affected skin with soap and water.

Gasoline (Petrol)

Highly flammable - OBSERVE NO SMOKING POLICY.

Swallowing gasoline (petrol) can result in mouth and throat irritation and absorption from the stomach can result in drowsiness and unconsciousness. Small amounts can be fatal to children. Inhalation into the lungs, through vomiting, is a very serious hazard.

Gasoline (petrol) dries the skin and can cause irritation and prolonged or repeated contact may cause dermatitis; if it is allowed to enter the eyes, it will cause severe smarting. Wash affected area with copious amounts of water and **SEEK IMMEDIATE MEDICAL ATTENTION.**

Gasoline (petrol) may contain appreciable quantities of benzene, which is toxic upon inhalation and the concentration of vapors must be kept very low. High concentrations will cause eye, nose and throat irritation, nausea, headache, depression and symptoms of drunkenness. Very high concentrations will result in rapid loss of consciousness.

Make sure there is adequate ventilation when handling and using gasoline (petrol). Great care must be taken to avoid the serious consequences of inhalation in the event of vapour build up arising from spillages in confined spaces.

Special precautions apply to cleaning and maintenance operations on gasoline (petrol) storage tanks.

Gasoline (petrol) should not be used as a cleaning agent. It must not be siphoned by mouth.

Gas-oil (Diesel Fuel)

Combustible.

Prolonged skin contact with high boiling point gas oils (diesel fuel) may cause serious skin disorders including skin cancer.

Inhalation into the lungs will cause internal bleeding - **SEEK IMMEDIATE MEDICAL ATTENTION.**

If swallowed, DO NOT induce vomiting - SEEK IMMEDIATE MEDICAL ATTENTION.

Kerosene (Paraffin)

Used also as heating fuel, solvent and cleaning agent.

Flammable - OBSERVE NO SMOKING POLICY.

Irritation of the mouth and throat may result from swallowing. The main hazard from swallowing arises if liquid aspiration into the lungs occurs.

Liquid contact dries the skin and can cause irritation or dermatitis. Splashes in the eye may be slightly irritating.

In normal circumstances the low volatility does not give rise to harmful vapors. Exposure to mists and vapors from kerosene at elevated temperature should be avoided (mists may arise in dewaxing). Avoid skin and eye contact and make sure there is adequate ventilation.

If swallowed, DO NOT induce vomiting - SEEK IMMEDIATE MEDICAL ATTENTION.

Gas Cylinders

Gases such as oxygen, acetylene, argon and propane are normally stored in cylinders at pressures of up to 138 bar (13800 kPa) (2000 lbf/in²) and great care should be taken in handling these cylinders to avoid mechanical damage to them or to the valve gear attached. The contents of each cylinder should be clearly identified by appropriate markings.

Cylinders should be stored in well ventilated enclosures, and protected from ice and snow or direct sunlight. Fuel gases, for example acetylene and propane should not be stored in close proximity to oxygen cylinders.

Care should be exercised to prevent leaks from gas cylinders and lines and also to avoid sources of ignition.

Only trained personnel should undertake work involving gas cylinders.

General Workshop Tools and Equipment

It is essential that all tools and equipment are maintained in good condition and the correct safety equipment is used where required.

Never use tools or equipment for any purpose other than that for which they were designed. Never overload equipment such as hoists, jacks, axle and chassis stands or lifting slings. Damage caused by overloading is not always immediately apparent and may result in a fatal failure the next time that the equipment is used.

Do not use damaged or defective tools or equipment, particularly high speed equipment such as grinding wheels. A damaged grinding wheel can disintegrate without warning and cause serious injury.

Wear suitable eye protection when using grinding, chiselling or sand blasting equipment.

Wear a suitable breathing mask when using abrasive blasting equipment or using spraying equipment.

Make sure there is adequate ventilation to control dusts, mists and fumes.

High Pressure Air, Lubrication and Oil Test Equipment

Always keep high pressure equipment in good condition, and regularly maintained, particularly at joints and unions.

Never direct a high pressure nozzle, for example diesel injector, at the skin as the fluid may penetrate to the underlying tissue and cause serious injury.

Jacking

Always refer to the Jacking and Lifting section of this manual prior to raising the vehicle off the ground.

When vehicle is to be raised by means of a jack, ensure that it is standing on level ground, that parking brake is applied and wheels are chocked. ALWAYS use the recommended jacking points and ensure that vehicle jack has sufficient load capacity for the weight of the vehicle.



WARNING: Do not work on or under a vehicle supported only by a jack. Always support the vehicle on safety stands.

Ensure that hoists have sufficient load capacity for the weight of the vehicle.

Legal Aspects

There are many laws and regulations relating to health and safety in the use and disposal of materials and equipment in a workshop.

For a safe working environment and to avoid environmental pollution, workshops should be familiar, in detail, with the many health and safety laws and regulations within their country, published by both national and local authorities.

Lubricants and Greases

Avoid all prolonged and repeated contact with mineral oils. All lubricants and greases may be irritating to the eyes and skin.

Used Engine Oil

Prolonged and repeated contact with engine oil will result in the removal of natural fats from the skin, leading to dryness, irritation and dermatitis. In addition, used engine oil contains potentially harmful contaminants which may cause skin cancer. Adequate means of skin protection and washing facilities must be provided.

Do not employ used engine oils as lubricants or for any application where appreciable skin contact is likely to occur.

Health Protection Precautions

- Avoid prolonged and repeated contact with oils, particularly used engine oils.
- Wear protective clothing, including impervious gloves where practicable.
- Do not put oily rags into pockets.
- Avoid contaminating clothes, particularly underpants, with oil.
- Heavily soiled clothing and oil-impregnated footwear should not be worn. Overalls must be cleaned regularly.
- First Aid treatment should be obtained immediately for open cuts and wounds.
- Use barrier creams, applying them before each work period, to help the removal of oil from the skin.
- Wash with soap and water to make sure all oil is removed (skin cleansers and nail brushes will help). Preparations containing lanoline replace the natural skin oils which have been removed.
- Do not use gasoline (petrol), kerosene (paraffin), diesel fuel (gas oil), thinners or solvents for cleaning skin.
- If skin disorders develop, obtain medical advice without delay.
- Where practicable, degrease components prior to handling.
- Where there is a risk of eye contact, eye protection should be worn, for example chemical goggles or face shields; in addition an eye wash facility should be provided.

Environmental Precautions

This section provides general information which can help to reduce the environmental impacts from the activities carried out in workshops.

Emissions to air

Many of the activities that are carried out in workshops emit gases and fumes which can contribute to global warming, depletion of the ozone layer and/or the formation of photochemical smog at ground level. By considering how the workshop activities are carried out, these gases and fumes can be minimised, thus reducing the impact on the environment.

Exhaust fumes

Running car engines is an essential part of workshop activities and exhaust fumes need to be ventilated to atmosphere. However, the amount of time engines are running and the position of the vehicle should be carefully considered at all times, to reduce the release of poisonous gases and minimise the inconvenience to people living nearby.

Solvents

Some of the cleaning agents used are solvent based and will evaporate rapidly to atmosphere if used carelessly, or if containers are left unsealed. All containers must be firmly closed when not required and solvent should be used sparingly. Wherever possible, solvents having a low toxicity and flammability should be selected. Always follow the instructions supplied by the solvent manufacturer. Similarly, many paints are solvent based and the spray should be used in such a way as to reduce emissions to a minimum.

Refrigerant

It is illegal to release any refrigerant into the atmosphere. Discharge and replacement of these materials from air conditioning units should only be carried out using the appropriate equipment.

Discharges to water

Most workshops will have two systems for discharging waste water - storm drains and foul drains. Storm drains should only receive clean water i.e. rainwater. Foul drains will accept many of the normal waste water i.e. washing water, detergents and domestic type waste BUT NOT oil, petrol, solvent, acids, hydraulic fluid, antifreeze and similar fluids. If in doubt, always consult the local authority or water company.

Spillages

Every precaution must be taken to prevent spillage of oil, fuel, solvents etc., reaching the drains. All handling of such materials must take place well away from drains and preferably in an area with a suitable containing wall to prevent discharge into drains or watercourses. If a spillage occurs, it must be soaked up immediately using a spill kit where provided.

Checklist

Spillage prevention:

- Store liquids in a secure area.
- Make sure that taps on liquid containers are secure and cannot be accidentally turned on.
- Protect bulk storage tanks from vandalism by locking the valves.
- Transfer liquids from one container to another in an area away from open drains.
- Ensure lids are replaced securely on containers.
- Have spill kits available near to points of storage and liquid handling areas.

Spill Kits

Special materials are available to absorb a number of different substances. They can be in granular form, ready to use and are supplied in suitable containers. Disposal of used spill absorbing material is dealt with in Waste management.

Land contamination

Oils, fuels and solvents etc. can contaminate any soil with which they come into contact. Such materials **MUST** never be disposed of by pouring on to soil and every precaution must be taken to avoid spillage reaching soil. Waste materials stored on open ground could either leak or have contaminating substances washed off them that would contaminate the land. Always store these materials in suitable skips or similarly robust containers.

Legal compliance

Some sites may have a discharge consent for effluent discharge to the foul drain for a car wash etc. It is essential to know the types of effluent which are allowed to be discharged into the drain and to check the results of any monitoring carried out by the Water Company.

Where paint spraying operations are carried out it may be necessary to apply to the Local Authority for an air emissions licence to operate the plant. If such a licence is necessary, additional precautions will be necessary to comply with the requirements and the results of any air quality monitoring must be checked regularly.

Checklist

Always adhere to the following:

- Know what legal consents and licences apply to the operations.
- Check that the emissions and discharges comply with legal requirements.

Waste Management

Pollution can be reduced by careful handling, storage and disposal of all waste materials that occur on sites. Legislation makes it illegal to dispose of waste materials other than to licensed waste carriers and disposal sites.

This means that it is necessary to not only know what the waste materials are but also to have the necessary documentation and licences.

Handling and storage of waste

Ensure that waste materials are not poured down the drain or on to soil and are stored in such a way that they do not escape on to land or soil.

All waste must be segregated into individual types e.g. oils, metals, batteries, scrap components etc. This will prevent any reaction between different materials and assist in disposal.

Disposal of waste

Dispose of waste in accordance with the following guidelines:

- **Fuel, hydraulic fluid, anti-freeze and oil:** Keep separate and dispose of to specialist contractors.
- **Refrigerant:** Collect in specialist equipment and reuse.
- **Detergents:** Safe to pour down the foul drain if diluted.
- **Paint, thinners:** Keep separate and dispose of to specialist contractor.
- **Components:** Return to supplier for refurbishment or disassemble and reuse any suitable parts. Dispose of remainder in ordinary waste.
- **Small parts:** Reuse any suitable parts, dispose of the remainder in ordinary waste.
- **Metals:** Can be sold if separate from general waste.
- **Tyres:** Keep separate and dispose of to specialist contractor. DO NOT attempt to dispose of tyres by burning.
- **Components/materials containing asbestos:** Keep separate and dispose of to specialist contractor.
- **Oil and fuel wastes (e.g. rags, used spill kit material):** Keep separate and dispose of to specialist contractors.
- **Air filters:** Keep separate and dispose of to specialist contractors.
- **Rubber/plastics:** Dispose of in ordinary waste.
- **Hoses:** Dispose of in ordinary waste.
- **Batteries:** Keep separate and dispose of to specialist contractors.
- **Air bags - DANGER EXPLOSIVES:** Keep separate and dispose of to specialist contractors.
- **Electrical components:** Return to supplier for refurbishment or disassemble and reuse any suitable components. Dispose of remainder in ordinary waste.
- **Catalytic converters:** May be sold if kept separate from general waste.
- **Packaging:** Compact/recycle as much as possible and dispose of in ordinary waste.
- **Office/paper waste:** Recycle paper and toner and ink cartridges, dispose of remainder in ordinary waste.

Noise

Car alarm testing, panel beating, running engines, using air tools etc. are operations which invariably produce a large amount of noise. The location of such activities and also the time of day must be carefully considered having regard to the proximity of houses schools etc.

Some operations may produce high noise levels which could, in time, damage hearing. In these cases, suitable ear protection must be worn.

Solder

Solders are mixtures of metals such that the melting point of the mixture is below that of the constituent metals

(normally lead and tin). Solder application does not normally give rise to toxic lead fumes, provided a gas/air flame is used. Oxy-acetylene flames should not be used, as they are much hotter and will cause lead fumes to be produced.

Some fumes may be produced by the application of any flame to surfaces coated with grease, and inhalation of these should be avoided.

Removal of excess solder should be undertaken with care, to make sure that fine lead dust is not produced, which can give toxic effects if inhaled. Respiratory protection may be necessary.

Solder spillage and filings should be collected and removed promptly to prevent general air contamination by lead.

High standards of personal hygiene are necessary in order to avoid ingestion of lead or inhalation of solder dust from clothing.

Solvents

For example acetone, white spirit, toluene, xylene, trichloroethane.

Used in cleaning and dewaxing materials, paints, plastics, resins and thinners.

Some may be highly flammable or flammable.

Skin contact will degrease the skin and may result in irritation and dermatitis following repeated or prolonged contact. Some can be absorbed through the skin in toxic or harmful quantities.

Splashes in the eye may cause severe irritation and could lead to loss of vision.

Brief exposure of high concentrations of vapors or mists will cause eye and throat irritation, drowsiness, dizziness, headaches and, in the worst circumstances, unconsciousness.

Repeated or prolonged exposure to excessive but lower concentrations of vapors or mists, for which there might not be adequate warning indications, can cause more serious toxic or harmful effects.

Aspiration into the lungs, for example through vomiting, is the most serious consequence of swallowing.

Avoid splashes to the skin, eyes and clothing. Wear protective gloves, goggles and clothing if necessary.

Make sure there is good ventilation when in use, avoid breathing fumes, vapors and spray mists and keep containers tightly sealed. Do not use in confined spaces.

When spraying materials containing solvents, for example paints, adhesives, and metal coatings, use extraction ventilation or personal respiratory protection in the absence of adequate general ventilation.

Do not apply heat or flame except under specific and detailed manufacturers instructions.

Suspended Loads



CAUTION: Never improvise lifting tackle.

There is always a danger when loads are lifted or suspended. Never work under an unsupported, suspended or raised load, for example a suspended engine.

Always make sure that lifting equipment such as jacks, hoists, axle stands and slings are adequate and suitable for the job, in good condition and regularly maintained.

Viton

In common with many other manufacturers vehicles, some components installed to Land Rover vehicles have seals, 'O' rings or gaskets which contain a material known as 'Viton'.

Viton is a fluoroelastomer, that is a synthetic rubber type which contains Fluorine. Although Viton is the most well known fluoroelastomer, there are others, including Fluorel and Tecnoflon.

When used under design conditions fluoroelastomers are perfectly safe. If, however, they are exposed to temperatures in excess of 400°C, the material will not burn, but will decompose, and one of the products formed is hydrofluoric acid.

This acid is extremely corrosive and may be absorbed directly, through contact, into the general body system.
WHERE CASES OF SKIN CONTACT OCCUR, SEEK IMMEDIATE MEDICAL HELP.

O-rings, seals or gaskets which have been exposed to very high temperatures will appear charred or as a black sticky substance.

DO NOT, under any circumstances touch them or the attached components.

Enquiries should be made to determine whether Viton or any other fluoroelastomer has been used in the affected O-ring, seal or gasket. If they are of natural rubber or nitrile there is no hazard. If in doubt, be cautious as the material may be Viton or any fluoroelastomer.

If Viton or any other fluoroelastomers have been used, the affected area should be decontaminated before the commencement of work.

Disposable heavy duty plastic gloves should be worn at all times, and the affected area washed down using wire wool and a limewater (calcium hydroxide) solution to neutralise the acid before disposing of the decomposed Viton residue and final cleaning of the area. After use, the plastic gloves should be discarded carefully and safely.

Welding

Welding processes include Resistance Welding (Spot Welding), Arc Welding and Gas Welding.

Resistance Welding

This process may cause particles of molten metal to be emitted at a high velocity, and the eyes and skin must be protected.

Arc Welding

This process emits a high level of ultra-violet radiation which may cause arc-eye and skin burns to the operator and to other persons nearby. Gas-shielded welding processes are particularly hazardous in this respect. Personal protection must be worn, and screens used to shield other people.

CONTACT LENS WEARERS ARE ADVISED TO REVERT TO ORDINARY SPECTACLES WHEN ARC WELDING as the arc spectrum is believed to emit microwaves which dry out the fluid between the lens and the eye. This may result in blindness when the lens is removed from the eye.

Metal spatter will also occur, and appropriate eye and skin protection is necessary.

The heat of the welding arc will produce fumes and gases from the metals being welded, the rods and from any applied coatings or contamination on the surfaces being worked on. These gases and fumes may be toxic and inhalation of these should be avoided. The use of extraction ventilation to remove the fumes from the working area may be necessary particularly in cases where the general ventilation is poor, or where considerable welding work is anticipated. In extreme cases or confined spaces where adequate ventilation cannot be provided, air-fed respirators may be necessary.



CAUTION: Some of the components installed to the vehicle e.g. the interior cross beam and underbonnet cross member are manufactured from magnesium alloy. On no account should any welding operations be attempted on these components.

Gas Welding (and Cutting)

Oxy-acetylene torches may be used for welding and cutting, and special care must be taken to prevent leakage of these gases, with consequent risk of fire and explosion.

The process will produce metal spatter and eye and skin protection is necessary.

The flame is bright, and eye protection should be used, but the ultra-violet emission is much less than that from arc welding, and lighter filters may be used.

The process itself produces few toxic fumes, but such fumes and gases may be produced from coatings on the work, particularly during cutting away of damaged body parts, and inhalation of the fumes should be avoided.

In brazing, toxic fumes may be produced from the metals in the brazing rod, and a severe hazard may arise if brazing rods containing cadmium are used. In this event particular care must be taken to avoid inhalation of fumes and expert advice may be required.

SPECIAL PRECAUTIONS MUST BE TAKEN BEFORE ANY WELDING OR CUTTING TAKES PLACE ON VESSELS WHICH HAVE CONTAINED COMBUSTIBLE MATERIALS, FOR EXAMPLE BOILING OR STEAMING OUT OF FUEL TANKS.

Warning Symbols on Vehicles

Decals showing warning symbols will be found on various vehicle components.

These decals must not be removed. The warnings are for the attention of owners/operators and persons carrying out service or repair operations on the vehicle.

Special Tool Glossary

Service Tools

Special service tools have been developed to facilitate removal, dismantling and assembly of mechanical components in a cost effective and time efficient manner. The use of such special tools also helps prevent the potential for damage to components.

Some operations described in this manual cannot be carried out properly without the aid of the relevant service tools.

All orders and enquiries from the United Kingdom and European countries except Germany, Austria, Switzerland and Spain and countries not in the following list should be sent direct to:

SPX UK Ltd.,

Genoa House,

Everdon Park,

Daventry,

Northants,

NN11 5YJ

England

Tel: 0044 (0) 1327 303467/303455

Fax: 0044 (0) 1327 706632

e-mail: spxsalesuk@servicesolutions.spx.com

Overseas orders for the following countries should be placed with the local distributor.

Germany, Austria and Switzerland

SPX Europe GMBH,

Porschestrasse 4,

63512 Hainburg,

Germany

Tel: 0049 61829590

Fax: 0049 6182959299

Spain

SPX Iberica SA,

C/Francisco Aritio,

158 nave 72 (Nudo Oeste),
19004 Guadalajara,
Spain
Tel: 0034 949208381
Fax: 0034 949208327

North America

SPX Corporation

665, Eisenhower Drive,
Owatonna,
MN 55060,
USA
Tel: 0018 772979110
Fax: 0018 005787375

Australia

SPX Australia,

28, Clayton Road,
Notting Hill,
Victoria 3168,
Australia
Tel: 0061 00395446222
Fax: 0061 00395445222
e-mail: sales@spx.com.au

Japan and East Asia

Jatek Ltd.,

5 - 53, Minawacho 2-chome,
Kohoku-ku,
Yokohama,
Kanagawa 223-0051,

Japan

Tel: 0081 455627700


Fax: 0081 455627800


Identification Codes

VIN Number

The VIN number is found in three locations:

1. Stamped on the RH side of the chassis towards the rear of the front lashing eye.
2. At the bottom of the windshield glass on the RH side of the vehicle and is visible from the outside.
3. On a plate attached to the brake pedal box in the engine compartment.






E91381

VIN Position	Character	Identifies
1 - 3 - World identifier	SAL	Land Rover (UK)
4,5 - Vehicle type	LD	Defender
6 - Class	H	110 inch
6 - Class	K	130 inch
6 - Class	V	90 inch
6 - Class	B	110 Extra heavy duty
7 - Body style	A	Regular
7 - Body style	B	3 Door station wagon
7 - Body style	F	4 Door Crew Cab non h/cap
7 - Body style	H	H/cap with or without 4 door crew cab
7 - Body style	M	4 Door Station Wagon
8 - Engine	S	2.4L Euro spec (EU4)
8 - Engine	T	2.4L ROW spec (non cat)
9 - Transmission and steering	7	RHD 6 speed manual transmission
9 - Transmission and steering	8	LHD 6 speed manual transmission
10 - Model year	7	2007 Model year
10 - Model year	8	2008 Model year
10 - Model year	9	2009 Model year
11 - Plant	A	Solihull
11 - Plant	C	Zimbabwe
11 - Plant	F	KD
11 - Plant	J	Malaysia
11 - Plant	K	Kenya
11 - Plant	P	Pakistan
11 - Plant	W	Turkey

Vehicle Identification Plate



The VIN plate contains the following information:

- A** - Type approval number
- B** - Vehicle identification number

C - Maximum permitted laden weight for vehicle

D - Maximum vehicle and trailer weight


E - Maximum road weight - front axle

F - Maximum road weight - rear axle

G - Paint code

H - Trim level


Unit/Assembly Serial Number Locations



Engine Identification Label


- Date and time of manufacture
- Engine part number

Manual Transmission Serial Number



The Manual Transmission Serial Number is stamped on a cast pad on the bottom RH side of the transmission casing.


Front Axle Serial Number



J6093

The front axle serial number is stamped on the LH side of the front axle tube, inboard of radius arm mounting bracket.


Rear Axle Serial Number



J6094

The rear axle serial number is stamped on the rear axle tube on the LH side, inboard of the spring mounting.

Transfer Case Serial Number



J6092

The transfer case serial number is stamped on the LH side of the transfer case below the mainshaft rear bearing housing adjacent to the bottom cover.


Vehicle Recovery



CAUTION: The vehicle has permanent four-wheel drive. The following towing instructions must be adhered to:

Towing the vehicle on all four wheels with driver operating steering and brakes.

- Turn ignition key to position '1' to release steering lock.
- Select neutral in main gearbox and transfer gearbox.



J6085

- Secure tow rope, chain or cable to front towing eyes (alternative types shown).
- Release the parking brake.



CAUTION: The brake booster and power assisted steering system will not be functional without the engine running. Greater pedal pressure will be required to apply the brakes, the steering system will require greater effort to turn the front road wheels. The vehicle tow connection should be used only in normal road conditions, 'snatch' recovery should be avoided.

Transporting the vehicle by trailer

Lashing/towing eyes are provided on front and rear of the chassis side members, see J6085, to facilitate the securing of the vehicle to a trailer or other means of transportation.



CAUTION: Underbody components must not be used as lashing points.

Install vehicle on trailer and apply park brake. Select neutral in main gearbox.

Rear suspended tow by breakdown vehicle

- If the front axle is to be trailed turn ignition key to position '1' to release steering lock.

- Select neutral in main gearbox and transfer box.
- The steering wheel and/or linkage must be secured in a straight ahead position. DO NOT use the steering lock mechanism for this purpose.

Jump starting



WARNING: Hydrogen and oxygen gases are produced during normal battery operation. This gas mixture can explode if flames, sparks or lighted tobacco are brought near battery. When charging or using a battery in an enclosed space, always provide ventilation and shield your eyes.

Keep out of reach of children. Batteries contain sulphuric acid. Avoid contact with skin, eyes, or clothing. Also, shield eyes when working near battery to protect against possible splashing of acid solution. In case of acid contact with skin, eyes, or clothing, flush immediately with water for a minimum of fifteen minutes. If acid is swallowed, drink large quantities of milk or water, followed by milk of magnesia, a beaten egg, or vegetable oil.

SEEK MEDICAL AID IMMEDIATELY.


To Jump Start - Negative Ground Battery



WARNING: To avoid any possibility of injury use particular care when connecting a booster battery to a discharged battery.

- Position vehicles so that jump leads will reach, ensuring that vehicles DO NOT TOUCH, alternatively a fully charged slave battery may be positioned on floor adjacent to vehicle.
- Ensuring that ignition and all electrical accessories are switched off, that parking brake is applied and neutral is selected, connect the jump leads as follows;

A. Connect one end of first jumper cable to positive (+) terminal of booster battery. B. Connect other end of first jumper cable to positive (+) terminal of discharged battery. C. Connect one end of second jumper cable to negative terminal of booster battery. D. Connect other end of second jumper cable to a good earth point on the disabled vehicle (eg. engine front lifting eye, as shown in J6086), NOT TO NEGATIVE TERMINAL OF DISCHARGED BATTERY. Keep jumper lead away from moving parts, pulleys, drive belts and fan blade assembly.



J6086



WARNING: Making final cable connection could cause an electrical arc which if made near battery could cause an explosion.

- If booster battery is installed in another vehicle, start engine and allow to idle.
- Start engine of vehicle with discharged battery, following starting procedure in Owners' Manual.



CAUTION: If vehicle fails to start within a maximum time of 12 seconds, switch ignition off and investigate cause. Failing to follow this instruction could result in irreparable damage to catalyst, if fitted.

- Remove negative (-) jumper cable from the engine and then terminal of booster battery.
- Remove positive (+) jumper cable from positive terminals of booster battery and discharged battery.

Jacking

General



WARNING: The following instructions must be adhered to before raising the vehicle off the ground:

- Position vehicle on a solid, level surface.
- Apply the parking brake.
- Select 'P' - PARK on automatic transmission selector or 1st gear on manual transmission and 'H' High on transfer case.
- Select low range in the transfer box.



CAUTION: To avoid damage occurring to the under body components of the vehicle the following jacking procedures must be adhered to.

DO NOT POSITION JACKS OR AXLE STANDS UNDER THE FOLLOWING COMPONENTS.

- Body structure
- Bumpers
- Fuel lines
- Brake lines
- Front radius arms
- Panhard rod
- Steering linkage
- Rear trailing links
- Fuel tank
- Engine sump
- Gearbox bell housing

Vehicle jack

The jack provided with the vehicle is only intended for use in an emergency such as changing a tire. DO NOT use the jack for any other purpose. Refer to the Owner's Handbook for the vehicle jack location points and jacking procedures.



WARNING: Never work under a vehicle supported solely by the vehicle jack.

Hydraulic jack

A hydraulic jack with a minimum lifting capacity of 1500 kg, (3,300 lbs) must be used.




WARNING: Do not commence work on the underside of the vehicle until suitable axle stands have been placed in the correct position.



WARNING: Always chock the wheels when jacking. The parking brake may be ineffective when the wheel(s) are off the ground.

Raising the Front of the Vehicle



J6083


- Position cup of hydraulic arm under differential casing.

NOTE:

The differential casing is not central to the axle. Care should be taken when raising the front road wheels off the ground as the rear axle has less sway stiffness.

- Raise front road wheels to enable an axle stand to be installed under left hand axle tube.
- Position an axle stand under right hand axle tube, carefully lower jack until axle sits securely on both axle stands, remove trolley jack.
- Before commencing work on underside of vehicle re-check security of vehicle on stands.
- Reverse procedure when removing vehicle from stands.

Raising the Rear of the Vehicle



J6084

- Position cup of hydraulic arm under differential casing.
- Raise vehicle to enable axle stands to be installed under left and right hand axle tubes.
- Lower jack until axle sits securely on axle stands, remove trolley jack.
- Before commencing work on underside of vehicle re-check security of vehicle on stands.
- Reverse procedure when removing vehicle from stands.


Lifting

Four post vehicle ramps

Position the vehicle on the ramp with the front and the rear of the vehicle equidistant from the ends of the ramp. Chock the wheels, select neutral on the transmission and where practicable apply the parking brake.

If a wheel free condition is required, use a wheel-free system which supports beneath the axle casings.

Two post vehicle ramps



E82298



WARNING: When raised to the desired height, make sure the vehicle is stable before starting work.



CAUTION: If the drive shafts are to be disconnected, release the parking brake and select neutral on the transmission in order that the shaft(s) can be rotated when the vehicle is raised to the desired height.

- Position the vehicle with the centre of the lifting pillars aligned with the front of the driver/passenger seat cushions.
- Extend the lifting arms and position the pads of each lifting arm beneath the body frame longitudinal lifting points, arrowed in the illustration.
- Raise the vehicle until the wheels are just clear of the ground and check that the pads of each lifting arm are still correctly positioned and are in full contact with the body frame longitudinals.
- Raise the vehicle to the desired height.
- Ensure that the vehicle is correctly supported on all four lifting pads, that the pads are still correctly positioned and are in full contact with the body frame longitudinals.

Road roller testing

Four wheel Rolling Road



WARNING: DO NOT attempt to drive individual wheels with vehicle supported on floor jacks or stands.

Provided that front and rear rollers are rotating at identical speeds and that normal workshop safety standards are applied, there is no speed restriction during testing except any that may apply to the tyres.

Two wheel rolling road

IMPORTANT: Use a four wheel rolling road for brake testing if possible.


If brake testing on a two wheel rolling road is necessary, it must be carried out with propeller shaft to the stationary axle removed and neutral selected in BOTH main gearbox and transfer gearbox. When checking brakes, run engine at idle speed to maintain brake servo vacuum.

Maintenance Schedules - Diesel Engines

Torque Specifications

Description	Nm	lb-ft
Wheel nuts - steel wheels	100	80
Wheel nuts - alloy wheels	130	96
Wheel nuts - Heavy duty wheels	170	125
Transfer box filler plug	30	22
Transfer box drain plug	30	22


Under Bonnet View



Item	Part Number	Description
1		Coolant expansion tank
2		Engine oil dipstick
3		Engine oil filler cap
4		Clutch fluid reservoir filler cap
5		Brake fluid reservoir filler cap
6		Windscreen washer reservoir
7		Power steering fluid reservoir

Seats and Safety Belts


1. Check seat frames are secured to floor and show no signs of movement.
2. Check operation of seat slide and tilt mechanisms, making sure there is no excessive play between seat cushion and seat back.
3. Check tightness of accessible seat fixings.
4. Fully extract seat belt and allow it to return under its own recoil mechanism.
5. Check entire length of seat belt webbing for signs of fraying or damage. Repeat for all belts.
6. Check security of seat belt upper mountings.



7. Check security of seat belt buckle mountings.

8. Connect each belt to the correct buckle, check seat belt buckle and tongue are secure. Release seat belt buckle and check for correct operation.

9. Check tightness of accessible seat belt mountings



Lamps, Horns and Warning Indicators

1. Check side, head, fog, reversing and tail lamps for correct operation.

2. Check operation of headlamp automatic levelling system - if installed.

3. Check turn signals and hazard warning lamps for correct operation.

4. Check brake (stop) lamps for correct operation.

5. Check all exterior lamp lenses for clarity and condition; pay particular attention to headlamp and fog lamp lenses for stone chips or damage.

6. Check horn for loud, clear sound.

7. Switch on headlamps and check that side/headlamp reminder warning sounds when door is opened.

8. Check operation of interior courtesy lamps.

9. Check operation of all instrument pack warning and indicator lamps.


Washers and Wipers

1. Operate screen washer and switch on wipers. Check washer jets are correctly aimed and check for smooth seamless operation across screen of wiper blades at all speeds, including intermittent.


2. Repeat operation for rear screen wipers and washers.

3. Check all wiper blades for condition and signs of splits or damage.

4. Check security of wiper arms.



M100634



M100633

Parking Brake

1. With the vehicle stationary, apply the parking brake and check for correct operation. For additional information, refer to [Parking Brake Shoe and Lining Adjustment](#) (206-05 Parking Brake and Actuation)

Release parking brake and check for correct operation.

Battery Condition

NOTE:

The vehicle may be fitted with an alarm and immobilisation system. To prevent the alarm from sounding, it is important that the following procedure is used when disconnecting the battery.

1. Remove drivers seat base.
2. Release clip securing battery cover.
3. Remove battery cover.
4. Turn the ignition switch to position 'II', and then to position '0'.
5. Remove the ignition key.

NOTE:

Always disconnect the -ve terminal first. When replacing, connect the +ve terminal first.


6. Disconnect the vehicle -ve terminal within 15 seconds.

7. The battery is designed to be maintenance free, so topping-up is not possible. On the top of the battery is a battery indicator. When the indicator shows:

- GREEN - The battery is in a good state of charge.
- DARK (turning to black) - The battery needs charging.
- CLEAR (or light yellow) - The battery needs replacing. Do not charge the battery or jump start the vehicle in this condition.
- If the green dot is missing, the battery needs charging.

NOTE:


If the indicator shows clear or yellow, tap the indicator with the handle of a screwdriver to disperse any air bubbles. If the indicator colour remains unchanged, the battery will need replacing.




8. Clean and grease battery terminals and leads with petroleum jelly.
9. Connect leads to battery (+ve first) and tighten clamp bolts.
10. Fit battery cover and secure with clip.
11. Fit drivers seat base.

Clean Battery Terminals

1. Remove drivers seat base.
2. Release clip securing battery cover. Remove battery cover.



3. Disconnect both battery terminals, -ve terminal first. Clean off corrosion and neutralise. Smear terminals with petroleum jelly.
4. Reconnect battery terminals +ve first, when maintenance operations have been completed.



10M0494

5. Fit battery cover and secure with clip.
6. Fit drivers seat base.

Handset Battery

NOTE:

Do not remove a battery until you are ready to install the replacement. Always fit a Land Rover STC4080 or a Panasonic CR2032 replacement battery.

1. Unlock the vehicle and disarm the alarm system.
2. Turn the ignition switch to position 'II', then turn to position '0' and remove the key.



CAUTION: Do not allow moisture to get inside the handset.

3. Carefully prise the handset apart, starting from the keying end. Avoid damaging the seal between the two halves of the case.
4. Slide the battery out of its clip, taking care to avoid touching the circuit board or the contact surfaces of the clip.
5. Press and hold one of the buttons for at least 5 seconds to drain any residual power from the handset.
6. Fit the new battery, making sure that correct polarity is maintained (+ve side facing up). Finger marks will adversely affect battery life. Avoid touching the flat surfaces of the battery, and wipe clean before fitment.
7. Reassemble the two halves of the handset. Operate the Padlock symbol button at least 4 times within range of the vehicle to resynchronise the handset.

Headlamp Alignment

1. Check alignment of headlamps. For additional information, refer to [Headlamp Adjustment](#) (417-01 Exterior Lighting)

Road Wheels

1. Loosen wheel nuts. Raise vehicle for wheel free condition and remove the wheel nuts.
2. Mark the wheel to stud relationship to make sure that the wheels are refitted in the same orientation.
3. Apply a thin coat of anti-seize compound to wheel hub centre.

NOTE:

When refitting road wheel nuts do not over tighten using powered tools. Make sure the wheel nuts are correctly tightened in the correct sequence.

4. Refit wheels to original hub position.

5. Tighten wheel nuts.

- Steel wheels - 100 Nm (80 lbf/ft)
- Alloy wheels - 130 Nm (96 lbf/ft)
- Heavy Duty wheels - 170 Nm (125 lbf/ft)

Tire Pressures, Condition and Tread Depth

1. Check for any apparent damage to tires, paying particular attention to side walls.

NOTE:

Any adjustments to steering or suspension will be subject to additional labour and/or material cost and should not be carried out without the authorisation of the customer.

2. Look at tires treads and check for any unusual wear patterns which may indicate out of specification adjustment of steering or suspension.

NOTE:

Any requirement to replace tires should be advised to the customer before any remedial work is carried out. This will be subject to additional labour and/or material cost and should not be carried out without the authorisation of the customer.

3. Measure the tread depth across the width of the tire and around the circumference. Annotate the maintenance check sheet with the lowest figure obtained from each tire.

Brake Pads, Calipers and Discs

1. With front road wheels removed, check brake pad thickness and make sure that both pads are wearing evenly.

NOTE:

Any requirement to replace brake pads or brake disc should be advised to the customer as this will incur additional labour and/or material cost and should not be carried out without the authorisation of the customer.

2. Check brake discs for signs of cracking, excessive scoring or oil contamination.

3. Check for any signs of brake fluid leakage from caliper seals, hoses or unions.

4. Using brake cleaner, remove excessive deposits of brake dust from pads, calipers and disc shields.



Road Wheel Speed Sensor Harness

1. Check each road wheel speed sensor harness is correctly and securely routed.

NOTE:

Any requirement to replace a road wheel speed sensor should be advised to the customer as this will incur additional labour and/or material cost and should not be carried out without the authorisation of the customer.

2. Inspect each harness for chafing or damage.



Fuel Filter



WARNING: Fuel vapour is highly flammable and in contained spaces is also explosive and toxic. Always have a fire extinguisher containing FOAM, CO2, GAS OR POWDER close at hand when handling or draining fuel.

Replace fuel filter. For additional information, refer to [Fuel Filter](#) (310-01 Fuel Tank and Lines - 2.4L Diesel)

Charge Air Cooler

1. Visually check for any obstructions in the radiator and charge air cooler matrix and remove debris as necessary.
2. Visually check fan blades for damage.
3. Check cooling, charge air cooler and heating systems for leaks, hoses and oil pipes for security and condition.
4. Check accessible hose clips for tightness.
5. Check coolant level, top-up if necessary

Charge Air Cooler Flush

1. Remove charge air cooler. For additional information, refer to [Charge Air Cooler](#) (303-12 Intake Air Distribution and Filtering - 2.4L Diesel)
2. Flush charge air cooler element using Unicorn Chemicals 'C' Solve following the manufacturers instructions.
3. Thoroughly dry charge air cooler and making sure that no trace of solvent remains in the element.
4. Install charge air cooler. For additional information, refer to [Charge Air Cooler](#) (303-12 Intake Air Distribution and Filtering - 2.4L Diesel)

Cooling System Top-Up

1. With engine cold, remove expansion tank filler cap.
2. Top-up with recommended mixture of coolant until level reaches mark on expansion tank.
3. Fit expansion tank filler cap.

Coolant Renew

1. Renew engine coolant. For additional information, refer to [Cooling System Draining, Filling and Bleeding](#) (303-03 Engine Cooling - 2.4L Diesel)
2. Fit expansion tank filler cap.

Door Locks and Hinges

1. Open each door in turn and lubricate door hinges and check strap using recommended lubricant.
2. Lubricate door lock, striker and private lock using PTFE lubricant. Remove excessive lubricant, particularly from door striker area, to avoid customer complaint.
3. Check tightness of accessible door lock and striker fixings
4. Open and close door to check for smooth, noise-free operation. Make sure door closes securely.
5. Check for smooth operation of private lock.
6. With bonnet open, lubricate hinges, striker, lock and safety catch using a suitable lubricant.

Air Cleaner Element

1. Replace air cleaner element. For additional information, refer to [Air Cleaner Element](#) (303-12 Intake Air Distribution and Filtering - 2.4L Diesel)

Accessory Drive Belt

Check accessory drive belt for signs of splits, fraying, oil contamination and wear.

NOTE:


Any requirement to replace the accessory drive belt should be advised to the customer as this will incur additional labour and/or material cost and should not be carried out without the authorisation of the customer.

1. Renew a damaged or contaminated accessory drive belt.

Fluid Levels

Brake Fluid Reservoir

1. Check the fluid level visually through transparent side of reservoir without removing cap.
2. If level is below **"MAX"** mark clean the area around the reservoir filler cap and remove cap.
3. Top up to **"MAX"** mark with recommended brake fluid. For additional information, refer to [Specifications](#) (206-00 Brake System - General Information)




J6103

4. Reinstall the reservoir filler cap.

Clutch Fluid Reservoir

1. Clean area around clutch fluid reservoir cap, and remove cap.



J6102


2. Check fluid level in clutch fluid reservoir.
3. Clean the area around the reservoir filler cap, remove the cap.
4. If necessary, top-up using the recommended fluid to the **"MAX"** mark on the reservoir. For additional information, refer to [Specifications](#) (206-00 Brake System - General Information)
5. Reinstall the reservoir filler cap.

Power Steering Fluid



CAUTION: To prevent over filling, check/top-up the system with the engine switched off and the system cold. Make sure that the steering wheel is in the straight ahead position, do not turn the steering wheel prior to checking the fluid level.

1. Check that the fluid level is to the mid-way mark between the 'MAX' and 'MIN' marks on the fluid reservoir, top-up if necessary.
2. Clean the area around the reservoir filler cap, remove the cap.
3. If necessary, top-up using the recommended fluid to the mid-way mark on the reservoir. For additional information, refer to [Specifications](#) (206-00 Brake System - General Information)



CAUTION: Do not fill reservoir above the 'MAX' mark.

4. Reinstall the reservoir filler cap.

Windshield Washer Reservoir

1. Remove the windshield washer reservoir filler cap.
2. Top-up the reservoir using a mixture of an approved windshield washer fluid and water until the level is to the bottom of the reservoir filler neck.
3. Reinstall the reservoir filler cap.

Engine Oil and Filter

1. Renew engine oil and filter. For additional information, refer to [Engine Oil Draining and Filling](#) (303-01 Engine - 2.4L Diesel)

Steering Box

1. Check steering box for leaks.
2. Check there is no backlash in steering box with the road wheels in the straight ahead position. Adjust if necessary. For additional information, refer to [Steering Gear Adjustment](#) (211-00 Steering System - General Information)

Manual Gearbox Oil



WARNING: Avoid excessive skin contact with used gearbox oil. Used gearbox oil contains potentially harmful contaminants which may cause skin cancer or other serious skin disorders.

1. Renew gearbox oil. For additional information, refer to [Transmission Draining and Filling](#) (308-03 Manual Transmission/Transaxle)

Transfer Case Oil

Check and Top-Up



WARNING: Avoid excessive skin contact with mineral oil. Mineral oils remove the natural fats from the skin, leading to dryness, irritation and dermatitis.



CAUTION: The transfer case oil filler plug must not be used as a transfer case oil level plug. Failure to follow this instruction may result in damage to the vehicle.

1. Drain and measure the transfer case oil. For additional information, refer to [Transfer Case Draining and Filling](#) (308-07A)
2. Refill the transfer case with the recommended oil. For additional information, refer to [Specifications](#) (308-07A)

Transfer Case Oil Replace



WARNING: Avoid excessive skin contact with mineral oil. Mineral oils remove the natural fats from the skin, leading to dryness, irritation and dermatitis.

1. Renew transfer case oil. For additional information, refer to [Transfer Case Draining and Filling](#) (308-07 Transfer Case - 2.4L Diesel)


Front and Rear Axles

Check



WARNING: Avoid excessive skin contact with used axle oil. Used axle oil contains potentially harmful contaminants which may cause skin cancer or other serious skin disorders.

1. Make sure vehicle is level.
2. Using 13 mm square drive wrench, remove filler/level plug.



Item	Part Number	Description
A		Front and rear axle - 90 models; Front - 110/130 models
B		Rear axle - 110/130 models

3. If necessary inject new oil until oil runs out from filler/level hole. Allow excess oil to drain and wipe clean. For additional information, refer to [Specifications](#) (205-02 Rear Drive Axle/Differential)

4. Clean and refit filler/level plug.

Replace




WARNING: Avoid excessive skin contact with used axle oil. Used axle oil contains potentially harmful contaminants which may cause skin cancer or other serious skin disorders.

1. Make sure vehicle is level and place suitable tray under axle to be drained.
2. Using 13mm square drive wrench, remove drain and filler/level plugs from axle and allow oil to drain completely.
3. Clean and refit drain plug.
4. Inject new oil, until it runs out from filler/level hole. Allow excess oil to drain and wipe clean.
5. Clean and refit filler/level plug.

Drive Shafts

1. Clean area around front universal joint grease nipple.
2. Apply recommended grease to the grease nipple.



J6113

Clutch Pipes and Unions

1. Check clutch pipes and unions for chafing, leaks and corrosion.

Power Steering Pipes and Unions

1. Check clutch pipes and unions for chafing, leaks and corrosion.

Engine, Gearbox, Transfer Case and Axles

1. Check for oil leaks from Engine, Gearbox, Transfer box, and axles. Pay particular attention to areas around oil seals.

Exhaust System

1. Visually check condition of exhaust system for signs of damage.
2. Check condition of exhaust heat shields.
3. Check exhaust system is firmly secured and check condition of exhaust mounting rubbers, clamps and brackets.

Steering Box and Suspension

1. Check steering box fixings. For additional information, refer to [Specifications](#) (204-00 Suspension System - General Information)
2. Check LH and RH front radius arm fixings. Tighten if necessary. For additional information, refer to [Specifications](#) (204-00 Suspension System - General Information)
3. Check Panhard rod fixings. Tighten if necessary. For additional information, refer to [Specifications](#) (204-00 Suspension System - General Information)
4. Check all rear axle fixings. Tighten if necessary. For additional information, refer to [Specifications](#) (205-02 Rear Drive Axle/Differential)

Steering Ball Joints

1. Check for wear in joints by attempting to move the joint from side to side and backwards and forwards. If free movement is apparent, fit a new joint assembly.



CAUTION: Do not check for wear by having an assistant move the steering wheel from side to side while observing the joint.


2. Check condition of steering ball joints paying particular attention to dust covers.

NOTE:

Any requirement to replace the steering ball joints should be advised to the customer as this will incur additional labour and/or material cost and should not be carried out without the authorisation of the customer.

NOTE:

Ball joints are lubricated for life during manufacture and require no further lubrication unless the rubber boot has been dislodged or damaged. All joints should be checked at specified service intervals, but more frequently if vehicle is used under arduous conditions.



M570830

Shock Absorbers

1. Check for signs of leakage from suspension dampers.
2. Check for signs of suspension damper damage.

Towing Bracket

1. Check security of towing bracket.

Engine and Transmission Mountings

1. Check condition of front LH engine mounting. Tighten fixings if necessary. For additional information, refer to [Specifications](#) (303-01 Engine - 2.4L Diesel)
2. Check condition of front RH engine mounting. Tighten fixings if necessary. For additional information, refer to [Specifications](#) (303-01 Engine - 2.4L Diesel)
3. Check condition of rear LH gearbox mounting. Tighten fixings if necessary. For additional information, refer to [Specifications](#) (308-03 Manual Transmission/Transaxle)
4. Check condition of rear RH gearbox mounting. Tighten fixings if necessary. For additional information, refer to

Road Test



WARNING: Two wheel roller tests where rollers are driven by the vehicle **MUST NOT** be carried out. For details of rolling road testing,

1. Check for correct operation of starter switch. Make sure the engine starts in a correct manner. Leave the engine running.
2. With vehicle stationary, turn steering from lock to lock. Check for smooth operation and make sure there is no undue noise from the power steering pump or drive belt.
3. Depress clutch and select all gears in turn. Check for smooth notch free engagement.
4. Drive vehicle on a short road test. Check all vehicle systems for correct operation. Pay particular attention to:
 - Manual gear selection.
 - Gear selection/noise - high/low range.
 - Steering for abnormal noise/effort.
 - Steering for free play.
 - Engine noise
 - Gearbox noise or vibration
 - Suspension noise or irregularities
 - Body noise
 - Braking system operation
 - Engine performance
 - Excessive exhaust smoke.
 - All instruments, gauges and warning indicators.
 - Heater and air conditioning systems.
 - Fully extend seat belt, check operation of retraction and latching. Inertia belts lock when snatched or vehicle on slope.
 - Seat reclining and latching.
5. Check for correct operation of all instruments and warning devices where practical.
6. After road test, carry out a final inspection of the vehicle on vehicle ramps.
7. Check all underbonnet fluid levels and top-up if necessary.

General

1. Endorse Service Record.
2. Report any unusual features of vehicle condition and any additional work required.