

Roof Panel

Removal

- 1 . Disconnect both battery leads, negative lead first.
- 2 . Remove rear bench seats.
- 3 . Remove front, centre and rear sections of headlining.
- 4 . Remove all bolts securing roof.
- 5 . Carefully cut sealant securing front edge of roof to windshield aperture.

Installation

- 1 . Prepare and clean panel joint faces.



M772115

- 2 . Reverse removal procedure.