



AIR: Accumulator Isolation Relay
TSMS: Traction System Master Switch
EXT: External Latching Relays:
 AMS: Accumulator Management System
 IMD: Insulation Monitoring Device
 HV AUX: High Voltage Auxiliary connector in the Accumulator
 HVC: High Voltage Connector on the Accumulator (Main Current Path)
 LVC: Low Voltage Connector on the Accumulator
 HVD: High Voltage Disconnect
 BSPD: Brake Plausibility Device
INT: Internal Latching Relays:
 ESTOP: Emergency Stop Button (Left, Right, Center)
 CRASH: Crash Sensor
 GLVMS: Grounded Low Voltage Master Switch