

### **CHANGING DATE & TIME**

1. Press the "F" and "1" at the same time.
2. Enter the System Password.
3. Select System Settings
4. Select Date & Time Setup
5. Enter the correct Date/Time and press Enter.

### **TURNING ON/OFF BEEPER**

1. Press the "F" and "1" at the same time.
2. Enter the System Password.
3. Select Operation Settings.
4. Select Buzzer Setup
5. Select Key Tone
6. Select ON or OFF

### **MANUALLY CLOSING BATCH**

1. Press the "F" and "1" at the same time.
2. Enter the System Password.
3. Select Host Settings.
4. Select Batch Close

### **CHANGING BATCH NUMBER**

1. Press the "F" and "1" at the same time.
2. Enter the System Password.
3. Select System Settings.
4. Select Batch Number.
5. Enter the System Password.
6. Increase the Batch Number by 1.
7. Return to the Main Screen and try to batch out.

### **CHANGING IP ADDRESS**

1. Press the "F" and "1" at the same time.
2. Enter the System Password.
3. Scroll down to Communications.
4. Select LAN Parameters
5. Select LAN Type
6. Select Static
7. Select IP Address
8. Erase the current IP Address with the yellow key.
9. Enter the new IP Address and press Enter to save.

### REVIEW TRANSACTIONS

1. Press the "F" and "1" at the same time.
2. Enter the System Password.
3. Select Review Transactions.
4. Select either Credit, Debit, or EBT
5. Use the up and down arrows to review the previous/next transaction.

### PING TERMINAL

1. Press the "F" and "1" at the same time.
2. Enter the System Password.
3. Scroll down to Communications.
4. Select LAN Parameters
5. Scroll Down to Ping and press Enter
6. It will display [www.google.com](http://www.google.com), press Enter
7. If the terminal says "Ping OK" you're connected to the internet. If you receive any other message, please contact our support team.

### CHANGE COMMUNICATION TYPE/PORT/PROTOCOL

1. Press the "F" and "1" at the same time.
2. Enter the System Password.
3. Scroll down to Communications.
4. Select LAN Parameters.
5. Select ECR COMM Type.
6. Select your communication type: (Depends on your POS System)
7. Enter your communication port: (Depends on your POS System)
8. Select your protocol type: (Depends on your POS System)
9. Press Enter to save.