






Note 1: WARNING: Verify continuity to the AMI Relay Box#2 earthing point from; AP, Relay, battery casings, and the AMI Relay Box#2 metal enclosure
Note 2: WARNING: Before opening AMI Relay Box#2 disconnect mains supply and DAQ supply





Cable Mtg Plug
(pin view)



Cable Mtg Skt
(pin view)





Cable Mtg Plug
(both cable ends)
(pin view)

Battery Switching v4.5/5.0 – Further Development

Note 1: Pin 3 switching generates a battery message

Note 2: Pins 4,5, and 6 switching ends comms

Note 2: Further development – LED to indicate relay coil status

Reserved

DAQ Mod 2, Ch3	RL7	APv4.5 battery
----------------	-----	----------------

DAQ Mod 3, Ch1	RL9	APv5.0 battery
----------------	-----	----------------

DAQ Mod 3, Ch4	R12	RLv4.5 battery
----------------	-----	----------------

Battery Switch Box v5.0

TBD