

91-21-12

SPARE WIRE LIST

91-21-12
SPARE WIRE LIST

Section	Page	Date	Section	Page	Date	Section	Page	Date
EFFECTIVE PAGES			R AE0103A	1	Jun 21/2016	AE0303A cont.		
	1 thru 2	Jun 21/2016	R	2	Jun 21/2016	R	7	Jun 21/2016
R AB0237A	1	Jun 21/2016	R AE0104A	1	Jun 21/2016	R	8	Jun 21/2016
R AB0340A	1	Jun 21/2016	R	2	Jun 21/2016	R AE0401A	1	Jun 21/2016
R	2	Jun 21/2016	R	3	Jun 21/2016	R	2	Jun 21/2016
R AB0340B	1	Jun 21/2016	R AE0105A	1	Jun 21/2016	R	3	Jun 21/2016
R AB0405B	1	Jun 21/2016	R AE0201A	1	Jun 21/2016	R	4	Jun 21/2016
R AB0420A	1	Jun 21/2016	R AE0202A	1	Jun 21/2016	R	5	Jun 21/2016
R AB0500DL	1	Jun 21/2016	R	2	Jun 21/2016	R AE0401D	1	Jun 21/2016
R AB0536L	1	Jun 21/2016	R AE0301A	1	Jun 21/2016	R AE0402A	1	Jun 21/2016
R AB1030A	1	Jun 21/2016	R	2	Jun 21/2016	R AE0502A	1	Jun 21/2016
R AB1050L	1	Jun 21/2016	R	3	Jun 21/2016	R	2	Jun 21/2016
R	2	Jun 21/2016	R	4	Jun 21/2016	R	3	Jun 21/2016
R AB1050R	1	Jun 21/2016	R	5	Jun 21/2016	R	4	Jun 21/2016
R AB1080	1	Jun 21/2016	R	6	Jun 21/2016		5	Dec 10/2015
AC0235A	1	Mar 14/2016	R	7	Jun 21/2016	R	6	Jun 21/2016
R AC0520	1	Jun 21/2016	R AE0302A	1	Jun 21/2016	R	7	Jun 21/2016
R	2	Jun 21/2016	R	2	Jun 21/2016	R AE0602A	1	Jun 21/2016
R AD0520	1	Jun 21/2016	R	3	Jun 21/2016	R AJ0020B	1	Jun 21/2016
R	2	Jun 21/2016	R	4	Jun 21/2016	R AJ0022	1	Jun 21/2016
R AE0101A	1	Jun 21/2016	R	5	Jun 21/2016	R AJ0024	1	Jun 21/2016
R	2	Jun 21/2016	R	6	Jun 21/2016	R AJ0046A	1	Jun 21/2016
R	3	Jun 21/2016	R AE0303A	1	Jun 21/2016	R AJ0046B	1	Jun 21/2016
R	4	Jun 21/2016	R	2	Jun 21/2016	R AJ0048A	1	Jun 21/2016
R AE0101B	1	Jun 21/2016	R	3	Jun 21/2016	R	2	Jun 21/2016
R	2	Jun 21/2016	R	4	Jun 21/2016	R AP0600A	1	Jun 21/2016
R AE0102A	1	Jun 21/2016	R	5	Jun 21/2016	R AP0600B	1	Jun 21/2016
R	2	Jun 21/2016	R	6	Jun 21/2016	R	2	Jun 21/2016

A = Added, R = Revised, D = Deleted, O = Overflow

SPARE WIRE LIST

D280A351

EFFECTIVE PAGES

Page 1
Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

91-21-12 SPARE WIRE LIST

Section	Page	Date	Section	Page	Date	Section	Page	Date
AP0600B cont.			R D40751P	1	Jun 21/2016	R P005-28	1	Jun 21/2016
R	3	Jun 21/2016	R D41066P	1	Jun 21/2016	R P008-25	1	Jun 21/2016
R	4	Jun 21/2016	R D41074J	1	Jun 21/2016	R P008-26	1	Jun 21/2016
R AP0900A	1	Jun 21/2016	R D41078J	1	Jun 21/2016	R P0091	1	Jun 21/2016
R	2	Jun 21/2016	R D41082P	1	Jun 21/2016	R P0092	1	Jun 21/2016
R	3	Jun 21/2016	R D41088J	1	Jun 21/2016	R P091-00	1	Jun 21/2016
R	4	Jun 21/2016	R DISC BRKT	1	Jun 21/2016	R UNK	1	Jun 21/2016
R AP1800A	1	Jun 21/2016	R DM0017	1	Jun 21/2016	R	2	Jun 21/2016
R AP1800B	1	Jun 21/2016	R DM0035	1	Jun 21/2016			
R	2	Jun 21/2016	R L01086	1	Jun 21/2016			
R	3	Jun 21/2016	R L01223	1	Jun 21/2016			
R AS0001L	1	Jun 21/2016	R M00276	1	Jun 21/2016			
R	2	Jun 21/2016	R M00414	1	Jun 21/2016			
R AS0001R	1	Jun 21/2016	R M00943	1	Jun 21/2016			
R	2	Jun 21/2016	R M01020	1	Jun 21/2016			
R AS0002L	1	Jun 21/2016	R M01022	1	Jun 21/2016			
R AS0002R	1	Jun 21/2016	R M01415	1	Jun 21/2016			
R AS0003L	1	Jun 21/2016	R M01418	1	Jun 21/2016			
R AS0003R	1	Jun 21/2016	R M01672	1	Jun 21/2016			
R AW0258L	1	Jun 21/2016	R M01673	1	Jun 21/2016			
R	2	Jun 21/2016	R M02061	1	Jun 21/2016			
R AW0258R	1	Jun 21/2016	R M02195	1	Jun 21/2016			
R	2	Jun 21/2016	R M02566	1	Jun 21/2016			
R D13832	1	Jun 21/2016	R M02816	1	Jun 21/2016			
R D40026P	1	Jun 21/2016	R N00226	1	Jun 21/2016			
R D40116J	1	Jun 21/2016	R OVHD DISC	1	Jun 21/2016			
R D40270J	1	Jun 21/2016	R P003-01	1	Jun 21/2016			
R D40272J	1	Jun 21/2016	R P003-07	1	Jun 21/2016			

A = Added, R = Revised, D = Deleted, O = Overflow

SPARE WIRE LIST

D280A351

EFFECTIVE PAGES

Page 2
Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From	Matewith	Pos	Bundle	Sep	Description		To			Pos	Effectivity	
	Equip		Term	Type	Wire No.	GA	TY	Equip	Term	Type			Matewith
I	AB0237A		03	W2705	NA2	DISCONNECT BRACKET							
I	D00803		19		0023	24	PK	D00403	A08		AE0401D	03	ALL
I	D00803		18		2046B	24	Y2	D00403	B07		AE0401D	03	ALL
I	D00803		17		2046R	24	Y2	D00403	A07		AE0401D	03	ALL
I	D00803	PERB			2046Z			D00403	PERG	1F	AE0401D	03	ALL

SPARE WIRE LIST

D280A351

91-21-12

Section AB0237A

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From Matewith	Pos	Bundle	Sep	Description		To	Term	Type	Matewith	Pos	Effectivity
	Equip	Term	Type	Wire No.	GA	TY	Equip					
I	AB0340A	01	W3058	RN2	DISCONNECT BRACKET-LEFT							
I	D40054J	5		0284	20	PA	D14376	CAP	Y	M01418		YT101-YT131
I	D40054J	6		0285	20	PA	D14376	CAP	Y	M01418		YT101-YT131
I	D40054J	8		0286	20	PA	D14376	CAP	Y	M01418		YT101-YT131
I	AB0340A	01	W5142	LN1*	DISCONNECT BRACKET-LEFT							
I	D40054P	5		0054	20	PA	D11416	CAP	Y	P091-00		ALL
I	D40054P	6		0055	20	PA	D11416	CAP	Y	P091-00		ALL
I	D40054P	8		0056	20	PA	D11416	CAP	Y	P091-00		ALL
I	AB0340A	02	W3144	LN2*	DISCONNECT BRACKET-LEFT							
I	D40216P	7		0021	16	PA	D40220P	21		AP1800A	06	ALL
I	AB0340A	02	W3158	LN1*	DISCONNECT BRACKET-LEFT							
I	D40216J	4		0101	20	PA	D40108J	1		AB0340A	06	ALL
I	D40216J	5		0102	20	PA	D40108J	2		AB0340A	06	ALL
I	AB0340A	03	W3142	LN2	DISCONNECT BRACKET-LEFT							
I	D40196J	8		0038	20	PA	D10746	CAP	Y	M01673		ALL
I	D40196J	CAP	Y	0039	20	PA	D10746	CAP	Y	M01673		ALL
I	AB0340A	04	W3058	RN2	DISCONNECT BRACKET-LEFT							
I	D40170J	18		0387	20	PA	D14372	CAP	Y	M01418		YT101-YT131
I	D40170J	19		0388	20	PA	D14372	CAP	Y	M01418		YT101-YT131
I	D40170J	31		0389	20	PA	D14372	CAP	Y	M01418		YT101-YT131
I	AB0340A	05	W3058	RN2	DISCONNECT BRACKET-LEFT							
I	D40050J	8		0381	20	PA	D40226P	8		AP0600A	05	YT101-YT131
I	D40050J	9		0382	20	PA	D40226P	9		AP0600A	05	YT101-YT131
I	D40050J	11		0383	20	PA	D40226P	12		AP0600A	05	YT101-YT131
I	AB0340A	05	W6242	RN1	DISCONNECT BRACKET-LEFT							
I	D40050P	8		0059	20	PA	D11452	CAP	Y	P0092		ALL
I	D40050P	9		0060	20	PA	D11452	CAP	Y	P0092		ALL
I	AB0340A	06	W3158	LN1*	DISCONNECT BRACKET-LEFT							
I	D40108J	1		0101	20	PA	D40216J	4		AB0340A	02	ALL

SPARE WIRE LIST

D280A351

91-21-12

Section AB0340A

Page 1

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

From	Matewith	Pos	Bundle	Sep	Description		To					
Equip	Term	Type	Wire No.		GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity
AB0340A	06	W3158	LN1*	DISCONNECT BRACKET-LEFT (continued)								
D40108J	2		0102		20	PA	D40216J	5		AB0340A	02	ALL
D40108J	11		0111		20	PA	D40116P	1		D40116J		ALL
D40108J	12		0112		20	PA	D40116P	3		D40116J		ALL

SPARE WIRE LIST

D280A351

91-21-12

Section AB0340A

Page 2 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From	Matewith	Pos	Bundle	Sep	Description							Pos	Effectivity	
	Equip		Term	Type	Wire No.	GA	TY	To	Equip	Term	Type	Matewith			
I	AB0340B		07	W4142	LB2*	DISCONNECT BRACKET-RIGHT									
I	D40296J		4		0036	20	PA	D14812	CAP	Y	M02816		ALL		
I	D40296J		7		0037	20	PA	D10744	CAP	Y	M01672		ALL		
I	D40296J		15		0038	20	PA	D14812	CAP	Y	M02816		ALL		
I	D40296J		CAP	Y	0039	20	PA	D10744	CAP	Y	M01672		ALL		

SPARE WIRE LIST

D280A351

91-21-12

Section AB0340B

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From Matewith	Pos	Bundle	Sep	Description		To					Pos	Effectivity	
	From Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith				
I	AB0405B	01	W4170	RA2*	DISCONNECT BRACKET									
I	D40728P	6		2609B	20	PB	D40732P	A10		AE0301A	36	ALL		
I	D40728P	7		2609R	20	PB	D40732P	B10		AE0301A	36	ALL		
I	AB0405B	01	W6170	RA2*	DISCONNECT BRACKET									
I	D40728J	6		2603B	20	PB	D39926	10		AD0520		ALL		
I	D40728J	7		2603R	20	PB	D39926	2		AD0520		ALL		
I	D40728J	8		2604B	20	PB	D39926	11		AD0520		ALL		
I	D40728J	9		2604R	20	PB	D39926	24		AD0520		ALL		
I	D40728J	15		2605B	20	PB	D39926	15		AD0520		ALL		
I	D40728J	16		2605R	20	PB	D39926	16		AD0520		ALL		
I	AB0405B	02	W4170	RA2*	DISCONNECT BRACKET									
I	D40730P	9		2605B	20	PB	D40732P	A05		AE0301A	36	ALL		
I	D40730P	10		2605R	20	PB	D40732P	B05		AE0301A	36	ALL		
I	D40730P	11		2606B	20	PB	D40732P	A06		AE0301A	36	ALL		
I	D40730P	12		2606R	20	PB	D40732P	B06		AE0301A	36	ALL		
I	AB0405B	02	W6172	RA2*	DISCONNECT BRACKET									
I	D40730J	9		2612B	20	PB	D39918	12		AD0520		ALL		
I	D40730J	10		2612R	20	PB	D39918	3		AD0520		ALL		
I	D40730J	11		2613B	20	PB	D39918	14		AD0520		ALL		
I	D40730J	12		2613R	20	PB	D39918	32		AD0520		ALL		

SPARE WIRE LIST

D280A351

91-21-12

Section AB0405B

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From Matewith	Pos	Bundle	Sep	Description		To				Pos	Effectivity
	From Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith		
I	AB0420A	01	W3170	LA2*	DISCONNECT BRACKET							
I	D40734P	1		2601B	20	PB	D40126P	A01		AE0202A	27	ALL
I	D40734P	2		2601R	20	PB	D40126P	B01		AE0202A	27	ALL
I	D40734P	3		2602B	20	PB	D40126P	A02		AE0202A	27	ALL
I	D40734P	4		2602R	20	PB	D40126P	B02		AE0202A	27	ALL
I	D40734P	5		2603B	20	PB	D40126P	A03		AE0202A	27	ALL
I	D40734P	6		2603R	20	PB	D40126P	B03		AE0202A	27	ALL
I	AB0420A	01	W5170	SA2*	DISCONNECT BRACKET							
I	D40734J	1		2601B	20	PB	D39925	10		AC0520		ALL
I	D40734J	2		2601R	20	PB	D39925	2		AC0520		ALL
I	D40734J	3		2602B	20	PB	D39925	11		AC0520		ALL
I	D40734J	4		2602R	20	PB	D39925	24		AC0520		ALL
I	D40734J	5		2603B	20	PB	D39925	15		AC0520		ALL
I	D40734J	6		2603R	20	PB	D39925	16		AC0520		ALL
I	AB0420A	02	W3170	LA2*	DISCONNECT BRACKET							
I	D40736P	1		2606B	20	X2	D49994P	A07		AE0301A	14	ALL
I	D40736P	2		2606R	20	X2	D49994P	B06		AE0301A	14	ALL
I	D40736P	S/R		2606Z			D49994P	PERG	1F	AE0301A	14	ALL
I	D40736P	4		2607B	20	X2	D40126P	A11		AE0202A	27	ALL
I	D40736P	5		2607R	20	X2	D40126P	B11		AE0202A	27	ALL
I	D40736P	S/R		2607Z			D40126P	PERG	1F	AE0202A	27	ALL
I	AB0420A	02	W5172	LA2*	DISCONNECT BRACKET							
I	D40736J	1		2604B	20	X2	D39917	12		AC0520		ALL
I	D40736J	2		2604R	20	X2	D39917	3		AC0520		ALL
I	D40736J	S/R		2604Z			D39917	S/R		AC0520		ALL
I	D40736J	4		2605B	20	X2	D39917	14		AC0520		ALL
I	D40736J	5		2605R	20	X2	D39917	32		AC0520		ALL
I	D40736J	S/R		2605Z			D39917	S/R		AC0520		ALL

SPARE WIRE LIST

D280A351

91-21-12

Section AB0420A

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From	Matewith	Pos	Bundle	Sep	Description		To				Pos	Effectivity
	Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith			
I	AB0500DL		05	W5248	LN2*	DISCONNECT BRACKET-LEFT WING							
I	D40500J		1		0499	20	PA	D40584P	A01		AE0402A	02	ALL
I	D40500J		3		0500	20	PA	D40584P	B01		AE0402A	02	ALL
I	AB0500DL		05	W6248	LN2*	DISCONNECT BRACKET-LEFT WING							
I	D40500P		1		0499	20	PA	D00866	CAP	Y	M00276		ALL
I	D40500P		3		0500	20	PA	D00866	CAP	Y	M00276		ALL
I	AB0500DL		09	W5526	SA2	DISCONNECT BRACKET-LEFT WING							
I	D40302J		10		5516	20	PA	D43016J	9		AE0104A	22	ALL
I	D40302J		11		5517	20	PA	D43016J	10		AE0104A	22	ALL

SPARE WIRE LIST

D280A351

91-21-12

Section AB0500DL

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From	Matewith	Pos	Bundle	Sep	Description		To	Term	Type	Matewith	Pos	Effectivity
	Equip	Term	Type	Wire No.	GA	TY	Equip						
I	AB0536L		01	W5526	SA2	DISCONNECT BRACKET-LEFT AC BAY							
I	D04580P		12		5512	20	PA	D43016J	7		AE0104A	22	ALL
I	D04580P		13		5513	20	PA	D43016J	8		AE0104A	22	ALL
I	AB0536L		02	W5104	LA2	DISCONNECT BRACKET-LEFT AC BAY							
I	D40056P		18		5520	20	PA	D40244P	B05		AE0401A	29	ALL
I	D40056P		19		5521	20	PA	D40244P	CAP	Y	AE0401A	29	ALL
I	D40056P		16		5522	20	PA	D40246P	A08		AE0202A	01	ALL

SPARE WIRE LIST

D280A351

91-21-12

Section AB0536L

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From	Matewith	Pos	Bundle	Sep	Description		To					Pos	Effectivity	
	Equip		Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith				
I	AB1030A		01	W3555	RN2	DISCONNECT BRACKET-AFT PRESSURE BLKHD.									
I	D04245J		9		0009	20	PA	D40125P	B02		AE0602A	11	ALL		
I	D04245J		10		0010	20	PA	D40125P	A03		AE0602A	11	ALL		
I	AB1030A		03	W3553	LN2	DISCONNECT BRACKET-AFT PRESSURE BLKHD.									
I	D04227J		9		0009	20	PA	D40121P	B02		AE0602A	12	ALL		
I	D04227J		10		0010	20	PA	D40121P	A03		AE0602A	12	ALL		

SPARE WIRE LIST

D280A351

91-21-12

Section AB1030A

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From Matewith	Pos	Bundle	Sep	Description		To					Effectivity	
	Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos		
I	AB1050L	02	W3393	LG2	DISCONNECT BRACKET-SEC 48 L								
I	D43393J	15		1015	20	VF	D00545	15		M00414		ALL	
I	D43393J	S/R		1015Z			GD04809	ST..	E			ALL	
I	D43393J	17		1017	20	VF	D00545	17		M00414		ALL	
I	D43393J	S/R		1017Z			GD04809	ST..	E			ALL	
I	D43393J	19		1019	20	VF	D00545	19		M00414		ALL	
I	D43393J	S/R		1019Z			GD04809	ST..	E			ALL	
I	D43393J	21		1021	20	VF	D00545	21		M00414		ALL	
I	D43393J	S/R		1021Z			D00545	S/R		M00414		ALL	
I	AB1050L	02	W5301	LG2	DISCONNECT BRACKET-SEC 48 L								
I	D43393P	15		0015	22	PA	D04425P	A05		AE0101A	08	ALL	
I	D43393P	17		0017	22	PA	D04425P	A07		AE0101A	08	ALL	
I	D43393P	19		0019	22	PA	D04425P	A09		AE0101A	08	ALL	
I	D43393P	21		0021	22	PA	D04425P	B01		AE0101A	08	ALL	
I	D43393P	10		2007B	22	PB	D04425P	B10		AE0101A	08	ALL	
I	D43393P	9		2007R	22	PB	D04425P	B09		AE0101A	08	ALL	
I	AB1050L	03	W3377	LA3	DISCONNECT BRACKET-SEC 48 L								
I	D43397P	46		0010	20	PA	D04079P	B01		AE0101A	32	ALL	
I	D43397P	41		3006B	22	PC	D04079P	B08		AE0101A	32	ALL	
I	D43397P	40		3006R	22	PC	D04079P	B07		AE0101A	32	ALL	
I	D43397P	42		3006Y	22	PC	D04079P	B09		AE0101A	32	ALL	
I	AB1050L	03	W3397	LA3	DISCONNECT BRACKET-SEC 48 L								
I	D43397J	41		3006B	22	HG	D01681	REF	VP	M01020		ALL	
I	D43397J	40		3006R	22	HG	D01681	REF	VP	M01020		ALL	
I	D43397J	42		3006Y	22	HG	D01681	REF	VP	M01020		ALL	
I	D43397J	S/R		3006Z			GD00949	ST..	E			ALL	
I	AB1050L	04	W3381	LE2	DISCONNECT BRACKET-SEC 48 L								
I	D44381P	1		0006	20	PA	D04083P	A02		AE0101A	26	ALL	
I	D44381P	2		0007	20	PA	D04083P	A07		AE0101A	26	ALL	
I	AB1050L	05	W5381	LE2	DISCONNECT BRACKET-SEC 48 L								
I	D45501J	13		2008B	22	VG	D45551P	B02		AE0101A	36	ALL	
I	D45501J	4		2008R	22	VG	D45551P	A02		AE0101A	36	ALL	
I	D45501J	S/R		2008Z			D45551P	PERG	1F	AE0101A	36	ALL	

SPARE WIRE LIST

D280A351

91-21-12

Section AB1050L

Page 1

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

From	Matewith	Pos	Bundle	Sep	Description		To					
Equip	Term	Type	Wire No.		GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity
AB1050L	05	W5381	LE2	DISCONNECT BRACKET-SEC 48 L (continued)								
D45501J	10		2009B		20	HF	D45551P	B09		AE0101A	36	ALL
D45501J	2		2009R		20	HF	D45551P	A09		AE0101A	36	ALL
D45501J	S/R		2009Z				D45551P	PERG	1F	AE0101A	36	ALL

SPARE WIRE LIST

D280A351

91-21-12

Section AB1050L

Page 2 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

From	Matewith	Pos	Bundle	Sep	Description		To	Term	Type	Matewith	Pos	Effectivity
Equip		Term	Type	Wire No.	GA	TY	Equip					
I	AB1050R	04	W3379	RB3	DISCONNECT BRACKET-SEC 48 R							
I	D43399P	2		0002	20	CQ	D40029P	A09		AE0302A	35	ALL
I	D43399P	50		0022	20	CQ	D04081J	3		AE0104A	03	ALL
I	D43399P	37		2010B	22	X2	D40029P	B02		AE0302A	35	ALL
I	D43399P	36		2010R	22	X2	D40029P	B01		AE0302A	35	ALL
I	D43399P	S/R		2010Z			D40029P	PERG	1F	AE0302A	35	ALL
I	D43399P	41		3006B	22	PC	D04081J	28		AE0104A	03	ALL
I	D43399P	40		3006R	22	PC	D04081J	27		AE0104A	03	ALL
I	D43399P	42		3006Y	22	PC	D04081J	29		AE0104A	03	ALL
I	D43399P	44		3007B	22	X3	D40029P	B09		AE0302A	35	ALL
I	D43399P	43		3007R	22	X3	D40029P	B08		AE0302A	35	ALL
I	D43399P	45		3007Y	22	X3	D40029P	B10		AE0302A	35	ALL
I	D43399P	S/R		3007Z			D40029P	PERG	1F	AE0302A	35	ALL
I	AB1050R	06	W5383	RF2	DISCONNECT BRACKET-SEC 48 R							
I	D45503J	13		2008B	22	VG	D45553J	13		AE0104A	13	ALL
I	D45503J	4		2008R	22	VG	D45553J	4		AE0104A	13	ALL
I	D45503J	S/R		2008Z			D45553J	S/R		AE0104A	13	ALL
I	D45503J	10		2009B	20	HF	D45553J	10		AE0104A	13	ALL
I	D45503J	2		2009R	20	HF	D45553J	2		AE0104A	13	ALL
I	D45503J	S/R		2009Z			D45553J	S/R		AE0104A	13	ALL

SPARE WIRE LIST

D280A351

91-21-12

Section AB1050R

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From Matewith	Pos	Bundle	Sep	Description		To	Term	Type	Matewith	Pos	Effectivity
	From Equip	Term	Type	Wire No.	GA	TY	Equip					
I	AB1080	03	W3399	RB3	DISCONNECT BRACKET-STA 1080							
I	D43389J	11		3006B	22	HG	D01687	REF	VP	M01022		ALL
I	D43389J	10		3006R	22	HG	D01687	REF	VP	M01022		ALL
I	D43389J	12		3006Y	22	HG	D01687	REF	VP	M01022		ALL
I	D43389J	S/R		3006Z			GD00973	ST..	E			ALL

SPARE WIRE LIST

D280A351

91-21-12

Section AB1080

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description							
Equip	Term	Type	Wire No.	GA	TY	To Equip	Term	Type	Matewith	Pos	Effectivity
AC0235A	02	W2104	LA1	DISCONNECT BRACKET - EFB CLASS 2							
D31018J	A10		0612	20	PA	D48100P	A10		AJ0048A	01	YT101-YT120
D31018J	B10		0613	20	PA	D48100P	B10		AJ0048A	01	YT101-YT120

SPARE WIRE LIST

D280A351

91-21-12

Section AC0235A

Page 1 End

Mar 14/2016



737-800 WIRING DIAGRAM MANUAL

	From	Pos	Bundle	Sep	Description		To					Effectivity	
	Matewith Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos		
I	AC0520		W1178	LN2	DISCONNECT BRACKET								
I	D39927	11		2001B	20	HQ	D08056J	13		AW0258L	06	ALL	
I	D39927	24		2001R	20	HQ	D08056J	12		AW0258L	06	ALL	
I	D39927	S/R		2001Z			D08056J	S/R		AW0258L	06	ALL	
I	D39927	10		2002B	20	HQ	D08056J	10		AW0258L	06	ALL	
I	D39927	2		2002R	20	HQ	D08056J	2		AW0258L	06	ALL	
I	D39927	S/R		2002Z			D08056J	S/R		AW0258L	06	ALL	
I	D39927	15		2003B	20	HQ	D08056J	14		AW0258L	06	ALL	
I	D39927	16		2003R	20	HQ	D08056J	4		AW0258L	06	ALL	
I	D39927	S/R		2003Z			D08056J	S/R		AW0258L	06	ALL	
I	AC0520		W1182	SB2	DISCONNECT BRACKET								
I	D39931	2		2001B	20	HQ	D30062	16		AW0258L	05	ALL	
I	D39931	3		2001R	20	HQ	D30062	15		AW0258L	05	ALL	
I	D39931	S/R		2001Z			D30062	S/R		AW0258L	05	ALL	
I	D39931	4		2002B	20	HQ	D30062	18		AW0258L	05	ALL	
I	D39931	5		2002R	20	HQ	D30062	17		AW0258L	05	ALL	
I	D39931	S/R		2002Z			D30062	S/R		AW0258L	05	ALL	
I	AC0520		W1184	SA1	DISCONNECT BRACKET								
I	D39911	6		2004B	20	HQ	D30014	37		AW0258L	04	ALL	
I	D39911	5		2004R	20	HQ	D30014	36		AW0258L	04	ALL	
I	D39911	S/R		2004Z			D30014	S/R		AW0258L	04	ALL	
I	AC0520		W5162	LB2*	DISCONNECT BRACKET								
I	D39921	14		2601B	20	X2	D40130P	A03		AE0202A	25	ALL	
I	D39921	5		2601R	20	X2	D40130P	B03		AE0202A	25	ALL	
I	D39921	S/R		2601Z			D40130P	PERG	1F	AE0202A	25	ALL	
I	D39921	31		2609B	20	X2	D40130P	A09		AE0202A	25	ALL	
I	D39921	30		2609R	20	X2	D40130P	B09		AE0202A	25	ALL	
I	D39921	S/R		2609Z			D40130P	PERG	1F	AE0202A	25	ALL	
I	AC0520		W5164	LA1*	DISCONNECT BRACKET								
I	D39933	26		2602B	20	X2	D40718P	A05		AE0201A	17	ALL	
I	D39933	25		2602R	20	X2	D40718P	B05		AE0201A	17	ALL	
I	D39933	S/R		2602Z			D40718P	PERG	1F	AE0201A	17	ALL	

SPARE WIRE LIST

D280A351

91-21-12

Section AC0520

Page 1

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From Matewith	Pos	Bundle	Sep	Description		To					Pos	Effectivity	
	Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith				
I	AC0520		W5168	SB2*	DISCONNECT BRACKET									
I	D39929	2		2601B	20	X2	D40138P	A02		AE0202A	08	ALL		
I	D39929	3		2601R	20	X2	D40138P	B02		AE0202A	08	ALL		
I	D39929	S/R		2601Z			D40138P	PERG	1F	AE0202A	08	ALL		
I	D39929	4		2602B	20	X2	D40138P	A03		AE0202A	08	ALL		
I	D39929	5		2602R	20	X2	D40138P	B03		AE0202A	08	ALL		
I	D39929	S/R		2602Z			D40138P	PERG	1F	AE0202A	08	ALL		
I	AC0520		W5170	SA2*	DISCONNECT BRACKET									
I	D39925	10		2601B	20	PB	D40734J	1		AB0420A	01	ALL		
I	D39925	2		2601R	20	PB	D40734J	2		AB0420A	01	ALL		
I	D39925	11		2602B	20	PB	D40734J	3		AB0420A	01	ALL		
I	D39925	24		2602R	20	PB	D40734J	4		AB0420A	01	ALL		
I	D39925	15		2603B	20	PB	D40734J	5		AB0420A	01	ALL		
I	D39925	16		2603R	20	PB	D40734J	6		AB0420A	01	ALL		
I	AC0520		W5172	LA2*	DISCONNECT BRACKET									
I	D39917	12		2604B	20	X2	D40736J	1		AB0420A	02	ALL		
I	D39917	3		2604R	20	X2	D40736J	2		AB0420A	02	ALL		
I	D39917	S/R		2604Z			D40736J	S/R		AB0420A	02	ALL		
I	D39917	14		2605B	20	X2	D40736J	4		AB0420A	02	ALL		
I	D39917	32		2605R	20	X2	D40736J	5		AB0420A	02	ALL		
I	D39917	S/R		2605Z			D40736J	S/R		AB0420A	02	ALL		
I	AC0520		W5564	SN2*	DISCONNECT BRACKET									
I	D39909	6		2601B	20	X2	D40136P	A01		AE0202A	07	ALL		
I	D39909	5		2601R	20	X2	D40136P	B01		AE0202A	07	ALL		
I	D39909	S/R		2601Z			D40136P	PERG	1F	AE0202A	07	ALL		

SPARE WIRE LIST

D280A351

91-21-12

Section AC0520

Page 2 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From Matewith	Pos	Bundle	Sep	Description		To	Term	Type	Matewith	Pos	Effectivity
	Equip	Term	Type	Wire No.	GA	TY	Equip					
I	AD0520		W1278	RN2	DISCONNECT BRACKET							
I	D39928	11		2001B	20	HQ	D08156J	13		AW0258R	06	ALL
I	D39928	24		2001R	20	HQ	D08156J	12		AW0258R	06	ALL
I	D39928	S/R		2001Z			D08156J	S/R		AW0258R	06	ALL
I	D39928	10		2002B	20	HQ	D08156J	10		AW0258R	06	ALL
I	D39928	2		2002R	20	HQ	D08156J	2		AW0258R	06	ALL
I	D39928	S/R		2002Z			D08156J	S/R		AW0258R	06	ALL
I	D39928	15		2003B	20	HQ	D08156J	14		AW0258R	06	ALL
I	D39928	16		2003R	20	HQ	D08156J	4		AW0258R	06	ALL
I	D39928	S/R		2003Z			D08156J	S/R		AW0258R	06	ALL
I	AD0520		W1282	SB2*	DISCONNECT BRACKET							
I	D39932	2		2001B	20	HQ	D30162	16		AW0258R	05	ALL
I	D39932	3		2001R	20	HQ	D30162	15		AW0258R	05	ALL
I	D39932	S/R		2001Z			D30162	S/R		AW0258R	05	ALL
I	D39932	4		2002B	20	HQ	D30162	18		AW0258R	05	ALL
I	D39932	5		2002R	20	HQ	D30162	17		AW0258R	05	ALL
I	D39932	S/R		2002Z			D30162	S/R		AW0258R	05	ALL
I	AD0520		W1284	SN1	DISCONNECT BRACKET							
I	D39912	6		2004B	20	HQ	D30114	37		AW0258R	04	ALL
I	D39912	5		2004R	20	HQ	D30114	36		AW0258R	04	ALL
I	D39912	S/R		2004Z			D30114	S/R		AW0258R	04	ALL
I	D39936	26		2001B	20	HQ	D30114	30		AW0258R	04	ALL
I	D39936	25		2001R	20	HQ	D30114	32		AW0258R	04	ALL
I	D39936	S/R		2001Z			D30114	S/R		AW0258R	04	ALL
I	AD0520		W6162	RB2*	DISCONNECT BRACKET							
I	D39922	14		2611B	20	PB	D40156P	A14		AE0401A	50	ALL
I	D39922	5		2611R	20	PB	D40156P	B14		AE0401A	50	ALL
I	D39922	31		2612B	20	PB	D40156P	A15		AE0401A	50	ALL
I	D39922	30		2612R	20	PB	D40156P	B15		AE0401A	50	ALL
I	AD0520		W6164	RB1*	DISCONNECT BRACKET							
I	D39934	26		2602B	20	PB	D40720P	A09		AE0402A	27	ALL
I	D39934	25		2602R	20	PB	D40720P	B09		AE0402A	27	ALL

SPARE WIRE LIST

D280A351

91-21-12

Section AD0520

Page 1

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From Matewith	Pos	Bundle	Sep	Description		To					Pos	Effectivity	
	From Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith				
I	AD0520		W6168	SB2*	DISCONNECT BRACKET									
I	D39930	2		2601B	20	VG	D40144P	A01		AE0401A	38	ALL		
I	D39930	3		2601R	20	VG	D40144P	B01		AE0401A	38	ALL		
I	D39930	S/R		2601Z			D40144P	PERG	1F	AE0401A	38	ALL		
I	D39930	4		2602B	20	VG	D40144P	A02		AE0401A	38	ALL		
I	D39930	5		2602R	20	VG	D40144P	B02		AE0401A	38	ALL		
I	D39930	S/R		2602Z			D40144P	PERG	1F	AE0401A	38	ALL		
I	AD0520		W6170	RA2*	DISCONNECT BRACKET									
I	D39926	10		2603B	20	PB	D40728J	6		AB0405B	01	ALL		
I	D39926	2		2603R	20	PB	D40728J	7		AB0405B	01	ALL		
I	D39926	11		2604B	20	PB	D40728J	8		AB0405B	01	ALL		
I	D39926	24		2604R	20	PB	D40728J	9		AB0405B	01	ALL		
I	D39926	15		2605B	20	PB	D40728J	15		AB0405B	01	ALL		
I	D39926	16		2605R	20	PB	D40728J	16		AB0405B	01	ALL		
I	AD0520		W6172	RA2*	DISCONNECT BRACKET									
I	D39918	12		2612B	20	PB	D40730J	9		AB0405B	02	ALL		
I	D39918	3		2612R	20	PB	D40730J	10		AB0405B	02	ALL		
I	D39918	14		2613B	20	PB	D40730J	11		AB0405B	02	ALL		
I	D39918	32		2613R	20	PB	D40730J	12		AB0405B	02	ALL		
I	AD0520		W6564	SN2*	DISCONNECT BRACKET									
I	D39910	6		2601B	20	VG	D40158P	A02		AE0401A	42	ALL		
I	D39910	5		2601R	20	VG	D40158P	B02		AE0401A	42	ALL		
I	D39910	S/R		2601Z			D40158P	PERG	1F	AE0401A	42	ALL		

SPARE WIRE LIST

D280A351

91-21-12

Section AD0520

Page 2 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From Matewith	Pos	Bundle	Sep	Description		To					Pos	Effectivity
	Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith			
I	AE0101A	03	W5111	NA2	DISCONNECT BRACKET - E1-1 SHELF								
I	D45133P	B06		2047B	24	Y2	D45131P	B03		AE0301A	08	ALL	
I	D45133P	A06		2047R	24	Y2	D45131P	A03		AE0301A	08	ALL	
I	D45133P	PERG	1F	2047Z			D45131P	PERG	1F	AE0301A	08	ALL	
I	AE0101A	04	W5161	LA2	DISCONNECT BRACKET - E1-1 SHELF								
I	D41145P	A04		0035	24	PK	D43145P	B01		AE0301A	15	ALL	
I	D41145P	A03		2511B	22	X2	D43155P	B16		AE0301A	16	ALL	
I	D41145P	A02		2511R	22	X2	D43155P	B15		AE0301A	16	ALL	
I	D41145P	PERG	1F	2511Z			D43155P	PERG	1F	AE0301A	16	ALL	
I	AE0101A	06	W5461	LA2	DISCONNECT BRACKET - E1-1 SHELF								
I	D42311P	A10		2103B	24	Y2	D42261P	B12		AE0302A	41	ALL	
I	D42311P	A09		2103R	24	Y2	D42261P	B11		AE0302A	41	ALL	
I	D42311P	PERG	1F	2103Z			D42261P	PERG	1F	AE0302A	41	ALL	
I	AE0101A	08	W5301	LG2	DISCONNECT BRACKET - E1-1 SHELF								
I	D04425P	A05		0015	22	PA	D43393P	15		AB1050L	02	ALL	
I	D04425P	A07		0017	22	PA	D43393P	17		AB1050L	02	ALL	
I	D04425P	A09		0019	22	PA	D43393P	19		AB1050L	02	ALL	
I	D04425P	B01		0021	22	PA	D43393P	21		AB1050L	02	ALL	
I	D04425P	B10		2007B	22	PB	D43393P	10		AB1050L	02	ALL	
I	D04425P	B09		2007R	22	PB	D43393P	9		AB1050L	02	ALL	
I	AE0101A	12	W6110	LA2*	DISCONNECT BRACKET - E1-1 SHELF								
I	D40364P	B05		0011	20	PA	D11418	CAP	Y	P0091		ALL	
I	D40364P	B06		0012	20	PA	D11418	CAP	Y	P0091		ALL	
I	D40364P	A06		0013	20	PA	D11418	CAP	Y	P0091		ALL	
I	D40364P	A04		0520	22	PA	D40368P	5		AP0600B	09	ALL	
I	D40364P	B03		0521	22	PA	D40368P	6		AP0600B	09	ALL	
I	AE0101A	13	W2101	LA2	DISCONNECT BRACKET - E1-1 SHELF								
I	D41811P	A01		0001	20	PA	D41801P	1		AP1800B	03	ALL	
I	D41811P	A02		0002	20	PA	D41801P	2		AP1800B	03	ALL	
I	D41811P	A03		0003	20	PA	D41801P	3		AP1800B	03	ALL	
I	D41811P	A08		0008	22	PA	D41801P	8		AP1800B	03	ALL	
I	D41811P	A09		0009	22	PA	D41801P	9		AP1800B	03	ALL	
I	D41811P	A10		0010	20	PA	D41801P	10		AP1800B	03	ALL	

SPARE WIRE LIST

D280A351

91-21-12

Section AE0101A

Page 1

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AE0101A	13	W2101	LA2	DISCONNECT BRACKET - E1-1 SHELF (continued)								
D41811P	B01		0011	20 PA	D41801P	11		AP1800B	03	ALL		
D41811P	B02		0012	20 PA	D41801P	12		AP1800B	03	ALL		
D41811P	B03		0013	20 PA	D41801P	13		AP1800B	03	ALL		
D41811P	B04		0014	20 PA	D41801P	14		AP1800B	03	ALL		
D41811P	B05		0015	20 PA	D41801P	15		AP1800B	03	ALL		
AE0101A	17	W5721	LE2	DISCONNECT BRACKET - E1-1 SHELF								
D41121P	B16		0026	22 CQ	D41129J	26		AE0104A	18	ALL		
AE0101A	19	W5111	NA2	DISCONNECT BRACKET - E1-1 SHELF								
D45113P	B14		2033B	24 Y2	D45111P	B17		AE0301A	07	ALL		
D45113P	A14		2033R	24 Y2	D45111P	A17		AE0301A	07	ALL		
D45113P	PERG	1F	2033Z		D45111P	PERG	1F	AE0301A	07	ALL		
AE0101A	20	W5161	LA2	DISCONNECT BRACKET - E1-1 SHELF								
D41155P	A17		0040	24 PK	D43145P	A17		AE0301A	15	ALL		
D41155P	A06		2503B	24 Y2	D45255J	A06		AE0502A	15	YT101-YT103		
D41155P	A06		2503B	24 Y2	D45255J	A06		AE0502A	03	YT104-YT133		
D41155P	A05		2503R	24 Y2	D45255J	A05		AE0502A	15	YT101-YT103		
D41155P	A05		2503R	24 Y2	D45255J	A05		AE0502A	03	YT104-YT133		
D41155P	PERG	1F	2503Z		D45255J	PERG	1F	AE0502A	15	YT101-YT103		
D41155P	PERG	1F	2503Z		D45255J	PERG	1F	AE0502A	03	YT104-YT133		
AE0101A	21	W5461	LA2	DISCONNECT BRACKET - E1-1 SHELF								
D43211P	B15		0045	24 PK	D42361P	B11		AE0302A	43	ALL		
D43211P	A14		0073	24 PK	D42361P	A14		AE0302A	43	ALL		
D43211P	B13		0074	24 PK	D42361P	B13		AE0302A	43	ALL		
AE0101A	22	W5461	LA2	DISCONNECT BRACKET - E1-1 SHELF								
D46461P	B04		2047B	24 Y2	D45261J	A20		AE0502A	06	YT126-YT133		
D46461P	A04		2047R	24 Y2	D45261J	A19		AE0502A	06	YT126-YT133		
D46461P	PERG	1F	2047Z		D45261J	PERG	1F	AE0502A	06	YT126-YT133		
AE0101A	24	W2175	LA2	DISCONNECT BRACKET - E1-1 SHELF								
D41821P	A06		0006	22 PA	D41803P	6		AP1800B	06	ALL		
D41821P	A08		0008	20 PA	D41803P	8		AP1800B	06	ALL		
D41821P	A09		0009	22 PA	D41803P	9		AP1800B	06	ALL		

SPARE WIRE LIST

D280A351

91-21-12

Section AE0101A

Page 2

Jun 21/2016

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AE0101A	24	W2175	LA2	DISCONNECT BRACKET - E1-1 SHELF (continued)								
D41821P	A10		0010	22 PA	D41803P	10		AP1800B	06	ALL		
D41821P	B02		0012	20 PA	D41803P	12		AP1800B	06	ALL		
D41821P	B03		0013	20 PA	D41803P	13		AP1800B	06	ALL		
D41821P	B05		0015	20 PA	D41803P	15		AP1800B	06	ALL		
D41821P	B07		0017	20 PA	D41803P	17		AP1800B	06	ALL		
D41821P	G		0024	16 PA	D41803P	CAP	Y	AP1800B	06	ALL		
AE0101A	25	W5719	LA2	DISCONNECT BRACKET - E1-1 SHELF								
D41125P	B07		0030	22 PA	D42111P	B02		AE0402A	01	ALL		
D41125P	B13		0036	20 PA	D41509P	36		AE0103A	19	ALL		
D41125P	A10		0037	22 PA	D41509P	37		AE0103A	19	ALL		
D41125P	B10		0038	24 PK	D41509P	38		AE0103A	19	ALL		
D41125P	A16		0039	20 PA	D41211J	39		AE0102A	01	ALL		
D41125P	B16		0041	22 PA	D41211J	41		AE0102A	01	ALL		
D41125P	A18		0043	22 PA	D41211J	40		AE0102A	01	ALL		
D41125P	B15		0051	22 PA	D41211J	31		AE0102A	01	ALL		
D41125P	A04		2005B	24 Y2	D41509P	46		AE0103A	19	ALL		
D41125P	A03		2005R	24 Y2	D41509P	45		AE0103A	19	ALL		
D41125P	PERG	1F	2005Z		D41509P			AE0103A	19	ALL		
D41125P	B04		2006B	24 Y2	D41509P	50		AE0103A	19	ALL		
D41125P	B03		2006R	24 Y2	D41509P	49		AE0103A	19	ALL		
D41125P	PERG	1F	2006Z		D41509P			AE0103A	19	ALL		
D41125P	A15		2010B	24 Y2	D41509P	44		AE0103A	19	ALL		
D41125P	A14		2010R	24 Y2	D41509P	43		AE0103A	19	ALL		
D41125P	PERG	1F	2010Z		D41509P	S/R		AE0103A	19	ALL		
AE0101A	26	W3381	LE2	DISCONNECT BRACKET - E1-1 SHELF								
D04083P	A02		0006	20 PA	D44381P	1		AB1050L	04	ALL		
D04083P	A07		0007	20 PA	D44381P	2		AB1050L	04	ALL		
AE0101A	27	W5367	LC3	DISCONNECT BRACKET - E1-1 SHELF								
D04073P	B02		3013B	22 HG	D01827	REF	VP	M00943		ALL		
D04073P	B01		3013R	22 HG	D01827	REF	VP	M00943		ALL		
D04073P	B03		3013Y	22 HG	D01827	REF	VP	M00943		ALL		
D04073P	PERG	1F	3013Z		D01827	DED		M00943		ALL		

SPARE WIRE LIST

D280A351

91-21-12

Section AE0101A

Page 3

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

From	Matewith	Pos	Bundle	Sep	Description		To	Term	Type	Matewith	Pos	Effectivity
Equip		Term	Type	Wire No.	GA	TY	Equip					
I	AE0101A	31	W5205	SA2	DISCONNECT BRACKET - E1-1 SHELF							
I	D45203P	A06		0006	22	PA	D45201J	6		AE0102A	10	ALL
I	D45203P	A10		0010	22	PA	D45201J	10		AE0102A	10	ALL
I	D45203P	B06		2006B	22	X2	D45201J	16		AE0102A	10	ALL
I	D45203P	B05		2006R	22	X2	D45201J	15		AE0102A	10	ALL
I	D45203P	PERG	1F	2006Z			D45201J	S/R		AE0102A	10	ALL
I	AE0101A	32	W3377	LA3	DISCONNECT BRACKET - E1-1 SHELF							
I	D04079P	B01		0010	20	PA	D43397P	46		AB1050L	03	ALL
I	D04079P	B08		3006B	22	PC	D43397P	41		AB1050L	03	ALL
I	D04079P	B07		3006R	22	PC	D43397P	40		AB1050L	03	ALL
I	D04079P	B09		3006Y	22	PC	D43397P	42		AB1050L	03	ALL
I	AE0101A	36	W5381	LE2	DISCONNECT BRACKET - E1-1 SHELF							
I	D45551P	B02		2008B	22	VG	D45501J	13		AB1050L	05	ALL
I	D45551P	A02		2008R	22	VG	D45501J	4		AB1050L	05	ALL
I	D45551P	PERG	1F	2008Z			D45501J	S/R		AB1050L	05	ALL
I	D45551P	B09		2009B	20	HF	D45501J	10		AB1050L	05	ALL
I	D45551P	A09		2009R	20	HF	D45501J	2		AB1050L	05	ALL
I	D45551P	PERG	1F	2009Z			D45501J	S/R		AB1050L	05	ALL

SPARE WIRE LIST

D280A351

91-21-12

Section AE0101A

Page 4 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From Matewith From	Pos	Bundle	Sep	Description		To						
	Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity	
I	AE0101B	01	W5463	RB2	DISCONNECT BRACKET - E1-1 SHELF								
I	D41563P	A03		0055	20	PA	D43263P	A13	VP	AE0302A	44	ALL	
I	AE0101B	02	W5160	RB2*	DISCONNECT BRACKET - E1-1 SHELF								
I	D40464P	B04		0619	22	PA	D10986	54		M02061		ALL	
I	AE0101B	08	W5463	RB2	DISCONNECT BRACKET - E1-1 SHELF								
I	D41163P	B14		0020	22	PA	D41463J	36		AE0104A	11	ALL	
I	D41163P	B12		0046	24	B6	D41463J	30		AE0104A	11	ALL	
I	AE0101B	09	W2383	RB2	DISCONNECT BRACKET - E1-1 SHELF								
I	D46023P	A05		0023	20	PA	D46065P	23		AP0600B	15	ALL	
I	AE0101B	10	W5723	RB2*	DISCONNECT BRACKET - E1-1 SHELF								
I	D43317P	A09		0074	20	CQ	D40047J	41		AE0104A	08	ALL	
I	D43317P	A02		0102	20	CQ	D40047J	2		AE0104A	08	ALL	
I	D43317P	A03		0103	20	CQ	D40047J	3		AE0104A	08	ALL	
I	AE0101B	11	W5163	RB2*	DISCONNECT BRACKET - E1-1 SHELF								
I	D41147P	G		0025	16	PA	D41557J	23		AE0105A	07	ALL	
I	D41147P	A07		0040	24	PK	D43147P	A07		AE0301A	28	ALL	
I	AE0101B	12	W5163	RB2*	DISCONNECT BRACKET - E1-1 SHELF								
	D41157P	A18		0004	22	PA	D45257J	A15		AE0502A	05	YT101-YT103	
I	D41157P	A18		0004	22	PA	D45257J	A15		AE0502A	28	YT104-YT133	
I	D41157P	B05		0035	22	PA	D41557J	4		AE0105A	07	ALL	
	D41157P	B20		0039	22	PA	D45257J	A07		AE0502A	05	YT101-YT103	
I	D41157P	B20		0039	22	PA	D45257J	A07		AE0502A	28	YT104-YT133	
I	D41157P	A02		2501B	24	Y2	D45257J	A02		AE0502A	28	YT126-YT133	
I	D41157P	A01		2501R	24	Y2	D45257J	A01		AE0502A	28	YT126-YT133	
I	D41157P	PERG	1F	2501Z			D45257J	PERG	1F	AE0502A	28	YT126-YT133	
I	D41157P	B11		2529B	24	Y2	D43147P	A20		AE0301A	28	ALL	
I	D41157P	B10		2529R	24	Y2	D43147P	A19		AE0301A	28	ALL	
I	D41157P	PERG	1F	2529Z			D43147P	PERG	1F	AE0301A	28	ALL	
I	AE0101B	13	W2103	RB2	DISCONNECT BRACKET - E1-1 SHELF								
I	D46013P	A05		0005	20	PA	D46061P	5		AP0600B	23	ALL	
I	D46013P	A06		0006	20	PA	D46061P	6		AP0600B	23	ALL	

SPARE WIRE LIST

D280A351

91-21-12

Section AE0101B

Page 1

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description		To						
Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AE0101B	13	W2103	RB2	DISCONNECT BRACKET - E1-1 SHELF (continued)								
D46013P	A08		0018	20	PA	D46061P	18		AP0600B	23	ALL	

SPARE WIRE LIST

D280A351

91-21-12

Section AE0101B

Page 2 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

From	Matewith	Pos	Bundle	Sep	Description		To	Term	Type	Matewith	Pos	Effectivity
Equip		Term	Type	Wire No.	GA	TY	Equip					
I	AE0102A	01	W5719	LA2	DISCONNECT BRACKET - E1-2 SHELF							
	D41211J	26		0026	24	PK	D41509P	26		AE0103A	19	ALL
	D41211J	27		0027	24	PK	D41509P	27		AE0103A	19	ALL
	D41211J	28		0028	20	PA	D41509P	28		AE0103A	19	ALL
	D41211J	39		0039	20	PA	D41125P	A16		AE0101A	25	ALL
	D41211J	41		0041	22	PA	D41125P	B16		AE0101A	25	ALL
	D41211J	40		0043	22	PA	D41125P	A18		AE0101A	25	ALL
	D41211J	31		0051	22	PA	D41125P	B15		AE0101A	25	ALL
	D41211J	44		2011B	24	Y2	D41509P	53		AE0103A	19	ALL
	D41211J	43		2011R	24	Y2	D41509P	52		AE0103A	19	ALL
	D41211J	S/R		2011Z			D41509P	S/R		AE0103A	19	ALL
I	AE0102A	02	W5111	NA2	DISCONNECT BRACKET - E1-2 SHELF							
	D45115J	9		0024	22	PA	D45111P	B02		AE0301A	07	ALL
I	AE0102A	03	W2149	NA2	DISCONNECT BRACKET - E1-2 SHELF							
	D04029J	23		0023	22	PA	D00263	CAP	Y	P008-25		ALL
	D04029J	27		0027	22	PA	D00303	CAP	Y	P008-25		ALL
	D04029J	34		2005B	24	Y2	D00303	CAP	Y	P008-25		ALL
	D04029J	33		2005R	24	Y2	D00303	CAP	Y	P008-25		ALL
	D04029J	S/R		2005Z			D00303	S/R		P008-25		ALL
	D04029J	36		2006B	24	Y2	D00263	CAP	Y	P008-25		ALL
	D04029J	35		2006R	24	Y2	D00263	CAP	Y	P008-25		ALL
	D04029J	S/R		2006Z			D00263	S/R		P008-25		ALL
I	AE0102A	05	W2205	SN2	DISCONNECT BRACKET - E1-2 SHELF							
	D04205J	11		2004B	24	Y2	D10853	CAP	Y	N00226		ALL
	D04205J	10		2004R	24	Y2	D10853	CAP	Y	N00226		ALL
	D04205J	S/R		2004Z			D10853	DED		N00226		ALL
	D04205J	13		2015B	24	Y2	D10853	CAP	Y	N00226		ALL
	D04205J	12		2015R	24	Y2	D10853	CAP	Y	N00226		ALL
	D04205J	S/R		2015Z			D10853	DED		N00226		ALL
I	AE0102A	06	W2651	SA2	DISCONNECT BRACKET - E1-2 SHELF							
	D41827J	11		0001	20	PA	D41807P	1		AP1800B	08	ALL
I	AE0102A	10	W5205	SA2	DISCONNECT BRACKET - E1-2 SHELF							
	D45201J	6		0006	22	PA	D45203P	A06		AE0101A	31	ALL

SPARE WIRE LIST

D280A351

91-21-12

Section AE0102A

Page 1

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AE0102A	10	W5205	SA2	DISCONNECT BRACKET - E1-2 SHELF (continued)								
D45201J	10		0010	22 PA	D45203P	A10		AE0101A	31	ALL		
D45201J	31		0053	20 CQ	D45207P	A03		AE0302A	14	ALL		
D45201J	16		2006B	22 X2	D45203P	B06		AE0101A	31	ALL		
D45201J	15		2006R	22 X2	D45203P	B05		AE0101A	31	ALL		
D45201J	S/R		2006Z		D45203P	PERG	1F	AE0101A	31	ALL		
D45201J	13		2031B	24 Y2	D45209J	A07		AE0502A	03	YT101-YT103		
D45201J	13		2031B	24 Y2	D45209J	A07		AE0502A	01	YT104-YT133		
D45201J	12		2031R	24 Y2	D45209J	A06		AE0502A	03	YT101-YT103		
D45201J	12		2031R	24 Y2	D45209J	A06		AE0502A	01	YT104-YT133		
D45201J	S/R		2031Z		D45209J	PERG	1F	AE0502A	03	YT101-YT103		
D45201J	S/R		2031Z		D45209J	PERG	1F	AE0502A	01	YT104-YT133		
AE0102A	12	W5723	RB2*	DISCONNECT BRACKET - E1-2 SHELF								
D41213J	15		2040B	24 Y2	D40047J	55		AE0104A	08	ALL		
D41213J	14		2040R	24 Y2	D40047J	54		AE0104A	08	ALL		
D41213J	S/R		2040Z		D40047J	S/R		AE0104A	08	ALL		
D41213J	4		2512B	24 Y2	D43306P	B04		AE0303A	05	YT101-YT103		
D41213J	4		2512B	24 Y2	D43306P	B04		AE0303A	48	YT104-YT133		
D41213J	3		2512R	24 Y2	D43306P	A04		AE0303A	05	YT101-YT103		
D41213J	3		2512R	24 Y2	D43306P	A04		AE0303A	48	YT104-YT133		
D41213J	S/R		2512Z		D43306P	PERG	1F	AE0303A	05	YT101-YT103		
D41213J	S/R		2512Z		D43306P	PERG	1F	AE0303A	48	YT104-YT133		
AE0102A	13	W5721	LE2	DISCONNECT BRACKET - E1-2 SHELF								
D41127J	23		0023	22 CQ	D41129J	23		AE0104A	18	ALL		
D41127J	8		0028	22 PA	D41129J	49		AE0104A	18	ALL		
D41127J	13		0053	20 CQ	D41129J	53		AE0104A	18	ALL		
D41127J	14		0054	20 CQ	D41129J	54		AE0104A	18	ALL		
D41127J	15		0055	20 CQ	D41129J	55		AE0104A	18	ALL		

SPARE WIRE LIST

D280A351

91-21-12

Section AE0102A

Page 2 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From Matewith	Pos	Bundle	Sep	Description		To					Effectivity	
	Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos		
I	AE0103A	03	W2661	SB2	DISCONNECT BRACKET - E1-3 SHELF								
I	D46051P	7		0007	18	PA	D46069P	7		AP0600B	20	ALL	
I	D46051P	10		0010	16	PA	D46069P	10		AP0600B	20	ALL	
I	AE0103A	09	W3307	NN2	DISCONNECT BRACKET - E1-3 SHELF								
I	D41337P	22		0008	24	PK	D14366	40		M01415		ALL	
I	D41337P	24		2003B	24	PL	D14366	39		M01415		ALL	
I	D41337P	23		2003R	24	PL	D14366	38		M01415		ALL	
I	AE0103A	14	W5160	RB2*	DISCONNECT BRACKET - E1-3 SHELF								
I	D40466P	4		0652	22	PA	D46102P	18		AJ0046A	14	ALL	
I	D40466P	5		0653	22	PA	D46102P	19		AJ0046A	14	ALL	
I	D40466P	27		0656	24	PK	D40470P	A01		AE0302A	37	ALL	
I	D40466P	28		0657	24	PK	D40470P	A06		AE0302A	37	ALL	
I	D40466P	30		2461B	24	Y2	D40470P	B07		AE0302A	37	ALL	
I	D40466P	29		2461R	24	Y2	D40470P	B06		AE0302A	37	ALL	
I	D40466P	31		2461Z			D40470P	PERG	1F	AE0302A	37	ALL	
I	AE0103A	17	W2651	SA2	DISCONNECT BRACKET - E1-3 SHELF								
I	D41831P	1		0012	20	PA	D41807P	12		AP1800B	08	ALL	
I	D41831P	2		0013	20	PA	D41807P	13		AP1800B	08	ALL	
I	D41831P	7		0019	16	PA	D41807P	6		AP1800B	08	ALL	
I	AE0103A	19	W5719	LA2	DISCONNECT BRACKET - E1-3 SHELF								
I	D41509P	26		0026	24	PK	D41211J	26		AE0102A	01	ALL	
I	D41509P	27		0027	24	PK	D41211J	27		AE0102A	01	ALL	
I	D41509P	28		0028	20	PA	D41211J	28		AE0102A	01	ALL	
I	D41509P	36		0036	20	PA	D41125P	B13		AE0101A	25	ALL	
I	D41509P	37		0037	22	PA	D41125P	A10		AE0101A	25	ALL	
I	D41509P	38		0038	24	PK	D41125P	B10		AE0101A	25	ALL	
I	D41509P	46		2005B	24	Y2	D41125P	A04		AE0101A	25	ALL	
I	D41509P	45		2005R	24	Y2	D41125P	A03		AE0101A	25	ALL	
I	D41509P			2005Z			D41125P	PERG	1F	AE0101A	25	ALL	
I	D41509P	50		2006B	24	Y2	D41125P	B04		AE0101A	25	ALL	
I	D41509P	49		2006R	24	Y2	D41125P	B03		AE0101A	25	ALL	
I	D41509P			2006Z			D41125P	PERG	1F	AE0101A	25	ALL	
I	D41509P	44		2010B	24	Y2	D41125P	A15		AE0101A	25	ALL	
I	D41509P	43		2010R	24	Y2	D41125P	A14		AE0101A	25	ALL	

SPARE WIRE LIST

D280A351

91-21-12

Section AE0103A

Page 1

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AE0103A	19	W5719	LA2	DISCONNECT BRACKET - E1-3 SHELF (continued)								
D41509P	S/R		2010Z		D41125P	PERG	1F	AE0101A	25	ALL		
D41509P	53		2011B	24 Y2	D41211J	44		AE0102A	01	ALL		
D41509P	52		2011R	24 Y2	D41211J	43		AE0102A	01	ALL		
D41509P	S/R		2011Z		D41211J	S/R		AE0102A	01	ALL		
D41509P			FRAA		D41509P	S/R		AE0103A	19	ALL		
D41509P	S/R		FRAA		D41509P			AE0103A	19	ALL		
D41509P			FRAB		D41509P	47		AE0103A	19	ALL		
D41509P	47		FRAB		D41509P			AE0103A	19	ALL		
D41509P	S/R		FRAC		D41509P			AE0103A	19	ALL		
D41509P			FRAC		D41509P	S/R		AE0103A	19	ALL		
D41509P	51		FRAD		D41509P			AE0103A	19	ALL		
D41509P			FRAD		D41509P	51		AE0103A	19	ALL		
AE0103A	22	W5723	RB2*	DISCONNECT BRACKET - E1-3 SHELF								
D41131P	35		2511B	24 Y2	D43306P	B03		AE0303A	05	YT101-YT103		
D41131P	35		2511B	24 Y2	D43306P	B03		AE0303A	48	YT104-YT133		
D41131P	34		2511R	24 Y2	D43306P	A03		AE0303A	05	YT101-YT103		
D41131P	34		2511R	24 Y2	D43306P	A03		AE0303A	48	YT104-YT133		
D41131P	36		2511Z		D43306P	PERG	1F	AE0303A	05	YT101-YT103		
D41131P	36		2511Z		D43306P	PERG	1F	AE0303A	48	YT104-YT133		

SPARE WIRE LIST

D280A351

91-21-12

Section AE0103A

Page 2 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From Matewith	Pos	Bundle	Sep	Description		To					
	From Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity
I	AE0104A	03	W3379	RB3	DISCONNECT BRACKET - E1-4 SHELF							
I	D04081J	3		0022	20	CQ	D43399P	50		AB1050R	04	ALL
I	D04081J	28		3006B	22	PC	D43399P	41		AB1050R	04	ALL
I	D04081J	27		3006R	22	PC	D43399P	40		AB1050R	04	ALL
I	D04081J	29		3006Y	22	PC	D43399P	42		AB1050R	04	ALL
I	AE0104A	06	W2251	RF2	DISCONNECT BRACKET - E1-4 SHELF							
I	D04311J	3		0003	22	PA	D04251P	3		AP0900A	23	ALL
I	D04311J	7		0007	22	CQ	D04251P	7		AP0900A	23	ALL
I	D04311J	9		0009	22	CQ	D04251P	9		AP0900A	23	ALL
I	D04311J	12		0012	20	PA	D04251P	12		AP0900A	23	ALL
I	D04311J	20		2003B	24	Y2	D04251P	20		AP0900A	23	ALL
I	D04311J	19		2003R	24	Y2	D04251P	19		AP0900A	23	ALL
I	D04311J	S/R		2003Z			D04251P	S/R		AP0900A	23	ALL
I	D04311J	22		2004B	24	Y2	D04251P	22		AP0900A	23	ALL
I	D04311J	21		2004R	24	Y2	D04251P	21		AP0900A	23	ALL
I	D04311J	S/R		2004Z			D04251P	S/R		AP0900A	23	ALL
I	AE0104A	07	W2205	SN2	DISCONNECT BRACKET - E1-4 SHELF							
I	D40049J	4		2012B	24	Y2	D10853	CAP	Y	N00226		ALL
I	D40049J	3		2012R	24	Y2	D10853	CAP	Y	N00226		ALL
I	D40049J	S/R		2012Z			D10853	DED		N00226		ALL
I	AE0104A	08	W5723	RB2*	DISCONNECT BRACKET - E1-4 SHELF							
I	D40047J	41		0074	20	CQ	D43317P	A09		AE0101B	10	ALL
I	D40047J	2		0102	20	CQ	D43317P	A02		AE0101B	10	ALL
I	D40047J	3		0103	20	CQ	D43317P	A03		AE0101B	10	ALL
I	D40047J	55		2040B	24	Y2	D41213J	15		AE0102A	12	ALL
I	D40047J	54		2040R	24	Y2	D41213J	14		AE0102A	12	ALL
I	D40047J	S/R		2040Z			D41213J	S/R		AE0102A	12	ALL
I	AE0104A	09	W2103	RB2	DISCONNECT BRACKET - E1-4 SHELF							
I	D46011J	12		0012	20	PA	D46061P	12		AP0600B	23	ALL
I	D46011J	13		0013	20	PA	D46061P	13		AP0600B	23	ALL
I	D46011J	7		0017	20	PA	D46061P	17		AP0600B	23	ALL
I	AE0104A	10	W2383	RB2	DISCONNECT BRACKET - E1-4 SHELF							
I	D46031J	9		0009	24	PK	D46065P	9		AP0600B	15	ALL

SPARE WIRE LIST

D280A351

91-21-12

Section AE0104A

Page 1

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AE0104A	10	W2383	RB2	DISCONNECT BRACKET - E1-4 SHELF (continued)								
D46031J	8		0024	20 PA	D46065P	24		AP0600B	15	ALL		
D46031J	6		0026	22 PA	D46065P	26		AP0600B	15	ALL		
AE0104A	11	W5463	RB2	DISCONNECT BRACKET - E1-4 SHELF								
D41463J	36		0020	22 PA	D41163P	B14		AE0101B	08	ALL		
D41463J	14		0022	22 PA	D45263J	A05		AE0502A	06	YT101-YT103		
D41463J	14		0022	22 PA	D45263J	A05		AE0502A	29	YT104-YT133		
D41463J	44		0030	24 PK	D42363P	A03		AE0302A	53	ALL		
D41463J	45		0031	24 PK	D42363P	B03		AE0302A	53	ALL		
D41463J	30		0046	24 B6	D41163P	B12		AE0101B	08	ALL		
AE0104A	12	W5121	NB2	DISCONNECT BRACKET - E1-4 SHELF								
D45123J	7		0013	24 PK	D45127P	B03		AE0302A	46	ALL		
D45123J	9		0017	20 PA	D45125J	9		AE0105A	09	ALL		
D45123J	45		2021B	24 Y2	D45121P	B20		AE0301A	32	ALL		
D45123J	44		2021R	24 Y2	D45121P	A20		AE0301A	32	ALL		
D45123J	S/R		2021Z		D45121P	PERG	1F	AE0301A	32	ALL		
AE0104A	13	W5383	RF2	DISCONNECT BRACKET - E1-4 SHELF								
D45553J	13		2008B	22 VG	D45503J	13		AB1050R	06	ALL		
D45553J	4		2008R	22 VG	D45503J	4		AB1050R	06	ALL		
D45553J	S/R		2008Z		D45503J	S/R		AB1050R	06	ALL		
D45553J	10		2009B	20 HF	D45503J	10		AB1050R	06	ALL		
D45553J	2		2009R	20 HF	D45503J	2		AB1050R	06	ALL		
D45553J	S/R		2009Z		D45503J	S/R		AB1050R	06	ALL		
AE0104A	15	W5375	RD3	DISCONNECT BRACKET - E1-4 SHELF								
D04077J	29		0011	20 PA	D42053P	A10		AE0302A	47	ALL		
AE0104A	17	W5191	NB3	DISCONNECT BRACKET - E1-4 SHELF								
D04273J	12		0025	20 PA	D04285P	B20		AE0401A	19	ALL		
AE0104A	18	W5721	LE2	DISCONNECT BRACKET - E1-4 SHELF								
D41129J	23		0023	22 CQ	D41127J	23		AE0102A	13	ALL		
D41129J	26		0026	22 CQ	D41121P	B16		AE0101A	17	ALL		
D41129J	49		0028	22 PA	D41127J	8		AE0102A	13	ALL		
D41129J	53		0053	20 CQ	D41127J	13		AE0102A	13	ALL		

SPARE WIRE LIST

D280A351

91-21-12

Section AE0104A

Page 2

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From Matewith From	Pos	Bundle	Sep	Description		To					Effectivity	
	Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos		
	AE0104A	18	W5721	LE2	DISCONNECT BRACKET - E1-4 SHELF (continued)								
	D41129J	54		0054	20	CQ	D41127J	14		AE0102A	13	ALL	
	D41129J	55		0055	20	CQ	D41127J	15		AE0102A	13	ALL	
	AE0104A	20	W5158	SB2*	DISCONNECT BRACKET - E1-4 SHELF								
	D40490J	4		0015	22	PA	D40638P	12		AJ0020B	02	ALL	
	D40490J	21		0634	20	PA	D40426P	14		AE0302A	28	YT101-YT103	
	D40490J	21		0634	20	PA	D40426P	B03		AE0302A	28	YT104-YT133	
	AE0104A	21	W5510	SA2*	DISCONNECT BRACKET - E1-4 SHELF								
	D40496J	19		0010	20	PA	D40672P	23		AJ0022	02	ALL	
	AE0104A	22	W5526	SA2	DISCONNECT BRACKET - E1-4 SHELF								
	D43016J	7		5512	20	PA	D04580P	12		AB0536L	01	ALL	
	D43016J	8		5513	20	PA	D04580P	13		AB0536L	01	ALL	
	D43016J	9		5516	20	PA	D40302J	10		AB0500DL	09	ALL	
	D43016J	10		5517	20	PA	D40302J	11		AB0500DL	09	ALL	
	AE0104A	26	W5204	NN2	DISCONNECT BRACKET - E1-4 SHELF								
	D40332J	2		0002	20	PA	D13928	17		D13832		ALL	
	AE0104A	27	W5514	SA2	DISCONNECT BRACKET - E1-4 SHELF								
	D40826J	7		0502	24	B6	D40824P	28		AP0900A	05	ALL	
	D40826J	16		0503	24	B6	D40824P	29		AP0900A	05	ALL	
	D40826J	17		0504	24	B6	D40824P	30		AP0900A	05	ALL	
	D40826J	18		0505	24	B6	D40824P	31		AP0900A	05	ALL	
	D40826J	6		5564	20	PA	D40824P	19		AP0900A	05	ALL	
	D40826J	8		5565	20	PA	D40824P	20		AP0900A	05	ALL	
	D40826J	12		5572	20	PA	D40830P	3		AP1800B	07	ALL	
	D40826J	13		5573	20	PA	D40830P	4		AP1800B	07	ALL	
	AE0104A	28	W5610	SA2*	DISCONNECT BRACKET - E1-4 SHELF								
	D40346J	11		0501	22	PA	D40348P	A02		AE0202A	10	ALL	
	D40346J	12		0502	22	PA	D40348P	B02		AE0202A	10	ALL	
	D40346J	13		0503	22	PA	D40348P	A03		AE0202A	10	ALL	

SPARE WIRE LIST

D280A351

91-21-12

Section AE0104A

Page 3 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From Matewith	Pos	Bundle	Sep	Description		To					Effectivity	
	Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos		
I	AE0105A	02	W2151	NB2	DISCONNECT BRACKET - E1-5 SHELF								
I	D04031J	23		0023	22	PA	D00265	CAP	Y	P008-26		ALL	
I	D04031J	27		0027	22	PA	D00305	CAP	Y	P008-26		ALL	
I	D04031J	34		2005B	24	Y2	D00305	CAP	Y	P008-26		ALL	
I	D04031J	33		2005R	24	Y2	D00305	CAP	Y	P008-26		ALL	
I	D04031J	S/R		2005Z			D00305	S/R		P008-26		ALL	
I	D04031J	36		2006B	24	Y2	D00265	CAP	Y	P008-26		ALL	
I	D04031J	35		2006R	24	Y2	D00265	CAP	Y	P008-26		ALL	
I	D04031J	S/R		2006Z			D00265	S/R		P008-26		ALL	
I	AE0105A	03	W5723	RB2*	DISCONNECT BRACKET - E1-5 SHELF								
	D41507J	42		2502B	24	Y2	D43333P	B08		AE0303A	44	YT101-YT103	
I	D41507J	42		2502B	24	Y2	D43333P	B08		AE0303A	47	YT104-YT133	
	D41507J	41		2502R	24	Y2	D43333P	A08		AE0303A	44	YT101-YT103	
I	D41507J	41		2502R	24	Y2	D43333P	A08		AE0303A	47	YT104-YT133	
	D41507J	S/R		2502Z			D43333P	PERG	1F	AE0303A	44	YT101-YT103	
I	D41507J	S/R		2502Z			D43333P	PERG	1F	AE0303A	47	YT104-YT133	
	D41507J	44		2503B	24	Y2	D43333P	B10		AE0303A	44	YT101-YT103	
I	D41507J	44		2503B	24	Y2	D43333P	B10		AE0303A	47	YT104-YT133	
	D41507J	43		2503R	24	Y2	D43333P	A10		AE0303A	44	YT101-YT103	
I	D41507J	43		2503R	24	Y2	D43333P	A10		AE0303A	47	YT104-YT133	
	D41507J	S/R		2503Z			D43333P	PERG	1F	AE0303A	44	YT101-YT103	
I	D41507J	S/R		2503Z			D43333P	PERG	1F	AE0303A	47	YT104-YT133	
	D41507J	48		2506B	24	Y2	D43333P	B07		AE0303A	44	YT101-YT103	
I	D41507J	48		2506B	24	Y2	D43333P	B07		AE0303A	47	YT104-YT133	
	D41507J	47		2506R	24	Y2	D43333P	A07		AE0303A	44	YT101-YT103	
I	D41507J	47		2506R	24	Y2	D43333P	A07		AE0303A	47	YT104-YT133	
	D41507J	S/R		2506Z			D43333P	PERG	1F	AE0303A	44	YT101-YT103	
I	D41507J	S/R		2506Z			D43333P	PERG	1F	AE0303A	47	YT104-YT133	
I	AE0105A	07	W5163	RB2*	DISCONNECT BRACKET - E1-5 SHELF								
I	D41557J	23		0025	16	PA	D41147P	G		AE0101B	11	ALL	
I	D41557J	4		0035	22	PA	D41157P	B05		AE0101B	12	ALL	
I	AE0105A	09	W5121	NB2	DISCONNECT BRACKET - E1-5 SHELF								
I	D45125J	9		0017	20	PA	D45123J	9		AE0104A	12	ALL	

SPARE WIRE LIST

D280A351

91-21-12

Section AE0105A

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From Matewith	Pos	Bundle	Sep	Description		To	Term	Type	Matewith	Pos	Effectivity
	Equip	Term	Type	Wire No.	GA	TY	Equip					
I	AE0201A	07	W5726	AD1	DISCONNECT BRACKET - E2-1 SHELF							
I	D40254P	F		0577	16	PA	D11438	2		P0091		ALL
I	D40254P	G		0578	16	PA	D11438	3		P0091		ALL
I	D40254P	H		0579	16	PA	D11438	4		P0091		ALL
I	D40254P	A01		0597	22	PA	D11438	7		P0091		ALL
I	AE0201A	08	W5510	SA2*	DISCONNECT BRACKET - E2-1 SHELF							
I	D40428P	A04		0011	24	PK	D40672P	9		AJ0022	02	ALL
I	D40428P	A08		0012	24	PK	D40672P	12		AJ0022	02	ALL
	AE0201A	15	W2138	LA1	DISCONNECT BRACKET - E2-1 SHELF							
	D41432P	3		5503	16	HA	D41430P	3		AP0600B	05	YT101-YT116, YT126-YT131
I	AE0201A	17	W5164	LA1*	DISCONNECT BRACKET - E2-1 SHELF							
I	D40718P	A05		2602B	20	X2	D39933	26		AC0520		ALL
I	D40718P	B05		2602R	20	X2	D39933	25		AC0520		ALL
I	D40718P	PERG	1F	2602Z			D39933	S/R		AC0520		ALL
I	AE0201A	18	W5612	SN2*	DISCONNECT BRACKET - E2-1 SHELF							
I	D40358P	A01		0001	20	PA	D40362P	A01		AE0302A	05	ALL
I	D40358P	B05		2204B	24	Y2	D40352P	28		AP0600B	16	ALL
I	D40358P	B04		2204R	24	Y2	D40352P	9		AP0600B	16	ALL
I	D40358P	DED		2204Z			D40352P	DED		AP0600B	16	ALL
I	D40358P	B08		2207B	22	PB	D40362P	B07		AE0302A	05	ALL
I	D40358P	A04		2207R	22	PB	D40362P	A07		AE0302A	05	ALL
I	AE0201A	19	W5110	LA2	DISCONNECT BRACKET - E2-1 SHELF							
I	D40340P	B01		0516	20	PA	D40338P	A10		AE0402A	07	ALL

SPARE WIRE LIST

D280A351

91-21-12

Section AE0201A

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From Matewith	Pos	Bundle	Sep	Description		To					Effectivity	
	Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos		
I	AE0202A	01	W5104	LA2	DISCONNECT BRACKET - E2-2 SHELF								
I	D40246P	A08		5522	20	PA	D40056P	16		AB0536L	02	ALL	
I	AE0202A	07	W5564	SN2*	DISCONNECT BRACKET - E2-2 SHELF								
I	D40136P	A01		2601B	20	X2	D39909	6		AC0520		ALL	
I	D40136P	B01		2601R	20	X2	D39909	5		AC0520		ALL	
I	D40136P	PERG	1F	2601Z			D39909	S/R		AC0520		ALL	
I	AE0202A	08	W5168	SB2*	DISCONNECT BRACKET - E2-2 SHELF								
I	D40138P	A02		2601B	20	X2	D39929	2		AC0520		ALL	
I	D40138P	B02		2601R	20	X2	D39929	3		AC0520		ALL	
I	D40138P	PERG	1F	2601Z			D39929	S/R		AC0520		ALL	
I	D40138P	A03		2602B	20	X2	D39929	4		AC0520		ALL	
I	D40138P	B03		2602R	20	X2	D39929	5		AC0520		ALL	
I	D40138P	PERG	1F	2602Z			D39929	S/R		AC0520		ALL	
I	AE0202A	10	W5610	SA2*	DISCONNECT BRACKET - E2-2 SHELF								
I	D40348P	A02		0501	22	PA	D40346J	11		AE0104A	28	ALL	
I	D40348P	B02		0502	22	PA	D40346J	12		AE0104A	28	ALL	
I	D40348P	A03		0503	22	PA	D40346J	13		AE0104A	28	ALL	
I	AE0202A	24	W5310	LB2*	DISCONNECT BRACKET - E2-2 SHELF								
I	D40450P	B06		5502	24	PK	D40446P	B10		AE0302A	04	ALL	
I	AE0202A	25	W5162	LB2*	DISCONNECT BRACKET - E2-2 SHELF								
I	D40130P	A03		2601B	20	X2	D39921	14		AC0520		ALL	
I	D40130P	B03		2601R	20	X2	D39921	5		AC0520		ALL	
I	D40130P	PERG	1F	2601Z			D39921	S/R		AC0520		ALL	
I	D40130P	A09		2609B	20	X2	D39921	31		AC0520		ALL	
I	D40130P	B09		2609R	20	X2	D39921	30		AC0520		ALL	
I	D40130P	PERG	1F	2609Z			D39921	S/R		AC0520		ALL	
I	AE0202A	26	W6214	LA2*	DISCONNECT BRACKET - E2-2 SHELF								
I	D40380P	B15		5536	20	PA	D40378P	B15		AE0401A	46	ALL	
I	AE0202A	27	W3170	LA2*	DISCONNECT BRACKET - E2-2 SHELF								
I	D40126P	A01		2601B	20	PB	D40734P	1		AB0420A	01	ALL	
I	D40126P	B01		2601R	20	PB	D40734P	2		AB0420A	01	ALL	

SPARE WIRE LIST

D280A351

91-21-12

Section AE0202A

Page 1

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

From	Matewith	Pos	Bundle	Sep	Description		To					
Equip	Term	Type	Wire No.		GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity
AE0202A	27	W3170	LA2*	DISCONNECT BRACKET - E2-2 SHELF (continued)								
D40126P	A02		2602B	20	PB		D40734P	3		AB0420A	01	ALL
D40126P	B02		2602R	20	PB		D40734P	4		AB0420A	01	ALL
D40126P	A03		2603B	20	PB		D40734P	5		AB0420A	01	ALL
D40126P	B03		2603R	20	PB		D40734P	6		AB0420A	01	ALL
D40126P	A11		2607B	20	X2		D40736P	4		AB0420A	02	ALL
D40126P	B11		2607R	20	X2		D40736P	5		AB0420A	02	ALL
D40126P	PERG	1F	2607Z				D40736P	S/R		AB0420A	02	ALL

SPARE WIRE LIST

D280A351

91-21-12

Section AE0202A

Page 2 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From Matewith	Pos	Bundle	Sep	Description		To					Pos	Effectivity	
	From	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith				
I	AE0301A	06	W0311	NA2	DISCONNECT BRACKET - E3-1									
I	D04267J	A18		2127B	22	X2	D45111J	B14		AE0301A	07	ALL		
I	D04267J	A17		2127R	22	X2	D45111J	A14		AE0301A	07	ALL		
I	D04267J	PERG	1F	2127Z			D45111J	PERG	1F	AE0301A	07	ALL		
I	AE0301A	06	W2207	NA2	DISCONNECT BRACKET - E3-1									
I	D04267P	A13		0003	22	PA	D04207P	13		AP0900A	03	ALL		
I	D04267P	A14		0004	22	PA	D04207P	14		AP0900A	03	ALL		
I	D04267P	B11		0031	22	PA	D04207P	31		AP0900A	03	ALL		
I	D04267P	B12		0032	22	PA	D04207P	32		AP0900A	03	ALL		
I	D04267P	B17		0037	22	PA	D04207P	37		AP0900A	03	ALL		
I	D04267P	B18		0038	22	PA	D04207P	38		AP0900A	03	ALL		
I	D04267P	B19		0040	22	CQ	D04207P	40		AP0900A	03	ALL		
I	D04267P	B20		0041	22	CQ	D04207P	41		AP0900A	03	ALL		
I	D04267P	A06		2003B	24	Y2	D04207P	6		AP0900A	03	ALL		
I	D04267P	A05		2003R	24	Y2	D04207P	5		AP0900A	03	ALL		
I	D04267P	PERG	1F	2003Z			D04207P	S/R		AP0900A	03	ALL		
I	D04267P	A08		2004B	24	Y2	D04207P	8		AP0900A	03	ALL		
I	D04267P	A07		2004R	24	Y2	D04207P	7		AP0900A	03	ALL		
I	D04267P	PERG	1F	2004Z			D04207P	S/R		AP0900A	03	ALL		
I	D04267P	A16		2008B	24	Y2	D04207P	16		AP0900A	03	ALL		
I	D04267P	A15		2008R	24	Y2	D04207P	15		AP0900A	03	ALL		
I	D04267P	PERG	1F	2008Z			D04207P	S/R		AP0900A	03	ALL		
I	D04267P	A20		2010B	24	Y2	D04207P	20		AP0900A	03	ALL		
I	D04267P	A19		2010R	24	Y2	D04207P	19		AP0900A	03	ALL		
I	D04267P	PERG	1F	2010Z			D04207P	S/R		AP0900A	03	ALL		
I	AE0301A	07	W0311	NA2	DISCONNECT BRACKET - E3-1									
I	D45111J	B14		2127B	22	X2	D04267J	A18		AE0301A	06	ALL		
I	D45111J	A14		2127R	22	X2	D04267J	A17		AE0301A	06	ALL		
I	D45111J	PERG	1F	2127Z			D04267J	PERG	1F	AE0301A	06	ALL		
I	AE0301A	07	W5111	NA2	DISCONNECT BRACKET - E3-1									
I	D45111P	B02		0024	22	PA	D45115J	9		AE0102A	02	ALL		
I	D45111P	B14		2030B	22	X2	D45117P	B13		AE0302A	20	ALL		
I	D45111P	A14		2030R	22	X2	D45117P	A13		AE0302A	20	ALL		
I	D45111P	PERG	1F	2030Z			D45117P	PERG	1F	AE0302A	20	ALL		
I	D45111P	B17		2033B	24	Y2	D45113P	B14		AE0101A	19	ALL		
I	D45111P	A17		2033R	24	Y2	D45113P	A14		AE0101A	19	ALL		

SPARE WIRE LIST

D280A351

91-21-12

Section AE0301A

Page 1

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To						
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AE0301A	07	W5111	NA2	DISCONNECT BRACKET - E3-1 (continued)							
D45111P	PERG	1F	2033Z		D45113P	PERG	1F	AE0101A	19	ALL	
D45111P	B18		2043B	24 Y2	D45117P	B17		AE0302A	20	ALL	
D45111P	A18		2043R	24 Y2	D45117P	A17		AE0302A	20	ALL	
D45111P	PERG	1F	2043Z		D45117P	PERG	1F	AE0302A	20	ALL	
AE0301A	08	W0311	NA2	DISCONNECT BRACKET - E3-1							
D45131J	B01		2140B	20 X2	D49994J	B08		AE0301A	14	ALL	
D45131J	A01		2140R	20 X2	D49994J	A08		AE0301A	14	ALL	
D45131J	PERG	1F	2140Z		D49994J	PERG	1F	AE0301A	14	ALL	
AE0301A	08	W5111	NA2	DISCONNECT BRACKET - E3-1							
D45131P	B03		2047B	24 Y2	D45133P	B06		AE0101A	03	ALL	
D45131P	A03		2047R	24 Y2	D45133P	A06		AE0101A	03	ALL	
D45131P	PERG	1F	2047Z		D45133P	PERG	1F	AE0101A	03	ALL	
AE0301A	09	W5111	NA2	DISCONNECT BRACKET - E3-1							
D45151P	B07		2056B	24 Y2	D43305P	B07		AE0303A	20	ALL	
D45151P	A07		2056R	24 Y2	D43305P	A07		AE0303A	20	ALL	
D45151P	PERG	1F	2056Z		D43305P	PERG	1F	AE0303A	20	ALL	
D45151P	B05		2057B	24 Y2	D43305P	B08		AE0303A	20	ALL	
D45151P	A05		2057R	24 Y2	D43305P	A08		AE0303A	20	ALL	
D45151P	PERG	1F	2057Z		D43305P	PERG	1F	AE0303A	20	ALL	
AE0301A	14	W0311	NA2	DISCONNECT BRACKET - E3-1							
D49994J	B08		2140B	20 X2	D45131J	B01		AE0301A	08	ALL	
D49994J	A08		2140R	20 X2	D45131J	A01		AE0301A	08	ALL	
D49994J	PERG	1F	2140Z		D45131J	PERG	1F	AE0301A	08	ALL	
AE0301A	14	W3170	LA2*	DISCONNECT BRACKET - E3-1							
D49994P	A07		2606B	20 X2	D40736P	1		AB0420A	02	ALL	
D49994P	B06		2606R	20 X2	D40736P	2		AB0420A	02	ALL	
D49994P	PERG	1F	2606Z		D40736P	S/R		AB0420A	02	ALL	
AE0301A	15	W0311	NA2	DISCONNECT BRACKET - E3-1							
D43145J	A03		0136	20 PA	D41817J	1		AE0301A	21	ALL	
D43145J	A04		0137	20 PA	D41817J	2		AE0301A	21	ALL	

SPARE WIRE LIST

D280A351

91-21-12

Section AE0301A

Page 2

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From Matewith	Pos	Bundle	Sep	Description		To				Pos	Effectivity
	From Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith		
I	AE0301A	15	W5161	LA2	DISCONNECT BRACKET - E3-1							
	D43145P	A05		0004	20	PA	D45245J	B15		AE0502A	14	YT101-YT103
I	D43145P	A05		0004	20	PA	D45245J	B15		AE0502A	02	YT104-YT133
	D43145P	A03		0027	20	PA	D45245J	B13		AE0502A	14	YT101-YT103
I	D43145P	A03		0027	20	PA	D45245J	B13		AE0502A	02	YT104-YT133
	D43145P	A04		0028	20	PA	D45245J	B14		AE0502A	14	YT101-YT103
I	D43145P	A04		0028	20	PA	D45245J	B14		AE0502A	02	YT104-YT133
I	D43145P	B01		0035	24	PK	D41145P	A04		AE0101A	04	ALL
I	D43145P	A17		0040	24	PK	D41155P	A17		AE0101A	20	ALL
I	AE0301A	16	W5161	LA2	DISCONNECT BRACKET - E3-1							
I	D43155P	B16		2511B	22	X2	D41145P	A03		AE0101A	04	ALL
I	D43155P	B15		2511R	22	X2	D41145P	A02		AE0101A	04	ALL
I	D43155P	PERG	1F	2511Z			D41145P	PERG	1F	AE0101A	04	ALL
	D43155P	B02		2518B	24	Y2	D45255J	B20		AE0502A	15	YT101-YT103
I	D43155P	B02		2518B	24	Y2	D45255J	B20		AE0502A	03	YT104-YT133
	D43155P	B01		2518R	24	Y2	D45255J	B19		AE0502A	15	YT101-YT103
I	D43155P	B01		2518R	24	Y2	D45255J	B19		AE0502A	03	YT104-YT133
	D43155P	PERG	1F	2518Z			D45255J	PERG	1F	AE0502A	15	YT101-YT103
I	D43155P	PERG	1F	2518Z			D45255J	PERG	1F	AE0502A	03	YT104-YT133
	D43155P	B10		2523B	24	Y2	D45265J	B02		AE0502A	16	YT101-YT103
I	D43155P	B10		2523B	24	Y2	D45265J	B02		AE0502A	04	YT104-YT133
	D43155P	B09		2523R	24	Y2	D45265J	B01		AE0502A	16	YT101-YT103
I	D43155P	B09		2523R	24	Y2	D45265J	B01		AE0502A	04	YT104-YT133
	D43155P	PERG	1F	2523Z			D45265J	PERG	1F	AE0502A	16	YT101-YT103
I	D43155P	PERG	1F	2523Z			D45265J	PERG	1F	AE0502A	04	YT104-YT133
I	AE0301A	18	W5205	SA2	DISCONNECT BRACKET - E3-1							
	D45205P	A05		0025	20	PA	D45209J	A05		AE0502A	03	YT101-YT103
I	D45205P	A05		0025	20	PA	D45209J	A05		AE0502A	01	YT104-YT133
	D45205P	B03		2001B	22	X2	D45209J	B03		AE0502A	03	YT101-YT103
I	D45205P	B03		2001B	22	X2	D45209J	B03		AE0502A	01	YT104-YT133
	D45205P	B02		2001R	22	X2	D45209J	B02		AE0502A	03	YT101-YT103
I	D45205P	B02		2001R	22	X2	D45209J	B02		AE0502A	01	YT104-YT133
	D45205P	PERG	1F	2001Z			D45209J	PERG	1F	AE0502A	03	YT101-YT103
I	D45205P	PERG	1F	2001Z			D45209J	PERG	1F	AE0502A	01	YT104-YT133
I	AE0301A	19	W5156	SA2*	DISCONNECT BRACKET - E3-1							
I	D40460P	B01		0668	22	PA	D40666P	20		AJ0022	03	ALL

SPARE WIRE LIST

D280A351

91-21-12

Section AE0301A

Page 3

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From Matewith	Pos	Bundle	Sep	Description		To				Pos	Effectivity
	From Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith		
I	AE0301A	21	W0311	NA2	DISCONNECT BRACKET - E3-1							
I	D41817J	1		0136	20	PA	D43145J	A03		AE0301A	15	ALL
I	D41817J	2		0137	20	PA	D43145J	A04		AE0301A	15	ALL
I	AE0301A	21	W2201	LA2	DISCONNECT BRACKET - E3-1							
I	D41817P	1		0001	20	PA	D41805P	1		AP1800B	01	ALL
I	D41817P	2		0002	20	PA	D41805P	2		AP1800B	01	ALL
I	D41817P	3		0003	20	PA	D41805P	3		AP1800B	01	ALL
I	D41817P	12		0010	20	PA	D41805P	10		AP1800B	01	ALL
I	D41817P	11		0011	20	PA	D41805P	11		AP1800B	01	ALL
I	D41817P	4		0019	16	PA	D41805P	19		AP1800B	01	ALL
I	D41817P	5		0021	20	PA	D41805P	21		AP1800B	01	ALL
I	AE0301A	22	W2653	SA2	DISCONNECT BRACKET - E3-1							
I	D41837P	1		0001	20	PA	D41809P	1		AP1800B	09	ALL
I	D41837P	2		0002	22	PA	D41809P	2		AP1800B	09	ALL
I	D41837P	7		0019	16	PA	D41809P	19		AP1800B	09	ALL
I	D41837P	10		0023	18	PA	D41809P	23		AP1800B	09	ALL
I	AE0301A	23	W2231	RB2	DISCONNECT BRACKET - E3-1							
I	D46017P	6		0006	20	PA	D46067P	6		AP0600B	10	ALL
I	D46017P	5		0007	20	PA	D46067P	7		AP0600B	10	ALL
I	D46017P	7		0027	16	PA	D46067P	27		AP0600B	10	ALL
I	D46017P	8		0028	20	PA	D46067P	28		AP0600B	10	ALL
I	AE0301A	24	W2169	RB2	DISCONNECT BRACKET - E3-1							
I	D46035P	1		0001	20	PA	D46063P	1		AP0600B	04	ALL
I	D46035P	2		0002	22	PA	D46063P	2		AP0600B	04	ALL
I	D46035P	3		0003	20	PA	D46063P	3		AP0600B	04	ALL
I	D46035P	9		0009	20	PA	D46063P	9		AP0600B	04	ALL
I	AE0301A	28	W5163	RB2*	DISCONNECT BRACKET - E3-1							
I	D43147P	A01		0021	20	PA	D45247J	A16		AE0502A	04	YT101-YT103
I	D43147P	A01		0021	20	PA	D45247J	A16		AE0502A	27	YT104-YT133
I	D43147P	A07		0040	24	PK	D41147P	A07		AE0101B	11	ALL
I	D43147P	A20		2529B	24	Y2	D41157P	B11		AE0101B	12	ALL
I	D43147P	A19		2529R	24	Y2	D41157P	B10		AE0101B	12	ALL
I	D43147P	PERG	1F	2529Z			D41157P	PERG	1F	AE0101B	12	ALL

SPARE WIRE LIST

D280A351

91-21-12

Section AE0301A

Page 4

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From Matewith	Pos	Bundle	Sep	Description		To					Pos	Effectivity	
	From Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith				
I	AE0301A	29	W5163	RB2*	DISCONNECT BRACKET - E3-1									
	D43157P	A20		0013	22	PA	D45247J	A08		AE0502A	04	YT101-YT103		
I	D43157P	A20		0013	22	PA	D45247J	A08		AE0502A	27	YT104-YT133		
	D43157P	A09		2508B	24	Y2	D45257J	A10		AE0502A	05	YT101-YT103		
I	D43157P	A09		2508B	24	Y2	D45257J	A10		AE0502A	28	YT104-YT133		
	D43157P	A08		2508R	24	Y2	D45257J	A09		AE0502A	05	YT101-YT103		
I	D43157P	A08		2508R	24	Y2	D45257J	A09		AE0502A	28	YT104-YT133		
	D43157P	PERG	1F	2508Z			D45257J	PERG	1F	AE0502A	05	YT101-YT103		
I	D43157P	PERG	1F	2508Z			D45257J	PERG	1F	AE0502A	28	YT104-YT133		
	D43157P	A11		2509B	24	Y2	D45257J	A12		AE0502A	05	YT101-YT103		
I	D43157P	A11		2509B	24	Y2	D45257J	A12		AE0502A	28	YT104-YT133		
	D43157P	A10		2509R	24	Y2	D45257J	A11		AE0502A	05	YT101-YT103		
I	D43157P	A10		2509R	24	Y2	D45257J	A11		AE0502A	28	YT104-YT133		
	D43157P	PERG	1F	2509Z			D45257J	PERG	1F	AE0502A	05	YT101-YT103		
I	D43157P	PERG	1F	2509Z			D45257J	PERG	1F	AE0502A	28	YT104-YT133		
I	AE0301A	31	W2237	NB2	DISCONNECT BRACKET - E3-1									
	D04297P	A13		0003	22	PA	D04237P	13		AP0900A	06	ALL		
I	D04297P	A14		0004	22	PA	D04237P	14		AP0900A	06	ALL		
I	D04297P	B09		0029	22	PA	D04237P	29		AP0900A	06	ALL		
I	D04297P	B10		0030	22	PA	D04237P	30		AP0900A	06	ALL		
I	D04297P	B11		0031	22	PA	D04237P	31		AP0900A	06	ALL		
I	D04297P	B12		0032	22	PA	D04237P	32		AP0900A	06	ALL		
I	D04297P	B17		0037	22	PA	D04237P	37		AP0900A	06	ALL		
I	D04297P	B18		0038	22	PA	D04237P	38		AP0900A	06	ALL		
I	D04297P	B19		0040	22	CQ	D04237P	40		AP0900A	06	ALL		
I	D04297P	B20		0041	22	CQ	D04237P	41		AP0900A	06	ALL		
I	D04297P	A06		2003B	24	Y2	D04237P	6		AP0900A	06	ALL		
I	D04297P	A05		2003R	24	Y2	D04237P	5		AP0900A	06	ALL		
I	D04297P	PERG	1F	2003Z			D04237P	S/R		AP0900A	06	ALL		
I	D04297P	A08		2004B	24	Y2	D04237P	8		AP0900A	06	ALL		
I	D04297P	A07		2004R	24	Y2	D04237P	7		AP0900A	06	ALL		
I	D04297P	PERG	1F	2004Z			D04237P	S/R		AP0900A	06	ALL		
I	D04297P	A16		2008B	24	Y2	D04237P	16		AP0900A	06	ALL		
I	D04297P	A15		2008R	24	Y2	D04237P	15		AP0900A	06	ALL		
I	D04297P	PERG	1F	2008Z			D04237P	S/R		AP0900A	06	ALL		
I	D04297P	A18		2009B	24	Y2	D04237P	18		AP0900A	06	ALL		
I	D04297P	A17		2009R	24	Y2	D04237P	17		AP0900A	06	ALL		
I	D04297P	PERG	1F	2009Z			D04237P	S/R		AP0900A	06	ALL		

SPARE WIRE LIST

D280A351

91-21-12

Section AE0301A

Page 5

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To						
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AE0301A	31	W2237	NB2	DISCONNECT BRACKET - E3-1 (continued)							
D04297P	A20		2010B	24 Y2	D04237P	20		AP0900A	06	ALL	
D04297P	A19		2010R	24 Y2	D04237P	19		AP0900A	06	ALL	
D04297P	PERG	1F	2010Z		D04237P	S/R		AP0900A	06	ALL	
D04297P	B02		2011B	24 Y2	D04237P	22		AP0900A	06	ALL	
D04297P	B01		2011R	24 Y2	D04237P	21		AP0900A	06	ALL	
D04297P	PERG	1F	2011Z		D04237P	S/R		AP0900A	06	ALL	
D04297P	B04		2012B	24 Y2	D04237P	24		AP0900A	06	ALL	
D04297P	B03		2012R	24 Y2	D04237P	23		AP0900A	06	ALL	
D04297P	PERG	1F	2012Z		D04237P	S/R		AP0900A	06	ALL	
AE0301A	32	W5121	NB2	DISCONNECT BRACKET - E3-1							
D45121P	B20		2021B	24 Y2	D45123J	45		AE0104A	12	ALL	
D45121P	A20		2021R	24 Y2	D45123J	44		AE0104A	12	ALL	
D45121P	PERG	1F	2021Z		D45123J	S/R		AE0104A	12	ALL	
AE0301A	33	W5121	NB2	DISCONNECT BRACKET - E3-1							
D45141P	B17		2042B	24 Y2	D43323P	B06		AE0303A	42	ALL	
D45141P	A17		2042R	24 Y2	D43323P	A06		AE0303A	42	ALL	
D45141P	PERG	1F	2042Z		D43323P	PERG	1F	AE0303A	42	ALL	
D45141P	B10		2051B	24 Y2	D43323P	B10		AE0303A	42	ALL	
D45141P	A10		2051R	24 Y2	D43323P	A10		AE0303A	42	ALL	
D45141P	PERG	1F	2051Z		D43323P	PERG	1F	AE0303A	42	ALL	
D45141P	B20		2063B	24 Y2	D43323P	B11		AE0303A	42	ALL	
D45141P	A20		2063R	24 Y2	D43323P	A11		AE0303A	42	ALL	
D45141P	PERG	1F	2063Z		D43323P	PERG	1F	AE0303A	42	ALL	
AE0301A	34	W6412	RB2*	DISCONNECT BRACKET - E3-1							
D40394P	A09		0508	20 PA	D41010P	2		AE0401A	33	ALL	
D40394P	A13		2608B	24 Y2	D40392P	A05		AE0302A	45	ALL	
D40394P	A14		2608R	24 Y2	D40392P	A06		AE0302A	45	ALL	
D40394P	PERG	1F	2608Z		D40392P	PERG	1F	AE0302A	45	ALL	
D40394P	A15		5535	20 PA	D40386P	29		AP0600B	14	ALL	
AE0301A	36	W4170	RA2*	DISCONNECT BRACKET - E3-1							
D40732P	A05		2605B	20 PB	D40730P	9		AB0405B	02	ALL	
D40732P	B05		2605R	20 PB	D40730P	10		AB0405B	02	ALL	
D40732P	A06		2606B	20 PB	D40730P	11		AB0405B	02	ALL	

SPARE WIRE LIST

D280A351

91-21-12

Section AE0301A

Page 6

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

From	Matewith	Pos	Bundle	Sep	Description		To					
Equip	Term	Type	Wire No.		GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity
AE0301A		36	W4170	RA2*	DISCONNECT BRACKET - E3-1 (continued)							
D40732P	B06		2606R		20	PB	D40730P	12		AB0405B	02	ALL
D40732P	A10		2609B		20	PB	D40728P	6		AB0405B	01	ALL
D40732P	B10		2609R		20	PB	D40728P	7		AB0405B	01	ALL
AE0301A		39	W5049	NB2	DISCONNECT BRACKET - E3-1							
D42049P	B04		2508B		24	Y2	D49001P	B04		AE0302A	63	YT104-YT133
D42049P	A04		2508R		24	Y2	D49001P	A04		AE0302A	63	YT104-YT133
D42049P	PERG	1F	2508Z				D49001P	PERG	1F	AE0302A	63	YT104-YT133

SPARE WIRE LIST

D280A351

91-21-12

Section AE0301A

Page 7 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From Matewith	Pos	Bundle	Sep	Description		To	Term	Type	Matewith	Pos	Effectivity	
	From Equip	Term	Type	Wire No.	GA	TY	Equip						
I	AE0302A	04	W5310	LB2*	DISCONNECT BRACKET - E3-2 SHELF								
I	D40446P	B10		5502	24	PK	D40450P	B06		AE0202A	24	ALL	
I	AE0302A	05	W5612	SN2*	DISCONNECT BRACKET - E3-2 SHELF								
I	D40362P	A01		0001	20	PA	D40358P	A01		AE0201A	18	ALL	
I	D40362P	A03		0554	24	PK	D40352P	21		AP0600B	16	ALL	
I	D40362P	B07		2207B	22	PB	D40358P	B08		AE0201A	18	ALL	
I	D40362P	A07		2207R	22	PB	D40358P	A04		AE0201A	18	ALL	
	AE0302A	09	W2805	NN2	DISCONNECT BRACKET - E3-2 SHELF								
	D43215P	B04		2503B	24	Y2	D02649	B		M02195		YT101-YT103	
	D43215P	A04		2503R	24	Y2	D02649	A		M02195		YT101-YT103	
	D43215P	PERG	1F	2503Z			D02649			M02195		YT101-YT103	
I	AE0302A	14	W5205	SA2	DISCONNECT BRACKET - E3-2 SHELF								
I	D45207P	A03		0053	20	CQ	D45201J	31		AE0102A	10	ALL	
I	AE0302A	16	W5156	SA2*	DISCONNECT BRACKET - E3-2 SHELF								
I	D40594P	A08		0660	20	CQ	D40666P	9		AJ0022	03	ALL	
I	D40594P	A02		0671	22	PA	D48114P	B07		AJ0048A	17	ALL	
I	D40594P	B02		0672	22	PA	D48114P	B08		AJ0048A	17	ALL	
I	D40594P	B01		0673	22	PA	D48114P	B09		AJ0048A	17	ALL	
I	D40594P	A01		0674	22	PA	D48114P	B10		AJ0048A	17	ALL	
I	AE0302A	17	W2805	NN2	DISCONNECT BRACKET - E3-2 SHELF								
I	D43215P	B04		2503B	24	Y2	D02649	B		M02195		YT104-YT133	
I	D43215P	A04		2503R	24	Y2	D02649	A		M02195		YT104-YT133	
I	D43215P	PERG	1F	2503Z			D02649			M02195		YT104-YT133	
	AE0302A	17	W5111	NA2	DISCONNECT BRACKET - E3-2 SHELF								
	D45177P	B05		2058B	24	Y2	D43307P	B10		AE0303A	12	YT101-YT103	
	D45177P	A05		2058R	24	Y2	D43307P	A10		AE0303A	12	YT101-YT103	
	D45177P	PERG	1F	2058Z			D43307P	PERG	1F	AE0303A	12	YT101-YT103	
	D45177P	B06		2059B	24	Y2	D43307P	B09		AE0303A	12	YT101-YT103	
	D45177P	A06		2059R	24	Y2	D43307P	A09		AE0303A	12	YT101-YT103	
	D45177P	PERG	1F	2059Z			D43307P	PERG	1F	AE0303A	12	YT101-YT103	

SPARE WIRE LIST

D280A351

91-21-12

Section AE0302A

Page 1

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From Matewith From	Pos	Bundle	Sep	Description		To						
	Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity	
I	AE0302A	18	W5111	NA2	DISCONNECT BRACKET - E3-2 SHELF								
	D45157P	A05		0030	20	CQ	D43307P	B16		AE0303A	12	YT101-YT103	
	D45157P	B05		0031	22	PA	D43307P	A17		AE0303A	12	YT101-YT103	
I	D45157P	A06		0032	22	PA	D43307P	B17		AE0303A	12	ALL	
I	D45157P	A03		0038	22	PA	D43307P	A14		AE0303A	12	ALL	
I	D45157P	B03		0039	22	PA	D43307P	B14		AE0303A	12	ALL	
I	D45157P	B15		2058B	24	Y2	D43307P	B10		AE0303A	12	YT104-YT133	
I	D45157P	A15		2058R	24	Y2	D43307P	A10		AE0303A	12	YT104-YT133	
I	D45157P	PERG	1F	2058Z			D43307P	PERG	1F	AE0303A	12	YT104-YT133	
I	D45157P	B16		2059B	24	Y2	D43307P	B09		AE0303A	12	YT104-YT133	
I	D45157P	A16		2059R	24	Y2	D43307P	A09		AE0303A	12	YT104-YT133	
I	D45157P	PERG	1F	2059Z			D43307P	PERG	1F	AE0303A	12	YT104-YT133	
I	D45157P	B08		2062B	24	Y2	D43307P	B04		AE0303A	12	ALL	
I	D45157P	A08		2062R	24	Y2	D43307P	A04		AE0303A	12	ALL	
I	D45157P	PERG	1F	2062Z			D43307P	PERG	1F	AE0303A	12	ALL	
I	D45157P	B09		2070B	24	Y2	D43307P	B18		AE0303A	12	ALL	
I	D45157P	A09		2070R	24	Y2	D43307P	A18		AE0303A	12	ALL	
I	D45157P	PERG	1F	2070Z			D43307P	PERG	1F	AE0303A	12	ALL	
I	D45157P	B07		2081B	24	Y2	D43307P	B05		AE0303A	12	ALL	
I	D45157P	A07		2081R	24	Y2	D43307P	A05		AE0303A	12	ALL	
I	D45157P	PERG	1F	2081Z			D43307P	PERG	1F	AE0303A	12	ALL	
I	AE0302A	20	W5111	NA2	DISCONNECT BRACKET - E3-2 SHELF								
I	D45117P	B13		2030B	22	X2	D45111P	B14		AE0301A	07	ALL	
I	D45117P	A13		2030R	22	X2	D45111P	A14		AE0301A	07	ALL	
I	D45117P	PERG	1F	2030Z			D45111P	PERG	1F	AE0301A	07	ALL	
I	D45117P	B17		2043B	24	Y2	D45111P	B18		AE0301A	07	ALL	
I	D45117P	A17		2043R	24	Y2	D45111P	A18		AE0301A	07	ALL	
I	D45117P	PERG	1F	2043Z			D45111P	PERG	1F	AE0301A	07	ALL	
I	AE0302A	25	W2231	RB2	DISCONNECT BRACKET - E3-2 SHELF								
	D46021P	9		0009	20	PA	D46067P	9		AP0600B	10	YT101-YT103	
I	D46021P	A09		0009	20	PA	D46067P	9		AP0600B	10	YT104-YT133	
	D46021P	1		0010	20	PA	D46067P	10		AP0600B	10	YT101-YT103	
I	D46021P	A01		0010	20	PA	D46067P	10		AP0600B	10	YT104-YT133	
	D46021P	2		0011	20	PA	D46067P	11		AP0600B	10	YT101-YT103	
I	D46021P	A02		0011	20	PA	D46067P	11		AP0600B	10	YT104-YT133	
	D46021P	3		0012	20	PA	D46067P	12		AP0600B	10	YT101-YT103	
I	D46021P	A03		0012	20	PA	D46067P	12		AP0600B	10	YT104-YT133	

SPARE WIRE LIST

D280A351

91-21-12

Section AE0302A

Page 2

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

From	Matewith	Pos	Bundle	Sep	Description		To	Term	Type	Matewith	Pos	Effectivity
Equip		Term	Type	Wire No.	GA	TY	Equip					
I	AE0302A	26	W2653	SA2	DISCONNECT BRACKET - E3-2 SHELF							
	D41839P	1		0011	20	PA	D41809P	11		AP1800B	09	YT101-YT103
I	D41839P	A01		0011	20	PA	D41809P	11		AP1800B	09	YT104-YT133
	D41839P	2		0012	20	PA	D41809P	12		AP1800B	09	YT101-YT103
I	D41839P	A02		0012	20	PA	D41809P	12		AP1800B	09	YT104-YT133
I	AE0302A	27	W2201	LA2	DISCONNECT BRACKET - E3-2 SHELF							
I	D41819P	13		0013	20	PA	D41805P	13		AP1800B	01	ALL
I	D41819P	16		0016	20	PA	D41805P	16		AP1800B	01	ALL
I	D41819P	17		0017	20	PA	D41805P	17		AP1800B	01	ALL
I	D41819P	18		0018	20	PA	D41805P	18		AP1800B	01	ALL
I	AE0302A	28	W5158	SB2*	DISCONNECT BRACKET - E3-2 SHELF							
	D40426P	8		0545	20	CQ	D40702P	13		AJ0024	06	YT101-YT103
I	D40426P	A08		0545	20	CQ	D40702P	13		AJ0024	06	YT104-YT133
	D40426P	14		0634	20	PA	D40490J	21		AE0104A	20	YT101-YT103
I	D40426P	B03		0634	20	PA	D40490J	21		AE0104A	20	YT104-YT133
	D40426P	7		0682	20	CQ	D40702P	21		AJ0024	06	YT101-YT103
I	D40426P	A07		0682	20	CQ	D40702P	21		AJ0024	06	YT104-YT133
I	AE0302A	30	W2169	RB2	DISCONNECT BRACKET - E3-2 SHELF							
	D46043P	11		0011	20	PA	D46063P	11		AP0600B	04	YT101-YT103
I	D46043P	B01		0011	20	PA	D46063P	11		AP0600B	04	YT104-YT133
	D46043P	12		0012	20	CQ	D46063P	12		AP0600B	04	YT101-YT103
I	D46043P	B02		0012	20	CQ	D46063P	12		AP0600B	04	YT104-YT133
I	AE0302A	35	W3379	RB3	DISCONNECT BRACKET - E3-2 SHELF							
I	D40029P	A09		0002	20	CQ	D43399P	2		AB1050R	04	ALL
I	D40029P	B02		2010B	22	X2	D43399P	37		AB1050R	04	ALL
I	D40029P	B01		2010R	22	X2	D43399P	36		AB1050R	04	ALL
I	D40029P	PERG	1F	2010Z			D43399P	S/R		AB1050R	04	ALL
I	D40029P	B09		3007B	22	X3	D43399P	44		AB1050R	04	ALL
I	D40029P	B08		3007R	22	X3	D43399P	43		AB1050R	04	ALL
I	D40029P	B10		3007Y	22	X3	D43399P	45		AB1050R	04	ALL
I	D40029P	PERG	1F	3007Z			D43399P	S/R		AB1050R	04	ALL
I	AE0302A	37	W5160	RB2*	DISCONNECT BRACKET - E3-2 SHELF							
I	D40470P	A01		0656	24	PK	D40466P	27		AE0103A	14	ALL

SPARE WIRE LIST

D280A351

91-21-12

Section AE0302A

Page 3

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AE0302A	37	W5160	RB2*	DISCONNECT BRACKET - E3-2 SHELF (continued)								
D40470P	A06		0657	24 PK	D40466P	28		AE0103A	14	ALL		
D40470P	B07		2461B	24 Y2	D40466P	30		AE0103A	14	ALL		
D40470P	B06		2461R	24 Y2	D40466P	29		AE0103A	14	ALL		
D40470P	PERG	1F	2461Z		D40466P	31		AE0103A	14	ALL		
AE0302A	40	W5461	LA2	DISCONNECT BRACKET - E3-2 SHELF								
D43261P	B10		2032B	24 Y2	D45261J	B10		AE0502A	18	YT101-YT103		
D43261P	B10		2032B	24 Y2	D45261J	B10		AE0502A	06	YT104-YT133		
D43261P	B09		2032R	24 Y2	D45261J	B09		AE0502A	18	YT101-YT103		
D43261P	B09		2032R	24 Y2	D45261J	B09		AE0502A	06	YT104-YT133		
D43261P	PERG	1F	2032Z		D45261J	PERG	1F	AE0502A	18	YT101-YT103		
D43261P	PERG	1F	2032Z		D45261J	PERG	1F	AE0502A	06	YT104-YT133		
AE0302A	41	W5461	LA2	DISCONNECT BRACKET - E3-2 SHELF								
D42261P	B10		0059	24 PK	D41561J	B14		AE0502A	17	YT101-YT103		
D42261P	B10		0059	24 PK	D41561J	B14		AE0502A	05	YT104-YT133		
D42261P	B05		0071	24 PK	D41561J	A16		AE0502A	17	YT101-YT103		
D42261P	B05		0071	24 PK	D41561J	A16		AE0502A	05	YT104-YT133		
D42261P	B12		2103B	24 Y2	D42311P	A10		AE0101A	06	ALL		
D42261P	B11		2103R	24 Y2	D42311P	A09		AE0101A	06	ALL		
D42261P	PERG	1F	2103Z		D42311P	PERG	1F	AE0101A	06	ALL		
AE0302A	42	W5160	RB2*	DISCONNECT BRACKET - E3-2 SHELF								
D40952P	A05		0620	20 PA	D40694P	31		AJ0024	07	ALL		
AE0302A	43	W5461	LA2	DISCONNECT BRACKET - E3-2 SHELF								
D42361P	B11		0045	24 PK	D43211P	B15		AE0101A	21	ALL		
D42361P	B06		0057	24 PK	D44161P	B04		AE0401A	24	ALL		
D42361P	A06		0058	24 PK	D44161P	A06		AE0401A	24	ALL		
D42361P	A14		0073	24 PK	D43211P	A14		AE0101A	21	ALL		
D42361P	B13		0074	24 PK	D43211P	B13		AE0101A	21	ALL		
AE0302A	44	W5463	RB2	DISCONNECT BRACKET - E3-2 SHELF								
D43263P	A13	VP	0055	20 PA	D41563P	A03		AE0101B	01	ALL		
D43263P	B14		2019B	24 Y2	D45263J	B14		AE0502A	06	YT101-YT103		
D43263P	B14		2019B	24 Y2	D45263J	B14		AE0502A	29	YT104-YT133		
D43263P	A14		2019R	24 Y2	D45263J	A14		AE0502A	06	YT101-YT103		

SPARE WIRE LIST

D280A351

91-21-12

Section AE0302A

Page 4

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To						
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AE0302A	44	W5463	RB2	DISCONNECT BRACKET - E3-2 SHELF (continued)							
D43263P	A14		2019R	24 Y2	D45263J	A14		AE0502A	29	YT104-YT133	
D43263P	PERG	1F	2019Z		D45263J	PERG	1F	AE0502A	06	YT101-YT103	
D43263P	PERG	1F	2019Z		D45263J	PERG	1F	AE0502A	29	YT104-YT133	
AE0302A	45	W6412	RB2*	DISCONNECT BRACKET - E3-2 SHELF							
D40392P	B18		2001B	24 Y2	D40390P	A06		AE0401A	52	ALL	
D40392P	B17		2001R	24 Y2	D40390P	A05		AE0401A	52	ALL	
D40392P	PERG	1F	2001Z		D40390P	PERG	1F	AE0401A	52	ALL	
D40392P	A05		2608B	24 Y2	D40394P	A13		AE0301A	34	ALL	
D40392P	A06		2608R	24 Y2	D40394P	A14		AE0301A	34	ALL	
D40392P	PERG	1F	2608Z		D40394P	PERG	1F	AE0301A	34	ALL	
D40392P	B03		5504	24 PK	D40390P	B03		AE0401A	52	ALL	
D40392P	A14		5529	20 PA	D40390P	A17		AE0401A	52	ALL	
D40392P	A18		5534	20 PA	D40386P	23		AP0600B	14	ALL	
AE0302A	46	W5121	NB2	DISCONNECT BRACKET - E3-2 SHELF							
D45127P	B03		0013	24 PK	D45123J	7		AE0104A	12	ALL	
AE0302A	47	W5375	RD3	DISCONNECT BRACKET - E3-2 SHELF							
D42053P	A10		0011	20 PA	D04077J	29		AE0104A	15	ALL	
AE0302A	53	W5463	RB2	DISCONNECT BRACKET - E3-2 SHELF							
D42363P	A03		0030	24 PK	D41463J	44		AE0104A	11	ALL	
D42363P	B03		0031	24 PK	D41463J	45		AE0104A	11	ALL	
D42363P	A10		2022B	24 Y2	D45263J	A20		AE0502A	29	YT104-YT105	
D42363P	A09		2022R	24 Y2	D45263J	A19		AE0502A	29	YT104-YT105	
D42363P	PERG	1F	2022Z		D45263J	PERG	1F	AE0502A	29	YT104-YT105	
AE0302A	56	W5121	NB2	DISCONNECT BRACKET - E3-2 SHELF							
D45147P	B17		2056B	24 Y2	D43323P	B17		AE0303A	42	ALL	
D45147P	A17		2056R	24 Y2	D43323P	A17		AE0303A	42	ALL	
D45147P	PERG	1F	2056Z		D43323P	PERG	1F	AE0303A	42	ALL	
D45147P	B20		2065B	24 Y2	D43323P	B20		AE0303A	42	ALL	
D45147P	A20		2065R	24 Y2	D43323P	A20		AE0303A	42	ALL	
D45147P	PERG	1F	2065Z		D43323P	PERG	1F	AE0303A	42	ALL	

SPARE WIRE LIST

D280A351

91-21-12

Section AE0302A

Page 5

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From	Matewith	Pos	Bundle	Sep	Description						Pos	Effectivity	
	Equip		Term	Type	Wire No.	GA	TY	To	Equip	Term	Type			Matewith
I	AE0302A		63	W5049	NB2	DISCONNECT BRACKET - E3-2 SHELF								
I	D49001P		B04		2508B	24	Y2	D42049P	B04			AE0301A	39	YT104-YT133
I	D49001P		A04		2508R	24	Y2	D42049P	A04			AE0301A	39	YT104-YT133
I	D49001P		PERG	1F	2508Z			D42049P	PERG	1F		AE0301A	39	YT104-YT133

SPARE WIRE LIST

D280A351

91-21-12

Section AE0302A

Page 6 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To						
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AE0303A	05	W5723	RB2*	DISCONNECT BRACKET - E3-3 SHELF							
D43306P	B03		2511B	24 Y2	D41131P	35		AE0103A	22	YT101-YT103	
D43306P	A03		2511R	24 Y2	D41131P	34		AE0103A	22	YT101-YT103	
D43306P	PERG	1F	2511Z		D41131P	36		AE0103A	22	YT101-YT103	
D43306P	B04		2512B	24 Y2	D41213J	4		AE0102A	12	YT101-YT103	
D43306P	A04		2512R	24 Y2	D41213J	3		AE0102A	12	YT101-YT103	
D43306P	PERG	1F	2512Z		D41213J	S/R		AE0102A	12	YT101-YT103	
AE0303A	10	W5105	RB2	DISCONNECT BRACKET - E3-3 SHELF							
D43361P	B06		2503B	24 Y2	D40115P	B04		AE0602A	08	YT101-YT103	
D43361P	A06		2503R	24 Y2	D40115P	A04		AE0602A	08	YT101-YT103	
D43361P	PERG	1F	2503Z		D40115P	PERG	1F	AE0602A	08	YT101-YT103	
D43361P	B05		2505B	24 Y2	D40115P	B07		AE0602A	08	YT101-YT103	
D43361P	A05		2505R	24 Y2	D40115P	A07		AE0602A	08	YT101-YT103	
D43361P	PERG	1F	2505Z		D40115P	PERG	1F	AE0602A	08	YT101-YT103	
I AE0303A	12	W5111	NA2	DISCONNECT BRACKET - E3-3 SHELF							
D43307P	B16		0030	20 CQ	D45157P	A05		AE0302A	18	YT101-YT103	
D43307P	A17		0031	22 PA	D45157P	B05		AE0302A	18	YT101-YT103	
I D43307P	B17		0032	22 PA	D45157P	A06		AE0302A	18	ALL	
I D43307P	A14		0038	22 PA	D45157P	A03		AE0302A	18	ALL	
I D43307P	B14		0039	22 PA	D45157P	B03		AE0302A	18	ALL	
D43307P	B10		2058B	24 Y2	D45177P	B05		AE0302A	17	YT101-YT103	
I D43307P	B10		2058B	24 Y2	D45157P	B15		AE0302A	18	YT104-YT133	
D43307P	A10		2058R	24 Y2	D45177P	A05		AE0302A	17	YT101-YT103	
I D43307P	A10		2058R	24 Y2	D45157P	A15		AE0302A	18	YT104-YT133	
D43307P	PERG	1F	2058Z		D45177P	PERG	1F	AE0302A	17	YT101-YT103	
I D43307P	PERG	1F	2058Z		D45157P	PERG	1F	AE0302A	18	YT104-YT133	
D43307P	B09		2059B	24 Y2	D45177P	B06		AE0302A	17	YT101-YT103	
I D43307P	B09		2059B	24 Y2	D45157P	B16		AE0302A	18	YT104-YT133	
D43307P	A09		2059R	24 Y2	D45177P	A06		AE0302A	17	YT101-YT103	
I D43307P	A09		2059R	24 Y2	D45157P	A16		AE0302A	18	YT104-YT133	
D43307P	PERG	1F	2059Z		D45177P	PERG	1F	AE0302A	17	YT101-YT103	
I D43307P	PERG	1F	2059Z		D45157P	PERG	1F	AE0302A	18	YT104-YT133	
I D43307P	B04		2062B	24 Y2	D45157P	B08		AE0302A	18	ALL	
I D43307P	A04		2062R	24 Y2	D45157P	A08		AE0302A	18	ALL	
I D43307P	PERG	1F	2062Z		D45157P	PERG	1F	AE0302A	18	ALL	
I D43307P	B18		2070B	24 Y2	D45157P	B09		AE0302A	18	ALL	
I D43307P	A18		2070R	24 Y2	D45157P	A09		AE0302A	18	ALL	

SPARE WIRE LIST

D280A351

91-21-12

Section AE0303A

Page 1

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AE0303A	12	W5111	NA2	DISCONNECT BRACKET - E3-3 SHELF (continued)								
D43307P	PERG	1F	2070Z		D45157P	PERG	1F	AE0302A	18	ALL		
D43307P	B05		2081B	24 Y2	D45157P	B07		AE0302A	18	ALL		
D43307P	A05		2081R	24 Y2	D45157P	A07		AE0302A	18	ALL		
D43307P	PERG	1F	2081Z		D45157P	PERG	1F	AE0302A	18	ALL		
AE0303A	13	W5111	NA2	DISCONNECT BRACKET - E3-3 SHELF								
D43321P	B06		2067B	24 Y2	D45211J	B07		AE0502A	12	ALL		
D43321P	A06		2067R	24 Y2	D45211J	A07		AE0502A	12	ALL		
D43321P	PERG	1F	2067Z		D45211J	PERG	1F	AE0502A	12	ALL		
D43321P	B19		2071B	22 X2	D45211J	B19		AE0502A	12	ALL		
D43321P	A19		2071R	22 X2	D45211J	A19		AE0502A	12	ALL		
D43321P	PERG	1F	2071Z		D45211J	PERG	1F	AE0502A	12	ALL		
D43321P	B04		2079B	24 Y2	D45211J	B14		AE0502A	12	ALL		
D43321P	A04		2079R	24 Y2	D45211J	A14		AE0502A	12	ALL		
D43321P	PERG	1F	2079Z		D45211J	PERG	1F	AE0502A	12	ALL		
D43321P	B05		2080B	24 Y2	D45211J	B15		AE0502A	12	ALL		
D43321P	A05		2080R	24 Y2	D45211J	A15		AE0502A	12	ALL		
D43321P	PERG	1F	2080Z		D45211J	PERG	1F	AE0502A	12	ALL		
D43321P	B10		2082B	24 Y2	D45211J	B02		AE0502A	12	ALL		
D43321P	A10		2082R	24 Y2	D45211J	A02		AE0502A	12	ALL		
D43321P	PERG	1F	2082Z		D45211J	PERG	1F	AE0502A	12	ALL		
D43321P	B01		2083B	24 Y2	D45211J	B03		AE0502A	12	ALL		
D43321P	A01		2083R	24 Y2	D45211J	A03		AE0502A	12	ALL		
D43321P	PERG	1F	2083Z		D45211J	PERG	1F	AE0502A	12	ALL		
D43321P	B02		2084B	24 Y2	D45211J	B04		AE0502A	12	ALL		
D43321P	A02		2084R	24 Y2	D45211J	A04		AE0502A	12	ALL		
D43321P	PERG	1F	2084Z		D45211J	PERG	1F	AE0502A	12	ALL		
D43321P	B03		2085B	24 Y2	D45211J	B05		AE0502A	12	ALL		
D43321P	A03		2085R	24 Y2	D45211J	A05		AE0502A	12	ALL		
D43321P	PERG	1F	2085Z		D45211J	PERG	1F	AE0502A	12	ALL		
AE0303A	17	W5331	NA2	DISCONNECT BRACKET - E3-3 SHELF								
D43345P	B07		2501B	24 Y2	D04115P	B07		AE0401A	14	ALL		
D43345P	A07		2501R	24 Y2	D04115P	A07		AE0401A	14	ALL		
D43345P	PERG	1F	2501Z		D04115P	PERG	1F	AE0401A	14	ALL		
D43345P	B09		2503B	24 Y2	D04115P	B09		AE0401A	14	YT126-YT133		
D43345P	A09		2503R	24 Y2	D04115P	A09		AE0401A	14	YT126-YT133		
D43345P	PERG	1F	2503Z		D04115P	PERG	1F	AE0401A	14	YT126-YT133		

SPARE WIRE LIST

D280A351

91-21-12

Section AE0303A

Page 2

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To						
Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity
AE0303A	17	W5331	NA2	DISCONNECT BRACKET - E3-3 SHELF (continued)							
D43345P	B10		2504B	24	Y2	D04115P	B10		AE0401A	14	ALL
D43345P	A10		2504R	24	Y2	D04115P	A10		AE0401A	14	ALL
D43345P	PERG	1F	2504Z			D04115P	PERG	1F	AE0401A	14	ALL
D43345P	B06		2505B	24	Y2	D04115P	B06		AE0401A	14	ALL
D43345P	A06		2505R	24	Y2	D04115P	A06		AE0401A	14	ALL
D43345P	PERG	1F	2505Z			D04115P	PERG	1F	AE0401A	14	ALL
D43345P	B05		2506B	24	Y2	D04115P	B05		AE0401A	14	ALL
D43345P	A05		2506R	24	Y2	D04115P	A05		AE0401A	14	ALL
D43345P	PERG	1F	2506Z			D04115P	PERG	1F	AE0401A	14	ALL
D43345P	B04		2507B	24	Y2	D04115P	B04		AE0401A	14	ALL
D43345P	A04		2507R	24	Y2	D04115P	A04		AE0401A	14	ALL
D43345P	PERG	1F	2507Z			D04115P	PERG	1F	AE0401A	14	ALL
D43345P	B11		2508B	24	Y2	D04115P	B11		AE0401A	14	YT126-YT133
D43345P	A11		2508R	24	Y2	D04115P	A11		AE0401A	14	YT126-YT133
D43345P	PERG	1F	2508Z			D04115P	PERG	1F	AE0401A	14	YT126-YT133
D43345P	B14		2511B	24	Y2	D04115P	B14		AE0401A	14	ALL
D43345P	A14		2511R	24	Y2	D04115P	A14		AE0401A	14	ALL
D43345P	PERG	1F	2511Z			D04115P	PERG	1F	AE0401A	14	ALL
D43345P	B16		2524B	24	Y2	D04115P	B16		AE0401A	14	YT126-YT133
D43345P	A16		2524R	24	Y2	D04115P	A16		AE0401A	14	YT126-YT133
D43345P	PERG	1F	2524Z			D04115P	PERG	1F	AE0401A	14	YT126-YT133
D43345P	B01		2527B	24	Y2	D04115P	B01		AE0401A	14	YT126-YT133
D43345P	A01		2527R	24	Y2	D04115P	A01		AE0401A	14	YT126-YT133
D43345P	PERG	1F	2527Z			D04115P	PERG	1F	AE0401A	14	YT126-YT133
D43345P	B02		2528B	24	Y2	D04115P	B02		AE0401A	14	ALL
D43345P	A02		2528R	24	Y2	D04115P	A02		AE0401A	14	ALL
D43345P	PERG	1F	2528Z			D04115P	PERG	1F	AE0401A	14	ALL
D43345P	B03		2532B	24	Y2	D04115P	B03		AE0401A	14	ALL
D43345P	A03		2532R	24	Y2	D04115P	A03		AE0401A	14	ALL
D43345P	PERG	1F	2532Z			D04115P	PERG	1F	AE0401A	14	ALL
AE0303A	18	W5331	NA2	DISCONNECT BRACKET - E3-3 SHELF							
D43347P	A05		0022	24	PK	D04117P	A05		AE0401A	15	ALL
D43347P	B05		0023	24	PK	D04117P	B05		AE0401A	15	ALL
D43347P	A06		0024	24	PK	D04117P	A06		AE0401A	15	ALL
D43347P	B06		0025	24	PK	D04117P	B06		AE0401A	15	ALL
D43347P	B10		2516B	24	Y2	D04117P	B10		AE0401A	15	ALL
D43347P	A10		2516R	24	Y2	D04117P	A10		AE0401A	15	ALL

SPARE WIRE LIST

D280A351

91-21-12

Section AE0303A

Page 3

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AE0303A	18	W5331	NA2	DISCONNECT BRACKET - E3-3 SHELF (continued)								
D43347P	PERG	1F	2516Z		D04117P	PERG	1F	AE0401A	15	ALL		
D43347P	B14		2520B	24 Y2	D04117P	B14		AE0401A	15	ALL		
D43347P	A14		2520R	24 Y2	D04117P	A14		AE0401A	15	ALL		
D43347P	PERG	1F	2520Z		D04117P	PERG	1F	AE0401A	15	ALL		
D43347P	B15		2521B	24 Y2	D04117P	B15		AE0401A	15	ALL		
D43347P	A15		2521R	24 Y2	D04117P	A15		AE0401A	15	ALL		
D43347P	PERG	1F	2521Z		D04117P	PERG	1F	AE0401A	15	ALL		
D43347P	B16		2522B	24 Y2	D04117P	B16		AE0401A	15	ALL		
D43347P	A16		2522R	24 Y2	D04117P	A16		AE0401A	15	ALL		
D43347P	PERG	1F	2522Z		D04117P	PERG	1F	AE0401A	15	ALL		
D43347P	B20		2561B	24 M5	D04117P	B20		AE0401A	15	ALL		
D43347P	A20		2561R	24 M5	D04117P	A20		AE0401A	15	ALL		
D43347P	A19		2561ZI		D04117P	A19		AE0401A	15	ALL		
D43347P	PERG	1F	2561ZO		D04117P	PERG	1F	AE0401A	15	ALL		
AE0303A	20	W5111	NA2	DISCONNECT BRACKET - E3-3 SHELF								
D43305P	B07		2056B	24 Y2	D45151P	B07		AE0301A	09	ALL		
D43305P	A07		2056R	24 Y2	D45151P	A07		AE0301A	09	ALL		
D43305P	PERG	1F	2056Z		D45151P	PERG	1F	AE0301A	09	ALL		
D43305P	B08		2057B	24 Y2	D45151P	B05		AE0301A	09	ALL		
D43305P	A08		2057R	24 Y2	D45151P	A05		AE0301A	09	ALL		
D43305P	PERG	1F	2057Z		D45151P	PERG	1F	AE0301A	09	ALL		
AE0303A	28	W2201	LA2	DISCONNECT BRACKET - E3-3 SHELF								
D43313P	6		0026	22 CQ	D41805P	26		AP1800B	01	YT101-YT103		
D43313P	2		0026	22 CQ	D41805P	26		AP1800B	01	YT104-YT120		
D43313P	2		0026	22 PA	D41805P	26		AP1800B	01	YT126-YT133		
AE0303A	29	W2231	RB2	DISCONNECT BRACKET - E3-3 SHELF								
D43309P	7		0019	16 CQ	D46067P	19		AP0600B	10	YT101-YT103		
AE0303A	34	W5105	NB2	DISCONNECT BRACKET - E3-3 SHELF								
D43361P	B06		2503B	24 Y2	D40115P	B04		AE0602A	08	YT107-YT133		
D43361P	A06		2503R	24 Y2	D40115P	A04		AE0602A	08	YT107-YT133		
D43361P	PERG	1F	2503Z		D40115P	PERG	1F	AE0602A	08	YT107-YT133		
D43361P	B05		2505B	24 Y2	D40115P	B07		AE0602A	08	YT107-YT133		
D43361P	A05		2505R	24 Y2	D40115P	A07		AE0602A	08	YT107-YT133		

SPARE WIRE LIST

D280A351

91-21-12

Section AE0303A

Page 4

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

From Matewith From Equip	Pos Term	Bundle Type	Sep Wire No.	Description GA TY	To Equip	Term	Type	Matewith	Pos	Effectivity
AE0303A	34	W5105	NB2	DISCONNECT BRACKET - E3-3 SHELF (continued)						
D43361P	PERG	1F	2505Z		D40115P	PERG	1F	AE0602A	08	YT107-YT133
D43361P	B06		2503B	24 Y2	D40115P	B04		AE0602A	08	YT104-YT106
D43361P	A06		2503R	24 Y2	D40115P	A04		AE0602A	08	YT104-YT106
D43361P	PERG	1F	2503Z		D40115P	PERG	1F	AE0602A	08	YT104-YT106
D43361P	B05		2505B	24 Y2	D40115P	B07		AE0602A	08	YT104-YT106
D43361P	A05		2505R	24 Y2	D40115P	A07		AE0602A	08	YT104-YT106
D43361P	PERG	1F	2505Z		D40115P	PERG	1F	AE0602A	08	YT104-YT106
AE0303A	42	W5121	NB2	DISCONNECT BRACKET - E3-3 SHELF						
D43323P	B06		2042B	24 Y2	D45141P	B17		AE0301A	33	ALL
D43323P	A06		2042R	24 Y2	D45141P	A17		AE0301A	33	ALL
D43323P	PERG	1F	2042Z		D45141P	PERG	1F	AE0301A	33	ALL
D43323P	B10		2051B	24 Y2	D45141P	B10		AE0301A	33	ALL
D43323P	A10		2051R	24 Y2	D45141P	A10		AE0301A	33	ALL
D43323P	PERG	1F	2051Z		D45141P	PERG	1F	AE0301A	33	ALL
D43323P	B01		2053B	24 Y2	D45213J	B03		AE0502A	11	YT101-YT103
D43323P	B01		2053B	24 Y2	D45213J	B03		AE0502A	26	YT104-YT133
D43323P	A01		2053R	24 Y2	D45213J	A03		AE0502A	11	YT101-YT103
D43323P	A01		2053R	24 Y2	D45213J	A03		AE0502A	26	YT104-YT133
D43323P	PERG	1F	2053Z		D45213J	PERG	1F	AE0502A	11	YT101-YT103
D43323P	PERG	1F	2053Z		D45213J	PERG	1F	AE0502A	26	YT104-YT133
D43323P	B02		2054B	24 Y2	D45213J	B04		AE0502A	11	YT101-YT103
D43323P	B02		2054B	24 Y2	D45213J	B04		AE0502A	26	YT104-YT133
D43323P	A02		2054R	24 Y2	D45213J	A04		AE0502A	11	YT101-YT103
D43323P	A02		2054R	24 Y2	D45213J	A04		AE0502A	26	YT104-YT133
D43323P	PERG	1F	2054Z		D45213J	PERG	1F	AE0502A	11	YT101-YT103
D43323P	PERG	1F	2054Z		D45213J	PERG	1F	AE0502A	26	YT104-YT133
D43323P	B03		2055B	24 Y2	D45213J	B05		AE0502A	11	YT101-YT103
D43323P	B03		2055B	24 Y2	D45213J	B05		AE0502A	26	YT104-YT133
D43323P	A03		2055R	24 Y2	D45213J	A05		AE0502A	11	YT101-YT103
D43323P	A03		2055R	24 Y2	D45213J	A05		AE0502A	26	YT104-YT133
D43323P	PERG	1F	2055Z		D45213J	PERG	1F	AE0502A	11	YT101-YT103
D43323P	PERG	1F	2055Z		D45213J	PERG	1F	AE0502A	26	YT104-YT133
D43323P	B17		2056B	24 Y2	D45147P	B17		AE0302A	56	ALL
D43323P	A17		2056R	24 Y2	D45147P	A17		AE0302A	56	ALL
D43323P	PERG	1F	2056Z		D45147P	PERG	1F	AE0302A	56	ALL
D43323P	B12		2057B	24 Y2	D45213J	B12		AE0502A	11	YT101-YT103
D43323P	B12		2057B	24 Y2	D45213J	B12		AE0502A	26	YT104-YT133

SPARE WIRE LIST

D280A351

91-21-12

Section AE0303A

Page 5

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To						
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AE0303A	42	W5121	NB2	DISCONNECT BRACKET - E3-3 SHELF (continued)							
I D43323P	A12		2057R	24 Y2	D45213J	A12		AE0502A	11	YT101-YT103	
I D43323P	A12		2057R	24 Y2	D45213J	A12		AE0502A	26	YT104-YT133	
I D43323P	PERG	1F	2057Z		D45213J	PERG	1F	AE0502A	11	YT101-YT103	
I D43323P	PERG	1F	2057Z		D45213J	PERG	1F	AE0502A	26	YT104-YT133	
I D43323P	B13		2058B	24 Y2	D45213J	B13		AE0502A	11	YT101-YT103	
I D43323P	B13		2058B	24 Y2	D45213J	B13		AE0502A	26	YT104-YT133	
I D43323P	A13		2058R	24 Y2	D45213J	A13		AE0502A	11	YT101-YT103	
I D43323P	A13		2058R	24 Y2	D45213J	A13		AE0502A	26	YT104-YT133	
I D43323P	PERG	1F	2058Z		D45213J	PERG	1F	AE0502A	11	YT101-YT103	
I D43323P	PERG	1F	2058Z		D45213J	PERG	1F	AE0502A	26	YT104-YT133	
I D43323P	B15		2061B	24 Y2	D45213J	B15		AE0502A	11	YT101-YT103	
I D43323P	B15		2061B	24 Y2	D45213J	B15		AE0502A	26	YT104-YT133	
I D43323P	A15		2061R	24 Y2	D45213J	A15		AE0502A	11	YT101-YT103	
I D43323P	A15		2061R	24 Y2	D45213J	A15		AE0502A	26	YT104-YT133	
I D43323P	PERG	1F	2061Z		D45213J	PERG	1F	AE0502A	11	YT101-YT103	
I D43323P	PERG	1F	2061Z		D45213J	PERG	1F	AE0502A	26	YT104-YT133	
I D43323P	B11		2063B	24 Y2	D45141P	B20		AE0301A	33	ALL	
I D43323P	A11		2063R	24 Y2	D45141P	A20		AE0301A	33	ALL	
I D43323P	PERG	1F	2063Z		D45141P	PERG	1F	AE0301A	33	ALL	
I D43323P	B16		2064B	24 Y2	D45213J	B16		AE0502A	11	YT101-YT103	
I D43323P	B16		2064B	24 Y2	D45213J	B16		AE0502A	26	YT104-YT133	
I D43323P	A16		2064R	24 Y2	D45213J	A16		AE0502A	11	YT101-YT103	
I D43323P	A16		2064R	24 Y2	D45213J	A16		AE0502A	26	YT104-YT133	
I D43323P	PERG	1F	2064Z		D45213J	PERG	1F	AE0502A	11	YT101-YT103	
I D43323P	PERG	1F	2064Z		D45213J	PERG	1F	AE0502A	26	YT104-YT133	
I D43323P	B20		2065B	24 Y2	D45147P	B20		AE0302A	56	ALL	
I D43323P	A20		2065R	24 Y2	D45147P	A20		AE0302A	56	ALL	
I D43323P	PERG	1F	2065Z		D45147P	PERG	1F	AE0302A	56	ALL	
AE0303A	43	W5335	NB2	DISCONNECT BRACKET - E3-3 SHELF							
I D43379P	A01		0001	22 PA	D04007P	A01		AE0401A	32	ALL	
I D43379P	A02		0003	22 PA	D04007P	A02		AE0401A	32	ALL	
I D43379P	B02		0004	22 PA	D04007P	B02		AE0401A	32	ALL	
I D43379P	B10		2503B	24 Y2	D04007P	B10		AE0401A	32	ALL	
I D43379P	A10		2503R	24 Y2	D04007P	A10		AE0401A	32	ALL	
I D43379P	PERG	1F	2503Z		D04007P	PERG	1F	AE0401A	32	ALL	
I D43379P	B11		2504B	24 Y2	D04009P	B01		AE0401A	41	ALL	
I D43379P	A11		2504R	24 Y2	D04009P	A01		AE0401A	41	ALL	

SPARE WIRE LIST

D280A351

91-21-12

Section AE0303A

Page 6

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AE0303A	43	W5335	NB2	DISCONNECT BRACKET - E3-3 SHELF (continued)								
D43379P	PERG	1F	2504Z			D04009P	PERG	1F	AE0401A	41	ALL	
D43379P	B13		2506B	24	Y2	D04009P	B03		AE0401A	41	ALL	
D43379P	A13		2506R	24	Y2	D04009P	A03		AE0401A	41	ALL	
D43379P	PERG	1F	2506Z			D04009P	PERG	1F	AE0401A	41	ALL	
D43379P	B14		2507B	24	Y2	D04009P	B04		AE0401A	41	ALL	
D43379P	A14		2507R	24	Y2	D04009P	A04		AE0401A	41	ALL	
D43379P	PERG	1F	2507Z			D04009P	PERG	1F	AE0401A	41	ALL	
D43379P	B15		2508B	24	Y2	D04009P	B05		AE0401A	41	ALL	
D43379P	A15		2508R	24	Y2	D04009P	A05		AE0401A	41	ALL	
D43379P	PERG	1F	2508Z			D04009P	PERG	1F	AE0401A	41	ALL	
D43379P	B07		2510B	24	Y2	D04007P	B07		AE0401A	32	ALL	
D43379P	A07		2510R	24	Y2	D04007P	A07		AE0401A	32	ALL	
D43379P	PERG	1F	2510Z			D04007P	PERG	1F	AE0401A	32	ALL	
D43379P	B06		2566B	24	M5	D04007P	B06		AE0401A	32	ALL	
D43379P	A06		2566R	24	M5	D04007P	A06		AE0401A	32	ALL	
D43379P	A05		2566ZI			D04007P	A05		AE0401A	32	ALL	
D43379P	PERG	1F	2566ZO			D04007P	PERG	1F	AE0401A	32	ALL	
D43379P	B19		2567B	24	Y2	D04009P	B09		AE0401A	41	ALL	
D43379P	A19		2567R	24	Y2	D04009P	A09		AE0401A	41	ALL	
D43379P	PERG	1F	2567Z			D04009P	PERG	1F	AE0401A	41	ALL	
AE0303A	44	W5723	RB2*	DISCONNECT BRACKET - E3-3 SHELF								
D43333P	B08		2502B	24	Y2	D41507J	42		AE0105A	03	YT101-YT103	
D43333P	A08		2502R	24	Y2	D41507J	41		AE0105A	03	YT101-YT103	
D43333P	PERG	1F	2502Z			D41507J	S/R		AE0105A	03	YT101-YT103	
D43333P	B10		2503B	24	Y2	D41507J	44		AE0105A	03	YT101-YT103	
D43333P	A10		2503R	24	Y2	D41507J	43		AE0105A	03	YT101-YT103	
D43333P	PERG	1F	2503Z			D41507J	S/R		AE0105A	03	YT101-YT103	
D43333P	B07		2506B	24	Y2	D41507J	48		AE0105A	03	YT101-YT103	
D43333P	A07		2506R	24	Y2	D41507J	47		AE0105A	03	YT101-YT103	
D43333P	PERG	1F	2506Z			D41507J	S/R		AE0105A	03	YT101-YT103	
AE0303A	47	W5723	RB2*	DISCONNECT BRACKET - E3-3 SHELF								
D43333P	B08		2502B	24	Y2	D41507J	42		AE0105A	03	YT104-YT133	
D43333P	A08		2502R	24	Y2	D41507J	41		AE0105A	03	YT104-YT133	
D43333P	PERG	1F	2502Z			D41507J	S/R		AE0105A	03	YT104-YT133	
D43333P	B10		2503B	24	Y2	D41507J	44		AE0105A	03	YT104-YT133	
D43333P	A10		2503R	24	Y2	D41507J	43		AE0105A	03	YT104-YT133	

SPARE WIRE LIST

D280A351

91-21-12

Section AE0303A

Page 7

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To						
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AE0303A	47	W5723	RB2*	DISCONNECT BRACKET - E3-3 SHELF (continued)							
D43333P	PERG	1F	2503Z		D41507J	S/R		AE0105A	03	YT104-YT133	
D43333P	B07		2506B	24 Y2	D41507J	48		AE0105A	03	YT104-YT133	
D43333P	A07		2506R	24 Y2	D41507J	47		AE0105A	03	YT104-YT133	
D43333P	PERG	1F	2506Z		D41507J	S/R		AE0105A	03	YT104-YT133	
AE0303A	48	W5723	RB2*	DISCONNECT BRACKET - E3-3 SHELF							
D43306P	B03		2511B	24 Y2	D41131P	35		AE0103A	22	YT104-YT133	
D43306P	A03		2511R	24 Y2	D41131P	34		AE0103A	22	YT104-YT133	
D43306P	PERG	1F	2511Z		D41131P	36		AE0103A	22	YT104-YT133	
D43306P	B04		2512B	24 Y2	D41213J	4		AE0102A	12	YT104-YT133	
D43306P	A04		2512R	24 Y2	D41213J	3		AE0102A	12	YT104-YT133	
D43306P	PERG	1F	2512Z		D41213J	S/R		AE0102A	12	YT104-YT133	
AE0303A	52	W2231	RB2	DISCONNECT BRACKET - E3-3 SHELF							
D43309P	8		0019	16 CQ	D46067P	19		AP0600B	10	YT104-YT133	

SPARE WIRE LIST

D280A351

91-21-12

Section AE0303A

Page 8 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From Matewith	Pos	Bundle	Sep	Description		To							
	Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity		
I	AE0401A	13	W6412	RB2*	DISCONNECT BRACKET - E4-1 SHELF									
I	D41830P	A06		0029	20	PA	D41832P	7		AP0600B	07	ALL		
I	AE0401A	14	W5331	NA2	DISCONNECT BRACKET - E4-1 SHELF									
I	D04115P	B07		2501B	24	Y2	D43345P	B07		AE0303A	17	ALL		
I	D04115P	A07		2501R	24	Y2	D43345P	A07		AE0303A	17	ALL		
I	D04115P	PERG	1F	2501Z			D43345P	PERG	1F	AE0303A	17	ALL		
I	D04115P	B09		2503B	24	Y2	D43345P	B09		AE0303A	17	YT126-YT133		
I	D04115P	A09		2503R	24	Y2	D43345P	A09		AE0303A	17	YT126-YT133		
I	D04115P	PERG	1F	2503Z			D43345P	PERG	1F	AE0303A	17	YT126-YT133		
I	D04115P	B10		2504B	24	Y2	D43345P	B10		AE0303A	17	ALL		
I	D04115P	A10		2504R	24	Y2	D43345P	A10		AE0303A	17	ALL		
I	D04115P	PERG	1F	2504Z			D43345P	PERG	1F	AE0303A	17	ALL		
I	D04115P	B06		2505B	24	Y2	D43345P	B06		AE0303A	17	ALL		
I	D04115P	A06		2505R	24	Y2	D43345P	A06		AE0303A	17	ALL		
I	D04115P	PERG	1F	2505Z			D43345P	PERG	1F	AE0303A	17	ALL		
I	D04115P	B05		2506B	24	Y2	D43345P	B05		AE0303A	17	ALL		
I	D04115P	A05		2506R	24	Y2	D43345P	A05		AE0303A	17	ALL		
I	D04115P	PERG	1F	2506Z			D43345P	PERG	1F	AE0303A	17	ALL		
I	D04115P	B04		2507B	24	Y2	D43345P	B04		AE0303A	17	ALL		
I	D04115P	A04		2507R	24	Y2	D43345P	A04		AE0303A	17	ALL		
I	D04115P	PERG	1F	2507Z			D43345P	PERG	1F	AE0303A	17	ALL		
I	D04115P	B11		2508B	24	Y2	D43345P	B11		AE0303A	17	YT126-YT133		
I	D04115P	A11		2508R	24	Y2	D43345P	A11		AE0303A	17	YT126-YT133		
I	D04115P	PERG	1F	2508Z			D43345P	PERG	1F	AE0303A	17	YT126-YT133		
I	D04115P	B14		2511B	24	Y2	D43345P	B14		AE0303A	17	ALL		
I	D04115P	A14		2511R	24	Y2	D43345P	A14		AE0303A	17	ALL		
I	D04115P	PERG	1F	2511Z			D43345P	PERG	1F	AE0303A	17	ALL		
I	D04115P	B16		2524B	24	Y2	D43345P	B16		AE0303A	17	YT126-YT133		
I	D04115P	A16		2524R	24	Y2	D43345P	A16		AE0303A	17	YT126-YT133		
I	D04115P	PERG	1F	2524Z			D43345P	PERG	1F	AE0303A	17	YT126-YT133		
I	D04115P	B01		2527B	24	Y2	D43345P	B01		AE0303A	17	YT126-YT133		
I	D04115P	A01		2527R	24	Y2	D43345P	A01		AE0303A	17	YT126-YT133		
I	D04115P	PERG	1F	2527Z			D43345P	PERG	1F	AE0303A	17	YT126-YT133		
I	D04115P	B02		2528B	24	Y2	D43345P	B02		AE0303A	17	ALL		
I	D04115P	A02		2528R	24	Y2	D43345P	A02		AE0303A	17	ALL		
I	D04115P	PERG	1F	2528Z			D43345P	PERG	1F	AE0303A	17	ALL		
I	D04115P	B03		2532B	24	Y2	D43345P	B03		AE0303A	17	ALL		
I	D04115P	A03		2532R	24	Y2	D43345P	A03		AE0303A	17	ALL		

SPARE WIRE LIST

D280A351

91-21-12

Section AE0401A

Page 1

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AE0401A	14	W5331	NA2	DISCONNECT BRACKET - E4-1 SHELF (continued)								
D04115P	PERG	1F	2532Z		D43345P	PERG	1F	AE0303A	17	ALL		
AE0401A	15	W5331	NA2	DISCONNECT BRACKET - E4-1 SHELF								
D04117P	A05		0022	24 PK	D43347P	A05		AE0303A	18	ALL		
D04117P	B05		0023	24 PK	D43347P	B05		AE0303A	18	ALL		
D04117P	A06		0024	24 PK	D43347P	A06		AE0303A	18	ALL		
D04117P	B06		0025	24 PK	D43347P	B06		AE0303A	18	ALL		
D04117P	B10		2516B	24 Y2	D43347P	B10		AE0303A	18	ALL		
D04117P	A10		2516R	24 Y2	D43347P	A10		AE0303A	18	ALL		
D04117P	PERG	1F	2516Z		D43347P	PERG	1F	AE0303A	18	ALL		
D04117P	B14		2520B	24 Y2	D43347P	B14		AE0303A	18	ALL		
D04117P	A14		2520R	24 Y2	D43347P	A14		AE0303A	18	ALL		
D04117P	PERG	1F	2520Z		D43347P	PERG	1F	AE0303A	18	ALL		
D04117P	B15		2521B	24 Y2	D43347P	B15		AE0303A	18	ALL		
D04117P	A15		2521R	24 Y2	D43347P	A15		AE0303A	18	ALL		
D04117P	PERG	1F	2521Z		D43347P	PERG	1F	AE0303A	18	ALL		
D04117P	B16		2522B	24 Y2	D43347P	B16		AE0303A	18	ALL		
D04117P	A16		2522R	24 Y2	D43347P	A16		AE0303A	18	ALL		
D04117P	PERG	1F	2522Z		D43347P	PERG	1F	AE0303A	18	ALL		
D04117P	B20		2561B	24 M5	D43347P	B20		AE0303A	18	ALL		
D04117P	A20		2561R	24 M5	D43347P	A20		AE0303A	18	ALL		
D04117P	A19		2561ZI		D43347P	A19		AE0303A	18	ALL		
D04117P	PERG	1F	2561ZO		D43347P	PERG	1F	AE0303A	18	ALL		
AE0401A	19	W5191	NB3	DISCONNECT BRACKET - E4-1 SHELF								
D04285P	B20		0025	20 PA	D04273J		12	AE0104A	17	ALL		
AE0401A	24	W5461	LA2	DISCONNECT BRACKET - E4-1 SHELF								
D44161P	B04		0057	24 PK	D42361P	B06		AE0302A	43	ALL		
D44161P	A06		0058	24 PK	D42361P	A06		AE0302A	43	ALL		
D44161P	B11		2018B	24 Y2	D41561J	B11		AE0502A	17	YT101-YT103		
D44161P	B11		2018B	24 Y2	D41561J	B11		AE0502A	05	YT104-YT133		
D44161P	A11		2018R	24 Y2	D41561J	A11		AE0502A	17	YT101-YT103		
D44161P	A11		2018R	24 Y2	D41561J	A11		AE0502A	05	YT104-YT133		
D44161P	PERG	1F	2018Z		D41561J	PERG	1F	AE0502A	17	YT101-YT103		
D44161P	PERG	1F	2018Z		D41561J	PERG	1F	AE0502A	05	YT104-YT133		
D44161P	B13		2029B	24 Y2	D45261J	B15		AE0502A	18	YT101-YT103		
D44161P	B13		2029B	24 Y2	D45261J	B15		AE0502A	06	YT104-YT133		

SPARE WIRE LIST

D280A351

91-21-12

Section AE0401A

Page 2

Jun 21/2016

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AE0401A	24	W5461	LA2	DISCONNECT BRACKET - E4-1 SHELF (continued)								
I D44161P	B12		2029R	24 Y2	D45261J	B14		AE0502A	18	YT101-YT103		
I D44161P	B12		2029R	24 Y2	D45261J	B14		AE0502A	06	YT104-YT133		
I D44161P	PERG	1F	2029Z		D45261J	PERG	1F	AE0502A	18	YT101-YT103		
I D44161P	PERG	1F	2029Z		D45261J	PERG	1F	AE0502A	06	YT104-YT133		
I D44161P	B17		2030B	24 Y2	D45261J	B17		AE0502A	18	YT101-YT103		
I D44161P	B17		2030B	24 Y2	D45261J	B17		AE0502A	06	YT104-YT133		
I D44161P	B16		2030R	24 Y2	D45261J	B16		AE0502A	18	YT101-YT103		
I D44161P	B16		2030R	24 Y2	D45261J	B16		AE0502A	06	YT104-YT133		
I D44161P	PERG	1F	2030Z		D45261J	PERG	1F	AE0502A	18	YT101-YT103		
I D44161P	PERG	1F	2030Z		D45261J	PERG	1F	AE0502A	06	YT104-YT133		
AE0401A	25	W5337	SN2	DISCONNECT BRACKET - E4-1 SHELF								
I D04161P	A07		0001	22 PA	D40664	24		DM0035		ALL		
AE0401A	29	W5104	LA2	DISCONNECT BRACKET - E4-1 SHELF								
I D40244P	B05		5520	20 PA	D40056P	18		AB0536L	02	ALL		
I D40244P	CAP	Y	5521	20 PA	D40056P	19		AB0536L	02	ALL		
AE0401A	31	W6214	LA2*	DISCONNECT BRACKET - E4-1 SHELF								
I D40328P	B02		5544	20 PA	D40444P	4		AP0600A	04	ALL		
I D40328P	B03		5545	20 PA	D40444P	5		AP0600A	04	ALL		
AE0401A	32	W5335	NB2	DISCONNECT BRACKET - E4-1 SHELF								
I D04007P	A01		0001	22 PA	D43379P	A01		AE0303A	43	ALL		
I D04007P	A02		0003	22 PA	D43379P	A02		AE0303A	43	ALL		
I D04007P	B02		0004	22 PA	D43379P	B02		AE0303A	43	ALL		
I D04007P	B10		2503B	24 Y2	D43379P	B10		AE0303A	43	ALL		
I D04007P	A10		2503R	24 Y2	D43379P	A10		AE0303A	43	ALL		
I D04007P	PERG	1F	2503Z		D43379P	PERG	1F	AE0303A	43	ALL		
I D04007P	B07		2510B	24 Y2	D43379P	B07		AE0303A	43	ALL		
I D04007P	A07		2510R	24 Y2	D43379P	A07		AE0303A	43	ALL		
I D04007P	PERG	1F	2510Z		D43379P	PERG	1F	AE0303A	43	ALL		
I D04007P	B06		2566B	24 M5	D43379P	B06		AE0303A	43	ALL		
I D04007P	A06		2566R	24 M5	D43379P	A06		AE0303A	43	ALL		
I D04007P	A05		2566ZI		D43379P	A05		AE0303A	43	ALL		
I D04007P	PERG	1F	2566ZO		D43379P	PERG	1F	AE0303A	43	ALL		

SPARE WIRE LIST

D280A351

91-21-12

Section AE0401A

Page 3

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From Matewith	Pos	Bundle	Sep	Description		To	Term	Type	Matewith	Pos	Effectivity
	Equip	Term	Type	Wire No.	GA	TY	Equip					
I	AE0401A	33	W6412	RB2*	DISCONNECT BRACKET - E4-1 SHELF							
I	D41010P	18		0008	20	PA	D40386P	27		AP0600B	14	ALL
I	D41010P	19		0009	20	PA	D40386P	31		AP0600B	14	ALL
I	D41010P	20		0010	20	PA	D40386P	32		AP0600B	14	ALL
I	D41010P	2		0508	20	PA	D40394P	A09		AE0301A	34	ALL
I	AE0401A	38	W6168	SB2*	DISCONNECT BRACKET - E4-1 SHELF							
I	D40144P	A01		2601B	20	VG	D39930	2		AD0520		ALL
I	D40144P	B01		2601R	20	VG	D39930	3		AD0520		ALL
I	D40144P	PERG	1F	2601Z			D39930	S/R		AD0520		ALL
I	D40144P	A02		2602B	20	VG	D39930	4		AD0520		ALL
I	D40144P	B02		2602R	20	VG	D39930	5		AD0520		ALL
I	D40144P	PERG	1F	2602Z			D39930	S/R		AD0520		ALL
I	AE0401A	41	W5335	NB2	DISCONNECT BRACKET - E4-1 SHELF							
I	D04009P	B01		2504B	24	Y2	D43379P	B11		AE0303A	43	ALL
I	D04009P	A01		2504R	24	Y2	D43379P	A11		AE0303A	43	ALL
I	D04009P	PERG	1F	2504Z			D43379P	PERG	1F	AE0303A	43	ALL
I	D04009P	B03		2506B	24	Y2	D43379P	B13		AE0303A	43	ALL
I	D04009P	A03		2506R	24	Y2	D43379P	A13		AE0303A	43	ALL
I	D04009P	PERG	1F	2506Z			D43379P	PERG	1F	AE0303A	43	ALL
I	D04009P	B04		2507B	24	Y2	D43379P	B14		AE0303A	43	ALL
I	D04009P	A04		2507R	24	Y2	D43379P	A14		AE0303A	43	ALL
I	D04009P	PERG	1F	2507Z			D43379P	PERG	1F	AE0303A	43	ALL
I	D04009P	B05		2508B	24	Y2	D43379P	B15		AE0303A	43	ALL
I	D04009P	A05		2508R	24	Y2	D43379P	A15		AE0303A	43	ALL
I	D04009P	PERG	1F	2508Z			D43379P	PERG	1F	AE0303A	43	ALL
I	D04009P	B09		2567B	24	Y2	D43379P	B19		AE0303A	43	ALL
I	D04009P	A09		2567R	24	Y2	D43379P	A19		AE0303A	43	ALL
I	D04009P	PERG	1F	2567Z			D43379P	PERG	1F	AE0303A	43	ALL
I	AE0401A	42	W6564	SN2*	DISCONNECT BRACKET - E4-1 SHELF							
I	D40158P	A02		2601B	20	VG	D39910	6		AD0520		ALL
I	D40158P	B02		2601R	20	VG	D39910	5		AD0520		ALL
I	D40158P	PERG	1F	2601Z			D39910	S/R		AD0520		ALL
I	AE0401A	46	W6214	LA2*	DISCONNECT BRACKET - E4-1 SHELF							
I	D40378P	B15		5536	20	PA	D40380P	B15		AE0202A	26	ALL

SPARE WIRE LIST

D280A351

91-21-12

Section AE0401A

Page 4

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

From	Matewith	Pos	Bundle	Sep	Description		To						
Equip	Term	Type	Wire No.		GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AE0401A													
		46	W6214	LA2*	DISCONNECT BRACKET - E4-1 SHELF (continued)								
D40378P	B16		5540		20	PA	D40444P	9		AP0600A	04	ALL	
D40378P	B14		5541		20	PA	D40444P	10		AP0600A	04	ALL	
AE0401A													
		50	W6162	RB2*	DISCONNECT BRACKET - E4-1 SHELF								
D40156P	A14		2611B		20	PB	D39922	14		AD0520		ALL	
D40156P	B14		2611R		20	PB	D39922	5		AD0520		ALL	
D40156P	A15		2612B		20	PB	D39922	31		AD0520		ALL	
D40156P	B15		2612R		20	PB	D39922	30		AD0520		ALL	
AE0401A													
		52	W6412	RB2*	DISCONNECT BRACKET - E4-1 SHELF								
D40390P	A06		2001B		24	Y2	D40392P	B18		AE0302A	45	ALL	
D40390P	A05		2001R		24	Y2	D40392P	B17		AE0302A	45	ALL	
D40390P	PERG	1F	2001Z				D40392P	PERG	1F	AE0302A	45	ALL	
D40390P	B03		5504		24	PK	D40392P	B03		AE0302A	45	ALL	
D40390P	A19		5508		22	PA	D40386P	9		AP0600B	14	ALL	
D40390P	A17		5529		20	PA	D40392P	A14		AE0302A	45	ALL	

SPARE WIRE LIST

D280A351

91-21-12

Section AE0401A

Page 5 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From Matewith	Pos	Bundle	Sep	Description		To					Pos	Effectivity
	Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith			
I	AE0401D	03	W2705	NA2	DISCONNECT BRACKET - E4-1 SHELF								
I	D00403	A08		0023	24	PK	D00803	19		AB0237A	03	ALL	
I	D00403	B07		2046B	24	Y2	D00803	18		AB0237A	03	ALL	
I	D00403	A07		2046R	24	Y2	D00803	17		AB0237A	03	ALL	
I	D00403	PERG	1F	2046Z			D00803	PERB		AB0237A	03	ALL	
I	AE0401D	04	W2705	NA2	DISCONNECT BRACKET - E4-1 SHELF								
I	D00414	A07		0004	24	PK	D00308	18		AP0900A	08	ALL	
I	D00414	B07		0022	24	PK	D00308	19		AP0900A	08	ALL	
I	AE0401D	06	W2705	NA2	DISCONNECT BRACKET - E4-1 SHELF								
I	D00406	B08		2048B	22	WC	D00901	26		OVHD DISC		ALL	
I	D00406	A08		2048W	22	WC	D00901	44		OVHD DISC		ALL	
I	D00406	PERG	1F	2048Z			D00901	PERB		OVHD DISC		ALL	
I	AE0401D	09	W2705	NA2	DISCONNECT BRACKET - E4-1 SHELF								
I	D00416	B17		2047B	22	X2	D00901	23		OVHD DISC		ALL	
I	D00416	A17		2047R	22	X2	D00901	41		OVHD DISC		ALL	
I	D00416	PERG	1F	2047Z			D00901	PERB		OVHD DISC		ALL	
I	AE0401D	14	W2709	NB2	DISCONNECT BRACKET - E4-1 SHELF								
I	D00404	A05		0015	24	PK	D40067P	9		AP0600B	01	ALL	
I	D00404	B05		0016	24	PK	D40067P	10		AP0600B	01	ALL	
I	AE0401D	15	W2709	NB2	DISCONNECT BRACKET - E4-1 SHELF								
I	D00415	A06		0017	24	PK	D00322	10		AP0900A	22	ALL	
I	D00415	B05		0018	24	PK	D00322	11		AP0900A	22	ALL	

SPARE WIRE LIST

D280A351

91-21-12

Section AE0401D

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From Matewith From	Pos	Bundle	Sep	Description		To						
	Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity	
I	AE0402A	01	W5719	LA2	DISCONNECT BRACKET - E4-2 SHELF								
I	D42111P	B02		0030	22	PA	D41125P	B07		AE0101A	25	ALL	
I	AE0402A	02	W5248	LN2*	DISCONNECT BRACKET - E4-2 SHELF								
I	D40584P	A01		0499	20	PA	D40500J	1		AB0500DL	05	ALL	
I	D40584P	B01		0500	20	PA	D40500J	3		AB0500DL	05	ALL	
I	AE0402A	07	W5110	LA2	DISCONNECT BRACKET - E4-2 SHELF								
I	D40338P	A10		0516	20	PA	D40340P	B01		AE0201A	19	ALL	
I	AE0402A	24	W6412	RB2*	DISCONNECT BRACKET - E4-2 SHELF								
I	D40388P	A16		5533	20	PA	D40386P	24		AP0600B	14	ALL	
I	AE0402A	27	W6164	RB1*	DISCONNECT BRACKET - E4-2 SHELF								
I	D40720P	A09		2602B	20	PB	D39934	26		AD0520		ALL	
I	D40720P	B09		2602R	20	PB	D39934	25		AD0520		ALL	
I	AE0402A	33	W5160	RB2*	DISCONNECT BRACKET - E4-2 SHELF								
I	D40472P	B06		2460B	22	PB	D10988	60		M02061		ALL	
I	D40472P	B05		2460R	22	PB	D10988	61		M02061		ALL	
I	AE0402A	37	W5160	RB2*	DISCONNECT BRACKET - E4-2 SHELF								
I	D40474P	B02		0530	22	PA	D40694P	16		AJ0024	07	ALL	

SPARE WIRE LIST

D280A351

91-21-12

Section AE0402A

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From Matewith	Pos	Bundle	Sep	Description		To					Pos	Effectivity
	Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith			
I	AE0502A	01	W5205	SA2	DISCONNECT BRACKET - E5-2 SHELF								
I	D45209J	A05		0025	20	PA	D45205P	A05		AE0301A	18	YT104-YT133	
I	D45209J	B03		2001B	22	X2	D45205P	B03		AE0301A	18	YT104-YT133	
I	D45209J	B02		2001R	22	X2	D45205P	B02		AE0301A	18	YT104-YT133	
I	D45209J	PERG	1F	2001Z			D45205P	PERG	1F	AE0301A	18	YT104-YT133	
I	D45209J	A07		2031B	24	Y2	D45201J	13		AE0102A	10	YT104-YT133	
I	D45209J	A06		2031R	24	Y2	D45201J	12		AE0102A	10	YT104-YT133	
I	D45209J	PERG	1F	2031Z			D45201J	S/R		AE0102A	10	YT104-YT133	
I	AE0502A	02	W5161	LA2	DISCONNECT BRACKET - E5-2 SHELF								
I	D45245J	B15		0004	20	PA	D43145P	A05		AE0301A	15	YT104-YT133	
I	D45245J	B13		0027	20	PA	D43145P	A03		AE0301A	15	YT104-YT133	
I	D45245J	B14		0028	20	PA	D43145P	A04		AE0301A	15	YT104-YT133	
I	AE0502A	03	W5161	LA2	DISCONNECT BRACKET - E5-2 SHELF								
I	D45255J	A06		2503B	24	Y2	D41155P	A06		AE0101A	20	YT104-YT133	
I	D45255J	A05		2503R	24	Y2	D41155P	A05		AE0101A	20	YT104-YT133	
I	D45255J	PERG	1F	2503Z			D41155P	PERG	1F	AE0101A	20	YT104-YT133	
I	D45255J	B20		2518B	24	Y2	D43155P	B02		AE0301A	16	YT104-YT133	
I	D45255J	B19		2518R	24	Y2	D43155P	B01		AE0301A	16	YT104-YT133	
I	D45255J	PERG	1F	2518Z			D43155P	PERG	1F	AE0301A	16	YT104-YT133	
	AE0502A	03	W5205	SA2	DISCONNECT BRACKET - E5-2 SHELF								
	D45209J	A05		0025	20	PA	D45205P	A05		AE0301A	18	YT101-YT103	
	D45209J	B03		2001B	22	X2	D45205P	B03		AE0301A	18	YT101-YT103	
	D45209J	B02		2001R	22	X2	D45205P	B02		AE0301A	18	YT101-YT103	
	D45209J	PERG	1F	2001Z			D45205P	PERG	1F	AE0301A	18	YT101-YT103	
	D45209J	A07		2031B	24	Y2	D45201J	13		AE0102A	10	YT101-YT103	
	D45209J	A06		2031R	24	Y2	D45201J	12		AE0102A	10	YT101-YT103	
	D45209J	PERG	1F	2031Z			D45201J	S/R		AE0102A	10	YT101-YT103	
I	AE0502A	04	W5161	LA2	DISCONNECT BRACKET - E5-2 SHELF								
I	D45265J	B02		2523B	24	Y2	D43155P	B10		AE0301A	16	YT104-YT133	
I	D45265J	B01		2523R	24	Y2	D43155P	B09		AE0301A	16	YT104-YT133	
I	D45265J	PERG	1F	2523Z			D43155P	PERG	1F	AE0301A	16	YT104-YT133	
	AE0502A	04	W5163	RB2*	DISCONNECT BRACKET - E5-2 SHELF								
	D45247J	A08		0013	22	PA	D43157P	A20		AE0301A	29	YT101-YT103	

SPARE WIRE LIST

D280A351

91-21-12

Section AE0502A

Page 1

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To						
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AE0502A	04	W5163	RB2*	DISCONNECT BRACKET - E5-2 SHELF (continued)							
D45247J	A16		0021	20 PA	D43147P	A01		AE0301A	28	YT101-YT103	
AE0502A	05	W5163	RB2*	DISCONNECT BRACKET - E5-2 SHELF							
D45257J	A15		0004	22 PA	D41157P	A18		AE0101B	12	YT101-YT103	
D45257J	A07		0039	22 PA	D41157P	B20		AE0101B	12	YT101-YT103	
D45257J	A10		2508B	24 Y2	D43157P	A09		AE0301A	29	YT101-YT103	
D45257J	A09		2508R	24 Y2	D43157P	A08		AE0301A	29	YT101-YT103	
D45257J	PERG	1F	2508Z		D43157P	PERG	1F	AE0301A	29	YT101-YT103	
D45257J	A12		2509B	24 Y2	D43157P	A11		AE0301A	29	YT101-YT103	
D45257J	A11		2509R	24 Y2	D43157P	A10		AE0301A	29	YT101-YT103	
D45257J	PERG	1F	2509Z		D43157P	PERG	1F	AE0301A	29	YT101-YT103	
I AE0502A	05	W5461	LA2	DISCONNECT BRACKET - E5-2 SHELF							
I D41561J	B14		0059	24 PK	D42261P	B10		AE0302A	41	YT104-YT133	
I D41561J	A16		0071	24 PK	D42261P	B05		AE0302A	41	YT104-YT133	
I D41561J	B11		2018B	24 Y2	D44161P	B11		AE0401A	24	YT104-YT133	
I D41561J	A11		2018R	24 Y2	D44161P	A11		AE0401A	24	YT104-YT133	
I D41561J	PERG	1F	2018Z		D44161P	PERG	1F	AE0401A	24	YT104-YT133	
I AE0502A	06	W5461	LA2	DISCONNECT BRACKET - E5-2 SHELF							
I D45261J	B15		2029B	24 Y2	D44161P	B13		AE0401A	24	YT104-YT133	
I D45261J	B14		2029R	24 Y2	D44161P	B12		AE0401A	24	YT104-YT133	
I D45261J	PERG	1F	2029Z		D44161P	PERG	1F	AE0401A	24	YT104-YT133	
I D45261J	B17		2030B	24 Y2	D44161P	B17		AE0401A	24	YT104-YT133	
I D45261J	B16		2030R	24 Y2	D44161P	B16		AE0401A	24	YT104-YT133	
I D45261J	PERG	1F	2030Z		D44161P	PERG	1F	AE0401A	24	YT104-YT133	
I D45261J	B10		2032B	24 Y2	D43261P	B10		AE0302A	40	YT104-YT133	
I D45261J	B09		2032R	24 Y2	D43261P	B09		AE0302A	40	YT104-YT133	
I D45261J	PERG	1F	2032Z		D43261P	PERG	1F	AE0302A	40	YT104-YT133	
I D45261J	A20		2047B	24 Y2	D46461P	B04		AE0101A	22	YT126-YT133	
I D45261J	A19		2047R	24 Y2	D46461P	A04		AE0101A	22	YT126-YT133	
I D45261J	PERG	1F	2047Z		D46461P	PERG	1F	AE0101A	22	YT126-YT133	
AE0502A	06	W5463	RB2	DISCONNECT BRACKET - E5-2 SHELF							
D45263J	A05		0022	22 PA	D41463J	14		AE0104A	11	YT101-YT103	
D45263J	B14		2019B	24 Y2	D43263P	B14		AE0302A	44	YT101-YT103	
D45263J	A14		2019R	24 Y2	D43263P	A14		AE0302A	44	YT101-YT103	

SPARE WIRE LIST

D280A351

91-21-12

Section AE0502A

Page 2

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description		To				Pos	Effectivity
	Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type		
AE0502A	06	W5463	RB2	DISCONNECT BRACKET - E5-2 SHELF (continued)							
D45263J	PERG	1F	2019Z			D43263P	PERG	1F	AE0302A	44	YT101-YT103
AE0502A	07	W2135	RB2	DISCONNECT BRACKET - E5-2 SHELF							
D45237J	B20		0034	22	PA	D01817	CAP	Y	P005-28		YT101-YT103
AE0502A	09	W2597	NA2	DISCONNECT BRACKET - E5-2 SHELF							
D45225J	B20		0017	22	PA	D40625P	40		AP0600B	13	YT104-YT133
D45225J	B04		2502B	22	X2	D40625P	12		AP0600B	13	YT104-YT133
D45225J	B03		2502R	22	X2	D40625P	11		AP0600B	13	YT104-YT133
D45225J	PERG	1F	2502Z			D40625P	S/R		AP0600B	13	YT104-YT133
D45225J	A20		2509B	24	Y2	D40625P	7		AP0600B	13	YT104-YT133
D45225J	A19		2509R	24	Y2	D40625P	6		AP0600B	13	YT104-YT133
D45225J	PERG	1F	2509Z			D40625P	S/R		AP0600B	13	YT104-YT133
D45225J	B14		2513B	22	X2	D40625P	39		AP0600B	13	YT104-YT133
D45225J	B13		2513R	22	X2	D40625P	38		AP0600B	13	YT104-YT133
D45225J	PERG	1F	2513Z			D40625P	S/R		AP0600B	13	YT104-YT133
AE0502A	11	W5121	NB2	DISCONNECT BRACKET - E5-2 SHELF							
D45213J	B03		2053B	24	Y2	D43323P	B01		AE0303A	42	YT101-YT103
D45213J	A03		2053R	24	Y2	D43323P	A01		AE0303A	42	YT101-YT103
D45213J	PERG	1F	2053Z			D43323P	PERG	1F	AE0303A	42	YT101-YT103
D45213J	B04		2054B	24	Y2	D43323P	B02		AE0303A	42	YT101-YT103
D45213J	A04		2054R	24	Y2	D43323P	A02		AE0303A	42	YT101-YT103
D45213J	PERG	1F	2054Z			D43323P	PERG	1F	AE0303A	42	YT101-YT103
D45213J	B05		2055B	24	Y2	D43323P	B03		AE0303A	42	YT101-YT103
D45213J	A05		2055R	24	Y2	D43323P	A03		AE0303A	42	YT101-YT103
D45213J	PERG	1F	2055Z			D43323P	PERG	1F	AE0303A	42	YT101-YT103
D45213J	B12		2057B	24	Y2	D43323P	B12		AE0303A	42	YT101-YT103
D45213J	A12		2057R	24	Y2	D43323P	A12		AE0303A	42	YT101-YT103
D45213J	PERG	1F	2057Z			D43323P	PERG	1F	AE0303A	42	YT101-YT103
D45213J	B13		2058B	24	Y2	D43323P	B13		AE0303A	42	YT101-YT103
D45213J	A13		2058R	24	Y2	D43323P	A13		AE0303A	42	YT101-YT103
D45213J	PERG	1F	2058Z			D43323P	PERG	1F	AE0303A	42	YT101-YT103
D45213J	B15		2061B	24	Y2	D43323P	B15		AE0303A	42	YT101-YT103
D45213J	A15		2061R	24	Y2	D43323P	A15		AE0303A	42	YT101-YT103
D45213J	PERG	1F	2061Z			D43323P	PERG	1F	AE0303A	42	YT101-YT103
D45213J	B16		2064B	24	Y2	D43323P	B16		AE0303A	42	YT101-YT103
D45213J	A16		2064R	24	Y2	D43323P	A16		AE0303A	42	YT101-YT103

SPARE WIRE LIST

D280A351

91-21-12

Section AE0502A

Page 3

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To						
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AE0502A	11	W5121	NB2	DISCONNECT BRACKET - E5-2 SHELF (continued)							
D45213J	PERG	1F	2064Z		D43323P	PERG	1F	AE0303A	42	YT101-YT103	
AE0502A	12	W5111	NA2	DISCONNECT BRACKET - E5-2 SHELF							
D45211J	B07		2067B	24 Y2	D43321P	B06		AE0303A	13	ALL	
D45211J	A07		2067R	24 Y2	D43321P	A06		AE0303A	13	ALL	
D45211J	PERG	1F	2067Z		D43321P	PERG	1F	AE0303A	13	ALL	
D45211J	B19		2071B	22 X2	D43321P	B19		AE0303A	13	ALL	
D45211J	A19		2071R	22 X2	D43321P	A19		AE0303A	13	ALL	
D45211J	PERG	1F	2071Z		D43321P	PERG	1F	AE0303A	13	ALL	
D45211J	B14		2079B	24 Y2	D43321P	B04		AE0303A	13	ALL	
D45211J	A14		2079R	24 Y2	D43321P	A04		AE0303A	13	ALL	
D45211J	PERG	1F	2079Z		D43321P	PERG	1F	AE0303A	13	ALL	
D45211J	B15		2080B	24 Y2	D43321P	B05		AE0303A	13	ALL	
D45211J	A15		2080R	24 Y2	D43321P	A05		AE0303A	13	ALL	
D45211J	PERG	1F	2080Z		D43321P	PERG	1F	AE0303A	13	ALL	
D45211J	B02		2082B	24 Y2	D43321P	B10		AE0303A	13	ALL	
D45211J	A02		2082R	24 Y2	D43321P	A10		AE0303A	13	ALL	
D45211J	PERG	1F	2082Z		D43321P	PERG	1F	AE0303A	13	ALL	
D45211J	B03		2083B	24 Y2	D43321P	B01		AE0303A	13	ALL	
D45211J	A03		2083R	24 Y2	D43321P	A01		AE0303A	13	ALL	
D45211J	PERG	1F	2083Z		D43321P	PERG	1F	AE0303A	13	ALL	
D45211J	B04		2084B	24 Y2	D43321P	B02		AE0303A	13	ALL	
D45211J	A04		2084R	24 Y2	D43321P	A02		AE0303A	13	ALL	
D45211J	PERG	1F	2084Z		D43321P	PERG	1F	AE0303A	13	ALL	
D45211J	B05		2085B	24 Y2	D43321P	B03		AE0303A	13	ALL	
D45211J	A05		2085R	24 Y2	D43321P	A03		AE0303A	13	ALL	
D45211J	PERG	1F	2085Z		D43321P	PERG	1F	AE0303A	13	ALL	
AE0502A	14	W5161	LA2	DISCONNECT BRACKET - E5-2 SHELF							
D45245J	B15		0004	20 PA	D43145P	A05		AE0301A	15	YT101-YT103	
D45245J	B13		0027	20 PA	D43145P	A03		AE0301A	15	YT101-YT103	
D45245J	B14		0028	20 PA	D43145P	A04		AE0301A	15	YT101-YT103	
AE0502A	15	W5161	LA2	DISCONNECT BRACKET - E5-2 SHELF							
D45255J	A06		2503B	24 Y2	D41155P	A06		AE0101A	20	YT101-YT103	
D45255J	A05		2503R	24 Y2	D41155P	A05		AE0101A	20	YT101-YT103	
D45255J	PERG	1F	2503Z		D41155P	PERG	1F	AE0101A	20	YT101-YT103	
D45255J	B20		2518B	24 Y2	D43155P	B02		AE0301A	16	YT101-YT103	

SPARE WIRE LIST

D280A351

91-21-12

Section AE0502A

Page 4

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To						
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AE0502A	15	W5161	LA2	DISCONNECT BRACKET - E5-2 SHELF (continued)							
D45255J	B19		2518R	24 Y2	D43155P	B01		AE0301A	16	YT101-YT103	
D45255J	PERG	1F	2518Z		D43155P	PERG	1F	AE0301A	16	YT101-YT103	
AE0502A	16	W5161	LA2	DISCONNECT BRACKET - E5-2 SHELF							
D45265J	B02		2523B	24 Y2	D43155P	B10		AE0301A	16	YT101-YT103	
D45265J	B01		2523R	24 Y2	D43155P	B09		AE0301A	16	YT101-YT103	
D45265J	PERG	1F	2523Z		D43155P	PERG	1F	AE0301A	16	YT101-YT103	
AE0502A	17	W5461	LA2	DISCONNECT BRACKET - E5-2 SHELF							
D41561J	B14		0059	24 PK	D42261P	B10		AE0302A	41	YT101-YT103	
D41561J	A16		0071	24 PK	D42261P	B05		AE0302A	41	YT101-YT103	
D41561J	B11		2018B	24 Y2	D44161P	B11		AE0401A	24	YT101-YT103	
D41561J	A11		2018R	24 Y2	D44161P	A11		AE0401A	24	YT101-YT103	
D41561J	PERG	1F	2018Z		D44161P	PERG	1F	AE0401A	24	YT101-YT103	
AE0502A	18	W5461	LA2	DISCONNECT BRACKET - E5-2 SHELF							
D45261J	B15		2029B	24 Y2	D44161P	B13		AE0401A	24	YT101-YT103	
D45261J	B14		2029R	24 Y2	D44161P	B12		AE0401A	24	YT101-YT103	
D45261J	PERG	1F	2029Z		D44161P	PERG	1F	AE0401A	24	YT101-YT103	
D45261J	B17		2030B	24 Y2	D44161P	B17		AE0401A	24	YT101-YT103	
D45261J	B16		2030R	24 Y2	D44161P	B16		AE0401A	24	YT101-YT103	
D45261J	PERG	1F	2030Z		D44161P	PERG	1F	AE0401A	24	YT101-YT103	
D45261J	B10		2032B	24 Y2	D43261P	B10		AE0302A	40	YT101-YT103	
D45261J	B09		2032R	24 Y2	D43261P	B09		AE0302A	40	YT101-YT103	
D45261J	PERG	1F	2032Z		D43261P	PERG	1F	AE0302A	40	YT101-YT103	
AE0502A	21	W2597	NA2	DISCONNECT BRACKET - E5-2 SHELF							
D45225J	B20		0017	22 PA	D40625P	40		AP0600B	13	YT101-YT103	
D45225J	B04		2502B	22 X2	D40625P	12		AP0600B	13	YT101-YT103	
D45225J	B03		2502R	22 X2	D40625P	11		AP0600B	13	YT101-YT103	
D45225J	PERG	1F	2502Z		D40625P	S/R		AP0600B	13	YT101-YT103	
D45225J	A20		2509B	24 Y2	D40625P	7		AP0600B	13	YT101-YT103	
D45225J	A19		2509R	24 Y2	D40625P	6		AP0600B	13	YT101-YT103	
D45225J	PERG	1F	2509Z		D40625P	S/R		AP0600B	13	YT101-YT103	
D45225J	B14		2513B	22 X2	D40625P	39		AP0600B	13	YT101-YT103	
D45225J	B13		2513R	22 X2	D40625P	38		AP0600B	13	YT101-YT103	
D45225J	PERG	1F	2513Z		D40625P	S/R		AP0600B	13	YT101-YT103	

SPARE WIRE LIST

D280A351

91-21-12

Section AE0502A

Page 5

Dec 10/2015



737-800 WIRING DIAGRAM MANUAL

From	Matewith	Pos	Bundle	Sep	Description		To	Term	Type	Matewith	Pos	Effectivity
Equip		Term	Type	Wire No.	GA	TY	Equip					
I	AE0502A	26	W5121	NB2	DISCONNECT BRACKET - E5-2 SHELF							
I	D45213J	B03		2053B	24	Y2	D43323P	B01		AE0303A	42	YT104-YT133
I	D45213J	A03		2053R	24	Y2	D43323P	A01		AE0303A	42	YT104-YT133
I	D45213J	PERG	1F	2053Z			D43323P	PERG	1F	AE0303A	42	YT104-YT133
I	D45213J	B04		2054B	24	Y2	D43323P	B02		AE0303A	42	YT104-YT133
I	D45213J	A04		2054R	24	Y2	D43323P	A02		AE0303A	42	YT104-YT133
I	D45213J	PERG	1F	2054Z			D43323P	PERG	1F	AE0303A	42	YT104-YT133
I	D45213J	B05		2055B	24	Y2	D43323P	B03		AE0303A	42	YT104-YT133
I	D45213J	A05		2055R	24	Y2	D43323P	A03		AE0303A	42	YT104-YT133
I	D45213J	PERG	1F	2055Z			D43323P	PERG	1F	AE0303A	42	YT104-YT133
I	D45213J	B12		2057B	24	Y2	D43323P	B12		AE0303A	42	YT104-YT133
I	D45213J	A12		2057R	24	Y2	D43323P	A12		AE0303A	42	YT104-YT133
I	D45213J	PERG	1F	2057Z			D43323P	PERG	1F	AE0303A	42	YT104-YT133
I	D45213J	B13		2058B	24	Y2	D43323P	B13		AE0303A	42	YT104-YT133
I	D45213J	A13		2058R	24	Y2	D43323P	A13		AE0303A	42	YT104-YT133
I	D45213J	PERG	1F	2058Z			D43323P	PERG	1F	AE0303A	42	YT104-YT133
I	D45213J	B15		2061B	24	Y2	D43323P	B15		AE0303A	42	YT104-YT133
I	D45213J	A15		2061R	24	Y2	D43323P	A15		AE0303A	42	YT104-YT133
I	D45213J	PERG	1F	2061Z			D43323P	PERG	1F	AE0303A	42	YT104-YT133
I	D45213J	B16		2064B	24	Y2	D43323P	B16		AE0303A	42	YT104-YT133
I	D45213J	A16		2064R	24	Y2	D43323P	A16		AE0303A	42	YT104-YT133
I	D45213J	PERG	1F	2064Z			D43323P	PERG	1F	AE0303A	42	YT104-YT133
I	AE0502A	27	W5163	RB2*	DISCONNECT BRACKET - E5-2 SHELF							
I	D45247J	A08		0013	22	PA	D43157P	A20		AE0301A	29	YT104-YT133
I	D45247J	A16		0021	20	PA	D43147P	A01		AE0301A	28	YT104-YT133
I	AE0502A	28	W5163	RB2*	DISCONNECT BRACKET - E5-2 SHELF							
I	D45257J	A15		0004	22	PA	D41157P	A18		AE0101B	12	YT104-YT133
I	D45257J	A07		0039	22	PA	D41157P	B20		AE0101B	12	YT104-YT133
I	D45257J	A02		2501B	24	Y2	D41157P	A02		AE0101B	12	YT126-YT133
I	D45257J	A01		2501R	24	Y2	D41157P	A01		AE0101B	12	YT126-YT133
I	D45257J	PERG	1F	2501Z			D41157P	PERG	1F	AE0101B	12	YT126-YT133
I	D45257J	A10		2508B	24	Y2	D43157P	A09		AE0301A	29	YT104-YT133
I	D45257J	A09		2508R	24	Y2	D43157P	A08		AE0301A	29	YT104-YT133
I	D45257J	PERG	1F	2508Z			D43157P	PERG	1F	AE0301A	29	YT104-YT133
I	D45257J	A12		2509B	24	Y2	D43157P	A11		AE0301A	29	YT104-YT133
I	D45257J	A11		2509R	24	Y2	D43157P	A10		AE0301A	29	YT104-YT133
I	D45257J	PERG	1F	2509Z			D43157P	PERG	1F	AE0301A	29	YT104-YT133

SPARE WIRE LIST

D280A351

91-21-12

Section AE0502A

Page 6

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From	Matewith	Pos	Bundle	Sep	Description		To					Effectivity	
	Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos			
I	AE0502A		29	W5463	RB2	DISCONNECT BRACKET - E5-2 SHELF								
I	D45263J	A05		0022	22	PA	D41463J	14		AE0104A	11	YT104-YT133		
I	D45263J	B14		2019B	24	Y2	D43263P	B14		AE0302A	44	YT104-YT133		
I	D45263J	A14		2019R	24	Y2	D43263P	A14		AE0302A	44	YT104-YT133		
I	D45263J	PERG	1F	2019Z			D43263P	PERG	1F	AE0302A	44	YT104-YT133		
	D45263J	A20		2022B	24	Y2	D42363P	A10		AE0302A	53	YT104-YT105		
	D45263J	A19		2022R	24	Y2	D42363P	A09		AE0302A	53	YT104-YT105		
	D45263J	PERG	1F	2022Z			D42363P	PERG	1F	AE0302A	53	YT104-YT105		
I	AE0502A		30	W2135	RB2	DISCONNECT BRACKET - E5-2 SHELF								
I	D45237J	B20		0034	22	PA	D01817	CAP	Y	P005-28		YT104-YT133		

SPARE WIRE LIST

D280A351

91-21-12

Section AE0502A

Page 7 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From Matewith	Pos	Bundle	Sep	Description		To					Pos	Effectivity	
	Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith				
I	AE0602A	08	W5105	NB2	DISCONNECT BRACKET - E6-2 SHELF									
I	D40115P	B04		2503B	24	Y2	D43361P	B06		AE0303A	34	YT107-YT133		
I	D40115P	A04		2503R	24	Y2	D43361P	A06		AE0303A	34	YT107-YT133		
I	D40115P	PERG	1F	2503Z			D43361P	PERG	1F	AE0303A	34	YT107-YT133		
I	D40115P	B07		2505B	24	Y2	D43361P	B05		AE0303A	34	YT107-YT133		
I	D40115P	A07		2505R	24	Y2	D43361P	A05		AE0303A	34	YT107-YT133		
I	D40115P	PERG	1F	2505Z			D43361P	PERG	1F	AE0303A	34	YT107-YT133		
	D40115P	B04		2503B	24	Y2	D43361P	B06		AE0303A	10	YT101-YT103		
	D40115P	B04		2503B	24	Y2	D43361P	B06		AE0303A	34	YT104-YT106		
	D40115P	A04		2503R	24	Y2	D43361P	A06		AE0303A	10	YT101-YT103		
	D40115P	A04		2503R	24	Y2	D43361P	A06		AE0303A	34	YT104-YT106		
	D40115P	PERG	1F	2503Z			D43361P	PERG	1F	AE0303A	10	YT101-YT103		
	D40115P	PERG	1F	2503Z			D43361P	PERG	1F	AE0303A	34	YT104-YT106		
	D40115P	B07		2505B	24	Y2	D43361P	B05		AE0303A	10	YT101-YT103		
	D40115P	B07		2505B	24	Y2	D43361P	B05		AE0303A	34	YT104-YT106		
	D40115P	A07		2505R	24	Y2	D43361P	A05		AE0303A	10	YT101-YT103		
	D40115P	A07		2505R	24	Y2	D43361P	A05		AE0303A	34	YT104-YT106		
	D40115P	PERG	1F	2505Z			D43361P	PERG	1F	AE0303A	10	YT101-YT103		
	D40115P	PERG	1F	2505Z			D43361P	PERG	1F	AE0303A	34	YT104-YT106		
I	AE0602A	11	W3555	RN2	DISCONNECT BRACKET - E6-2 SHELF									
I	D40125P	B02		0009	20	PA	D04245J	9		AB1030A	01	ALL		
I	D40125P	A03		0010	20	PA	D04245J	10		AB1030A	01	ALL		
I	AE0602A	12	W3553	LN2	DISCONNECT BRACKET - E6-2 SHELF									
I	D40121P	B02		0009	20	PA	D04227J	9		AB1030A	03	ALL		
I	D40121P	A03		0010	20	PA	D04227J	10		AB1030A	03	ALL		

SPARE WIRE LIST

D280A351

91-21-12

Section AE0602A

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From Matewith	Pos	Bundle	Sep	Description		To	Term	Type	Matewith	Pos	Effectivity
	From Equip	Term	Type	Wire No.	GA	TY	Equip					
I	AJ0020B	02	W5158	SB2*	DISCONNECT BRACKET-J20-B							
I	D40638P	12		0015	22	PA	D40490J	4		AE0104A	20	ALL
I	D40638P	14		0678	22	PA	D48116P	A03		AJ0048A	13	ALL
I	D40638P	2		0680	22	PA	D48116P	B04		AJ0048A	13	ALL
I	AJ0020B	03	W5158	SB2*	DISCONNECT BRACKET-J20-B							
I	D40640P	1		0706	20	PA	D46100P	24		AJ0046B	11	ALL

SPARE WIRE LIST

D280A351

91-21-12

Section AJ0020B

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From Matewith	Pos	Bundle	Sep	Description		To					Pos	Effectivity	
	From Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith				
I	AJ0022	02	W5510	SA2*	DISCONNECT BRACKET-J22									
I	D40672P	23		0010	20	PA	D40496J	19		AE0104A	21	ALL		
I	D40672P	9		0011	24	PK	D40428P	A04		AE0201A	08	ALL		
I	D40672P	12		0012	24	PK	D40428P	A08		AE0201A	08	ALL		
I	D40672P	11		5503	24	PK	D48122P	A03		AJ0048A	03	ALL		
I	D40672P	15		5510	24	PK	D48122P	B09		AJ0048A	03	ALL		
I	AJ0022	03	W5156	SA2*	DISCONNECT BRACKET-J22									
I	D40666P	31		0024	22	PA	D40576P	25		AP1800B	02	ALL		
I	D40666P	29	18	0025	18	PA	D40576P	24		AP1800B	02	ALL		
I	D40666P	25		0588	24	B6	D48114P	A03		AJ0048A	17	ALL		
I	D40666P	30		0594	24	PK	D48112P	A04		AJ0048A	16	ALL		
I	D40666P	9		0660	20	CQ	D40594P	A08		AE0302A	16	ALL		
I	D40666P	20		0668	22	PA	D40460P	B01		AE0301A	19	ALL		
I	AJ0022	06	W5100	SB2*	DISCONNECT BRACKET-J22									
I	D40668P	10		0003	24	PK	D40698P	24		AJ0024	03	ALL		
I	D40668P	31		0006	22	PA	D40698P	2		AJ0024	03	ALL		
I	D40668P	6		0007	22	PA	D40698P	5		AJ0024	03	ALL		

SPARE WIRE LIST

D280A351

91-21-12

Section AJ0022

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From Matewith	Pos	Bundle	Sep	Description		To	Term	Type	Matewith	Pos	Effectivity
	From Equip	Term	Type	Wire No.	GA	TY	Equip					
I	AJ0024	03	W5100	SB2*	DISCONNECT BRACKET-J24							
I	D40698P	24		0003	24	PK	D40668P	10		AJ0022	06	ALL
I	D40698P	2		0006	22	PA	D40668P	31		AJ0022	06	ALL
I	D40698P	5		0007	22	PA	D40668P	6		AJ0022	06	ALL
I	AJ0024	06	W5158	SB2*	DISCONNECT BRACKET-J24							
	D40702P	13		0545	20	CQ	D40426P	8		AE0302A	28	YT101-YT103
I	D40702P	13		0545	20	CQ	D40426P	A08		AE0302A	28	YT104-YT133
I	D40702P	14		0546	22	PA	D46100P	7		AJ0046B	11	ALL
I	D40702P	15		0547	22	PA	D46100P	8		AJ0046B	11	ALL
	D40702P	21		0682	20	CQ	D40426P	7		AE0302A	28	YT101-YT103
I	D40702P	21		0682	20	CQ	D40426P	A07		AE0302A	28	YT104-YT133
I	D40702P	22		0693	20	CQ	D40750P	14		AP0600B	02	ALL
I	D40702P	23		0694	20	CQ	D40750P	15		AP0600B	02	ALL
I	AJ0024	07	W5160	RB2*	DISCONNECT BRACKET-J24							
I	D40694P	16		0530	22	PA	D40474P	B02		AE0402A	37	ALL
I	D40694P	13		0588	22	GK	D46122P	13		AJ0046A	16	ALL
I	D40694P	31		0620	20	PA	D40952P	A05		AE0302A	42	ALL

SPARE WIRE LIST

D280A351

91-21-12

Section AJ0024

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From Matewith From	Pos	Bundle	Sep	Description		To					Effectivity	
	Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos		
I	AJ0046A	05	W5506	SB2*	DISCONNECT BRACKET - J46A								
I	D46128P	B10		6506	20	PA	D40800P	31		AP0600B	08	ALL	
I	AJ0046A	14	W0066	RN2	DISCONNECT BRACKET - J46A								
I	D46102J	18		0075	22	PA	D46100J	8		AJ0046B	11	ALL	
I	D46102J	19		0076	22	PA	D46100J	7		AJ0046B	11	ALL	
I	D46102J	20		0082	22	PA	D46138J	A04		AJ0046B	02	ALL	
I	AJ0046A	14	W5160	RB2*	DISCONNECT BRACKET - J46A								
I	D46102P	20		0629	22	PA	D10988	54		M02061		ALL	
I	D46102P	18		0652	22	PA	D40466P	4		AE0103A	14	ALL	
I	D46102P	19		0653	22	PA	D40466P	5		AE0103A	14	ALL	
I	AJ0046A	16	W0066	RN2	DISCONNECT BRACKET - J46A								
I	D46122J	3		0162	24	PK	D46112J	9		AJ0046B	12	ALL	
I	AJ0046A	16	W5160	RB2*	DISCONNECT BRACKET - J46A								
I	D46122P	13		0588	22	GK	D40694P	13		AJ0024	07	ALL	

SPARE WIRE LIST

D280A351

91-21-12

Section AJ0046A

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From Matewith	Pos	Bundle	Sep	Description		To	Term	Type	Matewith	Pos	Effectivity
	From Equip	Term	Type	Wire No.	GA	TY	Equip					
I	AJ0046B	02	W0066	RN2	DISCONNECT BRACKET - J46B							
I	D46138J	A04		0082	22	PA	D46102J	20		AJ0046A	14	ALL
I	D46138J	A05		0083	22	PA	D46100J	9		AJ0046B	11	ALL
I	AJ0046B	11	W0066	RN2	DISCONNECT BRACKET - J46B							
I	D46100J	8		0075	22	PA	D46102J	18		AJ0046A	14	ALL
I	D46100J	7		0076	22	PA	D46102J	19		AJ0046A	14	ALL
I	D46100J	9		0083	22	PA	D46138J	A05		AJ0046B	02	ALL
I	AJ0046B	11	W5158	SB2*	DISCONNECT BRACKET - J46B							
I	D46100P	7		0546	22	PA	D40702P	14		AJ0024	06	ALL
I	D46100P	8		0547	22	PA	D40702P	15		AJ0024	06	ALL
I	D46100P	18		0690	20	CQ	D40750P	4		AP0600B	02	ALL
I	D46100P	9		0695	22	PA	D40750P	6		AP0600B	02	ALL
I	D46100P	24		0706	20	PA	D40640P	1		AJ0020B	03	ALL
I	AJ0046B	12	W0066	RN2	DISCONNECT BRACKET - J46B							
I	D46112J	9		0162	24	PK	D46122J	3		AJ0046A	16	ALL

SPARE WIRE LIST

D280A351

91-21-12

Section AJ0046B

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To						
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AJ0048A	01	W2104	LA1	DISCONNECT BRACKET - J48A							
D48100P	A10		0612	20 PA	D31018J	A10		AC0235A	02	YT101-YT120	
D48100P	B10		0613	20 PA	D31018J	B10		AC0235A	02	YT101-YT120	
AJ0048A	03	W5510	SA2*	DISCONNECT BRACKET - J48A							
D48122P	A03		5503	24 PK	D40672P	11		AJ0022	02	ALL	
D48122P	B09		5510	24 PK	D40672P	15		AJ0022	02	ALL	
AJ0048A	13	W0088	LN2	DISCONNECT BRACKET - J48A							
D48116J	A03		0047	22 PA	D48104J	A07		AJ0048A	20	ALL	
AJ0048A	13	W5158	SB2*	DISCONNECT BRACKET - J48A							
D48116P	A03		0678	22 PA	D40638P	14		AJ0020B	02	ALL	
D48116P	B04		0680	22 PA	D40638P	2		AJ0020B	02	ALL	
AJ0048A	16	W5156	SA2*	DISCONNECT BRACKET - J48A							
D48112P	A04		0594	24 PK	D40666P	30		AJ0022	03	ALL	
AJ0048A	17	W0088	LN2	DISCONNECT BRACKET - J48A							
D48114J	B07		0123	22 G5	D48130J	A05		AJ0048A	23	ALL	
D48114J	B08		0124	22 G5	D48130J	A06		AJ0048A	23	ALL	
D48114J	B09		0125	22 G5	D48130J	A07		AJ0048A	23	ALL	
D48114J	B10		0126	22 G5	D48130J	A08		AJ0048A	23	ALL	
AJ0048A	17	W5156	SA2*	DISCONNECT BRACKET - J48A							
D48114P	A03		0588	24 B6	D40666P	25		AJ0022	03	ALL	
D48114P	B07		0671	22 PA	D40594P	A02		AE0302A	16	ALL	
D48114P	B08		0672	22 PA	D40594P	B02		AE0302A	16	ALL	
D48114P	B09		0673	22 PA	D40594P	B01		AE0302A	16	ALL	
D48114P	B10		0674	22 PA	D40594P	A01		AE0302A	16	ALL	
AJ0048A	20	W0088	LN2	DISCONNECT BRACKET - J48A							
D48104J	A07		0047	22 PA	D48116J	A03		AJ0048A	13	ALL	
AJ0048A	23	W0088	LN2	DISCONNECT BRACKET - J48A							
D48130J	A05		0123	22 G5	D48114J	B07		AJ0048A	17	ALL	
D48130J	A06		0124	22 G5	D48114J	B08		AJ0048A	17	ALL	

SPARE WIRE LIST

D280A351

91-21-12

Section AJ0048A

Page 1

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description		To						
Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AJ0048A	23	W0088	LN2	DISCONNECT BRACKET - J48A (continued)								
D48130J	A07		0125	22	G5	D48114J	B09		AJ0048A	17	ALL	
D48130J	A08		0126	22	G5	D48114J	B10		AJ0048A	17	ALL	

SPARE WIRE LIST

D280A351

91-21-12

Section AJ0048A

Page 2 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From	Matewith	Pos	Bundle	Sep	Description		To					Pos	Effectivity	
	Equip		Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith				
I	AP0600A		04	W6214	LA2*	DISCONNECT BRACKET-P5-P6 INTEGRATION									
I	D40444P		9		5540	20	PA	D40378P	B16		AE0401A	46	ALL		
I	D40444P		10		5541	20	PA	D40378P	B14		AE0401A	46	ALL		
I	D40444P		4		5544	20	PA	D40328P	B02		AE0401A	31	ALL		
I	D40444P		5		5545	20	PA	D40328P	B03		AE0401A	31	ALL		
I	AP0600A		05	W3058	RN2	DISCONNECT BRACKET-P5-P6 INTEGRATION									
I	D40226P		CAP	Y	0320	20	PA	GD11106	ST..	1			YT101-YT131		
I	D40226P		8		0381	20	PA	D40050J	8		AB0340A	05	YT101-YT131		
I	D40226P		9		0382	20	PA	D40050J	9		AB0340A	05	YT101-YT131		
I	D40226P		12		0383	20	PA	D40050J	11		AB0340A	05	YT101-YT131		

SPARE WIRE LIST

D280A351

91-21-12

Section AP0600A

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From Matewith	Pos	Bundle	Sep	Description		To					Pos	Effectivity	
	Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith				
I	AP0600B	01	W2709	NB2	DISCONNECT BRACKET-LOWER P6 PANEL									
I	D40067P	9		0015	24	PK	D00404	A05		AE0401D	14	ALL		
I	D40067P	10		0016	24	PK	D00404	B05		AE0401D	14	ALL		
I	AP0600B	02	W5158	SB2*	DISCONNECT BRACKET-LOWER P6 PANEL									
I	D40750P	4		0690	20	CQ	D46100P	18		AJ0046B	11	ALL		
I	D40750P	14		0693	20	CQ	D40702P	22		AJ0024	06	ALL		
I	D40750P	15		0694	20	CQ	D40702P	23		AJ0024	06	ALL		
I	D40750P	6		0695	22	PA	D46100P	9		AJ0046B	11	ALL		
I	D40750P	10		0707	22	PA	TB1808X	A003	%A			YT101-YT103		
I	D40750P	10		0707	22	PA	TB1808X	A003	1A			YT104-YT133		
I	AP0600B	04	W2169	RB2	DISCONNECT BRACKET-LOWER P6 PANEL									
I	D46063P	1		0001	20	PA	D46035P	1		AE0301A	24	ALL		
I	D46063P	2		0002	22	PA	D46035P	2		AE0301A	24	ALL		
I	D46063P	3		0003	20	PA	D46035P	3		AE0301A	24	ALL		
I	D46063P	9		0009	20	PA	D46035P	9		AE0301A	24	ALL		
I	D46063P	11		0011	20	PA	D46043P	11		AE0302A	30	YT101-YT103		
I	D46063P	11		0011	20	PA	D46043P	B01		AE0302A	30	YT104-YT133		
I	D46063P	12		0012	20	CQ	D46043P	12		AE0302A	30	YT101-YT103		
I	D46063P	12		0012	20	CQ	D46043P	B02		AE0302A	30	YT104-YT133		
	AP0600B	05	W2138	LA1	DISCONNECT BRACKET-LOWER P6 PANEL									
	D41430P	3		5503	16	HA	D41432P	3		AE0201A	15	YT101-YT116, YT126-YT131		
I	AP0600B	07	W6412	RB2*	DISCONNECT BRACKET-LOWER P6 PANEL									
I	D41832P	7		0029	20	PA	D41830P	A06		AE0401A	13	ALL		
I	AP0600B	08	W5506	SB2*	DISCONNECT BRACKET-LOWER P6 PANEL									
I	D40800P	31		6506	20	PA	D46128P	B10		AJ0046A	05	ALL		
I	AP0600B	09	W6110	LA2*	DISCONNECT BRACKET-LOWER P6 PANEL									
I	D40368P	5		0520	22	PA	D40364P	A04		AE0101A	12	ALL		
I	D40368P	6		0521	22	PA	D40364P	B03		AE0101A	12	ALL		
I	AP0600B	10	W2231	RB2	DISCONNECT BRACKET-LOWER P6 PANEL									
I	D46067P	6		0006	20	PA	D46017P	6		AE0301A	23	ALL		

SPARE WIRE LIST

D280A351

91-21-12

Section AP0600B

Page 1

Jun 21/2016

From Matewith From Equip	Pos Term	Bundle Type	Sep Wire No.	Description GA TY	To Equip	Term	Type	Matewith	Pos	Effectivity
AP0600B	10	W2231	RB2	DISCONNECT BRACKET-LOWER P6 PANEL (continued)						
D46067P	7		0007	20 PA	D46017P	5		AE0301A	23	ALL
D46067P	9		0009	20 PA	D46021P	9		AE0302A	25	YT101-YT103
D46067P	9		0009	20 PA	D46021P	A09		AE0302A	25	YT104-YT133
D46067P	10		0010	20 PA	D46021P	1		AE0302A	25	YT101-YT103
D46067P	10		0010	20 PA	D46021P	A01		AE0302A	25	YT104-YT133
D46067P	11		0011	20 PA	D46021P	2		AE0302A	25	YT101-YT103
D46067P	11		0011	20 PA	D46021P	A02		AE0302A	25	YT104-YT133
D46067P	12		0012	20 PA	D46021P	3		AE0302A	25	YT101-YT103
D46067P	12		0012	20 PA	D46021P	A03		AE0302A	25	YT104-YT133
D46067P	19		0019	16 CQ	D43309P	7		AE0303A	29	YT101-YT103
D46067P	19		0019	16 CQ	D43309P	8		AE0303A	52	YT104-YT133
D46067P	27		0027	16 PA	D46017P	7		AE0301A	23	ALL
D46067P	28		0028	20 PA	D46017P	8		AE0301A	23	ALL
AP0600B	11	W2030	SN2	DISCONNECT BRACKET-LOWER P6 PANEL						
D46052P	9		5516	20 PA	D40924P	5		AP0900A	14	ALL
D46052P	11		5522	20 PA	D40924P	3		AP0900A	14	ALL
D46052P	12		5523	20 PA	D40924P	7		AP0900A	14	ALL
D46052P	26		5526	20 PA	D40924P	25		AP0900A	14	ALL
D46052P	27		5527	20 PA	D40924P	26		AP0900A	14	ALL
AP0600B	13	W2597	NA2	DISCONNECT BRACKET-LOWER P6 PANEL						
D40625P	40		0017	22 PA	D45225J	B20		AE0502A	21	YT101-YT103
D40625P	40		0017	22 PA	D45225J	B20		AE0502A	09	YT104-YT133
D40625P	12		2502B	22 X2	D45225J	B04		AE0502A	21	YT101-YT103
D40625P	12		2502B	22 X2	D45225J	B04		AE0502A	09	YT104-YT133
D40625P	11		2502R	22 X2	D45225J	B03		AE0502A	21	YT101-YT103
D40625P	11		2502R	22 X2	D45225J	B03		AE0502A	09	YT104-YT133
D40625P	S/R		2502Z		D45225J	PERG	1F	AE0502A	21	YT101-YT103
D40625P	S/R		2502Z		D45225J	PERG	1F	AE0502A	09	YT104-YT133
D40625P	7		2509B	24 Y2	D45225J	A20		AE0502A	21	YT101-YT103
D40625P	7		2509B	24 Y2	D45225J	A20		AE0502A	09	YT104-YT133
D40625P	6		2509R	24 Y2	D45225J	A19		AE0502A	21	YT101-YT103
D40625P	6		2509R	24 Y2	D45225J	A19		AE0502A	09	YT104-YT133
D40625P	S/R		2509Z		D45225J	PERG	1F	AE0502A	21	YT101-YT103
D40625P	S/R		2509Z		D45225J	PERG	1F	AE0502A	09	YT104-YT133
D40625P	39		2513B	22 X2	D45225J	B14		AE0502A	21	YT101-YT103
D40625P	39		2513B	22 X2	D45225J	B14		AE0502A	09	YT104-YT133

SPARE WIRE LIST

D280A351

91-21-12

Section AP0600B

Page 2

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AP0600B	13	W2597	NA2	DISCONNECT BRACKET-LOWER P6 PANEL (continued)								
I D40625P	38		2513R	22 X2	D45225J	B13		AE0502A	21	YT101-YT103		
I D40625P	38		2513R	22 X2	D45225J	B13		AE0502A	09	YT104-YT133		
I D40625P	S/R		2513Z		D45225J	PERG	1F	AE0502A	21	YT101-YT103		
I D40625P	S/R		2513Z		D45225J	PERG	1F	AE0502A	09	YT104-YT133		
AP0600B	14	W6412	RB2*	DISCONNECT BRACKET-LOWER P6 PANEL								
I D40386P	27		0008	20 PA	D41010P	18		AE0401A	33	ALL		
I D40386P	31		0009	20 PA	D41010P	19		AE0401A	33	ALL		
I D40386P	32		0010	20 PA	D41010P	20		AE0401A	33	ALL		
I D40386P	9		5508	22 PA	D40390P	A19		AE0401A	52	ALL		
I D40386P	24		5533	20 PA	D40388P	A16		AE0402A	24	ALL		
I D40386P	23		5534	20 PA	D40392P	A18		AE0302A	45	ALL		
I D40386P	29		5535	20 PA	D40394P	A15		AE0301A	34	ALL		
AP0600B	15	W2383	RB2	DISCONNECT BRACKET-LOWER P6 PANEL								
I D46065P	9		0009	24 PK	D46031J	9		AE0104A	10	ALL		
I D46065P	15		0015	24 PK	D46033P	5		AP0900A	16	ALL		
I D46065P	19		0019	20 PA	D46033P	9		AP0900A	16	ALL		
I D46065P	23		0023	20 PA	D46023P	A05		AE0101B	09	ALL		
I D46065P	24		0024	20 PA	D46031J	8		AE0104A	10	ALL		
I D46065P	26		0026	22 PA	D46031J	6		AE0104A	10	ALL		
I D46065P	31		0031	20 PA	D46033P	1		AP0900A	16	ALL		
AP0600B	16	W5612	SN2*	DISCONNECT BRACKET-LOWER P6 PANEL								
I D40352P	21		0554	24 PK	D40362P	A03		AE0302A	05	ALL		
I D40352P	28		2204B	24 Y2	D40358P	B05		AE0201A	18	ALL		
I D40352P	9		2204R	24 Y2	D40358P	B04		AE0201A	18	ALL		
I D40352P	DED		2204Z		D40358P	DED		AE0201A	18	ALL		
AP0600B	17	W6208	RA2	DISCONNECT BRACKET-LOWER P6 PANEL								
D40820P	10		0512	16 PA	TB0606V	B013	1			YT101-YT112, YT126-YT130		
AP0600B	20	W2661	SB2	DISCONNECT BRACKET-LOWER P6 PANEL								
I D46069P	7		0007	18 PA	D46051P	7		AE0103A	03	ALL		
I D46069P	10		0010	16 PA	D46051P	10		AE0103A	03	ALL		

SPARE WIRE LIST

D280A351

91-21-12

Section AP0600B

Page 3

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From	Matewith	Pos	Bundle	Sep	Description		To					Effectivity	
	Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos			
I	AP0600B		22	W6414	RB2	DISCONNECT BRACKET-LOWER P6 PANEL								
I	D40396P		6		0502	24	PK	D11448	4		P0092		ALL	
I	D40396P		4		5508	18	PA	D11448	33		P0092		ALL	
I	AP0600B		23	W2103	RB2	DISCONNECT BRACKET-LOWER P6 PANEL								
I	D46061P		5		0005	20	PA	D46013P	A05		AE0101B	13	ALL	
I	D46061P		6		0006	20	PA	D46013P	A06		AE0101B	13	ALL	
I	D46061P		12		0012	20	PA	D46011J	12		AE0104A	09	ALL	
I	D46061P		13		0013	20	PA	D46011J	13		AE0104A	09	ALL	
I	D46061P		17		0017	20	PA	D46011J	7		AE0104A	09	ALL	
I	D46061P		18		0018	20	PA	D46013P	A08		AE0101B	13	ALL	

SPARE WIRE LIST

D280A351

91-21-12

Section AP0600B

Page 4 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From Matewith	Pos	Bundle	Sep	Description		To					Pos	Effectivity	
	Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith				
I	AP0900A	03	W0001	NA2	DISCONNECT BRACKET-P9-FWD INSTR PANEL									
I	D04207J	33		0168	22	PA	TB0201Z	A001	1A				ALL	
I	AP0900A	03	W2207	NA2	DISCONNECT BRACKET-P9-FWD INSTR PANEL									
I	D04207P	13		0003	22	PA	D04267P	A13		AE0301A	06	ALL		
I	D04207P	14		0004	22	PA	D04267P	A14		AE0301A	06	ALL		
I	D04207P	31		0031	22	PA	D04267P	B11		AE0301A	06	ALL		
I	D04207P	32		0032	22	PA	D04267P	B12		AE0301A	06	ALL		
I	D04207P	37		0037	22	PA	D04267P	B17		AE0301A	06	ALL		
I	D04207P	38		0038	22	PA	D04267P	B18		AE0301A	06	ALL		
I	D04207P	40		0040	22	CQ	D04267P	B19		AE0301A	06	ALL		
I	D04207P	41		0041	22	CQ	D04267P	B20		AE0301A	06	ALL		
I	D04207P	6		2003B	24	Y2	D04267P	A06		AE0301A	06	ALL		
I	D04207P	5		2003R	24	Y2	D04267P	A05		AE0301A	06	ALL		
I	D04207P	S/R		2003Z			D04267P	PERG	1F	AE0301A	06	ALL		
I	D04207P	8		2004B	24	Y2	D04267P	A08		AE0301A	06	ALL		
I	D04207P	7		2004R	24	Y2	D04267P	A07		AE0301A	06	ALL		
I	D04207P	S/R		2004Z			D04267P	PERG	1F	AE0301A	06	ALL		
I	D04207P	16		2008B	24	Y2	D04267P	A16		AE0301A	06	ALL		
I	D04207P	15		2008R	24	Y2	D04267P	A15		AE0301A	06	ALL		
I	D04207P	S/R		2008Z			D04267P	PERG	1F	AE0301A	06	ALL		
I	D04207P	20		2010B	24	Y2	D04267P	A20		AE0301A	06	ALL		
I	D04207P	19		2010R	24	Y2	D04267P	A19		AE0301A	06	ALL		
I	D04207P	S/R		2010Z			D04267P	PERG	1F	AE0301A	06	ALL		
I	AP0900A	05	W5514	SA2	DISCONNECT BRACKET-P9-FWD INSTR PANEL									
I	D40824P	28		0502	24	B6	D40826J	7		AE0104A	27	ALL		
I	D40824P	29		0503	24	B6	D40826J	16		AE0104A	27	ALL		
I	D40824P	30		0504	24	B6	D40826J	17		AE0104A	27	ALL		
I	D40824P	31		0505	24	B6	D40826J	18		AE0104A	27	ALL		
I	D40824P	19		5564	20	PA	D40826J	6		AE0104A	27	ALL		
I	D40824P	20		5565	20	PA	D40826J	8		AE0104A	27	ALL		
I	D40824P	32		5570	20	PA	D40830P	1		AP1800B	07	ALL		
I	D40824P	33		5571	20	PA	D40830P	2		AP1800B	07	ALL		
I	AP0900A	06	W0003	NB2	DISCONNECT BRACKET-P9-FWD INSTR PANEL									
I	D04237J	33		0609	22	PA	D01205	CAP	Y	P003-07		ALL		

SPARE WIRE LIST

D280A351

91-21-12

Section AP0900A

Page 1

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From Matewith	Pos	Bundle	Sep	Description		To					Pos	Effectivity	
	Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith				
I	AP0900A	06	W2237	NB2	DISCONNECT BRACKET-P9-FWD INSTR PANEL									
I	D04237P	13		0003	22	PA	D04297P	A13		AE0301A	31	ALL		
I	D04237P	14		0004	22	PA	D04297P	A14		AE0301A	31	ALL		
I	D04237P	29		0029	22	PA	D04297P	B09		AE0301A	31	ALL		
I	D04237P	30		0030	22	PA	D04297P	B10		AE0301A	31	ALL		
I	D04237P	31		0031	22	PA	D04297P	B11		AE0301A	31	ALL		
I	D04237P	32		0032	22	PA	D04297P	B12		AE0301A	31	ALL		
I	D04237P	37		0037	22	PA	D04297P	B17		AE0301A	31	ALL		
I	D04237P	38		0038	22	PA	D04297P	B18		AE0301A	31	ALL		
I	D04237P	40		0040	22	CQ	D04297P	B19		AE0301A	31	ALL		
I	D04237P	41		0041	22	CQ	D04297P	B20		AE0301A	31	ALL		
I	D04237P	6		2003B	24	Y2	D04297P	A06		AE0301A	31	ALL		
I	D04237P	5		2003R	24	Y2	D04297P	A05		AE0301A	31	ALL		
I	D04237P	S/R		2003Z			D04297P	PERG	1F	AE0301A	31	ALL		
I	D04237P	8		2004B	24	Y2	D04297P	A08		AE0301A	31	ALL		
I	D04237P	7		2004R	24	Y2	D04297P	A07		AE0301A	31	ALL		
I	D04237P	S/R		2004Z			D04297P	PERG	1F	AE0301A	31	ALL		
I	D04237P	16		2008B	24	Y2	D04297P	A16		AE0301A	31	ALL		
I	D04237P	15		2008R	24	Y2	D04297P	A15		AE0301A	31	ALL		
I	D04237P	S/R		2008Z			D04297P	PERG	1F	AE0301A	31	ALL		
I	D04237P	18		2009B	24	Y2	D04297P	A18		AE0301A	31	ALL		
I	D04237P	17		2009R	24	Y2	D04297P	A17		AE0301A	31	ALL		
I	D04237P	S/R		2009Z			D04297P	PERG	1F	AE0301A	31	ALL		
I	D04237P	20		2010B	24	Y2	D04297P	A20		AE0301A	31	ALL		
I	D04237P	19		2010R	24	Y2	D04297P	A19		AE0301A	31	ALL		
I	D04237P	S/R		2010Z			D04297P	PERG	1F	AE0301A	31	ALL		
I	D04237P	22		2011B	24	Y2	D04297P	B02		AE0301A	31	ALL		
I	D04237P	21		2011R	24	Y2	D04297P	B01		AE0301A	31	ALL		
I	D04237P	S/R		2011Z			D04297P	PERG	1F	AE0301A	31	ALL		
I	D04237P	24		2012B	24	Y2	D04297P	B04		AE0301A	31	ALL		
I	D04237P	23		2012R	24	Y2	D04297P	B03		AE0301A	31	ALL		
I	D04237P	S/R		2012Z			D04297P	PERG	1F	AE0301A	31	ALL		
I	AP0900A	08	W2705	NA2	DISCONNECT BRACKET-P9-FWD INSTR PANEL									
I	D00308	18		0004	24	PK	D00414	A07		AE0401D	04	ALL		
I	D00308	19		0022	24	PK	D00414	B07		AE0401D	04	ALL		
I	AP0900A	09	W0003	NB2	DISCONNECT BRACKET-P9-FWD INSTR PANEL									
I	D04221J	13		0595	22	CQ	D03991	6		P003-01		ALL		

SPARE WIRE LIST

D280A351

91-21-12

Section AP0900A

Page 2

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From Matewith	Pos	Bundle	Sep	Description		To				Pos	Effectivity
	From Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith		
I	AP0900A	14	W2030	SN2	DISCONNECT BRACKET-P9-FWD INSTR PANEL							
I	D40924P	5		5516	20	PA	D46052P	9		AP0600B	11	ALL
I	D40924P	3		5522	20	PA	D46052P	11		AP0600B	11	ALL
I	D40924P	7		5523	20	PA	D46052P	12		AP0600B	11	ALL
I	D40924P	25		5526	20	PA	D46052P	26		AP0600B	11	ALL
I	D40924P	26		5527	20	PA	D46052P	27		AP0600B	11	ALL
I	AP0900A	16	W2383	RB2	DISCONNECT BRACKET-P9-FWD INSTR PANEL							
I	D46033P	5		0015	24	PK	D46065P	15		AP0600B	15	ALL
I	D46033P	9		0019	20	PA	D46065P	19		AP0600B	15	ALL
I	D46033P	1		0031	20	PA	D46065P	31		AP0600B	15	ALL
I	AP0900A	17	W2175	LA2	DISCONNECT BRACKET-P9-FWD INSTR PANEL							
I	D41823P	4		0016	16	PA	D41803P	16		AP1800B	06	ALL
I	D41823P	9		0019	20	PA	D41803P	19		AP1800B	06	ALL
I	D41823P	10		0020	16	PA	D41803P	20		AP1800B	06	ALL
I	D41823P	1		0021	20	PA	D41803P	21		AP1800B	06	ALL
I	D41823P	3		0023	20	PA	D41803P	23		AP1800B	06	ALL
I	D41823P	5		0025	20	PA	D41803P	25		AP1800B	06	ALL
I	AP0900A	19	W2651	SA2	DISCONNECT BRACKET-P9-FWD INSTR PANEL							
I	D41833P	2		0018	20	PA	D41807P	18		AP1800B	08	ALL
I	D41833P	3		0020	20	PA	D41807P	20		AP1800B	08	ALL
I	D41833P	5		0021	20	PA	D41807P	21		AP1800B	08	ALL
I	D41833P	6		0022	20	PA	D41807P	22		AP1800B	08	ALL
I	D41833P	8		0024	20	PA	D41807P	24		AP1800B	08	ALL
I	AP0900A	22	W2709	NB2	DISCONNECT BRACKET-P9-FWD INSTR PANEL							
I	D00322	10		0017	24	PK	D00415	A06		AE0401D	15	ALL
I	D00322	11		0018	24	PK	D00415	B05		AE0401D	15	ALL
I	AP0900A	23	W2251	RF2	DISCONNECT BRACKET-P9-FWD INSTR PANEL							
I	D04251P	3		0003	22	PA	D04311J	3		AE0104A	06	ALL
I	D04251P	7		0007	22	CQ	D04311J	7		AE0104A	06	ALL
I	D04251P	9		0009	22	CQ	D04311J	9		AE0104A	06	ALL
I	D04251P	12		0012	20	PA	D04311J	12		AE0104A	06	ALL
I	D04251P	20		2003B	24	Y2	D04311J	20		AE0104A	06	ALL
I	D04251P	19		2003R	24	Y2	D04311J	19		AE0104A	06	ALL

SPARE WIRE LIST

D280A351

91-21-12

Section AP0900A

Page 3

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

From	Matewith	Pos	Bundle	Sep	Description		To					
Equip	Term	Type	Wire No.		GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity
AP0900A	23	W2251	RF2	DISCONNECT BRACKET-P9-FWD INSTR PANEL (continued)								
D04251P	S/R		2003Z				D04311J	S/R		AE0104A	06	ALL
D04251P	22		2004B		24	Y2	D04311J	22		AE0104A	06	ALL
D04251P	21		2004R		24	Y2	D04311J	21		AE0104A	06	ALL
D04251P	S/R		2004Z				D04311J	S/R		AE0104A	06	ALL

SPARE WIRE LIST

D280A351

91-21-12

Section AP0900A

Page 4 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From Matewith	Pos	Bundle	Sep	Description		To				Pos	Effectivity
	From Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith		
I	AP1800A	01	W3150	LN2*	DISCONNECT BRACKET-P5-P18 INTEGRATION							
I	D40198P	1		0901	20	PA	D40270P	2		D40270J		ALL
I	D40198P	2		0902	20	PA	D40270P	3		D40270J		ALL
I	D40198P	3		0903	20	PA	D40270P	8		D40270J		ALL
I	D40198P	4		0904	20	PA	D40270P	9		D40270J		ALL
I	AP1800A	06	W3144	LN2*	DISCONNECT BRACKET-P5-P18 INTEGRATION							
I	D40220P	13		0013	20	PA	D03738	CAP	Y	M01418		ALL
I	D40220P	14		0014	20	PA	D03738	CAP	Y	M01418		ALL
I	D40220P	15		0015	20	PA	D03732	CAP	Y	M01415		ALL
I	D40220P	16		0016	20	PA	D03732	CAP	Y	M01415		ALL
I	D40220P	21		0021	16	PA	D40216P	7		AB0340A	02	ALL
I	AP1800A	07	W4250	RN2*	DISCONNECT BRACKET-P5-P18 INTEGRATION							
I	D40298P	1		0901	20	PA	D40272P	2		D40272J		ALL
I	D40298P	3		0903	20	PA	D40272P	8		D40272J		ALL
I	D40298P	4		0904	20	PA	D40272P	9		D40272J		ALL
I	AP1800A	12	W3004	NN2	DISCONNECT BRACKET-P5-P18 INTEGRATION							
I	D40687P	3		0003	22	PA	D40751J	3		D40751P		YT105-YT133

SPARE WIRE LIST

D280A351

91-21-12

Section AP1800A

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From	Pos	Bundle	Sep	Description		To	Term	Type	Matewith	Pos	Effectivity
	Matewith From Equip	Term	Type	Wire No.	GA	TY	Equip					
I	AP1800B	01	W2201	LA2	DISCONNECT BRACKET-LOWER P18 PANEL							
I	D41805P	1		0001	20	PA	D41817P	1		AE0301A	21	ALL
I	D41805P	2		0002	20	PA	D41817P	2		AE0301A	21	ALL
I	D41805P	3		0003	20	PA	D41817P	3		AE0301A	21	ALL
I	D41805P	10		0010	20	PA	D41817P	12		AE0301A	21	ALL
I	D41805P	11		0011	20	PA	D41817P	11		AE0301A	21	ALL
I	D41805P	13		0013	20	PA	D41819P	13		AE0302A	27	ALL
I	D41805P	16		0016	20	PA	D41819P	16		AE0302A	27	ALL
I	D41805P	17		0017	20	PA	D41819P	17		AE0302A	27	ALL
I	D41805P	18		0018	20	PA	D41819P	18		AE0302A	27	ALL
I	D41805P	19		0019	16	PA	D41817P	4		AE0301A	21	ALL
I	D41805P	21		0021	20	PA	D41817P	5		AE0301A	21	ALL
	D41805P	26		0026	22	CQ	D43313P	6		AE0303A	28	YT101-YT103
	D41805P	26		0026	22	CQ	D43313P	2		AE0303A	28	YT104-YT120
I	D41805P	26		0026	22	PA	D43313P	2		AE0303A	28	YT126-YT133
I	AP1800B	02	W5156	SA2*	DISCONNECT BRACKET-LOWER P18 PANEL							
I	D40576P	25		0024	22	PA	D40666P	31		AJ0022	03	ALL
I	D40576P	24		0025	18	PA	D40666P	29	18	AJ0022	03	ALL
I	AP1800B	03	W2101	LA2	DISCONNECT BRACKET-LOWER P18 PANEL							
I	D41801P	1		0001	20	PA	D41811P	A01		AE0101A	13	ALL
I	D41801P	2		0002	20	PA	D41811P	A02		AE0101A	13	ALL
I	D41801P	3		0003	20	PA	D41811P	A03		AE0101A	13	ALL
I	D41801P	8		0008	22	PA	D41811P	A08		AE0101A	13	ALL
I	D41801P	9		0009	22	PA	D41811P	A09		AE0101A	13	ALL
I	D41801P	10		0010	20	PA	D41811P	A10		AE0101A	13	ALL
I	D41801P	11		0011	20	PA	D41811P	B01		AE0101A	13	ALL
I	D41801P	12		0012	20	PA	D41811P	B02		AE0101A	13	ALL
I	D41801P	13		0013	20	PA	D41811P	B03		AE0101A	13	ALL
I	D41801P	14		0014	20	PA	D41811P	B04		AE0101A	13	ALL
I	D41801P	15		0015	20	PA	D41811P	B05		AE0101A	13	ALL
I	AP1800B	06	W2175	LA2	DISCONNECT BRACKET-LOWER P18 PANEL							
I	D41803P	6		0006	22	PA	D41821P	A06		AE0101A	24	ALL
I	D41803P	8		0008	20	PA	D41821P	A08		AE0101A	24	ALL
I	D41803P	9		0009	22	PA	D41821P	A09		AE0101A	24	ALL
I	D41803P	10		0010	22	PA	D41821P	A10		AE0101A	24	ALL
I	D41803P	12		0012	20	PA	D41821P	B02		AE0101A	24	ALL

SPARE WIRE LIST

D280A351

91-21-12

Section AP1800B

Page 1

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AP1800B	06	W2175	LA2	DISCONNECT BRACKET-LOWER P18 PANEL (continued)								
D41803P	13		0013	20 PA	D41821P	B03		AE0101A	24	ALL		
D41803P	15		0015	20 PA	D41821P	B05		AE0101A	24	ALL		
D41803P	16		0016	16 PA	D41823P	4		AP0900A	17	ALL		
D41803P	17		0017	20 PA	D41821P	B07		AE0101A	24	ALL		
D41803P	19		0019	20 PA	D41823P	9		AP0900A	17	ALL		
D41803P	20		0020	16 PA	D41823P	10		AP0900A	17	ALL		
D41803P	21		0021	20 PA	D41823P	1		AP0900A	17	ALL		
D41803P	23		0023	20 PA	D41823P	3		AP0900A	17	ALL		
D41803P	CAP	Y	0024	16 PA	D41821P	G		AE0101A	24	ALL		
D41803P	25		0025	20 PA	D41823P	5		AP0900A	17	ALL		
AP1800B	07	W5514	SA2	DISCONNECT BRACKET-LOWER P18 PANEL								
D40830P	1		5570	20 PA	D40824P	32		AP0900A	05	ALL		
D40830P	2		5571	20 PA	D40824P	33		AP0900A	05	ALL		
D40830P	3		5572	20 PA	D40826J	12		AE0104A	27	ALL		
D40830P	4		5573	20 PA	D40826J	13		AE0104A	27	ALL		
AP1800B	08	W2651	SA2	DISCONNECT BRACKET-LOWER P18 PANEL								
D41807P	1		0001	20 PA	D41827J	11		AE0102A	06	ALL		
D41807P	23		0008	22 CQ	SP02185		S			ALL		
D41807P	9		0009	22 CQ	SP02186		S			ALL		
D41807P	27		0010	20 PA	SP02085		S			ALL		
D41807P	12		0012	20 PA	D41831P	1		AE0103A	17	ALL		
D41807P	13		0013	20 PA	D41831P	2		AE0103A	17	ALL		
D41807P	18		0018	20 PA	D41833P	2		AP0900A	19	ALL		
D41807P	6		0019	16 PA	D41831P	7		AE0103A	17	ALL		
D41807P	20		0020	20 PA	D41833P	3		AP0900A	19	ALL		
D41807P	21		0021	20 PA	D41833P	5		AP0900A	19	ALL		
D41807P	22		0022	20 PA	D41833P	6		AP0900A	19	ALL		
D41807P	24		0024	20 PA	D41833P	8		AP0900A	19	ALL		
AP1800B	09	W2653	SA2	DISCONNECT BRACKET-LOWER P18 PANEL								
D41809P	1		0001	20 PA	D41837P	1		AE0301A	22	ALL		
D41809P	2		0002	22 PA	D41837P	2		AE0301A	22	ALL		
D41809P	11		0011	20 PA	D41839P	1		AE0302A	26	YT101-YT103		
D41809P	11		0011	20 PA	D41839P	A01		AE0302A	26	YT104-YT133		
D41809P	12		0012	20 PA	D41839P	2		AE0302A	26	YT101-YT103		
D41809P	12		0012	20 PA	D41839P	A02		AE0302A	26	YT104-YT133		

SPARE WIRE LIST

D280A351

91-21-12

Section AP1800B

Page 2

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

From	Matewith	Pos	Bundle	Sep	Description		To					
Equip		Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity
AP1800B		09	W2653	SA2	DISCONNECT BRACKET-LOWER P18 PANEL (continued)							
D41809P		19		0019	16	PA	D41837P	7		AE0301A	22	ALL
D41809P		23		0023	18	PA	D41837P	10		AE0301A	22	ALL

SPARE WIRE LIST

D280A351

91-21-12

Section AP1800B

Page 3 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From Matewith	Pos	Bundle	Sep	Description		To					Pos	Effectivity	
	Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith				
I	AS0001L	01	W1168	LB2	DISCONNECT BRACKET-FIRE WALL(STRUT SIDE)									
I	D30260	39		2016B	20	E5	D30084	31		AW0258L	03	ALL		
I	D30260	22		2016R	20	E5	D30084	30		AW0258L	03	ALL		
I	D30260	PERB		2016Z			D30084	PERB		AW0258L	03	ALL		
I	AS0001L	03	W1170	LA2	DISCONNECT BRACKET-FIRE WALL(STRUT SIDE)									
I	D30212	2		2005B	20	HQ	D08056P	14		AW0258L	06	ALL		
I	D30212	1		2005R	20	HQ	D08056P	4		AW0258L	06	ALL		
I	D30212	S/R		2005Z			D08056P	S/R		AW0258L	06	ALL		
I	AS0001L	04	W1170	LA2	DISCONNECT BRACKET-FIRE WALL(STRUT SIDE)									
I	D30252	4		2004B	20	HQ	D08056P	13		AW0258L	06	ALL		
I	D30252	3		2004R	20	HQ	D08056P	12		AW0258L	06	ALL		
I	D30252	S/R		2004Z			D08056P	S/R		AW0258L	06	ALL		
I	AS0001L	05	W1166	SB2	DISCONNECT BRACKET-FIRE WALL(STRUT SIDE)									
I	D30220	2		2001B	20	HQ	D30064	16		AW0258L	05	ALL		
I	D30220	1		2001R	20	HQ	D30064	15		AW0258L	05	ALL		
I	D30220	S/R		2001Z			D30064	S/R		AW0258L	05	ALL		
I	AS0001L	06	W1170	LA2	DISCONNECT BRACKET-FIRE WALL(STRUT SIDE)									
I	D30228	16		2006B	20	HQ	D08056P	10		AW0258L	06	ALL		
I	D30228	15		2006R	20	HQ	D08056P	2		AW0258L	06	ALL		
I	D30228	S/R		2006Z			D08056P	S/R		AW0258L	06	ALL		
I	AS0001L	07	W1166	SB2	DISCONNECT BRACKET-FIRE WALL(STRUT SIDE)									
I	D30256	4		2002B	20	HQ	D30064	18		AW0258L	05	ALL		
I	D30256	3		2002R	20	HQ	D30064	17		AW0258L	05	ALL		
I	D30256	S/R		2002Z			D30064	S/R		AW0258L	05	ALL		
I	AS0001L	08	W1168	LB2	DISCONNECT BRACKET-FIRE WALL(STRUT SIDE)									
I	D30204	13		2015B	20	E5	D30084	14		AW0258L	03	ALL		
I	D30204	4		2015R	20	E5	D30084	5		AW0258L	03	ALL		
I	D30204	PERB		2015Z			D30084	PERB		AW0258L	03	ALL		
I	AS0001L	09	W1164	SA1	DISCONNECT BRACKET-FIRE WALL(STRUT SIDE)									
I	D30234	26		2005B	20	HQ	D30016	30		AW0258L	04	ALL		
I	D30234	12		2005R	20	HQ	D30016	32		AW0258L	04	ALL		

SPARE WIRE LIST

D280A351

91-21-12

Section AS0001L

Page 1

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

From	Matewith	Pos	Bundle	Sep	Description		To					
Equip		Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity
AS0001L		09	W1164	SA1	DISCONNECT BRACKET-FIRE WALL(STRUT SIDE) (continued)							
D30234		S/R		2005Z			D30016	S/R		AW0258L	04	ALL
D30234		37		2006B	20	HQ	D30016	37		AW0258L	04	ALL
D30234		20		2006R	20	HQ	D30016	36		AW0258L	04	ALL
D30234		S/R		2006Z			D30016	S/R		AW0258L	04	ALL

SPARE WIRE LIST

D280A351

91-21-12

Section AS0001L

Page 2 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From Matewith	Pos	Bundle	Sep	Description		To					Pos	Effectivity	
	Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith				
I	AS0001R	01	W1268	RB2	DISCONNECT BRACKET-FIRE WALL(STRUT SIDE)									
I	D30460	39		2016B	20	E5	D30184	31		AW0258R	03	ALL		
I	D30460	22		2016R	20	E5	D30184	30		AW0258R	03	ALL		
I	D30460	PERB		2016Z			D30184	PERB		AW0258R	03	ALL		
I	AS0001R	03	W1270	RA2	DISCONNECT BRACKET-FIRE WALL(STRUT SIDE)									
I	D30412	2		2005B	20	HQ	D08156P	14		AW0258R	06	ALL		
I	D30412	1		2005R	20	HQ	D08156P	4		AW0258R	06	ALL		
I	D30412	S/R		2005Z			D08156P	S/R		AW0258R	06	ALL		
I	AS0001R	04	W1270	RA2	DISCONNECT BRACKET-FIRE WALL(STRUT SIDE)									
I	D30452	4		2004B	20	HQ	D08156P	13		AW0258R	06	ALL		
I	D30452	3		2004R	20	HQ	D08156P	12		AW0258R	06	ALL		
I	D30452	S/R		2004Z			D08156P	S/R		AW0258R	06	ALL		
I	AS0001R	05	W1266	SB2	DISCONNECT BRACKET-FIRE WALL(STRUT SIDE)									
I	D30420	2		2001B	20	HQ	D30164	16		AW0258R	05	ALL		
I	D30420	1		2001R	20	HQ	D30164	15		AW0258R	05	ALL		
I	D30420	S/R		2001Z			D30164	S/R		AW0258R	05	ALL		
I	AS0001R	06	W1270	RA2	DISCONNECT BRACKET-FIRE WALL(STRUT SIDE)									
I	D30428	16		2006B	20	HQ	D08156P	10		AW0258R	06	ALL		
I	D30428	15		2006R	20	HQ	D08156P	2		AW0258R	06	ALL		
I	D30428	S/R		2006Z			D08156P	S/R		AW0258R	06	ALL		
I	AS0001R	07	W1266	SB2	DISCONNECT BRACKET-FIRE WALL(STRUT SIDE)									
I	D30456	4		2002B	20	HQ	D30164	18		AW0258R	05	ALL		
I	D30456	3		2002R	20	HQ	D30164	17		AW0258R	05	ALL		
I	D30456	S/R		2002Z			D30164	S/R		AW0258R	05	ALL		
I	AS0001R	08	W1268	RB2	DISCONNECT BRACKET-FIRE WALL(STRUT SIDE)									
I	D30404	13		2015B	20	E5	D30184	14		AW0258R	03	ALL		
I	D30404	4		2015R	20	E5	D30184	5		AW0258R	03	ALL		
I	D30404	PERB		2015Z			D30184	PERB		AW0258R	03	ALL		
I	AS0001R	09	W1264	SN1	DISCONNECT BRACKET-FIRE WALL(STRUT SIDE)									
I	D30434	26		2005B	20	HQ	D30116	30		AW0258R	04	ALL		
I	D30434	12		2005R	20	HQ	D30116	32		AW0258R	04	ALL		

SPARE WIRE LIST

D280A351

91-21-12

Section AS0001R

Page 1

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

From	Matewith	Pos	Bundle	Sep	Description		To					
Equip		Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity
AS0001R		09	W1264	SN1	DISCONNECT BRACKET-FIRE WALL(STRUT SIDE) (continued)							
D30434		S/R		2005Z			D30116	S/R		AW0258R	04	ALL
D30434		37		2006B	20	HQ	D30116	37		AW0258R	04	ALL
D30434		20		2006R	20	HQ	D30116	36		AW0258R	04	ALL
D30434		S/R		2006Z			D30116	S/R		AW0258R	04	ALL

SPARE WIRE LIST

D280A351

91-21-12

Section AS0001R

Page 2 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From	Matewith	Pos	Bundle	Sep	Description							
	Equip	Term	Type	Wire No.	GA	TY	To	Equip	Term	Type	Matewith	Pos	Effectivity
I	AS0002L		02	W1172	LA2	DISCONNECT BRACKET-T/R LEFT STRUT							
I	D30202		11		2014B	20	E5	D30042	12		AW0258L	02	ALL
I	D30202		2		2014R	20	E5	D30042	3		AW0258L	02	ALL
I	D30202	PERB			2014Z			D30042	PERB		AW0258L	02	ALL

SPARE WIRE LIST

D280A351

91-21-12

Section AS0002L

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From	Matewith	Pos	Bundle	Sep	Description		To				Pos	Effectivity
	Equip		Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith		
I	AS0002R		02	W1272	RA2	DISCONNECT BRACKET-T/R RIGHT STRUT							
I	D30402		11		2014B	20	E5	D30142	12		AW0258R	02	ALL
I	D30402		2		2014R	20	E5	D30142	3		AW0258R	02	ALL
I	D30402		PERB		2014Z			D30142	PERB		AW0258R	02	ALL

SPARE WIRE LIST

D280A351

91-21-12

Section AS0002R

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From	Matewith	Pos	Bundle	Sep	Description		To	Term	Type	Matewith	Pos	Effectivity
	Equip	Term	Type	Wire No.	GA	TY	Equip						
I	AS0003L		02	W1172	LA2	DISCONNECT BRACKET T/R LEFT STRUT							
I	D30206		11		2016B	20	E5	D30042	14		AW0258L	02	ALL
I	D30206		2		2016R	20	E5	D30042	32		AW0258L	02	ALL
I	D30206	PERB			2016Z			D30042	PERB		AW0258L	02	ALL

SPARE WIRE LIST

D280A351

91-21-12

Section AS0003L

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From	Matewith	Pos	Bundle	Sep	Description		To				Pos	Effectivity
	Equip		Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith		
I	AS0003R		02	W1272	RA2	DISCONNECT BRACKET-T/R RIGHT STRUT							
I	D30406		11		2016B	20	E5	D30142	14		AW0258R	02	ALL
I	D30406		2		2016R	20	E5	D30142	32		AW0258R	02	ALL
I	D30406		PERB		2016Z			D30142	PERB		AW0258R	02	ALL

SPARE WIRE LIST

D280A351

91-21-12

Section AS0003R

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From	Pos	Bundle	Sep	Description		To	Term	Type	Matewith	Pos	Effectivity
	Matewith Equip	Term	Type	Wire No.	GA	TY	Equip					
I	AW0258L	02	W1172	LA2	DISCONNECT BRACKET							
I	D30042	12		2014B	20	E5	D30202	11		AS0002L	02	ALL
I	D30042	3		2014R	20	E5	D30202	2		AS0002L	02	ALL
I	D30042	PERB		2014Z			D30202	PERB		AS0002L	02	ALL
I	D30042	14		2016B	20	E5	D30206	11		AS0003L	02	ALL
I	D30042	32		2016R	20	E5	D30206	2		AS0003L	02	ALL
I	D30042	PERB		2016Z			D30206	PERB		AS0003L	02	ALL
I	AW0258L	03	W1168	LB2	DISCONNECT BRACKET							
I	D30084	14		2015B	20	E5	D30204	13		AS0001L	08	ALL
I	D30084	5		2015R	20	E5	D30204	4		AS0001L	08	ALL
I	D30084	PERB		2015Z			D30204	PERB		AS0001L	08	ALL
I	D30084	31		2016B	20	E5	D30260	39		AS0001L	01	ALL
I	D30084	30		2016R	20	E5	D30260	22		AS0001L	01	ALL
I	D30084	PERB		2016Z			D30260	PERB		AS0001L	01	ALL
I	AW0258L	04	W1164	SA1	DISCONNECT BRACKET							
I	D30016	30		2005B	20	HQ	D30234	26		AS0001L	09	ALL
I	D30016	32		2005R	20	HQ	D30234	12		AS0001L	09	ALL
I	D30016	S/R		2005Z			D30234	S/R		AS0001L	09	ALL
I	D30016	37		2006B	20	HQ	D30234	37		AS0001L	09	ALL
I	D30016	36		2006R	20	HQ	D30234	20		AS0001L	09	ALL
I	D30016	S/R		2006Z			D30234	S/R		AS0001L	09	ALL
I	AW0258L	04	W1184	SA1	DISCONNECT BRACKET							
I	D30014	30		2001B	20	HQ	D39935	26		DM0017		ALL
I	D30014	32		2001R	20	HQ	D39935	25		DM0017		ALL
I	D30014	S/R		2001Z			D39935	S/R		DM0017		ALL
I	D30014	37		2004B	20	HQ	D39911	6		AC0520		ALL
I	D30014	36		2004R	20	HQ	D39911	5		AC0520		ALL
I	D30014	S/R		2004Z			D39911	S/R		AC0520		ALL
I	AW0258L	05	W1166	SB2	DISCONNECT BRACKET							
I	D30064	16		2001B	20	HQ	D30220	2		AS0001L	05	ALL
I	D30064	15		2001R	20	HQ	D30220	1		AS0001L	05	ALL
I	D30064	S/R		2001Z			D30220	S/R		AS0001L	05	ALL
I	D30064	18		2002B	20	HQ	D30256	4		AS0001L	07	ALL
I	D30064	17		2002R	20	HQ	D30256	3		AS0001L	07	ALL

SPARE WIRE LIST

D280A351

91-21-12

Section AW0258L

Page 1

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To						
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AW0258L	05	W1166	SB2	DISCONNECT BRACKET (continued)							
D30064	S/R		2002Z		D30256	S/R		AS0001L	07	ALL	
AW0258L	05	W1182	SB2	DISCONNECT BRACKET							
D30062	16		2001B	20 HQ	D39931	2		AC0520		ALL	
D30062	15		2001R	20 HQ	D39931	3		AC0520		ALL	
D30062	S/R		2001Z		D39931	S/R		AC0520		ALL	
D30062	18		2002B	20 HQ	D39931	4		AC0520		ALL	
D30062	17		2002R	20 HQ	D39931	5		AC0520		ALL	
D30062	S/R		2002Z		D39931	S/R		AC0520		ALL	
AW0258L	06	W1170	LA2	DISCONNECT BRACKET							
D08056P	13		2004B	20 HQ	D30252	4		AS0001L	04	ALL	
D08056P	12		2004R	20 HQ	D30252	3		AS0001L	04	ALL	
D08056P	S/R		2004Z		D30252	S/R		AS0001L	04	ALL	
D08056P	14		2005B	20 HQ	D30212	2		AS0001L	03	ALL	
D08056P	4		2005R	20 HQ	D30212	1		AS0001L	03	ALL	
D08056P	S/R		2005Z		D30212	S/R		AS0001L	03	ALL	
D08056P	10		2006B	20 HQ	D30228	16		AS0001L	06	ALL	
D08056P	2		2006R	20 HQ	D30228	15		AS0001L	06	ALL	
D08056P	S/R		2006Z		D30228	S/R		AS0001L	06	ALL	
AW0258L	06	W1178	LN2	DISCONNECT BRACKET							
D08056J	13		2001B	20 HQ	D39927	11		AC0520		ALL	
D08056J	12		2001R	20 HQ	D39927	24		AC0520		ALL	
D08056J	S/R		2001Z		D39927	S/R		AC0520		ALL	
D08056J	10		2002B	20 HQ	D39927	10		AC0520		ALL	
D08056J	2		2002R	20 HQ	D39927	2		AC0520		ALL	
D08056J	S/R		2002Z		D39927	S/R		AC0520		ALL	
D08056J	14		2003B	20 HQ	D39927	15		AC0520		ALL	
D08056J	4		2003R	20 HQ	D39927	16		AC0520		ALL	
D08056J	S/R		2003Z		D39927	S/R		AC0520		ALL	

SPARE WIRE LIST

D280A351

91-21-12

Section AW0258L

Page 2 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From Matewith	Pos	Bundle	Sep	Description		To	Term	Type	Matewith	Pos	Effectivity
	Equip	Term	Type	Wire No.	GA	TY	Equip					
I	AW0258R	02	W1272	RA2	DISCONNECT BRACKET							
I	D30142	12		2014B	20	E5	D30402	11		AS0002R	02	ALL
I	D30142	3		2014R	20	E5	D30402	2		AS0002R	02	ALL
I	D30142	PERB		2014Z			D30402	PERB		AS0002R	02	ALL
I	D30142	14		2016B	20	E5	D30406	11		AS0003R	02	ALL
I	D30142	32		2016R	20	E5	D30406	2		AS0003R	02	ALL
I	D30142	PERB		2016Z			D30406	PERB		AS0003R	02	ALL
I	AW0258R	03	W1268	RB2	DISCONNECT BRACKET							
I	D30184	14		2015B	20	E5	D30404	13		AS0001R	08	ALL
I	D30184	5		2015R	20	E5	D30404	4		AS0001R	08	ALL
I	D30184	PERB		2015Z			D30404	PERB		AS0001R	08	ALL
I	D30184	31		2016B	20	E5	D30460	39		AS0001R	01	ALL
I	D30184	30		2016R	20	E5	D30460	22		AS0001R	01	ALL
I	D30184	PERB		2016Z			D30460	PERB		AS0001R	01	ALL
I	AW0258R	04	W1264	SN1	DISCONNECT BRACKET							
I	D30116	30		2005B	20	HQ	D30434	26		AS0001R	09	ALL
I	D30116	32		2005R	20	HQ	D30434	12		AS0001R	09	ALL
I	D30116	S/R		2005Z			D30434	S/R		AS0001R	09	ALL
I	D30116	37		2006B	20	HQ	D30434	37		AS0001R	09	ALL
I	D30116	36		2006R	20	HQ	D30434	20		AS0001R	09	ALL
I	D30116	S/R		2006Z			D30434	S/R		AS0001R	09	ALL
I	AW0258R	04	W1284	SN1	DISCONNECT BRACKET							
I	D30114	30		2001B	20	HQ	D39936	26		AD0520		ALL
I	D30114	32		2001R	20	HQ	D39936	25		AD0520		ALL
I	D30114	S/R		2001Z			D39936	S/R		AD0520		ALL
I	D30114	37		2004B	20	HQ	D39912	6		AD0520		ALL
I	D30114	36		2004R	20	HQ	D39912	5		AD0520		ALL
I	D30114	S/R		2004Z			D39912	S/R		AD0520		ALL
I	AW0258R	05	W1266	SB2	DISCONNECT BRACKET							
I	D30164	16		2001B	20	HQ	D30420	2		AS0001R	05	ALL
I	D30164	15		2001R	20	HQ	D30420	1		AS0001R	05	ALL
I	D30164	S/R		2001Z			D30420	S/R		AS0001R	05	ALL
I	D30164	18		2002B	20	HQ	D30456	4		AS0001R	07	ALL
I	D30164	17		2002R	20	HQ	D30456	3		AS0001R	07	ALL

SPARE WIRE LIST

D280A351

91-21-12

Section AW0258R

Page 1

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To						
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AW0258R	05	W1266	SB2	DISCONNECT BRACKET (continued)							
D30164	S/R		2002Z		D30456	S/R		AS0001R	07	ALL	
AW0258R	05	W1282	SB2*	DISCONNECT BRACKET							
D30162	16		2001B	20 HQ	D39932	2		AD0520		ALL	
D30162	15		2001R	20 HQ	D39932	3		AD0520		ALL	
D30162	S/R		2001Z		D39932	S/R		AD0520		ALL	
D30162	18		2002B	20 HQ	D39932	4		AD0520		ALL	
D30162	17		2002R	20 HQ	D39932	5		AD0520		ALL	
D30162	S/R		2002Z		D39932	S/R		AD0520		ALL	
AW0258R	06	W1270	RA2	DISCONNECT BRACKET							
D08156P	13		2004B	20 HQ	D30452	4		AS0001R	04	ALL	
D08156P	12		2004R	20 HQ	D30452	3		AS0001R	04	ALL	
D08156P	S/R		2004Z		D30452	S/R		AS0001R	04	ALL	
D08156P	14		2005B	20 HQ	D30412	2		AS0001R	03	ALL	
D08156P	4		2005R	20 HQ	D30412	1		AS0001R	03	ALL	
D08156P	S/R		2005Z		D30412	S/R		AS0001R	03	ALL	
D08156P	10		2006B	20 HQ	D30428	16		AS0001R	06	ALL	
D08156P	2		2006R	20 HQ	D30428	15		AS0001R	06	ALL	
D08156P	S/R		2006Z		D30428	S/R		AS0001R	06	ALL	
AW0258R	06	W1278	RN2	DISCONNECT BRACKET							
D08156J	13		2001B	20 HQ	D39928	11		AD0520		ALL	
D08156J	12		2001R	20 HQ	D39928	24		AD0520		ALL	
D08156J	S/R		2001Z		D39928	S/R		AD0520		ALL	
D08156J	10		2002B	20 HQ	D39928	10		AD0520		ALL	
D08156J	2		2002R	20 HQ	D39928	2		AD0520		ALL	
D08156J	S/R		2002Z		D39928	S/R		AD0520		ALL	
D08156J	14		2003B	20 HQ	D39928	15		AD0520		ALL	
D08156J	4		2003R	20 HQ	D39928	16		AD0520		ALL	
D08156J	S/R		2003Z		D39928	S/R		AD0520		ALL	

SPARE WIRE LIST

D280A351

91-21-12

Section AW0258R

Page 2 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From	Matewith	Pos	Bundle	Sep	Description		To				Pos	Effectivity
	Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith			
I	D13832			W5204	NN2	PLUG-							
I	D13928	17			0002	20	PA	D40332J	2	AE0104A		26	ALL

SPARE WIRE LIST

D280A351

91-21-12

Section D13832

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From	Matewith	Pos	Bundle	Sep	Description		To				Pos	Effectivity
	Equip		Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith		
I	D40026P			W0152	SN2	PLUG, RECTANGULAR							
I	D40026J		17		0017	22	PA	D10180	5		L01223		YT101-YT131
I	D40026J		18		0018	22	PA	D10180	1		L01223		YT101-YT131

SPARE WIRE LIST

D280A351

91-21-12

Section D40026P

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From Matewith	Pos	Bundle	Sep	Description		To	Term	Type	Matewith	Pos	Effectivity
	From Equip	Term	Type	Wire No.	GA	TY	Equip					
I	D40116J		W3158	LN1*	RCPT, RECTANGULAR							
I	D40116P	1		0111	20	PA	D40108J	11		AB0340A	06	ALL
I	D40116P	3		0112	20	PA	D40108J	12		AB0340A	06	ALL

SPARE WIRE LIST

D280A351

91-21-12

Section D40116J

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From	Matewith	Pos	Bundle	Sep	Description		To					Pos	Effectivity	
	Equip		Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith				
I	D40270J			W3150	LN2*	RCPT, RECTANGULAR									
I	D40270P		2		0901	20	PA	D40198P	1		AP1800A	01	ALL		
I	D40270P		3		0902	20	PA	D40198P	2		AP1800A	01	ALL		
I	D40270P		8		0903	20	PA	D40198P	3		AP1800A	01	ALL		
I	D40270P		9		0904	20	PA	D40198P	4		AP1800A	01	ALL		

SPARE WIRE LIST

D280A351

91-21-12

Section D40270J

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From	Matewith	Pos	Bundle	Sep	Description		To				Pos	Effectivity
	Equip		Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith		
I	D40272J			W4250	RN2*	RCPT, RECTANGULAR							
I	D40272P		2		0901	20	PA	D40298P	1		AP1800A	07	ALL
I	D40272P		8		0903	20	PA	D40298P	3		AP1800A	07	ALL
I	D40272P		9		0904	20	PA	D40298P	4		AP1800A	07	ALL

SPARE WIRE LIST

D280A351

91-21-12

Section D40272J

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From	Matewith	Pos	Bundle	Sep	Description		To					
	Equip		Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity
I	D40751P			W3004	NN2	PLUG -							
I	D40751J		3		0003	22	PA	D40687P	3		AP1800A	12	YT105-YT133

SPARE WIRE LIST

D280A351

91-21-12

Section D40751P

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From	Matewith	Pos	Bundle	Sep	Description		To				Pos	Effectivity
	Equip		Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith		
I	D41066P			W4166	LN2*	PLUG-							
I	D41066J		C		0510	18	PA	D41088P	3		D41088J		ALL

SPARE WIRE LIST

D280A351

91-21-12

Section D41066P

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From	Matewith	Pos	Bundle	Sep	Description		To				Pos	Effectivity
	Equip		Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith		
I	D41074J			W3058	RN2	RCPT, RECTANGULAR							
I	D41074P		10		0575	18	PA	D41078P	B		D41078J		YT101-YT131
I	D41074P		11		0576	18	PA	D41078P	CAP	Y	D41078J		YT101-YT131
I	D41074P		12		0577	18	PA	D41078P	CAP	Y	D41078J		YT101-YT131

SPARE WIRE LIST

D280A351

91-21-12

Section D41074J

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From	Matewith	Pos	Bundle	Sep	Description		To				Pos	Effectivity
	Equip		Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith		
I	D41078J			W3058	RN2	RCPT-							
I	D41078P		B		0575	18	PA	D41074P	10		D41074J		YT101-YT131
I	D41078P		CAP	Y	0576	18	PA	D41074P	11		D41074J		YT101-YT131
I	D41078P		CAP	Y	0577	18	PA	D41074P	12		D41074J		YT101-YT131

SPARE WIRE LIST

D280A351

91-21-12

Section D41078J

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From	Matewith	Pos	Bundle	Sep	Description		To				Pos	Effectivity
	Equip		Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith		
I	D41082P			W0142	LN2	PLUG, RECTANGULAR							
I	D41082J		17		0017	22	PA	D03160	5		L01086		YT101-YT131
I	D41082J		18		0018	22	PA	D03160	1		L01086		YT101-YT131

SPARE WIRE LIST

D280A351

91-21-12

Section D41082P

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From	Matewith	Pos	Bundle	Sep	Description		To					
	Equip		Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity
I	D41088J			W4166	LN2*	RCPT, RECTANGULAR							
I	D41088P		3		0510	18	PA	D41066J	C		D41066P		ALL

SPARE WIRE LIST

D280A351

91-21-12

Section D41088J

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

I	From	Matewith	Pos	Bundle	Sep	Description		To				Pos	Effectivity
	Equip		Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith		
I	DISC BRKT			W5182	NN2								
I	D14012		CAP	Y	0004	22	PA	D14008	CAP	Y	M02566		ALL
I	DISC BRKT			W6182	NN2								
I	D14010		CAP	Y	0004	22	PA	D14006	CAP	Y	M02566		ALL

SPARE WIRE LIST

D280A351

91-21-12

Section DISC BRKT

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From Matewith	Pos	Bundle	Sep	Description		To	Term	Type	Matewith	Pos	Effectivity
	From Equip	Term	Type	Wire No.	GA	TY	Equip					
I	DM0017		W1184	SA1	CONNECTOR-FEED THROUGH							
I	D39935	26		2001B	20	HQ	D30014	30		AW0258L	04	ALL
I	D39935	25		2001R	20	HQ	D30014	32		AW0258L	04	ALL
I	D39935	S/R		2001Z			D30014	S/R		AW0258L	04	ALL

SPARE WIRE LIST

D280A351

91-21-12

Section DM0017

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From	Matewith	Pos	Bundle	Sep	Description		To	Term	Type	Matewith	Pos	Effectivity
	Equip		Term	Type	Wire No.	GA	TY	Equip					
I	DM0035			W5337	SN2	CONNECTOR-FEED THROUGH							
I	D40664		24		0001	22	PA	D04161P	A07		AE0401A	25	ALL

SPARE WIRE LIST

D280A351

91-21-12

Section DM0035

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From	Matewith	Pos	Bundle	Sep	Description		To				Pos	Effectivity
	Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith			
I	L01086			W0142	LN2	SIGN-EXIT LOCATOR							
I	D03160		5		0017	22	PA	D41082J	17		D41082P		ALL
I	D03160		1		0018	22	PA	D41082J	18		D41082P		ALL

SPARE WIRE LIST

D280A351

91-21-12

Section L01086

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From	Matewith	Pos	Bundle	Sep	Description		To					Pos	Effectivity	
	Equip		Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith				
I	L01223			W0152	SN2	SIGN-EXIT LOCATOR									
I	D10180		5		0017	22	PA	D40026J	17		D40026P		ALL		
I	D10180		1		0018	22	PA	D40026J	18		D40026P		ALL		

SPARE WIRE LIST

D280A351

91-21-12

Section L01223

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From	Matewith	Pos	Bundle	Sep	Description							
	Equip	Term	Type	Wire No.	GA	TY	To	Equip	Term	Type	Matewith	Pos	Effectivity
I	M00276			W6248	LN2*	DETECTOR-AFT OVHT							
I	D00866	CAP	Y	0499	20	PA	D40500P	1			AB0500DL	05	ALL
I	D00866	CAP	Y	0500	20	PA	D40500P	3			AB0500DL	05	ALL

SPARE WIRE LIST

D280A351

91-21-12

Section M00276

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From	Matewith	Pos	Bundle	Sep	Description		To					Pos	Effectivity	
	Equip		Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith				
I	M00414			W3393	LG2	ACTR-MACH TRIM									
I	D00545		15		1015	20	VF	D43393J	15		AB1050L	02	ALL		
I	D00545		17		1017	20	VF	D43393J	17		AB1050L	02	ALL		
I	D00545		19		1019	20	VF	D43393J	19		AB1050L	02	ALL		
I	D00545		21		1021	20	VF	D43393J	21		AB1050L	02	ALL		
I	D00545		S/R		1021Z			D43393J	S/R		AB1050L	02	ALL		

SPARE WIRE LIST

D280A351

91-21-12

Section M00414

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From	Matewith	Pos	Bundle	Sep	Description		To					Pos	Effectivity	
	Equip		Term	Type	Wire No.	GA	TY	Equip		Term	Type	Matewith			
I	M00943			W5367	LC3	ACTR-HYD A/P (AILERON 'A')									
I	D01827		REF	VP	3013B	22	HG	D04073P		B02		AE0101A	27	ALL	
I	D01827		REF	VP	3013R	22	HG	D04073P		B01		AE0101A	27	ALL	
I	D01827		REF	VP	3013Y	22	HG	D04073P		B03		AE0101A	27	ALL	
I	D01827		DED		3013Z			D04073P		PERG	1F	AE0101A	27	ALL	

SPARE WIRE LIST

D280A351

91-21-12

Section M00943

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From	Matewith	Pos	Bundle	Sep	Description		To				Pos	Effectivity
	Equip		Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith		
I	M01020			W3397	LA3	ACTR-HYD A/P (ELEVATOR 'A')							
I	D01681		REF	VP	3006B	22	HG	D43397J	41		AB1050L	03	ALL
I	D01681		REF	VP	3006R	22	HG	D43397J	40		AB1050L	03	ALL
I	D01681		REF	VP	3006Y	22	HG	D43397J	42		AB1050L	03	ALL

SPARE WIRE LIST

D280A351

91-21-12

Section M01020

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From	Matewith	Pos	Bundle	Sep	Description		To				Pos	Effectivity
	Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith			
I	M01022			W3399	RB3	ACTR-HYD A/P (ELEVATOR 'B')							
I	D01687	REF	VP	3006B	22	HG	D43389J	11		AB1080		03	ALL
I	D01687	REF	VP	3006R	22	HG	D43389J	10		AB1080		03	ALL
I	D01687	REF	VP	3006Y	22	HG	D43389J	12		AB1080		03	ALL

SPARE WIRE LIST

D280A351

91-21-12

Section M01022

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From	Matewith	Pos	Bundle	Sep	Description		To				Pos	Effectivity
	Equip		Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith		
I	M01415			W3144	LN2*	MDL-LAV A (SEE Y004+++)							
I	D03732		CAP	Y	0015	20	PA	D40220P	15		AP1800A	06	ALL
I	D03732		CAP	Y	0016	20	PA	D40220P	16		AP1800A	06	ALL
I	M01415			W3307	NN2	MDL-LAV A (SEE Y004+++)							
I	D14366		40		0008	24	PK	D41337P	22		AE0103A	09	ALL
I	D14366		39		2003B	24	PL	D41337P	24		AE0103A	09	ALL
I	D14366		38		2003R	24	PL	D41337P	23		AE0103A	09	ALL

SPARE WIRE LIST

D280A351

91-21-12

Section M01415

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From	Matewith	Pos	Bundle	Sep	Description		To	Term	Type	Matewith	Pos	Effectivity
	Equip		Term	Type	Wire No.	GA	TY	Equip					
I	M01418			W3058	RN2	AFT-LAV D (SEE Y007+++)							
I	D14372		CAP	Y	0387	20	PA	D40170J	18		AB0340A	04	YT101-YT131
I	D14372		CAP	Y	0388	20	PA	D40170J	19		AB0340A	04	YT101-YT131
I	D14372		CAP	Y	0389	20	PA	D40170J	31		AB0340A	04	YT101-YT131
I	D14376		CAP	Y	0284	20	PA	D40054J	5		AB0340A	01	YT101-YT131
I	D14376		CAP	Y	0285	20	PA	D40054J	6		AB0340A	01	YT101-YT131
I	D14376		CAP	Y	0286	20	PA	D40054J	8		AB0340A	01	YT101-YT131
I	M01418			W3144	LN2*	AFT-LAV D (SEE Y007+++)							
I	D03738		CAP	Y	0013	20	PA	D40220P	13		AP1800A	06	ALL
I	D03738		CAP	Y	0014	20	PA	D40220P	14		AP1800A	06	ALL

SPARE WIRE LIST

D280A351

91-21-12

Section M01418

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From	Matewith	Pos	Bundle	Sep	Description		To				Pos	Effectivity
	Equip		Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith		
I	M01672			W4142	LB2*	BATTERY PACK-EMERGENCY LIGHT							
I	D10744		CAP	Y	0037	20	PA	D40296J	7		AB0340B	07	ALL
I	D10744		CAP	Y	0039	20	PA	D40296J	CAP	Y	AB0340B	07	ALL

SPARE WIRE LIST

D280A351

91-21-12

Section M01672

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From	Matewith	Pos	Bundle	Sep	Description		To				Pos	Effectivity
	Equip		Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith		
I	M01673			W3142	LN2	BATTERY PACK-EMERGENCY LIGHT							
I	D10746		CAP	Y	0038	20	PA	D40196J	8		AB0340A	03	ALL
I	D10746		CAP	Y	0039	20	PA	D40196J	CAP	Y	AB0340A	03	ALL

SPARE WIRE LIST

D280A351

91-21-12

Section M01673

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From	Matewith	Pos	Bundle	Sep	Description		To				Pos	Effectivity
	Equip		Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith		
I	M02061			W5158	SB2*	MDL-PSEU							
I	D11140		8		0008	22	PA	TB1808X	B003	1A			ALL
I	M02061			W5160	RB2*	MDL-PSEU							
I	D10986		54		0619	22	PA	D40464P	B04		AE0101B	02	ALL
I	D10988		38		0038	22	PA	TB1808X	A003	1A			ALL
I	D10988		54		0629	22	PA	D46102P	20		AJ0046A	14	ALL
I	D10988		60		2460B	22	PB	D40472P	B06		AE0402A	33	ALL
I	D10988		61		2460R	22	PB	D40472P	B05		AE0402A	33	ALL

SPARE WIRE LIST

D280A351

91-21-12

Section M02061

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From	Matewith	Pos	Bundle	Sep	Description		To					Pos	Effectivity	
	Equip		Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith				
I	M02195			W2805	NN2	PRINTER-ACMS ARINC 740									
	D02649		B		2503B	24	Y2	D43215P	B04		AE0302A	09	YT101-YT103		
I	D02649		B		2503B	24	Y2	D43215P	B04		AE0302A	17	YT104-YT133		
	D02649		A		2503R	24	Y2	D43215P	A04		AE0302A	09	YT101-YT103		
I	D02649		A		2503R	24	Y2	D43215P	A04		AE0302A	17	YT104-YT133		
	D02649				2503Z			D43215P	PERG	1F	AE0302A	09	YT101-YT103		
I	D02649				2503Z			D43215P	PERG	1F	AE0302A	17	YT104-YT133		

SPARE WIRE LIST

D280A351

91-21-12

Section M02195

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From	Matewith	Pos	Bundle	Sep	Description		To			Pos	Effectivity	
	Equip		Term	Type	Wire No.	GA	TY	Equip	Term	Type			Matewith
I	M02566			W5182	NN2	ISPS - POWER SUPPLY EE BAY							
I	D14008		CAP	Y	0004	22	PA	D14012	CAP	Y	DISC BRKT	ALL	
I	M02566			W6182	NN2	ISPS - POWER SUPPLY EE BAY							
I	D14006		CAP	Y	0004	22	PA	D14010	CAP	Y	DISC BRKT	ALL	

SPARE WIRE LIST

D280A351

91-21-12

Section M02566

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From	Matewith	Pos	Bundle	Sep	Description		To	Term	Type	Matewith	Pos	Effectivity
	Equip		Term	Type	Wire No.	GA	TY	Equip					
I	M02816			W4142	LB2*	BATTERY PACK-EMERGENCY LIGHT							
I	D14812		CAP	Y	0036	20	PA	D40296J	4		AB0340B	07	ALL
I	D14812		CAP	Y	0038	20	PA	D40296J	15		AB0340B	07	ALL

SPARE WIRE LIST

D280A351

91-21-12

Section M02816

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From Matewith	Pos	Bundle	Sep	Description		To					Effectivity	
	From Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos		
I	N00226		W2205	SN2	INTEGRATED STANDBY FLIGHT DISPLAY								
I	D10853	CAP	Y	0002	20	CQ	GD00179	AC..	1A			ALL	
I	D10853	CAP	Y	0005	20	CQ	GD00179	AC..	1A			ALL	
I	D10853	CAP	Y	0007	22	PA	SP02186		S			ALL	
I	D10853	CAP	Y	0008	20	PA	GD00179	DC..	1A			ALL	
I	D10853	CAP	Y	0009	20	PA	GD00179	ST..	1A			ALL	
I	D10853	CAP	Y	0013	20	PA	GD00179	DC..	1A			ALL	
I	D10853	CAP	Y	0014	20	PA	SP02085		S			ALL	
I	D10853	CAP	Y	0026	20	PA	GD00179	ST..	1A			ALL	
I	D10853	CAP	Y	0054	22	PA	SP02185		S			ALL	
I	D10853	CAP	Y	2004B	24	Y2	D04205J	11		AE0102A	05	ALL	
I	D10853	CAP	Y	2004R	24	Y2	D04205J	10		AE0102A	05	ALL	
I	D10853	DED		2004Z			D04205J	S/R		AE0102A	05	ALL	
I	D10853	CAP	Y	2012B	24	Y2	D40049J	4		AE0104A	07	ALL	
I	D10853	CAP	Y	2012R	24	Y2	D40049J	3		AE0104A	07	ALL	
I	D10853	DED		2012Z			D40049J	S/R		AE0104A	07	ALL	
I	D10853	CAP	Y	2015B	24	Y2	D04205J	13		AE0102A	05	ALL	
I	D10853	CAP	Y	2015R	24	Y2	D04205J	12		AE0102A	05	ALL	
I	D10853	DED		2015Z			D04205J	S/R		AE0102A	05	ALL	

SPARE WIRE LIST

D280A351

91-21-12

Section N00226

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From	Matewith	Pos	Bundle	Sep	Description		To					Pos	Effectivity
	Equip		Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith			
I	OVHD DISC			W2705	NA2									
I	D00901		23		2047B	22	X2	D00416	B17		AE0401D	09	ALL	
I	D00901		41		2047R	22	X2	D00416	A17		AE0401D	09	ALL	
I	D00901	PERB			2047Z			D00416	PERG	1F	AE0401D	09	ALL	
I	D00901		26		2048B	22	WC	D00406	B08		AE0401D	06	ALL	
I	D00901		44		2048W	22	WC	D00406	A08		AE0401D	06	ALL	
I	D00901	PERB			2048Z			D00406	PERG	1F	AE0401D	06	ALL	

SPARE WIRE LIST

D280A351

91-21-12

Section OVHD DISC

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From	Matewith	Pos	Bundle	Sep	Description		To	Term	Type	Matewith	Pos	Effectivity
	Equip		Term	Type	Wire No.	GA	TY	Equip					
I	P003-01			W0003	NB2	PNL-FIRST OFFICER INSTRUMENT							
I	D03991		6		0595	22	CQ	D04221J	13		AP0900A	09	ALL

SPARE WIRE LIST

D280A351

91-21-12

Section P003-01

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From	Matewith	Pos	Bundle	Sep	Description		To					
	Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity	
I	P003-07			W0003	NB2	PNL-GND PROX TEST							
I	D01205	CAP	Y	0609	22	PA	D04237J	33		AP0900A	06	ALL	

SPARE WIRE LIST

D280A351

91-21-12

Section P003-07

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From	Matewith	Pos	Bundle	Sep	Description		To			Pos	Effectivity	
	Equip		Term	Type	Wire No.	GA	TY	Equip	Term	Type			Matewith
I	P005-28			W2135	RB2	PNL-INSTRUMENT SWITCHING							
	D01817		CAP	Y	0034	22	PA	D45237J	B20		AE0502A	07	YT101-YT103
I	D01817		CAP	Y	0034	22	PA	D45237J	B20		AE0502A	30	YT104-YT133

SPARE WIRE LIST

D280A351

91-21-12

Section P005-28

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From Matewith	Pos	Bundle	Sep	Description		To					Effectivity
	Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	
	P008-25		W2149	NA2								
	D00263	CAP	Y	0023	22	PA	D04029J	23		AE0102A	03	YT120
	D00263	CAP	Y	2006B	24	Y2	D04029J	36		AE0102A	03	YT120
	D00263	CAP	Y	2006R	24	Y2	D04029J	35		AE0102A	03	YT120
	D00263	S/R		2006Z			D04029J	S/R		AE0102A	03	YT120
	D00303	CAP	Y	0027	22	PA	D04029J	27		AE0102A	03	YT120
	D00303	CAP	Y	2005B	24	Y2	D04029J	34		AE0102A	03	YT120
	D00303	CAP	Y	2005R	24	Y2	D04029J	33		AE0102A	03	YT120
	D00303	S/R		2005Z			D04029J	S/R		AE0102A	03	YT120
	P008-25		W2149	NA2	PNL-CAPTAIN VHF NAVIGATION							
	D00263	CAP	Y	0023	22	PA	D04029J	23		AE0102A	03	YT101-YT119, YT126-YT133
	D00263	CAP	Y	2006B	24	Y2	D04029J	36		AE0102A	03	YT101-YT119, YT126-YT133
	D00263	CAP	Y	2006R	24	Y2	D04029J	35		AE0102A	03	YT101-YT119, YT126-YT133
	D00263	S/R		2006Z			D04029J	S/R		AE0102A	03	YT101-YT119, YT126-YT133
	D00303	CAP	Y	0027	22	PA	D04029J	27		AE0102A	03	YT101-YT119, YT126-YT133
	D00303	CAP	Y	2005B	24	Y2	D04029J	34		AE0102A	03	YT101-YT119, YT126-YT133
	D00303	CAP	Y	2005R	24	Y2	D04029J	33		AE0102A	03	YT101-YT119, YT126-YT133
	D00303	S/R		2005Z			D04029J	S/R		AE0102A	03	YT101-YT119, YT126-YT133

SPARE WIRE LIST

D280A351

91-21-12

Section P008-25

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To						
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity	

I	P008-26		W2151	NB2							
I	D00265	CAP	Y	0023	22 PA	D04031J	23	AE0105A	02	YT120	
I	D00265	CAP	Y	2006B	24 Y2	D04031J	36	AE0105A	02	YT120	
I	D00265	CAP	Y	2006R	24 Y2	D04031J	35	AE0105A	02	YT120	
I	D00265	S/R		2006Z		D04031J	S/R	AE0105A	02	YT120	
I	D00305	CAP	Y	0027	22 PA	D04031J	27	AE0105A	02	YT120	
I	D00305	CAP	Y	2005B	24 Y2	D04031J	34	AE0105A	02	YT120	
I	D00305	CAP	Y	2005R	24 Y2	D04031J	33	AE0105A	02	YT120	
I	D00305	S/R		2005Z		D04031J	S/R	AE0105A	02	YT120	
I	P008-26		W2151	NB2	PNL-FIRST OFFICER VHF NAVIGATION						
I	D00265	CAP	Y	0023	22 PA	D04031J	23	AE0105A	02	YT101-YT119, YT126-YT133	
I	D00265	CAP	Y	2006B	24 Y2	D04031J	36	AE0105A	02	YT101-YT119, YT126-YT133	
I	D00265	CAP	Y	2006R	24 Y2	D04031J	35	AE0105A	02	YT101-YT119, YT126-YT133	
I	D00265	S/R		2006Z		D04031J	S/R	AE0105A	02	YT101-YT119, YT126-YT133	
I	D00305	CAP	Y	0027	22 PA	D04031J	27	AE0105A	02	YT101-YT119, YT126-YT133	
I	D00305	CAP	Y	2005B	24 Y2	D04031J	34	AE0105A	02	YT101-YT119, YT126-YT133	
I	D00305	CAP	Y	2005R	24 Y2	D04031J	33	AE0105A	02	YT101-YT119, YT126-YT133	
I	D00305	S/R		2005Z		D04031J	S/R	AE0105A	02	YT101-YT119, YT126-YT133	

SPARE WIRE LIST

D280A351

91-21-12

Section P008-26

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From	Matewith	Pos	Bundle	Sep	Description		To				Pos	Effectivity
	Equip		Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith		
I	P0091			W5726	AD1								
I	D11438		2		0577	16	PA	D40254P	F		AE0201A	07	ALL
I	D11438		3		0578	16	PA	D40254P	G		AE0201A	07	ALL
I	D11438		4		0579	16	PA	D40254P	H		AE0201A	07	ALL
I	D11438		7		0597	22	PA	D40254P	A01		AE0201A	07	ALL
I	P0091			W6110	LA2*								
I	D11418		CAP	Y	0011	20	PA	D40364P	B05		AE0101A	12	ALL
I	D11418		CAP	Y	0012	20	PA	D40364P	B06		AE0101A	12	ALL
I	D11418		CAP	Y	0013	20	PA	D40364P	A06		AE0101A	12	ALL

SPARE WIRE LIST

D280A351

91-21-12

Section P0091

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

I	From	Matewith	Pos	Bundle	Sep	Description		To				Pos	Effectivity
	Equip		Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith		
I	P0092			W6242	RN1								
I	D11452		CAP	Y	0059	20	PA	D40050P	8		AB0340A	05	ALL
I	D11452		CAP	Y	0060	20	PA	D40050P	9		AB0340A	05	ALL
I	P0092			W6414	RB2								
I	D11448		4		0502	24	PK	D40396P	6		AP0600B	22	ALL
I	D11448		33		5508	18	PA	D40396P	4		AP0600B	22	ALL

SPARE WIRE LIST

D280A351

91-21-12

Section P0092

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	From	Matewith	Pos	Bundle	Sep	Description							
	Equip	Term	Type	Wire No.	GA	TY	To	Equip	Term	Type	Matewith	Pos	Effectivity
I	P091-00			W5142	LN1*	PNL-POWER DISTRIBUTION NO.1							
I	D11416	CAP	Y	0054	20	PA	D40054P	5			AB0340A	01	ALL
I	D11416	CAP	Y	0055	20	PA	D40054P	6			AB0340A	01	ALL
I	D11416	CAP	Y	0056	20	PA	D40054P	8			AB0340A	01	ALL

SPARE WIRE LIST

D280A351

91-21-12

Section P091-00

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

From Equip	Matewith Term	Pos	Bundle Type	Sep Wire No.	Description GA TY		To Equip	Term	Type	Matewith	Pos	Effectivity
I	UNK		W0001	NA2								
I	TB0201Z	A001	1A	0168	22	PA	D04207J	33		AP0900A	03	ALL
I	UNK		W0443	LA2								
I	L00728	CAP	Y	0051	20	PA	L00728	CAP	Y			ALL
I	L00728	CAP	Y	0052	20	PA	L00728	CAP	Y			ALL
I	S00742	= R1	*	0002K	20	XN	TB0806X	CAP	Y			ALL
I	S00742	= G1	*	0015RN	20	XN	TB0806X	CAP	Y			ALL
I	S00742	= G2	*	0016ON	20	XN	TB0806X	CAP	Y			ALL
I	S00742	= R2	*	0019KV	20	XN	TB0806X	CAP	Y			ALL
I	TB0806X	CAP	Y	0002K	20	XN	S00742	= R1	*			ALL
I	TB0806X	CAP	Y	0015RN	20	XN	S00742	= G1	*			ALL
I	TB0806X	CAP	Y	0016ON	20	XN	S00742	= G2	*			ALL
I	TB0806X	CAP	Y	0019KV	20	XN	S00742	= R2	*			ALL
I	UNK		W0445	RB2								
I	L00729	CAP	Y	0061	20	PA	L00729	CAP	Y			ALL
I	L00729	CAP	Y	0062	20	PA	L00729	CAP	Y			ALL
I	S00743	= R1	*	0022K	20	XN	TB0805X	CAP	Y			ALL
I	S00743	= G1	*	0035RN	20	XN	TB0805X	CAP	Y			ALL
I	S00743	= G2	*	0036ON	20	XN	TB0805	CAP	Y			ALL
I	S00743	= R2	*	0039KV	20	XN	TB0805	CAP	Y			ALL
I	TB0805	CAP	Y	0036ON	20	XN	S00743	= G2	*			ALL
I	TB0805	CAP	Y	0039KV	20	XN	S00743	= R2	*			ALL
I	TB0805X	CAP	Y	0022K	20	XN	S00743	= R1	*			ALL
I	TB0805X	CAP	Y	0035RN	20	XN	S00743	= G1	*			ALL
I	UNK		W2205	SN2								
I	GD00179	AC..	1A	0002	20	CQ	D10853	CAP	Y	N00226		ALL
I	GD00179	AC..	1A	0005	20	CQ	D10853	CAP	Y	N00226		ALL
I	GD00179	DC..	1A	0008	20	PA	D10853	CAP	Y	N00226		ALL
I	GD00179	ST..	1A	0009	20	PA	D10853	CAP	Y	N00226		ALL
I	GD00179	DC..	1A	0013	20	PA	D10853	CAP	Y	N00226		ALL
I	GD00179	ST..	1A	0026	20	PA	D10853	CAP	Y	N00226		ALL
I	SP02085		S	0014	20	PA	D10853	CAP	Y	N00226		ALL
I	SP02185		S	0054	22	PA	D10853	CAP	Y	N00226		ALL
I	SP02186		S	0007	22	PA	D10853	CAP	Y	N00226		ALL

SPARE WIRE LIST

D280A351

91-21-12

Section UNK

Page 1

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

I	From Matewith	Pos	Bundle	Sep	Description		To				Pos	Effectivity
	From Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith		
I	UNK		W2214	RB1								
I	TB0503V	B031	CT	5502	18	PA	TB0606V	A013	1			ALL
I	TB0606V	A013	1	5502	18	PA	TB0503V	B031	CT			ALL
I	UNK		W2651	SA2								
I	SP02085		S	0010	20	PA	D41807P	27		AP1800B	08	ALL
I	SP02185		S	0008	22	CQ	D41807P	23		AP1800B	08	ALL
I	SP02186		S	0009	22	CQ	D41807P	9		AP1800B	08	ALL
I	UNK		W3058	RN2								
I	GD11106	ST..	1	0320	20	PA	D40226P	CAP	Y	AP0600A	05	YT101-YT131
I	UNK		W3393	LG2								
I	GD04809	ST..	E	1015Z			D43393J	S/R		AB1050L	02	ALL
I	GD04809	ST..	E	1017Z			D43393J	S/R		AB1050L	02	ALL
I	GD04809	ST..	E	1019Z			D43393J	S/R		AB1050L	02	ALL
I	UNK		W3397	LA3								
I	GD00949	ST..	E	3006Z			D43397J	S/R		AB1050L	03	ALL
I	UNK		W3399	RB3								
I	GD00973	ST..	E	3006Z			D43389J	S/R		AB1080	03	ALL
I	UNK		W5158	SB2*								
I	TB1808X	B003	1A	0008	22	PA	D11140	8		M02061		ALL
I	TB1808X	A003	%A	0707	22	PA	D40750P	10		AP0600B	02	YT101-YT103
I	TB1808X	A003	1A	0707	22	PA	D40750P	10		AP0600B	02	YT104-YT133
I	UNK		W5160	RB2*								
I	TB1808X	A003	1A	0038	22	PA	D10988	38		M02061		ALL
I	UNK		W6208	RA2								
I	TB0606V	B013	1	0512	16	PA	D40820P	10		AP0600B	17	YT101-YT112, YT126-YT130

SPARE WIRE LIST

D280A351

91-21-12

Section UNK

Page 2 End

Jun 21/2016