

**CHAPTER**

**74**

**IGNITION**

**(CFM56 ENGINES (CFM56-7))**


**737-600/700/800/900  
FAULT ISOLATION MANUAL**

**CHAPTER 74  
IGNITION**

Subject/Page	Date	COC	Subject/Page	Date	COC	Subject/Page	Date	COC
74-EFFECTIVE PAGES			74-21 TASKS (cont)					
1	JUN 15/2016		O 222	Jun 15/2016				
2	BLANK		O 223	Jun 15/2016				
74-HOW TO USE THE FIM			O 224	Jun 15/2016				
1	Feb 15/2013		O 225	Jun 15/2016				
2	Feb 15/2013		O 226	Jun 15/2016				
3	Feb 15/2013		O 227	Jun 15/2016				
4	Feb 15/2013		O 228	Jun 15/2016				
5	Feb 15/2013		O 229	Jun 15/2016				
6	Feb 15/2013		O 230	Jun 15/2016				
74-MAINT MSG INDEX			O 231	Jun 15/2016				
101	Oct 15/2015		O 232	Jun 15/2016				
R 102	Jun 15/2016		74-21 TASK SUPPORT					
103	Feb 15/2013		301	Feb 15/2013				
104	Feb 15/2013		302	Feb 15/2013				
74-21 TASKS			303	Feb 15/2013				
O 201	Jun 15/2016		304	Feb 15/2013				
O 202	Jun 15/2016		305	Feb 15/2013				
O 203	Jun 15/2016		306	Feb 15/2013				
O 204	Jun 15/2016							
O 205	Jun 15/2016							
O 206	Jun 15/2016							
O 207	Jun 15/2016							
O 208	Jun 15/2016							
O 209	Jun 15/2016							
O 210	Jun 15/2016							
O 211	Jun 15/2016							
O 212	Jun 15/2016							
O 213	Jun 15/2016							
O 214	Jun 15/2016							
O 215	Jun 15/2016							
O 216	Jun 15/2016							
O 217	Jun 15/2016							
O 218	Jun 15/2016							
O 219	Jun 15/2016							
O 220	Jun 15/2016							
O 221	Jun 15/2016							

A = Added, R = Revised, D = Deleted, O = Overflow, C = Customer Originated Change

## 74-EFFECTIVE PAGES

**737-600/700/800/900  
FAULT ISOLATION MANUAL**

G04902 S0000148576\_V1

**Basic Fault Isolation Process  
Figure 1**

EFFECTIVITY  
AKS ALL

## 74-HOW TO USE THE FIM

D633A103-AKS

Page 1  
Feb 15/2013

**737-600/700/800/900  
FAULT ISOLATION MANUAL**

Some airplane systems have built-in test equipment (BITE). IF the system finds a fault when you do a BITE test, it will give you a maintenance message.

A maintenance message can be any of these:

- a code
- a text message
- a light
- an indication.

To find the fault isolation task for a maintenance message, go to the Maintenance Message Index in the chapter for the applicable system.

If you do not know which chapter is the correct one, look at the list at the front of any Maintenance Message Index. For each system or component (LRU) that has BITE, this list gives the chapter number where you can find the Index that you need.

Find the maintenance message for the applicable LRU or system in the Index. Then find the task number on the same line as the maintenance message. Go to the task in the FIM and do the steps of the task (see Figure 4).

G04950 S0000148578\_V1

**Getting Fault Information from BITE**  
**Figure 2**


EFFECTIVITY  
AKS ALL

## 74-HOW TO USE THE FIM

D633A103-AKS

Page 2  
Feb 15/2013

## 737-600/700/800/900 FAULT ISOLATION MANUAL



G04979 S0000148579\_V2

Finding the Fault Isolation Task in the FIM  
Figure 3

EFFECTIVITY  
AKS ALL

## 74-HOW TO USE THE FIM

D633A103-AKS

Page 3  
Feb 15/2013

## 737-600/700/800/900 FAULT ISOLATION MANUAL

### ASSUMED CONDITIONS AT START OF TASK

- External electrical power is ON
- Hydraulic power and pneumatic power are OFF
- Engines are shut down
- No equipment in the system is deactivated

### POSSIBLE CAUSES

- The list of possible causes has the most likely cause first and the least likely cause last.
- You can use the maintenance records of your airline to determine if the fault occurred before. Compare the list of possible causes to the past maintenance actions. This will help prevent repetition of the same maintenance actions.

### INITIAL EVALUATION PARAGRAPH

- The primary purpose of the Initial Evaluation paragraph at the start of the task is to help you find out if you can detect the fault right now:
  - If you cannot detect the fault right now, then the task cannot isolate the fault and the Initial Evaluation paragraph will say that there was an intermittent fault.
  - If you have an intermittent fault, you must use your judgement (and follow your airline's policy) to decide which maintenance action to take. Then monitor the airplane to see if the fault happens again on subsequent flights.
- The Initial Evaluation paragraph can also help you find out which Fault Isolation Procedure to use to isolate and correct the fault.

### FAULT ISOLATION STEPS

- The FIM task steps are presented in a specified order. The "If... then" statements will guide you along a logical path. But if you do not plan to follow the FIM task exactly, make sure that you read it before you start to isolate the fault. Some FIM procedures start with important steps that have an effect on the other steps in the procedure.
- When you are at the endpoint of the path, the step says "...you corrected the fault." Complete the step and exit the procedure.

G05009 S0000148580\_V3

### Doing the Fault Isolation Task Figure 4


EFFECTIVITY  
AKS ALL

## 74-HOW TO USE THE FIM

D633A103-AKS

Page 4  
Feb 15/2013

# 737-600/700/800/900 FAULT ISOLATION MANUAL




**Subjects at Front of FIM  
Figure 5**

EFFECTIVITY  
AKS ALL

## 74-HOW TO USE THE FIM

D633A103-AKS

# 737-600/700/800/900 FAULT ISOLATION MANUAL



G05102 S0000148582\_V1

**Subjects in Each FIM Chapter**  
**Figure 6**

EFFECTIVITY	
AKS ALL	

## 74-HOW TO USE THE FIM

D633A103-AKS

Page 6  
Feb 15/2013



## 737-600/700/800/900 FAULT ISOLATION MANUAL

<u>LRU/SYSTEM</u>	<u>SHORT NAME</u>	<u>CHAPTER</u>
Air Data Inertial Reference System	ADIRS	34
Air Traffic Controller Transponder - 1 (Left)	ATC XPDR - 1 (L)	34
Air Traffic Controller Transponder - 2 (Right)	ATC XPDR - 2 (R)	34
Airborne Vibration Monitor System Signal Conditioner	AVM SIG COND	77
Antiskid Control Unit	ANTISKID	32
Attendant Control Panel	ACP	23
Automatic Direction Finder Receiver - 1	ADF RECVR - 1	34
Automatic Direction Finder Receiver - 2	ADF RECVR - 2	34
Autothrottle System	A/T	22
Auxiliary Power Unit	APU	49
Auxiliary Power Unit Generator Control Unit	APU GCU	24
Bus Power Control Unit	BPCU	24
Cabin Pressure Controller	CAB PRESS CON	21
Cargo Electronic Unit - Forward	CEU - FWD	26
Cargo Electronic Unit - Lower	CEU - LOWER	26
Cargo Electronic Unit - Main Aft	CEU - MAIN AFT	26
Cargo Electronic Unit - Main Forward	CEU - MAIN FWD	26
Common Display System	CDS	31
Compartment Overheat Detection Control Module	WING/BODY OHT	26
Digital Flight Control System	DFCS	22
Distance Measurement Equipment Interrogator	DME INTROGTR	34
Electrical Meters, Battery, and Galley Power Module	P5-13	24
Electronic Engine Controller - 1	ENGINE - 1	73
Electronic Engine Controller - 2	ENGINE - 2	73
Emergency Locator Transmitter	ELT	23
Engine Accessory Unit	EAU	78
Engine Accessory Unit/TR DEPLOY ENG 1	EAU/TR DPLOY-ENG 1	78
Engine Accessory Unit/TR DEPLOY ENG 2	EAU/TR DPLOY-ENG 2	78
Engine Accessory Unit/TR STOW ENG 1	EAU/TR STOW-ENG 1	78
Engine Accessory Unit/TR STOW ENG 2	EAU/TR STOW-ENG 2	78
Engine and Auxiliary Power Unit Fire Detection Control Module	ENG/APU FIRE	26
Flap/Slat Electronics Unit	FSEU	27
Flight Data Acquisition Unit	FDAU	31
Flight Management Computer System	FMCS	34
Fuel Quantity Indicating System	FQIS	28

EFFECTIVITY  
AKS ALL

## 74-MAINT MSG INDEX

**737-600/700/800/900  
FAULT ISOLATION MANUAL**

<b><u>LRU/SYSTEM</u></b>	<b><u>SHORT NAME</u></b>	<b><u>CHAPTER</u></b>
Generator Control Unit - 1	GCU - 1	24
Generator Control Unit - 2	GCU - 2	24
Ground Proximity Computer	GROUND PROX	34
High Frequency Transceiver	HF XCVR	23
Multi-Mode Receiver	MMR	34
Nitrogen Generation System BITE Display Unit	NGS	47
Pack Flow Temperature Controller	PFTC	21
Pack/Zone Temperature Controller - Left	PACK/ZN CON - L	21
Pack/Zone Temperature Controller - Right	PACK/ZN CON - R	21
Proximity Switch Electronics Unit	PSEU	32
Radio Altimeter Receiver/Transmitter	RADIO ALTIMTR	34
Stall Management Yaw Damper Computer - 1	SMYD - 1	27
Stall Management Yaw Damper Computer - 2	SMYD - 2	27
Traffic Alert and Collision Avoidance System Computer	TCAS COMPUTER	34
VHF Omnidirectional Ranging Marker Beacon Receiver	VOR/MKR RCVR	34
Very High Frequency Transceiver	VHF XCVR	23
Waste Tank Logic Control Module	WASTE TANK	38
Weather Radar Receiver/Transmitter	WEATHER RADAR	34
Window Heat Control Unit - Left Forward	WHCU - L FWD	30
Window Heat Control Unit - Left Side	WHCU - L SIDE	30
Window Heat Control Unit - Right Forward	WHCU - R FWD	30
Window Heat Control Unit - Right Side	WHCU - R SIDE	30

EFFECTIVITY  
AKS ALL

## 74-MAINT MSG INDEX

D633A103-AKS

Page 102  
Jun 15/2016

## 737-600/700/800/900 FAULT ISOLATION MANUAL

LRU/SYSTEM	MAINTENANCE MESSAGE	GO TO FIM TASK
ENGINE - 1	74-10951 IGN L (IGN 1) IS FAILED	74-21 TASK 806
ENGINE - 1	74-10961 IGN R (IGN 2) IS FAILED	74-21 TASK 807
ENGINE - 1	74-10971 THE APL INPUT VOLTAGE FOR THE L EXCITER (IGN 1) IS OUT OF RANGE	74-21 TASK 801
ENGINE - 1	74-10981 THE APL INPUT VOLTAGE FOR THE R EXCITER (IGN 2) IS OUT OF RANGE	74-21 TASK 802
ENGINE - 1	74-10991 THE APL INPUT VOLTAGE FOR THE L EXCITER (IGN 1) IS ALWAYS ON	74-21 TASK 803
ENGINE - 1	74-11001 THE APL INPUT VOLTAGE FOR THE R EXCITER (IGN 2) IS ALWAYS ON	74-21 TASK 804
ENGINE - 1	74-11301 DEU1 IGNITER DATA IS NOT CORRECT	74-21 TASK 805
ENGINE - 1	74-11311 DEU2 IGNITER DATA IS NOT CORRECT	74-21 TASK 805
ENGINE - 1	74-20951 IGN L (IGN 1) IS FAILED	74-21 TASK 806
ENGINE - 1	74-20961 IGN R (IGN 2) IS FAILED	74-21 TASK 807
ENGINE - 1	74-20971 THE APL INPUT VOLTAGE FOR THE L EXCITER (IGN 1) IS OUT OF RANGE	74-21 TASK 801
ENGINE - 1	74-20981 THE APL INPUT VOLTAGE FOR THE R EXCITER (IGN 2) IS OUT OF RANGE	74-21 TASK 802
ENGINE - 1	74-20991 THE APL INPUT VOLTAGE FOR THE L EXCITER (IGN 1) IS ALWAYS ON	74-21 TASK 803
ENGINE - 1	74-21001 THE APL INPUT VOLTAGE FOR THE R EXCITER (IGN 2) IS ALWAYS ON	74-21 TASK 804
ENGINE - 1	74-21301 DEU1 IGNITER DATA IS NOT CORRECT	74-21 TASK 805
ENGINE - 1	74-21311 DEU2 IGNITER DATA IS NOT CORRECT	74-21 TASK 805
ENGINE - 1	74-30951 IGN L (IGN 1) IS FAILED	74-21 TASK 806
ENGINE - 1	74-30961 IGN R (IGN 2) IS FAILED	74-21 TASK 807
ENGINE - 1	74-30971 THE APL INPUT VOLTAGE FOR THE L EXCITER IS OUT OF RANGE	74-21 TASK 801
ENGINE - 1	74-30981 THE APL INPUT VOLTAGE FOR THE R EXCITER (IGN 2) IS OUT OF RANGE	74-21 TASK 802
ENGINE - 1	74-30991 THE APL INPUT VOLTAGE FOR THE L EXCITER IS ALWAYS ON	74-21 TASK 803
ENGINE - 1	74-31001 THE APL INPUT VOLTAGE FOR THE R EXCITER (IGN 2) IS ALWAYS ON	74-21 TASK 804
ENGINE - 1	74-31301 DEU1 IGNITER DATA IS NOT CORRECT	74-21 TASK 805
ENGINE - 1	74-31311 DEU2 IGNITER DATA IS NOT CORRECT	74-21 TASK 805
ENGINE - 2	74-10952 IGN L (IGN 1) IS FAILED	74-21 TASK 806
ENGINE - 2	74-10962 IGN R (IGN 2) IS FAILED	74-21 TASK 807

EFFECTIVITY  
AKS ALL

## 74-MAINT MSG INDEX

D633A103-AKS

Page 103  
Feb 15/2013

**737-600/700/800/900  
FAULT ISOLATION MANUAL**

LRU/SYSTEM	MAINTENANCE MESSAGE	GO TO FIM TASK
ENGINE - 2	74-10972 THE APL INPUT VOLTAGE FOR THE L EXCITER (IGN 1) IS OUT OF RANGE	74-21 TASK 801
ENGINE - 2	74-10982 THE APL INPUT VOLTAGE FOR THE R EXCITER (IGN 2) IS OUT OF RANGE	74-21 TASK 802
ENGINE - 2	74-10992 THE APL INPUT VOLTAGE FOR THE L EXCITER (IGN 1) IS ALWAYS ON	74-21 TASK 803
ENGINE - 2	74-11002 THE APL INPUT VOLTAGE FOR THE R EXCITER (IGN 2) IS ALWAYS ON	74-21 TASK 804
ENGINE - 2	74-11302 DEU1 IGNITER DATA IS NOT CORRECT	74-21 TASK 805
ENGINE - 2	74-11312 DEU2 IGNITER DATA IS NOT CORRECT	74-21 TASK 805
ENGINE - 2	74-20952 IGN L (IGN 1) IS FAILED	74-21 TASK 806
ENGINE - 2	74-20962 IGN R (IGN 2) IS FAILED	74-21 TASK 807
ENGINE - 2	74-20972 THE APL INPUT VOLTAGE FOR THE L EXCITER (IGN 1) IS OUT OF RANGE	74-21 TASK 801
ENGINE - 2	74-20982 THE APL INPUT VOLTAGE FOR THE R EXCITER (IGN 2) IS OUT OF RANGE	74-21 TASK 802
ENGINE - 2	74-20992 THE APL INPUT VOLTAGE FOR THE L EXCITER (IGN 1) IS ALWAYS ON	74-21 TASK 803
ENGINE - 2	74-21002 THE APL INPUT VOLTAGE FOR THE R EXCITER (IGN 2) IS ALWAYS ON	74-21 TASK 804
ENGINE - 2	74-21302 DEU1 IGNITER DATA IS NOT CORRECT	74-21 TASK 805
ENGINE - 2	74-21312 DEU2 IGNITER DATA IS NOT CORRECT	74-21 TASK 805
ENGINE - 2	74-30952 IGN L (IGN 1) IS FAILED	74-21 TASK 806
ENGINE - 2	74-30962 IGN R (IGN 2) IS FAILED	74-21 TASK 807
ENGINE - 2	74-30972 THE APL INPUT VOLTAGE FOR THE L EXCITER (IGN 1) IS OUT OF RANGE	74-21 TASK 801
ENGINE - 2	74-30982 THE APL INPUT VOLTAGE FOR THE R EXCITER (IGN 2) IS OUT OF RANGE	74-21 TASK 802
ENGINE - 2	74-30992 THE APL INPUT VOLTAGE FOR THE L EXCITER (IGN 1) IS ALWAYS ON	74-21 TASK 803
ENGINE - 2	74-31002 THE APL INPUT VOLTAGE FOR THE R EXCITER (IGN 2) IS ALWAYS ON	74-21 TASK 804
ENGINE - 2	74-31302 DEU1 IGNITER DATA IS NOT CORRECT	74-21 TASK 805
ENGINE - 2	74-31312 DEU2 IGNITER DATA IS NOT CORRECT	74-21 TASK 805

 EFFECTIVITY  
AKS ALL

## 74-MAINT MSG INDEX

D633A103-AKS

 Page 104  
Feb 15/2013

## 737-600/700/800/900 FAULT ISOLATION MANUAL

### 801. Airplane Input Voltage For The Left Exciter (IGN 1) Is Out of Range - Fault Isolation

#### A. Description

- (1) This task is for these maintenance message numbers:
  - (a) 74-10971, 74-10972, 74-20971, 74-20972, 74-30971, and 74-30972.
  - (b) For the maintenance message 74-X097Y; where X = EEC Channel (1=Channel A, 2=Channel B, 3=Dual Channel), and Y = Engine Position (1=Eng 1, 2=Eng 2), do the applicable Fault Isolation:
  - (c) If X=1 or 2, do the Fault Isolation Procedure - Single Channel Fault.
  - (d) If X=1 and 2 (two messages), or if X=3, do the Fault Isolation Procedure - Dual Channel Fault.
- (2) This message can be set by one of these conditions:
  - (a) The EEC senses that the left igniter power (115 VAC) is less than 89 V with the start lever in the IDLE position.
  - (b) The EEC senses that the left igniter power (115 VAC) is more than 141 V with the start lever in the IDLE position.
- (3) This fault is reported when the EEC has electrical power.
  - (a) This fault should show as a dual channel message. If a single channel message shows, there is an internal EEC problem.

#### B. Possible Causes

- (1) For the single channel maintenance message:
  - (a) EEC, M1818.
- (2) For the dual channel maintenance message:
  - (a) The wires, the connectors and the ignition switches between the ignition circuit breakers and the EEC
  - (b) EEC, M1818.

#### C. Circuit Breakers

- (1) For Engine 1,
  - (a) This is the primary circuit breaker related to the fault:

##### CAPT Electrical System Panel, P18-2

<u>Row</u>	<u>Col</u>	<u>Number</u>	<u>Name</u>
A	3	C00153	ENGINE 1 IGNITION LEFT

- (2) For Engine 2,
  - (a) This is the circuit breaker:

##### F/O Electrical System Panel, P6-2

<u>Row</u>	<u>Col</u>	<u>Number</u>	<u>Name</u>
D	6	C00151	ENGINE 2 IGNITION LEFT

#### D. Related Data

- (1) Component Location (Figure 301)
- (2) Simplified Schematic (Figure 302)
- (3) (SSM 74-11-11)

## 737-600/700/800/900 FAULT ISOLATION MANUAL

(4) (WDM 74-11-11)

### E. Initial Evaluation

- (1) To find out if the fault is still active, do this task: Ignition System Audible Test, AMM TASK 74-00-00-750-801-F00
  - (a) If maintenance message number 74-10971, 74-10972, 74-20971, or 74-20972 shows, then do the Fault Isolation Procedure - Single Channel Fault.
  - (b) If maintenance message number 74-30971 or 74-30972 shows, then do the Fault Isolation Procedure - Dual Channel Fault.
  - (c) If the maintenance message does not show on the FMCS CDU, then there was a momentary loss of electrical power to the left exciter or EEC, or an intermittent fault.
    - 1) For a momentary loss of electrical power, do a check of the pilots' log for an indication of a momentary power interruption on the airplane or on the 115 VAC transfer bus 1 (Eng 1) or 2 (Eng 2).
      - a) If you find a report, then this was the cause of this fault. If no report was made, then there was an intermittent fault.
    - 2) For an intermittent fault you must use your judgment, your airline policies, and the Possible Causes list to make the decision if you will try to correct the fault.
    - 3) If you will try to correct the fault, it is recommended that you do these steps:
      - a) Do the visual checks of the electrical connectors in the applicable fault isolation procedure below.
      - b) Use the WDM references to identify intermediate electrical connections in the wire harness and do a visual check.
      - c) If you find no problems, then replace components as listed in the Possible Causes list above.
    - 4) Monitor the airplane on the subsequent flight.

### F. Fault Isolation Procedure - Single Channel Fault

- (1) If the fault was found by the Initial Evaluation, then replace the EEC, M1818.  
These are the tasks:  
EEC Removal, AMM TASK 73-21-60-000-801-F00,  
EEC Installation, AMM TASK 73-21-60-400-801-F00.
  - (a) Do the Repair Confirmation at the end of this task.

### G. Fault Isolation Procedure - Dual Channel Fault

- (1) Do these steps to prepare for the procedure:
  - (a) For Engine 1,
    - 1) Make sure that these circuit breakers are open and have safety tags:

#### CAPT Electrical System Panel, P18-2

<u>Row</u>	<u>Col</u>	<u>Number</u>	<u>Name</u>
A	3	C00153	ENGINE 1 IGNITION LEFT
A	4	C01390	ENGINE 1 ALTN PWR CHAN B
A	5	C01314	ENGINE 1 ALTN PWR CHAN A

- (b) For Engine 2,

## 737-600/700/800/900 FAULT ISOLATION MANUAL

- 1) Make sure that these circuit breakers are open and have safety tags:

### F/O Electrical System Panel, P6-2

<u>Row</u>	<u>Col</u>	<u>Number</u>	<u>Name</u>
D	6	C00151	ENGINE 2 IGNITION LEFT
D	7	C01391	ENGINE 2 ALTN PWR CHAN B
D	8	C01315	ENGINE 2 ALTN PWR CHAN A

- (c) Make sure that the applicable start lever is in the CUTOFF position.
  - (d) If not already done, do this task: Open the Fan Cowl Panels, AMM TASK 71-11-02-010-801-F00.
- (2) Examine the electrical connector DP0101 at the EEC:
 

NOTE: The electrical connector DP0101 is on the MW0301 wire harness at the J1 receptacle.

  - (a) Make sure that the electrical connector DP0101 is correctly connected to the EEC.
  - (b) Disconnect the electrical connector DP0101 from the EEC.
  - (c) Visually examine the EEC J1 receptacle and wire harness connector.
    - 1) If the EEC J1 receptacle is damaged, then replace the EEC, M1818.  
 These are the tasks:  
 EEC Removal, AMM TASK 73-21-60-000-801-F00,  
 EEC Installation, AMM TASK 73-21-60-400-801-F00.
      - a) Do the Repair Confirmation at the end of this task.
      - b) If the Repair Confirmation is not satisfactory then continue.
    - 2) If the harness connector is damaged, then replace the MW0301 wire harness.  
 These are the tasks:  
 Nacelle Wiring Harnesses Removal, AMM TASK 71-51-03-000-801-F00,  
 Nacelle Wiring Harnesses Installation, AMM TASK 71-51-03-400-801-F00.
      - a) Do the Repair Confirmation at the end of this task.
      - b) If the Repair Confirmation is not satisfactory, then continue.
    - 3) If the connector was not correctly connected, and no other problem was found, then do the Repair Confirmation at the end of this task.
    - 4) If the Repair Confirmation is not satisfactory, then continue.
  - (d) If you did not find a problem, then continue.
- (3) To examine the applicable left ignition switches, S88 (Eng 1) or S90 (Eng 2), in the engine start brake assembly, you can use input monitoring to see if the switch operation agrees with the selected start lever position.

NOTE: Some initial switches in the engine start brake assembly can cause engine start problems.

- (a) For Engine 1,
  - 1) Remove the safety tags and close these circuit breakers:

### CAPT Electrical System Panel, P18-2

<u>Row</u>	<u>Col</u>	<u>Number</u>	<u>Name</u>
A	3	C00153	ENGINE 1 IGNITION LEFT

## 737-600/700/800/900 FAULT ISOLATION MANUAL

(Continued)

**CAPT Electrical System Panel, P18-2**

<u>Row</u>	<u>Col</u>	<u>Number</u>	<u>Name</u>
A	4	C01390	ENGINE 1 ALTN PWR CHAN B
A	5	C01314	ENGINE 1 ALTN PWR CHAN A

(b) For Engine 2,

- 1) Remove the safety tags and close these circuit breakers:

**F/O Electrical System Panel, P6-2**

<u>Row</u>	<u>Col</u>	<u>Number</u>	<u>Name</u>
D	6	C00151	ENGINE 2 IGNITION LEFT
D	7	C01391	ENGINE 2 ALTN PWR CHAN B
D	8	C01315	ENGINE 2 ALTN PWR CHAN A

(c) Get access to the input monitoring screen on the CDU:

- 1) Push the INIT REF key two times.

NOTE: This causes the PERF INIT INDEX to show.

- 2) Push the INDEX line select key (LSK).

- 3) Push the MAINT LSK.

- 4) Push the ENGINE LSK.

- 5) Push the line select key for the applicable engine (ENGINE 1 or ENGINE 2).

NOTE: This causes the ENGINE X BITE TEST MAIN MENU to show.

- 6) Push the INPUT MONITORING LSK.

NOTE: An alert message will show to tell you that only data from one channel is available.

- 7) Push the CONTINUE LSK.

NOTE: This causes the INPUT MONITORING MENU to show. Push the NEXT PAGE key to go to page 2 of the menu

- 8) Push the DISCRETES LSK.

NOTE: This causes the INPUT MONITORING GMM DISCRETES screen to show.

- 9) Push the NEXT PAGE key twice to see page 3/3 and find the L IGNITER 115V line on the screen.

(d) With the applicable start lever in the CUTOFF position, make sure the value is OFF.

(e) Put the applicable start lever to the IDLE position and make sure the value is ON for each line.

(f) Operate the start lever several times and see if the switch operates correctly.

(g) If the switch does not operate correctly, replace the switch, S88 or S90.

These are the tasks:

Engine Start Brake Assembly Switch Removal, AMM TASK 76-11-11-010-801-F00,

Engine Start Brake Assembly Switch Installation, AMM TASK 76-11-11-420-801-F00.

- 1) Do the Repair Confirmation at the end of the task.

(h) If the switch operates correctly, then continue.



**737-600/700/800/900  
FAULT ISOLATION MANUAL**

- (4) Do these steps to measure the input voltage at the EEC electrical connector DP0101:
  - (a) Put the applicable start lever to the IDLE position.
  - (b) Do a check for 115 VAC from pin A to pin B (ground) of the electrical connector DP0101.
    - 1) Put the applicable start lever to the CUTOFF position.
  - (c) If 115 VAC is not found, then examine and repair the wires, connectors from the left ignition switch S88 (Engine 1) or S90 (Engine 2) to the EEC.
    - 1) Do the Repair Confirmation at the end of this task.
  - (d) If 115 VAC is found, then continue.
- (5) Do the audible test again. To do the test, do this task: Ignition System Audible Test, AMM TASK 74-00-00-750-801-F00.
  - (a) If the maintenance message shows, then replace the EEC, M1818.  
These are the tasks:  
EEC Removal, AMM TASK 73-21-60-000-801-F00,  
EEC Installation, AMM TASK 73-21-60-400-801-F00.
    - 1) Do the Repair Confirmation at the end of this task.
  - (b) If the maintenance message does not show, then there was an intermittent fault.

#### H. Repair Confirmation

- (1) Do these steps to prepare for the procedure:
  - (a) Make sure that the electrical connector DP0101 is correctly connected to the EEC.
  - (b) For Engine 1,
    - 1) Make sure that these circuit breakers are closed:

**CAPT Electrical System Panel, P18-2**

<u>Row</u>	<u>Col</u>	<u>Number</u>	<u>Name</u>
A	3	C00153	ENGINE 1 IGNITION LEFT
A	4	C01390	ENGINE 1 ALTN PWR CHAN B
A	5	C01314	ENGINE 1 ALTN PWR CHAN A

- (c) For Engine 2,
  - 1) Make sure that these circuit breakers are closed:

**F/O Electrical System Panel, P6-2**

<u>Row</u>	<u>Col</u>	<u>Number</u>	<u>Name</u>
D	6	C00151	ENGINE 2 IGNITION LEFT
D	7	C01391	ENGINE 2 ALTN PWR CHAN B
D	8	C01315	ENGINE 2 ALTN PWR CHAN A

- (2) Do this task: Ignition System Audible Test, AMM TASK 74-00-00-750-801-F00.
  - (a) If the maintenance message does not show, then you corrected the fault.
- (3) Do this task: Close the Fan Cowl Panels, AMM TASK 71-11-02-410-801-F00.

————— **END OF TASK** —————

## 737-600/700/800/900 FAULT ISOLATION MANUAL

### 802. Airplane Input Voltage For The Right Exciter (IGN 2) Is Out of Range - Fault Isolation

#### A. Description

- (1) This task is for these maintenance message numbers:
  - (a) 74-10981, 74-10982, 74-20981, 74-20982, 74-30981, and 74-30982.
  - (b) For the maintenance message 74-X098Y; where X = EEC Channel (1=Channel A, 2=Channel B, 3=Dual Channel), and Y = Engine Position (1=Eng 1, 2=Eng 2), do the applicable Fault Isolation:
  - (c) If X=1 or 2, do the Fault Isolation Procedure - Single Channel Fault.
  - (d) If X=1 and 2 (two messages), or if X=3, do the Fault Isolation Procedure - Dual Channel Fault.
- (2) This message can be set by one of these condition:
  - (a) The EEC senses that the right igniter power (115 VAC) is less than 89 V with the start lever in the IDLE position.
  - (b) The EEC senses that the right igniter power (115 VAC) is more than 141 V with the start lever in the IDLE position.
- (3) This fault is reported when the EEC has electrical power.
  - (a) This fault should show as a dual channel message. If a single channel message shows there is an internal EEC problem.

#### B. Possible Causes

- (1) For the single channel maintenance message:
  - (a) EEC, M1818.
- (2) For the dual channel maintenance message:
  - (a) The wires, the connectors and the ignition switches between the ignition circuit breakers and the EEC
  - (b) EEC, M1818.

#### C. Circuit Breakers

- (1) For Engine 1:
  - (a) This is the primary circuit breaker related to the fault:

##### CAPT Electrical System Panel, P18-2

<u>Row</u>	<u>Col</u>	<u>Number</u>	<u>Name</u>
A	1	C00458	ENGINE 1 IGNITION RIGHT

- (2) For Engine 2:
  - (a) This is the primary circuit breaker related to the fault:

##### F/O Electrical System Panel, P6-2

<u>Row</u>	<u>Col</u>	<u>Number</u>	<u>Name</u>
D	4	C00459	ENGINE 2 IGNITION RIGHT

#### D. Related Data

- (1) Component Location (Figure 301)
- (2) Simplified Schematic (Figure 302)
- (3) (SSM 74-11-11)

EFFECTIVITY  
AKS ALL

## 74-21 TASK 802

## 737-600/700/800/900 FAULT ISOLATION MANUAL

(4) (WDM 74-11-11)

### E. Initial Evaluation

- (1) To find out if the fault is still active, do this task: Ignition System Audible Test, AMM TASK 74-00-00-750-801-F00
  - (a) If maintenance message number 74-10981, 74-10982, 74-20981, or 74-20982 shows, then do the Fault Isolation Procedure - Single Channel Fault.
  - (b) If maintenance message number 74-30981 or 74-30982 shows, then do the Fault Isolation Procedure - Dual Channel Fault.
  - (c) If the maintenance message does not show on the FMCS CDU, then the Initial Evaluation has shown that the fault is not active at this time and you have an intermittent fault.
    - 1) If you cannot find the fault at this time, then the Fault Isolation Procedure cannot isolate the fault.
    - 2) For an intermittent fault you must use your judgment, your airline policies, and the Possible Causes list to make the decision if you will try to correct the fault.
    - 3) If you will try to correct the fault, it is recommended that you do these steps:
      - a) Do the visual checks of the electrical connectors in the applicable fault isolation procedure below.
      - b) Use the WDM references to identify intermediate electrical connections in the wire harness and do a visual check.
      - c) If you find no problems, then replace components as listed in the Possible Causes list above.
    - 4) Monitor the airplane on the subsequent flight.

### F. Fault Isolation Procedure - Single Channel Fault

- (1) If the fault was found by the Initial Evaluation, then replace the EEC, M1818.  
These are the tasks:  
EEC Removal, AMM TASK 73-21-60-000-801-F00,  
EEC Installation, AMM TASK 73-21-60-400-801-F00.
  - (a) Do the Repair Confirmation at the end of this task.

### G. Fault Isolation Procedure - Dual Channel Fault

- (1) Do these steps to prepare for the procedure:
  - (a) For Engine 1:
    - 1) Make sure that these circuit breakers are open and have safety tags:

#### CAPT Electrical System Panel, P18-2

<u>Row</u>	<u>Col</u>	<u>Number</u>	<u>Name</u>
A	1	C00458	ENGINE 1 IGNITION RIGHT
A	4	C01390	ENGINE 1 ALTN PWR CHAN B
A	5	C01314	ENGINE 1 ALTN PWR CHAN A

- (b) For Engine 2:

## 737-600/700/800/900 FAULT ISOLATION MANUAL

- 1) Make sure that these circuit breakers are open and have safety tags:

### F/O Electrical System Panel, P6-2

<u>Row</u>	<u>Col</u>	<u>Number</u>	<u>Name</u>
D	4	C00459	ENGINE 2 IGNITION RIGHT
D	7	C01391	ENGINE 2 ALTN PWR CHAN B
D	8	C01315	ENGINE 2 ALTN PWR CHAN A

- (c) Make sure that the applicable start lever is in the CUTOFF position.
  - (d) If not already done, do this task: Open the Fan Cowl Panels, AMM TASK 71-11-02-010-801-F00.
- (2) Examine the electrical connector DP0202 at the EEC:
 

**NOTE:** The electrical connector DP0202 is on the MW0302 wire harness at the J2 receptacle

    - (a) Make sure that the electrical connector DP0202 is correctly connected to the EEC.
    - (b) Disconnect the electrical connector DP0202 from the EEC.
    - (c) Visually examine the EEC J2 receptacle and wire harness connector.
      - 1) If the EEC J2 receptacle is damaged, then replace the EEC, M1818.  
These are the tasks:  
EEC Removal, AMM TASK 73-21-60-000-801-F00,  
EEC Installation, AMM TASK 73-21-60-400-801-F00.
        - a) Do the Repair Confirmation at the end of this task.
        - b) If the Repair Confirmation is not satisfactory, then continue.
      - 2) If the harness connector is damaged, then replace the MW0302 wire harness.  
These are the tasks:  
Nacelle Wiring Harnesses Removal, AMM TASK 71-51-03-000-801-F00,  
Nacelle Wiring Harnesses Installation, AMM TASK 71-51-03-400-801-F00.
        - a) Do the Repair Confirmation at the end of this task.
        - b) If the Repair Confirmation is not satisfactory, then continue.
      - 3) If the connector was not correctly connected, and no other problem was found, then do the Repair Confirmation at the end of this task.
      - 4) If the Repair Confirmation is not satisfactory, then continue.
    - (d) If you did not find a problem, then continue.
  - (3) To examine the applicable right ignition switch, S89 (Eng 1) or S91 (Eng 2) in the engine start brake assembly, you can use input monitoring the see if the switch position agrees with the selected start lever position.

**NOTE:** Some initial switches in the engine start brake assembly can cause engine start problems.

- (a) For Engine 1:
  - 1) Remove the safety tags and close these circuit breakers:

### CAPT Electrical System Panel, P18-2

<u>Row</u>	<u>Col</u>	<u>Number</u>	<u>Name</u>
A	1	C00458	ENGINE 1 IGNITION RIGHT

## 737-600/700/800/900 FAULT ISOLATION MANUAL

(Continued)

**CAPT Electrical System Panel, P18-2**

<u>Row</u>	<u>Col</u>	<u>Number</u>	<u>Name</u>
A	4	C01390	ENGINE 1 ALTN PWR CHAN B
A	5	C01314	ENGINE 1 ALTN PWR CHAN A

(b) For Engine 2:

- 1) Remove the safety tags and close these circuit breakers:

**F/O Electrical System Panel, P6-2**

<u>Row</u>	<u>Col</u>	<u>Number</u>	<u>Name</u>
D	4	C00459	ENGINE 2 IGNITION RIGHT
D	7	C01391	ENGINE 2 ALTN PWR CHAN B
D	8	C01315	ENGINE 2 ALTN PWR CHAN A

(c) Get access to the input monitoring screen on the CDU:

- 1) Push the INIT REF key two times.

NOTE: This causes the PERF INIT INDEX to show.

- 2) Push the INDEX line select key (LSK).

- 3) Push the MAINT LSK.

- 4) Push the ENGINE LSK.

- 5) Push the line select key for the applicable engine (ENGINE 1 or ENGINE 2).

NOTE: This causes the ENGINE X BITE TEST MAIN MENU to show.

- 6) Push the INPUT MONITORING LSK.

NOTE: An alert message will show to tell you that only data from one channel is available.

- 7) Push the CONTINUE LSK.

NOTE: This causes the INPUT MONITORING MENU to show. Push the NEXT PAGE key to go to page 2 of the menu

- 8) Push the DISCRETES LSK.

NOTE: This causes the INPUT MONITORING GMM DISCRETES screen to show.

- 9) Push the NEXT PAGE key twice to see page 3/3 and find the R IGNITER 115V line on the screen.

(d) With the applicable start lever in the CUTOFF position, make sure the value is OFF.

(e) Put the applicable start lever to the IDLE position and make sure the value is ON.

(f) Operate the start lever several times to see if the switch operates correctly.

(g) If the switch does not operate correctly, replace the switch, S89 or S91.

These are the tasks:

Engine Start Brake Assembly Switch Removal, AMM TASK 76-11-11-010-801-F00,

Engine Start Brake Assembly Switch Installation, AMM TASK 76-11-11-420-801-F00.

- 1) Do the Repair Confirmation at the end of the task.

(h) If the switch operates correctly, then continue.

(4) Do these steps to measure the input voltage at the EEC electrical connector DP0202:

EFFECTIVITY  
AKS ALL

# 74-21 TASK 802

## 737-600/700/800/900 FAULT ISOLATION MANUAL

- (a) Put the applicable start lever to the IDLE position.
- (b) Do a check for 115 VAC from pin A to pin B (ground) of the electrical connector DP0202.
  - 1) Put the applicable start lever to the CUTOFF position.
- (c) If 115 VAC is not found, then examine and repair the wires, connectors from the right ignition switch S89 (Engine 1) or S91 (Engine 2) to the EEC.
  - 1) Do the Repair Confirmation at the end of this task.
- (d) If 115 VAC is found, then continue.
- (5) Do the audible test again. To do the test, do this task: Ignition System Audible Test, AMM TASK 74-00-00-750-801-F00.
  - (a) If the maintenance message shows, then replace the EEC, M1818.  
These are the tasks:  
EEC Removal, AMM TASK 73-21-60-000-801-F00,  
EEC Installation, AMM TASK 73-21-60-400-801-F00.
    - 1) Do the Repair Confirmation at the end of this task.
  - (b) If the maintenance message does not show, then there was an intermittent fault.

### H. Repair Confirmation

- (1) Do these steps to prepare for the procedure:
  - (a) Make sure that the electrical connector DP0202 is correctly connected to the EEC.
  - (b) For Engine 1:
    - 1) Remove the safety tags and close these circuit breakers:

#### CAPT Electrical System Panel, P18-2

<u>Row</u>	<u>Col</u>	<u>Number</u>	<u>Name</u>
A	1	C00458	ENGINE 1 IGNITION RIGHT
A	4	C01390	ENGINE 1 ALTN PWR CHAN B
A	5	C01314	ENGINE 1 ALTN PWR CHAN A

- (c) For Engine 2:
  - 1) Remove the safety tags and close these circuit breakers:

#### F/O Electrical System Panel, P6-2

<u>Row</u>	<u>Col</u>	<u>Number</u>	<u>Name</u>
D	4	C00459	ENGINE 2 IGNITION RIGHT
D	7	C01391	ENGINE 2 ALTN PWR CHAN B
D	8	C01315	ENGINE 2 ALTN PWR CHAN A

- (2) Do this task: Ignition System Audible Test, AMM TASK 74-00-00-750-801-F00.
  - (a) If the maintenance message does not show, then you corrected the fault.
- (3) Do this task: Close the Fan Cowl Panels, AMM TASK 71-11-02-410-801-F00.

————— **END OF TASK** —————

## 737-600/700/800/900 FAULT ISOLATION MANUAL

### 803. Airplane Input Voltage For The Left Exciter (IGN 1) Is Always On - Fault Isolation

#### A. Description

- (1) This task is for these maintenance message numbers:
  - (a) 74-10991, 74-10992, 74-20991, 74-20992, 74-30991, and 74-30992.
  - (b) For the maintenance message 74-X099Y; where X = EEC Channel (1=Channel A, 2=Channel B, 3=Dual Channel), and Y = Engine Position (1=Eng 1, 2=Eng 2), do the applicable Fault Isolation:
  - (c) If X=1 or 2, do the Fault Isolation Procedure - Single Channel Fault.
  - (d) If X=1 and 2 (two messages), or If X=3, do the Fault Isolation Procedure - Dual Channel Fault.
- (2) This message can be set by this condition:
  - (a) The EEC senses that the left igniter power (115 VAC) is 89 V or more with the start lever in the CUTOFF position.
- (3) This fault is reported when the EEC has electrical power.
  - (a) This fault should show as a dual channel message. If a single channel message shows, there is an internal EEC problem.

#### B. Possible Causes

- (1) For the single channel maintenance message:
  - (a) EEC, M1818.
- (2) For the dual channel maintenance message:
  - (a) The wires, the connectors and the ignition switches between the ignition circuit breakers and the EEC
  - (b) EEC, M1818.

#### C. Circuit Breakers

- (1) For Engine 1:
  - (a) This is the primary circuit breaker related to the fault:

##### CAPT Electrical System Panel, P18-2

<u>Row</u>	<u>Col</u>	<u>Number</u>	<u>Name</u>
A	3	C00153	ENGINE 1 IGNITION LEFT

- (2) For Engine 2:
  - (a) This is the primary circuit breaker related to the fault:

##### F/O Electrical System Panel, P6-2

<u>Row</u>	<u>Col</u>	<u>Number</u>	<u>Name</u>
D	6	C00151	ENGINE 2 IGNITION LEFT

#### D. Related Data

- (1) Component Location (Figure 301)
- (2) Simplified Schematic (Figure 302)
- (3) (SSM 74-11-11)
- (4) (WDM 74-11-11)

## 737-600/700/800/900 FAULT ISOLATION MANUAL

### E. Initial Evaluation

- (1) To find out if the fault is still active, do this task: EEC TEST, AMM TASK 73-21-00-700-804-F00.
  - (a) If maintenance message number 74-10991, 74-10992, 74-20991, or 74-20992 shows, then do the Fault Isolation Procedure - Single Channel Fault.
  - (b) If maintenance message number 74-30991 or 74-30992 shows, then do the Fault Isolation Procedure - Dual Channel Fault.
  - (c) If the maintenance message does not show on the FMCS CDU, then the Initial Evaluation has shown that the fault is not active at this time and you have an intermittent fault.
    - 1) If you cannot find the fault at this time, then the Fault Isolation Procedure cannot isolate the fault.
    - 2) For an intermittent fault you must use your judgment, your airline policies, and the Possible Causes list to make the decision if you will try to correct the fault.
    - 3) If you will try to correct the fault, it is recommended that you do these steps:
      - a) Do the visual checks of the electrical connectors in the applicable fault isolation procedure below.
      - b) Use the WDM references to identify intermediate electrical connections in the wire harness and do a visual check.
      - c) If you find no problems, then replace components as listed in the Possible Causes list above.
  - (d) Monitor the airplane on the subsequent flight.

### F. Fault Isolation Procedure - Single Channel Fault

- (1) If the fault was found by the Initial Evaluation, then replace the EEC, M1818.  
These are the tasks:  
EEC Removal, AMM TASK 73-21-60-000-801-F00,  
EEC Installation, AMM TASK 73-21-60-400-801-F00.
  - (a) Do the Repair Confirmation at the end of this task.

### G. Fault Isolation Procedure - Dual Channel Fault

- (1) Do these steps to prepare for the procedure:
  - (a) For Engine 1:
    - 1) Open these circuit breakers and install safety tags:

#### CAPT Electrical System Panel, P18-2

<u>Row</u>	<u>Col</u>	<u>Number</u>	<u>Name</u>
A	3	C00153	ENGINE 1 IGNITION LEFT
A	4	C01390	ENGINE 1 ALTN PWR CHAN B
A	5	C01314	ENGINE 1 ALTN PWR CHAN A

- (b) For Engine 2:



## 737-600/700/800/900 FAULT ISOLATION MANUAL

- 1) Open these circuit breakers and install safety tags:

### F/O Electrical System Panel, P6-2

<u>Row</u>	<u>Col</u>	<u>Number</u>	<u>Name</u>
D	6	C00151	ENGINE 2 IGNITION LEFT
D	7	C01391	ENGINE 2 ALTN PWR CHAN B
D	8	C01315	ENGINE 2 ALTN PWR CHAN A

- (c) Make sure that the applicable start lever is in the CUTOFF position.
  - (d) If not already done, do this task: Open the Fan Cowl Panels, AMM TASK 71-11-02-010-801-F00.
- (2) Examine the electrical connector DP0101 at the EEC:
 

NOTE: The electrical connector DP0101 is on the MW0301 wire harness at the J1 receptacle.

  - (a) Make sure that the electrical connector DP0101 is correctly connected to the EEC.
  - (b) Disconnect the electrical connector DP0101 from the EEC.
  - (c) Visually examine the EEC J1 receptacle and wire harness connector.
    - 1) If the EEC J1 receptacle is damaged, then replace the EEC, M1818.  
 These are the tasks:  
 EEC Removal, AMM TASK 73-21-60-000-801-F00,  
 EEC Installation, AMM TASK 73-21-60-400-801-F00.
      - a) Do the Repair Confirmation at the end of this task.
      - b) If the Repair Confirmation is not satisfactory, then continue.
    - 2) If the harness connector is damaged, then replace the MW0301 wire harness.  
 These are the tasks:  
 Nacelle Wiring Harnesses Removal, AMM TASK 71-51-03-000-801-F00,  
 Nacelle Wiring Harnesses Installation, AMM TASK 71-51-03-400-801-F00.
      - a) Do the Repair Confirmation at the end of this task.
      - b) If the Repair Confirmation is not satisfactory, then continue.
    - 3) If the connector was not correctly connected and no other problem was found, then do the Repair Confirmation at the end of this task.
      - a) If the Repair Confirmation is not satisfactory, then continue.
  - (d) If you did not find a problem, then continue.
- (3) Do these steps to measure the input voltage at the electrical connector DP0101 at the EEC:
  - (a) For Engine 1:
    - 1) Remove the safety tag and close this circuit breaker:

### CAPT Electrical System Panel, P18-2

<u>Row</u>	<u>Col</u>	<u>Number</u>	<u>Name</u>
A	3	C00153	ENGINE 1 IGNITION LEFT

- (b) For Engine 2:

## 737-600/700/800/900 FAULT ISOLATION MANUAL

- 1) Remove the safety tag and close this circuit breaker:

### F/O Electrical System Panel, P6-2

<u>Row</u>	<u>Col</u>	<u>Number</u>	<u>Name</u>
D	6	C00151	ENGINE 2 IGNITION LEFT

- (c) Do a check for 0 VAC from pin A to pin B (ground) of the DP0101 electrical connector.
- (d) If the voltage is 0 VAC and the fault was found by the Initial Evaluation, then replace the EEC, M1818.

These are the tasks:

EEC Removal, AMM TASK 73-21-60-000-801-F00,

EEC Installation, AMM TASK 73-21-60-400-801-F00.

- 1) Do the Repair Confirmation at the end of this task.
- (e) If the voltage is not 0 VAC, then continue.
- (4) Do this check of the applicable left ignition switch S88 (Engine 1) or S90 (Engine 2):

**NOTE:** The S88 switch is in the engine 1 start brake assembly M1824 in the control stand.  
The S90 switch is in the engine 2 start brake assembly M1825.

- (a) Remove the upper and side panels from the control stand.
- (b) Disconnect the electrical connector D11286P or D11290P from the control stand.
- (c) Do a continuity check from the pin 11 to pin 13 of the connector.
- (d) If there is continuity, then replace the applicable S88 or S90 switch for a faulty ignition switch.

These are the tasks:

Engine Start Brake Assembly Switch Removal, AMM TASK 76-11-11-010-801-F00,

Engine Start Brake Assembly Switch Installation, AMM TASK 76-11-11-420-801-F00.

- 1) Do the Repair Confirmation at the end of this task.
- (e) If there is not continuity, then examine and repair the wires and connectors between the ignition switch and the EEC.
- 1) Do the Repair Confirmation at the end of this task.

### H. Repair Confirmation

- (1) Prepare for the procedure:
  - (a) Make sure that the electrical connector DP0101 is correctly connected to the EEC.
  - (b) Make sure that the electrical connectors D11286P and D11290P are correctly connected to the control stand.
  - (c) For Engine 1:
    - 1) Make sure that these circuit breakers are closed:

### CAPT Electrical System Panel, P18-2

<u>Row</u>	<u>Col</u>	<u>Number</u>	<u>Name</u>
A	3	C00153	ENGINE 1 IGNITION LEFT
A	4	C01390	ENGINE 1 ALTN PWR CHAN B
A	5	C01314	ENGINE 1 ALTN PWR CHAN A

- (d) For Engine 2:

EFFECTIVITY  
AKS ALL

# 74-21 TASK 803

D633A103-AKS

Page 214  
Jun 15/2016

## 737-600/700/800/900 FAULT ISOLATION MANUAL

- 1) Make sure that these circuit breakers are closed:

### F/O Electrical System Panel, P6-2

<u>Row</u>	<u>Col</u>	<u>Number</u>	<u>Name</u>
D	6	C00151	ENGINE 2 IGNITION LEFT
D	7	C01391	ENGINE 2 ALTN PWR CHAN B
D	8	C01315	ENGINE 2 ALTN PWR CHAN A

- (2) Do this task: EEC TEST, AMM TASK 73-21-00-700-804-F00.
  - (a) If the maintenance message does not show, you corrected the fault.
- (3) Install the upper and side panels to the control stand.
- (4) Do this task: Close the Fan Cowl Panels, AMM TASK 71-11-02-410-801-F00.

### ————— END OF TASK —————

## 804. Airplane Input Voltage For The Right Exciter (IGN 2) Is Always On - Fault Isolation

### A. Description

- (1) This task is for these maintenance message numbers:
  - (a) 74-11001, 74-11002, 74-21001, 74-21002, 74-31001, and 74-31002.
  - (b) For the maintenance message 74-X100Y; where X = EEC Channel (1=Channel A, 2=Channel B, 3=Dual Channel), and Y = Engine Position (1=Eng 1, 2=Eng 2), do the applicable Fault Isolation:
  - (c) If X=1 or 2, do the Fault Isolation Procedure - Single Channel Fault.
  - (d) If X=1 and 2 (two messages), or if X=3, do the Fault Isolation Procedure - Dual Channel Fault.
- (2) This message can be set by this condition:
  - (a) The EEC senses that the right igniter power (115 VAC) is 89 V or more with the start lever in the CUTOFF position.
- (3) This fault is reported when the EEC has electrical power.
  - (a) This fault should show as a dual channel message. If a single channel message shows there is an internal EEC problem.

### B. Possible Causes

- (1) For the single channel maintenance message:
  - (a) EEC, M1818.
- (2) For the dual channel maintenance message:
  - (a) The wires, the connectors and the ignition switches between the ignition circuit breakers and the EEC
  - (b) EEC, M1818.

### C. Circuit Breakers

- (1) For Engine 1:
  - (a) This is the primary circuit breaker related to the fault:

### CAPT Electrical System Panel, P18-2

<u>Row</u>	<u>Col</u>	<u>Number</u>	<u>Name</u>
A	1	C00458	ENGINE 1 IGNITION RIGHT

EFFECTIVITY  
AKS ALL

## 74-21 TASKS 803-804

## 737-600/700/800/900 FAULT ISOLATION MANUAL

- (2) For Engine 2:
- (a) This is the primary circuit breaker related to the fault:

### F/O Electrical System Panel, P6-2

<u>Row</u>	<u>Col</u>	<u>Number</u>	<u>Name</u>
D	4	C00459	ENGINE 2 IGNITION RIGHT

#### D. Related Data

- (1) Component Location (Figure 301)
- (2) Simplified Schematic (Figure 302)
- (3) (SSM 74-11-11)
- (4) (WDM 74-11-11)

#### E. Initial Evaluation

- (1) To find out if the fault is still active, do this task: EEC TEST, AMM TASK 73-21-00-700-804-F00
  - (a) If maintenance message number 74-11001, 74-11002, 74-21001, or 74-21002 shows, then do the Fault Isolation Procedure - Single Channel Fault.
  - (b) If maintenance message number 74-31001 or 74-31002 shows, then do the Fault Isolation Procedure - Dual Channel Fault.
  - (c) If the maintenance message does not show on the FMCS CDU, then the Initial Evaluation has shown that the fault is not active at this time and you have an intermittent fault.
    - 1) If you cannot find the fault at this time, then the Fault Isolation Procedure cannot isolate the fault.
    - 2) For an intermittent fault you must use your judgment, your airline policies, and the Possible Causes list to make the decision if you will try to correct the fault.
    - 3) If you will try to correct the fault, it is recommended that you do these steps:
      - a) Do the visual checks of the electrical connectors in the applicable fault isolation procedure below.
      - b) Use the WDM references to identify intermediate electrical connections in the wire harness and do a visual check.
      - c) If you find no problems, then replace components as listed in the Possible Causes list above.
  - (d) Monitor the airplane on the subsequent flight.

#### F. Fault Isolation Procedure - Single Channel Fault

- (1) If the fault was found by the Initial Evaluation, then replace the EEC, M1818.  
These are the tasks:  
EEC Removal, AMM TASK 73-21-60-000-801-F00,  
EEC Installation, AMM TASK 73-21-60-400-801-F00.
  - (a) Do the Repair Confirmation at the end of this task.

#### G. Fault Isolation Procedure - Dual Channel Fault

- (1) Do these steps to prepare for the procedure:
  - (a) For Engine 1

## 737-600/700/800/900 FAULT ISOLATION MANUAL

- 1) Open these circuit breakers and install safety tags:

### CAPT Electrical System Panel, P18-2

<u>Row</u>	<u>Col</u>	<u>Number</u>	<u>Name</u>
A	1	C00458	ENGINE 1 IGNITION RIGHT
A	4	C01390	ENGINE 1 ALTN PWR CHAN B
A	5	C01314	ENGINE 1 ALTN PWR CHAN A

- (b) For Engine 2

- 1) Open these circuit breakers and install safety tags:

### F/O Electrical System Panel, P6-2

<u>Row</u>	<u>Col</u>	<u>Number</u>	<u>Name</u>
D	4	C00459	ENGINE 2 IGNITION RIGHT
D	7	C01391	ENGINE 2 ALTN PWR CHAN B
D	8	C01315	ENGINE 2 ALTN PWR CHAN A

- (c) Make sure that the applicable start lever is in the CUTOFF position.
  - (d) If not already done, do this task: Open the Fan Cowl Panels, AMM TASK 71-11-02-010-801-F00.
- (2) Examine the electrical connector DP0202 at the EEC:  
**NOTE:** The electrical connector DP0202 is on the MW0302 wire harness at the J2 receptacle.
    - (a) Make sure that the electrical connector DP0202 is correctly connected to the EEC.
    - (b) Disconnect the electrical connector DP0202 from the EEC.
    - (c) Visually examine the EEC J2 receptacle and wire harness connector.
      - 1) If the EEC J2 receptacle is damaged, then replace the EEC, M1818.  
 These are the tasks:  
 EEC Removal, AMM TASK 73-21-60-000-801-F00,  
 EEC Installation, AMM TASK 73-21-60-400-801-F00.
        - a) Do the Repair Confirmation at the end of this task.
        - b) If the Repair Confirmation is not satisfactory, then continue.
      - 2) If the harness connector is damaged, then replace the MW0302 wire harness.  
 These are the tasks:  
 Nacelle Wiring Harnesses Removal, AMM TASK 71-51-03-000-801-F00,  
 Nacelle Wiring Harnesses Installation, AMM TASK 71-51-03-400-801-F00.
        - a) Do the Repair Confirmation at the end of this task.
        - b) If the Repair Confirmation is not satisfactory, then continue.
      - 3) If the connector was not correctly connected and no other problem was found, then do the Repair Confirmation at the end of this task.
        - a) If the Repair Confirmation is not satisfactory, then continue.
    - (d) If you did not find a problem, then continue.
  - (3) Do these steps to measure the input voltage at the electrical connector DP0202 at the EEC:
    - (a) For Engine 1

## 737-600/700/800/900 FAULT ISOLATION MANUAL

- 1) Remove the safety tag and close this circuit breaker:

### CAPT Electrical System Panel, P18-2

<u>Row</u>	<u>Col</u>	<u>Number</u>	<u>Name</u>
A	1	C00458	ENGINE 1 IGNITION RIGHT

- (b) For Engine 2

- 1) Remove the safety tag and close this circuit breaker:

### F/O Electrical System Panel, P6-2

<u>Row</u>	<u>Col</u>	<u>Number</u>	<u>Name</u>
D	4	C00459	ENGINE 2 IGNITION RIGHT

- (c) Do a check for 0 VAC from pin A to pin B (ground) of the DP0202 electrical connector.
- (d) If the voltage is 0 VAC and the fault was found by the Initial Evaluation, then replace the EEC, M1818.

These are the tasks:

EEC Removal, AMM TASK 73-21-60-000-801-F00,

EEC Installation, AMM TASK 73-21-60-400-801-F00.

- 1) Do the Repair Confirmation at the end of this task.

- (e) If the voltage is not 0 VAC, then continue.

- (4) Do this check of the applicable right ignition switch S89 (Engine 1) or S91 (Engine 2):

**NOTE:** The S89 switch is in the engine 1 start brake assembly M1824 in the control stand.  
The S91 switch is in the engine 2 start brake assembly M1825.

- (a) Remove the upper and side panels from the control stand.
- (b) Disconnect the electrical connector D11288P or D11292P from the control stand
- (c) Do a continuity check from the pin 11 to pin 13 of the connector.
- (d) If there is continuity, then replace the applicable S89 or S91 switch for a faulty ignition switch.

These are the tasks:

Engine Start Brake Assembly Switch Removal, AMM TASK 76-11-11-010-801-F00,

Engine Start Brake Assembly Switch Installation, AMM TASK 76-11-11-420-801-F00.

- 1) Do the Repair Confirmation at the end of this task.

- (e) If there is not continuity, then examine and repair the wires and connectors between the ignition switch and the EEC.

- 1) Do the Repair Confirmation at the end of this task.

## H. Repair Confirmation

- (1) Prepare for the procedure:
  - (a) Make sure that the electrical connector DP0202 is correctly connected to the EEC.
  - (b) Make sure that the electrical connectors D11288P and D11292P are correctly connected to the control stand.
  - (c) For Engine 1

## 737-600/700/800/900 FAULT ISOLATION MANUAL

- 1) Make sure that these circuit breakers are closed:

### CAPT Electrical System Panel, P18-2

<u>Row</u>	<u>Col</u>	<u>Number</u>	<u>Name</u>
A	1	C00458	ENGINE 1 IGNITION RIGHT
A	4	C01390	ENGINE 1 ALTN PWR CHAN B
A	5	C01314	ENGINE 1 ALTN PWR CHAN A

- (d) For Engine 2

- 1) Make sure that these circuit breakers are closed:

### F/O Electrical System Panel, P6-2

<u>Row</u>	<u>Col</u>	<u>Number</u>	<u>Name</u>
D	4	C00459	ENGINE 2 IGNITION RIGHT
D	7	C01391	ENGINE 2 ALTN PWR CHAN B
D	8	C01315	ENGINE 2 ALTN PWR CHAN A

- (2) Do this task: EEC TEST, AMM TASK 73-21-00-700-804-F00.
- (a) If the maintenance message does not show, you corrected the fault.
- (3) Install the upper and side panels to the control stand.
- (4) Do this task: Close the Fan Cowl Panels, AMM TASK 71-11-02-410-801-F00.

————— **END OF TASK** —————

## 805. DEU Igniter Data Is Incorrect - Fault Isolation

### A. Description

- (1) This task is for these maintenance message numbers:
- (a) 74-11301, 74-11302, 74-21301, 74-21302, 74-31301, or 74-31302 and 74-11311, 74-11312, 74-21311, 74-21312, 74-31311, or 74-31312.
- (b) The maintenance messages 74-X130Y or 74-X131Y where X = EEC Channel (1=Channel A, 2=Channel B, 3=Dual Channel), and Y = Engine Position (1=Eng 1, 2=Eng 2), do the applicable Fault Isolation Procedure:
- (c) 74-X130Y is reported by the EEC for data from DEU1. 74-X131Y is reported by the EEC for data from DEU2.
- (2) This message can be set by this condition:
- (a) The EEC notes that DEU1 or DEU2 cannot sense the selection of the left igniter or the right igniter from the engine ignition switch S858.
- (3) This fault is reported when the EEC has electrical power.
- (a) This fault should show as a dual channel message.
- (4) You should do the Initial Evaluation to see if a dual channel maintenance message is set.

### B. Possible Causes - One DEU Fault

- (1) The wires and the connectors between the engine ignition switch (P5 forward overhead panel) and the DEUs
- (2) DEU, M1808 (DEU1), M1809 (DEU2)
- (3) Engine Ignition Switch, S858.

EFFECTIVITY  
AKS ALL

## 74-21 TASKS 804-805

D633A103-AKS

Page 219  
Jun 15/2016

## 737-600/700/800/900 FAULT ISOLATION MANUAL

### C. Possible Causes - Two DEU Fault

- (1) Engine ignition switch, S858.

### D. Circuit Breakers

- (1) These are the primary circuit breakers related to the fault:

#### CAPT Electrical System Panel, P18-2

<u>Row</u>	<u>Col</u>	<u>Number</u>	<u>Name</u>
D	5	C01359	DISPLAY DEU 1 PRI

#### F/O Electrical System Panel, P6-1

<u>Row</u>	<u>Col</u>	<u>Number</u>	<u>Name</u>
D	9	C01362	DISPLAY DEU 2 HOLDUP
D	10	C01361	DISPLAY DEU 1 HOLDUP
D	11	C01360	DISPLAY DEU 2 PRI

### E. Related Data

- (1) Component Location (Figure 301)
- (2) Simplified Schematic (Figure 303)
- (3) (SSM 74-31-11)
- (4) (WDM 74-31-11)

### F. Initial Evaluation

- (1) To find out if the fault is active, for each engine, do this task: EEC TEST, AMM TASK 73-21-00-700-804-F00
  - (a) If one of these combinations of maintenance messages, 74-X1301 and 74-X1302, or 74-X1311 and 74-X1312 shows for one DEU, then do the Fault Isolation Procedure - One DEU Fault.
  - (b) If all four maintenance messages 74-X1301, 74-X1302, 74-X1311 and 74-X1312 show for the two DEU's, then do the Fault Isolation Procedure - Two DEU Fault.
  - (c) If the maintenance message does not show on the FMCS CDU, then the Initial Evaluation has shown that the fault is not active at this time and you have an intermittent fault.
    - 1) If you cannot find the fault at this time, then the Fault Isolation Procedure cannot isolate the fault.
    - 2) For an intermittent fault you must use your judgment, your airline policies, and the Possible Causes list to make the decision if you will try to correct the fault.
    - 3) If you will try to correct the fault, it is recommended that you do these steps:
      - a) Do the visual checks of the electrical connectors in the applicable fault isolation procedure below.
      - b) Use the WDM references to identify intermediate electrical connections in the wire harness and do a visual check.
      - c) If you find no problems, then replace components as listed in the Possible Causes list above.
    - 4) Monitor the airplane on the subsequent flight.

### G. Fault Isolation Procedure - One DEU Fault

- (1) Do these steps to prepare for the procedure:

EFFECTIVITY  
AKS ALL

## 74-21 TASK 805

D633A103-AKS

Page 220  
Jun 15/2016



## 737-600/700/800/900 FAULT ISOLATION MANUAL

- (a) Make sure that these circuit breakers are open and have safety tags:

### CAPT Electrical System Panel, P18-2

<u>Row</u>	<u>Col</u>	<u>Number</u>	<u>Name</u>
D	5	C01359	DISPLAY DEU 1 PRI

### F/O Electrical System Panel, P6-1

<u>Row</u>	<u>Col</u>	<u>Number</u>	<u>Name</u>
D	9	C01362	DISPLAY DEU 2 HOLDUP
D	10	C01361	DISPLAY DEU 1 HOLDUP
D	11	C01360	DISPLAY DEU 2 PRI

- (b) Get access to the E3-1 shelf in the EE bay.

Open this access panel:

<u>Number</u>	<u>Name/Location</u>
117A	Electronic Equipment Access Door

- (2) Do this check of the wiring:

- (a) Remove the S858 switch.  
(b) Remove the applicable DEU.

These are the tasks:

Display Electronic Unit Removal, AMM TASK 31-62-21-000-801,

Display Electronic Unit Installation, AMM TASK 31-62-21-400-801.

- (c) Do this resistance check between these pins to examine the wires from the engine ignition switch S858 in the P5 pilots overhead panel to the two DEUs or to ground:

**Table 201**

SWITCH		DEU CONNECTOR		RESISTANCE
S858	PIN 2	DEU 1	D3973E PIN A7	LESS THAN 10 OHMS
	PIN 2	DEU 2	D3975E PIN A7	LESS THAN 10 OHMS
	PIN 8	DEU 1	D3973A PIN A7	LESS THAN 10 OHMS
	PIN 8	DEU 2	D3935A PIN A7	LESS THAN 10 OHMS
	PIN 3 TO THE AIRPLANE GROUND			GREATER THAN 1 MEGOHM
	PIN 7 TO THE AIRPLANE GROUND			GREATER THAN 1 MEGOHM

- (d) If the resistance is not in the specified range, then repair or replace the wires between the S858 switch, and the DEU connector or ground.
- 1) Do the Repair Confirmation at the end of this task.
  - 2) If the Repair Confirmation is not satisfactory, then continue.
- (e) If resistance is in the specified range, then do these steps:
- 1) With the S858 switch in the BOTH position, do a check for continuity through the switch between pins 2 and 3 and between pins 8 and 7.
  - 2) If there is continuity, then replace the S858 switch.

EFFECTIVITY  
AKS ALL

# 74-21 TASK 805

D633A103-AKS

Page 221  
Jun 15/2016

## 737-600/700/800/900 FAULT ISOLATION MANUAL

- a) Do the Repair Confirmation at the end of this task.
- 3) If there is not continuity, then replace the applicable DEU.

These are the tasks:

Display Electronic Unit Removal, AMM TASK 31-62-21-000-801,

Display Electronic Unit Installation, AMM TASK 31-62-21-400-801.

- a) Do the Repair Confirmation at the end of this task.

### H. Fault Isolation Procedure - Two DEU Fault

- (1) Replace the engine ignition switch, S858 on the P5 pilots overhead panel.

- (a) Do the Repair Confirmation at the end of this task.

### I. Repair Confirmation

- (1) Prepare for the procedure:

- (a) Make sure that the DEUs are installed in the E3-1 shelf.
- (b) Make sure the S858 ignition switch and connector are correctly connected in the P5 overhead panel.
- (c) Make sure that these circuit breakers are closed:

#### CAPT Electrical System Panel, P18-2

<u>Row</u>	<u>Col</u>	<u>Number</u>	<u>Name</u>
D	5	C01359	DISPLAY DEU 1 PRI

#### F/O Electrical System Panel, P6-1

<u>Row</u>	<u>Col</u>	<u>Number</u>	<u>Name</u>
D	9	C01362	DISPLAY DEU 2 HOLDUP
D	10	C01361	DISPLAY DEU 1 HOLDUP
D	11	C01360	DISPLAY DEU 2 PRI

- (2) Do this task: EEC TEST, AMM TASK 73-21-00-700-804-F00.
- (a) If the maintenance message does not show, then you corrected the fault.
- (b) Close this access panel:

<u>Number</u>	<u>Name/Location</u>
117A	Electronic Equipment Access Door

————— END OF TASK —————

## 806. IGN L (IGN 1) Is Failed - Fault Isolation

### A. Description

- (1) This task is for these maintenance message numbers:
  - (a) 74-10951, 74-10952, 74-20951, 74-20952, 74-30951, and 74-30952.
  - (b) For the maintenance message 74-X095Y; where X = EEC Channel (1=Channel A, 2=Channel B, 3=Dual Channel), and Y = Engine Position (1=Eng 1, 2=Eng 2), do the Fault Isolation Procedure.
- (2) The EEC detects that there was no engine start (no increase in EGT) with these conditions:
  - (a) The start lever is in the IDLE position.
  - (b) The fuel metering valve (FMV) is in the correct position.

EFFECTIVITY  
AKS ALL

## 74-21 TASKS 805-806

D633A103-AKS

Page 222  
Jun 15/2016

## 737-600/700/800/900 FAULT ISOLATION MANUAL

- (c) The input voltage to the EEC for the left exciter is correct.
- (d) The engine did not start when the left igniter was selected.
- (3) This fault is reported when the EEC has electrical power.
  - (a) This fault should show as a dual channel message.

### B. Possible Causes

- (1) For an Audible Igniters Test (Left Igniter) with one audible confirmation:
  - (a) EEC, M1818.
- (2) For an Audible Igniters Test (Left Igniter) with no audible confirmation:
  - (a) Left igniter plug
  - (b) Left ignition lead
  - (c) Left ignition exciter
  - (d) MW0301 wire harness.
- (3) For an Audible Igniters Test (Left Igniter) with two audible confirmations:
  - (a) Left igniter plug
  - (b) Start brake assembly M1824 (Eng 1), M1825 (Eng 2), for left ignition switches S88, S90
  - (c) left ignition lead
  - (d) Left ignition exciter
  - (e) EEC, M1818
  - (f) MW0301 wire harness
  - (g) Upper 11 fuel nozzles if first start of the day or cold soaked engine.

### C. Circuit Breakers

- (1) For Engine 1:
  - (a) This is the primary circuit breaker related to the fault:

#### CAPT Electrical System Panel, P18-2

<u>Row</u>	<u>Col</u>	<u>Number</u>	<u>Name</u>
A	3	C00153	ENGINE 1 IGNITION LEFT

- (2) For Engine 2:
  - (a) This is the primary circuit breaker related to the fault:

#### F/O Electrical System Panel, P6-2

<u>Row</u>	<u>Col</u>	<u>Number</u>	<u>Name</u>
D	6	C00151	ENGINE 2 IGNITION LEFT

### D. Related Data

- (1) Component Location (Figure 301)
- (2) Simplified Schematic (Figure 302)
- (3) (SSM 74-11-11)
- (4) (WDM 74-11-11)

## 737-600/700/800/900 FAULT ISOLATION MANUAL

### E. Initial Evaluation

- (1) Do this task: EEC BITE Procedure, 73-00 TASK 801.
  - (a) Look at the RECENT FAULTS for Flight Leg 0.
  - (b) If maintenance message number 74-X095Y shows, then do the Fault Isolation Procedure.
  - (c) If the maintenance message does not show on the FMCS CDU, then the Initial Evaluation has shown that the fault is not active at this time and you have an intermittent fault.
    - 1) If you cannot find the fault at this time, then the Fault Isolation Procedure cannot isolate the fault.
    - 2) For an intermittent fault you must use your judgment, your airline policies, and the Possible Causes list to make the decision if you will try to correct the fault.
    - 3) If you will try to correct the fault, it is recommended that you do these steps:
      - a) Do the visual checks of the electrical connectors in the applicable fault isolation procedure below.
      - b) Use the WDM references to identify intermediate electrical connections in the wire harness and do a visual check.
      - c) If you find no problems, then replace components as listed in the Possible Causes list above.
    - 4) Monitor the airplane on the subsequent flight.

### F. Fault Isolation Procedure

- (1) To see if the left igniter plug operates, do this task: Ignition System Audible Test, AMM TASK 74-00-00-750-801-F00.
  - (a) The operation of the left igniter plug should be heard twice, for CH A and then for CH B.
  - (b) If only one audible confirmation is heard, do the Fault Isolation Procedure - One Audible Confirmation.
  - (c) If no audible confirmation is heard, do the Fault Isolation Procedure - No Audible Confirmation.
  - (d) If the two audible confirmations are heard, do these steps:
    - 1) With the IGN L selected, do this task: Start the Engine Procedure (Selection), AMM TASK 71-00-00-800-807-F00.
    - 2) If the engine start is correct, then there was an intermittent fault.
    - 3) If the engine does not start, do the Fault Isolation Procedure - Two Audible Confirmations.

### G. Fault Isolation Procedure - One Audible Confirmation

- (1) Replace the EEC, M1818, for a defective EEC internal igniter relay.  
These are the tasks:  
EEC Removal, AMM TASK 73-21-60-000-801-F00,  
EEC Installation, AMM TASK 73-21-60-400-801-F00.
  - (a) Do the Repair Confirmation at the end of this task.

### H. Fault Isolation Procedure - No Audible Confirmation

- (1) If there are maintenance messages, do the fault isolation for those messages.
  - (a) Do the Repair Confirmation at the end of this task.

EFFECTIVITY  
AKS ALL

## 74-21 TASK 806

D633A103-AKS

Page 224  
Jun 15/2016

## 737-600/700/800/900 FAULT ISOLATION MANUAL

- (b) If the Repair Confirmation is not satisfactory, then continue.
- (2) If there are no maintenance messages, then continue.
  - (a) Examine the left igniter plug; do this task: Main Igniter Plug Inspection, AMM TASK 74-21-02-200-801-F00.
    - 1) If the damage is more than the limits, replace the left igniter plug.  
These are the tasks:  
Main Igniter Plug Removal, AMM TASK 74-21-02-000-801-F00,  
Main Igniter Plug Installation, AMM TASK 74-21-02-400-801-F00.
    - 2) Do the Repair Confirmation at the end of this task.
    - 3) If the Repair Confirmation is not satisfactory, then continue.
  - (b) Examine the left ignition lead; do this task: Ignition Lead Inspection, AMM TASK 74-21-01-200-801-F00.
    - 1) If the damage is more than the limits, replace the left ignition lead.  
These are the tasks:  
Ignition Lead Removal, AMM TASK 74-21-01-000-801-F00,  
Ignition Lead Installation, AMM TASK 74-21-01-400-801-F00.
    - 2) Do the Repair Confirmation at the end of this task.
    - 3) If the Repair Confirmation is not satisfactory, then continue.
  - (c) Examine the left ignition exciter; do this task: Ignition Exciter Inspection, AMM TASK 74-11-01-200-801-F00.
    - 1) If the damage is more than the limits, replace the left ignition exciter.  
These are the tasks:  
Ignition Exciter Removal, AMM TASK 74-11-01-000-801-F00,  
Ignition Exciter Installation, AMM TASK 74-11-01-400-801-F00.
    - 2) Do the Repair Confirmation at the end of this task.
    - 3) If the Repair Confirmation is not satisfactory, then continue.
- (3) Examine the electrical connector DP0101 at the EEC:
 

**NOTE:** The electrical connector DP0101 is on the MW0301 wire harness at the J1 receptacle.

  - (a) Make sure that the electrical connector DP0101 is correctly connected to the EEC.
  - (b) Disconnect the electrical connector DP0101 from the EEC.
  - (c) Visually examine the EEC J1 receptacle and wire harness connector.
    - 1) If the EEC J1 receptacle is damaged, then replace the EEC, M1818.  
These are the tasks:  
EEC Removal, AMM TASK 73-21-60-000-801-F00,  
EEC Installation, AMM TASK 73-21-60-400-801-F00.
      - a) Do the Repair Confirmation at the end of this task.
    - 2) If the harness connector is damaged, then replace the MW0301 wire harness.  
These are the tasks:  
Nacelle Wiring Harnesses Removal, AMM TASK 71-51-03-000-801-F00,  
Nacelle Wiring Harnesses Installation, AMM TASK 71-51-03-400-801-F00.

## 737-600/700/800/900 FAULT ISOLATION MANUAL

- a) Do the Repair Confirmation at the end of this task.
- 3) If the connector was not correctly connected, and no other problem was found, then do the Repair Confirmation at the end of this task.

### I. Fault Isolation Procedure - Two Audible Confirmation

- (1) For the left igniter plug, do this task: Main Igniter Plug Inspection, AMM TASK 74-21-02-200-801-F00.
  - (a) If the damage to the igniter plug is more than the limits, then replace the left igniter plug (AMM TASK 74-21-02-400-801-F00).
    - 1) Do the Repair Confirmation at the end of this task.
    - 2) If the Repair Confirmation is not satisfactory, then continue.
  - (b) If the damage is in the limits, then re-install the left igniter plug (AMM TASK 74-21-02-400-801-F00) and continue.
- (2) Replace the upper 11 fuel nozzles.
  - (a) Fuel Nozzles Removal (AMM TASK 73-11-04-000-805-F01 or AMM TASK 73-11-04-000-804-F02).
  - (b) Fuel Nozzles Installation (AMM TASK 73-11-04-400-805-F01 or AMM TASK 73-11-04-400-804-F02).
- (3) If the problem continues, then there was an intermittent fault.
  - (a) For an intermittent fault you must use your judgment, your airline policies, and the Possible Causes list to make the decision if you will try to correct the fault.
    - 1) Replace components as listed in the Possible Causes list above and do the Repair Confirmation.
    - 2) To examine the operation of the ignition switch in the engine start brake assembly, you can do the procedure that follows.
- (4) To examine the applicable left ignition switches, S88 (Eng 1) or S90 (Eng 2), in the engine start brake assembly, you can use input monitoring to see if the switch operation agrees with the selected start lever position.

**NOTE:** Some switches in the engine start brake assembly can cause engine start problems.

- (a) Get access to the input monitoring screen on the CDU:
  - 1) Push the INIT REF key two times.  
**NOTE:** This causes the PERF INIT INDEX to show.
  - 2) Push the INDEX line select key (LSK).
  - 3) Push the MAINT LSK.
  - 4) Push the ENGINE LSK.
  - 5) Push the line select key for the applicable engine (ENGINE 1 or ENGINE 2).  
**NOTE:** This causes the ENGINE X BITE TEST MAIN MENU to show.
  - 6) Push the INPUT MONITORING LSK.  
**NOTE:** An alert message will show to tell you that only data from one channel is available.
  - 7) Push the CONTINUE LSK.  
**NOTE:** This causes the INPUT MONITORING MENU to show. Push the NEXT PAGE key to go to page 2 of the menu

## 737-600/700/800/900 FAULT ISOLATION MANUAL

- 8) Push the DISCRETES LSK.

NOTE: This causes the INPUT MONITORING GMM DISCRETES screen to show.

- 9) Push the NEXT PAGE key twice to see page 3/3 and find the L IGNITER 115V line on the screen.

- (b) With the applicable start lever in the CUTOFF position, make sure the value is OFF.
- (c) Put the applicable start lever to the IDLE position and make sure the value is ON for each line.
- (d) Operate the start lever several times and see if the switch operates correctly.
- 1) If the switch does not operate correctly, replace the switch, S88 or S90.

These are the tasks:

Engine Start Brake Assembly Switch Removal, AMM TASK 76-11-11-010-801-F00,  
Engine Start Brake Assembly Switch Installation, AMM  
TASK 76-11-11-420-801-F00.

### J. Repair Confirmation

- (1) Do these steps to prepare for the procedure:
- (a) Make sure that the electrical connector DP0102 is correctly connected to the left ignition exciter.
- (b) Make sure that the electrical connector DP0101 is correctly connected to the EEC at J1.
- (2) If the initial audible test of the ignition system failed, do these steps:
- (a) For the left igniter plug, do this task: Ignition System Audible Test, AMM TASK 74-00-00-750-801-F00.
- (b) If the left igniter test passes and two audible confirmations are heard then you corrected the fault.
- (3) If the initial audible test of the ignition system passed, do these steps:
- (a) With the IGN I selected, do this task: Start the Engine Procedure (Selection), AMM TASK 71-00-00-800-807-F00.
- (b) If the engine start is normal, then you corrected the fault.
- (4) Do this task: Close the Fan Cowl Panels, AMM TASK 71-11-02-410-801-F00.

————— **END OF TASK** —————

### 807. IGN R (IGN 2) Is Failed - Fault Isolation

#### A. Description

- (1) This task is for these maintenance message numbers:
- (a) 74-10961, 74-10962, 74-20961, 74-20962, 74-30961, and 74-30962.
- (b) For the maintenance message 74-X096Y; where X = EEC Channel (1=Channel A, 2=Channel B, 3=Dual Channel), and Y = Engine Position (1=Eng 1, 2=Eng 2), do the Fault Isolation Procedure.
- (2) The EEC detects that there was no engine start (no increase in EGT) with these conditions:
- (a) The start lever is in the IDLE position.
- (b) The fuel metering valve (FMV) is in the correct position.
- (c) The input voltage to the EEC for the right exciter is correct.
- (d) The engine did not start when the right igniter was selected.

EFFECTIVITY  
AKS ALL

## 74-21 TASKS 806-807

D633A103-AKS

Page 227  
Jun 15/2016

## 737-600/700/800/900 FAULT ISOLATION MANUAL

- (3) This fault is reported when the EEC has electrical power.
  - (a) This fault should show as a dual channel message.

### B. Possible Causes

- (1) For an Audible Igniters Test (Right Igniter) with one audible confirmation.
  - (a) EEC, M1818.
- (2) For an Audible Igniters Test (Right Igniter) with no audible confirmation:
  - (a) Right igniter plug
  - (b) Right ignition lead
  - (c) Right ignition exciter
  - (d) MW0302 wire harness.
- (3) For an Audible Igniters Test (Right Igniter) with two audible confirmations:
  - (a) Right igniter plug
  - (b) Start brake assembly M1824 (Eng 1), M1825 (Eng 2), for right ignition switches S89, S91
  - (c) Right ignition lead
  - (d) EEC, M1818
  - (e) MW0302 wire harness
  - (f) Upper 11 fuel nozzles if first start of the day or cold soaked engine

### C. Circuit Breakers

- (1) For Engine 1:
  - (a) This is the primary circuit breaker related to the fault:

#### CAPT Electrical System Panel, P18-2

<u>Row</u>	<u>Col</u>	<u>Number</u>	<u>Name</u>
A	1	C00458	ENGINE 1 IGNITION RIGHT

- (2) For Engine 2:
  - (a) This is the primary circuit breaker related to the fault:

#### F/O Electrical System Panel, P6-2

<u>Row</u>	<u>Col</u>	<u>Number</u>	<u>Name</u>
D	4	C00459	ENGINE 2 IGNITION RIGHT

### D. Related Data

- (1) Component Location (Figure 301)
- (2) Simplified Schematic (Figure 302)
- (3) (SSM 74-11-11)
- (4) (WDM 74-11-11)

### E. Initial Evaluation

- (1) Do this task: EEC BITE Procedure, 73-00 TASK 801.
  - (a) Look at the RECENT FAULTS for Flight Leg 0.
  - (b) If maintenance message number 74-X096 is set, then do the Fault Isolation Procedure.



**737-600/700/800/900  
FAULT ISOLATION MANUAL**

- (c) If the maintenance message does not show on the FMCS CDU, then the Initial Evaluation has shown that the fault is not active at this time and you have an intermittent fault.
  - 1) If you cannot find the fault at this time, then the Fault Isolation Procedure cannot isolate the fault.
  - 2) For an intermittent fault you must use your judgment, your airline policies, and the Possible Causes list to make the decision if you will try to correct the fault.
  - 3) If you will try to correct the fault, it is recommended that you do these steps:
    - a) Do the visual checks of the electrical connectors in the applicable fault isolation procedure below.
    - b) Use the WDM references to identify intermediate electrical connections in the wire harness and do a visual check.
    - c) If you find no problems, then replace components as listed in the Possible Causes list above.
  - 4) Monitor the airplane on the subsequent flight.

**F. Fault Isolation Procedure**

- (1) To see if the right igniter plug operates, do this task: Ignition System Audible Test, AMM TASK 74-00-00-750-801-F00.
  - (a) The operation of the right igniter plug should be heard twice, for CH A and then for CH B.
  - (b) If only one audible confirmation is heard, do the Fault Isolation Procedure - One Audible Confirmation.
  - (c) If no audible confirmation is heard, do the Fault Isolation Procedure - No Audible Confirmation.
  - (d) If the two audible confirmations are heard, do these steps:
    - 1) With the IGN R selected, do this task: Start the Engine Procedure (Selection), AMM TASK 71-00-00-800-807-F00.
    - 2) If the engine start is correct, then there was an intermittent fault.
    - 3) If the engine does not start, do the Fault Isolation Procedure - Two Audible Confirmations.

**G. Fault Isolation Procedure - One Audible Confirmation**

- (1) Replace the EEC, M1818, for a defective EEC internal igniter relay.  
These are the tasks:  
EEC Removal, AMM TASK 73-21-60-000-801-F00,  
EEC Installation, AMM TASK 73-21-60-400-801-F00.
  - (a) Do the Repair Confirmation at the end of this task.

**H. Fault Isolation Procedure - No Audible Confirmation**

- (1) If there are maintenance messages, do the fault isolation for those messages.
  - (a) Do the Repair Confirmation at the end of this task.
  - (b) If the Repair Confirmation is not satisfactory, then continue.
- (2) If there are no maintenance messages, then continue.
  - (a) Examine the right igniter plug; do this task: Main Igniter Plug Inspection, AMM TASK 74-21-02-200-801-F00.

## 737-600/700/800/900 FAULT ISOLATION MANUAL

- 1) If the damage is more than the limits, replace the right igniter plug.  
These are the tasks:  
Main Igniter Plug Removal, AMM TASK 74-21-02-000-801-F00,  
Main Igniter Plug Installation, AMM TASK 74-21-02-400-801-F00.
- 2) Do the Repair Confirmation at the end of this task.
- 3) If the Repair Confirmation is not satisfactory, then continue.
- (b) Examine the right igniter lead. To examine it, do this task: Ignition Lead Inspection, AMM TASK 74-21-01-200-801-F00.
  - 1) If the damage is more than the limits, replace the right ignition lead.  
These are the tasks:  
Ignition Lead Removal, AMM TASK 74-21-01-000-801-F00,  
Ignition Lead Installation, AMM TASK 74-21-01-400-801-F00.
  - 2) Do the Repair Confirmation at the end of this task.
  - 3) If the Repair Confirmation is not satisfactory, then continue.
- (c) Examine the right ignition exciter. To examine it, do this task: Ignition Exciter Inspection, AMM TASK 74-11-01-200-801-F00.
  - 1) If the damage is more than the limits, replace the right ignition exciter.  
These are the tasks:  
Ignition Exciter Removal, AMM TASK 74-11-01-000-801-F00,  
Ignition Exciter Installation, AMM TASK 74-11-01-400-801-F00.
  - 2) Do the Repair Confirmation at the end of this task.
  - 3) If the Repair Confirmation is not satisfactory, then continue.
- (3) Examine the electrical connector DP0202 at the EEC:  
**NOTE:** The electrical connector DP0202 is on the MW0302 wire harness at the J2 receptacle.
  - (a) Make sure that the electrical connector DP0202 is correctly connected to the EEC.
  - (b) Disconnect the electrical connector DP0202 from the EEC.
  - (c) Visually examine the EEC J2 receptacle and wire harness connector.
    - 1) If the EEC J2 receptacle is damaged, then replace the EEC, M1818.  
These are the tasks:  
EEC Removal, AMM TASK 73-21-60-000-801-F00,  
EEC Installation, AMM TASK 73-21-60-400-801-F00.
      - a) Do the Repair Confirmation at the end of this task.
    - 2) If the harness connector is damaged, then replace the MW0302 wire harness.  
These are the tasks:  
Nacelle Wiring Harnesses Removal, AMM TASK 71-51-03-000-801-F00,  
Nacelle Wiring Harnesses Installation, AMM TASK 71-51-03-400-801-F00.
      - a) Do the Repair Confirmation at the end of this task.
    - 3) If the connector was not correctly connected, and no other problem was found, then do the Repair Confirmation at the end of this task.

## 737-600/700/800/900 FAULT ISOLATION MANUAL

### I. Fault Isolation Procedure - Two Audible Confirmation

- (1) For the right igniter plug, do this task: Main Igniter Plug Inspection, AMM TASK 74-21-02-200-801-F00.
  - (a) If the damage to the igniter plug is more than the limits, then replace the right igniter plug (AMM TASK 74-21-02-400-801-F00).
    - 1) Do the Repair Confirmation at the end of this task.
    - 2) If the Repair Confirmation is not satisfactory, then continue.
  - (b) If the damage is in the limits, then re-install the right igniter plug (AMM TASK 74-21-02-400-801-F00) and continue.
- (2) Replace the upper 11 fuel nozzles.
  - (a) Fuel Nozzles Removal (AMM TASK 73-11-04-000-805-F01 or AMM TASK 73-11-04-000-804-F02).
  - (b) Fuel Nozzles Installation (AMM TASK 73-11-04-400-805-F01 or AMM TASK 73-11-04-400-804-F02).
- (3) If the problem continues, then there was an intermittent fault.
  - (a) For an intermittent fault, you must use your judgment, your airline policies, and the Possible Causes list to make the decision if you will try to correct the fault.
    - 1) Replace components as listed in the Possible Causes list above and do the Repair Confirmation.
    - 2) To examine the operation of the ignition switch in the engine start brake assembly, you can do the procedure that follows.
- (4) To examine the applicable right ignition switch, S89 (Eng 1) or S91 (Eng 2) in the engine start brake assembly, you can use input monitoring the see if the switch position agrees with the selected start lever position.

**NOTE:** Some initial switches in the engine start brake assembly can cause engine start problems.

- (a) Get access to the input monitoring screen on the CDU:
  - 1) Push the INIT REF key two times.  
**NOTE:** This causes the PERF INIT INDEX to show.
  - 2) Push the INDEX line select key (LSK).
  - 3) Push the MAINT LSK.
  - 4) Push the ENGINE LSK.
  - 5) Push the line select key for the applicable engine (ENGINE 1 or ENGINE 2).  
**NOTE:** This causes the ENGINE X BITE TEST MAIN MENU to show.
  - 6) Push the INPUT MONITORING LSK.  
**NOTE:** An alert message will show to tell you that only data from one channel is available.
  - 7) Push the CONTINUE LSK.  
**NOTE:** This causes the INPUT MONITORING MENU to show. Push the NEXT PAGE key to go to page 2 of the menu
  - 8) Push the DISCRETES LSK.  
**NOTE:** This causes the INPUT MONITORING GMM DISCRETES screen to show.

**737-600/700/800/900  
FAULT ISOLATION MANUAL**

- 9) Push the NEXT PAGE key twice to see page 3/3 and find the R IGNITER 115V line on the screen.
- (b) With the applicable start lever in the CUTOFF position, make sure the value is OFF.
- (c) Put the applicable start lever to the IDLE position and make sure the value is ON.
- (d) Operate the start lever several times to see if the switch operates correctly.
  - 1) If the switch does not operate correctly, replace the switch, S89 or S91.

These are the tasks:

Engine Start Brake Assembly Switch Removal, AMM TASK 76-11-11-010-801-F00,

Engine Start Brake Assembly Switch Installation, AMM


TASK 76-11-11-420-801-F00.

**J. Repair Confirmation**

- (1) Do these steps to prepare for the procedure:
  - (a) Make sure that the electrical connector DP0201 is correctly connected to the right ignition exciter.
  - (b) Make sure that the electrical connector DP0202 is correctly connected to the EEC at J2.
- (2) If the initial audible test of the ignition system failed, then do these steps:
  - (a) For the right igniter plug, do this task: Ignition System Audible Test, AMM TASK 74-00-00-750-801-F00
  - (b) If the right igniter test passes two audible confirmations are heard, then you corrected the fault.
    - 1) Monitor the airplane on the subsequent flight.
- (3) If the initial audible test of the ignition system passed, then do these steps:
  - (a) With the IGN R selected, do this task: Start the Engine Procedure (Selection), AMM TASK 71-00-00-800-807-F00.
  - (b) If the engine start is normal, then you corrected the fault.

————— **END OF TASK** —————

# 737-600/700/800/900 FAULT ISOLATION MANUAL



H65981 S0006745929\_V1

**Ignition System - Component Location**  
Figure 301/74-21-00-990-801-F00 (Sheet 1 of 2)


EFFECTIVITY  
AKS ALL

## 74-21 TASK SUPPORT

D633A103-AKS

Page 301  
Feb 15/2013

# 737-600/700/800/900 FAULT ISOLATION MANUAL



H66035 S0006745932\_V1

**Ignition System - Component Location**  
**Figure 301/74-21-00-990-801-F00 (Sheet 2 of 2)**


EFFECTIVITY  
AKS ALL

## 74-21 TASK SUPPORT

D633A103-AKS

Page 302  
Feb 15/2013

## 737-600/700/800/900 FAULT ISOLATION MANUAL



H66499 S0006745933\_V1

Ignition Power Simplified Schematic  
Figure 302/74-21-00-990-802-F00 (Sheet 1 of 2)


EFFECTIVITY  
AKS ALL

## 74-21 TASK SUPPORT

D633A103-AKS

Page 303  
Feb 15/2013

# 737-600/700/800/900 FAULT ISOLATION MANUAL



H66828 S0006745934\_V1

Ignition Power Simplified Schematic  
 Figure 302/74-21-00-990-802-F00 (Sheet 2 of 2)

EFFECTIVITY  
 AKS ALL




## 74-21 TASK SUPPORT

D633A103-AKS

Page 304  
 Feb 15/2013



# 737-600/700/800/900 FAULT ISOLATION MANUAL



H67808 S0006745935\_V1

**Engine Ignition Control Simplified Schematic**  
Figure 303/74-21-00-990-803-F00 (Sheet 1 of 2)


EFFECTIVITY  
AKS ALL

## 74-21 TASK SUPPORT

D633A103-AKS

Page 305  
Feb 15/2013

# 737-600/700/800/900 FAULT ISOLATION MANUAL



H67746 S0006745936\_V1

Engine Ignition Control Simplified Schematic  
Figure 303/74-21-00-990-803-F00 (Sheet 2 of 2)

EFFECTIVITY  
AKS ALL

## 74-21 TASK SUPPORT

D633A103-AKS

BOEING PROPRIETARY - Copyright © Unpublished Work - See title page for details

Page 306  
Feb 15/2013