

INDEXES



737-600/700/800/900
ILLUSTRATED TOOL AND EQUIPMENT MANUAL

| Subject/Page | Date | Subject/Page | Date | Subject/Page | Date |
|-----------------|-------------|--------------|------|--------------|------|
| EFFECTIVE PAGES | | | | | |
| 1 | Feb 05/2016 | | | | |
| 2 | BLANK | | | | |
| NUMERICAL INDEX | | | | | |
| O 1 | Feb 05/2016 | | | | |
| O 2 | Feb 05/2016 | | | | |
| O 3 | Feb 05/2016 | | | | |
| O 4 | Feb 05/2016 | | | | |
| O 5 | Feb 05/2016 | | | | |
| O 6 | Feb 05/2016 | | | | |
| O 7 | Feb 05/2016 | | | | |
| O 8 | Feb 05/2016 | | | | |
| O 9 | Feb 05/2016 | | | | |
| O 10 | Feb 05/2016 | | | | |
| O 11 | Feb 05/2016 | | | | |
| O 12 | Feb 05/2016 | | | | |
| O 13 | Feb 05/2016 | | | | |
| O 14 | Feb 05/2016 | | | | |
| O 15 | Feb 05/2016 | | | | |
| O 16 | Feb 05/2016 | | | | |
| O 17 | Feb 05/2016 | | | | |
| O 18 | Feb 05/2016 | | | | |

A = Added, R = Revised, D = Deleted, O = Overflow

EFFECTIVE PAGES



737-600/700/800/900
ILLUSTRATED TOOL AND EQUIPMENT MANUAL

NUMERICAL INDEX

| <u>PART NO.</u> | <u>TITLE</u> | <u>SUBJECT</u> |
|---------------------------------------|--|-----------------------|
| A00001 | Welding Specification, Ground Support Equipment | 20-00-07 |
| A09003-1, -2 | Lock Pin - Nose Gear Towing Lever | 09-00-03 |
| A10002-7 | Pole - Removal/Installation Pitot Static Probe Cover | 10-10-01 |
| A20001-82, -152 | Boom Hoist Equipment - General (400 Pound Capacity) (CE) | 20-10-08 |
| A20005-9 | Clamp - Control Cable | 20-10-03 |
| A20006-32 | Grommet Installation Set | 20-10-04 |
| A20008-1 | SOCKET SET - SPHERICAL BEARING | 20-51-41 |
| A20011-64, -76, -141 | BUSHING REMOVAL/INSTALLATION KIT - LANDING GEAR | 20-50-01 |
| A20012-10, -11 | SWAGING TOOL - BEARING | 20-50-02 |
| A20013-1 | Work Table - Pilots Aisle Stand | 20-00-01 |
| A21010-187, -188, -189, -190, -203 | Vacuum Tank - Pressure Relief Valve Test | 21-30-01 |
| A21015-8 | DISPATCH EQUIPMENT - BLANK-OFF PLATE, TRIM AIR CHECK VALVE | 21-00-03 |
| A22004-1 | Checking Fixture - Autothrottle Gearbox | 22-30-03 |
| A22008-25, -42 | Rigging Equipment - Autothrottle Brake | 22-30-02 |
| A25020-1, -4, -8 | Gauge - Inspection, Seat Track, Flight Crew | 25-10-01 |
| A27021-29 | Adapter Equipment - Control Wheels | 27-30-01 |
| A27035-1 | Screwdriver - Adapter Rudder/Elevator Feel Actuator Cylinder | 27-00-02 |
| A27041-175, -188 | Test Equipment - Elevator Feel and Centering Unit | 27-30-11 |
| A27063-91 | Breakout Box Equipment - Position Sensors, Flight Control Rigging | 27-20-07 |
| A27081-1 | Readout and Control Equipment - Functional Test Stands | 27-30-14 |
| A27092-84, -106 | Actuator/Deactuator Set - Proximity Sensors | 32-00-03 |
| A28003-88, -89, -90, -91 | Ventilation Equipment - Fuel Tank | 28-10-07 |
| A28005-42, -48, -50, -82 | Test Equipment - Leak and Pressure, APU Fuel Line Shroud | 28-20-03 |
| A31007-1, -30, -39, -49, -59 | Adapter Cable - Tester, Digital Flight Recorder System | 31-30-01 |
| A32066-1 | Drain Equipment - Shock Strut, Main Landing Gear/Nose Landing Gear | 12-10-06 |
| A32075-1, -9, -10 | Adapter - Antiskid Transducer, Spin-up | 32-40-01 |
| A32091 | HOLE SAW | 20-50-03 |
| A33003-359, -681 | Breakout Box - Multipurpose | 33-00-01 |
| A34011-1, -112 | Breakout Box Equipment - ARINC 600, Line Maintenance | 34-10-02 |
| A34012-19, -24 | Test Fixture - Angle Of Attack | 34-20-02 |
| A34015-27, -35 | Test Box - Power Interrupt/Pulse | 23-10-01 |

NUMERICAL INDEX



737-600/700/800/900
ILLUSTRATED TOOL AND EQUIPMENT MANUAL

| <u>PART NO.</u> | <u>TITLE</u> | <u>SUBJECT</u> |
|--|--|-----------------------|
| A34016-1, -2, -4, -5, -7, -8, -9, -10, -11, -12, -17, -19, -20, -21, -22, -23, -24, -26, -27, -28, -30, -35, -36, -38, -41, -42, -44, -46, -47, -48, -49, -50, -55, -57, -58, -59, -60, -61, -62, -64, -65, -67, -69, -181, -186, -205, -206, -208, -209, -217, -218, -223, -224 | Breakout Box Equipment - ARINC 600, Line Maintenance | 34-10-03 |
| A35001-13 | Retraction Equipment - Firing Pin, Oxygen System | 35-20-01 |
| A38001-16, -22, -68 | Vacuum Test Equipment - Vacuum Waste System | 38-30-04 |
| A38003-20, -30 | Blockage Remover - Vacuum Toilet | 38-30-02 |
| A38006-1, -19 | Tester - Toilet Vacuum | 38-30-08 |
| A38007-9 | Plug - Vacuum Waste System | 38-30-03 |
| A38009-11 | Cleaner - Lavatory Waste Tank | 38-30-05 |
| A38010-11, -45 | Test Cable - Potable Water Quantity Transmitter | 38-10-01 |
| A38012-1, -18, -31, -32, -39, -40 | Pump Equipment - Vacuum Lavatory System | 38-30-10 |
| A49002-2 | Lifting Eye - Generators and Starters (CE) | 49-40-01 |
| A51002-1 | Alignment Equipment - Airplane Structural Repair | 51-50-01 |
| A52020-1 | MANDREL EQUIPMENT - BEARING INSTALLATION | 20-50-04 |
| A52037 | Test Box - Flight Deck Access System (FDAS) | 52-50-01 |
| A71015-108 | Lift Fixture - Engine Accessory (CE) | 21-50-04 |
| A78019-27, -29 | Hand Pump - Opening System, Thrust Reverser | 78-30-02 |
| A78025-93, -100 | Breakout Box - Test, Thrust Reverser (and Airplane Relays) | 78-30-24 |
| B20004-21, -42 | Leverage Adapter Equipment - Access Panel | 20-10-01 |
| B20005-41, -52, -75, -82 | Test Equipment - Velocity/Position Transducer | 78-40-01 |
| B26002-1 | Test Equipment - Discharge Lines, Cargo Fire Extinguisher | 26-20-04 |
| B27064-1, -2 | Torque Equipment - Rudder Pedal Adjustment | 27-20-08 |
| B27070-1 | Alignment Pin - Feel Actuator Piston | 27-30-12 |
| B28001-11, -13, -18 | Adapter - Sump Drain Valve, Removal/Installation | 28-10-03 |
| B28003-1 | Puller - Main Tank Fuel Boost Pump Assembly | 28-20-01 |
| B28009-1 | Alignment Equipment - Fuel Shutoff Valve | 28-20-02 |
| B29002-5 | Lock Set - Hydraulic Reservoir Vent Valve | 29-10-02 |
| B32066-1 | ROLLER SWAGING AND REMOVAL EQUIPMENT - BEARING | 20-50-05 |
| B32070-1 | INSTALLATION KIT - BUSHINGS, NOSE LANDING GEAR (NLG) | 20-50-06 |

NUMERICAL INDEX



737-600/700/800/900
ILLUSTRATED TOOL AND EQUIPMENT MANUAL

| <u>PART NO.</u> | <u>TITLE</u> | <u>SUBJECT</u> |
|--|---|-----------------------|
| B34002-1, -2, -3, -4, -5, -9, -10, -11, -12, -13, -14, -15, -26, -27, -28, -29, -30, -31, -32, -33, -35, -41, -42, -44, -45, -46, -47, -63, -66, -80, -91 | Breakout Box Equipment - ARINC 404, Line Maintenance | 34-10-06 |
| B52004-1 | Installation Tool - Door Seal | 52-00-01 |
| B54001-53 | Hydraulic Pump - Engine C-Duct | 78-30-10 |
| B71040-38, -39 | Sling Equipment - Inlet Cowl (CE) | 71-10-01 |
| B71044-10, -28 | Adapter Equipment - Load Test, Pressure Relief Door Latch | 54-50-01 |
| B78006-7 | Rigging Bar - Thrust Reverser Position Feedback Linear Variable Displacement Transducer (LVDT) | 78-30-07 |
| B78008-19 | Wrench Set - Thrust Reverser Actuator | 78-30-19 |
| B78009-21, -26 | Lock Equipment - Thrust Reverser Maintenance | 78-30-08 |
| B78010-9, -28 | Stand - Functional Test Equipment, Locking and Non-Locking Thrust Reverser Actuator | 78-30-15 |
| B78013-1 | Overhaul Equipment - Thrust Reverser Locking Actuator Assembly | 78-30-20 |
| B78014-29, -37 | Test Fixture - Rod End and Stroke Stop, Locking and Non-locking Thrust Reverser Actuator | 78-30-16 |
| B78015-17, -23, -39 | Overhaul Set - Thrust Reverser Locking Actuator Assembly | 78-30-17 |
| B78016-1 | Overhaul Set - Thrust Reverser Locking and Non-Locking Actuator Assembly | 78-30-21 |
| B78017-1 | Installation Equipment - Bearing - Lead Screw, Thrust Reverser Non-Locking Actuator Assembly | 78-30-22 |
| C07002-1 | Fitting - Wing Jacking | 07-10-01 |
| C07004-1 | Pad - Aircraft Jacking, Aft Body | 07-10-02 |
| C07005-1 | Fitting - Airplane Tiedown | 10-20-01 |
| C07006-16 | Tethering Fixture - Rear Spar Vertical Fin, Aft Fitting | 07-00-04 |
| C07007-19 | Jack Fitting - Forward Body Station 294.5 | 07-10-03 |
| C07008-21, -28 | Restraint Equipment - Outboard Trailing Edge Flap Tracks | 07-00-05 |
| C07010-1 | Sling - Tethering/Lifting, Airplane Recovery (CE) | 07-00-09 |
| C07011-1 | Tether Fitting - Forward Body Jack Location | 07-00-10 |
| C07012-1 | Sling Equipment - Aircraft Recovery (CE) | 07-00-13 |
| C07013-1, -64 | Tail Stand - Aft Fuselage Jacking Point | 07-00-11 |
| C09002 | Data Sheet - 737 Towbar Design | 09-00-01 |
| C10002-9 | Mooring Equipment - Nose Landing Gear | 10-20-02 |
| C10003 | Exhaust Plugs - Auxiliary Power Unit | 10-10-02 |
| C10004-1 | Protective Cover - Vane Sensor, Angle-of-Attack | 10-10-04 |
| C12001-35, -38 | Guard - Inlet, Engine Run-Up (CE) | 71-00-08 |

NUMERICAL INDEX



737-600/700/800/900
ILLUSTRATED TOOL AND EQUIPMENT MANUAL

| <u>PART NO.</u> | <u>TITLE</u> | <u>SUBJECT</u> |
|--|--|-----------------------|
| C12002-7 | Drain Hose - Surge Tank Sump | 12-10-03 |
| C20001-1 | ROLLER SWAGE - BEARING INSTALLATION, ELEVATOR TAB CONTROL CRANK ASSEMBLY | 20-50-07 |
| C21003-80, -81, -82, -133, -134, -135 | Backflush Equipment - Air Conditioning Pack Heat Exchanger | 21-50-02 |
| C21005-62, -70 | Hoist Adapter - Air Conditioning Pack (CE) | 21-50-03 |
| C21006-1, -7 | Deactivation Tool - Check Valve | 21-50-05 |
| C21007-1 | Diagnostic Equipment - Air Conditioning System, Mixed Manifold | 21-20-01 |
| C21008-1 | Extension Cable - Outflow Valve Installation, Aft Fuselage | 21-30-03 |
| C21009-1 | Dispatch Link - Srada Stowage | 21-50-12 |
| C22001 | Test Box - Inertial Reference System (IRS) Master Caution Module | 22-10-01 |
| C22005-1, -4, -5, -6, -22, -25, -32 | Breakout Box, Multipurpose, 100/124 Pin | 22-10-02 |
| C23001 | Test Box - Attendant Handset Integrated Handset Controller, Printed Wire Assembly | 23-40-01 |
| C23002 | Acoustic Coupler Equipment - Handset Transmitter and Receiver Assembly | 23-40-02 |
| C23003-1 | Test Cable - High Frequency Coupler | 23-10-02 |
| C24002-31, -39, -77, -78 | Jack Adapter - Variable Speed Constant Frequency (VSCF) and Integrated Drive Generator (IDG) | 24-10-01 |
| C24003-1 | Tray Assembly - Battery, Removal and Installation | 24-30-01 |
| C24004-1, -43 | Power Distribution Panel (PDP)- Removal and Installation Equipment | 24-20-01 |
| C24005 | Test Box - P5-4 Panel, AC System Generator and APU Module | 24-30-02 |
| C24006 | Test Box - P5-5 Generator Drive and Standby Power | 24-30-03 |
| C25001-1 | Wrench - Anti-Rattle Nut | 25-20-02 |
| C25002-1 | Removal/Installation Tool - 737 Boeing Sky Interior Ceiling Panel | 25-20-08 |
| C26003-1 | Nut Driver - Light Base | 26-10-01 |
| C26004-8, -32, -33, -73, -74, -78, -79 | Test Equipment - Engine Fire Extinguishing System | 26-20-03 |
| C26005-1 | Test Box - APU/Engine Fire Detection System | 26-20-02 |
| C26006-1, -29, -54, -70 | Test Box - Cargo Fire Extinguishing System | 26-20-05 |
| C26007-1, -72 | Test Equipment - Compartment Overheat Detection (M237, In-Line) | 26-10-02 |
| C27001-16, -41, -42, -51 | Ground Lock Set - Outboard Spoiler Actuators (CE) | 27-60-01 |
| C27005-1, -19 | Assembly Fixture - Elevator Feel and Centering Unit | 27-30-13 |
| C27006-42, -47, -48 | Test Equipment - Cutout Switch, Stabilizer Trim Control | 27-40-15 |
| C27007-21, -26, -31 | Test Box - Cutout Switch, Stabilizer Trim Control (Line Maintenance) | 27-40-04 |
| C27008-20, -22 | Lock Equipment - Actuation Control, Flap | 27-50-04 |
| C27022-1 | Clamp Set - Trailing Edge Flap Torque Tube | 27-50-05 |

NUMERICAL INDEX



737-600/700/800/900
ILLUSTRATED TOOL AND EQUIPMENT MANUAL

| <u>PART NO.</u> | <u>TITLE</u> | <u>SUBJECT</u> |
|-------------------------------|---|-----------------------|
| C27026-1, -14, -24 | Test Fixture - Brake Assembly, Stabilizer Trim Actuator | 27-40-16 |
| C27028-1, -21 | Rigging Bar - Elevator Tab | 27-30-02 |
| C27030-33, -94 | Test Equipment - Flap Screw Backlash | 27-50-10 |
| C27033-1, -5, -6 | Wrench - Retaining Nut, Stabilizer Trim Actuator | 27-40-18 |
| C27034-1 | Sling - Elevator Removal/Installation | 27-30-05 |
| C27035-20 | Sling Equipment - Rudder Removal/Installation (CE) | 27-20-05 |
| C27036-1 | Support Set - Forward Elevator Control Quadrant | 27-30-08 |
| C27038-6 | Lockout Pin - Leading Edge Cruise Depressurization Valve (CE) | 27-80-05 |
| C27039-1 | Spanner Wrench - Hinge Bearing, Horizontal Stabilizer | 55-10-03 |
| C27040-1, -29 | Hoist Adapter - Installation/Removal, Flap Track (CE) | 27-50-02 |
| C27041-1 | Wrench - Coupling Sleeve, Flap Actuation | 27-50-06 |
| C27042-1 | Wrench - Torque Equipment, Rudder Power Control Unit Attachment | 27-20-02 |
| C27043-1, -16 | Seal Installation Equipment - Trailing Edge Flap Drive | 27-50-15 |
| C27044-15 | Rigging Beam - Elevator Index Plate Installation | 27-30-04 |
| C27045-1 | Kit - Rigging Equipment, Slat | 27-80-01 |
| C27046-1, -13 | Lock Set - Inboard Ground Spoiler Actuator (CE) | 27-60-02 |
| C27047-19, -20, -41, -42, -43 | Lock Set - Flight Spoiler Actuator | 27-60-03 |
| C27049-1, -36 | Removal/Installation Equipment - Rudder Power Control Unit (CE) | 27-20-04 |
| C27050-82, -125 | Handling Equipment - Removal/Installation, Stabilizer Jackscrew | 27-40-06 |
| C27051-1, -29 | Lock Set - Leading Edge Slat and Krueger Flap Actuators | 27-80-03 |
| C27052-25, -39 | Sling Equipment - Trailing Edge Flaps (CE) | 27-50-03 |
| C27054-1 | Thread Protector Set - Horizontal Stabilizer Hinge Pin | 27-40-10 |
| C27055-1 | Sling - Aileron, Installation/Removal (CE) | 27-10-05 |
| C27056-19, -35 | Sling Equipment - Leading Edge Slat, Removal and Installation (CE) | 27-80-04 |
| C27057-1 | Lock - Rudder Power Control Unit (PCU) Removed | 27-20-03 |
| C27058-1 | Axial Load Equipment - Flap Actuation, Torque Brake | 27-50-11 |
| C27060-1 | Adapter Equipment - Control Wheel | 27-40-09 |
| C27061-1 | Adapter - Wrench, Flight Spoiler Actuator Power Control Unit | 27-60-06 |
| C27062-1 | Test Block - Cartridge Valve, Flight Spoiler Actuator | 27-60-08 |
| C27064-1 | Torque Wrench Adapter - Manual Stabilizer Trim Wheel | 27-40-07 |
| C27065-1, -20 | Check Equipment - Jackscrew Backlash, Horizontal Stabilizer (CE) | 27-40-08 |
| C27066-1 | Lock Equipment - Aileron/Elevator Power Control Unit Input Rod (POGO) | 27-10-06 |
| C27067-81, -82, -87, -88 | Test Equipment - Torque Limiter, Transmission, Trailing Edge Flap | 27-50-12 |
| C27068-65 | Test Equipment - Trailing Edge Flap Drive Gearboxes | 27-50-09 |
| C27069-12, -20 | Rigging Equipment - Interlock Valve Cable, Ground Spoiler | 27-60-07 |

NUMERICAL INDEX



737-600/700/800/900
ILLUSTRATED TOOL AND EQUIPMENT MANUAL

| <u>PART NO.</u> | <u>TITLE</u> | <u>SUBJECT</u> |
|------------------------|---|-----------------------|
| C27072-178, -179 | Test Equipment - Trailing Edge Flap Transmission, Aft U-Joint and Ballscrew (CE) | 27-50-13 |
| C27073-1 | Test Equipment - Quadrant Assembly, Elevator Controls | 27-30-15 |
| C27074-1 | Overhaul Equipment, Spring Stack, Trailing Edge Flap Transmission | 27-50-17 |
| C27075-1, -9 | Spanner Wrench - Brake Nut, Stabilizer Trim Actuator | 27-40-22 |
| C27077-1 | Test Equipment - Quadrant Assembly, Aileron Control | 27-10-07 |
| C27078-1 | Measurement Tool - Stabilizer System Test | 27-40-21 |
| C27079-1 | Holding Equipment - Trailing Edge Inboard Flap | 27-50-14 |
| C27080-1 | Drum Wrench - Stabilizer Trim Actuator | 27-40-20 |
| C27082-1 | Fixture Equipment - Pushrod Length Adjustment, Elevator Tab and Aileron | 27-30-16 |
| C27083-1 | Rigging Bar - Elevator Tab | 27-30-17 |
| C27084-1 | Test Equipment - Outboard Trailing Edge Flap Transmission, No-Back Brake Operational Test | 27-50-20 |
| C27085-1 | Removal/Installation Equipment - Tab Mechanism Assembly, Elevator Control | 27-30-18 |
| C27086-1 | Spring Removal/Installation Equipment - Elevator Tab Mechanism Assembly | 27-30-35 |
| C27088-1 | Test Fixture - Hypoid Gear Backlash | 27-50-40 |
| C27089-1 | Axial Load Equipment - Torque Brake Assembly, Trailing Edge Flap | 27-50-39 |
| C27090-1 | Torque Socket - Upper Stop, Stabilizer Trim Jack Screw | 27-40-41 |
| C27093-1, -2 | Functional Test - Transfer Mechanism, Aileron Control | 27-10-10 |
| C28008-1 | Test Equipment - Fuel Tank and Vent System | 28-10-06 |
| C28011 | Test Box - P5-2, Fuel Control Module Assembly | 28-20-04 |
| C28012-1, -8 | Test Assembly - Float Switch Conduit | 28-20-06 |
| C28013-2, -3 | Protective Equipment - Protective Ring For Lower Wing Panel Access Door | 57-00-02 |
| C28014-1 | Test Equipment - Engine Fuel Feed Manifold | 28-20-07 |
| C29001-1 | Cap - Sealing, Pressure Transmitter Mount | 29-00-05 |
| C29002-17 | Test Equipment - Rudder Power Control Unit | 29-00-03 |
| C29003-1 | Seal Installation Equipment - Hydraulic Swivel Assembly | 29-00-04 |
| C29004-1 | Drain Hose - Hydraulic Reservoir | 29-20-01 |
| C29005-1 | Adapter - Tee, Standby Hydraulic System Test | 29-20-02 |
| C29006-1 | Adapter - Ground Service Connection, Hydraulic Power | 29-00-06 |
| C29007-1 | Torque Tool Set - AC Motor Driven Hydraulic Pump | 29-10-06 |
| C29008-1 | Seal Compression Equipment - Hydraulic Swivel Assembly | 29-00-07 |
| C30001 | Test Box - P5-9, Window and Pitot Heat Module | 30-00-01 |
| C32009-1 | SWAGING EQUIPMENT - OVERSIZE NOSE GEAR BEARING, UPPER DRAG BRACE | 20-50-08 |
| C32012-12 | Removal/Installation Equipment - Wheel Retention Nut, Main Landing Gear and Nose Landing Gear | 32-40-02 |

NUMERICAL INDEX



737-600/700/800/900
ILLUSTRATED TOOL AND EQUIPMENT MANUAL

| <u>PART NO.</u> | <u>TITLE</u> | <u>SUBJECT</u> |
|---|--|-----------------------|
| C32013-1 | Torque Wrench Adapter - Aft Bearing Retainer Nut, Main Landing Gear Trunnion | 32-10-01 |
| C32014-1 | Spring Extender - Downlock, Nose and Main Landing Gear (CE) | 32-30-01 |
| C32015-1, -18 | Puller Equipment - Fuse Pin, Main Landing Gear Forward Trunnion Support | 32-10-06 |
| C32016-33, -46 | Removal/Installation Equipment - Nose Landing Gear Lower Seals | 32-20-03 |
| C32017-52, -53 | Replacement Equipment - Lower Bearing Seals, Main Landing Gear | 32-10-09 |
| C32019-1 | Extension - Orifice Tube, Nose Gear Shock Strut | 32-20-08 |
| C32020-1, -15 | Extension Bar - Functional Test, Nose Landing Gear Steering | 32-50-01 |
| C32021-1 | Wrench Set - Retainer Nut, Removal/Installation, Anti-Skid Transducer, Main Landing Gear | 32-40-03 |
| C32022-2, -15, -17, -20, -23, -32, -35 | Thread Protector Equipment - Main Landing Gear/Nose Landing Gear Axle | 32-40-05 |
| C32023-1, -12 | Wrench - Trunnion Spherical Bearing, Main Landing Gear | 57-10-01 |
| C32025-1, -7 | Spanner Wrench - Gland Nut, Nose Landing Gear | 32-20-01 |
| C32026-1, -6 | Downlock Equipment - Nose Landing Gear and Main Landing Gear | 32-00-01 |
| C32027-1, -2, -3 | Holding Fixture Equipment - Functional Test, Landing Gear Control Lever | 32-30-10 |
| C32028-1, -3, -56, -58, -59, -109, -110, -111 | Removal/Installation Equipment - Walking Beam Assembly, Main Landing Gear (CE) | 32-30-02 |
| C32029-38, -45 | Pin Installation/Removal Kit - Main Landing Gear | 32-10-04 |
| C32030-10 | Retention Strap Equipment - Inner Cylinder, Nose and Main Landing Gear | 32-10-02 |
| C32031-1, -22 | Removal/Installation Equipment - Aft Trunnion Pin, Main Landing Gear | 32-10-07 |
| C32032-98 | Puller Equipment - Axle/Brake Sleeve, Main Landing Gear (CE) | 32-10-05 |
| C32033-1 | Removal/Installation Equipment - Trunnion Pin, Nose Landing Gear | 32-20-02 |
| C32034-9, -227, -273 | Removal/Installation Equipment - Main Landing Gear | 32-10-08 |
| C32035-1 | Metering Pin and Retainer Ring Removal/Installation Equipment - Nose Landing Gear | 32-20-06 |
| C32036-1, -45, -46, -88 | Fixture Equipment - Actuator Assemblies, Nose Landing Gear | 32-30-03 |
| C32037-1 | Holding Fixture - Main Landing Gear | 32-10-10 |
| C32038-55 | Rod End Bearing Removal/Installation Equipment - Actuators Main Landing Gear (MLG) | 32-30-04 |
| C32039-1 | Adapter - Functional Test, Nose Landing Gear Steering Actuator | 32-50-03 |
| C32040-1, -6 | Spanner Wrench - Nose Landing Gear Steering Collar Retainer | 32-50-02 |
| C32041-57, -67 | Buildup Equipment - Nose Landing Gear (CE) | 32-20-07 |
| C32042-61 | Removal/Installation Equipment - Orifice Tube and Metering Pin, Main Landing Gear | 32-10-11 |
| C32044-1 | Freeplay Check Equipment - Nose Landing Gear | 32-20-05 |
| C32045-23 | Holding Fixture - Seal Change, Main Landing Gear | 32-10-12 |

NUMERICAL INDEX



737-600/700/800/900
ILLUSTRATED TOOL AND EQUIPMENT MANUAL

| <u>PART NO.</u> | <u>TITLE</u> | <u>SUBJECT</u> |
|------------------------------------|--|-----------------------|
| C32046-1 | Holding Fixture Equipment - Shimmy Damper Assembly, Main Landing Gear | 32-30-06 |
| C32048-1 | Adapter Assembly - Uplock, Main Landing Gear | 32-30-08 |
| C32049-1 | Outrigger Assembly - Removal and Installation/Ground Handling, Nose Landing Gear | 32-20-09 |
| C32050-1 | Lockout Pin - Tail Skid | 32-70-01 |
| C32051-1 | Test Equipment - Hydraulic Brake System Pressure Checking | 32-40-07 |
| C32052-1 | Lever Tool - Downlock Release Main Landing Gear | 32-10-13 |
| C32053-37 | Fixture Equipment - Side Strut Assembly, Main Landing Gear | 32-10-35 |
| C32055-1 | Clamp Assembly - Steering Cables, Nose Landing Gear | 32-20-21 |
| C33001-1 | Test Cabling - 737 Boeing Sky Interior Light Assemblies | 33-20-01 |
| C34005-1, -16 | Extender Box - Radio Altimeter Receiver Transmitter | 34-30-01 |
| C34012-2, -21 | Test Box - Total Air Temperature Probe, Air Data System | 34-10-01 |
| C35001-1, -6 | Pressure Leak Test Equipment - Crew Oxygen System | 35-10-01 |
| C35002-1, -14 | Pressure Leak Test Equipment - Passenger Oxygen System | 35-10-02 |
| C35003-10, -20 | Retraction Equipment - Firing Pin, Oxygen System | 35-20-02 |
| C36001-63, -64, -111 | Test Equipment - Engine Bleed Air Systems | 36-10-01 |
| C36002-1 | Dispatch Kit - Precooler Control Valve | 36-10-08 |
| C38001-23, -29 | Drain Mast Plug - Waste Water | 38-30-07 |
| C38002-1 | Plug Equipment - Skin Fitting, Door Sill Drain | 38-30-09 |
| C38003-1 | Installation Assembly - Sleeve, Waste Tank | 38-30-11 |
| C47001-1 | Test Equipment - Nitrogen-Enriched Air Distribution Negative Pressure Leak Check | 47-20-01 |
| C49004-36, -37, -38, -39, -40, -41 | Sling Equipment - Auxiliary Power Unit (CE) | 49-10-02 |
| C49006-1 | Thread Protector Equipment - Auxiliary Power Unit Mount Bolts | 49-10-01 |
| C49007-35, -36, -42 | Hoist Equipment - Auxiliary Power Unit (CE) | 49-10-05 |
| C49008-37 | Adapter Equipment - Auxiliary Power Unit Jacking (CE) | 49-10-03 |
| C49009-1 | Tool Kit - Auxiliary Power Unit Deletion | 49-10-09 |
| C49010-50 | Cradle Assembly - AE131-9B Auxiliary Power Unit | 49-10-06 |
| C49011-1 | Test Equipment - Fuel Feed, Auxiliary Power Unit | 49-30-01 |
| C52001-1 | Holding Fixture - Compressed Spring Cartridge | 52-30-01 |
| C52002-32, -33 | Repair Fixture - Forward and Aft Cargo Door | 52-30-02 |
| C52004-1 | Spring - Loading Control Equipment | 52-30-03 |
| C52005-1 | Fixture Equipment - Automatic Overwing Exit Door Spring | 52-20-01 |
| C52006-64, -74 | Rigging Simulator - Escape Slide, Passenger Door | 52-10-09 |
| C52007-1 | Torque Wrench Adapter Equipment - Automatic Overwing Exit Hatch | 52-20-02 |

NUMERICAL INDEX



737-600/700/800/900
ILLUSTRATED TOOL AND EQUIPMENT MANUAL

| <u>PART NO.</u> | <u>TITLE</u> | <u>SUBJECT</u> |
|-------------------------|---|-----------------------|
| C52008-1 | Torque Wrench Assembly - Galley and Entry Door | 52-10-07 |
| C52009-1, -2 | Lifting Fixture Equipment - Main Deck Cargo Door (CE) | 52-30-04 |
| C52010-1 | Support Equipment - Mid-Exit Door | 52-20-03 |
| C52011-1 | Safety Barrier - Mid-Exit Door | 52-10-13 |
| C52012-15, -29 | Personnel Barrier - Entry and Galley Doors | 52-10-12 |
| C52013-1 | Transportation Sling Equipment - Forward Airstair (CE) | 52-60-02 |
| C52014-1 | Removal/Installation Equipment - Forward Airstair (CE) | 52-60-07 |
| C54007-1 | Feeler Gauge - CFM56-7 Strut to Wing | 54-50-06 |
| C54008-1, -28, -53, -54 | Aft Fairing - Removal and Installation (CE) | 54-50-04 |
| C54009-27 | Removal/Installation Kit - Fuse Pin | 54-50-03 |
| C54010-26, -29 | Sling Equipment - Fuse Pin Removal/Installation, CFM56-7 (CE) | 54-50-02 |
| C54011-59 | Removal/Installation Equipment - Engine Strut, CFM56-7 (CE) | 54-50-05 |
| C54013-1 | Alignment Equipment - Eccentric | 54-10-01 |
| C54015-1 | Spanner Wrench - Thrust Reverser Hinge Fitting | 54-50-07 |
| C54020-9 | Installation Equipment - Strut Fire Seal | 54-50-08 |
| C55002-1 | Punch Set - Horizontal Stabilizer Center Section Hinge Pin Removal | 55-10-01 |
| C55005-1, -11, -19 | Pin Removal Equipment - Horizontal Stabilizer | 27-40-19 |
| C55007-1, -29 | Sling Equipment - Horizontal Stabilizer Removal/Installation (CE) | 27-40-12 |
| C55008-1, -18 | Alignment Equipment - Horizontal Stabilizer Installation | 27-40-13 |
| C55009-1 | Alignment Tool - Fin Installation | 55-10-02 |
| C55010-1, -33 | Sling Equipment - Vertical Fin (CE) | 55-30-01 |
| C56001-1 | Window Latch Torquing Socket Assembly - Right and Left Hand | 56-10-01 |
| C57001-1 | ROLLER SWAGING EQUIPMENT - HINGE BRACKET | 20-50-09 |
| C57002-15 | Sling Equipment - Removal/Installation, Winglet (CE) | 57-20-01 |
| C57003-1 | Test Equipment - Wing Dry Bay Vapor Seal | 57-20-02 |
| C57004-1 | Removal Equipment - Secondary Torque Tube, Inboard Main Flap Assembly | 27-50-41 |
| C71015-79, -83 | Engine Sling Equipment - Overhead Shop Handling (CE) | 71-00-03 |
| C71020-91 | Bootstrap Equipment - CFM56-7 Engine (CE) | 71-00-01 |
| C71022-6 | Torque Wrench - Engine Mount Bolts | 71-20-01 |
| C71023-1 | Proof Load Fixture - Bootstrap | 71-00-05 |
| C71024-1, -10 | Sling Assembly - Engine Aft Mount, CFM56-7 Engine (CE) | 71-20-02 |
| C71025-1 | Safety Screen - Personnel Barrier, CFM56-7 Inlet (CE) | 71-00-04 |
| C71026-1, -8 | Sling Assembly - Fan Cowl, CFM56-7 Engine (CE) | 71-20-03 |
| C71027-1 | Installation/Removal Frame Equipment - Inlet Cowl (CE) | 71-10-02 |
| C71028 | Specification - Interface Control, CFM56-7 Bootstrap/Ground Handling | 71-00-06 |

NUMERICAL INDEX



737-600/700/800/900
ILLUSTRATED TOOL AND EQUIPMENT MANUAL

| <u>PART NO.</u> | <u>TITLE</u> | <u>SUBJECT</u> |
|------------------------------|--|-----------------------|
| C76002-24, -25, -26 | Hand Tool Set - Control Stand, Disassembly/Assembly | 76-10-01 |
| C77004-10 | Test Box - Generic Airborne Vibration Monitoring Interface | 77-30-01 |
| C78004-1 | Lockpin Equipment - Thrust Reverser Actuation Module Lockout | 78-30-03 |
| C78005-26, -53 | Hand Pump - Opening System, Thrust Reverser | 78-30-01 |
| C78009-1, -19, -38, -39, -72 | Remove/Install Tool - Primary Exhaust Assemblies (CE) | 78-10-01 |
| C78011-37, -60, -78 | Dolly and Hydraulic Equipment | 78-30-12 |
| C78018-50 | Sling Equipment - Thrust Reverser, CFM56-7 (CE) | 78-30-04 |
| C78019-15 | Hold Open Equipment - Thrust Reverser Cowl, CFM56-7 Engine (CE) | 78-30-05 |
| C78020-11, -14 | Latching Tool - Thrust Reverser C-Duct Halves | 78-30-09 |
| C78021-1 | 65-Degree Hold Open Equipment - Thrust Reverser Cowl, CFM56-7 Engine (CE) | 78-30-11 |
| C78022-1 | Sling Equipment - Thrust Reverser Sleeve (CE) | 78-30-14 |
| C78023-1 | Lock Assembly - Thrust Reverser Actuator, CFM56-7 (CE) | 78-30-06 |
| C78025-21 | Actuator - Installation/Removal Tool | 78-30-13 |
| C78026-161, -259 | Boom Hoist - Ground Based Removal/Installation (CE) | 78-00-01 |
| C78027-1 | Torque Fixture - Locking and Non-Locking Thrust Reverser Actuator Assembly | 78-30-23 |
| C78030-1 | Gap Measurement Gauge - Thrust Reverser Actuator System Locking Actuator | 78-30-46 |
| F70038 | Wrench Assembly - Mechanism Nut, Door Handle | 52-10-05 |
| F70043 | Gauge Assembly - Airplane Attitude | 08-00-01 |
| F70071-1 | RETAINER - BEARING, THRUST REVERSER | 20-50-10 |
| F70073-1 | SLEEVE - BEARING, THRUST REVERSER | 20-50-11 |
| F70085 | Wrench - Spanner, Bearing Retainer Nut | 52-10-02 |
| F70109 | Wrench Assembly - Stabilizer Trim Actuator | 27-40-23 |
| F70150 | PULLER ASSEMBLY - CONTROL ACTUATOR BEARING | 20-50-12 |
| F70167-1 | Assembly Jig - Stabilizer Trim Actuator | 27-40-24 |
| F70197-1 | BEARING REMOVAL TOOL | 20-50-13 |
| F70199-1, -24, -25, -52 | Inflation Tool - Tire | 12-10-02 |
| F70200-1, -17, -18 | Inflation Tool - Strut | 12-10-01 |
| F70206-1 | Adapter Assembly - Hollow Bolt, Fuel Leak Tracing | 28-10-12 |
| F70207-109, -128, -135, -139 | Kit - Rigging Pin | 27-80-02 |
| F70230-1 | Temporary Repair Tool - Self-Sealing Rivets, Fuel System | 28-10-04 |
| F70244-17 | Sling Assembly - Lifting, Fuselage | 07-00-01 |
| F70284-1 | Wear Gauge Set - Plug and Receptacle, Ground Power | 24-40-01 |

NUMERICAL INDEX



737-600/700/800/900
ILLUSTRATED TOOL AND EQUIPMENT MANUAL

| <u>PART NO.</u> | <u>TITLE</u> | <u>SUBJECT</u> |
|--|---|-----------------------|
| F70292-1 | ROLLER SWAGING TOOL - SLEEVE, ROD AND HEAD ENDS, MAIN LANDING GEAR ACTUATOR | 20-50-14 |
| F70297-1 | ROLLER SWAGING TOOL - BEARING HOUSING DRIVE SCREW, FILLET FLAP | 20-50-15 |
| F70300-1 | Adapter - Flap Drive | 27-50-01 |
| F70313-1, -2, -3, -4, -5, -6 | Standard Box - Support Equipment | 20-00-06 |
| F70320-1 | Holding Fixture - Control Column | 27-00-03 |
| F70321-1, -2, -3, -4, -5, -6, -7, -8, -9, -10, -11, -12, -13, -14, -15, -16, -17, -18, -19, -20, -21, -22, -23, -24, -25, -26, -27, -28, -29, -30, -31, -32, -33, -34, -35, -36, -37, -38, -39, -40 | INSTALLATION MANDREL - SHRINK FIT BUSHING | 20-50-16 |
| F70324-1 | Canopy - Forward Entry Door | 52-10-03 |
| F70328-1 | Probe - Film Resistance Measuring | 51-20-01 |
| F70330-3, -4, -126, -162 | Static Balance Equipment - Control Surfaces | 51-10-01 |
| F70335-1 | Line Reaming Tool Set - Entry Door Hinge, Support Fitting | 52-10-10 |
| F70336-1 | Spanner Wrench - Assist Handle, Main Entry Door | 52-10-04 |
| F70339-43 | Test Equipment - Door Snubber Extension and Retraction | 52-10-06 |
| F71267 | Wrench Assembly - Pinion Gear | 27-40-05 |
| F71290-1, -2, -7, -10 | Wrench - Spanner, Bearing Retainer Nut | 27-40-11 |
| F71291-500 | Compressor - Actuator Spring, Stabilizer Trim | 27-40-25 |
| F71313-6, -7, -8, -9, -10, -11, -12, -13, -14, -15, -16, -17, -18, -19, -20, -21, -22, -23, -24, -25, -31, -32, -33, -34, -35, -36, -37, -38, -39, -40, -41, -42, -43, -44, -45, -46, -47, -48, -49, -50 | WRENCH - SOCKET, ROD END BEARING | 20-50-17 |
| F71329 | Leakage Tracing Device - Integral Tank Leakage Test | 28-10-10 |
| F71336-500, -501 | Lock Assembly - Stabilizer Trim | 27-40-02 |
| F71421-500, -501 | Fixture - End Play Checking, Stabilizer Trim Actuator | 27-40-26 |
| F71422-829, -839, -844 | Test Jig - Cable Tension, Stabilizer Trim Actuator | 27-40-14 |
| F72719-5, -500 | Towing Eye Bolt Assembly - Main Gear | 09-00-02 |
| F72790 | Protractor Mount Assembly - Pilot's and Copilot's Control Wheel | 27-00-01 |
| F72813-1 | BEARING STAKING TOOL ASSEMBLY | 20-50-18 |
| F72820-1 | BEARING PULLER ASSEMBLY | 20-50-19 |

NUMERICAL INDEX



737-600/700/800/900
ILLUSTRATED TOOL AND EQUIPMENT MANUAL

| <u>PART NO.</u> | <u>TITLE</u> | <u>SUBJECT</u> |
|---|---|-----------------------|
| F72865-1 | PRESSURE STAKING TOOL - FORWARD LINK PIVOT BEARING, THRUST REVERSER | 20-50-20 |
| F72867-1 | Adapter Assembly - Control Wheel, Torque and Force Test | 27-10-01 |
| F72896-1 | BUSHING STAKING TOOL - APU DUCT FLANGE SUPPORT | 20-50-21 |
| F72916-1 | ROLLER SWAGING ASSEMBLY - BEARING HOUSING CONTROL CRANK | 20-50-22 |
| F72917-19 | Test Console - Ground Fault Protection System, Hydraulic Electric Motor Driven Pump | 29-10-03 |
| F72918-1, -2 | Dummy Test Relief Valve - Modular System | 29-10-04 |
| F72924-1 | Holder - Stabilizer Trim Jackscrew Ballnut and Screw Assembly | 27-40-27 |
| F72928-33, -34, -52, -53, -54, -58, -62, -63 | Air Pressure Regulator Equipment - Elevator Feel Computer | 27-30-06 |
| F72942-1 | Lubrication Set - Entry, Cargo, Service and Galley Door Camshaft Bearings | 12-10-04 |
| F72950-3, -127, -128, -138, -139, -158 | Auxiliary Power Unit Transportation Equipment | 49-10-07 |
| F72951-1 | Water Manometer - Test Equipment | 28-10-05 |
| F72959-1, -2, -3, -4, -5, -6, -7, -8, -9, -10, -11, -12, -31, -32, -33, -34, -35, -36, -37, -38, -39, -40, -41, -42 | Spanner Wrench - AN Standard Type | 32-20-04 |
| F72975-1 | BEARING INSTALLATION TOOL - TORQUE LIMITER, FLAP TRANSMISSION | 20-50-23 |
| F72977-44, -45, -46, -47, -62 | Gauge Equipment - Hydraulic Brake System Pressure Checking | 32-40-04 |
| F73012-1 | SWAGING EQUIPMENT - ROLLER, LOCK ACTUATOR BARREL, MAIN LANDING GEAR | 20-50-24 |
| F80027-18 | Lock Equipment - Horizontal Stabilizer | 27-40-01 |
| F80033-1, -8 | Adapter Assembly - Wrench, Hook Spanner | 32-10-03 |
| F80039-43 | Hoist Equipment - Auxiliary Power Unit | 49-10-08 |
| F80049-17, -31, -46, -56, -65, -66 | Lock Assembly - Flight Controls | 27-10-03 |
| F80053-1 | Wrench Assembly - Face Spanner, Lug | 27-40-28 |
| F80055-1, -10 | Trammel Bar - Stabilizer Trim Actuator | 27-40-03 |
| F80063-501 | Fixture - Elevator Rigging and Restraining | 27-30-10 |
| F80085-1, -12 | Test Fixture - Cylinder Assembly, Feel Actuator | 27-00-04 |
| F80106-1, -2 | Wrench - Lug Spanner | 27-60-04 |
| F80113-37, -50, -61, -64, -70, -88, -95, -105 | KIT - ROLLER SWAGE | 20-50-25 |
| F80117-1, -10 | SWAGE ASSEMBLY - ROLLER | 20-50-26 |

NUMERICAL INDEX



737-600/700/800/900
ILLUSTRATED TOOL AND EQUIPMENT MANUAL

| <u>PART NO.</u> | <u>TITLE</u> | <u>SUBJECT</u> |
|--|---|-----------------------|
| F80118-1, -15, -27, -31, -38, -42 | KIT - BEARING RETENTION/REMOVAL | 20-50-27 |
| F80120-1 | Test Fixture - Elevator and Rudder Centering Unit | 27-20-06 |
| F80135-1, -10, -13 | Cable Assembly - Hydraulic Leakage Check | 29-10-01 |
| F80145-1, -4 | Door Assembly - Purging, Center Integral Wing Fuel Tank | 28-10-09 |
| F80153-1 | Safety Pin - Elevator Feel Computer | 27-30-03 |
| F80166-1 | Test Fixture - Pressure Relief Valve, Flame Arrestor Surge Tank | 28-10-08 |
| F80168-1, -2, -3 | Socket - Axle Nut | 32-40-06 |
| F80178-1 | Setting Tool - Forward Entry Door Latch Roller | 52-10-08 |
| F80195-1 | Dowel Set - Thrust Lever Control Stand | 76-10-03 |
| F80197-5 | Wrench Set - Limit Switch, Flap Control Unit | 27-50-08 |
| F80201-1 | Drain Tool - Fuel Sump | 12-10-05 |
| F80205-1 | BEARING SWAGING EQUIPMENT | 20-50-28 |
| F80212-30 | Adapter - Rudder Pedal Force Check | 27-20-01 |
| F80220-1 | Functional Test - Transfer Mechanism, Aileron Control | 27-10-08 |
| F80222-1, -11 | Protractor - Aileron Tab Alignment | 27-10-04 |
| F80224-60, -79 | Test Equipment - Flight Spoiler Power Control Unit | 27-60-05 |
| F80229-15, -20, -48, -52, -55, -56, -57, -58, -59, -60, -61, -69 | Test Equipment - Fire Extinguishing System | 26-20-01 |
| F80232-1 | Test Fixture - Control Valve Assembly, Trailing Edge Flap | 27-50-18 |
| F80239-21, -22, -25 | Safety Lanyard - Personnel, Engine Maintenance | 71-00-02 |
| F80240-1 | Restraint Equipment - Passenger Window | 07-00-02 |
| F80241-1, -9 | Restraint - Tethering, Sta 322.5 Forward Entry And Forward Galley Doors | 07-00-03 |
| F80249-7 | Torque Socket - Ball Nut/Screw Assembly, Stabilizer Trim | 27-40-29 |
| G20001-1, -18 | SWAGING EQUIPMENT - FORE FLAP LEVER BEARING | 20-50-29 |
| G20003-15 | STAKING EQUIPMENT - MAIN LANDING GEAR. ACTUATOR | 20-50-30 |
| G20004-15 | STAKING EQUIPMENT - BODY LANDING GEAR AND WING LANDING GEAR, RETRACT ACTUATOR, ROD END AND HEAD END | 20-50-31 |
| G21007-1 | Air Flow Cup - LO/HI Blow Test | 05-50-01 |
| G25012-1, -8 | Anti-Rattle Nut Wrench Kit | 25-20-05 |
| G28005-35 | Check Fixture Equipment - Pressure Relief Valve | 28-10-01 |
| G29015-1 | Ground Fault Circuit Interrupter Tester - Hydraulic Pump | 29-10-05 |
| G32019-1 | ROLLER SWAGING EQUIPMENT - OUTBOARD TRUNNION BEARING ASSEMBLY, MAIN LANDING GEAR | 20-50-32 |
| G32021-18 | Force Gauge Equipment - Landing Gear Lever | 32-30-05 |
| G38004-10, -13 | Blockage Removal Tool - Vacuum Lavatory System | 38-30-01 |

NUMERICAL INDEX



737-600/700/800/900
ILLUSTRATED TOOL AND EQUIPMENT MANUAL

| <u>PART NO.</u> | <u>TITLE</u> | <u>SUBJECT</u> |
|---|---|-----------------------|
| G38006-1 | Blockage Removal Equipment - Vacuum Waste System | 38-30-06 |
| G45002-29 | Ground Support Equipment (GSE) Kit - Maintenance Laptop (Windows 7) | 45-00-01 |
| G47001-19 | Test Equipment - Leak and Pressure, Nitrogen Generation System | 47-00-01 |
| G51002-1 | Fall Protection - Overhead Personnel Support | 51-00-01 |
| G51003-1 | Fall Protection - Overhead Personnel Support | 51-00-02 |
| G57012-1 | Spotface Equipment - Corrosion Removal, Wing Box Skins | 57-20-04 |
| G76002-19 | Protractor - Thrust Reverser Levers, Forward and Reverse | 76-10-02 |
| G78004-1, -12 | INSTALLATION/REMOVAL EQUIPMENT - OVERSIZE BEARING | 20-50-33 |
| G78009-1 | Gauge - Wear Measurement, Thrust Reverser Blocker Door | 78-30-44 |
| J20009-68, -108, -109, -110 | Jacking Equipment - Hydraulic Telescoping (CE) | 49-10-04 |
| J20010-1, -2, -3, -4, -5, -6, -7, -8 | WRENCH - SPANNER, BEARING RETAINER NUT | 20-50-34 |
| J21009-33, -48 | Air Sampler, Aircraft Pneumatic System | 21-00-01 |
| J22001-1, -8 | Tool Set - Autothrottle Servo Assembly | 76-10-04 |
| J22002-1 | Spline Wrench - Gearbox, Autothrottle Control Stand | 22-30-04 |
| J22004-67, -68, -156, -157 | Test Equipment - Autothrottle, Gearbox, Brake | 22-30-01 |
| J24015-1 | Pressure Test Equipment - Engine Generators | 24-10-02 |
| J24016-1 | Battery Inspection Gauge Tool | 24-30-04 |
| J25008-1 | Cart, Passenger Seat | 25-20-03 |
| J27054-1 | Test Equipment - Leakage Test | 27-50-16 |
| J27056-43, -44, -45, -46, -71, -72, -155, -156 | Test Equipment - Run-In, Variable Drive | 27-50-07 |
| J27057-22, -29 | Measurement Equipment - Bearing Width | 27-50-19 |
| J28006-1 | Sealing Tool - Rivet, Fuel Tank | 28-10-11 |
| J28010-26, -135 | Console Equipment - Shop Air Supply | 57-20-03 |
| J28011-1, -5, -6, -205 | Auxiliary Defueling Equipment - External Power Control Unit | 28-20-08 |
| J32001-63, -64, -67, -68 | Measuring Equipment - Brake Pedal | 32-40-08 |
| J32037-106 | Spring Removal/Installation Equipment - Main Landing Gear and Nose Landing Gear | 32-30-09 |
| J32060-1 | Drain Equipment - Oleo Strut, Main Landing Gear/Nose Landing Gear | 12-10-07 |
| J32062-1 | Transporter and Positioner Equipment - Main Landing Gear | 32-40-09 |
| J32091-1, -3, -7 | Test Equipment - Velocity/Position Transducer | 78-30-47 |
| J32092-1 | BUSHING REPLACEMENT AND HONING KIT - MAIN LANDING GEAR | 20-50-35 |
| J34002-18, -19 | Test Fixture - Angle of Attack | 34-20-01 |

NUMERICAL INDEX



737-600/700/800/900
ILLUSTRATED TOOL AND EQUIPMENT MANUAL

| <u>PART NO.</u> | <u>TITLE</u> | <u>SUBJECT</u> |
|--|--|-----------------------|
| J34004-1, -9 | BREAKOUT BOX EQUIPMENT - CONNECTORS (S280W551), LINE MAINTENANCE | 34-10-07 |
| J38004-232, -247 | Pump Equipment - Vacuum Lavatory System | 38-30-15 |
| J46002-3, -4, -8, -9, -11, -13, -15, -16 | Fiber Optic Breakout Equipment - ARINC 600 Style Connectors | 46-00-01 |
| J51004-1 | Vacuum Generator Test Equipment | 52-00-04 |
| J52039-1, -87, -88, -90 | Personnel Barrier Equipment - Main Cargo Door | 52-00-03 |
| J71044 | Specification - Lever Operated Chain Hoist (CE) | 71-00-38 |
| J71046 | Specification - Load Cell Equipment | 71-00-07 |
| J71047-1 | Storage Cart - Support Equipment | 71-00-39 |
| ME141A6480-1 | Transportation Sling - Forward Airstair | 52-60-01 |
| MIT161W1122 | MISCELLANEOUS TOOL - BUSHING REPLACEMENT AND HONING KIT, INNER CYLINDER, CENTER AXLE | 20-50-36 |
| MIT311A1550 | MISCELLANEOUS TOOL - BEARING REPLACEMENT KIT, 737 THRUST REVERSER | 20-50-37 |
| MIT314T3281-3 | FITTING ASSEMBLY - TOGGLE HINGE, CORE COWL | 20-50-38 |
| MIT315W3402 | MISCELLANEOUS TOOL - BUSHING REPLACEMENT, LATCH BEAM | 20-50-39 |
| MIT65B02023 | BEARING SWAGING TOOL - FOREFLAP LEVER | 20-50-40 |
| MIT65B02505 | SWAGING TOOL - STATION 2598 BULKHEAD TRUSS BEARING | 20-50-41 |
| MIT65B05336 | BUSHING SWAGING TOOL - LOWER JURY STRUT, WING LANDING GEAR | 20-50-42 |
| MIT65B05338 | BUSHING SWAGING TOOL - UPPER JURY STRUT, WING LANDING GEAR | 20-50-43 |
| MIT65B10901 | ROLLER SWAGE - SPHERICAL BEARING SLEEVE | 20-50-44 |
| MIT65B63429 | BALL STAKING TOOL - BEARING | 20-50-45 |
| MIT65B90361 | TOOL - ROLLER SWAGING, 60B00180-302 BEARING | 20-50-46 |
| MIT65B97321 | INSTALLATION AND REMOVAL TOOL - ROLLER SWAGED BEARING | 20-50-47 |
| SE27-0001 | Control Wheel Straightedge | 27-10-02 |
| SE28-1103 | Adapter Assembly - Sump Drain Valve Removal | 28-10-18 |
| ST1064 | STAKING TOOL - BACB28B7 | 20-50-48 |
| ST1065C | Standard Tool - Installation Tool, Grommet, NAS1368 | 20-10-05 |
| ST1066RB | Standard Tool - Release Key For Pivot Bin Snubber, "Boeing Sky" Interior | 25-20-09 |
| ST1212 | ARBOR - HOLE SAW | 20-50-49 |
| ST1212E | STANDARD TOOL - HOLE SAW | 20-50-50 |
| ST1864P | Standard Tool Reamer - Carbide, Straight Flute, Piloted | 51-10-03 |
| ST2570-28 | SCREWDRIVER - SPECIAL FOR BACB10B CAM FOLLOWER BEARINGS | 20-50-51 |
| ST2580-103 | WRENCH - ROD END | 20-50-52 |
| ST2580-163A | Wrench - Spanner Type | 25-20-04 |
| ST2580-286-8 | STANDARD TOOL - SPANNER WRENCH, FACE TYPE | 20-50-53 |

NUMERICAL INDEX



737-600/700/800/900
ILLUSTRATED TOOL AND EQUIPMENT MANUAL

| <u>PART NO.</u> | <u>TITLE</u> | <u>SUBJECT</u> |
|--------------------------------------|---|-----------------------|
| ST2580-334C-1-145, -185 | Standard Tool - Spanner Nose Pliers | 25-20-01 |
| ST2597 | PLIERS - RETAINER RING | 20-50-54 |
| ST30-8783 | ROAD MAP, TEST TOOL BEARING, PROOF LOAD TEST | 20-50-55 |
| ST30-8783A | ROAD MAP FOR BEARING PROOF LOAD TESTING | 20-50-56 |
| ST321-A | SUPPORT - BUSHING INSTALLATION, ARBOR PRESS | 20-50-57 |
| ST732 | Standard Tool Cutter - Scotchcal Marking Material | 20-10-02 |
| ST848 | Installation Tools - O-Rings | 29-00-01 |
| ST848R | Removal Tool - O-Ring | 20-00-02 |
| ST8709H-1, -2, -3, -4, -5, -6, -7 | Standard Tool - Go/No-Go Gauge, For Assembly of Wiggins BACC42R Coupling | 28-20-05 |
| ST8783-6 | STANDARD TOOL - ASSEMBLY, PROOF LOAD TEST EQUIPMENT, BACB10FB08GC BEARING INSTALLATION | 20-50-58 |
| ST8783F | STANDARD TOOL - BEARING RETENTION PROOF TEST | 20-50-59 |
| ST878D | Standard Tool - Sleeveset for Presetting BACS13AP Flareless Tube Fittings | 29-00-02 |
| ST879A | Hand Presetting Tool - Flareless Tube Fittings MS21922 | 20-10-06 |
| ST879AF | Holding Fixture - Hand Presetting Tools, ST879A | 20-10-07 |
| ST895A-1 | Sensor For Film Thickness | 51-20-02 |
| ST895A-3 | Probe - Surface Resistivity Measurment | 20-00-05 |
| ST918A | MANDREL - BEARING PRESSING BACB10A | 20-50-60 |
| ST918B | MANDREL - BEARING PRESSING BACB10B | 20-50-61 |
| ST918C | MANDREL - BEARING PRESSING BACB10C | 20-50-62 |
| ST918CA-1000-1625 | BEARING INSTALLATION TOOL | 20-50-63 |
| ST918D | MANDREL - BEARING PRESSING BACB10D | 20-50-64 |
| ST919 | SUPPORT - BEARING INSTALLATION | 20-50-65 |
| ST919-MP | MOUNTING PLATE - BEARING INSTALLATION | 20-50-66 |
| ST920 | MANDREL - NAS PRESS FIT BUSHING INSTALLATION TOOL | 20-50-67 |
| ST920A | MANDREL - INSERTION TOOL, BUSHING | 20-50-68 |
| ST920B | INSTALLATION TOOL - PRESS BUSHING | 20-50-69 |
| ST921B | BUSHING PULLER | 20-50-70 |
| ST921C | BUSHING REMOVAL TOOL | 20-50-71 |
| ST922 | STAKING TOOL - BUSHING | 20-50-72 |
| ST922A-6 | STAKING TOOL - 3/8-INCH DIAMETER BUSHING | 20-50-73 |
| ST922C | STAKING TOOL - (X/16) BUSHING, BACB28B-X | 20-50-74 |
| ST922E | STAKING TOOL - 1/4 BUSHING, BACB28B-4-239P | 20-50-75 |
| ST922F-4 | STAKING TOOL - 1/4 DIAMETER BUSHING | 20-50-76 |

NUMERICAL INDEX



737-600/700/800/900
ILLUSTRATED TOOL AND EQUIPMENT MANUAL

| <u>PART NO.</u> | <u>TITLE</u> | <u>SUBJECT</u> |
|-----------------------------|--|-----------------------|
| ST923 | ADAPTOR FOR 0.374 SHANK TO 0.750 | 20-50-77 |
| ST925 | POINT STAKING TOOL - BEARING RETENTION | 20-50-78 |
| ST925A | STAKING TOOL - HINGE FLAP, FORWARD ENTRY DOOR | 20-50-79 |
| ST926-1, -2, -3, -4, -5, -6 | ROLLER STAKING TOOL | 20-50-80 |
| ST926A | ROLLER STAKING TOOL | 20-50-81 |
| ST926B | ROLLER STAKING TOOL - PORTABLE, HAND OPERATED | 20-50-82 |
| ST926C | ROLLER STAKING TOOL | 20-50-83 |
| ST926D | STAKING TOOL - ROLLER BEARING | 20-50-84 |
| ST926E | ROLLER SWAGING TOOL - BEARING | 20-50-85 |
| ST926F-1, -34 | ROLLER SWAGE BEARING AND SLEEVE REPAIR KIT - BAC5435 PROCESS | 20-50-86 |
| ST926G | STANDARD TOOL - BEARING REMOVE/INSTALL/SWAGE, BEARING WITH GROOVE 0.500 TO 1.250-INCH RACE SWAGE (TYPE III) | 20-50-87 |
| ST927 | BEARING REMOVAL TOOL | 20-50-88 |
| ST927A | BUSHING REMOVAL TOOL FOR 69B13953 | 20-50-89 |
| ST927AA-1 | STANDARD TOOL - BACB10CN3 BEARING REMOVAL TOOL | 20-50-90 |
| ST927AA-2 | STANDARD TOOL - BACB10AG4MC BEARING REMOVAL TOOL | 20-50-91 |
| ST927B | BEARING REMOVAL TOOL | 20-50-92 |
| ST927C | STANDARD TOOL - BEARING REMOVAL TOOL | 20-50-93 |
| ST927J | STANDARD TOOL - HOLE SAW, BEARING REMOVAL | 20-50-94 |
| ST928 | STANDARD TOOL - ROLLER STAKING TOOL, ALUMINUM SLEEVE | 20-50-95 |
| ST928-A | STANDARD TOOL - ROLLER SWAGING, ALUMINUM SLEEVE 69-38919 | 20-50-96 |
| ST928A | ROLLER STAKING HAND TOOL - YD-134 BEARING | 20-50-97 |
| ST928B | ROLLER SWAGING TOOL - BEARING SLEEVE | 20-50-98 |
| ST928C | ROLLER SWAGING TOOL - BEARING SLEEVE | 20-50-99 |
| ST928D | ROLLER SWAGING TOOL FOR BACB10C94H | 20-51-01 |
| ST928E | ROLLER SWAGING TOOL - ALUMINUM SLEEVE, 69-38919-2 | 20-51-02 |
| ST928F | ROLLER STAKING TOOL - ALUMINUM SLEEVE | 20-51-03 |
| ST928G | STANDARD TOOL - ROLLER SWAGING ACCESSORIES FOR ST928 | 20-51-04 |
| ST928H | STANDARD TOOL - BEARING REMOVE/INSTALL/SWAGE, SLEEVE OUTSIDE DIAMETER 1.33 THRU 2.25-INCH SLEEVE TYPE | 20-51-05 |
| ST929-2B | 12 POINT STAKING TOOL | 20-51-10 |
| ST929-1 | BEARING ROLLER SWAGING TOOL | 20-51-06 |
| ST929-1A | STANDARD TOOL - ROLLER SWAGING SLEEVE BEARING | 20-51-07 |
| ST929-1B | ROLLER SWAGING TOOL - ROD END | 20-51-08 |
| ST929-2A | BEARING SLEEVE STAKING TOOL - 3 POINT | 20-51-09 |

NUMERICAL INDEX



737-600/700/800/900
ILLUSTRATED TOOL AND EQUIPMENT MANUAL

| <u>PART NO.</u> | <u>TITLE</u> | <u>SUBJECT</u> |
|------------------------|--|-----------------------|
| ST929-2C | STAKING TOOL - BEARING SLEEVE, 6 POINT | 20-51-11 |
| ST929-3A | STAKING TOOL - BEARING SLEEVE, 3 POINT | 20-51-12 |
| ST929-4 | LINE STAKING TOOL - BEARING | 20-51-13 |
| ST930 | BUSHING STAKING TOOL | 20-51-14 |
| ST930-LT | LOAD TEST - BEARING BAC 5435 | 20-51-17 |
| ST930B | STAKING TOOL - PRESSURE | 20-51-15 |
| ST930C | STANDARD TOOL - ANVIL SWAGING TOOL | 20-51-16 |
| ST931 | BALL POINT MULTIPLE - BEARING STAKING TOOL | 20-51-18 |
| ST931A | BEARING STAKING TOOL - ADJUSTABLE BALL POINT | 20-51-19 |
| ST931B | YOKE BALL POINT - BEARING STAKING | 20-51-20 |
| ST931D | BALL STAKING TOOL - BEARING | 20-51-21 |
| ST931E-500-1000 | SWAGING TOOL - THRUST LINK FITTING, FORWARD ENGINE MOUNT | 20-51-22 |
| ST932 | ROLLER SWAGE TOOL HOUSING - BEARING RETENTION | 20-51-23 |
| ST932-P | PILOT - ROLLER SWAGING TOOL, BEARING RETENTION | 20-51-24 |
| ST932-R | ROLLER - STAKING TOOL, BEARING RETENTION | 20-51-26 |
| ST932-S | SPINDLE - ROLLER SWAGE TOOL HOUSING, BEARING RETENTION | 20-51-25 |
| ST932A-R | ROLLER STAKING TOOL - BEARING RETENTION | 20-51-27 |
| ST932B | ROLLER SWAGING TOOL - HOUSING, BEARING | 20-51-28 |
| ST932C | ROLLER SWAGING TOOL FOR BACB10A-38 BEARING | 20-51-29 |
| ST932E | ROLLER SWAGING AUTOTHROTTLER, BRACKET ASSEMBLY | 20-51-30 |
| ST933 | SWAGING TOOL - HOUSING BEARING RING LOCK | 20-51-31 |
| ST933-100 | SWAGING TOOL - SHAFT BEARING RING LOCK | 20-51-32 |
| ST934 | BEARING ROLLER SWAGING TOOL | 20-51-33 |
| ST937D-1 | STANDARD TOOL - ANVIL SWAGE NACELLE SUPPORT FITTINGS | 20-51-40 |
| 150MIT65B00112 | Spotface Tool - Corrosion Removal, Wing Box Skins | 57-00-01 |
| 2ME50-7945 | Canopy Assembly - Forward Entry Door | 52-10-15 |
| 2MIT65B02070 | INSTALLATION AND REMOVAL TOOL - ROLLER SWAGED BEARING | 20-51-35 |
| 2MIT65B02661 | ROLLER SWAGE - BEARING RETAINING RING | 20-51-34 |
| 2MIT65B05370 | SWAGE TOOL - UPPER AND LOWER JURY STRUT, BODY LANDING GEAR | 20-51-36 |
| 2MIT65B90361 | TOOL - REMOVAL, 60B00180-302 BEARING | 20-51-37 |
| 4MIT65B01501 | DIE - BEARING STAKE, ROD END ASSEMBLY, 65B01521 AND 65B01537 | 20-51-38 |
| 4MIT65B80307-1 | Protractor Assembly - Control Column | 27-30-07 |
| 7MIT65B01500 | DIE - BEARING STAKE, ROD END ASSEMBLY 65B01513-1 AND -6 | 20-51-39 |

NUMERICAL INDEX