



707, 727-787
STANDARD WIRING PRACTICES MANUAL
AIRPLANE FLAMMABLE LEAKAGE ZONES

TABLE OF CONTENTS

<u>PARAGRAPH</u>	<u>PAGE</u>
1. <u>GENERAL DATA</u>	2
A. Definition of a Flammable Leakage Zone	2
B. General Conditions	2
C. Fire Safety Precautions	2
2. <u>LOCATION OF THE FLAMMABLE LEAKAGE ZONES</u>	3
A. 707 Model Flammable Leakage Zones	3
B. 727 Model Flammable Leakage Zones	4
C. 737 Model Flammable Leakage Zones	5
D. 747 Model Flammable Leakage Zones	6
E. 757 Model Flammable Leakage Zones	7
F. 767 Model Flammable Leakage Zones	8
G. 777 Model Flammable Leakage Zones	9
H. 787 Model Flammable Leakage Zones	10

20-02-10



707, 727-787
STANDARD WIRING PRACTICES MANUAL
AIRPLANE FLAMMABLE LEAKAGE ZONES

1. GENERAL DATA

A. Definition of a Flammable Leakage Zone

A flammable leakage zone is an area where leakage of flammable fluids or flammable vapors can occur as a result of:

- One failure
- Leakage during normal operation.

B. General Conditions

Refer to Subject 20-30-00 for the applicable conditions for protection of electrical connections in a flammable leakage zone.

C. Fire Safety Precautions

Refer to Subject 20-00-10 for the fire safety precautions in that apply to the electrical power of the circuits in a flammable leakage zone.

These conditions are applicable in an area where there are flammable vapors:

- All flames, smoking, sparks, and other sources of ignition must not occur
- Tools and test equipment that can make a spark must not be used
- A megohmmeter must not be used
- All electrical equipment, such as lights, motors, wiring, etc., must meet the necessary electrical and fire codes
- The accumulation of vapors must be prevented by sufficient ventilation.


20-02-10



707, 727-787
STANDARD WIRING PRACTICES MANUAL
AIRPLANE FLAMMABLE LEAKAGE ZONES

2. LOCATION OF THE FLAMMABLE LEAKAGE ZONES

A. 707 Model Flammable Leakage Zones



2448050 S00061543085_V1


FLAMMABLE LEAKAGE ZONES
Figure 1

20-02-10





707, 727-787
STANDARD WIRING PRACTICES MANUAL
AIRPLANE FLAMMABLE LEAKAGE ZONES

B. 727 Model Flammable Leakage Zones



Flammable Leakage Zone



2443674 S00061543086_V1

FLAMMABLE LEAKAGE ZONES


Figure 2

20-02-10



707, 727-787
STANDARD WIRING PRACTICES MANUAL
AIRPLANE FLAMMABLE LEAKAGE ZONES

C. 737 Model Flammable Leakage Zones



2448051 S00061543087_V1

FLAMMABLE LEAKAGE ZONES


Figure 3

20-02-10



707, 727-787
STANDARD WIRING PRACTICES MANUAL
AIRPLANE FLAMMABLE LEAKAGE ZONES

D. 747 Model Flammable Leakage Zones



2448052 S00061543088_V1

FLAMMABLE LEAKAGE ZONES


Figure 4

20-02-10





707, 727-787
STANDARD WIRING PRACTICES MANUAL
AIRPLANE FLAMMABLE LEAKAGE ZONES

E. 757 Model Flammable Leakage Zones



Flammable Leakage Zone



2448053 S00061543089_V1

FLAMMABLE LEAKAGE ZONES

Figure 5

20-02-10

D6-54446


BOEING PROPRIETARY - Copyright © Unpublished Work - See title page for details

Page 7
Oct 15/2015



707, 727-787
STANDARD WIRING PRACTICES MANUAL
AIRPLANE FLAMMABLE LEAKAGE ZONES

F. 767 Model Flammable Leakage Zones



2448054 S00061543090_V1

FLAMMABLE LEAKAGE ZONES


Figure 6

20-02-10



707, 727-787
STANDARD WIRING PRACTICES MANUAL
AIRPLANE FLAMMABLE LEAKAGE ZONES

G. 777 Model Flammable Leakage Zones



2448055 S00061543091_V1

FLAMMABLE LEAKAGE ZONES

Figure 7

20-02-10


D6-54446

BOEING PROPRIETARY - Copyright © Unpublished Work - See title page for details



707, 727-787
STANDARD WIRING PRACTICES MANUAL
AIRPLANE FLAMMABLE LEAKAGE ZONES

H. 787 Model Flammable Leakage Zones



2443686 S00061543092_V1

FLAMMABLE LEAKAGE ZONES

Figure 8

20-02-10



707, 727-787
STANDARD WIRING PRACTICES MANUAL
AIRPLANE TEMPERATURE AREAS

TABLE OF CONTENTS

<u>PARAGRAPH</u>	<u>PAGE</u>
1. <u>GENERAL DATA</u>	2
A. General Conditions	2
2. <u>LOCATION OF HIGH TEMPERATURE AREAS</u>	3
A. Typical and Usual Locations of High Temperature Areas	3

20-02-20



707, 727-787
STANDARD WIRING PRACTICES MANUAL
AIRPLANE TEMPERATURE AREAS

1. GENERAL DATA

A. General Conditions

The materials used for repair of a wire harness in a high temperature area must have Temperature Grade D.

Refer to:

- The applicable repair subject for the selection of materials
- Subject 20-10-13 for the general conditions for the repair of wire and cable.


20-02-20



707, 727-787
STANDARD WIRING PRACTICES MANUAL
AIRPLANE TEMPERATURE AREAS

2. LOCATION OF HIGH TEMPERATURE AREAS

A. Typical and Usual Locations of High Temperature Areas



2448056 S00061543094_V1

TYPICAL AND USUAL LOCATIONS OF HIGH TEMPERATURE AREAS FOR ALL MODELS

Figure 1

20-02-20



707, 727-787
STANDARD WIRING PRACTICES MANUAL
AIRPLANE VIBRATION AREAS

TABLE OF CONTENTS

<u>PARAGRAPH</u>	<u>PAGE</u>
1. <u>GENERAL DATA</u>	2
A. General Conditions	2
2. <u>LOCATION OF THE VIBRATION AREAS</u>	2
A. Usual Locations of the Vibration Areas	2

20-02-30



707, 727-787
STANDARD WIRING PRACTICES MANUAL
AIRPLANE VIBRATION AREAS

1. GENERAL DATA

A. General Conditions

For the applicable conditions for the assembly and installation of wire harnesses in a high vibration area, refer to Subject 20-10-11.

2. LOCATION OF THE VIBRATION AREAS

A. Usual Locations of the Vibration Areas

Table 1
VIBRATION LEVEL AND VIBRATION AREA TYPE

Vibration Level	Type
1	Not a high vibration area
2	A high vibration area
3	A high vibration area

The usual locations for vibration areas with Vibration Level 1 are:

- The cabin
- The EE bay
- The cargo area.

The usual locations for vibration areas with Vibration Level 2 are:

- The ECS bay
- The empennage
- The fuel tanks
- The horizontal stabilizer
- The leading edge of the wing
- The radome
- The rudder
- The struts
- The trailing edge of the wing
- The wheel wells
- The wing to body fairing.

The usual locations for vibration areas with Vibration Level 3 are:


- The engine core
- The engine nacelle
- The APU compartment.

Refer to Figure 1.

20-02-30



707, 727-787
STANDARD WIRING PRACTICES MANUAL
AIRPLANE VIBRATION AREAS



2448049 S00061543096_V1

USUAL LOCATIONS OF THE VIBRATION AREAS FOR ALL MODELS
Figure 1

20-02-30