

91-21-21

GROUND LIST

91-21-21
GROUND LIST

Section	Page	Date	Section	Page	Date	Section	Page	Date
EFFECTIVE PAGES			GB01400 cont.			GD00100 cont.		
	1 thru 3	Jun 21/2016	R	4	Jun 21/2016	R	3	Jun 21/2016
	4	BLANK	R	GB01500	1 Jun 21/2016	R	4	Jun 21/2016
R	GB00000	1 Jun 21/2016	R	GB01800	1 Jun 21/2016	R	5	Jun 21/2016
R	GB00100	1 Jun 21/2016	R	GB02100	1 Jun 21/2016	R	GD00200	1 Jun 21/2016
R	GB00200	1 Jun 21/2016	R	GB02200	1 Jun 21/2016	R		2 Jun 21/2016
R	GB00300	1 Jun 21/2016	R	GB03000	1 Jun 21/2016	R		3 Jun 21/2016
R	GB00500	1 Jun 21/2016	R	GB03100	1 Jun 21/2016	R		4 Jun 21/2016
R		2 Jun 21/2016	R		2 Jun 21/2016	R	GD00300	1 Jun 21/2016
R		3 Jun 21/2016	R		3 Jun 21/2016	R		2 Jun 21/2016
R		4 Jun 21/2016	R		4 Jun 21/2016	R		3 Jun 21/2016
R		5 Jun 21/2016	R		5 Jun 21/2016	R		4 Jun 21/2016
R		6 Jun 21/2016	R		6 Jun 21/2016	R	GD00400	1 Jun 21/2016
R	GB00600	1 Jun 21/2016	R	GB03200	1 Jun 21/2016	R		2 Jun 21/2016
R		2 Jun 21/2016	R		2 Jun 21/2016	R		3 Jun 21/2016
R	GB00800	1 Jun 21/2016	R	GB03300	1 Jun 21/2016	R		4 Jun 21/2016
R	GB01000	1 Jun 21/2016	R	GB03900	1 Jun 21/2016	R	GD00500	1 Jun 21/2016
R	GB01100	1 Jun 21/2016	R	GB04100	1 Jun 21/2016	R		2 Jun 21/2016
R		2 Jun 21/2016	R	GB04200	1 Jun 21/2016	R		3 Jun 21/2016
R		3 Jun 21/2016	R	GD00000	1 Jun 21/2016	R		4 Jun 21/2016
R		4 Jun 21/2016	R		2 Jun 21/2016	R		5 Jun 21/2016
R		5 Jun 21/2016	R		3 Jun 21/2016	R		6 Jun 21/2016
R	GB01200	1 Jun 21/2016	R		4 Jun 21/2016	R		7 Jun 21/2016
R		2 Jun 21/2016	R		5 Jun 21/2016	R		8 Jun 21/2016
R	GB01300	1 Jun 21/2016	R		6 Jun 21/2016	R		9 Jun 21/2016
R	GB01400	1 Jun 21/2016	R		7 Jun 21/2016	R		10 Jun 21/2016
R		2 Jun 21/2016	R	GD00100	1 Jun 21/2016	R	GD00600	1 Jun 21/2016
R		3 Jun 21/2016	R		2 Jun 21/2016	R		2 Jun 21/2016

A = Added, R = Revised, D = Deleted, O = Overflow

GROUND LIST

D280A351

EFFECTIVE PAGES

Page 1
Jun 21/2016

91-21-21
GROUND LIST

Section	Page	Date	Section	Page	Date	Section	Page	Date
GD00600 cont.			R GD01700	1	Jun 21/2016	GD03700 cont.		
R	3	Jun 21/2016	R GD01800	1	Jun 21/2016	R	5	Jun 21/2016
R	4	Jun 21/2016	R GD01900	1	Jun 21/2016	R GD03800	1	Jun 21/2016
R	5	Jun 21/2016	R GD02000	1	Jun 21/2016	R	2	Jun 21/2016
R GD00700	1	Jun 21/2016	R	2	Jun 21/2016	R	3	Jun 21/2016
R	2	Jun 21/2016	R GD02100	1	Jun 21/2016	R	4	Jun 21/2016
R GD00800	1	Jun 21/2016	R	2	Jun 21/2016	R	5	Jun 21/2016
R	2	Jun 21/2016	R GD02200	1	Jun 21/2016	R GD03900	1	Jun 21/2016
R	3	Jun 21/2016	R GD02300	1	Jun 21/2016	R	2	Jun 21/2016
R	4	Jun 21/2016	R	2	Jun 21/2016	R	3	Jun 21/2016
R	5	Jun 21/2016	R	3	Jun 21/2016	R	4	Jun 21/2016
R	6	Jun 21/2016	R	4	Jun 21/2016	R	5	Jun 21/2016
R GD00900	1	Jun 21/2016	R GD02500	1	Jun 21/2016	R GD04000	1	Jun 21/2016
R	2	Jun 21/2016	R GD02900	1	Jun 21/2016	R	2	Jun 21/2016
R GD01000	1	Jun 21/2016	R GD03000	1	Jun 21/2016	R	3	Jun 21/2016
R	2	Jun 21/2016	R	2	Jun 21/2016	R GD04100	1	Jun 21/2016
R	3	Jun 21/2016	R GD03100	1	Jun 21/2016	R	2	Jun 21/2016
R	4	Jun 21/2016	R GD03200	1	Jun 21/2016	R	3	Jun 21/2016
R GD01100	1	Jun 21/2016	R	2	Jun 21/2016	R	4	Jun 21/2016
R	2	Jun 21/2016	R	3	Jun 21/2016	R GD04200	1	Jun 21/2016
R	3	Jun 21/2016	R	4	Jun 21/2016	R	2	Jun 21/2016
R GD01200	1	Jun 21/2016	R GD03300	1	Jun 21/2016	R	3	Jun 21/2016
R	2	Jun 21/2016	R	2	Jun 21/2016	R GD04300	1	Jun 21/2016
R GD01300	1	Jun 21/2016	R GD03400	1	Jun 21/2016	R GD04400	1	Jun 21/2016
R GD01400	1	Jun 21/2016	R GD03700	1	Jun 21/2016	R GD04800	1	Jun 21/2016
R	2	Jun 21/2016	R	2	Jun 21/2016	R	2	Jun 21/2016
R GD01500	1	Jun 21/2016	R	3	Jun 21/2016	R GD05000	1	Jun 21/2016
R GD01600	1	Jun 21/2016	R	4	Jun 21/2016	R GD05100	1	Jun 21/2016

A = Added, R = Revised, D = Deleted, O = Overflow

GROUND LIST

D280A351

EFFECTIVE PAGES

Page 2
Jun 21/2016

91-21-21
GROUND LIST

Section	Page	Date	Section	Page	Date	Section	Page	Date
GD05100 cont.			R GD11700	1	Jun 21/2016			
R GD05200	2	Jun 21/2016	R GD11800	1	Jun 21/2016			
R GD05500	1	Jun 21/2016	R GD11900	1	Jun 21/2016			
R GD06100	2	Jun 21/2016	R GD30100	1	Jun 21/2016			
R GD06200	1	Jun 21/2016						
R GD06300	1	Jun 21/2016						
R GD06500	1	Jun 21/2016						
R GD07000	1	Jun 21/2016						
GD07100	1	Mar 14/2016						
R GD07200	1	Jun 21/2016						
R GD08000	1	Jun 21/2016						
R	2	Jun 21/2016						
R	3	Jun 21/2016						
R	4	Jun 21/2016						
R	5	Jun 21/2016						
R GD08100	1	Jun 21/2016						
R GD08200	1	Jun 21/2016						
R GD08400	1	Jun 21/2016						
R GD09000	1	Jun 21/2016						
R GD09100	1	Jun 21/2016						
R GD09200	1	Jun 21/2016						
R GD10000	1	Jun 21/2016						
R GD10100	1	Jun 21/2016						
R GD11000	1	Jun 21/2016						
R GD11100	1	Jun 21/2016						
R GD11300	1	Jun 21/2016						

A = Added, R = Revised, D = Deleted, O = Overflow

GROUND LIST

D280A351

EFFECTIVE PAGES

Page 3
Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No.		Part Number		Wire No.	GA	CO	Station / WL / BL	Effectivity
Term	Type	Bundle					Diagram	
I	GB00020		PARTOFTB0020				J020-0B/ /	ALL
I	ST..	1A	W0072	2001Z			73-21-11	ALL
I	ST..	1A	W0072	2011Z			31-32-15	ALL
I	ST..	1A	W0072	2012Z			73-24-12	ALL
I	ST..	1A	W0072	2013Z			73-24-12	ALL
I	GB00022		PARTOFTB0022				J022-00/ /	ALL
I	GB00023		PARTOFTB0023				J023-00/ /	ALL
I	ST..	1A	W0078	0099	20		73-21-11	ALL
I	GB00024		PARTOFTB0024				J024-00/ /	ALL
I	GB00028		PARTOFTB0028				J020-0A/ /	ALL
I	GB00032		PARTOFTB0032				J022-00/ /	ALL
I	GB00033		PARTOFTB0033				J023-00/ /	ALL
I	GB00034		PARTOFTB0034				J024-00/ /	ALL
I	ST..	1A	W0080	1301Z			73-22-11	ALL
I	ST..	1A	W0080	1302Z			73-22-11	ALL

GROUND LIST

D280A351

91-21-21

Section GB00000

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
I	GB00101		PARTOFTB0101			P001-00/ /	ALL
I	ST..	1A	W0001	1009Z		33-11-32	ALL
I	ST..	1A	W0001	2001Z		31-62-11	ALL
I	ST..	1A	W0001	2005Z		31-62-13	ALL
I	ST..	1A	W0001	2006Z		31-62-13	ALL
I	ST..	1A	W0001	2010Z		31-62-11	ALL
I	ST..	1A	W0001	2011Z		31-62-11	ALL

GROUND LIST

D280A351

91-21-21

Section GB00100

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No.		Part Number		Station / WL / BL		Effectivity
Term	Type	Bundle	Wire No.	GA	CO	
I	GB00201	PARTOFTB0201		P002-00/ /		ALL
I	GB00261	PARTOFTB0261		261/282/R005		ALL
I	ST..	1A	W2112	2601Z	73-21-12	ALL
I	DC..	1A	W2114	A-AG	33-51-12	ALL
I	ST..	1A	W2216	2601Z	73-21-12	ALL
I	ST..	1A	W2709	2075Z	34-36-12	ALL
I	ST..	1A	W2709	2076Z	34-36-12	ALL
I	ST..	1A	W5172	2610Z	73-21-12	ALL
I	ST..	1A	W5172	2617Z	74-31-11	ALL
I	ST..	1A	W6172	2611Z	73-21-12	ALL
I	ST..	1A	W6172	2614Z	74-31-11	ALL
I	GB00262	PARTOFTB0262		/ /		ALL

GROUND LIST

D280A351

91-21-21

Section GB00200

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GB00301		PARTOFTB0301				P003-00/ /	ALL
ST..	1A	W0003	2501Z			31-62-21	ALL
ST..	1A	W0003	2505Z			31-62-23	ALL
ST..	1A	W0003	2506Z			31-62-23	ALL
ST..	1A	W0003	2510Z			31-62-21	ALL
ST..	1A	W0003	2511Z			31-62-21	ALL

GROUND LIST

D280A351

91-21-21

Section GB00300

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GB00521		PARTOFTB0521				E005-02/ /	ALL
ST..	1A	W0521	2502Z			34-61-11	YT101-YT108, YT126-YT129
ST..	1A	W0521	2506Z			34-61-12	ALL
ST..	1A	W0521	2507Z			34-61-12	ALL
ST..	1A	W0521	2576Z			31-62-15	ALL
ST..	1A	W0521	2590Z			31-22-11	ALL
ST..	1A	W0521	2614Z			34-58-11	ALL
ST..	1A	W0523	2512Z			34-61-14	YT104-YT133
ST..	1A	W0523	2702Z			34-61-11	ALL
ST..	1A	W0523	2703Z			34-61-11	ALL
ST..	1A	W0523	2707Z			34-61-14	YT101-YT103
ST..	1A	W0523	2712Z			34-61-14	ALL
ST..	1A	W0523	2713Z			34-61-14	YT101-YT103
ST..	1A	W0523	2716Z			34-61-15	YT104-YT133
ST..	1A	W0523	2717Z			34-61-18	ALL
ST..	1A	W0523	2724Z			34-21-23	ALL
ST..	1A	W0523	2726Z			34-21-23	ALL
ST..	1A	W0523	2727Z			34-21-23	ALL
ST..	1A	W0523	2728Z			34-21-23	ALL
ST..	1A	W0523	2729Z			34-21-23	ALL
ST..	1A	W0523	2730Z			34-21-23	ALL
ST..	1A	W0523	2732Z			34-21-23	ALL
ST..	1A	W0523	2733Z			34-21-23	ALL
ST..	1A	W0523	2734Z			34-21-23	ALL
ST..	1A	W0523	2736Z			34-21-23	ALL
ST..	1A	W0523	2737Z			34-21-23	ALL
ST..	1A	W0523	2739Z			34-21-24	ALL
ST..	1A	W0523	2740Z			34-21-24	ALL
ST..	1A	W0523	2742Z			34-21-24	ALL
ST..	1A	W0523	2743Z			34-21-24	ALL
ST..	1A	W0523	2745Z			34-21-24	ALL
ST..	1A	W0523	2747Z			34-21-24	ALL
ST..	1A	W0523	2749Z			34-21-24	ALL
ST..	1A	W0523	2756Z			31-62-25	ALL
ST..	1A	W0523	2760Z			34-31-21	ALL
ST..	1A	W0523	2772Z			34-21-23	ALL
ST..	1A	W0523	2773Z			34-21-24	ALL
ST..	1A	W0523	2776Z			34-21-24	ALL
ST..	1A	W0523	2784Z			34-58-21	ALL
ST..	1A	W0523	2794Z			34-21-24	ALL
ST..	1A	W0523	2798Z			34-61-15	ALL

GROUND LIST

D280A351

91-21-21

Section GB00500

Page 1

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GB00521		PARTOFTB0521 (continued)				E005-02/ /	ALL
ST..	1A	W0523	2799Z			34-61-15	ALL
ST..	1A	W0523	2802Z			34-61-21	ALL
ST..	1A	W0523	2803Z			34-61-21	ALL
ST..	1A	W0523	2818Z			31-33-01	ALL
ST..	1A	W0523	2820Z			34-21-24	ALL
ST..	1A	W0523	2839Z			34-21-23	ALL
ST..	1A	W0523	2848Z			34-61-15	YT101-YT120
ST..	1A	W0523	2852Z			34-61-14	YT101-YT120
GB00522		PARTOFTB0522				E005-02/ /	ALL
ST..	1A	W0521	2506ZO			34-61-12	ALL
ST..	1A	W0521	2507ZO			34-61-12	ALL
ST..	1A	W0521	2529Z			34-61-15	YT101-YT103
ST..	1A	W0521	2566Z			22-11-51	ALL
ST..	1A	W0521	2569Z			28-41-11	ALL
ST..	1A	W0521	2580Z			34-31-11	ALL
ST..	1A	W0521	2582Z			34-51-11	ALL
ST..	1A	W0521	2585Z			22-31-52	ALL
ST..	1A	W0521	2586Z			22-31-52	ALL
ST..	1A	W0521	2587Z			34-55-11	ALL
ST..	1A	W0521	2588Z			34-55-11	ALL
ST..	1A	W0521	2589Z			34-55-11	ALL
ST..	1A	W0521	2591Z			31-22-11	ALL
ST..	1A	W0521	2597Z			22-31-52	ALL
ST..	1A	W0521	2598Z			31-22-11	ALL
ST..	1A	W0521	2599Z			31-22-11	ALL
ST..	1A	W0521	2608Z			34-58-11	ALL
ST..	1A	W0521	2615Z			34-58-11	ALL
ST..	1A	W0521	2616Z			34-58-11	ALL
ST..	1A	W0521	2624Z			34-61-21	YT101-YT110
ST..	1A	W0521	2625Z			34-61-21	YT101-YT110
ST..	1A	W0521	2648Z			34-61-15	YT101-YT103
ST..	1A	W0521	2649Z			34-61-15	YT101-YT103
ST..	1A	W0521	2693Z			34-61-15	ALL
ST..	1A	W0521	2913Z			34-61-18	ALL
ST..	1A	W0521	2914Z			34-61-18	ALL
ST..	1A	W0521	2915Z			34-61-18	ALL
ST..	1A	W0521	2919Z			34-61-12	ALL
ST..	1A	W0521	2920Z			34-61-12	ALL
ST..	1A	W0521	2939Z			34-61-15	YT101-YT103

GROUND LIST

D280A351

91-21-21

Section GB00500

Page 2

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GB00522		PARTOFTB0522 (continued)				E005-02/ /	ALL
ST..	1A	W0523	2503Z			34-61-15	YT126-YT133
ST..	1A	W0523	2513Z			34-61-15	YT104-YT120
ST..	1A	W0523	2714Z			34-61-15	YT101-YT103
ST..	1A	W0523	2715Z			34-61-15	YT101-YT103
ST..	1A	W0523	2716Z			34-61-15	YT101-YT103
ST..	1A	W0523	2762Z			34-51-21	ALL
ST..	1A	W0523	2764Z			34-55-21	ALL
ST..	1A	W0523	2765Z			34-55-21	ALL
ST..	1A	W0523	2770Z			34-61-15	ALL
ST..	1A	W0523	2771Z			34-55-21	ALL
ST..	1A	W0523	2828Z			31-32-15	YT111-YT133
ST..	1A	W0523	2829Z			31-32-15	YT111-YT133
ST..	1A	W0523	2831Z			34-61-18	ALL
ST..	1A	W0523	2833Z			34-61-26	ALL
ST..	1A	W0523	2835Z			34-61-15	ALL
ST..	1A	W0523	2851Z			34-61-15	YT101-YT103
ST..	1A	W0523	3601Z			34-21-22	ALL
ST..	1A	W0523	3602Z			34-21-22	ALL
ST..	1A	W0523	3603Z			34-21-22	ALL
GB00523		PARTOFTB0523				E005-02/ /	ALL
ST..	1A	W0521	2501Z			34-61-22	ALL
ST..	1A	W0521	2503Z			34-61-11	YT101-YT110, YT126-YT133
ST..	1A	W0521	2505Z			34-61-14	ALL
ST..	1A	W0521	2506Z			34-61-12	ALL
ST..	1A	W0521	2507Z			34-61-12	ALL
ST..	1A	W0521	2509Z			34-61-14	ALL
ST..	1A	W0521	2510Z			34-61-14	ALL
ST..	1A	W0521	2511Z			34-61-14	ALL
ST..	1A	W0521	2512Z			34-61-14	ALL
ST..	1A	W0521	2513Z			34-61-14	ALL
ST..	1A	W0521	2517Z			34-61-22	ALL
ST..	1A	W0521	2518Z			34-61-14	ALL
ST..	1A	W0521	2519Z			34-61-14	ALL
ST..	1A	W0521	2520Z			34-61-14	ALL
ST..	1A	W0521	2521Z			34-61-14	ALL
ST..	1A	W0521	2522Z			34-61-14	ALL
ST..	1A	W0521	2523Z			34-61-15	ALL
ST..	1A	W0521	2524Z			34-61-15	ALL
ST..	1A	W0521	2525Z			34-61-15	ALL

GROUND LIST

D280A351

91-21-21

Section GB00500

Page 3

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GB00523		PARTOFTB0523 (continued)				E005-02/ /	ALL
ST..	1A	W0521	2526Z			34-61-15	ALL
ST..	1A	W0521	2528Z			34-61-14	ALL
ST..	1A	W0521	2530Z			34-61-15	ALL
ST..	1A	W0521	2548Z			34-21-14	ALL
ST..	1A	W0521	2549Z			34-21-14	ALL
ST..	1A	W0521	2550Z			34-21-14	ALL
ST..	1A	W0521	2551Z			34-21-14	ALL
ST..	1A	W0521	2554Z			34-21-14	YT101-YT103
ST..	1A	W0521	2556Z			34-21-14	ALL
ST..	1A	W0521	2557Z			34-21-14	ALL
ST..	1A	W0521	2558Z			34-21-14	ALL
ST..	1A	W0521	2559Z			34-21-14	ALL
ST..	1A	W0521	2575Z			31-62-15	ALL
ST..	1A	W0521	2579Z			34-31-11	ALL
ST..	1A	W0521	2581Z			34-51-11	ALL
ST..	1A	W0521	2591Z			31-22-11	ALL
ST..	1A	W0521	2592Z			34-61-22	ALL
ST..	1A	W0521	2593Z			34-61-14	ALL
ST..	1A	W0521	2594Z			34-61-14	ALL
ST..	1A	W0521	2595Z			34-61-15	ALL
ST..	1A	W0521	2600Z			34-21-14	ALL
ST..	1A	W0521	2602Z			34-61-15	YT107-YT133
ST..	1A	W0521	2604Z			34-21-14	ALL
ST..	1A	W0521	2640Z			34-61-22	ALL
ST..	1A	W0521	2647Z			34-61-14	ALL
ST..	1A	W0521	2650Z			34-61-15	YT107-YT133
ST..	1A	W0521	2677Z			34-21-14	ALL
ST..	1A	W0521	2716Z			34-21-14	YT104-YT133
ST..	1A	W0521	FRDA			34-61-11	YT111-YT120
ST..	1A	W0523	2755Z			31-62-25	ALL
ST..	1A	W0523	2764Z			34-55-21	ALL
GB00524		PARTOFTB0524				E005-02/ /	ALL
ST..	1A	W0521	2504Z			34-61-11	YT101-YT110, YT126-YT133
ST..	1A	W0521	2506ZO			34-61-12	ALL
ST..	1A	W0521	2507ZO			34-61-12	ALL
ST..	1A	W0521	2527Z			34-61-18	ALL
ST..	1A	W0521	2529Z			34-61-15	ALL
ST..	1A	W0521	2533Z			34-21-13	ALL
ST..	1A	W0521	2535Z			34-21-13	ALL

GROUND LIST

D280A351

91-21-21

Section GB00500

Page 4

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GB00524		PARTOFTB0524 (continued)				E005-02/ /	ALL
ST..	1A	W0521	2536Z			34-21-13	YT111-YT133
ST..	1A	W0521	2537Z			34-21-13	ALL
ST..	1A	W0521	2538Z			34-21-13	ALL
ST..	1A	W0521	2544Z			34-21-13	ALL
ST..	1A	W0521	2545Z			34-21-13	ALL
ST..	1A	W0521	2546Z			34-21-13	ALL
ST..	1A	W0521	2547Z			34-21-13	ALL
ST..	1A	W0521	2567Z			22-11-51	ALL
ST..	1A	W0521	2569Z			28-41-11	ALL
ST..	1A	W0521	2570Z			28-41-11	ALL
ST..	1A	W0521	2571Z			28-41-11	ALL
ST..	1A	W0521	2611Z			34-58-11	ALL
ST..	1A	W0521	2615Z			34-58-11	ALL
ST..	1A	W0521	2666Z			31-33-01	ALL
ST..	1A	W0521	2679Z			34-21-13	YT111-YT133
ST..	1A	W0521	2680Z			34-21-13	ALL
ST..	1A	W0521	2919Z			34-61-12	ALL
ST..	1A	W0521	2920Z			34-61-12	ALL
ST..	1A	W0521	3501Z			34-21-12	ALL
ST..	1A	W0521	3502Z			34-21-12	ALL
ST..	1A	W0521	3503Z			34-21-12	ALL
ST..	1A	W0521	FRDD			34-61-21	YT111-YT133
ST..	1A	W0523	2701Z			34-61-11	ALL
ST..	1A	W0523	2705Z			34-61-14	ALL
ST..	1A	W0523	2706Z			34-61-14	ALL
ST..	1A	W0523	2709Z			34-61-14	ALL
ST..	1A	W0523	2710Z			34-61-14	ALL
ST..	1A	W0523	2711Z			34-61-14	ALL
ST..	1A	W0523	2718Z			34-61-14	ALL
ST..	1A	W0523	2759Z			34-31-21	ALL
ST..	1A	W0523	2761Z			34-51-21	ALL
ST..	1A	W0523	2766Z			34-61-11	ALL
ST..	1A	W0523	2767Z			34-61-11	ALL
ST..	1A	W0523	2768Z			34-61-14	ALL
ST..	1A	W0523	2769Z			34-61-14	ALL
ST..	1A	W0523	2786Z			34-61-14	ALL
ST..	1A	W0523	2787Z			34-58-21	ALL
ST..	1A	W0523	2795Z			34-61-14	ALL
ST..	1A	W0523	2796Z			34-61-21	ALL
ST..	1A	W0523	2832Z			34-61-26	ALL

GROUND LIST

D280A351

91-21-21

Section GB00500

Page 5

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GB00524		PARTOFTB0524 (continued)				E005-02/ /	ALL
ST..	1A	W0523	2840Z			34-61-14	ALL
ST..	1A	W0523	2843Z			34-61-14	YT101-YT120

GROUND LIST

D280A351

91-21-21

Section GB00500

Page 6 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GB00606		PARTOFTB0606				270/176/R027	ALL
ST..	1A	W2216	1301Z			73-21-12	ALL
ST..	1A	W5158	2601Z			78-32-61	ALL
ST..	1A	W5158	2602Z			78-32-61	ALL
ST..	1A	W6162	1301Z			73-21-12	ALL
ST..	1A	W6172	1301Z			73-21-12	ALL
ST..	1A	W6172	2601Z			78-32-61	ALL
ST..	1A	W6172	2602Z			78-32-61	ALL
GB00608		PARTOFTB0608				268/175/R028	ALL
GB00610		PARTOFTB0610				P006-00/ /	ALL
ST..	1A	W0041	2504Z			31-32-15	ALL
ST..	1A	W0041	2533Z			31-32-15	ALL
ST..	1A	W0041	2534Z			31-32-15	ALL
ST..	1A	W0044	2011Z			23-42-14	ALL
GB00621		PARTOFTB0621				E006-02/ /	ALL
ST..	1A	W0621	2020ZO			23-22-11	ALL
ST..	1A	W0621	2034Z			23-11-16	ALL
ST..	1A	W0621	2035Z			23-11-16	ALL
ST..	1A	W0621	2036Z			23-11-16	ALL
ST..	1A	W0621	2037Z			23-11-26	ALL
ST..	1A	W0621	2038Z			23-11-26	ALL
ST..	1A	W0621	2039Z			23-11-26	ALL
ST..	1A	W0621	2041Z			23-11-16	YT101-YT105
ST..	1A	W0621	2042Z			23-11-26	YT101-YT105
ST..	1A	W0621	2501ZO			23-11-11	ALL
ST..	1A	W0621	2502ZO			23-11-11	ALL
ST..	1A	W0621	2506Z			23-11-11	ALL
ST..	1A	W0621	2508Z			23-12-41	ALL
ST..	1A	W0621	2509Z			23-12-41	ALL
ST..	1A	W0621	2510Z			23-12-41	ALL
ST..	1A	W0621	2511Z			23-12-41	ALL
ST..	1A	W0621	2512Z			34-61-14	ALL
ST..	1A	W0621	2514Z			34-61-15	ALL
ST..	1A	W0621	2519Z			23-12-41	ALL
ST..	1A	W0621	2521Z			23-27-36	ALL
ST..	1A	W0621	2523Z			23-27-36	ALL
ST..	1A	W0621	2526Z			23-27-36	ALL
ST..	1A	W0621	2528Z			23-27-36	ALL

GROUND LIST

D280A351

91-21-21

Section GB00600

Page 1

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GB00621		PARTOFTB0621 (continued)				E006-02/ /	ALL
ST..	1A	W0621	2529Z			23-12-41	ALL
GB00660		PARTOFTB0660				/ /	ALL
GB00662		PARTOFTB0662				/ /	ALL
GB00664		PARTOFTB0664				/ /	ALL
GB00666		PARTOFTB0666				/ /	ALL

GROUND LIST

D280A351

91-21-21

Section GB00600

Page 2 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	Ground No.	Type	Part Number		Wire No.	GA	CO	Station / WL / BL	Effectivity
	Term		Bundle					Diagram	
I	GB00801		PARTOFTB0801					J38/ /	ALL
I	ST..	1A	W5506	2201Z				24-22-11	ALL
I	ST..	1A	W5510	2201Z				24-22-11	ALL
I	GB00803		PARTOFTB0803					*/*/*	ALL
I	GB00804		PARTOFTB0804					*/*/*	ALL

GROUND LIST

D280A351

91-21-21

Section GB00800

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
I GB01092		PARTOFTB1092				P001-01/ /	ALL

GROUND LIST

D280A351

91-21-21

Section GB01000

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GB01101		PARTOFTB1101				E001-01/ /	ALL
ST..	1A	W0111	2003Z			34-33-21	ALL
ST..	1A	W0111	2004Z			34-33-21	ALL
ST..	1A	W0111	2005Z			34-33-21	ALL
GB01102		PARTOFTB1102				E001-01/ /	ALL
ST..	1A	W0111	1032Z			27-25-11	ALL
ST..	1A	W0111	1033Z			27-25-11	ALL
ST..	1A	W0111	1035Z			27-25-11	ALL
ST..	1A	W0111	1036Z			27-25-11	ALL
GB01103		PARTOFTB1103				E001-01/ /	ALL
ST..	1A	W0111	2058Z			34-45-11	ALL
ST..	1A	W0111	2070Z			34-45-21	ALL
ST..	1A	W0111	2071Z			34-45-21	ALL
ST..	1A	W0111	2072Z			34-45-21	ALL
ST..	1A	W0111	2073Z			34-45-21	ALL
ST..	1A	W0111	2103Z			34-21-13	YT101-YT120
ST..	1A	W0111	2108Z			34-21-14	YT101-YT120
ST..	1A	W0111	2128Z			31-62-15	YT101-YT120
ST..	1A	W0111	2175ZO			34-45-21	ALL
ST..	1A	W0111	2209Z			34-58-11	YT101-YT120
ST..	1A	W0111	2274Z			34-21-13	YT101-YT120
ST..	1A	W0111	2275Z			34-21-14	YT101-YT120
ST..	1A	W0111	2278Z			34-21-13	YT101-YT120
ST..	1A	W0111	2279Z			34-21-14	YT101-YT120
ST..	1A	W0111	2280Z			34-58-11	YT101-YT120
ST..	1A	W0111	2281Z			34-58-11	YT101-YT120
ST..	1A	W0111	2285Z			31-62-15	YT101-YT120
ST..	1A	W0111	2286Z			31-62-15	YT101-YT120
GB01104		PARTOFTB1104				E001-01/ /	ALL
ST..	1A	W0111	1014Z			22-12-31	ALL
ST..	1A	W0111	1038Z			22-11-81	ALL
ST..	1A	W0111	2002Z			34-33-21	ALL
ST..	1A	W0111	2030Z			22-11-51	ALL
ST..	1A	W0111	2031Z			22-11-51	ALL
ST..	1A	W0111	2037Z			22-12-31	ALL
ST..	1A	W0111	2038Z			22-12-31	ALL
ST..	1A	W0111	2039Z			22-12-31	ALL
ST..	1A	W0111	2042Z			22-18-11	ALL

GROUND LIST

D280A351

91-21-21

Section GB01100

Page 1

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GB01104		PARTOFTB1104 (continued)				E001-01/ /	ALL
ST..	1A	W0111	2078Z			34-55-11	ALL
ST..	1A	W0111	2088Z			22-31-52	ALL
ST..	1A	W0111	2089Z			22-31-52	ALL
ST..	1A	W0111	2090Z			22-31-52	ALL
ST..	1A	W0111	2091Z			22-31-52	ALL
ST..	1A	W0111	2092Z			22-31-52	ALL
ST..	1A	W0111	2093Z			22-31-52	ALL
ST..	1A	W0111	2094Z			22-31-52	ALL
ST..	1A	W0111	2103Z			34-21-13	YT126-YT133
ST..	1A	W0111	2108Z			34-21-14	YT126-YT133
ST..	1A	W0111	2122Z			34-31-11	ALL
ST..	1A	W0111	2124Z			34-31-21	ALL
ST..	1A	W0111	2126Z			34-51-11	ALL
ST..	1A	W0111	2128Z			31-62-15	ALL
ST..	1A	W0111	2130Z			31-62-25	ALL
ST..	1A	W0111	2174Z			22-31-52	ALL
ST..	1A	W0111	2219Z			22-11-53	ALL
ST..	1A	W0111	2221Z			31-32-15	ALL
ST..	1A	W0111	2225Z			22-11-81	ALL
ST..	1A	W0111	2226Z			22-11-81	ALL
ST..	1A	W0111	2229Z			22-12-31	ALL
ST..	1A	W0111	3004Z			22-12-31	ALL
ST..	1A	W0111	3010Z			22-11-81	ALL
GB01105		PARTOFTB1105				E001-01/ /	ALL
ST..	1A	W0111	1021Z			22-11-31	ALL
ST..	1A	W0111	1037Z			22-11-81	ALL
ST..	1A	W0111	2006Z			22-11-31	ALL
ST..	1A	W0111	2007Z			22-11-31	ALL
ST..	1A	W0111	2012Z			22-11-31	ALL
ST..	1A	W0111	2013Z			22-11-31	ALL
ST..	1A	W0111	2032Z			22-11-51	ALL
ST..	1A	W0111	2033Z			22-11-51	ALL
ST..	1A	W0111	2060Z			22-11-51	ALL
ST..	1A	W0111	2084Z			22-31-31	ALL
ST..	1A	W0111	2085Z			22-31-41	ALL
ST..	1A	W0111	2086Z			22-31-41	ALL
ST..	1A	W0111	2087Z			22-31-41	ALL
ST..	1A	W0111	2116Z			34-21-24	ALL
ST..	1A	W0111	2133Z			73-24-11	ALL

GROUND LIST

D280A351

91-21-21

Section GB01100

Page 2

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GB01105		PARTOFTB1105 (continued)				E001-01/ /	ALL
ST..	1A	W0111	2134Z			73-24-11	ALL
ST..	1A	W0111	2135Z			73-24-21	ALL
ST..	1A	W0111	2136Z			73-24-21	ALL
ST..	1A	W0111	2220Z			31-32-15	ALL
ST..	1A	W0111	2221Z			31-32-15	ALL
ST..	1A	W0111	2222Z			31-32-15	ALL
ST..	1A	W0111	2223Z			22-11-81	ALL
ST..	1A	W0111	2224Z			22-11-81	ALL
ST..	1A	W0111	2290Z			31-32-15	YT105-YT133
ST..	1A	W0111	2333Z			22-11-51	ALL
ST..	1A	W0111	3001Z			22-11-31	ALL
ST..	1A	W0111	3002Z			22-11-31	ALL
ST..	1A	W0111	3003Z			22-12-31	ALL
GB01106		PARTOFTB1106				E001-01/ /	ALL
ST..	1A	W0111	1017Z			22-11-31	ALL
ST..	1A	W0111	1018Z			22-11-31	ALL
ST..	1A	W0111	1019Z			22-11-31	ALL
ST..	1A	W0111	2015Z			22-11-51	ALL
ST..	1A	W0111	2016Z			22-11-51	ALL
ST..	1A	W0111	2017Z			22-11-51	ALL
ST..	1A	W0111	2018Z			22-11-51	ALL
ST..	1A	W0111	2019Z			22-11-51	ALL
ST..	1A	W0111	2055Z			34-33-11	ALL
ST..	1A	W0111	2056Z			34-33-11	ALL
ST..	1A	W0111	2057Z			34-33-11	ALL
ST..	1A	W0111	2067Z			34-45-11	ALL
ST..	1A	W0111	2068Z			34-45-11	ALL
ST..	1A	W0111	2069Z			34-45-11	ALL
ST..	1A	W0111	2172Z			34-45-11	ALL
ST..	1A	W0111	2173Z			22-11-51	ALL
GB01107		PARTOFTB1107				E001-01/ /	ALL
ST..	1A	W0111	1012Z			22-12-31	ALL
ST..	1A	W0111	1013Z			22-12-31	ALL
ST..	1A	W0111	1015Z			22-12-31	ALL
ST..	1A	W0111	2008Z			22-11-31	ALL
ST..	1A	W0111	2009Z			22-11-31	ALL
ST..	1A	W0111	2010Z			22-11-31	ALL
ST..	1A	W0111	2011Z			22-11-31	ALL

GROUND LIST

D280A351

91-21-21

Section GB01100

Page 3

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GB01107		PARTOFTB1107 (continued)				E001-01/ /	ALL
ST..	1A	W0111	2042Z			22-18-11	ALL
ST..	1A	W0111	2043Z			22-18-11	ALL
ST..	1A	W0111	2044Z			22-18-11	ALL
GB01108		PARTOFTB1108				E001-01/ /	ALL
ST..	1A	W0111	2064Z			34-33-11	ALL
ST..	1A	W0111	2065Z			34-33-11	ALL
ST..	1A	W0111	2066Z			34-33-11	ALL
ST..	1A	W0111	2075Z			34-49-11	ALL
ST..	1A	W0111	2076Z			34-49-11	ALL
ST..	1A	W0111	2077Z			34-49-11	ALL
ST..	1A	W0111	2216Z			34-49-11	ALL
GB01109		PARTOFTB1109				E001-01/ /	ALL
ST..	1A	W0111	2051Z			27-32-12	ALL
ST..	1A	W0111	2053Z			27-32-12	ALL
ST..	1A	W0111	2054Z			27-32-12	ALL
ST..	1A	W0111	2079Z			22-31-31	ALL
ST..	1A	W0111	2080Z			22-31-31	ALL
ST..	1A	W0111	2081Z			22-31-41	ALL
ST..	1A	W0111	2111Z			34-21-23	ALL
ST..	1A	W0111	2113Z			34-21-23	ALL
ST..	1A	W0111	2114Z			34-21-23	ALL
ST..	1A	W0111	2115Z			34-21-23	ALL
ST..	1A	W0111	2207Z			34-21-23	ALL
GB01110		PARTOFTB1110				E001-01/ /	ALL
ST..	1A	W0111	2020Z			22-11-51	ALL
ST..	1A	W0111	2021Z			22-11-51	ALL
ST..	1A	W0111	2022Z			22-11-51	ALL
ST..	1A	W0111	2023Z			22-11-51	ALL
ST..	1A	W0111	2024Z			22-11-51	ALL
ST..	1A	W0111	2025Z			22-11-51	ALL
ST..	1A	W0111	2026Z			22-11-51	ALL
ST..	1A	W0111	2028Z			22-11-51	ALL
ST..	1A	W0111	2029Z			22-11-51	ALL
ST..	1A	W0111	2045Z			22-11-51	ALL
ST..	1A	W0111	2046Z			22-11-51	ALL
ST..	1A	W0111	2059Z			22-11-51	ALL
ST..	1A	W0111	2095Z			34-21-13	ALL

GROUND LIST

D280A351

91-21-21

Section GB01100

Page 4

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GB01110		PARTOFTB1110 (continued)				E001-01/ /	ALL
ST..	1A	W0111	2097Z			34-21-13	ALL
ST..	1A	W0111	2098Z			34-21-13	ALL
ST..	1A	W0111	2099Z			34-21-13	ALL
ST..	1A	W0111	2101Z			34-21-13	ALL
ST..	1A	W0111	2102Z			34-21-13	ALL
ST..	1A	W0111	2104Z			34-21-14	ALL
ST..	1A	W0111	2105Z			34-21-14	ALL
ST..	1A	W0111	2106Z			34-21-14	ALL
ST..	1A	W0111	2107Z			34-21-14	ALL
ST..	1A	W0111	2171Z			22-11-51	ALL
ST..	1A	W0111	2230Z			22-11-51	ALL
ST..	1A	W0111	2287Z			22-11-51	YT104-YT133
GB01111		PARTOFTB1111				E001-01/ /	ALL
ST..	1A	W0111	2241Z			21-31-24	ALL
ST..	1A	W0111	2242Z			21-31-24	ALL
ST..	1A	W0111	2243Z			21-31-24	ALL
ST..	1A	W0111	2244Z			21-31-24	ALL
ST..	1A	W0111	2245Z			21-31-24	ALL
ST..	1A	W0111	2246Z			21-31-24	ALL
ST..	1A	W0111	2247Z			21-31-24	ALL
ST..	1A	W0111	2248Z			21-31-24	ALL
ST..	1A	W0111	2253Z			27-32-22	ALL
ST..	1A	W0111	2254Z			27-32-12	ALL
ST..	1A	W0111	2255Z			34-21-14	ALL
ST..	1A	W0111	2256Z			34-21-24	ALL

GROUND LIST

D280A351

91-21-21

Section GB01100

Page 5 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GB01201		PARTOFTB1201				E001-02/ /	ALL
ST..	1A	W0121	2014Z			34-31-11	ALL
ST..	1A	W0121	2015Z			34-31-11	ALL
ST..	1A	W0121	2016Z			34-31-11	ALL
ST..	1A	W0121	2017Z			34-31-11	ALL
ST..	1A	W0121	2018Z			34-31-11	ALL
ST..	1A	W0121	2020Z			34-31-11	ALL
ST..	1A	W0121	2021Z			34-31-11	ALL
ST..	1A	W0121	2023Z			34-51-11	ALL
ST..	1A	W0121	2024Z			34-51-11	ALL
ST..	1A	W0121	2025Z			34-51-11	ALL
ST..	1A	W0121	2026Z			34-51-11	ALL
ST..	1A	W0121	2028Z			34-51-11	ALL
ST..	1A	W0121	2029Z			34-51-11	ALL
ST..	1A	W0121	2030Z			34-51-11	ALL
ST..	1A	W0121	2031Z			34-51-11	ALL
ST..	1A	W0121	2032Z			34-51-11	ALL
ST..	1A	W0121	2036Z			34-31-11	ALL
ST..	1A	W0121	2037Z			34-31-11	ALL
ST..	1A	W0121	2038Z			34-31-11	ALL
ST..	1A	W0121	2049Z			34-31-11	ALL
ST..	1A	W0121	2050Z			34-51-11	ALL
ST..	1A	W0121	2057Z			34-58-11	ALL
ST..	1A	W0121	2059Z			34-58-11	YT101-YT103
ST..	1A	W0121	2060Z			34-58-11	ALL
ST..	1A	W0121	2061Z			34-58-11	ALL
ST..	1A	W0121	2065Z			34-58-11	YT101-YT103
ST..	1A	W0121	2066Z			34-58-11	YT101-YT103
ST..	1A	W0121	2085Z			34-31-11	ALL
ST..	1A	W0121	2086Z			34-31-11	ALL
ST..	1A	W0121	2515Z			34-53-11	YT101-YT103
GB01202		PARTOFTB1202				E001-02/ /	ALL
ST..	1A	W0121	2001Z			34-53-11	ALL
ST..	1A	W0121	2004Z			34-45-21	ALL
ST..	1A	W0121	2005Z			34-45-21	ALL
ST..	1A	W0121	2022Z			34-53-11	YT104-YT133
ST..	1A	W0121	2035Z			34-21-14	ALL
ST..	1A	W0121	2042Z			34-58-11	YT104-YT133
ST..	1A	W0121	2043Z			34-58-11	YT104-YT133
ST..	1A	W0121	2044Z			34-21-24	ALL

GROUND LIST

D280A351

91-21-21

Section GB01200

Page 1

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GB01202		PARTOFTB1202 (continued)				E001-02/ /	ALL
ST..	1A	W0121	2059Z			34-58-11	YT104-YT133
ST..	1A	W0121	2062Z			34-45-21	ALL
ST..	1A	W0121	2064Z			34-45-21	ALL
ST..	1A	W0121	2065Z			34-58-11	YT104-YT133
ST..	1A	W0121	2066Z			34-58-11	YT104-YT133
ST..	1A	W0121	2500Z			34-53-11	YT104-YT133
ST..	1A	W0121	2510Z			22-11-51	ALL
ST..	1A	W0121	2511Z			34-21-13	ALL
ST..	1A	W0121	2514Z			34-61-14	ALL
ST..	1A	W0121	2515Z			34-53-11	ALL
ST..	1A	W0121	2516Z			31-31-13	ALL
GB01203		PARTOFTB1203				E001-02/ /	ALL
GB01204		PARTOFTB1204				E001-02/ /	ALL
ST..	1A	W0121	2006Z			34-55-11	ALL
ST..	1A	W0121	2007Z			34-55-11	ALL
ST..	1A	W0121	2008Z			34-55-11	ALL
ST..	1A	W0121	2009ZO			34-55-11	ALL
ST..	1A	W0121	2010Z			34-55-11	ALL
ST..	1A	W0121	2011Z			34-55-11	ALL
ST..	1A	W0121	2012Z			34-55-11	ALL
ST..	1A	W0121	2013Z			34-55-11	ALL
ST..	1A	W0121	2025Z			34-51-11	ALL
ST..	1A	W0121	2034Z			34-55-11	ALL
ST..	1A	W0121	2045Z			34-61-14	ALL
ST..	1A	W0121	2048Z			34-55-11	ALL
ST..	1A	W0121	2514Z			34-61-14	ALL

GROUND LIST

D280A351

91-21-21

Section GB01200

Page 2 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GB01301		PARTOFTB1301				E001-03/ /	ALL
ST..	1A	W0131	2501Z			23-12-41	ALL
ST..	1A	W0131	2502ZO			23-12-11	ALL
ST..	1A	W0131	2503ZO			23-12-11	ALL
ST..	1A	W0131	2504ZO			23-22-11	ALL
ST..	1A	W0131	2519Z			23-12-41	ALL
ST..	1A	W0131	2525Z			23-12-11	ALL
GB01303		PARTOFTB1303				E001-03/ /	ALL
ST..	1A	W0131	2508Z			34-21-13	ALL
ST..	1A	W0131	2509Z			34-21-23	ALL
ST..	1A	W0131	2510Z			32-41-11	ALL
ST..	1A	W0131	2511Z			32-41-11	ALL
ST..	1A	W0131	2512Z			32-41-11	ALL
ST..	1A	W0131	2513Z			32-41-11	ALL
ST..	1A	W0131	2514Z			32-42-11	ALL

GROUND LIST

D280A351

91-21-21

Section GB01300

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GB01401		PARTOFTB1401				E001-04/ /	ALL
ST..	1A	W0141	0066Z			22-11-31	ALL
ST..	1A	W0141	0067Z			22-11-31	ALL
ST..	1A	W0141	0068Z			22-11-31	ALL
ST..	1A	W0141	0089Z			22-12-41	ALL
ST..	1A	W0141	0090Z			22-12-41	ALL
ST..	1A	W0141	0091Z			22-12-41	ALL
ST..	1A	W0141	0092Z			22-12-41	ALL
ST..	1A	W0141	1012Z			22-11-11	ALL
ST..	1A	W0141	1014Z			22-11-81	ALL
ST..	1A	W0141	2010Z			22-11-31	ALL
ST..	1A	W0141	2012Z			22-11-31	ALL
ST..	1A	W0141	2013Z			22-11-31	ALL
ST..	1A	W0141	2014Z			22-11-31	ALL
ST..	1A	W0141	2017Z			22-11-51	YT101-YT103
ST..	1A	W0141	2018Z			22-11-51	YT101-YT103
ST..	1A	W0141	2019Z			22-11-51	YT101-YT103
ST..	1A	W0141	2024Z			22-11-51	YT101-YT103
ST..	1A	W0141	2027Z			22-11-51	ALL
ST..	1A	W0141	2028Z			22-11-51	ALL
ST..	1A	W0141	2033Z			22-12-41	ALL
ST..	1A	W0141	2034Z			22-12-41	ALL
ST..	1A	W0141	2035Z			22-12-41	ALL
ST..	1A	W0141	2036Z			22-12-41	ALL
ST..	1A	W0141	2054Z			22-11-81	ALL
ST..	1A	W0141	2057Z			34-21-14	ALL
ST..	1A	W0141	2152Z			34-55-21	ALL
ST..	1A	W0141	2301Z			34-31-11	ALL
ST..	1A	W0141	2362Z			31-62-15	ALL
ST..	1A	W0141	3004Z			22-12-41	ALL
ST..	1A	W0141	3005Z			22-12-41	ALL
ST..	1A	W0141	3006Z			22-11-81	ALL
GB01402		PARTOFTB1402				E001-04/ /	ALL
ST..	1A	W0141	0065Z			22-11-31	ALL
ST..	1A	W0141	0066Z			22-11-31	ALL
ST..	1A	W0141	1011Z			22-11-11	ALL
ST..	1A	W0141	1013Z			22-11-81	ALL
ST..	1A	W0141	2001Z			22-11-11	ALL
ST..	1A	W0141	2008Z			22-11-31	ALL
ST..	1A	W0141	2009Z			22-11-31	ALL

GROUND LIST

D280A351

91-21-21

Section GB01400

Page 1

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GB01402		PARTOFTB1402 (continued)				E001-04/ /	ALL
ST..	1A	W0141	2010Z			22-11-31	ALL
ST..	1A	W0141	2011Z			22-11-31	ALL
ST..	1A	W0141	2015Z			22-11-31	ALL
ST..	1A	W0141	2016Z			22-11-51	ALL
ST..	1A	W0141	2020Z			22-11-51	ALL
ST..	1A	W0141	2021Z			22-11-51	ALL
ST..	1A	W0141	2022Z			22-11-51	ALL
ST..	1A	W0141	2023Z			22-11-51	ALL
ST..	1A	W0141	2025Z			22-11-51	ALL
ST..	1A	W0141	2026Z			22-11-51	ALL
ST..	1A	W0141	2034Z			22-12-41	ALL
ST..	1A	W0141	2039Z			27-32-22	ALL
ST..	1A	W0141	2048Z			31-32-15	ALL
ST..	1A	W0141	2049Z			31-32-15	ALL
ST..	1A	W0141	2050Z			31-32-15	ALL
ST..	1A	W0141	2051Z			22-11-53	ALL
ST..	1A	W0141	2053Z			22-11-81	ALL
ST..	1A	W0141	2055Z			22-11-81	ALL
ST..	1A	W0141	2056Z			22-11-81	ALL
ST..	1A	W0141	2058Z			34-33-11	ALL
ST..	1A	W0141	2059Z			22-12-41	ALL
ST..	1A	W0141	2060Z			22-11-51	ALL
ST..	1A	W0141	2070Z			34-21-23	YT101-YT120
ST..	1A	W0141	2071Z			34-21-23	YT101-YT120
ST..	1A	W0141	2072Z			34-21-24	YT101-YT120
ST..	1A	W0141	2073Z			34-21-24	YT101-YT120
ST..	1A	W0141	2078Z			31-62-25	YT101-YT120
ST..	1A	W0141	2079Z			31-62-25	YT101-YT120
ST..	1A	W0141	2101Z			22-31-52	ALL
ST..	1A	W0141	2102Z			34-21-13	ALL
ST..	1A	W0141	2103Z			34-21-23	YT101-YT120
ST..	1A	W0141	2104Z			34-21-24	ALL
ST..	1A	W0141	2304Z			34-31-21	ALL
ST..	1A	W0141	2318Z			34-51-21	ALL
ST..	1A	W0141	2351Z			22-11-51	ALL
ST..	1A	W0141	2363Z			31-62-25	ALL
ST..	1A	W0141	3001Z			22-11-31	ALL
ST..	1A	W0141	3002Z			22-11-31	ALL
ST..	1A	W0141	3003Z			22-12-41	ALL

GROUND LIST

D280A351

91-21-21

Section GB01400

Page 2

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GB01403		PARTOFTB1403				E001-04/ /	ALL
ST..	1A	W0141	2041Z			34-58-21	YT101-YT103
ST..	1A	W0141	2043Z			34-58-21	YT101-YT103
ST..	1A	W0141	2044Z			34-58-21	YT101-YT103
ST..	1A	W0141	2063Z			34-58-21	YT101-YT103
ST..	1A	W0141	2080Z			34-58-21	YT101-YT103
ST..	1A	W0141	2304Z			34-31-21	ALL
ST..	1A	W0141	2305Z			34-31-21	ALL
ST..	1A	W0141	2306Z			34-31-21	ALL
ST..	1A	W0141	2307Z			34-31-21	ALL
ST..	1A	W0141	2308Z			34-31-21	ALL
ST..	1A	W0141	2309Z			34-31-21	ALL
ST..	1A	W0141	2310Z			34-31-21	ALL
ST..	1A	W0141	2311Z			34-31-21	ALL
ST..	1A	W0141	2312Z			34-31-21	ALL
ST..	1A	W0141	2313Z			34-31-21	ALL
ST..	1A	W0141	2314Z			34-51-21	ALL
ST..	1A	W0141	2315Z			34-51-21	ALL
ST..	1A	W0141	2316Z			34-51-21	ALL
ST..	1A	W0141	2318Z			34-51-21	ALL
ST..	1A	W0141	2319Z			34-51-21	ALL
ST..	1A	W0141	2321Z			34-51-21	ALL
ST..	1A	W0141	2322Z			34-51-21	ALL
ST..	1A	W0141	2323Z			34-51-21	ALL
ST..	1A	W0141	2324Z			34-51-21	ALL
ST..	1A	W0141	2325Z			34-51-21	ALL
ST..	1A	W0141	2352Z			34-31-21	ALL
ST..	1A	W0141	2353Z			34-51-21	ALL
GB01404		PARTOFTB1404				E001-04/ /	ALL
ST..	1A	W0141	2017Z			22-11-51	YT104-YT133
ST..	1A	W0141	2018Z			22-11-51	YT104-YT133
ST..	1A	W0141	2019Z			22-11-51	YT104-YT133
ST..	1A	W0141	2024Z			22-11-51	YT104-YT133
ST..	1A	W0141	2041Z			34-58-21	YT104-YT133
ST..	1A	W0141	2043Z			34-58-21	YT104-YT133
ST..	1A	W0141	2044Z			34-58-21	YT104-YT133
ST..	1A	W0141	2063Z			34-58-21	YT104-YT133
ST..	1A	W0141	2074Z			22-11-51	YT104-YT133
ST..	1A	W0141	2080Z			34-58-21	YT104-YT120
ST..	1A	W0141	2083Z			34-58-21	YT104-YT133

GROUND LIST

D280A351

91-21-21

Section GB01400

Page 3

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GB01404		PARTOFTB1404 (continued)				E001-04/ /	ALL
ST..	1A	W0141	2317ZO			34-51-21	ALL

GROUND LIST

D280A351

91-21-21

Section GB01400

Page 4 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GB01501		PARTOFTB1501				E005-01/ /	ALL
ST..	1A	W0151	2006Z			34-55-21	ALL
ST..	1A	W0151	2007Z			34-55-21	ALL
ST..	1A	W0151	2008Z			34-55-21	ALL
ST..	1A	W0151	2009ZO			34-55-21	ALL
ST..	1A	W0151	2011Z			34-55-21	ALL
ST..	1A	W0151	2012Z			34-55-21	ALL
ST..	1A	W0151	2013Z			34-55-21	ALL
ST..	1A	W0151	2014Z			34-51-21	ALL
ST..	1A	W0151	2015Z			34-55-21	ALL
ST..	1A	W0151	2020Z			34-61-14	ALL
ST..	1A	W0151	2049Z			34-55-21	ALL
ST..	1A	W0151	2051Z			34-55-21	ALL
ST..	1A	W0151	2058Z			34-61-14	ALL
GB01502		PARTOFTB1501				E005-02/ /	ALL
GB01503		PARTOFTB1501				E005-02/ /	ALL
GB01504		PARTOFTB1501				E005-01/ /	ALL
ST..	1A	W0151	2001Z			34-53-21	ALL
ST..	1A	W0151	2002Z			34-21-23	ALL
ST..	1A	W0151	2004Z			34-45-21	ALL
ST..	1A	W0151	2005Z			34-45-21	ALL
ST..	1A	W0151	2016Z			34-21-14	ALL
ST..	1A	W0151	2017Z			34-21-24	ALL
ST..	1A	W0151	2018Z			34-21-24	ALL
ST..	1A	W0151	2019Z			34-21-24	ALL
ST..	1A	W0151	2023Z			34-45-21	ALL
ST..	1A	W0151	2024Z			34-45-21	ALL
ST..	1A	W0151	2056Z			22-11-51	ALL
ST..	1A	W0151	2058Z			34-61-14	ALL
ST..	1A	W0151	2059Z			34-53-21	ALL
ST..	1A	W0151	2062Z			34-53-21	YT104-YT133

GROUND LIST

D280A351

91-21-21

Section GB01500

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
I GB01806		PARTOFTB1806				261/ /	ALL
I ST..	1A	W2207	2011Z			28-41-11	ALL
I ST..	1A	W2207	2012Z			28-41-11	ALL
I ST..	1A	W2363	1026Z			33-18-51	ALL
I ST..	1A	W5558	2604Z			28-41-11	YT110-YT120, YT130-YT133
I ST..	1A	W5562	2601Z			28-41-11	YT101-YT109, YT126-YT129
I ST..	1A	W5580	2601Z			28-41-11	YT101-YT109, YT126-YT129
I ST..	1A	W6578	2601Z			28-41-11	YT110-YT120, YT130-YT133
I GB01808		PARTOFTB1808				261/172/L025	ALL
I ST..	1A	W3323	2504ZO			34-41-11	ALL
I ST..	1A	W5172	2601Z			78-32-51	ALL
I ST..	1A	W5172	2602Z			78-32-51	ALL
I ST..	1A	W5510	2601Z			78-32-51	ALL
I ST..	1A	W5510	2602Z			78-32-51	ALL
I ST..	1A	W6491	2201ZO			34-41-11	ALL
I GB01882		PARTOFTB1882				XXX XXX/ /	ALL
I ST..	1A	W0088	1001Z			73-21-12	ALL
I ST..	1A	W0088	1002Z			73-21-12	ALL
I ST..	1A	W0088	1003Z			73-21-12	ALL
I GB01884		PARTOFTB1884				/ /	ALL

GROUND LIST

D280A351

91-21-21

Section GB01800

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No.		Part Number		Station / WL / BL		Effectivity
Term	Type	Bundle	Wire No.	GA	CO	
GB02101		PARTOFTB2101		E002-01/ /		ALL
ST..	1A	W0210	2002Z		30-41-11	YT101-YT116, YT126-YT131
ST..	1A	W0210	2004Z		30-41-11	YT101-YT116, YT126-YT131
ST..	1A	W0210	2005Z		30-41-11	YT101-YT116, YT126-YT131

GROUND LIST

D280A351

91-21-21

Section GB02100

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GB02201		PARTOFTB2201				E002-02/ /	ALL
ST..	1A	W0220	2031Z			73-24-11	ALL
ST..	1A	W0220	2032Z			73-24-11	ALL
ST..	1A	W0220	2033Z			73-24-11	ALL
ST..	1A	W0220	2044Z			73-24-11	ALL
ST..	1A	W0220	2045Z			73-24-11	ALL
ST..	1A	W0220	2046Z			73-24-11	ALL

GROUND LIST

D280A351

91-21-21

Section GB02200

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number		Wire No.	GA	CO	Station / WL / BL		Effectivity
		Bundle					Diagram		
I GB03092		PARTOFTB3092					P003-01/ /		ALL

GROUND LIST

D280A351

91-21-21

Section GB03000

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GB03101		PARTOFTB3101				E003-01/ /	ALL
ST..	1A	W0311	2001Z			31-62-12	ALL
ST..	1A	W0311	2002Z			31-62-12	ALL
ST..	1A	W0311	2003Z			31-62-12	ALL
ST..	1A	W0311	2004Z			31-62-12	ALL
ST..	1A	W0311	2005Z			31-62-12	ALL
ST..	1A	W0311	2006Z			31-62-12	ALL
ST..	1A	W0311	2007Z			31-62-12	ALL
ST..	1A	W0311	2008Z			31-62-12	ALL
ST..	1A	W0311	2009Z			31-62-12	ALL
ST..	1A	W0311	2010Z			31-62-13	ALL
ST..	1A	W0311	2011Z			31-62-13	ALL
ST..	1A	W0311	2012Z			31-62-13	ALL
ST..	1A	W0311	2014Z			31-62-15	ALL
ST..	1A	W0311	2015Z			31-62-15	ALL
ST..	1A	W0311	2016Z			31-62-15	ALL
ST..	1A	W0311	2017Z			31-62-15	ALL
ST..	1A	W0311	2018Z			31-62-15	ALL
ST..	1A	W0311	2019Z			31-62-15	YT101-YT103
ST..	1A	W0311	2020Z			31-62-15	ALL
ST..	1A	W0311	2021Z			31-62-15	ALL
ST..	1A	W0311	2022Z			31-62-15	ALL
ST..	1A	W0311	2026Z			31-62-15	ALL
ST..	1A	W0311	2027Z			31-62-15	ALL
ST..	1A	W0311	2028Z			31-62-15	ALL
ST..	1A	W0311	2029Z			31-62-15	ALL
ST..	1A	W0311	2073Z			31-62-15	ALL
ST..	1A	W0311	2075Z			34-33-11	ALL
ST..	1A	W0311	2076Z			34-33-11	ALL
ST..	1A	W0311	2077Z			34-33-11	ALL
ST..	1A	W0311	2078Z			34-33-11	ALL
ST..	1A	W0311	2079Z			34-33-11	ALL
ST..	1A	W0311	2080Z			34-33-11	ALL
ST..	1A	W0311	2081Z			34-57-11	ALL
ST..	1A	W0311	2082Z			34-57-11	ALL
ST..	1A	W0311	2083Z			34-57-11	ALL
ST..	1A	W0311	2084Z			34-57-11	YT101-YT103
ST..	1A	W0311	2085Z			31-35-02	ALL
ST..	1A	W0311	2086Z			31-35-02	ALL
ST..	1A	W0311	2087Z			31-35-02	ALL
ST..	1A	W0311	2093Z			34-55-11	ALL

GROUND LIST

D280A351

91-21-21

Section GB03100

Page 1

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GB03101		PARTOFTB3101 (continued)				E003-01/ /	ALL
ST..	1A	W0311	2094Z			34-55-11	ALL
ST..	1A	W0311	2095Z			34-55-11	ALL
ST..	1A	W0311	2096Z			34-31-11	ALL
ST..	1A	W0311	2097Z			34-31-11	ALL
ST..	1A	W0311	2098Z			34-31-11	ALL
ST..	1A	W0311	2099Z			34-31-11	ALL
ST..	1A	W0311	2100Z			34-31-11	ALL
ST..	1A	W0311	2103Z			34-61-15	ALL
ST..	1A	W0311	2104Z			34-61-15	ALL
ST..	1A	W0311	2105Z			34-61-15	ALL
ST..	1A	W0311	2106Z			34-61-15	ALL
ST..	1A	W0311	2107Z			34-61-15	ALL
ST..	1A	W0311	2108Z			34-61-15	ALL
ST..	1A	W0311	2109Z			31-32-15	ALL
ST..	1A	W0311	2110Z			31-32-15	ALL
ST..	1A	W0311	2112Z			31-32-15	ALL
ST..	1A	W0311	2117Z			34-21-14	ALL
ST..	1A	W0311	2118Z			34-21-14	ALL
ST..	1A	W0311	2119Z			34-21-14	ALL
ST..	1A	W0311	2120Z			34-21-14	ALL
ST..	1A	W0311	2121Z			34-21-14	ALL
ST..	1A	W0311	2122Z			34-21-14	ALL
ST..	1A	W0311	2136Z			34-45-11	ALL
ST..	1A	W0311	2137Z			34-45-11	ALL
ST..	1A	W0311	2138Z			34-45-11	ALL
ST..	1A	W0311	2144Z			34-41-11	ALL
ST..	1A	W0311	2145Z			34-41-11	ALL
ST..	1A	W0311	2155Z			31-35-02	ALL
ST..	1A	W0311	2156Z			27-81-41	ALL
ST..	1A	W0311	2157Z			27-81-41	ALL
ST..	1A	W0311	2159Z			23-27-38	ALL
ST..	1A	W0311	2160Z			23-27-38	ALL
ST..	1A	W0311	2161Z			23-27-38	ALL
ST..	1A	W0311	2273Z			31-62-15	YT104-YT133
ST..	1A	W0311	2284Z			34-57-11	YT104-YT133
ST..	1A	W0313	2046Z			31-62-25	ALL
ST..	1A	W0313	2218Z			31-62-25	YT104-YT133
ST..	1A	W0313	2284Z			34-57-21	YT104-YT133
ST..	1A	W0313	2501Z			31-62-22	ALL
ST..	1A	W0313	2502Z			31-62-22	ALL

GROUND LIST

D280A351

91-21-21

Section GB03100

Page 2

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GB03101		PARTOFTB3101 (continued)				E003-01/ /	ALL
ST..	1A	W0313	2503Z			31-62-22	ALL
ST..	1A	W0313	2504Z			31-62-22	ALL
ST..	1A	W0313	2505Z			31-62-22	ALL
ST..	1A	W0313	2506Z			31-62-22	ALL
ST..	1A	W0313	2507Z			31-62-22	ALL
ST..	1A	W0313	2508Z			31-62-22	ALL
ST..	1A	W0313	2509Z			31-62-22	ALL
ST..	1A	W0313	2510Z			31-62-23	ALL
ST..	1A	W0313	2511Z			31-62-23	ALL
ST..	1A	W0313	2512Z			31-62-23	ALL
ST..	1A	W0313	2514Z			31-62-25	ALL
ST..	1A	W0313	2515Z			31-62-25	ALL
ST..	1A	W0313	2516Z			31-62-25	ALL
ST..	1A	W0313	2517Z			31-62-25	ALL
ST..	1A	W0313	2518Z			31-62-25	ALL
ST..	1A	W0313	2519Z			31-62-25	YT101-YT103
ST..	1A	W0313	2520Z			31-62-25	ALL
ST..	1A	W0313	2521Z			31-62-25	ALL
ST..	1A	W0313	2522Z			31-62-25	ALL
ST..	1A	W0313	2581Z			34-57-21	ALL
ST..	1A	W0313	2582Z			34-57-21	ALL
ST..	1A	W0313	2583Z			34-57-21	ALL
ST..	1A	W0313	2584Z			34-57-21	YT101-YT103
ST..	1A	W0313	2593Z			34-55-21	ALL
ST..	1A	W0313	2594Z			34-55-21	ALL
ST..	1A	W0313	2595Z			34-55-21	ALL
ST..	1A	W0313	2596Z			34-31-21	ALL
ST..	1A	W0313	2597Z			34-31-21	ALL
ST..	1A	W0313	2598Z			34-31-21	ALL
ST..	1A	W0313	2599Z			34-31-21	ALL
ST..	1A	W0313	2600Z			34-31-21	ALL
ST..	1A	W0313	2603Z			34-61-15	ALL
ST..	1A	W0313	2604Z			34-61-15	ALL
ST..	1A	W0313	2605Z			34-61-15	ALL
ST..	1A	W0313	2606Z			34-61-15	ALL
ST..	1A	W0313	2607Z			34-61-15	ALL
ST..	1A	W0313	2608Z			34-61-15	ALL
ST..	1A	W0313	2617Z			34-21-24	ALL
ST..	1A	W0313	2618Z			34-21-24	ALL
ST..	1A	W0313	2619Z			34-21-24	ALL

GROUND LIST

D280A351

91-21-21

Section GB03100

Page 3

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GB03101		PARTOFTB3101 (continued)				E003-01/ /	ALL
ST..	1A	W0313	2620Z			34-21-24	ALL
ST..	1A	W0313	2621Z			34-21-24	ALL
ST..	1A	W0313	2622Z			34-21-24	ALL
ST..	1A	W0313	2636Z			34-45-11	ALL
ST..	1A	W0313	2637Z			34-45-11	ALL
ST..	1A	W0313	2638Z			34-45-11	ALL
ST..	1A	W0313	2639Z			34-49-11	ALL
ST..	1A	W0313	2640Z			34-49-11	ALL
ST..	1A	W0313	2641Z			34-49-11	ALL
ST..	1A	W0313	2643Z			34-41-11	ALL
ST..	1A	W0313	2644Z			34-41-11	ALL
ST..	1A	W0313	2645Z			34-41-11	ALL
ST..	1A	W0313	2648Z			22-11-51	ALL
ST..	1A	W0313	2649Z			22-11-51	ALL
ST..	1A	W0313	2650Z			22-11-51	ALL
ST..	1A	W0313	2657Z			27-81-41	ALL
ST..	1A	W0313	2671Z			34-41-11	ALL
ST..	1A	W0313	2672Z			34-41-11	ALL
GB03102		PARTOFTB3102				E003-01/ /	ALL
ST..	1A	W0311	1001Z			31-62-14	ALL
ST..	1A	W0311	1002Z			31-62-14	ALL
ST..	1A	W0311	1003Z			31-62-14	ALL
ST..	1A	W0311	1004Z			79-31-11	ALL
ST..	1A	W0311	1005Z			79-31-11	ALL
ST..	1A	W0311	1006Z			79-31-11	ALL
ST..	1A	W0311	1007Z			79-31-11	ALL
ST..	1A	W0311	2034Z			77-31-11	ALL
ST..	1A	W0311	2035Z			77-31-11	ALL
ST..	1A	W0311	2036Z			77-31-11	ALL
ST..	1A	W0311	2037Z			49-62-11	ALL
ST..	1A	W0311	2038Z			49-62-11	ALL
ST..	1A	W0311	2039Z			49-62-11	ALL
ST..	1A	W0311	2040Z			49-62-11	ALL
ST..	1A	W0311	2041Z			73-24-11	ALL
ST..	1A	W0311	2042Z			73-24-11	ALL
ST..	1A	W0311	2043Z			73-24-11	ALL
ST..	1A	W0311	2044Z			73-24-11	ALL
ST..	1A	W0311	2045Z			73-24-11	ALL
ST..	1A	W0311	2046Z			73-24-11	ALL

GROUND LIST

D280A351

91-21-21

Section GB03100

Page 4

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GB03102		PARTOFTB3102 (continued)				E003-01/ /	ALL
ST..	1A	W0311	2049Z			73-24-12	ALL
ST..	1A	W0311	2050Z			73-24-12	ALL
ST..	1A	W0311	2051Z			73-24-12	ALL
ST..	1A	W0311	2052Z			73-24-12	ALL
ST..	1A	W0311	2053Z			28-41-11	ALL
ST..	1A	W0311	2054Z			28-41-11	ALL
ST..	1A	W0311	2055Z			28-41-11	ALL
ST..	1A	W0311	2057Z			28-41-11	ALL
ST..	1A	W0311	2058Z			28-41-11	ALL
ST..	1A	W0311	2060Z			28-41-11	ALL
ST..	1A	W0311	2061Z			28-41-11	ALL
ST..	1A	W0311	2062Z			28-41-11	ALL
ST..	1A	W0311	2065Z			77-12-11	ALL
ST..	1A	W0311	2066Z			77-12-11	ALL
ST..	1A	W0311	2067Z			77-12-11	ALL
ST..	1A	W0311	2068Z			77-31-11	ALL
ST..	1A	W0311	2069Z			77-12-21	ALL
ST..	1A	W0311	2070Z			77-12-21	ALL
ST..	1A	W0311	2071Z			77-12-21	ALL
ST..	1A	W0311	2072Z			77-31-11	ALL
ST..	1A	W0311	2113Z			28-41-11	YT104-YT133
ST..	1A	W0311	2123Z			79-31-11	ALL
ST..	1A	W0311	2124Z			79-31-11	ALL
ST..	1A	W0311	2125Z			79-31-11	ALL
ST..	1A	W0311	2126Z			79-31-11	ALL
ST..	1A	W0311	2162Z			49-62-11	ALL
ST..	1A	W0311	3001Z			79-31-11	ALL
ST..	1A	W0313	1501Z			31-62-24	ALL
ST..	1A	W0313	1502Z			31-62-24	ALL
ST..	1A	W0313	1503Z			31-62-24	ALL
ST..	1A	W0313	1504Z			79-31-11	ALL
ST..	1A	W0313	1505Z			79-31-11	ALL
ST..	1A	W0313	1506Z			79-31-11	ALL
ST..	1A	W0313	1507Z			79-31-11	ALL
ST..	1A	W0313	2534Z			34-61-14	ALL
ST..	1A	W0313	2541Z			73-24-21	ALL
ST..	1A	W0313	2542Z			73-24-21	ALL
ST..	1A	W0313	2543Z			73-24-21	ALL
ST..	1A	W0313	2544Z			73-24-21	ALL
ST..	1A	W0313	2545Z			73-24-21	ALL

GROUND LIST

D280A351

91-21-21

Section GB03100

Page 5

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GB03102		PARTOFTB3102 (continued)				E003-01/ /	ALL
ST..	1A	W0313	2546Z			73-24-21	ALL
ST..	1A	W0313	2547Z			73-24-21	ALL
ST..	1A	W0313	2548Z			73-24-21	ALL
ST..	1A	W0313	2549Z			73-24-12	ALL
ST..	1A	W0313	2550Z			73-24-12	ALL
ST..	1A	W0313	2551Z			73-24-12	ALL
ST..	1A	W0313	2552Z			34-61-14	ALL
ST..	1A	W0313	2559Z			28-41-11	ALL
ST..	1A	W0313	2563Z			34-61-14	ALL
ST..	1A	W0313	2565Z			77-12-11	ALL
ST..	1A	W0313	2566Z			77-12-11	ALL
ST..	1A	W0313	2567Z			77-12-11	ALL
ST..	1A	W0313	2568Z			77-31-21	ALL
ST..	1A	W0313	2569Z			77-12-21	ALL
ST..	1A	W0313	2570Z			77-12-21	ALL
ST..	1A	W0313	2571Z			77-12-21	ALL
ST..	1A	W0313	2572Z			77-31-21	ALL
ST..	1A	W0313	2623Z			79-31-11	ALL
ST..	1A	W0313	2624Z			79-31-11	ALL
ST..	1A	W0313	2625Z			79-31-11	ALL
ST..	1A	W0313	2626Z			79-31-11	ALL
ST..	1A	W0313	3501Z			79-31-11	ALL

GROUND LIST

D280A351

91-21-21

Section GB03100

Page 6 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GB03201		PARTOFTB3201				E003-02 /	ALL
ST..	1A	W0321	2001Z			31-31-11	ALL
ST..	1A	W0321	2002Z			31-31-11	ALL
ST..	1A	W0321	2003Z			31-31-11	ALL
ST..	1A	W0321	2016Z			34-61-14	ALL
ST..	1A	W0321	2017Z			34-21-14	ALL
ST..	1A	W0321	2018Z			34-61-14	ALL
ST..	1A	W0321	2025Z			27-32-12	ALL
ST..	1A	W0321	2026Z			27-32-12	ALL
ST..	1A	W0321	2027Z			27-32-22	ALL
ST..	1A	W0321	2028Z			27-32-22	ALL
ST..	1A	W0321	2029Z			34-21-14	ALL
ST..	1A	W0321	2030Z			34-21-14	ALL
ST..	1A	W0321	2031Z			31-33-01	ALL
ST..	1A	W0321	2032Z			31-35-02	ALL
ST..	1A	W0321	2033Z			31-33-01	ALL
ST..	1A	W0321	2034Z			31-33-01	ALL
ST..	1A	W0321	2035Z			31-35-02	ALL
ST..	1A	W0321	2036Z			31-35-02	ALL
ST..	1A	W0321	2064Z			31-33-01	ALL
ST..	1A	W0321	2065Z			31-33-01	ALL
ST..	1A	W0321	2117Z			27-32-22	ALL
ST..	1A	W0321	2167Z			34-61-14	ALL
ST..	1A	W0321	2173Z			34-33-21	ALL
ST..	1A	W0321	2174Z			34-33-21	ALL
ST..	1A	W0321	2175Z			34-33-21	ALL
ST..	1A	W0321	2176Z			34-33-21	ALL
ST..	1A	W0321	2177Z			34-33-21	ALL
ST..	1A	W0321	2178Z			34-33-21	ALL
ST..	1A	W0321	2179Z			34-33-21	ALL
ST..	1A	W0321	2180Z			34-33-21	ALL
ST..	1A	W0321	2181Z			34-41-11	ALL
ST..	1A	W0321	2184Z			77-31-11	ALL
ST..	1A	W0321	2185Z			77-31-11	ALL
ST..	1A	W0321	2186Z			77-31-11	ALL
ST..	1A	W0321	2221Z			22-23-12	ALL
ST..	1A	W0321	2222Z			22-23-12	ALL
ST..	1A	W0321	2225Z			22-23-12	ALL
ST..	1A	W0321	2228Z			22-23-12	ALL
ST..	1A	W0321	2242Z			77-31-21	YT106-YT133
ST..	1A	W0321	2463Z			34-33-21	ALL

GROUND LIST

D280A351

91-21-21

Section GB03200

Page 1

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GB03201		PARTOFTB3201 (continued)				E003-02/ /	ALL
ST..	1A	W0321	2464Z			27-32-12	ALL
ST..	1A	W0321	2513Z			31-33-01	YT101-YT120
ST..	1A	W0321	2514Z			31-33-01	YT101-YT120
ST..	1A	W0321	2709Z			22-23-12	ALL
ST..	1A	W0321	2713Z			27-32-12	ALL
ST..	1A	W0321	2714Z			27-32-12	ALL
ST..	1A	W0321	2715Z			27-32-12	ALL
ST..	1A	W0321	2717Z			27-32-12	ALL
ST..	1A	W0321	2719Z			22-23-12	ALL
ST..	1A	W0321	2725Z			27-81-41	ALL
ST..	1A	W0321	2751Z			27-81-41	ALL
ST..	1A	W0321	2752Z			27-81-41	ALL
ST..	1A	W0321	2753Z			27-32-22	ALL
ST..	1A	W0321	2754Z			27-32-22	ALL
ST..	1A	W0321	2755Z			27-32-22	ALL
ST..	1A	W0321	2756Z			27-32-22	ALL
ST..	1A	W0321	2763Z			31-33-01	ALL

GROUND LIST

D280A351

91-21-21

Section GB03200

Page 2 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GB03301		PARTOFTB3301				E003-03/ /	ALL
ST..	1A	W0331	2521Z			23-27-37	ALL
ST..	1A	W0331	2541Z			34-61-23	ALL
ST..	1A	W0331	2542Z			34-61-23	ALL
ST..	1A	W0331	2601Z			23-27-32	ALL
ST..	1A	W0331	2602Z			23-27-32	ALL
ST..	1A	W0331	2603Z			23-27-32	ALL
ST..	1A	W0331	2608Z			23-27-33	ALL
ST..	1A	W0331	2609Z			23-27-33	ALL
ST..	1A	W0331	2624Z			23-27-37	ALL
ST..	1A	W0331	2626Z			23-27-37	ALL
ST..	1A	W0331	2640Z			34-61-23	ALL
ST..	1A	W0331	2641Z			34-61-23	ALL
ST..	1A	W0331	2642Z			34-61-23	ALL
ST..	1A	W0331	2803Z			34-61-23	ALL
ST..	1A	W0331	2822Z			23-27-33	ALL
GB03302		PARTOFTB3302				E003-03/ /	ALL
ST..	1A	W0331	2515Z			23-11-26	ALL
ST..	1A	W0331	2660Z			34-45-21	ALL
ST..	1A	W0331	2662Z			34-45-21	ALL
ST..	1A	W0331	2703Z			23-11-16	ALL
ST..	1A	W0331	2807Z			34-45-21	ALL
ST..	1A	W0331	2808Z			34-45-21	ALL

GROUND LIST

D280A351

91-21-21

Section GB03300

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No.		Part Number		Station / WL / BL		Effectivity
Term	Type	Bundle	Wire No.	GA	CO	
Diagram						
I	GB03901	PARTOFTB3901			AJ0039/ /	ALL
I	ST..	1A	W0082	1001Z	27-62-11	ALL
I	ST..	1A	W0082	1002Z	27-62-11	ALL
I	ST..	1A	W0082	1005Z	27-62-11	ALL
I	ST..	1A	W0082	1006Z	27-62-11	ALL
I	ST..	1A	W0082	1009Z	27-62-11	ALL
I	ST..	1A	W0082	1010Z	27-62-11	ALL
I	ST..	1A	W0082	1011Z	27-62-11	ALL
I	ST..	1A	W0082	1012Z	27-62-11	ALL
I	ST..	1A	W0082	1013Z	27-62-11	ALL
I	ST..	1A	W0082	1014Z	27-62-11	ALL
I	ST..	1A	W0082	1015Z	27-62-11	ALL
I	ST..	1A	W0082	1016Z	27-62-11	ALL
I	ST..	1A	W0082	1018Z	27-62-11	ALL
I	ST..	1A	W0082	1019Z	27-62-11	ALL
I	ST..	1A	W0082	1020Z	27-62-11	ALL
I	ST..	1A	W0082	1021Z	27-62-11	ALL
I	ST..	1A	W0082	1022Z	27-62-11	ALL
I	ST..	1A	W0082	1023Z	27-62-11	ALL
I	ST..	1A	W0082	1024Z	27-62-11	ALL
I	ST..	1A	W0082	1025Z	27-62-11	ALL
I	GB03902	PARTOFTB3902			BJ0039/ /	ALL
I	ST..	1A	W0084	FRAB	23-42-14	ALL
I	ST..	1A	W0084	FRAD	23-42-14	ALL

GROUND LIST

D280A351

91-21-21

Section GB03900

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GB04101		PARTOFTB4101				E004-01/ /	ALL
ST..	1A	W0410	2026Z			31-22-11	ALL
ST..	1A	W0410	2027Z			31-22-11	ALL
ST..	1A	W0410	2028ZO			34-45-21	ALL
ST..	1A	W0411	2515Z			31-22-11	ALL
ST..	1A	W0411	2527ZO			34-45-21	ALL
ST..	1A	W0411	2528ZO			34-45-21	ALL
ST..	1A	W0411	3501Z			23-41-11	ALL
ST..	1A	W0411	3502Z			23-41-11	ALL

GROUND LIST

D280A351

91-21-21

Section GB04100

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

I	Ground No.	Type	Part Number		GA	CO	Station / WL / BL	Effectivity
	Term		Bundle	Wire No.			Diagram	
	GB04201		PARTOFTB4201				E004-02/ /	ALL
	ST..	1A	W0420	2002Z			30-41-12	YT101-YT116, YT126-YT131
	ST..	1A	W0420	2004Z			30-41-12	YT101-YT116, YT126-YT131
	ST..	1A	W0420	2005Z			30-41-12	YT101-YT116, YT126-YT131

GROUND LIST

D280A351

91-21-21

Section GB04200

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
I GD00002		DC				645/162/R042	ALL
I GD00005		ST-				RUD56.4/ /	ALL
I ST..	E	W3389	0015	20		27-24-11	ALL
I GD00007		ST-				RUD56.4/ /	ALL
I ST..	E	W3387	0014	20		22-23-12	ALL
I ST..	E	W3387	0015	20		22-23-12	ALL
I GD00008		AC-				375/157/L029	ALL
I AC..	F	W5030	0505	10		24-53-11	ALL
I GD00010		AC-				378/168/R047	ALL
I AC..	F	W6110	0518	08		24-53-11	ALL
I GD00012		BACC50AN16				543/159/L026	ALL
I AC..	1	W5230	0004	20		33-42-11	YT101-YT112, YT126-YT130
I ST..	1	W5230	0005	20		33-42-11	YT101-YT112, YT126-YT130
I ST..	1	W5230	YAAF			29-11-12	YT101-YT119, YT126-YT131
I GD00015		DC				1132/360/L001	ALL
I DC..	E	W7381	1001	20		22-11-81	ALL
I DC..	E	W7381	1001Z			22-11-81	ALL
I DC..	E	W7381	1002	20		22-11-81	ALL
I DC..	E	W7381	1002Z			22-11-81	ALL
I GD00016		BACC50AN16				543/160/R027	ALL
I AC..	1	W6128	0004	20		33-42-11	YT101-YT112, YT126-YT130
I ST..	1	W6128	0005	20		33-42-11	YT101-YT112, YT126-YT130
I ST..	1	W6128	YAAF			29-11-12	YT101-YT119, YT126-YT131
I AC..	1	W6202	1038	20		21-61-13	ALL
I ST..	1	W6202	1038Z			21-61-13	ALL
I DC..	1	W6202	1040	20		21-61-13	ALL
I ST..	1	W6202	1040Z			21-61-13	ALL
I AC..	1	W6202	1042	20		21-61-14	ALL
I ST..	1	W6202	1042Z			21-61-14	ALL
I DC..	1	W6202	1045	20		21-61-14	ALL
I ST..	1	W6202	1045Z			21-61-14	ALL

GROUND LIST

D280A351

91-21-21

Section GD00000

Page 1

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD00020		DC-				224/175/L023	ALL
DC..	E	W6570	6008	20		28-41-11	YT101-YT109, YT126-YT129
DC..	E	W6578	6008	20		28-41-11	YT110-YT120, YT130-YT133
GD00022		DC-				224/175/L022	ALL
DC..	E	W5558	6007	20		28-41-11	YT110-YT120, YT130-YT133
DC..	E	W5562	6007	20		28-41-11	YT101-YT109, YT126-YT129
GD00023		DC-				294/235/L056	ALL
GD00024		BACC50AN16				1085/275/L020	ALL
ST..	1	W3391	1004Z			22-13-11	ALL
ST..	1	W3391	1005Z			22-13-11	ALL
ST..	1	W3391	1010Z			22-13-11	ALL
ST..	1	W3391	1012Z			22-13-11	ALL
ST..	1	W4134	1013Z			31-53-11	ALL
ST..	1	W4134	1014Z			31-53-11	ALL
DC..	1	W4134	A-F			31-53-11	ALL
DC..	1	W4134	B-F			31-53-11	ALL
DC..	1	W4134	C-F			31-53-11	ALL
GD00028		BACC50AN16				849/184/L046	ALL
ST..	1	W5112	0510	20		38-41-13	ALL
DC..	1	W6248	5545	20		30-71-11	ALL
DC..	1	W6248	5547	20		30-71-11	ALL
AC..	1	W6248	5549	20		30-71-11	ALL
AC..	1	W6248	5559	20		30-71-11	ALL
AC..	1	W6248	5571	20		30-71-11	ALL
GD00029		DC-				1085/232/L018	ALL
GD00030		AC-				258/196/L033	ALL
AC..	E	W5100	0508	22		32-51-11	ALL
AC..	E	W5156	0650	18		32-64-11	ALL
AC..	E	W5506	6109	20		30-81-11	ALL
GD00032		ST-				258/195/L033	ALL
ST..	E	W5100	0507	22		32-51-11	ALL
ST..	E	W5506	6110	20		30-81-11	ALL

GROUND LIST

D280A351

91-21-21

Section GD00000

Page 2

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD00034		BACC50AN16				213/192/R034	ALL
DC..	1	W5158	0301	20		31-31-15	ALL
DC..	1	W5158	0590	20		32-64-12	ALL
DC..	1	W5160	0008	20		52-71-13	ALL
DC..	1	W5160	0508	20		52-71-13	ALL
DC..	1	W5160	0550	20		32-64-21	ALL
DC..	1	W5160	0622	20		32-31-12	ALL
DC..	1	W6024	0516	22		32-44-11	ALL
GD00036		BACC50AN16				1085/274/L022	ALL
ST..	1	W4222	1001Z			27-41-12	ALL
ST..	1	W4222	1002Z			27-41-12	ALL
ST..	1	W4222	1003Z			27-41-12	ALL
ST..	1	W4222	1005Z			27-41-12	ALL
ST..	1	W4222	1006Z			27-41-12	ALL
DC..	1	W7030	0523	18		27-31-11	ALL
AC..	1	W8030	0502	18		33-49-11	ALL
ST..	1	W8030	0503	18		33-49-11	ALL
AC..	1	W8030	0512	18		33-49-11	ALL
ST..	1	W8030	0513	18		33-49-11	ALL
DC..	1	W8030	0523	18		27-31-11	ALL
GD00038		AC-				227/184/R024	ALL
AC..	H7	W6026	0004	04		24-41-11	ALL
GD00041		DC-				210/207/L022	ALL
DC..	E	W0145	0002	20		27-32-11	ALL
GD00044		BACC50AN16				213/192/R033	ALL
DC..	1	W5156	0545	20		32-64-11	ALL
DC..	1	W5156	0612	22		32-31-11	ALL
DC..	1	W5156	0653	20		44-21-22	ALL
DC..	1	W5156	6002R	20		26-11-31	ALL
GD00045		BACC50AN16				1087/230/R018	ALL
AC..	1	W3391	1009	16		22-13-11	ALL
ST..	1	W3391	1009Z			22-13-11	ALL
AC..	1	W3391	1013	16		22-13-11	ALL
ST..	1	W3391	1013Z			22-13-11	ALL
AC..	1	W3391	1014	20		22-13-11	ALL

GROUND LIST

D280A351

91-21-21

Section GD00000

Page 3

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD00045		BACC50AN16 (continued)				1087/230/R018	ALL
ST..	1	W3391	1014Z			22-13-11	ALL
GD00046		BACC50AN16				AB1088/230/R017	ALL
AC..	1	W4222	1008	18		27-41-12	ALL
AC..	1	W4222	1008Z			27-41-12	ALL
DC..	1	W4222	1009	18		27-41-12	ALL
DC..	1	W4222	1009Z			27-41-12	ALL
ST..	1	W4222	1010	18		27-41-12	ALL
AC..	1	W4724	0034	18		33-35-11	ALL
AC..	1	W4724	0036	18		33-35-11	ALL
DC..	1	W4724	1111R	20		26-11-31	ALL
DED		W4724	1111Z			26-11-31	ALL
DC..	1	W4724	1112R	20		26-11-31	ALL
DED		W4724	1112Z			26-11-31	ALL
GD00048		BACC50AN16				1063/249/R042	ALL
AC..	1	W4724	0025	18		33-35-11	YT101-YT111, YT126-YT130
AC..	1	W4724	0025	20		33-35-11	YT112-YT120, YT131-YT133
AC..	1	W4724	0026	18		33-35-11	YT101-YT111, YT126-YT130
AC..	1	W4724	0026	20		33-35-11	YT112-YT120, YT131-YT133
DC..	1	W4726	0535	20		49-62-11	ALL
GD00053		DC-				210/206/R022	ALL
DC..	E	W0147	0002	20		27-32-21	ALL
GD00054		AC-				1037/239/L033	ALL
GD00056		AC-				992/294/L032	ALL
GD00061		ST-				P061-00/ /	ALL
ST..	E	W0041	0009	22		31-32-15	YT102-YT133
ST..	E	W0041	0012	22		31-32-15	ALL
ST..	E	W0041	0037	20		34-21-11	ALL
ST..	E	W0041	0041	20		31-32-15	ALL
ST..	E	W0041	0042	20		31-32-15	ALL
ST..	E	W0041	0043	20		31-32-15	ALL
ST..	E	W0044	6100	20		23-42-14	ALL

GROUND LIST

D280A351

91-21-21

Section GD00000

Page 4

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD00068		BACC50AN16				520/177/L053	ALL
DC..	1	W5104	0328	20		21-25-11	ALL
DC..	1	W5162	0007	20		36-11-11	ALL
DC..	1	W5162	0008	20		73-21-12	ALL
DC..	1	W5162	0009	20		78-35-11	ALL
DC..	1	W5162	0010	20		30-11-11	ALL
DC..	1	W5162	0011	20		78-36-11	ALL
DC..	1	W5162	0012	20		36-11-11	ALL
DC..	1	W5162	0013	20		78-36-11	ALL
ST..	1	W5248	0001	20		31-35-05	ALL
DC..	1	W5526	5532	20		21-51-15	ALL
GD00069		DC				RUD56.4/ /	ALL
DC..	E	W6136	0509	20		27-23-11	ALL
DC..	E	W6136	0510	20		27-25-11	ALL
DC..	E	W6136	0511	20		27-25-11	ALL
DC..	E	W7383	1003	20		22-11-81	ALL
DC..	E	W7383	1003Z			22-11-81	ALL
DC..	E	W7383	1004	20		22-11-81	ALL
DC..	E	W7383	1004Z			22-11-81	ALL
GD00070		BACC50AN16				947/205/R017	ALL
AC..	1	W5112	0512	20		38-41-13	ALL
DC..	1	W5146	0004	20		38-41-11	ALL
ST..	1	W5146	0005	20		38-41-11	ALL
AC..	1	W6248	5555	20		30-71-11	ALL
AC..	1	W6248	5561	20		30-71-11	ALL
AC..	1	W6248	5581	20		30-71-11	ALL
AC..	1	W6248	5583	20		30-71-11	ALL
AC..	1	W6248	5585	20		30-71-11	ALL
GD00072		BACC50AN16				500I+17/176/R053	ALL
ST..	1	W6162	0001	20		31-35-05	ALL
DC..	1	W6162	0007	20		36-11-11	ALL
DC..	1	W6162	0008	20		73-21-12	ALL
DC..	1	W6162	0009	20		78-35-21	ALL
DC..	1	W6162	0010	20		30-11-11	ALL
DC..	1	W6162	0011	20		78-36-21	ALL
DC..	1	W6162	0012	20		36-11-11	ALL
DC..	1	W6162	0013	20		78-36-21	ALL

GROUND LIST

D280A351

91-21-21

Section GD00000

Page 5

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD00072		BACC50AN16 (continued)				500I+17/176/R053	ALL
ST..	1	W6230	FRFA			21-51-24	ALL
GD00074		ST-				847/189/L041	ALL
ST..	E	W5230	0518	12		38-32-12	YT101-YT119, YT126-YT131
GD00080		BACC50AN20				500B/203/L021	ALL
GD00083		ST-				694/306/R002	ALL
ST..	E	W5273	0001	20		34-57-11	ALL
ST..	E	W5273	0003	20		34-57-11	ALL
ST..	E	W5273	8991Z			34-57-11	ALL
GD00084		BACC50AN20				431/162/R036	ALL
DC..	1A	W5248	0007	20		33-36-11	ALL
DC..	1A	W5248	0156	20		52-71-12	ALL
GD00085		ST-				727A+7/300/R002	ALL
ST..	E	W5275	0001	20		34-57-21	ALL
ST..	E	W5275	0003	20		34-57-21	ALL
ST..	E	W5275	8991Z			34-57-21	ALL
GD00086		BACC50AN16				500/202/L011	ALL
AC..	1	W5248	0014	20		33-36-11	ALL
GD00090		AC-				724/194/L028	ALL
AC..	E	W7026	0513	18		33-32-11	YT101-YT111, YT126-YT130
AC..	E	W7026	0513	20		33-32-11	YT112-YT120, YT131-YT133
GD00091		ST-				500I+3/199/R013	ALL
ST..	E	W5208	0006	20		47-30-11	ALL
GD00092		AC-				703/200/R020	ALL
AC..	E	W7026	0514	18		33-32-11	YT101-YT111, YT126-YT130
AC..	E	W7026	0514	20		33-32-11	YT112-YT120, YT131-YT133
AC..	E	W8224	A-Y			32-64-12	ALL
GD00094		AC-				//	ALL

GROUND LIST

D280A351

91-21-21

Section GD00000

Page 6

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
I GD00095		ST-				540/162/R039	ALL
I ST..	N	W7208	0099	20		47-30-11	ALL
I GD00096		AC-				/ /	ALL
I GD00098		BACC50AN16				1087/232/L017	ALL
I AC..	1	W4724	1002	18		33-35-11	ALL
I ST..	1	W4724	1002Z			33-35-11	ALL
I AC..	1	W4724	1004	20		33-44-12	ALL
I ST..	1	W4724	1004Z			33-44-12	ALL
I DC..	1	W4726	1104R	18		26-21-11	ALL
I ST..	1	W4726	1104Z			26-21-11	ALL
I ST..	1	W4726	1106R	18		26-21-11	ALL
I DED		W4726	1106Z			26-21-11	ALL
I DC..	1	W4726	1107R	18		26-21-11	ALL
I ST..	1	W4726	1107Z			26-21-11	ALL

GROUND LIST

D280A351

91-21-21

Section GD00000

Page 7 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD00100		ST-				321/290/R023	ALL
ST..	D	W0010	0003	20		33-26-21	ALL
ST..	D	W0010	0007	20		33-26-21	ALL
GD00102		DC-				184/240/L017	ALL
DC..	E	W2108	5501	16		30-42-11	ALL
GD00104		DC-				184/238/R017	ALL
DC..	E	W2208	5501	16		30-42-11	ALL
GD00107		BACC50AN20				//	ALL
GD00109		ST-				655/164/L042	ALL
ST..	N	W7202	0022	16		47-30-11	ALL
ST..	N	W7202	0023	16		47-30-11	ALL
ST..	N	W7202	0027	16		47-30-11	ALL
ST..	N	W7202	0028	16		47-30-11	ALL
GD00111		ST-				611/163/L055	ALL
ST..	N	W7202	0020	16		47-30-11	ALL
ST..	N	W7202	0026	16		47-30-11	ALL
GD00112		DC-				//	ALL
GD00113		ST-				647/165/L061	ALL
ST..	N	W7202	0029	16		47-30-11	ALL
GD00120		ST-				ORSS/543/	ALL
ST..	E	W1024	2001Z			27-18-11	YT101-YT119, YT126-YT131
ST..	E	W1024	3001Z			27-18-11	YT101-YT119, YT126-YT131
GD00121		DC-				500I+3/200/R012	ALL
DC..	E	W5208	0005	20		47-30-11	ALL
DC..	E	W5208	0021	20		47-30-11	ALL
DC..	E	W5208	0022	20		47-30-11	ALL
DC..	E	W5208	0023	20		47-30-11	ALL
DC..	E	W5208	0024	20		47-30-11	ALL
GD00122		ST-				ORSS/370/	ALL
ST..	E	W1024	2011Z			27-62-14	YT101-YT119, YT126-YT131

GROUND LIST

D280A351

91-21-21

Section GD00100

Page 1

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD00122		ST- (continued)				ORSS/370/	ALL
ST..	E	W1024	3011Z			27-62-14	YT101-YT119, YT126-YT131
GD00124		ST-				ORSS/370/	ALL
ST..	E	W1024	1003	18		27-53-21	YT101-YT119, YT126-YT131
ST..	E	W1024	1003Z			27-53-21	YT101-YT119, YT126-YT131
GD00126		ST-				ORSS 449/ /	ALL
ST..	E	W1024	0513	20		27-52-11	YT101-YT119, YT126-YT131
ST..	E	W1024	1002	18		27-53-21	YT101-YT119, YT126-YT131
ST..	E	W1024	1002Z			27-53-21	YT101-YT119, YT126-YT131
GD00129		ST-				573/151/L043	ALL
ST..	N	W7202	0024	16		47-30-11	ALL
GD00130		ST-				ORSS/543/	ALL
ST..	E	W1034	2001Z			27-18-11	YT101-YT119, YT126-YT131
ST..	E	W1034	3001Z			27-18-11	YT101-YT119, YT126-YT131
GD00132		ST-				ORSS/370/	ALL
ST..	E	W1034	2011Z			27-62-14	YT101-YT119, YT126-YT131
ST..	E	W1034	3011Z			27-62-14	YT101-YT119, YT126-YT131
GD00134		ST-				ORSS/370/	ALL
ST..	E	W1034	1003	18		27-53-21	YT101-YT119, YT126-YT131
ST..	E	W1034	1003Z			27-53-21	YT101-YT119, YT126-YT131
GD00136		ST-				ORSS/449/	ALL
ST..	E	W1034	0513	20		27-52-11	YT101-YT119, YT126-YT131
ST..	E	W1034	1002	18		27-53-21	YT101-YT119, YT126-YT131
ST..	E	W1034	1002Z			27-53-21	YT101-YT119, YT126-YT131
GD00138		DC-				726/169/R020	ALL
DC..	E	W8524	6004R	18		26-11-31	ALL
GD00140		ST-				978/289/R018	ALL
GD00141		AC-				P001-00/ /	ALL
AC..	E	W0001	0190	14		33-11-11	ALL
AC..	E	W0001	0195	14		33-11-11	ALL

GROUND LIST

D280A351

91-21-21

Section GD00100

Page 2

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD00141		AC- (continued)				P001-00/ /	ALL
AC..	E	W0001	0202	14		33-11-31	ALL
AC..	E	W0001	0215	20		33-11-32	ALL
GD00142		AC-				P003-00/ /	ALL
AC..	E	W0003	0667	16		33-11-21	ALL
AC..	E	W0003	0674	14		33-11-21	ALL
AC..	E	W0003	0711	16		33-11-32	ALL
GD00144		AC-				IFSS 167/ /	ALL
AC..	E	W1280	J-Y			27-81-21	ALL
GD00148		AC-				IFSS 149/ /	ALL
AC..	E	W1280	K-Y			27-81-21	ALL
AC..	E	W1280	L-Y			27-81-21	ALL
GD00150		ST-				328/293/L004	ALL
GD00152		ST-				976/292/R006	ALL
GD00154		AC-				P018-00/ /	ALL
AC..	E	W0020	0889	06		24-53-11	ALL
GD00156		DC-				/ /	ALL
GD00158		DC-				/ /	ALL
GD00160		AC-				IFSS-149/ /	ALL
AC..	E	W1180	K-Y			27-81-11	ALL
AC..	E	W1180	L-Y			27-81-11	ALL
GD00162		DC-				IFSS 113/ /	ALL
DC..	GW	W1664	1032Z			28-43-11	ALL
DC..	GW	W1664	1033	20		28-43-11	ALL
GD00164		ST-				IFSS-133/ /	ALL
ST..	GW	W1180	6001	18		28-23-11	ALL
GD00166		DC-				IFSS-118/ /	ALL
DC..	GW	W1662	1012Z			28-43-11	ALL

GROUND LIST

D280A351

91-21-21

Section GD00100

Page 3

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD00166		DC- (continued)				IFSS-118/ /	ALL
DC..	GW	W1662	1013	20		28-43-11	ALL
GD00170		ST-				//	ALL
GD00171		DC-				261/185/L033	ALL
DC..	E	W5501	0003	20		34-21-12	ALL
DC..	E	W5501	0004	20		34-21-12	ALL
DC..	E	W5506	6111	20		30-81-11	ALL
GD00172		DC-				IRSS 141/ /	ALL
DC..	E	W1134	1301	20		28-43-11	YT101-YT119, YT126-YT131
GD00174		DC-				//	ALL
GD00176		ST-				//	ALL
GD00178		DC-				//	ALL
GD00179		BACC50AN20				183/222/L006	ALL
AC..	1A	W2205	0002	20		SPARE	ALL
AC..	1A	W2205	0005	20		SPARE	ALL
DC..	1A	W2205	0008	20		SPARE	ALL
ST..	1A	W2205	0009	20		SPARE	ALL
AC..	1A	W2205	0011	20		33-11-32	ALL
DC..	1A	W2205	0013	20		SPARE	ALL
ST..	1A	W2205	0026	20		SPARE	ALL
DC..	1A	W2205	0039	20		34-24-15	ALL
ST..	1A	W2205	0040	20		34-24-15	ALL
GD00180		ST-				665/178/L031	ALL
ST..	E	W7122	0521	20		27-11-11	YT101-YT119, YT126-YT131
GD00182		ST-				//	ALL
GD00184		DC-				IRSS/149/	ALL
DC..	E	W1136	1303	20		28-43-11	YT101-YT119, YT126-YT131
GD00185		AC-				1157/289/R017	ALL
GD00186		ST-				//	ALL

GROUND LIST

D280A351

91-21-21

Section GD00100

Page 4

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	Ground No.	Type	Part Number		Wire No.	GA	CO	Station / WL / BL	Effectivity
	Term		Bundle					Diagram	
I	GD00187		ST-					1157/288/R017	ALL
I	GD00188		ST-					/ /	ALL
I	GD00190		ST-					666/198/R060	ALL
I	ST..	E	W1126	1307	18			28-22-11	ALL
I	DED		W1126	1307Z				28-22-11	ALL
I	ST..	E	W1134	1302Z				28-43-11	YT101-YT119, YT126-YT131
I	ST..	E	W1134	3601Z				28-23-11	YT101-YT119, YT126-YT131
I	GD00192		DC-					/ /	ALL
I	GD00194		AC-					IFSS-111/ /	ALL
	AC..	N	W1662	1004	12			33-42-11	YT101-YT112, YT126-YT130
	AC..	N	W1662	1004Z				33-42-11	YT101-YT112, YT126-YT130
	AC..	GW	W1662	1006	16			33-45-11	YT101-YT112, YT126-YT130
	AC..	GW	W1662	1006Z				33-45-11	YT101-YT112, YT126-YT130
I	GD00198		AC-					IFSS-98/ /	ALL
	AC..	N	W1662	1002	12			33-42-11	YT101-YT112, YT126-YT130
	AC..	N	W1662	1002Z				33-42-11	YT101-YT112, YT126-YT130

GROUND LIST

D280A351

91-21-21

Section GD00100

Page 5 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
I GD00204		AC-				OFSS 108/ /	ALL
AC..	N	W1664	1004	12		33-42-11	YT101-YT112, YT126-YT130
AC..	N	W1664	1004Z			33-42-11	YT101-YT112, YT126-YT130
AC..	GW	W1664	1006	16		33-45-11	YT101-YT112, YT126-YT130
AC..	GW	W1664	1006Z			33-45-11	YT101-YT112, YT126-YT130
I GD00207		ST-				642/272/R057	ALL
I ST..	E	W4246	0036	18		33-21-12	ALL
I GD00208		AC-				OFSS 98/ /	ALL
AC..	N	W1664	1002	12		33-42-11	YT101-YT112, YT126-YT130
AC..	N	W1664	1002Z			33-42-11	YT101-YT112, YT126-YT130
I GD00210		AC-				226/232/R040	ALL
I AC..	E	W2204	5534	20		33-14-11	ALL
I GD00211		ST-				642/272/L057	ALL
I ST..	E	W3246	0036	18		33-21-12	ALL
I GD00217		ST-				581/272/R057	ALL
I ST..	E	W4246	0026	18		33-21-12	ALL
I GD00220		ST-				//	ALL
I GD00222		ST-				//	ALL
I GD00224		ST-				ORSS/251/	ALL
I ST..	E	W1022	1002	18		27-53-21	YT101-YT119, YT126-YT131
I ST..	E	W1022	1002Z			27-53-21	YT101-YT119, YT126-YT131
I GD00226		ST-				726/194/L048	ALL
I ST..	E	W1022	1003	18		27-53-21	YT101-YT119, YT126-YT131
I ST..	E	W1022	1003Z			27-53-21	YT101-YT119, YT126-YT131
I GD00228		AC				//	ALL
I GD00229		ST-				581/372/L057	ALL
I ST..	E	W3246	0026	18		33-21-12	ALL
I GD00230		ST-				//	ALL

GROUND LIST

D280A351

91-21-21

Section GD00200

Page 1

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
I GD00232		ST-				/ /	ALL
I GD00234		ST-				ORSS 251/ /	ALL
I ST..	E	W1032	1002	18		27-53-21	YT101-YT119, YT126-YT131
I ST..	E	W1032	1002Z			27-53-21	YT101-YT119, YT126-YT131
I GD00236		ST-				726/201/R041	ALL
I ST..	E	W1032	1003	18		27-53-21	YT101-YT119, YT126-YT131
I ST..	E	W1032	1003Z			27-53-21	YT101-YT119, YT126-YT131
I GD00240		DC-				OFSS 367/ /	ALL
I DC..	E	W1664	0034	20		28-44-11	ALL
I DC..	E	W1664	0036	20		28-44-11	ALL
I DC..	E	W1664	0038	20		28-44-11	ALL
I ST..	E	W1664	1013Z			28-44-11	ALL
I GD00246		ST-				724/155/R012	ALL
I ST..	E	W8524	0501	18		29-32-11	ALL
I ST..	E	W8524	2001Z			29-32-11	ALL
I GD00261		BACC50AN20				261/280/L008	ALL
I AC..	1A	W2112	6043	20		28-23-11	ALL
I AC..	1A	W2112	6044	20		28-23-11	ALL
I AC..	1A	W2112	6045	20		28-23-11	ALL
I AC..	1A	W2112	6056	20		28-23-11	ALL
I ST..	1A	W2216	5516	20		21-61-11	ALL
I AC..	1A	W2216	5517	20		21-61-11	ALL
I DC..	1A	W2508	5613	20		33-14-12	ALL
I ST..	1D	W2705	0011	18		34-36-11	ALL
I DC..	1D	W2705	0012	18		34-36-11	ALL
I AC..	1A	W2705	0015	20		33-12-11	ALL
I GD00262		ST-				IFSS 129/ /	ALL
I ST..	GW	W1280	6001	18		28-23-11	ALL
I ST..	GW	W1664	1019Z			28-44-11	ALL
I ST..	GW	W1664	1026Z			28-44-11	ALL
I GD00263		BACC50AN16				261/282/L008	ALL

GROUND LIST

D280A351

91-21-21

Section GD00200

Page 2

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD00264		BACC50AN20				261/280/R008	YT101-YT116, YT126-YT131
AC..	1A	W2218	6043	20		28-23-11	YT101-YT116, YT126-YT131
AC..	1A	W2218	6044	20		28-23-11	YT101-YT116, YT126-YT131
AC..	1A	W2218	6045	20		28-23-11	YT101-YT116, YT126-YT131
AC..	1A	W2218	6056	20		28-23-11	YT101-YT116, YT126-YT131
DC..	1A	W2508	2002B	20		33-14-12	YT101-YT116, YT126-YT131
DED		W2508	2002Z			33-14-12	YT101-YT116, YT126-YT131
DC..	1A	W2508	5629	20		33-18-42	YT101-YT116, YT126-YT131
DC..	1A	W2508	5630	20		33-18-42	YT101-YT116, YT126-YT131
DC..	1A	W2508	5631	20		33-18-42	YT101-YT116, YT126-YT131
I GD00266		BACC50AN16				261/282/R008	ALL
I GD00270		DC-				363/157/L029	ALL
I ST..	E	W2536	0515	14		24-34-11	ALL
I ST..	E	W5506	0520	24		24-34-11	ALL
I GD00272		ST-				388/167/R047	ALL
I ST..	E	W6210	2201B	22		24-23-21	ALL
I GD00276		ST-				387/173/L053	ALL
I ST..	E	W5726	2237B	22		24-23-11	ALL
I ST..	E	W5726	2239B	22		24-22-31	ALL
I ST..	E	W5726	4102G	20		24-21-31	ALL
I GD00280		BACC50AN16				P018-00/ /	ALL
AC..	1	W0018	0130	20		46-15-11	YT101-YT120
AC..	1	W0018	0131	20		46-15-11	YT101-YT120
AC..	1	W0018	0137	20		46-15-11	YT101-YT120
DC..	1	W0018	0141	20		46-15-11	YT101-YT120
AC..	1	W0018	0183	20		46-15-11	YT101-YT120
AC..	1	W0018	0185	20		46-15-11	YT101-YT120
AC..	1	W0018	0189	20		46-15-11	YT101-YT120
AC..	1	W0018	0190	20		46-15-11	YT101-YT120
I GD00287		ST-				239/203/L013	ALL
I ST..	E	W5369	0035	20		22-11-11	ALL
I ST..	E	W5457	0015	20		22-11-11	ALL

GROUND LIST

D280A351

91-21-21

Section GD00200

Page 3

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	Ground No.	Type	Part Number	Wire No.	GA	CO	Station / WL / BL	Effectivity
	Term		Bundle				Diagram	
I	GD00289		ST-				211/197/L026	ALL
I	ST..	E	W5369	0045	20		22-11-11	ALL
I	GD00298		DC-				199/203/L015	ALL
I	DC..	E	W5514	5781	22		32-44-11	ALL

GROUND LIST

D280A351

91-21-21

Section GD00200

Page 4 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD00302		AC-				726/165/L020	ALL
AC..	E	W7128	0304	16		27-53-12	YT101-YT119, YT126-YT131
GD00303		BACC50AN20				/ /	ALL
GD00304		ST-				706/200/L010	ALL
ST..	E	W7128	0510	20		29-31-11	YT101-YT119, YT126-YT131
GD00308		DC-				726/180/L008	ALL
DC..	E	W7128	0512	18		32-44-11	YT101-YT119, YT126-YT131
DC..	E	W7128	0515	18		32-44-11	YT101-YT119, YT126-YT131
GD00310		DC-				715/200/R031	ALL
DC..	E	W8226	0504	20		27-53-12	YT101-YT104
DC..	N	W8226	0504	20		27-53-12	YT105-YT133
DC..	E	W8226	0506	20		22-23-12	YT101-YT104
DC..	N	W8226	0506	20		22-23-12	YT105-YT133
DC..	E	W8226	0508	20		33-25-11	YT101-YT104
DC..	N	W8226	0508	20		33-25-11	YT105-YT133
DC..	E	W8226	B-AA			27-53-12	ALL
GD00312		DC-				665/191/R015	ALL
DC..	E	W8222	0507	20		29-33-11	ALL
DC..	E	W8222	0508	18		29-11-11	ALL
DC..	E	W8222	0511	20		29-33-11	ALL
DC..	E	W8228	0502	18		31-53-11	ALL
GD00314		DC-				664/178/R031	ALL
DC..	E	W1126	1304	20		28-43-11	ALL
DED		W1126	1304Z			28-43-11	ALL
DC..	E	W8122	0504	20		29-25-11	ALL
GD00315		DC-				301/181/R020	ALL
DC..	E	W5205	0009	20		34-51-41	ALL
GD00316		DC-				726/166/L020	ALL
DC..	E	W7128	0405	20		29-35-11	YT101-YT119, YT126-YT131
DC..	E	W7128	0407	18		27-53-11	YT101-YT119, YT126-YT131
DC..	E	W7128	0521	18		27-23-11	YT101-YT119, YT126-YT131

GROUND LIST

D280A351

91-21-21

Section GD00300

Page 1

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
I GD00317		DC-				308/178/R022	ALL
I DC..	E	W5163	0037	22		34-51-41	ALL
I GD00318		DC-				663/165/R004	ALL
I DC..	E	W6128	0501	18		29-11-12	YT101-YT119, YT126-YT131
I DC..	E	W6128	0508	18		29-34-11	YT101-YT119, YT126-YT131
I DC..	E	W7122	0503	18		29-25-11	YT101-YT119, YT126-YT131
I DC..	E	W8122	0507	20		29-23-11	ALL
I DC..	E	W8122	0509	20		29-23-11	ALL
I GD00320		DC-				665/182/L024	ALL
I DC..	E	W1128	1302	20		28-43-11	ALL
I DED		W1128	1302Z			28-43-11	ALL
I DC..	E	W5367	0012	20		22-11-31	ALL
I DC..	E	W5367	0013	20		22-11-31	ALL
I DC..	E	W7122	0505	20		27-23-14	YT101-YT119, YT126-YT131
I DC..	E	W7122	0508	18		27-61-11	YT101-YT119, YT126-YT131
I DC..	E	W7122	0512	18		27-23-11	YT101-YT119, YT126-YT131
I GD00322		DC-				662/165/L004	ALL
I DC..	E	W5230	0501	18		29-11-12	YT101-YT119, YT126-YT131
I DC..	E	W5230	0508	18		29-34-11	YT101-YT119, YT126-YT131
I DC..	E	W8122	0508	20		29-23-11	ALL
I GD00324		DC-				665/182/R054	ALL
I DC..	E	W1126	1308	18		28-22-11	ALL
I DED		W1126	1308Z			28-22-11	ALL
I DC..	E	W8122	0502	20		27-23-14	ALL
I DC..	E	W8122	0513	20		27-23-11	ALL
I DC..	E	W8122	0544	18		27-61-11	ALL
I GD00326		DC-				/ /	ALL
I GD00328		DC-				674/200/R038	ALL
I DC..	E	W8224	0505	20		29-23-11	ALL
I GD00330		DC-				665/179/L041	ALL
I DC..	E	W5375	0002	20		22-11-31	ALL
I DC..	E	W5375	0022	20		22-11-31	ALL
I DC..	E	W7026	0505	18		49-62-11	ALL

GROUND LIST

D280A351

91-21-21

Section GD00300

Page 2

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD00330		DC- (continued)				665/179/L041	ALL
DC..	E	W7522	0503	18		29-11-11	ALL
DC..	E	W7522	0505	20		29-33-11	ALL
DC..	E	W7522	0507	20		29-33-11	ALL
GD00332		DC-				717/200/R020	ALL
DC..	E	W8124	0504	18		27-53-11	ALL
DC..	E	W8124	0505	20		32-64-21	YT101-YT104
DC..	N	W8124	0505	20		32-64-21	YT105-YT133
DC..	E	W8124	0510	20		32-64-21	YT101-YT104
DC..	N	W8124	0510	20		32-64-21	YT105-YT133
DC..	E	W8124	0514	20		21-51-14	YT101-YT104
DC..	N	W8124	0514	20		21-51-14	YT105-YT133
GD00334		ST-				DELETED/ /	ALL
GD00336		ST-				665/188/R015	ALL
ST..	E	W8222	0509	18		29-32-11	ALL
GD00338		ST-				/ /	ALL
GD00340		DC-				726/172/L020	ALL
DC..	E	W7128	0402	18		29-31-11	YT101-YT119, YT126-YT131
GD00342		DC-				715/198/L051	ALL
DC..	E	W7592	6010R	20		26-21-11	ALL
DC..	E	W7592	6011R	20		26-21-11	ALL
DC..	E	W7592	6012R	20		26-21-11	ALL
DC..	E	W7592	6013R	20		26-21-11	ALL
DC..	E	W7592	6014R	20		26-21-11	ALL
GD00344		DC				724/198/L051	ALL
DC..	E	W7594	6009R	20		26-21-11	ALL
DC..	E	W7594	6010R	20		26-21-11	ALL
DC..	E	W7594	6011R	20		26-21-11	ALL
DC..	E	W7594	6012R	20		26-21-11	ALL
DC..	E	W7594	6013R	20		26-21-11	ALL
GD00346		AC-				286/184/R017	ALL
AC..	E	W5160	0505	18		32-64-12	ALL

GROUND LIST

D280A351

91-21-21

Section GD00300

Page 3

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
I GD00356		DC-				//	ALL
I GD00360		DC				224/180/L003	ALL
I DC..	E	W6024	0513	22		23-43-11	ALL
I GD00374		DC-				644/159/R009	ALL
I DC..	GW	W6202	1033	20		21-51-22	ALL
I DC..	GW	W6202	1033Z			21-51-22	ALL
I GD00380		DC-				705/200/L037	ALL
I DC..	E	W7126	0502	18		31-31-15	ALL
I DC..	E	W7126	0504	18		32-41-11	ALL
I GD00382		DC-				644/159/L009	ALL
I DC..	GW	W5102	1028	20		21-51-12	ALL
I DC..	GW	W5102	1028Z			21-51-12	ALL
I GD00383		BACC50AN20				198/172/R007	YT101-YT102
DC..	1A	W5158	0671	20		21-27-31	YT101-YT102
ST..	1A	W5158	0672	20		21-27-31	YT101-YT102
DC..	1A	W5158	0677	20		21-27-31	YT101-YT102
AC..	1A	W6491	0003	20		34-41-11	YT101-YT102
AC..	1A	W6491	0016	20		34-41-11	YT101-YT102
DC..	1A	W6491	0017	20		34-41-11	YT101-YT102
ST..	1A	W6491	0041	20		34-41-11	YT101-YT102
ST..	1A	W6491	0058	20		34-41-11	YT101-YT102
ST..	1A	W6491	0059	20		34-41-11	YT101-YT102
ST..	1A	W6491	0060	20		34-41-11	YT101-YT102
ST..	1A	W6491	0061	20		34-41-11	YT101-YT102
ST..	1A	W6491	0062	20		31-62-15	YT101-YT102
ST..	1A	W6491	0063	20		31-62-25	YT101-YT102
ST..	1A	W6491	0064	20		34-21-13	YT101-YT102
ST..	1A	W6491	0065	20		34-21-23	YT101-YT102
I GD00384		YHLZG8-1				198/172/R007	YT104-YT133
I ST..	2	W6491	0159	20		34-41-11	YT104-YT133
I GD00396		AC-				224/181/L002	ALL
I AC..	E	W6024	0501	18		33-32-11	YT101-YT111, YT126-YT130
I AC..	E	W6024	0501	20		33-32-11	YT112-YT120, YT131-YT133

GROUND LIST

D280A351

91-21-21

Section GD00300

Page 4 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD00400		BACC50AN20				196/175/R018	YT103-YT133
DC..	1A	W5158	0671	20		21-27-31	YT103-YT133
ST..	1A	W5158	0672	20		21-27-31	YT103-YT133
DC..	1A	W5158	0677	20		21-27-31	YT103-YT133
AC..	1A	W6491	0003	20		34-41-11	YT103-YT133
AC..	1A	W6491	0016	20		34-41-11	YT103-YT133
DC..	1A	W6491	0017	20		34-41-11	YT103-YT133
ST..	1A	W6491	0041	20		34-41-11	YT103-YT133
ST..	1A	W6491	0058	20		34-41-11	YT103-YT133
ST..	1A	W6491	0059	20		34-41-11	YT103-YT133
ST..	1A	W6491	0060	20		34-41-11	YT103-YT133
ST..	1A	W6491	0061	20		34-41-11	YT103-YT133
ST..	1A	W6491	0062	20		31-62-15	YT103-YT133
ST..	1A	W6491	0063	20		31-62-25	YT103-YT133
ST..	1A	W6491	0064	20		34-21-13	YT103-YT133
ST..	1A	W6491	0065	20		34-21-23	YT103-YT133
GD00408		BACC50AN20				375/170/R047	ALL
ST..	1A	W6414	0051	20		25-29-11	ALL
AC..	1A	W6414	0052	20		25-29-11	ALL
DC..	1A	W6414	0519	20		24-51-21	ALL
ST..	1A	W6414	5505	20		21-27-21	ALL
ST..	1A	W6430	5504	20		21-27-31	ALL
GD00412		AC-				286/190/L017	ALL
AC..	E	W5156	0601	18		32-31-11	ALL
AC..	E	W5156	0651	18		32-64-11	ALL
GD00420		BACC50AN20				419/206/L029	ALL
DC..	1A	W5161	0017	20		34-21-12	ALL
GD00424		DC-				418/203/R033	ALL
DC..	E	W2705	0013	16		34-36-11	ALL
DC..	E	W2705	0086	22		34-36-11	ALL
GD00426		BACC50AN16				418/203/R033	ALL
ST..	1	W2705	0014	16		34-36-11	ALL
GD00428		BACC50AN16				440/204/L012	ALL
ST..	1	W5086	6015	20		26-16-21	ALL

GROUND LIST

D280A351

91-21-21

Section GD00400

Page 1

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD00428		BACC50AN16 (continued)				440/204/L012	ALL
DC..	1	W5163	0017	20		34-21-22	ALL
AC..	1	W5248	0018	20		33-36-11	ALL
GD00430		BACC50AN16				460/202/L011	ALL
ST..	1	W5086	6005	20		26-16-21	ALL
ST..	1	W5086	6031	22		26-16-21	ALL
DC..	1	W5088	6010	22		26-16-21	ALL
DC..	1	W5088	6011	22		26-16-21	ALL
ST..	1	W5088	6012	22		26-16-21	ALL
AC..	1	W5248	0020	20		33-36-11	YT101-YT111, YT126-YT130
GD00431		BACC50AN16				907/205/R038	ALL
DC..	1	W5124	0510	20		27-31-11	ALL
DC..	1	W5124	0515	22		27-31-37	ALL
DC..	1	W5124	0570	20		29-25-11	ALL
DC..	1	W5124	0571	20		29-25-11	ALL
AC..	1	W5431	0001	20		23-71-01	ALL
ST..	1	W5431	0005	20		23-71-01	ALL
DC..	1	W5431	0006	20		23-71-01	ALL
DC..	1	W5431	0017	20		23-71-01	ALL
AC..	1	W6248	5573	20		30-71-11	ALL
AC..	1	W6248	5575	20		30-71-11	ALL
AC..	1	W6248	5577	20		30-71-11	ALL
AC..	1	W6248	5579	20		30-71-11	ALL
GD00432		BACC50AN16				460/203/R053	ALL
AC..	1	W5248	0012	20		33-36-11	ALL
GD00433		ST-				196/192/L029	ALL
DC..	E	W5501	0001	20		34-21-12	ALL
DC..	E	W5501	0007	20		34-21-12	ALL
GD00434		ST-				196/173/R011	ALL
ST..	E	W5156	5511	20		21-27-21	ALL
GD00435		AC-				197/190/L029	ALL
ST..	E	W5501	0010	22		27-32-11	ALL

GROUND LIST

D280A351

91-21-21

Section GD00400

Page 2

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
I GD00437		ST-				197/198/R030	ALL
I ST..	E	W5503	0009	22		27-32-21	ALL
I GD00439		DC-				197/198/R031	ALL
I DC..	E	W5503	0007	20		34-21-22	ALL
I GD00442		AC-				286/189/L017	ALL
I AC..	E	W5160	0002	16		33-45-11	YT101-YT112, YT126-YT130
I AC..	E	W5160	0603	18		32-31-12	ALL
I GD00446		AC-				244/180/R038	ALL
I AC..	E	W5160	0650	18		32-64-12	ALL
I GD00447		BACC50AN16				907/205/R053	ALL
I DC..	1	W5431	0037	20		23-71-01	ALL
I ST..	1	W5431	0055	20		23-27-35	ALL
I GD00448		BACC50AN16				479/203/L009	YT112-YT120, YT131-YT133
I AC..	1	W5248	0020	20		33-36-11	YT112-YT120, YT131-YT133
I GD00449		ST-				179/199/L005	ALL
I DC..	E	W6491	0044	20		34-41-11	ALL
I ST..	E	W6491	0051	20		34-41-11	ALL
I ST..	E	W6491	0052	20		34-41-11	ALL
I GD00451		ST-				179/198/L005	ALL
I ST..	E	W6491	2001Z			34-41-11	ALL
I ST..	E	W6491	2002Z			34-41-11	ALL
I ST..	E	W6491	2003Z			34-41-11	ALL
I GD00458		ST-				660/154/L032	ALL
I ST..	E	W5104	0331	20		21-51-14	ALL
I GD00459		ST-				179/197/L005	ALL
I GD00460		ST-				660/155/R033	ALL
I ST..	E	W6230	0331	20		21-51-24	ALL
I GD00462		ST-				OFSS 378/ /	ALL
I ST..	E	W1664	1017Z			28-44-11	ALL

GROUND LIST

D280A351

91-21-21

Section GD00400

Page 3

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD00462		ST- (continued)				OFSS 378/ /	ALL
ST..	E	W1664	1024Z			28-44-11	ALL
GD00467		ST-				848/215/L068	ALL
ST..	E	W4258	0030	10		25-29-12	ALL
GD00475		AC-				220/203/R015	ALL
AC..	E	W0445	0034KY	20		33-11-21	ALL
AC..	E	W6110	0006	20		33-34-11	ALL
GD00476		DC-				IRSS/215/	ALL
DC..	E	W7230	6002	18		28-42-11	ALL
GD00479		DC-				1157/285/R011	ALL
DC..	E	W3393	0011	20		22-18-11	ALL
DC..	E	W3393	0014	20		22-18-11	ALL
GD00490		ST-				665/174/L031	ALL
GD00492		DC				/ /	ALL

GROUND LIST

D280A351

91-21-21

Section GD00400

Page 4 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD00500		AC-				389/173/L053	ALL
AC..	F	W3154	0022	08		24-51-11	ALL
GD00501		BACC50AN20				P005-00/ /	ALL
DC..	1A	W2112	5558	20		36-21-11	ALL
DC..	1A	W2112	6015	20		74-31-11	ALL
DC..	1A	W2112	6018	20		74-31-11	ALL
DC..	1A	W2112	6020	20		74-31-11	ALL
ST..	1A	W2114	0019	20		33-44-11	ALL
DC..	1A	W2218	0015	20		33-25-11	ALL
DC..	1A	W2218	0016	20		33-25-11	ALL
DC..	1A	W2218	0019	20		33-25-11	ALL
DC..	1A	W2218	0029	20		33-51-11	ALL
DC..	1A	W2218	0032	20		33-51-11	ALL
DC..	1A	W2218	6014	20		74-31-11	ALL
DC..	1A	W2218	6015	20		74-31-11	ALL
DC..	1A	W2218	6020	20		74-31-11	ALL
DC..	1A	W2508	5575	20		33-18-37	ALL
GD00502		BACC50AN20				P005-00/ /	ALL
GD00503		BACC50AN20				P005-00/ /	ALL
DC..	1A	W2218	0522	20		24-28-11	ALL
DC..	1A	W2218	0557	20		24-28-11	ALL
DC..	1A	W2218	0558	20		24-28-11	ALL
DC..	1A	W2508	0504	20		24-32-11	ALL
DC..	1A	W2508	0517	20		24-34-11	ALL
DC..	1A	W2508	5528	20		33-18-31	ALL
DC..	1A	W2508	5538	20		33-18-33	ALL
DC..	1A	W2508	5539	20		33-18-33	ALL
DC..	1A	W2508	5543	20		33-18-33	ALL
DC..	1A	W2508	6010	20		28-21-11	ALL
ST..	1A	W2508	6013	20		28-43-11	ALL
DC..	1A	W2508	6027	20		76-21-11	ALL
DC..	1A	W2508	8001	20		34-51-41	ALL
DC..	1A	W2508	8003	20		34-51-41	ALL
AC..	1A	W2508	8006	20		34-21-15	ALL
DC..	1A	W2508	8018	20		34-21-15	ALL
GD00504		BACC50AN20				P005-00/ /	ALL

GROUND LIST

D280A351

91-21-21

Section GD00500

Page 1

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD00505		BACC50AN20				P005-00/ /	ALL
GD00506		BACC50AN20				P005-00/ /	ALL
DC..	1A	W2114	5504	20		21-61-51	ALL
DC..	1A	W2114	5505	20		21-61-51	ALL
DC..	1A	W2114	5516	20		30-31-11	ALL
ST..	1A	W2218	2003Z			30-41-12	ALL
DC..	1A	W2218	5502	22		21-27-21	ALL
ST..	1A	W2218	5509	20		21-31-23	ALL
ST..	1A	W2218	5510	20		21-31-23	ALL
DC..	1A	W2218	5516	20		21-51-22	ALL
DC..	1A	W2218	5545	20		36-11-11	ALL
AC..	1A	W2218	5550	20		36-21-11	ALL
DC..	1A	W2218	5565	20		21-61-13	ALL
DC..	1A	W2218	5567	20		21-61-15	ALL
ST..	1A	W2218	5573	20		30-41-12	YT101-YT116, YT126-YT131
ST..	1A	W2218	5573	24		30-41-12	YT117-YT120, YT132-YT133
DC..	1A	W2218	6007	20		30-21-21	ALL
DC..	1A	W2218	6011	20		73-23-11	ALL
ST..	1A	W2218	FRAA			21-31-23	ALL
GD00507		BACC50AN20				P005-00/ /	ALL
GD00508		BACC50AN20				P005-00/ /	ALL
DC..	1A	W2112	6026	20		73-21-12	ALL
ST..	1A	W2112	6027	20		73-21-12	ALL
DC..	1A	W2112	8008	20		27-32-11	ALL
ST..	1A	W2216	6007	20		73-21-12	ALL
DC..	1A	W2216	6008	20		73-21-12	ALL
AC..	1A	W2218	5655	20		33-12-12	ALL
AC..	1A	W2218	5733	20		33-12-12	ALL
DC..	1A	W2218	8002	20		27-32-21	ALL
DC..	1A	W2508	5596	20		33-18-42	ALL
DC..	1A	W2508	5602	20		33-18-42	ALL
DC..	1A	W2508	5644	20		35-11-11	ALL
DC..	1A	W2508	5646	20		35-21-11	ALL
DC..	1A	W3327	0005	22		23-51-31	ALL
ST..	1A	W3327	0011	20		23-51-31	ALL

GROUND LIST

D280A351

91-21-21

Section GD00500

Page 2

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD00509		BACC50AN20				P005-00/ /	ALL
ST..	1A	W2035	0036	20		34-21-11	ALL
DC..	1A	W2035	0039	20		34-16-11	ALL
DC..	1A	W2112	0016	20		30-81-11	ALL
ST..	1A	W2112	0017	20		30-81-11	ALL
DC..	1A	W2112	0019	20		30-81-11	ALL
AC..	1A	W2112	0020	20		30-81-11	ALL
ST..	1A	W2135	0002	20		34-21-21	ALL
DC..	1A	W2135	0031	20		34-16-21	ALL
DC..	1A	W2218	0523	20		27-81-11	ALL
ST..	1A	W2218	0556	20		27-81-11	ALL
AC..	1A	W2218	5734	20		33-12-12	ALL
DC..	1A	W2508	5628	20		33-18-42	ALL
DC..	1A	W2508	5655	20		33-18-42	ALL
DC..	1A	W2508	5667	20		33-18-37	ALL
DC..	1A	W2589	0016	22		23-24-11	ALL
GD00510		BACC50AN16				P005-00/ /	ALL
DC..	1	W2112	5556	18		30-42-11	ALL
DC..	1	W2112	6053	20		28-43-11	ALL
AC..	1	W2218	5561	18		33-14-12	ALL
AC..	1	W2218	5563	18		33-14-12	ALL
DC..	1	W2218	5575	18		30-42-11	ALL
AC..	1	W2218	5605	20		33-12-12	ALL
AC..	1	W2218	5609	20		33-12-12	ALL
GD00512		BACC50AN20				J004-00/ /	ALL
DC..	1A	W0094	0165	20		44-21-22	ALL
AC..	1A	W0094	0238	20		33-42-21	YT113-YT120, YT131-YT133
ST..	1A	W0094	0536	20		44-35-20	YT101-YT102
DC..	1A	W0094	0536	20		44-35-20	YT103-YT133
GD00514		BACC50AN16				J004-00/ /	ALL
AC..	1	W0094	0084	20		33-42-21	YT113-YT120, YT131-YT133
GD00515		BACC50AN20				P005-00/ /	ALL
DC..	1A	W2112	0513	20		24-28-11	ALL
DC..	1A	W2114	5502	22		21-27-31	ALL
DC..	1A	W2114	8002	20		34-41-11	ALL
DC..	1A	W2135	0019	22		31-62-25	ALL

GROUND LIST

D280A351

91-21-21

Section GD00500

Page 3

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD00515		BACC50AN20 (continued)				P005-00/ /	ALL
DC..	1A	W2135	0025	20		34-51-41	ALL
DC..	1A	W2135	0026	20		34-51-41	ALL
DC..	1A	W2135	0030	22		31-62-25	ALL
DC..	1A	W2218	0512	20		24-28-11	ALL
ST..	1A	W2218	0513	20		24-28-11	ALL
AC..	1A	W2508	8013	20		34-21-15	ALL
DC..	1A	W2510	0504	20		24-31-12	ALL
DC..	1A	W2510	5703	20		31-52-41	ALL
DC..	1A	W2510	6001	20		28-21-11	ALL
ST..	1A	W2510	6013	20		28-43-11	ALL
DC..	1A	W2510	6016	20		76-21-21	ALL
GD00516		BACC50AN20				P005-00/ /	ALL
ST..	1A	W2112	2003Z			30-41-11	ALL
DC..	1A	W2112	5506	22		21-27-21	ALL
DC..	1A	W2112	5512	20		21-31-22	ALL
ST..	1A	W2112	5514	20		21-31-22	ALL
ST..	1A	W2112	5515	20		21-31-22	ALL
DC..	1A	W2112	5531	24		30-41-11	YT117-YT120, YT132-YT133
DC..	1A	W2112	5536	24		30-41-11	YT117-YT120, YT132-YT133
ST..	1A	W2112	5542	20		30-41-11	ALL
DC..	1A	W2112	6003	20		34-61-17	ALL
DC..	1A	W2112	6005	20		34-61-17	ALL
DC..	1A	W2112	6006	20		34-61-17	ALL
DC..	1A	W2112	6011	20		30-11-11	ALL
DC..	1A	W2112	6029	20		73-23-11	ALL
ST..	1A	W2112	FRAA			21-31-22	ALL
DC..	1A	W2218	5577	20		36-21-11	ALL
ST..	1A	W2218	5578	20		36-21-11	ALL
GD00517		BACC50AN20				P005-00/ /	ALL
DC..	1A	W2035	0029	22		31-62-15	ALL
DC..	1A	W2035	0038	22		31-62-15	ALL
DC..	1A	W2112	0502	20		24-11-11	ALL
ST..	1A	W2112	0514	20		24-28-11	ALL
DC..	1A	W2112	0515	20		24-28-11	ALL
DC..	1A	W2112	0520	20		27-83-11	ALL
DC..	1A	W2112	8010	20		34-51-41	ALL
DC..	1A	W2112	8017	20		22-23-11	ALL
DC..	1A	W2112	8018	20		22-23-11	ALL

GROUND LIST

D280A351

91-21-21

Section GD00500

Page 4

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD00517		BACC50AN20 (continued)				P005-00/ /	ALL
AC..	1A	W2112	8024	20		34-21-15	ALL
DC..	1A	W2212	0512	20		27-23-14	ALL
DC..	1A	W2216	5525	22		21-27-31	ALL
AC..	1A	W2218	0514	20		24-28-11	ALL
AC..	1A	W2218	6002	20		28-42-11	ALL
DC..	1A	W2218	8004	20		34-51-41	ALL
DC..	1A	W2508	8011	22		34-36-12	ALL
GD00518		BACC50AN20				P005-00/ /	ALL
DC..	1A	W2216	5527	20		21-51-12	ALL
DC..	1A	W2216	5550	20		30-31-12	ALL
DC..	1A	W2216	5560	20		21-61-11	ALL
ST..	1A	W2216	5561	20		21-61-11	ALL
DC..	1A	W2216	5564	20		21-61-14	ALL
DC..	1A	W2216	6004	20		34-61-17	ALL
DC..	1A	W2216	6005	20		34-61-17	ALL
DC..	1A	W2508	5502	20		21-31-11	ALL
DC..	1A	W2508	5568	20		33-18-36	ALL
DC..	1A	W2508	5603	20		33-18-36	ALL
DC..	1A	W2508	5619	20		21-51-11	ALL
DC..	1A	W2508	5632	20		33-18-35	ALL
DC..	1A	W2508	5745	20		33-18-35	ALL
ST..	1A	W2508	FRAB			21-31-11	ALL
DC..	1A	W2510	5504	20		21-31-23	ALL
DC..	1A	W2510	5506	22		21-43-21	ALL
GD00519		BACC50AN20				P005-00/ /	ALL
AC..	1A	W2216	5703	20		33-12-11	ALL
AC..	1A	W2216	5705	20		33-12-11	ALL
AC..	1A	W2216	5707	20		33-12-11	ALL
AC..	1A	W2216	5709	20		33-12-11	ALL
AC..	1A	W2218	5703	20		33-12-12	ALL
AC..	1A	W2218	5709	20		33-12-12	ALL
AC..	1A	W2218	5710	20		33-12-12	ALL
AC..	1A	W2218	5713	20		33-12-12	ALL
AC..	1A	W2218	5716	20		33-12-12	ALL
DC..	1A	W2508	0025	20		34-24-15	ALL
DC..	1A	W2508	8027	22		34-36-12	ALL
DC..	1A	W2508	8028	22		34-36-12	ALL
DC..	1A	W2510	6051	22		24-28-41	ALL

GROUND LIST

D280A351

91-21-21

Section GD00500

Page 5

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD00520		BACC50AN20				P005-00/ /	ALL
DC..	1A	W2212	0523	20		29-35-11	ALL
DC..	1A	W2212	0526	20		29-35-11	ALL
AC..	1A	W2216	5603	20		33-12-11	ALL
AC..	1A	W2216	5605	20		33-12-11	ALL
AC..	1A	W2216	5607	20		33-12-11	ALL
AC..	1A	W2216	5609	20		33-12-11	ALL
AC..	1A	W2216	5611	20		33-12-11	ALL
AC..	1A	W2216	5653	20		33-12-11	ALL
AC..	1A	W2216	5655	20		33-12-11	ALL
AC..	1A	W2216	5659	20		33-12-11	ALL
AC..	1A	W2216	5663	20		33-12-11	ALL
AC..	1A	W2216	5665	20		33-12-11	ALL
DC..	1A	W2218	5532	24		30-41-12	YT117-YT118
DC..	1A	W2218	5533	24		30-41-12	YT117-YT118
AC..	1A	W2218	5705	20		33-12-12	ALL
GD00522		BACC50AN16				J022-00/ /	ALL
DC..	1	W0076	0095	20		30-81-11	ALL
DC..	1	W0076	0310	18		78-32-51	ALL
DC..	1	W0076	0312	18		78-32-51	ALL
DC..	1	W0076	0413	20		31-31-15	ALL
GD00524		BACC50AN20				J024-00/ /	ALL
DC..	1A	W0080	0502	20		27-62-11	ALL
DC..	1A	W0080	0515	20		32-41-11	ALL
DC..	1A	W0080	0522	20		32-44-11	ALL
ST..	1A	W0080	2601Z			73-21-11	ALL
DC..	1A	W0080	5617	20		31-35-03	ALL
DC..	1A	W0080	6008	24		73-22-31	ALL
DC..	1A	W0080	6014	20		76-21-21	ALL
DC..	1A	W0080	6032	20		78-34-21	ALL
DC..	1A	W0080	6088	20		47-30-11	ALL
DC..	1A	W0080	6108	20		47-30-11	ALL
DC..	1A	W0080	6504	22		31-31-11	ALL
DC..	1A	W0080	6510	22		31-31-11	ALL
GD00526		BACC50AN16				J023-00/ /	ALL
DC..	1	W0078	0317	20		35-21-11	ALL
DC..	1	W0078	0327	20		35-21-11	ALL

GROUND LIST

D280A351

91-21-21

Section GD00500

Page 6

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD00528		BACC50AN20				J020-0B/ /	ALL
DC..	1A	W0072	0112	20		21-27-31	ALL
DC..	1A	W0072	0130	20		46-15-11	ALL
DC..	1A	W0072	0134	20		21-27-31	ALL
DC..	1A	W0072	0153	22		27-62-11	ALL
DC..	1A	W0072	0164	22		27-62-11	ALL
DC..	1A	W0072	0171	22		27-62-11	ALL
DC..	1A	W0072	0173	20		78-34-21	ALL
DC..	1A	W0072	0177	22		27-62-11	ALL
DC..	1A	W0072	0184	22		27-62-11	ALL
DC..	1A	W0072	0185	22		27-62-11	ALL
DC..	1A	W0072	0189	22		27-62-11	ALL
DC..	1A	W0072	0190	22		27-62-11	ALL
DC..	1A	W0072	0224	20		27-62-11	ALL
DC..	1A	W0072	0284	20		23-42-11	YT106-YT120
DC..	1A	W0072	0289	20		23-42-11	YT106-YT120
GD00532		BACC50AN20				J022-00/ /	ALL
DC..	1A	W0076	0010	20		52-71-13	ALL
DC..	1A	W0076	0018	20		52-71-13	ALL
DC..	1A	W0076	0161	20		26-23-11	ALL
DC..	1A	W0076	0213	22		27-62-11	ALL
DC..	1A	W0076	0218	24		32-41-11	ALL
DC..	1A	W0076	0264	22		27-62-11	ALL
DC..	1A	W0076	0268	22		27-62-11	ALL
DC..	1A	W0076	0276	20		34-61-26	ALL
DC..	1A	W0076	0278	20		34-61-26	ALL
DC..	1A	W0076	0338	20		47-30-11	ALL
DC..	1A	W0076	0341	20		47-30-11	ALL
DC..	1A	W0076	0408	20		31-35-03	ALL
DC..	1A	W0076	0528	22		78-32-51	ALL
ST..	1A	W0076	1001Z			73-22-11	ALL
ST..	1A	W0076	1002Z			73-22-11	ALL
GD00534		BACC50AN20				J024-00/ /	ALL
DC..	1A	W0080	0008	20		52-71-14	ALL
DC..	1A	W0080	0009	20		52-71-14	ALL
DC..	1A	W0080	5539	22		21-27-21	ALL
DC..	1A	W0080	6020	22		78-32-61	ALL
DC..	1A	W0080	6021	22		78-32-61	ALL

GROUND LIST

D280A351

91-21-21

Section GD00500

Page 7

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD00534		BACC50AN20 (continued)				J024-00/ /	ALL
DC..	1D	W0080	6023	18		78-32-61	ALL
DC..	1D	W0080	6024	18		78-32-61	ALL
DC..	1A	W0080	6025	22		78-32-61	ALL
DC..	1D	W0080	6026	18		78-32-61	ALL
DC..	1A	W0080	6028	22		78-32-61	ALL
DC..	1D	W0080	6029	18		78-32-61	ALL
DC..	1D	W0080	6043	18		78-32-61	ALL
DC..	1D	W0080	6049	18		78-32-61	ALL
DC..	1D	W0080	6103	18		78-32-61	ALL
GD00540		AC-				191/242/R002	ALL
GD00541		AC-				191/242/L002	ALL
AC..	E	W2363	1063	20		33-11-31	ALL
DED		W2363	1063Z			33-11-31	ALL
GD00542		BACC50AN20				J022-00/ /	ALL
DC..	1A	W0076	0086	22		34-41-11	ALL
DC..	1A	W0076	0115	20		78-34-11	ALL
DC..	1A	W0076	0117	20		23-11-16	ALL
DC..	1A	W0076	0125	24		73-22-31	ALL
DC..	1A	W0076	0128	22		31-31-11	ALL
DC..	1A	W0076	0138	20		76-21-11	ALL
DC..	1A	W0076	0152	22		78-32-51	ALL
DC..	1D	W0076	0155	18		78-32-51	ALL
DC..	1D	W0076	0157	18		78-32-51	ALL
DC..	1A	W0076	0172	22		78-32-51	ALL
DC..	1A	W0076	0174	22		78-32-51	ALL
DC..	1A	W0076	0274	20		78-34-11	ALL
DC..	1D	W0076	0350	18		78-32-51	ALL
ST..	1D	W0076	0529	18		78-32-51	ALL
DC..	1D	W0076	0530	18		78-32-51	ALL
ST..	1A	W0076	2001Z			73-21-11	ALL
GD00544		BACC50AN16				J024-00/ /	ALL
DC..	1	W0080	1309R	20		26-21-11	ALL
DED		W0080	1309Z			26-21-11	ALL
DC..	1	W0080	1310R	20		26-21-11	ALL
DED		W0080	1310Z			26-21-11	ALL
DC..	1	W0080	5504	20		21-25-11	ALL

GROUND LIST

D280A351

91-21-21

Section GD00500

Page 8

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD00544		BACC50AN16 (continued)				J024-00/ /	ALL
DC..	1	W0080	5518	22		21-43-21	ALL
DC..	1	W0080	5521	22		21-43-21	ALL
DC..	1	W0080	5524	22		21-43-21	ALL
DC..	1	W0080	5552	20		21-25-11	ALL
DC..	1	W0080	5558	20		21-25-11	ALL
DC..	1	W0080	5613	20		21-27-21	ALL
DC..	1	W0080	6113	20		31-31-15	ALL
GD00545		ST-				/ /	ALL
GD00546		BACC50AN20				J023-00/ /	ALL
GD00548		AC-				597/158/L007	ALL
AC..	GW	W5502	0004	20		33-33-11	YT112-YT120, YT131-YT133
AC..	GW	W5502	1007	20		36-11-11	ALL
AC..	GW	W5502	1007Z			36-11-11	ALL
GD00550		AC-				/ /	ALL
GD00552		AC-				655/156/L039	ALL
AC..	GW	W5102	0014	20		33-33-11	ALL
AC..	GW	W5102	1202	20		33-44-11	ALL
AC..	GW	W5102	1202Z			33-44-11	ALL
GD00556		AC-				653/156/R009	ALL
AC..	GW	W6202	1032	20		21-51-22	ALL
AC..	GW	W6202	1032Z			21-51-22	ALL
GD00558		AC-				653/155/L009	ALL
GD00568		ST-				373/184/R048	ALL
ST..	E	W2108	FRAD			30-41-11	YT101-YT116, YT126-YT131
ST..	E	W2208	FRAD			30-41-12	YT101-YT116, YT126-YT131
GD00570		ST-				/ /	ALL
GD00572		DC-				364/157/L029	ALL
DC..	F	W2536	0513	08		24-34-11	ALL
GD00574		ST-				J009/ /	ALL

GROUND LIST

D280A351

91-21-21

Section GD00500

Page 9

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
I GD00578		BACC50AN20				P0015/ /	ALL
I GD00582		DC-				/ /	ALL
I GD00588		BACC50AN20				J022-00/ /	ALL
I DC..	1A	W0076	0353	20		46-15-11	ALL
I DC..	1A	W0076	0415	22		44-21-22	ALL
I DC..	1A	W0076	0416	20		46-13-11	YT104-YT133
I GD00590		AC-				372/157/L048	ALL
I AC..	E	W5142	2428B	18		33-23-11	ALL
I AC..	E	W5142	2429B	18		33-23-11	ALL
I AC..	E	W5142	2430B	18		33-23-11	ALL
I GD00592		AC-				373/157/L030	ALL
I AC..	E	W5142	2431B	18		33-23-11	ALL
I AC..	E	W5142	2432B	18		33-23-12	ALL
I AC..	E	W5142	2433B	18		33-23-12	ALL
I GD00594		AC-				374/157/L030	ALL
I AC..	E	W5142	2434B	18		33-23-12	ALL
I AC..	E	W5142	2435B	18		33-23-12	ALL
I AC..	E	W5142	2436B	18		33-23-12	ALL
I GD00596		AC-				213/208/L036	ALL
I AC..	E	W2102	5518	20		33-11-11	ALL
I AC..	E	W2102	5535	20		33-17-11	ALL
I GD00598		BACC50AN20				220/264/L027	ALL

GROUND LIST

D280A351

91-21-21

Section GD00500

Page 10 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD00600		AC-				387/167/R047	ALL
AC..	F	W4256	0022	08		24-51-21	ALL
GD00602		AC-				195/208/L032	ALL
AC..	E	W5501	0006	20		34-21-12	ALL
AC..	E	W5501	0009	22		27-32-11	ALL
AC..	E	W5501	0013	22		30-31-11	ALL
GD00604		AC-				223/267/L015	ALL
AC..	E	W2102	5528	20		33-17-11	ALL
GD00606		AC-				195/208/R033	ALL
AC..	E	W5503	0006	20		34-21-22	ALL
AC..	E	W5503	0008	22		27-32-21	ALL
AC..	E	W5503	0011	22		30-31-12	ALL
AC..	E	W5503	0013	22		30-31-12	ALL
GD00608		AC-				P006-00/ /	ALL
AC..	E	W0044	0074	10		33-12-11	ALL
AC..	E	W0044	0084	10		33-12-12	ALL
AC..	E	W0044	0456	20		21-31-25	ALL
GD00610		AC-				223/267/R015	ALL
AC..	E	W2204	5507	18		33-14-12	ALL
AC..	E	W2204	5510	20		33-17-11	ALL
AC..	E	W2204	B-BG			33-17-11	ALL
GD00612		AC-				244/180/R037	ALL
AC..	E	W6024	0503	22		24-41-11	ALL
GD00614		AC-				IFSS-167/ /	ALL
AC..	E	W1180	J-Y			27-81-11	ALL
GD00618		AC-				P006-00/ /	ALL
AC..	E	W0044	A-AG			33-17-11	ALL
GD00620		BACC50AN20				P006-00/ /	ALL
DC..	1A	W0044	0022	24		24-31-11	ALL
DC..	1A	W0044	0127	20		33-18-11	ALL
DC..	1A	W0044	0181	20		33-18-36	ALL

GROUND LIST

D280A351

91-21-21

Section GD00600

Page 1

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD00620		BACC50AN20 (continued)				P006-00/ /	ALL
DC..	1A	W0044	0559	22		49-31-31	ALL
DC..	1A	W0044	0564	20		33-29-11	ALL
GD00622		DC-				P006-00/ /	ALL
DC..	E	W0044	0454	22		21-31-23	ALL
GD00624		BACC50AN16				P006-00/ /	ALL
AC..	1	W0041	0002	22		31-32-15	YT102-YT133
AC..	1	W0041	0011	22		31-32-15	ALL
DC..	1	W0041	0038	20		31-52-71	ALL
DC..	1	W0041	0055	20		34-58-21	ALL
DC..	1	W0041	0057	20		23-51-31	ALL
DC..	1	W0041	0104	20		34-58-11	ALL
DC..	1	W0041	0106	20		34-58-11	ALL
DC..	1	W0044	0249	22		31-53-11	ALL
DC..	1	W0044	0539	20		33-18-62	ALL
ST..	1	W0044	0991	16		44-21-10	YT101-YT120
GD00626		BACC50AN20				P006-00/ /	ALL
DC..	1A	W0044	0110	20		33-18-11	ALL
DC..	1A	W0044	0111	20		33-18-11	ALL
DC..	1A	W0044	0113	20		33-18-11	ALL
DC..	1A	W0044	0114	20		33-18-11	ALL
DC..	1A	W0044	0120	20		33-18-11	ALL
DC..	1A	W0044	0123	20		33-18-11	ALL
DC..	1A	W0044	0444	20		21-31-11	ALL
DC..	1A	W0044	0450	20		21-31-22	ALL
GD00628		DC-				P006-00/ /	ALL
DC..	E	W0044	A-AB			33-14-12	ALL
GD00630		BACC50AN20				P006-00/ /	ALL
AC..	1A	W0044	0367	24		24-32-11	ALL
AC..	1A	W0044	0368	24		24-32-11	ALL
DC..	1A	W0044	0525	24		24-31-12	ALL
GD00632		BACC50AN20				P006-00/ /	ALL
DC..	1A	W0044	0524	24		24-31-12	ALL
DC..	1A	W0044	0526	24		24-31-12	ALL

GROUND LIST

D280A351

91-21-21

Section GD00600

Page 2

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD00632		BACC50AN20 (continued)				P006-00/ /	ALL
DC..	1A	W0044	0550	24		24-31-11	ALL
DC..	1A	W0044	0551	24		24-31-11	ALL
GD00634		AC-				P006-00/ /	ALL
AC..	E	W0040	6204	08		24-53-11	ALL
GD00636		AC-				P006-00/ /	ALL
AC..	E	W0040	6207	10		24-53-11	ALL
GD00638		BACC50AN20				P006-00/ /	ALL
DC..	1A	W0044	0252	20		25-29-11	ALL
ST..	1A	W0044	0253	20		25-29-11	ALL
AC..	1A	W0044	0255	20		25-29-11	ALL
ST..	1A	W0044	0256	20		25-29-11	ALL
ST..	1A	W0044	0646	20		28-21-21	ALL
DC..	1A	W0044	0651	20		28-21-21	ALL
DC..	1A	W0044	0655	20		28-21-21	ALL
DC..	1A	W0044	0901	22		52-51-11	ALL
ST..	1A	W0044	0906	22		52-51-11	ALL
DC..	1A	W0044	0907	22		52-51-11	ALL
DC..	1A	W0044	0941	20		28-23-11	ALL
GD00642		BACC50AN20				P006-00/ /	ALL
DC..	1A	W0044	0937	20		28-23-11	ALL
AC..	1A	W0044	0997	20		23-70-11	ALL
DC..	1A	W0044	6116	20		44-21-10	ALL
GD00644		ST-				P006-00/ /	ALL
ST..	F	W0044	0692	08		24-31-12	ALL
GD00652		ST-				345/160/L021	ALL
GD00654		BACC50AN16				867/196/R061	ALL
DC..	1	W5124	0526	20		27-41-12	ALL
AC..	1	W5124	0548	20		33-26-31	ALL
DC..	1	W5726	0554	16		49-62-51	ALL
ST..	1	W5726	0555	16		49-62-51	ALL
ST..	1	W5726	0556	20		49-62-51	ALL

GROUND LIST

D280A351

91-21-21

Section GD00600

Page 3

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD00656		DC-				660/153/L032	ALL
DC..	E	W5104	0334	20		21-51-14	ALL
GD00658		DC-				660/154/R033	ALL
DC..	E	W6230	0334	20		21-51-24	ALL
GD00660		DC				//	ALL
GD00662		BACC50AN20				721/204/R035	ALL
ST..	1A	W5204	1001Z			47-30-11	ALL
ST..	1A	W5204	1002Z			47-30-11	ALL
ST..	1A	W5204	1003Z			47-30-11	ALL
ST..	1A	W5204	1004Z			47-30-11	ALL
ST..	1A	W5204	1005Z			47-30-11	ALL
ST..	1A	W5204	1006Z			47-30-11	ALL
ST..	1A	W5204	1007Z			47-30-11	ALL
ST..	1A	W5204	1008Z			47-30-11	ALL
ST..	1A	W5204	1009Z			47-30-11	ALL
ST..	1A	W5204	1010Z			47-30-11	ALL
DC..	1A	W6124	0526	22		31-53-11	ALL
ST..	1A	W6124	5501Z			21-51-14	ALL
DC..	1A	W6228	0511	22		32-42-11	ALL
DC..	1A	W6228	0512	22		32-42-11	ALL
DC..	1A	W6228	0592	22		32-41-11	ALL
GD00674		DC-				//	ALL
GD00690		AC-				374/167/R047	ALL
AC..	E	W6242	2428B	18		33-23-21	ALL
AC..	E	W6242	2429B	18		33-23-21	ALL
AC..	E	W6242	2430B	18		33-23-21	ALL
GD00692		AC-				375/168/R047	ALL
AC..	E	W6242	2431B	18		33-23-21	ALL
AC..	E	W6242	2432B	18		33-23-22	ALL
AC..	E	W6242	2433B	18		33-23-22	ALL
GD00694		AC-				376/168/R047	ALL
AC..	E	W6242	2434B	18		33-23-22	ALL
AC..	E	W6242	2435B	18		33-23-22	ALL

GROUND LIST

D280A351

91-21-21

Section GD00600

Page 4

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD00694		AC- (continued)				376/168/R047	ALL
AC..	E	W6242	2436B	18		33-23-22	ALL

GROUND LIST

D280A351

91-21-21

Section GD00600

Page 5 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
I GD00701		DC-				P007-01/ /	ALL
I DC..	E	W0001	0281	18		31-62-11	ALL
I GD00702		ST-				/ /	ALL
I GD00703		DC-				P007-02/ /	ALL
I DC..	E	W0003	0681	18		31-62-21	ALL
I GD00704		ST-				/ /	ALL
I GD00706		ST-				/ /	ALL
I GD00708		ST-				/ /	ALL
I GD00710		ST-				IFSS-84/ /	ALL
I ST..	E	W5104	0332	20		21-51-14	ALL
I GD00712		DC-				IFSS-84/ /	ALL
I DC..	E	W5104	0333	20		21-51-14	ALL
I GD00714		ST-				520/175/R058	ALL
I ST..	E	W6230	0332	20		21-51-24	ALL
I GD00716		DC-				520/174/R057	ALL
I DC..	E	W6230	0333	20		21-51-24	ALL
I GD00722		BACC50AN20				P015-00/ /	ALL
I GD00748		AC-				365/158/L030	ALL
I AC..	F	W2536	0514	12		24-34-11	ALL
I GD00752		DC-				367/152/L019	ALL
I DC..	F8	W2532	0534	02		24-31-11	ALL
I GD00754		ST-				/ /	ALL
I GD00756		ST-				685/157/R007	ALL
I ST..	E	W8228	2601Z			78-34-21	ALL
I ST..	E	W8228	2602Z			78-34-21	ALL
I ST..	E	W8228	2603Z			78-34-21	ALL

GROUND LIST

D280A351

91-21-21

Section GD00700

Page 1

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD00756		ST- (continued)				685/157/R007	ALL
ST..	E	W8228	3601Z			78-36-21	ALL
ST..	E	W8228	3602Z			78-36-21	ALL
GD00758		ST-				//	ALL
GD00760		DC-				663/155/L016	ALL
ST..	E	W7522	2601Z			78-34-11	ALL
ST..	E	W7522	2602Z			78-34-11	ALL
ST..	E	W7522	2603Z			78-34-11	ALL
ST..	E	W7522	3601Z			78-36-11	ALL
ST..	E	W7522	3602Z			78-36-11	ALL
GD00790		AC-				//	ALL
GD00792		AC-				//	ALL
GD00794		AC-				//	ALL
GD00796		AC-				//	ALL

GROUND LIST

D280A351

91-21-21

Section GD00700

Page 2 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD00800		BACC50AN20				208/203/R014	ALL
DC..	1A	W5369	0021	20		22-13-11	ALL
DC..	1A	W5369	0022	20		22-13-11	ALL
DC..	1A	W5369	0023	20		22-13-11	ALL
DC..	1A	W5369	0107	22		22-31-51	ALL
DC..	1A	W5506	6011	20		76-21-11	ALL
DC..	1A	W5510	6001	20		76-21-11	ALL
DC..	1A	W5514	5550	20		21-33-11	ALL
DC..	1A	W6208	0563	20		31-53-11	ALL
DC..	1A	W6208	0576	20		27-62-21	ALL
DC..	1A	W6208	0623	20		32-64-21	ALL
DC..	1A	W6208	5507	20		33-18-61	ALL
GD00801		BACC50AN20				P008-00/ /	ALL
DC..	1A	W2149	0011	22		34-51-11	ALL
DC..	1A	W2149	0014	22		34-51-11	YT120, YT130-YT133
DC..	1A	W2149	0028	20		34-51-41	ALL
DC..	1A	W2149	0048	22		34-51-11	ALL
DC..	1A	W2177	0006	20		34-53-11	ALL
ST..	1A	W2177	0028	20		34-53-11	ALL
ST..	1A	W2247	0029	20		34-53-21	ALL
ST..	1A	W2413	0001	20		23-12-11	ALL
DC..	1A	W2413	0041	20		23-12-11	ALL
ST..	1A	W2889	0015	20		34-61-23	ALL
AC..	1A	W6208	0513	20		27-28-11	ALL
AC..	1A	W6208	0515	20		27-28-11	ALL
ST..	1A	W6208	0516	20		27-28-11	ALL
GD00802		BACC50AN16				208/203/R014	ALL
DC..	1	W5503	0017	20		21-33-11	ALL
DC..	1	W6208	0614	20		27-41-11	ALL
DC..	1	W6208	0615	20		27-41-11	ALL
AC..	1	W6208	5506	16		33-11-41	ALL
GD00803		BACC50AN20				P008-00/ /	ALL
DC..	1A	W2151	0011	22		34-51-21	ALL
DC..	1A	W2151	0014	22		34-51-21	YT120, YT130-YT133
DC..	1A	W2151	0028	20		34-51-41	ALL
DC..	1A	W2151	0048	22		34-51-21	ALL
DC..	1A	W2247	0006	20		34-53-21	ALL
DC..	1A	W2307	0002	20		23-31-01	ALL

GROUND LIST

D280A351

91-21-21

Section GD00800

Page 1

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD00803		BACC50AN20 (continued)				P008-00/ /	ALL
AC..	1A	W2805	0002	20		31-33-01	ALL
ST..	1A	W2805	0003	20		31-33-01	ALL
DC..	1A	W2805	0004	20		31-33-01	ALL
AC..	1A	W2805	0006	20		33-11-41	ALL
DC..	1A	W3323	0005	22		23-51-11	ALL
ST..	1A	W3323	0011	20		23-51-11	ALL
DC..	1A	W5457	0107	22		22-31-51	ALL
DC..	1A	W6208	0630	20		27-41-11	ALL
DC..	1A	W6208	0631	20		27-41-11	ALL
GD00805		BACC50AN20				P008-00/ /	ALL
AC..	1A	W2149	0052	20		33-11-33	ALL
AC..	1A	W2151	0052	20		33-11-41	ALL
AC..	1A	W2177	0002	20		33-11-33	ALL
AC..	1A	W2265	0006	20		33-11-33	ALL
AC..	1A	W2413	0038	20		33-11-33	ALL
AC..	1A	W2415	0038	20		33-11-41	ALL
AC..	1A	W2705	0053	20		33-11-41	ALL
AC..	1A	W3319	0009	20		33-11-33	ALL
AC..	1A	W3323	0009	20		33-11-33	ALL
AC..	1A	W5506	5505	20		33-11-33	ALL
AC..	1A	W6206	5534	20		33-11-41	ALL
AC..	1A	W6208	5502	20		33-11-41	ALL
AC..	1A	W6208	5504	20		33-11-41	ALL
AC..	1A	W6491	2019B	20		33-11-41	ALL
GD00806		ST-				E008-01/ /	ALL
ST..	E	W0811	0073	10		25-29-12	ALL
GD00807		BACC50AN20				P008-00/ /	ALL
DC..	1A	W2110	6010	20		26-16-21	ALL
DC..	1A	W2110	6011	20		26-16-21	ALL
ST..	1A	W2110	6012	20		26-16-21	ALL
AC..	1A	W2110	6033	20		33-11-33	ALL
ST..	1A	W2415	0001	20		23-12-21	ALL
DC..	1A	W2415	0041	20		23-12-21	ALL
ST..	1A	W2417	0001	20		23-12-31	ALL
AC..	1A	W2417	0038	20		33-11-41	ALL
DC..	1A	W2417	0041	20		23-12-31	ALL
ST..	1A	W2873	0015	20		34-61-23	ALL

GROUND LIST

D280A351

91-21-21

Section GD00800

Page 2

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD00807		BACC50AN20 (continued)				P008-00/ /	ALL
AC..	1A	W3709	0002	20		33-11-41	ALL
DC..	1A	W6206	0011	22		52-51-11	ALL
GD00808		AC-				E008-01/ /	ALL
AC..	E	W0811	0074	10		25-29-12	ALL
GD00809		BACC50AN20				P008-00/*/*	ALL
DC..	1A	W3319	0005	22		23-51-21	ALL
ST..	1A	W3319	0011	20		23-51-21	ALL
DC..	1A	W5369	0028	20		22-13-11	ALL
DC..	1A	W5369	0031	20		22-13-11	ALL
DC..	1A	W5506	6026R	22		26-11-11	ALL
DC..	1A	W6208	0521	20		27-41-11	ALL
DC..	1A	W6208	0522	20		27-41-11	ALL
DC..	1A	W6208	0527	20		27-41-11	ALL
DC..	1A	W6208	0528	20		27-41-11	ALL
DC..	1A	W6506	6007	20		76-21-21	ALL
DC..	1A	W6510	6007	20		76-21-21	ALL
GD00811		BACC50AN20				P008-00/ /	ALL
ST..	1A	W2149	0042	20		34-51-11	ALL
AC..	1A	W2149	0055	20		34-51-11	ALL
ST..	1A	W2151	0042	20		34-51-21	ALL
AC..	1A	W2151	0055	20		34-51-21	ALL
AC..	1A	W2177	0004	20		34-53-11	ALL
DC..	1A	W2177	0008	20		34-53-11	ALL
AC..	1A	W2247	0004	20		34-53-21	ALL
DC..	1A	W2247	0008	20		34-53-21	ALL
ST..	1A	W2265	0001	20		34-57-11	ALL
AC..	1A	W2265	0004	20		34-57-11	ALL
ST..	1A	W2267	0001	20		34-57-21	ALL
AC..	1A	W2267	0004	20		34-57-21	ALL
AC..	1A	W6208	0510	20		27-21-11	ALL
ST..	1A	W6208	0511	20		27-21-11	ALL
AC..	1A	W6208	0564	20		27-11-11	ALL
GD00813		BACC50AN20				P008-00/*/*	ALL
DC..	1A	W5510	0540	22		31-53-11	ALL
DC..	1A	W5510	0571	22		32-64-21	ALL
DC..	1A	W5510	0573	22		32-64-21	ALL

GROUND LIST

D280A351

91-21-21

Section GD00800

Page 3

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD00813		BACC50AN20 (continued)				P008-00/*/*	ALL
DC..	1A	W5510	6087	22		30-11-11	ALL
DC..	1A	W6491	0014	20		34-41-11	ALL
DC..	1A	W6506	0540	22		31-53-11	ALL
DC..	1A	W6506	0559	22		32-64-21	ALL
DC..	1A	W6506	0560	22		32-64-21	ALL
DC..	1A	W6506	6001R	20		26-11-31	ALL
DC..	1A	W6506	6004R	20		26-11-31	ALL
DC..	1A	W6506	6084R	22		26-11-21	ALL
DC..	1A	W6506	6086	22		30-11-11	ALL
DC..	1A	W6510	6017	20		76-21-21	YT113-YT120, YT132-YT133
GD00815		BACC50AN20				P008-00/*/*	ALL
ST..	1A	W5162	6003	20		73-21-21	ALL
ST..	1A	W5172	6002	20		73-21-21	ALL
ST..	1A	W5506	6085	20		78-35-11	ALL
DC..	1A	W5510	6022	20		76-21-11	YT113-YT120, YT132-YT133
ST..	1A	W6162	6003	20		73-21-21	ALL
ST..	1A	W6172	6002	20		73-21-21	ALL
ST..	1A	W6491	0042	20		34-41-11	ALL
ST..	1A	W6506	6079	20		78-35-21	ALL
GD00817		BACC50AN16				J019-00/ /	ALL
AC..	1	W6206	5502	16		33-11-33	ALL
AC..	1	W6206	5508	16		33-11-33	ALL
AC..	1	W6206	5522	16		33-11-41	ALL
AC..	1	W6206	5529	16		33-11-41	ALL
AC..	1	W6206	5530	16		33-11-41	ALL
AC..	1	W6206	5538	18		33-14-12	ALL
GD00822		AC-				IFSS-118/ /	YT113-YT120, YT131-YT133
AC..	GW	W1662	1024	18		33-42-21	YT113-YT120, YT131-YT133
GD00824		ST-				IFSS-118/ /	YT113-YT120, YT131-YT133
ST..	GW	W1662	0019	18		33-42-21	YT113-YT120, YT131-YT133
ST..	GW	W1662	1024Z			33-42-21	YT113-YT120, YT131-YT133
GD00826		AC-				IFSS 98/ /	YT111-YT120, YT131-YT133
AC..	GW	W1664	1025	18		33-42-21	YT113-YT120, YT131-YT133

GROUND LIST

D280A351

91-21-21

Section GD00800

Page 4

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD00828		ST-				IFSS 98/ /	YT113-YT120, YT131-YT133
ST..	GW	W1664	0019	18		33-42-21	YT113-YT120, YT131-YT133
ST..	GW	W1664	1025Z			33-42-21	YT113-YT120, YT131-YT133
GD00830		BACC50AN20				P005-00/ /	YT113-YT120, YT131-YT133
AC..	1A	W2104	0023	20		33-42-21	YT113-YT120, YT131
AC..	1A	W2104	0024	20		33-42-21	YT113-YT120, YT131
AC..	1A	W2104	0025	20		33-42-21	YT113-YT120, YT131
DC..	1A	W2218	5532	20		30-41-12	YT119-YT120, YT132-YT133
DC..	1A	W2218	5533	20		30-41-12	YT119-YT120, YT132-YT133
DC..	1A	W2508	2002B	20		33-14-12	YT117-YT120, YT132-YT133
DC..	1A	W2508	5629	20		33-18-42	YT117-YT120, YT132-YT133
DC..	1A	W2508	5630	20		33-18-42	YT117-YT120, YT132-YT133
DC..	1A	W2508	5631	20		33-18-42	YT117-YT120, YT132-YT133
GD00832		BACC50AN20				P005-00/ /	YT113-YT120, YT131-YT133
AC..	1A	W2212	0020	20		33-42-21	YT113-YT120, YT131-YT133
AC..	1A	W2212	0021	20		33-42-21	YT113-YT120, YT131-YT133
AC..	1A	W2212	0022	20		33-42-21	YT113-YT120, YT131-YT133
AC..	1A	W2218	6043	20		28-23-11	YT117-YT120, YT132-YT133
AC..	1A	W2218	6044	20		28-23-11	YT117-YT120, YT132-YT133
AC..	1A	W2218	6045	20		28-23-11	YT117-YT120, YT132-YT133
AC..	1A	W2218	6056	20		28-23-11	YT117-YT120, YT132-YT133
GD00840		DC-				TBD/ /	ALL
GD00870		DC				OFSS373/ /	ALL
ST..	E	W1664	1020Z			28-44-11	ALL
ST..	E	W1664	1021Z			28-44-11	ALL
ST..	E	W1664	1022Z			28-44-11	ALL
ST..	E	W1664	1023Z			28-44-11	ALL
ST..	E	W1664	1026Z			28-44-11	ALL
GD00887		AC				F057/330/L002	ALL
AC..	E	W7057	0004	18		23-11-11	ALL
AC..	E	W7061	0004	18		23-11-21	ALL
GD00889		DC				F057/330/L002	ALL
DC..	E	W7057	0006	18		23-11-11	ALL
DC..	E	W7061	0006	18		23-11-21	ALL

GROUND LIST

D280A351

91-21-21

Section GD00800

Page 5

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	Ground No.	Type	Part Number	Wire No.	GA	CO	Station / WL / BL	Effectivity
	Term		Bundle				Diagram	
I	GD00891		ST-				238/202/L014	ALL
I	ST..	E	W5457	0025	20		22-11-11	ALL

GROUND LIST

D280A351

91-21-21

Section GD00800

Page 6 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD00912		AC-				366/157/L029	ALL
AC..	F	W2132	0004	08		24-51-11	ALL
GD00918		DC-				388/173/L053	ALL
DC..	E	W5726	0569	20		24-51-11	ALL
GD00920		AC-				377/168/R048	ALL
AC..	F	W6424	0012	08		24-51-21	ALL
GD00922		DC-				389/167/R047	ALL
DC..	E	W6410	0506	20		24-51-21	ALL
GD00947		ST-				666/194/L059	ALL
ST..	E	W1136	1304Z			28-43-11	YT101-YT119, YT126-YT131
ST..	E	W1136	3601Z			28-23-11	YT101-YT119, YT126-YT131
ST..	E	W5375	YAAA			22-11-31	ALL
ST..	E	W7026	0519	20		32-35-11	ALL
GD00949		ST-				1157/260/L010	ALL
DC..	E	W3397	0002	20		22-12-31	ALL
DC..	E	W3397	0022	20		22-12-31	ALL
ST..	E	W3397	1001Z			22-12-31	ALL
ST..	E	W3397	1004Z			22-12-31	ALL
ST..	E	W3397	2006Z			22-12-31	ALL
ST..	E	W3397	2007Z			22-12-31	ALL
ST..	E	W3397	3001Z			22-12-31	ALL
ST..	E	W3397	3006Z			SPARE	ALL
GD00971		DC-				//	ALL
GD00973		ST-				1160/284/L018	ALL
ST..	E	W3397	1002Z			22-11-12	ALL
ST..	E	W3397	1003Z			22-11-12	ALL
ST..	E	W3399	1001Z			22-12-41	ALL
ST..	E	W3399	1004Z			22-12-41	ALL
DC..	E	W3399	1010	20		22-12-41	ALL
DC..	E	W3399	1010Z			22-12-41	ALL
DC..	E	W3399	1011	20		22-12-41	ALL
DC..	E	W3399	1011Z			22-12-41	ALL
ST..	E	W3399	2006Z			22-12-41	ALL

GROUND LIST

D280A351

91-21-21

Section GD00900

Page 1

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD00973		ST- (continued)				1160/284/L018	ALL
ST..	E	W3399	2007Z			22-12-41	ALL
ST..	E	W3399	3001Z			22-12-41	ALL
ST..	E	W3399	3006Z			SPARE	ALL
GD00977		ST-				192/242/L003	ALL
ST..	E	W2108	FRAC			30-41-11	ALL
ST..	E	W2108	YAAD			30-41-11	YT117-YT120, YT132-YT133
ST..	E	W2363	1001Z			22-11-11	ALL
ST..	E	W2363	1002Z			22-11-11	ALL
ST..	E	W2363	1005Z			22-11-11	ALL
ST..	E	W2363	1015Z			22-31-51	ALL
GD00980		ST-				191/242/R002	ALL
ST..	E	W2208	FRAC			30-41-12	ALL
ST..	E	W2208	YAAD			30-41-12	YT117-YT120, YT132-YT133
ST..	E	W2465	1001Z			22-11-11	ALL
ST..	E	W2465	1005Z			22-11-11	ALL
ST..	E	W2465	1047Z			22-11-11	ALL
ST..	E	W2465	1055Z			22-11-11	ALL
GD00981		DC-				192/242/L004	ALL
DC..	E	W2363	1001	20		22-11-11	ALL
DC..	E	W2363	1002	20		22-11-11	ALL
DC..	E	W2363	1005	20		22-11-11	ALL
DC..	E	W2363	1015	22		22-31-51	ALL
GD00985		DC-				191/242/R003	ALL
DC..	E	W2465	1001	20		22-11-11	ALL
DC..	E	W2465	1005	20		22-11-11	ALL
DC..	E	W2465	1047	20		22-11-11	ALL
DC..	E	W2465	1055	20		22-11-11	ALL

GROUND LIST

D280A351

91-21-21

Section GD00900

Page 2 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD01000		ST-				224/175/L022	ALL
ST..	E	W5558	6001	20		28-41-11	YT110-YT120, YT130-YT133
ST..	E	W5562	6006	22		28-41-11	YT101-YT109, YT126-YT129
ST..	E	W5580	6006	22		28-41-11	YT101-YT109, YT126-YT129
ST..	E	W6578	6004	20		28-41-11	YT110-YT120, YT130-YT133
GD01008		BACC50AN20				376/169/R048	ALL
ST..	1A	W5030	5504	20		21-27-31	ALL
DC..	1A	W5158	0002	20		35-11-11	ALL
AC..	1D	W5158	0037	18		25-29-11	ALL
ST..	1D	W5158	0043	18		25-29-11	ALL
ST..	1D	W5158	0044	18		25-29-11	ALL
DC..	1A	W5158	0553	20		21-43-21	ALL
DC..	1A	W5158	0554	20		21-31-24	ALL
ST..	1A	W5158	0556	20		21-43-21	ALL
DC..	1A	W5158	0702	22		35-11-11	ALL
DC..	1A	W5337	0002	22		34-21-22	ALL
DC..	1A	W5337	0004	22		34-21-12	ALL
ST..	1A	W6110	5506	20		21-27-21	ALL
GD01018		AC-				259/280/L009	ALL
AC..	E	W2216	5543	10		33-12-11	ALL
GD0101A		BACC50AN16				P001-00/ /	ALL
ST..	1	W0001	0002	16		31-62-11	ALL
ST..	1	W0001	0003	16		31-62-11	ALL
ST..	1	W0001	0004	16		31-62-11	ALL
ST..	1	W0001	0005	16		31-62-11	ALL
ST..	1	W0001	0007	16		31-62-11	ALL
ST..	1	W0001	0008	16		31-62-11	ALL
ST..	1	W0001	0009	16		31-62-11	ALL
ST..	1	W0001	0010	16		31-62-11	ALL
GD0101B		BACC50AN20				P001-00/ /	ALL
ST..	1A	W0001	0016	20		31-62-11	ALL
DC..	1A	W0001	0089	20		22-14-11	ALL
DC..	1A	W0001	0104	22		34-61-16	ALL
DC..	1A	W0001	0166	22		34-49-11	ALL
ST..	1A	W0001	0172	20		31-22-11	ALL
DC..	1A	W0001	0173	20		31-22-11	ALL

GROUND LIST

D280A351

91-21-21

Section GD01000

Page 1

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD0101C		BACC50AN20				P001-00/ /	ALL
DC..	1A	W0001	0034	22		31-62-12	ALL
DC..	1A	W0001	0035	22		31-62-12	ALL
DC..	1A	W0001	0053	22		31-62-13	ALL
DC..	1A	W0001	0054	22		31-62-13	ALL
DC..	1A	W0001	0055	22		31-62-13	ALL
GD0101D		BACC50AN20				P001-00/ /	ALL
DC..	1A	W0001	0036	22		31-62-12	ALL
DC..	1A	W0001	0037	22		31-62-12	ALL
DC..	1A	W0003	0554	22		31-62-23	ALL
DC..	1A	W0003	0555	22		31-62-23	ALL
GD01022		ST-				294.5/ /	ALL
ST..	E	W1024	0523	20		27-62-11	YT101-YT119, YT126-YT131
GD01024		ST-				396.3/ /	ALL
ST..	E	W1034	0520	20		27-62-11	YT101-YT119, YT126-YT131
GD01026		ST-				397.4/ /	ALL
ST..	E	W1034	0521	20		27-62-11	YT101-YT119, YT126-YT131
GD01030		ST-				295.4/ /	ALL
ST..	E	W1024	0522	20		27-62-11	YT101-YT119, YT126-YT131
GD01034		AC-				OFSS 257/ /	ALL
AC..	E	W1664	1009	20		30-11-11	ALL
AC..	E	W1664	1009Z			30-11-11	ALL
GD01036		DC-				670/196/R067	ALL
DC..	E	W8228	0506	20		27-62-11	ALL
GD01038		ST-				675/196/R070	ALL
ST..	E	W8228	0504	20		27-62-11	ALL
GD01040		ST				/ /	ALL
GD01041		ST-				221/198/R026	ALL
ST..	E	W5369	0001	20		22-11-11	ALL

GROUND LIST

D280A351

91-21-21

Section GD01000

Page 2

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD01044		DC-				201/205/L012	ALL
DC..	E	W6208	0555	20		27-62-11	ALL
DC..	E	W6208	0557	20		27-62-11	ALL
GD01047		DC-				E005-00/ /	ALL
DC..	E	W0737	0036	22		34-61-19	ALL
DC..	E	W0737	0037	22		34-61-19	ALL
GD01053		ST-				225/199/R024	ALL
ST..	E	W5457	0035	20		22-11-11	ALL
GD01054		DC-				OFSS 374/ /	ALL
ST..	E	W1664	1012Z			28-44-11	ALL
DC..	E	W1664	1016	20		28-44-11	ALL
DC..	E	W1664	1016Z			28-44-11	ALL
DC..	E	W1664	A-E			28-44-11	ALL
GD01062		DC-				E004-02/ /	ALL
GD01064		ST-				411.1/ /	ALL
ST..	E	W1024	0516	20		27-62-11	YT101-YT119, YT126-YT131
GD01066		ST-				409.7/ /	ALL
ST..	E	W1024	0517	20		27-62-11	YT101-YT119, YT126-YT131
GD01068		ST-				354.2/ /	ALL
ST..	E	W1034	0518	20		27-62-11	YT101-YT119, YT126-YT131
GD01070		ST-				355.6/ /	ALL
ST..	E	W1034	0519	20		27-62-11	YT101-YT119, YT126-YT131
GD01072		ST-				339.4/ /	ALL
ST..	E	W1024	0520	20		27-62-11	YT101-YT119, YT126-YT131
GD01074		ST-				338.4/ /	ALL
ST..	E	W1024	0521	20		27-62-11	YT101-YT119, YT126-YT131
GD01076		ST-				425.1/ /	ALL
ST..	E	W1034	0522	20		27-62-11	YT101-YT119, YT126-YT131

GROUND LIST

D280A351

91-21-21

Section GD01000

Page 3

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
I GD01078		ST-				426.3/ /	ALL
I ST..	E	W1034	0523	20		27-62-11	YT101-YT119, YT126-YT131
I GD01080		ST-				381.6/ /	ALL
I ST..	E	W1024	0518	20		27-62-11	YT101-YT119, YT126-YT131
I GD01082		ST-				380.3/ /	ALL
I ST..	E	W1024	0519	20		27-62-11	YT101-YT119, YT126-YT131
I GD01084		ST-				312.5/ /	ALL
I ST..	E	W1034	0516	20		27-62-11	YT101-YT119, YT126-YT131
I GD01086		ST-				313.7/ /	ALL
I ST..	E	W1034	0517	20		27-62-11	YT101-YT119, YT126-YT131
I GD01096		ST-				/ /	ALL

GROUND LIST

D280A351

91-21-21

Section GD01000

Page 4 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD01100		AC-				OFSS-257/ /	ALL
AC..	E	W1662	1009	20		30-11-11	ALL
AC..	E	W1662	1009Z			30-11-11	ALL
GD01101		BACC50AN16				E001-01/ /	ALL
GD01102		BACC50AN20				E001-01/ /	ALL
AC..	1A	W0111	0004	22		22-11-11	ALL
DC..	1A	W0111	0005	20		22-11-11	ALL
DC..	1A	W0111	0006	20		22-11-11	ALL
DC..	1A	W0111	0007	20		22-11-11	ALL
ST..	1A	W0111	0008	20		22-11-11	ALL
AC..	1A	W0111	0035	20		22-11-11	ALL
AC..	1A	W0111	0067	22		34-45-11	ALL
DC..	1A	W0111	0116	22		22-11-75	ALL
AC..	1A	W0111	0118	22		27-51-11	ALL
AC..	1A	W0111	0133	22		22-18-11	ALL
AC..	1A	W0111	0134	22		22-18-11	ALL
DC..	1A	W0111	0218	22		27-81-41	ALL
ST..	1A	W0111	0394	20		34-21-21	ALL
AC..	1A	W0111	0712	22		27-53-21	ALL
AC..	1A	W0111	0713	22		27-53-21	ALL
AC..	1A	W0111	1003	20		27-52-11	ALL
DED		W0111	1003Z			27-52-11	ALL
GD01103		BACC50AN20				E001-01/ /	ALL
ST..	1A	W0111	0031	20		22-11-11	ALL
DC..	1A	W0111	0032	20		22-11-11	ALL
DC..	1A	W0111	0070	22		22-11-14	ALL
DC..	1A	W0111	0081	22		22-11-75	ALL
DC..	1A	W0111	0249	22		22-18-11	ALL
DC..	1A	W0111	0380	22		34-21-15	ALL
DC..	1A	W0111	0382	22		34-21-15	ALL
AC..	1A	W0111	0399	20		34-21-21	ALL
DC..	1A	W0111	0571	20		34-21-21	ALL
ST..	1A	W0111	0696	22		27-81-11	ALL
DC..	1A	W0111	0699	22		27-81-11	ALL
DC..	1A	W0111	0701	22		27-81-11	ALL
DC..	1A	W0111	0704	22		27-81-11	ALL
DC..	1A	W0111	0717	22		34-61-12	ALL
DC..	1A	W0111	0719	22		34-61-12	ALL

GROUND LIST

D280A351

91-21-21

Section GD01100

Page 1

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD01104		S280W555-401				E001-01/ /	ALL
DC..	1A	W0111	0068	22		34-45-11	ALL
DC..	1A	W0111	0069	22		34-45-11	ALL
DC..	1A	W0111	0125	22		22-11-75	ALL
DC..	1A	W0111	0219	22		34-21-16	ALL
DC..	1A	W0111	0225	22		22-11-75	ALL
DC..	1A	W0111	0229	22		34-45-11	ALL
DC..	1A	W0111	0230	22		34-45-11	ALL
DC..	1A	W0111	0790	24		22-11-75	ALL
DC..	1A	W0111	0888	20		31-53-11	ALL
DC..	1A	W0111	0927	24		22-11-75	ALL
GD01105		BACC50AN20				E001-01/ /	ALL
AC..	1A	W0111	0024	20		22-11-11	ALL
AC..	1A	W0111	0233	22		34-49-11	ALL
DC..	1A	W0111	0234	22		34-49-11	ALL
DC..	1A	W0111	0838	22		27-81-41	ALL
DC..	1A	W0111	0889	20		31-53-11	ALL
GD01106		S280W555-401				E001-01/ /	ALL
ST..	1A	W0111	0025	20		22-11-11	ALL
DC..	1A	W0111	0062	22		22-11-14	ALL
AC..	1A	W0111	0272	22		22-11-11	ALL
AC..	1A	W0111	0274	22		22-11-11	ALL
AC..	1A	W0111	0276	22		22-11-11	ALL
AC..	1A	W0111	0278	22		22-11-11	ALL
AC..	1A	W0111	0727	22		22-18-11	ALL
AC..	1A	W0111	0728	22		22-18-11	ALL
DC..	1A	W0111	0777	22		22-31-51	ALL
DC..	1A	W0111	0796	20		21-31-23	ALL
ST..	1A	W0111	0797	20		21-31-23	ALL
DC..	1A	W0111	0798	22		21-31-23	ALL
DC..	1A	W0111	0799	22		21-31-23	ALL
DC..	1A	W0111	0811	22		21-31-23	ALL
GD01111		DC-				313/161/L028	ALL
DC..	E	W2247	0013	20		34-53-31	ALL
DC..	E	W2247	0028	20		34-53-31	ALL
GD01148		DC-				655/165/R040	ALL
DC..	GW	W6202	1012	20		27-83-11	ALL

GROUND LIST

D280A351

91-21-21

Section GD01100

Page 2

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD01148		DC- (continued)				655/165/R040	ALL
DC..	GW	W6202	1012Z			27-83-11	ALL
DC..	GW	W6202	1029	20		27-83-21	ALL
DC..	GW	W6202	1029Z			27-83-21	ALL
GD01154		AC-				578/155/L040	ALL
GD01160		DC-				//	ALL
GD01170		DC-				//	ALL
GD01182		DC-				TBD/TBD/TBD	ALL
GD01184		DC				TBD/TBD/TBD	ALL
GD01188		BACC50AN16				//	ALL

GROUND LIST

D280A351

91-21-21

Section GD01100

Page 3 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD01201		S280W555-402				E001-02/ /	ALL
ST..	1A	W0121	0036	20		34-31-11	ALL
AC..	1A	W0121	0042	20		34-51-11	ALL
ST..	1A	W0121	0043	20		34-51-11	ALL
GD01202		S280W555-402				E001-02/ /	ALL
AC..	1A	W0121	0035	20		34-31-11	ALL
DC..	1A	W0121	0089	22		34-31-11	YT120, YT130-YT133
DC..	1A	W0121	0090	22		34-31-11	YT120, YT130-YT133
DC..	1A	W0121	0091	22		34-31-11	YT120, YT130-YT133
DC..	1A	W0121	0092	22		34-31-11	YT120, YT130-YT133
GD01203		S280W555-402				E001-02/ /	ALL
AC..	1A	W0121	0004	20		34-53-11	ALL
ST..	1A	W0121	0006	20		34-53-11	ALL
DC..	1A	W0121	0008	20		34-53-11	ALL
ST..	1A	W0121	0009	20		34-53-11	ALL
ST..	1A	W0121	0010	20		34-53-11	ALL
ST..	1A	W0121	0018	22		34-55-11	ALL
ST..	1A	W0121	0025	20		34-53-11	ALL
DC..	1A	W0121	0028	22		34-55-11	ALL
ST..	1A	W0121	0029	22		34-55-11	ALL
DC..	%A	W0121	0050	22		34-53-11	ALL
GD01204		S280W555-402				E001-02/ /	ALL
AC..	1A	W0121	0019	22		34-55-11	ALL
GD01207		BACC50AN20				E003-03/ /	ALL
GD01210		DC-				197/170/0	ALL
DC..	E	W5160	0106	18		52-71-12	ALL
GD01218		AC-				986/203/R025	ALL
GD01220		DC-				394/186/R047	ALL
DC..	P	W0422	0134	08		24-32-11	ALL
GD01222		BACC50AN20				775/199/R064	ALL

GROUND LIST

D280A351

91-21-21

Section GD01200

Page 1

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD01230		BACC50AN16				520/170/L053	ALL
DC..	1	W5172	0009	18		78-32-51	ALL
DC..	1	W5172	0010	18		78-32-51	ALL
DC..	1	W5172	0011	20		78-36-11	ALL
DC..	1	W5172	0012	20		73-21-12	ALL
DC..	1	W5172	0013	20		78-36-11	ALL
DC..	1	W5172	0014	20		78-35-11	ALL
GD01232		BACC50AN16				500I+14/175/R053	ALL
DC..	1	W6172	0009	18		78-32-61	ALL
DC..	1	W6172	0010	18		78-32-61	ALL
DC..	1	W6172	0011	20		78-36-21	ALL
DC..	1	W6172	0012	20		73-21-12	ALL
DC..	1	W6172	0013	20		78-36-21	ALL
DC..	1	W6172	0014	20		78-35-21	ALL
GD01240		BACC50AN16				AB1088/232/L018	ALL
DC..	1	W4724	0515	20		49-52-31	ALL
DC..	1	W4724	0517	20		49-52-31	ALL
DC..	1	W4724	0549	20		49-62-12	ALL
DC..	1	W4724	0560	20		49-94-21	ALL
DC..	1	W4724	0563	20		49-94-21	ALL
DC..	1	W4724	0575	22		49-62-12	ALL
ST..	1	W4724	0587	22		49-62-12	ALL
DC..	1	W4724	0589	20		49-94-21	ALL
ST..	1	W4724	0590	22		49-94-21	ALL
GD01252		DC-				394/184/R047	ALL
DC..	P	W0422	0125	08		24-32-11	ALL
GD01254		AC-				E002-02/ /	ALL
GD01256		DC-				393/194/L019	ALL
DC..	P	W0212	0051	08		24-32-11	ALL
GD01258		ST-				/ /	ALL

GROUND LIST

D280A351

91-21-21

Section GD01200

Page 2 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD01301		BACC50AN16				E001-03/ /	ALL
DC..	1	W0131	0016	18		23-31-01	ALL
DC..	1	W0131	0033	16		23-12-11	ALL
GD01302		S280W555-401				E001-03/ /	ALL
DC..	1A	W0131	0034	22		23-12-11	ALL
DC..	1A	W0131	0039	22		23-12-11	ALL
DC..	1A	W0131	0435	22		23-12-11	ALL
GD01303		S280W555-401				E001-03/ /	ALL
GD01304		S280W555-401				E001-03/ /	ALL
DC..	1A	W0131	0001	22		32-42-11	ALL
DC..	1A	W0131	0002	22		32-42-11	ALL
ST..	1A	W0131	0003	22		32-41-11	ALL
DC..	1A	W0131	0106	22		32-41-11	ALL
DC..	1A	W0131	0107	22		32-41-11	ALL
ST..	1A	W0131	0108	22		32-41-11	ALL
GD01322		DC-				335/159/L029	ALL
DC..	E	W5156	0002	18		52-71-12	ALL
GD01352		AC-				250/228/R049	ALL
AC..	E	W2108	1003	20		30-41-11	ALL
AC..	E	W2108	1003Z			30-41-11	ALL
ST..	E	W2108	YAAC			30-41-11	YT117-YT120, YT132-YT133
AC..	E	W2204	5503	18		33-14-12	ALL
GD01354		AC-				251/228/L049	ALL
AC..	E	W2102	5517	18		33-14-12	ALL
AC..	E	W2208	1003	18		30-41-12	YT101-YT116, YT126-YT131
AC..	E	W2208	1003	20		30-41-12	YT117-YT120, YT132-YT133
AC..	E	W2208	1003Z			30-41-12	ALL
ST..	E	W2208	YAAC			30-41-12	YT117-YT120, YT132-YT133

GROUND LIST

D280A351

91-21-21

Section GD01300

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD01401		S280W555-402				E001-04/ /	ALL
AC..	1A	W0141	0006	22		22-11-11	ALL
DC..	1A	W0141	0048	22		22-11-14	ALL
DC..	1A	W0141	0049	22		22-11-14	ALL
DC..	1A	W0141	0056	20		22-11-11	ALL
DC..	1A	W0141	0057	20		22-11-11	ALL
DC..	1A	W0141	0058	20		22-11-11	ALL
ST..	1A	W0141	0059	20		22-11-11	ALL
DC..	1A	W0141	0086	22		22-11-75	ALL
DC..	1A	W0141	0087	22		22-11-75	ALL
AC..	1A	W0141	0122	22		22-18-11	ALL
AC..	1A	W0141	0123	22		22-18-11	ALL
DC..	1A	W0141	0146	22		22-11-75	ALL
GD01402		S280W555-402				E001-04/ /	ALL
AC..	1A	W0141	0133	22		22-11-11	ALL
AC..	1A	W0141	0135	22		22-11-11	ALL
AC..	1A	W0141	0137	22		22-11-11	ALL
AC..	1A	W0141	0139	22		22-11-11	ALL
GD01403		S280W555-402				E001-04/ /	ALL
AC..	1A	W0141	0703	20		34-31-21	ALL
ST..	1A	W0141	0704	20		34-31-21	ALL
AC..	1A	W0141	0710	20		34-51-21	ALL
ST..	1A	W0141	0711	20		34-51-21	ALL
DC..	1A	W0141	0713	22		34-51-21	ALL
DC..	1A	W0141	0730	22		34-31-21	YT120, YT130-YT133
DC..	1A	W0141	0731	22		34-31-21	YT120, YT130-YT133
DC..	1A	W0141	0732	22		34-31-21	YT120, YT130-YT133
DC..	1A	W0141	0733	22		34-31-21	YT120, YT130-YT133
GD01404		S280W555-402				E001-04/ /	ALL
DC..	1A	W0141	0416R	20		26-12-11	ALL
DC..	1A	W0141	0417R	20		26-12-11	ALL
AC..	1A	W0141	0418R	20		26-12-11	ALL
DED		W0141	0418Z			26-12-11	ALL
AC..	1A	W0141	0419R	20		26-12-11	ALL
DED		W0141	0419Z			26-12-11	ALL
GD01444		AC-				226/232/L040	ALL
AC..	E	W2102	5534	20		33-14-11	ALL

GROUND LIST

D280A351

91-21-21

Section GD01400

Page 1

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
I GD01450		ST-				E002-01/ /	ALL

GROUND LIST

D280A351

91-21-21

Section GD01400

Page 2 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
I GD01501		BACC50AN16				E001-05/ /	ALL
I DC..	1	W0151	0035	16		23-12-21	ALL
I GD01502		S280W555-402				E001-05/ /	ALL
I ST..	1A	W0151	0018	22		34-55-21	ALL
I AC..	1A	W0151	0019	22		34-55-21	ALL
I DC..	1A	W0151	0028	22		34-55-21	ALL
I ST..	1A	W0151	0029	22		34-55-21	ALL
I GD01503		S280W555-402				E001-05/ /	ALL
I AC..	1A	W0151	0004	20		34-53-21	ALL
I ST..	1A	W0151	0006	20		34-53-21	ALL
I DC..	1A	W0151	0008	20		34-53-21	ALL
I ST..	1A	W0151	0009	20		34-53-21	ALL
I ST..	1A	W0151	0010	20		34-53-21	ALL
I DC..	1A	W0151	0036	22		23-12-21	ALL
I DC..	1A	W0151	0037	22		23-12-21	ALL
I DC..	%A	W0151	0048	22		34-53-21	ALL
I DC..	1A	W0151	0072	22		23-12-21	ALL
I GD01505		ST-				679/201/L040	ALL
I ST..	E	W5375	YAAA			22-11-31	ALL

GROUND LIST

D280A351

91-21-21

Section GD01500

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
I GD01637		DC-				266/42/254	ALL

GROUND LIST

D280A351

91-21-21

Section GD01600

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	Ground No.	Type	Part Number		Wire No.	GA	CO	Station / WL / BL	Effectivity
	Term		Bundle					Diagram	
I	GD01748		DC					/ /	ALL
I	GD01753		DC-					196/171/R012	ALL
I	DC..	E	W5156	5510	20			21-27-21	ALL
I	DC..	E	W5503	0001	20			34-21-22	ALL
I	GD01788		AC-					1033/298/L011	ALL
I	AC..	E	W6134	5502	20			30-31-11	ALL
I	AC..	E	W6134	5505	20			30-31-12	ALL
I	GD01790		ST-					1031/298/L011	ALL
I	GD01792		ST-					69 FIN/ /	ALL
I	ST..	E	W7102	2001Z				30-31-11	ALL
I	GD01794		ST-					69 FIN/ /	ALL
I	ST..	E	W7102	2002Z				30-31-12	ALL

GROUND LIST

D280A351

91-21-21

Section GD01700

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
I GD01800		AC-				//	ALL
I GD01814		BACC50AN20				AB1088/ /	ALL
I GD01816		ST-				//	ALL
I GD01818		DC-				//	ALL
I GD01820		AC-				1064/285/L036	ALL
I GD01822		AC-				//	ALL
I GD01826		AC-				1166/243/R014	ALL
I GD01828		DC-				//	ALL
I GD01830		ST-				//	ALL
I GD01832		DC-				//	ALL
I GD01835		ST-				237/202/L006	ALL
I ST..	E	W2705	0020	20		34-36-11	ALL
I ST..	E	W5353	0001	22		22-31-31	ALL
I ST..	E	W5353	0004	22		22-31-31	ALL
I GD01836		DC-				237/201/L006	ALL
I DC..	E	W2705	0019	20		34-36-11	ALL
I DC..	E	W5353	0002	22		22-31-31	ALL
I GD01837		DC-				237/201/R006	ALL
I DC..	E	W5397	0002	22		22-31-41	ALL
I GD01838		ST-				237/202/R006	ALL
I ST..	E	W5397	0001	22		22-31-41	ALL
I ST..	E	W5397	0004	22		22-31-41	ALL
I GD01840		AC-				//	ALL
I GD01850		DC-				P018-00/ /	ALL
I DC..	E	W0018	0894	22		27-32-11	ALL

GROUND LIST

D280A351

91-21-21

Section GD01800

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
I GD01904		DC-				* */*	ALL
I GD01906		BACC50AN20				//	ALL
I GD01910		BACC50AN20				//	ALL
I GD01914		ST				285/189/L017	ALL
I ST..	E	W6110	5513	20		21-42-11	ALL
I GD01916		BACC50AN20				//	ALL
I GD01946		AC-				//	ALL
I GD01948		AC-				673/199/L057	ALL
I AC..	E	W7026	0515	18		33-32-11	YT101-YT111, YT126-YT130
I AC..	E	W7026	0515	20		33-32-11	YT112-YT120, YT131-YT133
I AC..	E	W7230	A-Y			32-64-11	ALL
I GD01950		AC-				701/201/R062	ALL
I AC..	E	W7026	0516	18		33-32-11	YT101-YT111, YT126-YT130
I AC..	E	W7026	0516	20		33-32-11	YT112-YT120, YT131-YT133
I AC..	E	W8228	A-Y			32-64-11	ALL
I GD01952		AC-				//	ALL
I GD01962		AC-				665/196/L059	ALL
I AC..	E	W7126	A-Y			32-64-12	ALL
I GD01964		ST-				664/166/L055	ALL
I ST..	E	W7230	0503	18		29-32-11	ALL
I GD01966		ST-				678/200/R036	ALL
I ST..	E	W8224	0510	20		29-31-11	ALL
I GD01968		ST-				716/197/L007	ALL
I ST..	E	W8230	0501	18		32-42-11	ALL

GROUND LIST

D280A351

91-21-21

Section GD01900

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD0201A		BACC50AN16				P002-00/ /	ALL
ST..	1	W0001	0012	16		31-62-11	ALL
ST..	1	W0001	0013	16		31-62-11	ALL
ST..	1	W0001	0014	16		31-62-11	ALL
ST..	1	W0001	0015	16		31-62-11	ALL
GD0201B		BACC50AN20				P002-00/ /	ALL
DC..	1A	W0001	0137	22		32-42-11	ALL
DC..	1A	W0001	0145	22		32-42-11	ALL
DC..	1A	W0001	0146	22		32-42-11	ALL
DC..	1A	W0001	0255	22		29-23-11	ALL
DC..	1A	W0001	0301	22		32-64-11	ALL
DC..	1A	W0001	0306	22		32-64-11	ALL
DC..	1A	W0001	0311	22		32-41-11	ALL
DC..	1A	W0001	0314	22		32-41-11	ALL
GD0201C		BACC50AN20				P002-00/ /	ALL
DC..	1A	W0001	0032	22		31-62-12	ALL
DC..	1A	W0001	0033	22		31-62-12	ALL
DC..	1A	W0001	0048	22		31-62-13	ALL
DC..	1A	W0001	0049	22		31-62-13	ALL
DC..	1A	W0001	0050	22		31-62-13	ALL
DC..	1A	W0001	0051	22		31-62-13	ALL
DC..	1A	W0001	0052	22		31-62-13	ALL
GD0201D		BACC50AN20				P002-00/ /	ALL
DC..	1A	W0003	0548	22		31-62-23	ALL
DC..	1A	W0003	0549	22		31-62-23	ALL
DC..	1A	W0003	0550	22		31-62-23	ALL
DC..	1A	W0003	0551	22		31-62-23	ALL
DC..	1A	W0003	0552	22		31-62-23	ALL
GD02054		AC-				ORSS/166/	ALL
GD02058		AC-				/ /	ALL
GD02064		AC-				IRSS156/ /	ALL
GD02068		AC-				/ /	ALL

GROUND LIST

D280A351

91-21-21

Section GD02000

Page 1

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	Ground No.	Type	Part Number		Wire No.	GA	CO	Station / WL / BL	Effectivity
	Term		Bundle					Diagram	
I	GD02070		AC-					726/196/L034	ALL
I	AC..	E	W7126	0521	18			32-64-12	ALL
I	AC..	E	W7126	0533	18			32-31-12	ALL
I	GD02074		AC-					726/197/L047	ALL
I	AC..	E	W7230	0521	18			32-64-11	ALL
I	AC..	E	W7230	0533	18			32-31-11	ALL
I	GD02076		AC-					726/200/R035	ALL
I	AC..	E	W8224	0523	18			32-64-12	ALL
I	AC..	E	W8224	0541	18			32-31-12	ALL
I	GD02080		AC-					726/196/R036	ALL
I	AC..	E	W8228	0513	18			32-64-11	ALL
I	AC..	E	W8228	0540	18			32-31-11	ALL

GROUND LIST

D280A351

91-21-21

Section GD02000

Page 2 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD02102		BACC50AN20				E002-01/ /	ALL
GD02103		BACC50AN20				E002-01/ /	ALL
DC..	1A	W0212	0012	20		24-11-11	ALL
ST..	1A	W0212	0013	20		24-11-11	ALL
GD02104		BACC50AN20				E002-01/ /	ALL
AC..	1A	W0210	5504	20		30-41-11	ALL
DC..	1A	W0210	5506	20		30-41-11	ALL
AC..	1A	W0210	5513	20		30-41-11	YT101-YT116, YT126-YT131
DC..	1A	W0210	5515	20		30-41-11	ALL
DC..	1A	W0212	0026	22		24-22-31	ALL
ST..	1A	W0212	0027	22		24-22-31	ALL
DC..	1A	W0212	0028	22		24-22-31	ALL
DC..	1A	W0212	0068	22		24-23-11	ALL
GD02105		BACC50AN16				E002-01/ /	ALL
ST..	1	W0210	5502	16		30-41-11	YT101-YT116, YT126-YT131
AC..	1	W0210	5503	16		30-41-11	YT101-YT116, YT126-YT131
AC..	1	W0212	0055	18		24-32-11	ALL
GD02106		CGH20-22-1				E002-01/ /	ALL
ST..	1F	W0210	1001ZO			30-41-11	YT117-YT120, YT132-YT133
ST..	1F	W0210	1002ZO			30-41-11	YT117-YT120, YT132-YT133
ST..	1F	W0210	1003Z			30-41-11	YT117-YT120, YT132-YT133
ST..	1F	W0210	1004Z			30-41-11	YT117-YT120, YT132-YT133
ST..	1F	W0210	2003Z			30-41-11	YT101-YT116, YT126-YT131
ST..	1F	W0210	2003ZO			30-41-11	YT117-YT120, YT132-YT133
ST..	1F	W0210	2004Z			30-41-11	ALL
ST..	1F	W0210	2006ZO			30-41-11	YT117-YT120, YT132-YT133
ST..	1F	W0210	3001ZO			30-41-11	YT117-YT120, YT132-YT133
ST..	1F	W0210	FRAB			30-41-11	YT117-YT120, YT132-YT133
ST..	1F	W0210	FRAC			30-41-11	YT117-YT120, YT132-YT133
GD02107		ST-				E002-01/ /	ALL
ST..	E	W0210	5511	12		30-41-11	ALL
GD02108		AC-				E002-01/ /	ALL
AC..	E	W0210	5512	12		30-41-11	ALL
AC..	E	W0210	5531	14		30-41-11	YT117-YT120, YT132-YT133

GROUND LIST

D280A351

91-21-21

Section GD02100

Page 1

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD02108		AC- (continued)				E002-01/ /	ALL
AC..	E	W0210	5536	18		30-41-11	YT117-YT120, YT132-YT133
GD02109		BACC50AN20				E002-01/ /	ALL
ST..	1A	W0212	2002Z			24-21-11	ALL
ST..	1A	W0212	3001Z			24-21-11	ALL
GD02110		BACC50AN20				E002-01/ /	ALL
ST..	1A	W0212	4006Z			24-24-31	ALL
GD02112		CGH20-22-1				E002-01/ /	ALL
ST..	1F	W0210	2001Z			30-41-11	YT101-YT116, YT126-YT131
ST..	1F	W0210	2002Z			30-41-11	YT101-YT116, YT126-YT131
GD02156		DC-				IRSS 210/ /	ALL
DC..	E	W1722	0502	14		49-31-31	ALL

GROUND LIST

D280A351

91-21-21

Section GD02100

Page 2 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD02201		BACC50AN20				E002-02/ /	ALL
GD02202		BACC50AN20				E002-02/ /	ALL
GD02203		BACC50AN20				E002-02/ /	ALL
ST..	1A	W0220	0019	20		33-44-11	ALL
ST..	1A	W0220	0052	20		21-31-22	ALL
AC..	1A	W0220	0110	20		49-41-11	ALL
DC..	1A	W0220	0112	20		49-41-11	ALL
AC..	1A	W0220	0126	22		49-41-11	ALL
GD02204		BACC50AN20				E002-02/ /	ALL
DC..	1A	W0220	0051	20		21-31-22	ALL
DC..	1A	W0220	0059	22		21-31-22	ALL
DC..	1A	W0220	0061	22		21-31-22	ALL
DC..	1A	W0220	0238	22		21-31-22	ALL
DC..	1A	W0220	1026R	20		26-11-11	ALL
DED		W0220	1026Z			26-11-11	ALL
DC..	1A	W0220	1027R	20		26-11-11	ALL
DED		W0220	1027Z			26-11-11	ALL
DC..	1A	W0220	1033R	20		26-11-21	ALL
DED		W0220	1033Z			26-11-21	ALL
DC..	1A	W0220	1036R	20		26-11-21	ALL
DED		W0220	1036Z			26-11-21	ALL
DC..	1A	W0220	1125R	20		26-11-31	ALL
DED		W0220	1125Z			26-11-31	ALL
DC..	1A	W0220	1126R	20		26-11-31	ALL
DED		W0220	1126Z			26-11-31	ALL
DC..	1A	W0220	1127R	20		26-11-31	ALL
DED		W0220	1127Z			26-11-31	ALL
DC..	1A	W0220	1128R	20		26-11-31	ALL
DED		W0220	1128Z			26-11-31	ALL
GD02205		BACC50AN16				E002-02/ /	ALL
ST..	1	W0220	0124	16		49-41-11	ALL
ST..	1	W0220	0125	16		49-41-11	ALL
GD02207		BACC50AN20				E002-02/ /	ALL
ST..	1A	W0220	2002Z			24-21-31	ALL
ST..	1A	W0220	3001Z			24-21-31	ALL

GROUND LIST

D280A351

91-21-21

Section GD02200

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
I GD02300		ST-				653/150/L008	ALL
I GD02301		DC-				213/208/R036	ALL
I DC..	E	W3319	0016	20		23-51-21	ALL
I GD02302		ST-				661/156/L016	ALL
I ST..	GW	W5102	1013Z			26-12-11	ALL
I ST..	GW	W5102	1025Z			26-12-11	ALL
I GD02303		DC-				214/208/L038	ALL
I DC..	E	W3323	0016	20		23-51-11	ALL
I GD02304		ST-				661/164/L026	ALL
I ST..	GW	W5230	YAAF			29-11-12	YT101-YT119, YT126-YT131
I GD02306		AC				536/158/R027	ALL
I AC..	GW	W6202	0010	20		33-33-11	YT112-YT120, YT131-YT133
I AC..	GW	W6202	5556	20		30-71-11	ALL
I AC..	GW	W6202	5557	20		30-71-11	ALL
I GD02308		ST-				579/161/L039	ALL
I GD02312		ST-				578.5/153/L039	ALL
I GD02314		ST-				570/153/L039	ALL
I GD02316		DC-				570/155/L039	ALL
I DC..	GW	W5102	1005	20		21-51-15	ALL
I DC..	GW	W5102	1005Z			21-51-15	ALL
I DC..	GW	W5102	1014Z			26-12-11	ALL
I DC..	GW	W5102	1034	20		21-51-15	ALL
I DC..	GW	W5102	1034Z			21-51-15	ALL
I DC..	GW	W5102	1050	20		21-61-51	ALL
I DC..	GW	W5102	1050Z			21-61-51	ALL
I GD02318		ST-				543/155/L040	ALL
I ST..	GW	W5102	1016Z			33-33-11	ALL
I ST..	GW	W5102	1017Z			33-33-11	ALL
I ST..	GW	W5102	1018Z			33-33-11	ALL
I ST..	GW	W5102	1019Z			33-33-11	ALL

GROUND LIST

D280A351

91-21-21

Section GD02300

Page 1

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD02318		ST- (continued)				543/155/L040	ALL
ST..	N	W7202	0021	16		47-30-11	ALL
ST..	N	W7202	0025	16		47-30-11	ALL
GD02320		ST-				537/161/L032	ALL
ST..	GW	W5102	1015Z			26-12-11	ALL
ST..	GW	W5102	1030Z			36-21-11	ALL
ST..	GW	W5102	2007Z			36-21-11	ALL
ST..	GW	W5102	5515	20		36-21-11	ALL
GD02322		AC-				537/157/L027	ALL
AC..	GW	W5102	0012	20		33-33-11	ALL
GD02324		ST-				544/154/L008	ALL
ST..	GW	W5502	0006	20		21-61-11	ALL
ST..	GW	W5502	1035Z			21-61-11	ALL
ST..	GW	W5502	1037Z			21-61-11	ALL
ST..	GW	W5502	1038Z			21-61-11	ALL
ST..	GW	W5502	1039Z			21-61-11	ALL
ST..	GW	W5502	2083Z			21-61-11	ALL
ST..	GW	W5502	2084Z			21-61-11	ALL
GD02326		ST				571/163/L007	ALL
ST..	GW	W5502	1010Z			26-12-11	ALL
GD02328		ST-				577/157/L007	ALL
ST..	GW	W5502	1002Z			21-51-11	YT101-YT115, YT126-YT131
ST..	GW	W5502	1004Z			21-51-11	YT101-YT115, YT126-YT131
ST..	GW	W5502	1006Z			21-51-11	YT101-YT115, YT126-YT131
ST..	GW	W5502	2002Z			21-51-11	YT101-YT115, YT126-YT131
GD02330		ST-				603/152/L007	ALL
ST..	GW	W5502	0016	24		21-51-12	YT116-YT120, YT132-YT133
ST..	GW	W5502	1010Z			26-12-11	ALL
ST..	GW	W5502	1011Z			26-12-11	ALL
GD02332		ST-				653/151/R008	ALL
GD02334		ST-				661/156/R016	ALL
ST..	GW	W6202	1008Z			26-12-11	ALL

GROUND LIST

D280A351

91-21-21

Section GD02300

Page 2

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD02334		ST- (continued)				661/156/R016	ALL
ST..	GW	W6202	1009Z			26-12-11	ALL
GD02336		ST-				661/162/R030	ALL
ST..	GW	W6128	YAAF			29-11-12	YT101-YT119, YT126-YT131
ST..	E	W8122	YAAF			27-81-51	ALL
GD02338		ST-				655/165/R041	ALL
ST..	GW	W6202	1011Z			27-83-11	ALL
ST..	GW	W6202	1012Z			27-83-11	ALL
ST..	GW	W6202	1013Z			27-83-21	ALL
ST..	GW	W6202	1029Z			27-83-21	ALL
GD02340		ST-				580/162/R040	ALL
GD02342		ST-				571/166/R030	ALL
GD02344		DC-				570/156/R040	ALL
DC..	GW	W6202	0014	20		21-51-25	ALL
DC..	GW	W6202	0015	20		21-51-25	ALL
DC..	GW	W6202	0016	20		21-61-51	ALL
DC..	GW	W6202	1010Z			26-12-11	ALL
DC..	GW	W6202	1027Z			21-51-25	ALL
DC..	GW	W6202	1034Z			21-51-25	ALL
DC..	GW	W6202	1049Z			21-61-51	ALL
DC..	GW	W6202	2079Z			21-51-22	ALL
DC..	GW	W6202	2080Z			21-51-23	ALL
GD02346		ST-				570/156/R039	ALL
GD02348		ST-				551/155/R033	ALL
GD02350		ST-				544/155/R035	ALL
ST..	GW	W6202	1014Z			33-33-11	ALL
ST..	GW	W6202	1015Z			33-33-11	ALL
ST..	GW	W6202	1016Z			33-33-11	ALL
ST..	GW	W6202	1017Z			33-33-11	ALL
GD02352		ST-				537/161/R032	ALL
ST..	GW	W6202	1010Z			26-12-11	ALL

GROUND LIST

D280A351

91-21-21

Section GD02300

Page 3

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD02352		ST- (continued)				537/161/R032	ALL
ST..	GW	W6202	1030Z			36-21-11	ALL
ST..	GW	W6202	2007Z			36-21-11	ALL
ST..	GW	W6202	5515	20		36-21-11	ALL
GD02354		ST-				537/155/R027	ALL
ST..	GW	W6202	1018Z			30-71-11	ALL
ST..	GW	W6202	1038Z			21-61-13	ALL
ST..	GW	W6202	1039Z			21-61-13	ALL
ST..	GW	W6202	1040Z			21-61-13	ALL
ST..	GW	W6202	1041Z			21-61-13	ALL
ST..	GW	W6202	2083Z			21-61-13	ALL
ST..	GW	W6202	2084Z			21-61-13	ALL
ST..	GW	W6202	5564	20		21-61-13	ALL
ST..	GW	W6202	5567	20		21-61-14	ALL
GD02356		ST-				571/162/R007	ALL
ST..	GW	W6502	1003Z			26-12-11	ALL
GD02358		ST-				578/155/R007	ALL
ST..	GW	W6502	1006Z			21-51-21	ALL
ST..	GW	W6502	1007Z			21-51-21	YT101-YT115, YT126-YT131
ST..	GW	W6502	1008Z			21-51-21	ALL
ST..	GW	W6502	2001Z			21-51-21	ALL
ST..	GW	W6502	2002Z			21-51-21	ALL
ST..	GW	W6502	5501	20		21-61-15	ALL
GD02360		ST-				578/161/R007	ALL
ST..	GW	W6504	1001Z			21-51-21	ALL
ST..	GW	W6504	1002Z			21-42-11	ALL
ST..	GW	W6504	1003Z			21-51-21	ALL
GD02362		ST-				570/153/R040	ALL

GROUND LIST

D280A351

91-21-21

Section GD02300

Page 4 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	Ground No.	Type	Part Number	Wire No.	GA	CO	Station / WL / BL	Effectivity
	Term		Bundle				Diagram	
I	GD02564		AC-				1087/244/L003	ALL
I	AC..	R	W4722	0004	04		24-21-31	ALL

GROUND LIST

D280A351

91-21-21

Section GD02500

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	Ground No.	Type	Part Number	Wire No.	GA	CO	Station / WL / BL	Effectivity
	Term		Bundle				Diagram	
I	GD02994		ST-				RUD56.4/ /	ALL
I	ST..	E	W6136	0508	20		27-25-11	ALL
I	ST..	E	W6136	1008	20		27-21-11	ALL
I	ST..	E	W6136	1008Z			27-21-11	ALL

GROUND LIST

D280A351

91-21-21

Section GD02900

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
I GD03002		BACC50AN16				579/251/L 66	ALL
I GD03004		BACC50AN16				560/229/L 69	ALL
I GD03006		BACC50AN16				595/256/L 68	ALL
I GD03014		BACC50AN16				601/259/L 67	ALL
I GD03016		BACC50AN16				560/229/R 69	ALL
I GD03018		BACC50AN16				578/259/R 67	ALL
I GD0301A		BACC50AN16				P003-00/ /	ALL
I ST..	1	W0003	0502	16		31-62-21	ALL
I ST..	1	W0003	0503	16		31-62-21	ALL
I ST..	1	W0003	0504	16		31-62-21	ALL
I ST..	1	W0003	0505	16		31-62-21	ALL
I ST..	1	W0003	0507	16		31-62-21	ALL
I ST..	1	W0003	0508	16		31-62-21	ALL
I ST..	1	W0003	0509	16		31-62-21	ALL
I ST..	1	W0003	0510	16		31-62-21	ALL
I GD0301B		BACC50AN20				P003-00/ /	ALL
I ST..	1A	W0003	0516	20		31-62-21	ALL
I DC..	1A	W0003	0578	20		22-14-11	ALL
I DC..	1A	W0003	0604	22		34-61-16	ALL
I DC..	1A	W0003	0628	22		34-49-11	ALL
I DC..	1A	W0003	0631	22		34-49-11	ALL
I DC..	1A	W0003	0634	22		34-49-11	ALL
I ST..	1A	W0003	0642	20		31-22-11	ALL
I DC..	1A	W0003	0643	20		31-22-11	ALL
I DC..	1A	W0003	2515B	24		29-32-11	ALL
I ST..	1A	W0003	2515Z			29-32-11	ALL
I DC..	1A	W0003	2516B	24		29-32-11	ALL
I ST..	1A	W0003	2516Z			29-32-11	ALL
I GD0301C		BACC50AN20				P003-00/ /	ALL
I DC..	1A	W0003	0534	22		31-62-22	ALL
I DC..	1A	W0003	0535	22		31-62-22	ALL
I DC..	1A	W0003	0546	22		31-62-23	ALL

GROUND LIST

D280A351

91-21-21

Section GD03000

Page 1

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD0301C		BACC50AN20 (continued)				P003-00/ /	ALL
DC..	1A	W0003	0547	22		31-62-23	ALL
GD0301D		BACC50AN20				P003-00/ /	ALL
DC..	1A	W0001	0046	22		31-62-13	ALL
DC..	1A	W0001	0047	22		31-62-13	ALL
DC..	1A	W0003	0536	22		31-62-22	ALL
DC..	1A	W0003	0537	22		31-62-22	ALL
GD03032		BACC50AN16				500A/220/R069	YT101-YT120
ST..	1	W3483	0005	16		44-21-16	YT101-YT120
ST..	1	W3483	0006	16		44-21-16	YT101-YT120
GD03034		BACC50AN16				500A/220/L069	YT101-YT120
ST..	1	W3483	0002	16		44-21-16	YT101-YT120
ST..	1	W3483	0003	16		44-21-16	YT101-YT120

GROUND LIST

D280A351

91-21-21

Section GD03000

Page 2 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No.		Part Number		Wire No.	GA	CO	Station / WL / BL	Effectivity
Term	Type	Bundle					Diagram	
GD03101		BACC50AN20					E003-01/ /	ALL
AC..	1A	W0311	0151	20			34-33-11	ALL
ST..	1A	W0311	0152	20			34-33-11	ALL
DC..	1A	W0311	0156	22			34-33-11	ALL
DC..	1A	W0311	0157	22			34-33-11	ALL
GD03102		BACC50AN20					E003-01/ /	ALL
AC..	1A	W0311	0143	20			34-57-11	ALL
ST..	1A	W0311	0144	20			34-57-11	ALL
DC..	1A	W0311	0145	22			34-57-11	ALL
GD03103		BACC50AN16					E003-01/ /	ALL
ST..	1	W0311	0010	16			31-62-11	ALL
ST..	1	W0311	0011	16			31-62-11	ALL
DC..	1	W0311	0025	22			31-62-41	ALL
DC..	1	W0311	0026	22			31-62-41	ALL
DC..	1	W0311	0171	22			31-62-41	ALL
GD03104		BACC50AN16					E003-01/ /	ALL
ST..	1	W0313	0510	16			31-62-21	ALL
ST..	1	W0313	0511	16			31-62-21	ALL
DC..	1	W0313	0525	22			31-62-41	ALL
DC..	1	W0313	0526	22			31-62-41	ALL
DC..	1	W0313	0672	22			31-62-41	ALL
GD03105		BACC50AN20					E003-01/ /	ALL
AC..	1A	W0313	0643	20			34-57-21	ALL
ST..	1A	W0313	0644	20			34-57-21	ALL
DC..	1A	W0313	0645	22			34-57-21	ALL

GROUND LIST

D280A351

91-21-21

Section GD03100

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD03200		BACC50AN20				378/157/L029	ALL
ST..	1A	W5110	0531	20		24-31-12	ALL
ST..	1A	W5110	0539	20		24-31-12	ALL
AC..	1A	W5112	4101G	20		24-21-11	ALL
AC..	1A	W6110	0050	20		33-34-11	ALL
AC..	1A	W6110	0060	20		33-34-11	ALL
DC..	1A	W6110	0516	20		24-51-11	ALL
ST..	1A	W6210	0521	20		24-31-11	ALL
DC..	1A	W6214	5552	20		21-61-11	ALL
DC..	1A	W6214	5554	20		21-61-51	ALL
GD03201		BACC50AN20				E003-02/ /	ALL
AC..	1A	W0321	0036	22		31-31-14	ALL
AC..	1A	W0321	0043	22		31-31-14	ALL
AC..	1A	W0321	0128	22		27-32-11	ALL
DC..	1A	W0321	0130	22		27-32-11	ALL
DC..	1A	W0321	0148	22		27-32-11	ALL
DC..	1A	W0321	0169	22		22-23-11	ALL
DC..	1A	W0321	0286	20		27-32-21	ALL
DC..	1A	W0321	0377	22		27-32-11	ALL
DC..	1A	W0321	0450	22		27-32-11	ALL
DC..	1A	W0321	0466	22		27-32-21	ALL
AC..	1A	W0321	0476	22		31-31-14	ALL
AC..	1A	W0321	0603	20		22-23-12	ALL
GD03202		BACC50AN20				E003-02/ /	ALL
DC..	1A	W0321	0246	22		22-23-11	ALL
AC..	1A	W0321	0252	22		27-32-21	ALL
AC..	1A	W0321	0255	22		27-32-21	ALL
DC..	1A	W0321	0257	22		27-32-21	ALL
AC..	1A	W0321	0366	24		31-31-14	ALL
AC..	1A	W0321	0367	24		31-31-14	ALL
DC..	1A	W0321	0493	22		27-32-21	ALL
AC..	1A	W0321	2023B	22		31-31-14	ALL
AC..	1A	W0321	2152B	22		31-31-14	ALL
AC..	1A	W0321	2160B	22		31-31-14	ALL
GD03203		BACC50AN20				E003-02/ /	ALL
AC..	1A	W0321	0046	22		31-31-14	ALL
AC..	1A	W0321	0053	22		31-31-14	ALL
DC..	1A	W0321	0307	20		78-34-21	ALL

GROUND LIST

D280A351

91-21-21

Section GD03200

Page 1

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD03203		BACC50AN20 (continued)				E003-02/ /	ALL
DC..	1A	W0321	0322	20		78-34-11	ALL
AC..	1A	W0321	0375	22		27-24-11	ALL
AC..	1A	W0321	0606	20		27-24-11	ALL
DC..	1A	W0321	0707	20		78-36-11	ALL
ST..	1A	W0321	0708	20		78-36-11	ALL
DC..	1A	W0321	0710	20		78-36-21	ALL
ST..	1A	W0321	0711	20		78-36-21	ALL
AC..	1A	W0321	0771	24		77-31-11	ALL
AC..	1A	W0321	0772	24		77-31-11	ALL
DC..	1A	W0321	0773	24		77-31-11	ALL
ST..	1A	W0321	0774	24		77-31-21	ALL
GD03204		BACC50AN20				E003-02/ /	ALL
AC..	1A	W0321	0002	22		31-31-11	ALL
DC..	1A	W0321	0003	22		31-31-11	ALL
DC..	1A	W0321	0004	22		31-31-11	ALL
DC..	1A	W0321	0005	22		31-31-11	ALL
DC..	1A	W0321	0006	22		31-31-11	ALL
AC..	1A	W0321	0035	22		31-31-14	ALL
AC..	1A	W0321	0042	22		31-31-14	ALL
AC..	1A	W0321	0045	22		31-31-14	ALL
AC..	1A	W0321	0052	22		31-31-14	ALL
AC..	1A	W0321	0091	24		27-18-11	ALL
AC..	1A	W0321	0127	20		27-32-11	ALL
DC..	1A	W0321	0165	22		31-31-11	ALL
AC..	1A	W0321	0254	20		27-32-21	ALL
AC..	1A	W0321	0475	22		31-31-14	ALL
DC..	1A	W0321	0557	22		31-31-11	ALL
GD03205		BACC50AN20				E003-02/ /	ALL
AC..	1A	W0321	0131	22		27-32-11	ALL
AC..	1A	W0321	0261	22		22-23-12	ALL
ST..	1A	W0321	0341	20		34-33-21	ALL
AC..	1A	W0321	0343	20		34-33-21	ALL
DC..	1A	W0321	0352	22		34-33-21	ALL
DC..	1A	W0321	0353	22		34-33-21	ALL
GD03207		CGH20-22-1				E003-02/ /	ALL
DC..	1F	W0321	0186	22		27-32-11	ALL
DC..	1F	W0321	0187	22		27-32-11	ALL

GROUND LIST

D280A351

91-21-21

Section GD03200

Page 2

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD03207		CGH20-22-1 (continued)				E003-02/ /	ALL
ST..	1F	W0321	2025Z			27-32-12	ALL
ST..	1F	W0321	2029Z			34-21-14	ALL
ST..	1F	W0321	2047Z			34-21-23	ALL
ST..	1F	W0321	2166Z			34-21-13	ALL
ST..	1F	W0321	2167Z			34-61-14	ALL
ST..	1F	W0321	2211Z			22-11-51	ALL
ST..	1F	W0321	2221Z			22-23-12	ALL
ST..	1F	W0321	2222Z			22-23-12	ALL
ST..	1F	W0321	2716Z			31-62-15	ALL
GD03209		CGH20-22-1				E003-02/ /	ALL
DC..	1F	W0321	0129	22		27-32-11	ALL
DC..	1F	W0321	0188	22		27-32-11	ALL
ST..	1F	W0321	2062Z			22-23-11	ALL
ST..	1F	W0321	2063Z			22-23-11	ALL
ST..	1F	W0321	2223Z			22-23-12	ALL
ST..	1F	W0321	2505Z			27-32-11	ALL
ST..	1F	W0321	3225Z			22-23-12	ALL
GD03211		CGH20-22-1				E003-02/ /	ALL
DC..	1F	W0321	0190	22		27-32-21	ALL
DC..	1F	W0321	0191	22		27-32-21	ALL
ST..	1F	W0321	2027Z			27-32-22	ALL
ST..	1F	W0321	2048Z			34-21-23	ALL
ST..	1F	W0321	2145Z			34-21-24	YT104-YT133
ST..	1F	W0321	2165Z			34-21-13	ALL
ST..	1F	W0321	2168Z			34-61-14	ALL
ST..	1F	W0321	2170Z			34-21-24	YT101-YT103
ST..	1F	W0321	2212Z			22-11-51	ALL
ST..	1F	W0321	2507Z			27-32-21	ALL
ST..	1F	W0321	2709Z			22-23-12	ALL
ST..	1F	W0321	2719Z			22-23-12	ALL
ST..	1F	W0321	2750Z			31-62-25	ALL
GD03213		CGH20-22-1				E003-02/ /	ALL
DC..	1F	W0321	0189	22		27-32-21	ALL
DC..	1F	W0321	0256	22		27-32-21	ALL
ST..	1F	W0321	2062Z			22-23-11	ALL
ST..	1F	W0321	2063Z			22-23-11	ALL
ST..	1F	W0321	2720Z			27-24-11	ALL

GROUND LIST

D280A351

91-21-21

Section GD03200

Page 3

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD03213		CGH20-22-1 (continued)				E003-02/ /	ALL
ST..	1F	W0321	3721Z			27-24-11	ALL
GD03214		ST				500I+19/163/L039	ALL
ST..	E	W5104	1013Z			21-51-14	ALL
ST..	E	W5104	2006Z			21-51-12	YT116-YT120, YT132-YT133
GD03215		ST				500I+12/176/L053	ALL
ST..	E	W5104	FRFA			21-51-14	ALL
GD03234		ST-				520/154/R018	ALL
ST..	E	W6230	0328	14		21-25-11	ALL
GD03250		DC-				547/158/L007	ALL
DC..	GW	W5502	0005	20		34-61-17	ALL
DC..	GW	W5502	1007Z			36-11-11	ALL
DC..	GW	W5502	1008Z			34-61-17	ALL
DC..	GW	W5502	1038	20		21-61-11	ALL
DC..	GW	W5502	1038Z			21-61-11	ALL
DC..	GW	W5502	4001Z			36-11-11	ALL
GD03252		DC-				361/153/L002	ALL
DC..	H8	W2532	0502	*1		24-31-11	ALL
DC..	H8	W2532	0516	*1		49-41-11	ALL
DC..	H	W2532	2201B	20		24-31-11	ALL
GD03254		BACC50AN20				520/154/R017	ALL
DC..	1A	W6230	0327	20		21-25-11	ALL
ST..	1A	W6230	1013Z			21-51-24	ALL
ST..	1A	W6230	2005Z			21-51-22	YT116-YT120, YT132-YT133
DC..	1A	W6528	0309	20		21-51-25	ALL
GD03256		DC-				368/153/L016	ALL
DC..	H8	W2532	0531	*1		24-31-12	ALL
DC..	H	W2532	2202B	20		24-31-12	ALL
GD03258		ST				520/154/L017	ALL
ST..	E	W5104	0327	14		21-25-11	ALL

GROUND LIST

D280A351

91-21-21

Section GD03200

Page 4 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD03303		BACC50AN20				E003-03/ /	ALL
DC..	1A	W0330	0211	22		21-51-12	YT116-YT120, YT132-YT133
AC..	1A	W0330	0215	22		21-51-12	YT116-YT120, YT132-YT133
DC..	1A	W0330	0240	22		21-51-12	YT116-YT120, YT132-YT133
DC..	1A	W0330	0241	22		21-51-12	YT116-YT120, YT132-YT133
AC..	1A	W0330	0313	22		21-51-12	ALL
DC..	1A	W0330	0316	22		21-51-12	ALL
ST..	1A	W0330	0319	20		21-51-12	YT101-YT115, YT126-YT131
ST..	1A	W0330	0319	22		21-51-12	YT116-YT120, YT132-YT133
DC..	1A	W0331	0105	22		23-12-31	ALL
DC..	1A	W0331	0106	22		23-12-31	ALL
DC..	1A	W0331	0341	22		31-35-03	ALL
DC..	1A	W0331	0345	22		31-35-03	ALL
DC..	1A	W0331	0470	22		23-12-31	ALL
DC..	1A	W0331	0548	22		31-35-03	ALL
GD03304		BACC50AN20				E003-03/ /	ALL
AC..	1A	W0330	0349	22		21-51-22	YT101-YT115, YT126-YT131
AC..	1A	W0330	0349	24		21-51-22	YT116-YT120, YT132-YT133
DC..	1A	W0330	0352	22		21-51-22	YT101-YT115, YT126-YT131
DC..	1A	W0330	0352	24		21-51-22	YT116-YT120, YT132-YT133
ST..	1A	W0330	0355	20		21-51-22	YT101-YT115, YT126-YT131
ST..	1A	W0330	0355	24		21-51-22	YT116-YT120, YT132-YT133
AC..	1A	W0331	0339	20		31-35-03	ALL
GD03305		BACC50AN16				E003-03/ /	ALL
DC..	1	W0331	0104	16		23-12-31	ALL
GD03308		DC-				368/153/L019	ALL
DC..	F8	W2532	0532	02		24-31-12	ALL
GD03316		AC-				213/208/R036	ALL
AC..	E	W2204	5513	20		33-11-21	ALL
AC..	E	W2204	5535	20		33-17-11	ALL
GD03322		BACC50AN16				685/211/L066	ALL
ST..	1	W3483	0008	16		44-21-16	YT101-YT120
ST..	1	W3483	0009	16		44-21-16	YT101-YT120
ST..	1	W3749	0001	16		44-21-16	YT101-YT120
ST..	1	W3749	0002	16		44-21-16	YT101-YT120

GROUND LIST

D280A351

91-21-21

Section GD03300

Page 1

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	Ground No.		Part Number		Wire No.	GA	CO	Station / WL / BL	Effectivity
	Term	Type	Bundle					Diagram	
I	GD03356		AC-					//	ALL
I	GD03366		ST-					//	ALL
I	GD03372		BACC50AN16					847/220/L069	ALL
I	DC..	1	W3142	0468		20		33-51-22	ALL
I	DC..	1	W3142	0469		16		33-51-22	ALL
	ST..	1	W3753	0001		16		44-21-16	YT101-YT120
	ST..	1	W3753	0002		16		44-21-16	YT101-YT120

GROUND LIST

D280A351

91-21-21

Section GD03300

Page 2 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	Ground No.	Type	Part Number	Wire No.	GA	CO	Station / WL / BL	Effectivity
	Term		Bundle				Diagram	
I	GD03404		BACC50AN16				387/170/R048	ALL
I	ST..	1	W6210	2202B	22		24-41-11	ALL
I	AC..	1	W6210	4101G	20		24-21-21	ALL
I	ST..	1	W6210	4102G	22		24-41-11	ALL
I	GD03448		BACC50AN16				827/205/L030	ALL

GROUND LIST

D280A351

91-21-21

Section GD03400

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD03704		BACC50AN20				J020-0A/ /	ALL
DC..	1A	W0074	0187	22		21-31-22	ALL
DC..	1A	W0074	0188	22		21-31-22	ALL
DC..	1A	W0074	0189	22		21-31-22	ALL
DC..	1A	W0074	0190	22		21-31-22	ALL
DC..	1A	W0074	0191	20		21-31-22	ALL
DC..	1A	W0074	0197	22		21-31-23	ALL
DC..	1A	W0074	0198	22		21-31-23	ALL
DC..	1A	W0074	0199	22		21-31-23	ALL
DC..	1A	W0074	0200	22		21-31-23	ALL
DC..	1A	W0074	0201	20		21-31-23	ALL
DC..	1A	W0074	0207	20		47-30-11	ALL
DC..	1A	W0074	0209	20		28-44-11	ALL
GD03728		BACC50AN16				597/295/L031	ALL
DC..	1	W3142	0058	20		33-51-13	ALL
DC..	1	W3142	0273	20		33-51-13	ALL
DC..	1	W3142	0274	16		33-51-13	ALL
DC..	1	W3142	0435	20		52-71-13	ALL
DC..	1	W3142	0439	20		52-71-13	ALL
DC..	1	W3142	0577	16		33-51-13	ALL
AC..	1	W3142	5537	20		21-42-11	ALL
AC..	1	W3166	0105	18		33-22-41	ALL
ST..	1	W3166	0106	18		33-22-41	ALL
AC..	1	W3166	0285	18		33-22-21	ALL
ST..	1	W3166	0286	18		33-22-21	ALL
GD03734		BACC50AN20				359/291/L027	ALL
DC..	1A	W3142	0276	20		33-51-21	ALL
DC..	1A	W3142	0376	20		33-51-21	ALL
AC..	1D	W3144	0002	18		33-25-21	ALL
ST..	1A	W3144	1161	20		23-70-11	ALL
ST..	1A	W3702	0001	22		23-70-11	ALL
GD03736		BACC50AN16				986.5/294/R028	ALL
AC..	1	W3144	0097	18		33-25-22	ALL
GD03738		BACC50AN16				967/181/R008	ALL
ST..	1	W6102	1001Z			21-31-22	ALL
ST..	1	W6102	2001Z			21-31-22	ALL
ST..	1	W6102	2002Z			21-31-22	ALL

GROUND LIST

D280A351

91-21-21

Section GD03700

Page 1

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD03738		BACC50AN16 (continued)				967/181/R008	ALL
ST..	1	W6102	2004Z			21-31-11	ALL
ST..	1	W6102	3002Z			21-31-11	ALL
ST..	1	W6102	5503	20		21-31-22	ALL
ST..	1	W6102	5504	20		21-31-22	ALL
DC..	1	W6102	5505	20		21-31-22	ALL
DC..	1	W6102	5506	20		21-31-22	ALL
ST..	1	W6102	5507	20		21-31-11	ALL
GD03740		BACC50AN16				967/181/R015	ALL
ST..	1	W6204	1001Z			21-31-23	ALL
ST..	1	W6204	2001Z			21-31-23	ALL
ST..	1	W6204	2002Z			21-31-23	ALL
ST..	1	W6204	5503	20		21-31-23	ALL
ST..	1	W6204	5504	20		21-31-23	ALL
DC..	1	W6204	5505	20		21-31-23	ALL
DC..	1	W6204	5506	20		21-31-23	ALL
AC..	1	W6248	5551	20		30-71-11	ALL
AC..	1	W6248	5553	20		30-71-11	ALL
AC..	1	W6248	5565	20		30-71-11	ALL
GD03742		BACC50AN16				558/284/L047	ALL
AC..	1	W3166	0055	18		33-22-41	ALL
ST..	1	W3166	0056	18		33-22-41	ALL
AC..	1	W3166	0275	18		33-22-21	ALL
ST..	1	W3166	0276	18		33-22-21	ALL
GD03744		BACC50AN16				616/280/L051	ALL
DC..	1	W3142	0073	20		33-51-21	ALL
DC..	1	W3142	0253	20		33-51-13	ALL
DC..	1	W3142	0255	16		33-51-13	ALL
DC..	1	W3142	0269	16		33-51-12	ALL
DC..	1	W3142	0467	20		52-71-13	ALL
AC..	1	W3142	5535	20		21-42-11	ALL
AC..	1	W3246	0022	18		33-21-12	ALL
ST..	1	W3246	0023	18		33-21-12	ALL
ST..	1	W3246	0025	18		33-21-12	ALL
AC..	1	W3246	0032	18		33-21-12	ALL
ST..	1	W3246	0033	18		33-21-12	ALL
ST..	1	W3246	0035	18		33-21-12	ALL

GROUND LIST

D280A351

91-21-21

Section GD03700

Page 2

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD03746		BACC50AN16				617/XXX/LXXX	ALL
GD03750		BACC50AN16				558/292/R036	ALL
AC..	1	W4142	1202	20		33-44-11	ALL
ST..	1	W4142	1202Z			33-44-11	ALL
ST..	1	W4142	1203	20		33-44-11	ALL
ST..	1	W4142	1203Z			33-44-11	ALL
AC..	1	W4166	0055	18		33-22-51	ALL
ST..	1	W4166	0056	18		33-22-51	ALL
AC..	1	W4166	0275	18		33-22-31	ALL
ST..	1	W4166	0276	18		33-22-31	ALL
GD03754		BACC50AN16				664/234/L073	ALL
DC..	1	W3142	0082	20		33-51-22	ALL
DC..	1	W3142	0251	16		33-51-13	ALL
DC..	1	W3142	0461	20		52-71-13	ALL
AC..	1	W3142	5527	20		21-42-11	ALL
AC..	1	W3142	5574	20		21-42-11	ALL
GD03756		BACC50AN16				727D/296/L028	ALL
AC..	1	W3166	0525	18		33-22-22	ALL
ST..	1	W3166	0526	18		33-22-22	ALL
AC..	1	W3166	0555	18		33-22-41	ALL
ST..	1	W3166	0556	18		33-22-41	ALL
GD03760		BACC50AN16				727D+19/204/L022	YT101-YT111, YT126-YT130
GD03760		BACC50AN16				727C+22/204/L023	YT112-YT120, YT131-YT133
AC..	1	W6248	0274	20		33-36-12	ALL
GD03764		BACC50AN16				765/296/L029	ALL
DC..	1	W3142	0448	16		33-51-14	ALL
DC..	1	W3142	0456	20		33-51-14	ALL
AC..	1	W3166	0175	18		33-22-41	ALL
ST..	1	W3166	0176	18		33-22-41	ALL
AC..	1	W3166	0375	18		33-22-22	ALL
ST..	1	W3166	0376	18		33-22-22	ALL
DC..	CT	W3419	0034	20		23-24-11	ALL
DC..	1	W3419	0035	20		23-24-11	ALL
DC..	1	W3419	0036	20		23-24-11	ALL

GROUND LIST

D280A351

91-21-21

Section GD03700

Page 3

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD03770		BACC50AN16				886/296/L028	ALL
AC..	1	W3058	0054	18		33-26-31	YT101-YT131
DC..	1	W3058	0430	22		33-51-11	YT101-YT131
AC..	1	W3166	0515	18		33-22-22	ALL
ST..	1	W3166	0516	18		33-22-22	ALL
GD03772		BACC50AN16				966/294/R029	ALL
ST..	1	W3144	5503	20		21-42-11	ALL
DC..	1	W4142	0459	20		33-51-14	ALL
AC..	1	W4142	0476	20		33-26-11	ALL
GD03774		ST-				665/181/L040	ALL
ST..	E	W7580	1301ZO			28-41-11	ALL
ST..	E	W7580	1302Z			28-41-11	ALL
ST..	E	W7580	1303Z			28-41-11	ALL
GD03776		BACC50AN16				993/ /L	ALL
GD03778		BACC50AN16				1005/248/L055	ALL
DC..	1	W3142	0451	18		33-51-14	ALL
DC..	1	W3142	0452	20		33-51-22	ALL
AC..	1	W6248	0102	20		52-71-11	ALL
GD03780		BACC50AN16				420/218/L068	ALL
DC..	1	W3142	0078	20		33-51-21	ALL
DC..	1	W3142	0079	16		33-51-21	ALL
GD03782		BACC50AN16				301/222/L060	ALL
DC..	1	W4142	0152	20		33-51-21	ALL
GD03794		BACC50AN16				616/280/R052	ALL
DC..	1	W4142	0351	20		33-51-21	ALL
DC..	1	W4142	0353	20		33-51-13	ALL
DC..	1	W4142	0354	16		33-51-13	ALL
DC..	1	W4142	0361	16		33-51-12	ALL
DC..	1	W4142	0439	20		52-71-14	ALL
DC..	1	W4142	0443	20		52-71-14	ALL
DC..	1	W4142	0467	20		52-71-14	ALL
DC..	1	W4142	0551	16		33-51-12	ALL
AC..	1	W4142	5533	20		21-42-11	ALL

GROUND LIST

D280A351

91-21-21

Section GD03700

Page 4

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD03794		BACC50AN16 (continued)				616/280/R052	ALL
AC..	1	W4142	5535	20		21-42-11	ALL
AC..	1	W4142	5537	20		21-42-11	ALL
GD03798		BACC50AN16				597/295/R031	ALL
AC..	1	W4166	0065	18		33-22-51	ALL
ST..	1	W4166	0066	18		33-22-51	ALL
AC..	1	W4166	0285	18		33-22-31	ALL
ST..	1	W4166	0286	18		33-22-31	ALL
AC..	1	W4246	0022	18		33-21-12	ALL
ST..	1	W4246	0023	18		33-21-12	ALL
ST..	1	W4246	0025	18		33-21-12	ALL
AC..	1	W4246	0032	18		33-21-12	ALL
ST..	1	W4246	0033	18		33-21-12	ALL
ST..	1	W4246	0035	18		33-21-12	ALL

GROUND LIST

D280A351

91-21-21

Section GD03700

Page 5 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD03801		BACC50AN16				380/218/R068	YT101-YT120
ST..	1	W3479	0005	16		44-21-16	YT101-YT120
ST..	1	W3479	0006	16		44-21-16	YT101-YT120
GD03802		BACC50AN16				664/234/R073	ALL
DC..	1	W4142	0252	16		33-51-14	ALL
DC..	1	W4142	0461	20		52-71-14	ALL
AC..	1	W4142	5514	20		21-42-11	ALL
AC..	1	W4142	5527	20		21-42-11	ALL
GD03804		BACC50AN16				685/287/R044	ALL
AC..	1	W4166	0075	18		33-22-51	ALL
ST..	1	W4166	0076	18		33-22-51	ALL
GD03806		BACC50AN16				727B/296/R031	ALL
DC..	1	W4142	0621	20		33-51-14	ALL
DC..	1	W4142	0625	20		33-51-14	ALL
AC..	1	W4166	0325	18		33-22-32	ALL
ST..	1	W4166	0326	18		33-22-32	ALL
AC..	1	W4166	0545	18		33-22-32	ALL
ST..	1	W4166	0546	18		33-22-32	ALL
GD03808		BACC50AN16				767/296/R031	ALL
DC..	1	W4142	0623	20		33-51-14	ALL
AC..	1	W4166	0165	18		33-22-51	ALL
ST..	1	W4166	0166	18		33-22-51	ALL
AC..	1	W4166	0505	18		33-22-32	ALL
ST..	1	W4166	0506	18		33-22-32	ALL
GD03810		BACC50AN16				1006/248/R056	ALL
DC..	1	W4142	0451	18		33-51-14	ALL
DC..	1	W4142	0452	20		33-51-22	ALL
AC..	1	W6248	0104	20		52-71-11	ALL
GD03814		BACC50AN16				986/292/L030	ALL
DC..	1	W3142	0474	20		33-51-14	ALL
AC..	1	W3142	0476	20		33-26-11	ALL
GD03816		BACC50AN16				867/297/R029	ALL
DC..	1	W4142	0629	20		33-51-14	ALL

GROUND LIST

D280A351

91-21-21

Section GD03800

Page 1

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD03816		BACC50AN16 (continued)				867/297/R029	ALL
AC..	1	W4166	0195	18		33-22-51	ALL
ST..	1	W4166	0196	18		33-22-51	ALL
AC..	1	W4246	0042	18		33-21-12	ALL
ST..	1	W4246	0043	18		33-21-12	ALL
ST..	1	W4246	0044	18		33-21-12	ALL
AC..	1	W4246	0052	18		33-21-12	ALL
ST..	1	W4246	0053	18		33-21-12	ALL
ST..	1	W4246	0054	18		33-21-12	ALL
GD03822		BACC50AN16				807/296/R031	ALL
GD03834		AC-				IFSS-200/ /	ALL
AC..	IA	W1186	0004	04		24-21-11	ALL
GD03836		BACC50AN16				NSTA 161/137/L 1	ALL
DC..	1	W1164	0001	20		80-11-11	ALL
ST..	1	W1164	0002	20		80-11-11	ALL
DC..	1	W1164	0003	20		80-11-11	ALL
DC..	1	W1164	0005	20		29-11-11	ALL
DC..	1	W1164	0006	20		76-21-11	ALL
DC..	1	W1164	0007	20		76-21-11	ALL
DC..	1	W1164	1012	18		24-11-11	ALL
DED		W1164	1012Z			24-11-11	ALL
GD03838		BACC50AN16				NSTA 161/137/R 2	ALL
DC..	1	W1170	0002	20		30-21-11	ALL
DC..	1	W1170	0009	18		30-21-11	ALL
DC..	1	W1170	0010	18		30-21-11	ALL
DC..	1	W1170	0012	18		30-21-11	ALL
DC..	1	W1170	0015	18		30-21-11	ALL
GD03840		BACC50AN16				NSTA 161/137/R 4	ALL
AC..	1	W1166	0001	20		74-11-11	ALL
AC..	1	W1166	0002	20		73-22-11	ALL
ST..	1	W1166	0010	18		26-12-11	ALL
AC..	1	W1170	1002	20		74-11-11	ALL
ST..	1	W1170	1002Z			74-11-11	ALL
AC..	1	W1170	1006	20		73-22-11	ALL
ST..	1	W1170	1006Z			73-22-11	ALL

GROUND LIST

D280A351

91-21-21

Section GD03800

Page 2

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD03842		ST-				1/1/1	ALL
ST..	GW	W1166	0010	18		26-12-11	ALL
ST..	GW	W1166	FRAA			26-12-11	ALL
GD03846		BACC50AN16				480/300/R020	ALL
AC..	1	W4166	0525	18		33-22-31	ALL
ST..	1	W4166	0526	18		33-22-31	ALL
GD03848		BACC50AN16				727A/296/L028	ALL
DC..	1	W3142	0613	20		33-51-13	ALL
DC..	1	W3142	0615	20		33-51-13	ALL
AC..	1	W3166	0335	18		33-22-22	ALL
ST..	1	W3166	0336	18		33-22-22	ALL
GD03854		BACC50AN16				400/299/R012	ALL
DC..	1	W4142	0070	20		33-51-12	ALL
GD03856		BACC50AN16				420/298/L016	ALL
AC..	1	W3246	0002	18		33-21-12	ALL
ST..	1	W3246	0003	18		33-21-12	ALL
ST..	1	W3246	0004	18		33-21-12	ALL
AC..	1	W3246	0012	18		33-21-12	ALL
ST..	1	W3246	0013	18		33-21-12	ALL
ST..	1	W3246	0014	18		33-21-12	ALL
GD03858		BACC50AN20				419/294/R028	ALL
AC..	1D	W4246	0002	18		33-21-12	ALL
ST..	1D	W4246	0003	18		33-21-12	ALL
ST..	1D	W4246	0004	18		33-21-12	ALL
AC..	1D	W4246	0012	18		33-21-12	ALL
ST..	1D	W4246	0013	18		33-21-12	ALL
ST..	1D	W4246	0014	18		33-21-12	ALL
AC..	1A	W6288	0004	20		21-61-13	ALL
ST..	1A	W6288	0005	20		21-61-13	ALL
DC..	1A	W6288	0014	20		21-61-51	ALL
GD03860		BACC50AN16				459/299/L020	ALL
DC..	1	W3142	0637	20		33-51-12	ALL
AC..	1	W3166	0225	18		33-22-21	ALL
ST..	1	W3166	0226	18		33-22-21	ALL

GROUND LIST

D280A351

91-21-21

Section GD03800

Page 3

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD03860		BACC50AN16 (continued)				459/299/L020	ALL
AC..	1	W3166	0565	18		33-22-41	ALL
ST..	1	W3166	0566	18		33-22-41	ALL
GD03862		BACC50AN16				499/295/R030	ALL
AC..	1	W4166	0425	18		33-22-31	ALL
ST..	1	W4166	0426	18		33-22-31	ALL
AC..	1	W4166	0575	18		33-22-51	ALL
ST..	1	W4166	0576	18		33-22-51	ALL
GD03864		BACC50AN16				926/302/L004	ALL
ST..	1	W3144	0301	18		33-26-31	ALL
DC..	1	W3144	0311	20		33-51-22	ALL
DC..	1	W3144	0315	18		35-21-21	ALL
AC..	1	W3144	0328	18		33-25-11	ALL
ST..	1	W3144	0330	18		33-26-31	ALL
AC..	1	W3144	0339	18		33-26-31	ALL
AC..	1	W3144	0340	18		33-26-31	ALL
DC..	1	W5409	0003	20		31-31-11	ALL
DC..	1	W5409	0004	20		31-31-11	ALL
AC..	1	W5409	0005	20		31-31-11	ALL
GD03866		BACC50AN16				500/295/L030	ALL
DC..	1	W3142	0068	16		33-51-12	ALL
AC..	1	W3166	0085	18		33-22-41	ALL
ST..	1	W3166	0086	18		33-22-41	ALL
AC..	1	W3166	0535	18		33-22-21	ALL
ST..	1	W3166	0536	18		33-22-21	ALL
GD03868		BACC50AN16				500B/296/R031	ALL
AC..	1	W3755	0003	20		44-35-20	ALL
ST..	1	W3755	0004	20		44-35-20	ALL
DC..	1	W4142	0537	20		33-51-12	ALL
DC..	1	W4142	0538	20		33-51-12	ALL
AC..	1	W4166	0115	18		33-22-51	ALL
ST..	1	W4166	0116	18		33-22-51	ALL
AC..	1	W4166	0245	18		33-22-31	ALL
ST..	1	W4166	0246	18		33-22-31	ALL
DC..	1	W4250	0924	18		33-27-31	ALL

GROUND LIST

D280A351

91-21-21

Section GD03800

Page 4

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD03876		BACC50AN16				380/220/L068	ALL
DC..	1	W3142	0151	16		33-51-12	ALL
ST..	1	W3479	0002	16		44-21-16	YT101-YT120
ST..	1	W3479	0003	16		44-21-16	YT101-YT120
GD03880		BACC50AN16				344/227/R065	ALL
DC..	1	W4142	0051	18		33-51-12	ALL
AC..	1	W6412	0005	20		52-71-11	ALL
GD03882		BACC50AN16				727D/296/R031	ALL
AC..	1	W4166	0535	18		33-22-32	ALL
ST..	1	W4166	0536	18		33-22-32	ALL
GD03892		ST-				OFSS-737/ /	ALL
ST..	N	W1242	1007	12		33-43-11	ALL
ST..	N	W1242	1007Z			33-43-11	ALL
GD03896		ST-				FSS737/ /	ALL
ST..	N	W1244	1007	12		33-43-11	ALL
ST..	N	W1244	1007Z			33-43-11	ALL
GD03898		AC-				OFSS-745/234/R072	ALL
AC..	N	W1242	1004	12		33-43-11	ALL
AC..	N	W1242	1004Z			33-43-11	ALL
AC..	N	W1242	1006	12		33-43-11	ALL
AC..	N	W1242	1006Z			33-43-11	ALL
AC..	N	W1242	1021	20		33-44-12	ALL
AC..	N	W1242	1021Z			33-44-12	ALL

GROUND LIST

D280A351

91-21-21

Section GD03800

Page 5 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD03900		ST-				OFSS-739/ /	ALL
ST..	N	W1242	1022	20		33-44-12	ALL
ST..	N	W1242	1022Z			33-44-12	ALL
GD03902		AC-				OFSS 745/ /	ALL
AC..	N	W1244	1004	12		33-43-11	ALL
AC..	N	W1244	1004Z			33-43-11	ALL
AC..	N	W1244	1006	12		33-43-11	ALL
AC..	N	W1244	1006Z			33-43-11	ALL
AC..	N	W1244	1021	20		33-44-12	ALL
AC..	N	W1244	1021Z			33-44-12	ALL
GD03904		ST-				OFSS 739/ /	ALL
ST..	N	W1244	1022	20		33-44-12	ALL
ST..	N	W1244	1022Z			33-44-12	ALL
GD03906		ST				IFSS-102/ /	ALL
ST..	GW	W1662	1001Z			33-42-11	YT101-YT112, YT126-YT130
ST..	GW	W1662	1002Z			33-42-11	YT101-YT112, YT126-YT130
ST..	GW	W1662	1003Z			33-42-11	YT101-YT112, YT126-YT130
GD03920		ST-				OFSS-260/ /	ALL
ST..	E	W1182	1003Z			26-12-11	ALL
ST..	E	W1188	1014Z			26-12-11	ALL
GD03924		BACC50AN16				328/293/R014	ALL
ST..	1	W3703	0001	22		23-70-11	ALL
DC..	1	W4142	0059	20		33-51-12	ALL
DC..	1	W4142	0066	18		35-21-21	ALL
DC..	1	W4142	0078	18		35-21-31	ALL
GD03926		BACC50AN16				328/295/L014	ALL
DC..	1	W3058	0063	20		33-29-11	YT101-YT131
ST..	1	W3058	0083	18		33-24-21	YT101-YT131
AC..	1	W3058	0084	18		33-24-21	YT101-YT131
ST..	1	W3058	0085	18		33-24-21	YT101-YT131
AC..	1	W3058	0086	18		33-24-21	YT101-YT131
GD03934		AC-				IFSS 200/ /	ALL
AC..	IA	W1286	0004	04		24-21-21	ALL

GROUND LIST

D280A351

91-21-21

Section GD03900

Page 1

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD03936		BACC50AN16				NSTA 162/137/0	ALL
DC..	1	W1264	0001	20		80-11-11	ALL
ST..	1	W1264	0002	20		80-11-11	ALL
DC..	1	W1264	0003	20		80-11-11	ALL
DC..	1	W1264	0005	20		29-11-11	ALL
DC..	1	W1264	0006	20		76-21-21	ALL
DC..	1	W1264	0007	20		76-21-21	ALL
DC..	1	W1264	1012	18		24-11-21	ALL
DED		W1264	1012Z			24-11-21	ALL
GD03938		BACC50AN16				NSTA 162/137/R001	ALL
DC..	1	W1270	0002	20		30-21-21	ALL
DC..	1	W1270	0009	18		30-21-21	ALL
DC..	1	W1270	0010	18		30-21-21	ALL
DC..	1	W1270	0012	18		30-21-21	ALL
DC..	1	W1270	0015	18		30-21-21	ALL
GD03940		BACC50AN16				NSTA/ /	ALL
AC..	1	W1266	0001	20		74-11-11	ALL
AC..	1	W1266	0002	20		73-22-11	ALL
ST..	1	W1266	0010	18		26-12-11	ALL
AC..	1	W1270	1002	20		74-11-11	ALL
ST..	1	W1270	1002Z			74-11-11	ALL
AC..	1	W1270	1006	20		73-22-11	ALL
ST..	1	W1270	1006Z			73-22-11	ALL
GD03942		ST-				1/1/1	ALL
ST..	GW	W1266	0010	18		26-12-11	ALL
ST..	GW	W1266	FRAA			26-12-11	ALL
GD03946		BACC50AN16				727D/221/L070	ALL
DC..	1	W3142	0301	16		33-51-11	ALL
ST..	1	W3142	0307	20		33-51-11	ALL
DC..	1	W3142	0394	20		33-51-22	ALL
DC..	1	W3142	0395	16		33-51-22	ALL
GD03948		BACC50AN16				947/300/L007	ALL
DC..	1	W3058	0233	20		38-32-13	YT101-YT131
DC..	1	W3058	0255	20		23-42-11	YT101-YT131
DC..	1	W3142	0401	16		33-51-11	ALL
ST..	1	W3142	0407	20		33-51-11	ALL

GROUND LIST

D280A351

91-21-21

Section GD03900

Page 2

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD03948		BACC50AN16 (continued)				947/300/L007	ALL
DC..	1	W3311	0004	20		23-31-01	ALL
ST..	1	W3311	0005	20		23-42-12	ALL
DC..	1	W7359	0002	18		35-21-21	ALL
GD03950		DC-				OFSS-267/ /	ALL
ST..	E	W1140	001TO			28-41-11	ALL
ST..	E	W1140	1002Z			28-41-11	ALL
ST..	E	W1140	1003Z			28-41-11	ALL
GD03951		BACC50AN16				948/302/L005	ALL
ST..	1	W3311	0045	22		23-31-01	ALL
ST..	1	W5431	0028	22		23-71-01	ALL
DC..	1	W5431	0029	22		23-71-01	ALL
DC..	1	W5431	0033	24		23-71-01	ALL
GD03952		DC-				OFSS 267/ /	ALL
ST..	E	W1138	001TO			28-41-11	ALL
ST..	E	W1138	1002Z			28-41-11	ALL
ST..	E	W1138	1003Z			28-41-11	ALL
GD03956		AC-				987/298/R018	ALL
AC..	P	W3154	0010	08		25-31-11	ALL
GD03958		AC-				987/297/R018	ALL
AC..	GY	W3154	0020	10		25-31-11	ALL
GD03960		AC-				295/287/R013	ALL
AC..	GY	W4256	0014	10		25-31-11	ALL
GD03973		DC-				E003-01/ /	ALL
DC..	E	W0311	0003	14		31-62-11	ALL
DC..	E	W0311	0005	14		31-62-11	ALL
GD03975		DC-				E003-01/ /	ALL
DC..	E	W0313	0503	14		31-62-21	ALL
DC..	E	W0313	0505	14		31-62-21	ALL
GD03977		DC-				191/228/L020	ALL
DC..	E	W0001	0001	14		31-62-11	ALL

GROUND LIST

D280A351

91-21-21

Section GD03900

Page 3

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD03979		DC-				191/228/L012	ALL
DC..	E	W0001	0006	14		31-62-11	ALL
GD03980		DC-				OFSS-274/ /	ALL
DC..	E	W1178	1011	18		28-21-11	ALL
DC..	E	W1178	1011Z			28-21-11	ALL
DC..	E	W1188	1013	20		30-11-11	ALL
DC..	E	W1188	1013Z			30-11-11	ALL
GD03981		DC-				191/226/R003	ALL
DC..	E	W0001	0011	14		31-62-11	ALL
GD03982		ST-				OFSS-274/ /	ALL
ST..	E	W1178	1013	18		28-21-11	ALL
ST..	E	W1178	1013Z			28-21-11	ALL
GD03983		DC-				200/216/L004	ALL
DC..	E	W0003	0511	14		31-62-21	ALL
GD03984		DC-				OFSS 273/ /	ALL
DC..	E	W1278	1011	18		28-21-11	ALL
DC..	E	W1278	1011Z			28-21-11	ALL
DC..	E	W1288	1013	20		30-11-11	ALL
DC..	E	W1288	1013Z			30-11-11	ALL
GD03985		DC-				191/228/R020	ALL
DC..	E	W0003	0501	14		31-62-21	ALL
GD03986		ST-				OFSS 274/ /	ALL
ST..	E	W1278	1013	18		28-21-11	ALL
ST..	E	W1278	1013Z			28-21-11	ALL
GD03987		DC-				190/227/R010	ALL
DC..	E	W0003	0506	14		31-62-21	ALL
GD03988		BACC50AN16				638/280/L051	ALL
DC..	1	W3142	0465	20		52-71-13	ALL
AC..	1	W3142	5516	20		21-42-11	ALL
AC..	1	W3142	5533	20		21-42-11	ALL

GROUND LIST

D280A351

91-21-21

Section GD03900

Page 4

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD03990		BACC50AN16				826/296/L029	ALL
DC..	1	W3150	0926	18		33-27-22	ALL
AC..	1	W3166	0185	18		33-22-41	ALL
ST..	1	W3166	0186	18		33-22-41	ALL
AC..	1	W3166	0505	18		33-22-22	ALL
ST..	1	W3166	0506	18		33-22-22	ALL
GD03996		BACC50AN16				639/285/R047	ALL
DC..	1	W4142	0082	20		33-51-22	ALL
DC..	1	W4142	0355	20		33-51-13	ALL
DC..	1	W4142	0356	16		33-51-13	ALL
DC..	1	W4142	0465	20		52-71-14	ALL
AC..	1	W4142	5516	20		21-42-11	ALL
GD03998		BACC50AN16				947.5/294/R030	ALL
ST..	1	W3058	0092	18		33-24-22	YT101-YT131
AC..	1	W3058	0093	18		33-24-22	YT101-YT131
ST..	1	W3058	0094	18		33-24-22	YT101-YT131
AC..	1	W3058	0095	18		33-24-22	YT101-YT131
AC..	1	W3058	0096	18		33-24-22	YT101-YT131
ST..	1	W3058	0097	18		33-24-22	YT101-YT131
DC..	1	W3058	0464	20		33-51-14	YT101-YT131
DC..	1	W3058	0466	20		33-29-11	YT101-YT131
DC..	1	W3058	0476	20		23-42-11	YT101-YT131
DC..	1	W4142	0401	16		33-51-11	ALL
ST..	1	W4142	0407	20		33-51-11	ALL

GROUND LIST

D280A351

91-21-21

Section GD03900

Page 5 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD04002		BACC50AN16				827/296/R031	ALL
AC..	1	W4166	0185	18		33-22-51	ALL
ST..	1	W4166	0186	18		33-22-51	ALL
AC..	1	W4166	0515	18		33-22-32	ALL
ST..	1	W4166	0516	18		33-22-32	ALL
DC..	1	W4250	0926	18		33-27-32	ALL
GD04004		BACC50AN16				705/295/L031	ALL
DC..	1	W3150	0925	18		33-27-22	ALL
AC..	1	W3166	0115	18		33-22-41	ALL
ST..	1	W3166	0116	18		33-22-41	ALL
AC..	1	W3166	0295	18		33-22-21	ALL
ST..	1	W3166	0296	18		33-22-21	ALL
GD04006		BACC50AN16				866/296/L028	ALL
AC..	1	W3246	0042	18		33-21-12	ALL
ST..	1	W3246	0043	18		33-21-12	ALL
ST..	1	W3246	0044	18		33-21-12	ALL
AC..	1	W3246	0052	18		33-21-12	ALL
ST..	1	W3246	0053	18		33-21-12	ALL
ST..	1	W3246	0054	18		33-21-12	ALL
GD04008		BACC50AN16				706/297/R031	ALL
AC..	1	W4166	0085	18		33-22-51	ALL
ST..	1	W4166	0086	18		33-22-51	ALL
DC..	1	W4250	0925	18		33-27-32	ALL
GD04024		ST-				OFSS 260/ /	ALL
ST..	E	W1282	1003Z			26-12-11	ALL
ST..	E	W1288	1014Z			26-12-11	ALL
GD04031		ST				/ /	ALL
GD04032		ST				OFSS98/ /	ALL
ST..	GW	W1664	1001Z			33-42-11	YT101-YT112, YT126-YT130
ST..	GW	W1664	1002Z			33-42-11	YT101-YT112, YT126-YT130
ST..	GW	W1664	1003Z			33-42-11	YT101-YT112, YT126-YT130
GD04048		ST-				IFSS-165/ /	ALL
ST..	E	W1180	2001Z			27-81-11	ALL

GROUND LIST

D280A351

91-21-21

Section GD04000

Page 1

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
I GD04050		ST-				IFSS-167/ /	ALL
I ST..	E	W1180	2002Z			27-81-11	ALL
I GD04052		ST-				IFSS-150/ /	ALL
I ST..	GW	W1180	2003Z			27-81-11	ALL
I ST..	GW	W1180	2004Z			27-81-11	ALL
I GD04054		AC-				IFSS-165/ /	ALL
I AC..	E	W1180	I-Y			27-81-11	ALL
I GD04056		AC-				OFSS-711/ /	ALL
I AC..	E	W1188	A-Y			27-81-12	ALL
I GD04058		AC-				OFSS-661/ /	ALL
I AC..	E	W1188	B-Y			27-81-12	ALL
I GD04060		AC-				OFSS-579/ /	ALL
I AC..	E	W1188	C-Y			27-81-12	ALL
I GD04062		AC-				OFSS-534/ /	ALL
I AC..	E	W1188	D-Y			27-81-12	ALL
I GD04064		ST-				OFSS-713/ /	ALL
I ST..	E	W1188	2005Z			27-81-12	ALL
I GD04066		ST-				OFSS-660/ /	ALL
I ST..	E	W1188	2006Z			27-81-12	ALL
I GD04068		ST-				OFSS-581/ /	ALL
I ST..	E	W1188	2007Z			27-81-12	ALL
I GD04070		ST-				OFSS-534/ /	ALL
I ST..	E	W1188	2008Z			27-81-12	ALL
I GD04072		AC-				OFSS-460/ /	ALL
I AC..	E	W1188	E-Y			27-81-12	ALL
I GD04074		AC-				OFSS-415/ /	ALL
I AC..	E	W1188	F-Y			27-81-12	ALL

GROUND LIST

D280A351

91-21-21

Section GD04000

Page 2

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
I GD04076		AC-				OFSS-341/ /	ALL
I AC..	E	W1188	G-Y			27-81-12	ALL
I GD04078		AC-				OFSS-299/ /	ALL
I AC..	E	W1188	H-Y			27-81-12	ALL
I GD04080		ST-				OFSS-459/ /	ALL
I ST..	E	W1188	2009Z			27-81-12	ALL
I GD04082		ST-				OFSS-415/ /	ALL
I ST..	E	W1188	2010Z			27-81-12	ALL
I GD04084		ST-				OFSS-341/ /	ALL
I ST..	E	W1188	2011Z			27-81-12	ALL
I GD04086		ST-				OFSS-299/ /	ALL
I ST..	E	W1188	2012Z			27-81-12	ALL
I GD04090		ST-				OFSS 459/ /	ALL
I ST..	E	W1288	2007Z			27-81-22	ALL
I GD04092		ST-				OFSS 415/ /	ALL
I ST..	E	W1288	2008Z			27-81-22	ALL
I GD04094		AC-				IFSS 165/ /	ALL
I AC..	E	W1280	I-Y			27-81-21	ALL
I GD04096		ST-				OFSS 341/ /	ALL
I ST..	E	W1288	2005Z			27-81-22	ALL
I GD04098		ST-				OFSS 299/ /	ALL
I ST..	E	W1288	2006Z			27-81-22	ALL

GROUND LIST

D280A351

91-21-21

Section GD04000

Page 3 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD04100		BACC50AN16				927/296/R029	ALL
ST..	1	W3144	0351	18		33-26-31	ALL
DC..	1	W3144	0365	18		35-21-31	ALL
AC..	1	W3144	0378	18		33-25-11	ALL
ST..	1	W3144	0380	18		33-26-31	ALL
AC..	1	W3144	0389	18		33-26-31	ALL
AC..	1	W3144	0390	18		33-26-31	ALL
GD04102		BACC50AN20				E004-01/ /	ALL
DC..	1A	W0411	0021	22		23-51-51	ALL
DC..	1A	W0411	0022	22		23-51-51	ALL
DC..	1A	W0411	0023	22		23-51-51	ALL
DC..	1A	W0411	0024	22		23-51-51	ALL
DC..	1A	W0411	0025	22		23-51-51	ALL
DC..	1A	W0411	0026	22		23-51-51	ALL
DC..	1A	W0411	0027	22		23-51-51	ALL
DC..	1A	W0411	0043	22		23-31-04	ALL
DC..	1A	W0411	0050	22		23-22-11	ALL
ST..	1A	W0411	0051	22		23-22-11	ALL
DC..	1A	W0411	0054	22		23-22-11	ALL
DC..	1A	W0411	0057	22		23-22-11	ALL
DC..	1A	W0411	0201	22		23-43-11	YT106-YT120
DC..	1A	W0411	0202	22		23-43-11	YT106-YT120
DC..	1A	W0411	0297	22		23-27-31	ALL
GD04103		BACC50AN20				E004-01/ /	ALL
ST..	1A	W0410	0309	20		21-51-11	ALL
DC..	1A	W0410	0332	20		21-51-14	ALL
ST..	1A	W0410	0351	20		21-51-21	ALL
DC..	1A	W0411	0200	22		23-43-11	ALL
DC..	1A	W0411	0201	22		23-43-11	YT101-YT105, YT126-YT133
DC..	1A	W0411	0202	22		23-43-11	YT101-YT105, YT126-YT133
DC..	1A	W0411	0203	22		23-43-11	ALL
AC..	1A	W0411	0293	20		23-27-31	ALL
ST..	1A	W0411	0294	20		23-27-31	ALL
DC..	1A	W0411	0338	22		23-31-04	ALL
DC..	1A	W0411	0345	22		23-27-38	ALL
DC..	1A	W0411	0362	20		34-24-15	ALL
DC..	1A	W0411	2003B	24		23-51-11	ALL
DC..	1A	W0411	2006B	24		23-51-21	ALL

GROUND LIST

D280A351

91-21-21

Section GD04100

Page 1

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD04104		BACC50AN20				E004-01/ /	ALL
DC..	1A	W0410	0312	20		21-51-11	ALL
DC..	1A	W0410	0341	20		21-51-15	ALL
DC..	1A	W0410	0354	20		21-51-21	ALL
DC..	1A	W0410	0374	20		21-51-24	ALL
DC..	1A	W0410	0381	20		21-51-25	ALL
DC..	1A	W0410	0488	20		34-61-17	ALL
DC..	1A	W0410	0490	20		34-61-17	ALL
GD04105		BACC50AN16				E004-01/ /	ALL
GD04108		ST-				E004-01/ /	ALL
ST..	E	W0411	0396	08		34-24-15	ALL
GD04110		ST-				OFSS 713/ /	ALL
ST..	E	W1288	2011Z			27-81-22	ALL
GD04112		ST-				OFSS 660/ /	ALL
ST..	E	W1288	2012Z			27-81-22	ALL
GD04114		AC-				OFSS 341/ /	ALL
AC..	E	W1288	A-Y			27-81-22	ALL
GD04118		AC-				OFSS 299/ /	ALL
AC..	E	W1288	B-Y			27-81-22	ALL
GD04120		AC-				OFSS 460/ /	ALL
AC..	E	W1288	C-Y			27-81-22	ALL
GD04122		AC-				OFSS 415/ /	ALL
AC..	E	W1288	D-Y			27-81-22	ALL
GD04124		AC-				OFSS 579/ /	ALL
AC..	E	W1288	E-Y			27-81-22	ALL
GD04126		AC-				OFSS 534/ /	ALL
AC..	E	W1288	F-Y			27-81-22	ALL
GD04128		AC-				OFSS 711/ /	ALL
AC..	E	W1288	G-Y			27-81-22	ALL

GROUND LIST

D280A351

91-21-21

Section GD04100

Page 2

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD04130		AC-				OFSS 661/ /	ALL
AC..	E	W1288	H-Y			27-81-22	ALL
GD04132		ST-				OFSS-587/ /	ALL
ST..	E	W1662	2001Z			28-44-11	ALL
GD04140		ST-				/ /	ALL
GD04142		ST-				OFSS 587/ /	ALL
ST..	E	W1664	1018Z			28-44-11	ALL
ST..	E	W1664	1024Z			28-44-11	ALL
GD04148		ST-				OFSS 379/ /	ALL
ST..	E	W1664	0023	16		28-44-11	ALL
ST..	E	W1664	0025	16		28-44-11	ALL
ST..	E	W1664	0027	16		28-44-11	ALL
ST..	E	W1664	3002ZO			23-41-11	ALL
GD04164		BACC50AN16				312/293/L020	ALL
DC..	1	W3058	0021	20		24-23-51	YT101-YT131
DC..	1	W3058	0172	20		23-42-14	YT101-YT131
ST..	1	W3058	0173	20		23-42-14	YT101-YT131
ST..	1	W3058	0174	20		23-42-14	YT101-YT131
ST..	1	W3058	0175	20		23-42-14	YT101-YT131
AC..	1	W3058	0373	20		33-29-11	YT101-YT118, YT126-YT131
ST..	1	W3307	0096	22		23-31-01	ALL
GD04168		BACC50AN16				312/294/L017	ALL
DC..	1	W3307	0020	20		44-21-10	ALL
DC..	1	W3307	0098	20		23-31-01	ALL
DC..	1	W4142	0101	16		33-51-11	ALL
ST..	1	W4142	0107	20		33-51-11	ALL
DC..	1	W4142	0159	20		33-51-12	ALL
GD04170		BACC50AN20				328/293/L014	ALL
DC..	1A	W3058	0029	22		52-71-11	YT101-YT131
AC..	1A	W3058	0055	20		33-26-11	YT101-YT131
AC..	1D	W3058	0088	18		33-24-21	YT101-YT131
ST..	1D	W3058	0089	18		33-24-21	YT101-YT131
AC..	1D	W3058	0090	18		33-24-21	YT101-YT131

GROUND LIST

D280A351

91-21-21

Section GD04100

Page 3

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD04170		BACC50AN20 (continued)				328/293/L014	ALL
ST..	1D	W3058	0091	18		33-24-21	YT101-YT131
DC..	1A	W3058	0364	20		33-51-12	YT101-YT131
DC..	1A	W3058	0370	20		23-42-11	YT101-YT131

GROUND LIST

D280A351

91-21-21

Section GD04100

Page 4 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD04201		BACC50AN20				E004-02/ /	ALL
DC..	1A	W0422	0083	20		24-11-21	ALL
ST..	1A	W0422	0144	20		24-41-11	ALL
ST..	1A	W0422	0501	20		24-28-41	ALL
GD04202		BACC50AN20				E004-02/ /	ALL
DC..	1A	W0422	0032	22		27-62-11	ALL
DC..	1A	W0422	0034	22		27-62-11	ALL
DC..	1A	W0422	0035	22		27-62-11	ALL
ST..	1A	W0422	0084	20		24-11-21	ALL
DC..	1A	W0422	0142	20		24-41-11	ALL
GD04203		BACC50AN20				E004-02/ /	ALL
AC..	1A	W0420	5504	20		30-41-12	ALL
DC..	1A	W0420	5506	20		30-41-12	ALL
AC..	1A	W0420	5513	20		30-41-12	YT101-YT116, YT126-YT131
DC..	1A	W0420	5515	20		30-41-12	ALL
GD04204		BACC50AN16				E004-02/ /	ALL
ST..	1	W0420	5502	16		30-41-12	YT101-YT116, YT126-YT131
AC..	1	W0420	5503	16		30-41-12	YT101-YT116, YT126-YT131
AC..	1	W0422	0124	18		24-32-11	ALL
AC..	1	W0422	0135	18		24-32-11	ALL
GD04207		ST-				E004-02/ /	ALL
ST..	E	W0420	5511	12		30-41-12	ALL
GD04208		AC-				E004-02/ /	ALL
AC..	E	W0420	5512	12		30-41-12	ALL
AC..	E	W0420	5531	14		30-41-12	YT117-YT120, YT132-YT133
AC..	E	W0420	5536	18		30-41-12	YT117-YT120, YT132-YT133
GD04209		BACC50AN20				E004-02/ /	ALL
ST..	1A	W0422	2002Z			24-21-21	ALL
ST..	1A	W0422	3001Z			24-21-21	ALL
GD04210		BACC50AN20				E004-02/ /	ALL
GD04212		CGH20-22-1				E004-02/ /	ALL
ST..	1F	W0420	2001Z			30-41-12	YT101-YT116, YT126-YT131

GROUND LIST

D280A351

91-21-21

Section GD04200

Page 1

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD04212		CGH20-22-1 (continued)				E004-02/ /	ALL
ST..	1F	W0420	2004Z			30-41-12	YT101-YT116, YT126-YT131
GD04214		CGH20-22-1				E004-02/ /	ALL
ST..	1F	W0420	1001ZO			30-41-12	YT117-YT120, YT132-YT133
ST..	1F	W0420	1002ZO			30-41-12	YT117-YT120, YT132-YT133
ST..	1F	W0420	1003Z			30-41-12	YT117-YT120, YT132-YT133
ST..	1F	W0420	1004Z			30-41-12	YT117-YT120, YT132-YT133
ST..	1F	W0420	2002Z			30-41-12	YT101-YT116, YT126-YT131
ST..	1F	W0420	2003Z			30-41-12	YT101-YT116, YT126-YT131
ST..	1F	W0420	2003ZO			30-41-12	YT117-YT120, YT132-YT133
ST..	1F	W0420	2004Z			30-41-12	YT117-YT120, YT132-YT133
ST..	1F	W0420	2006ZO			30-41-12	YT117-YT120, YT132-YT133
ST..	1F	W0420	3001ZO			30-41-12	YT117-YT120, YT132-YT133
ST..	1F	W0420	FRAB			30-41-12	YT117-YT120, YT132-YT133
ST..	1F	W0420	FRAC			30-41-12	YT117-YT120, YT132-YT133
GD04216		CGH20-22-1				E004-02/ /	ALL
ST..	1F	W0422	1001Z			27-62-11	ALL
ST..	1F	W0422	1003Z			27-62-11	ALL
ST..	1F	W0422	1102Z			27-62-11	ALL
ST..	1F	W0422	1103Z			27-62-11	ALL
GD04223		BACC50AN16				907/296/L028	ALL
DC..	1	W3058	0180	20		23-42-15	YT101-YT131
ST..	1	W3058	0181	20		23-42-15	YT101-YT131
ST..	1	W3058	0182	20		23-42-15	YT101-YT131
ST..	1	W3058	0183	20		23-42-15	YT101-YT131
DC..	1	W5409	0006	20		31-31-11	ALL
GD04226		ST				IFSS 150/ /	ALL
ST..	GW	W1280	2003Z			27-81-21	ALL
ST..	GW	W1280	2004Z			27-81-21	ALL
GD04228		ST				IFSS 165/ /	ALL
ST..	E	W1280	2001Z			27-81-21	ALL
GD04230		ST				IFSS 167/ /	ALL
ST..	E	W1280	2002Z			27-81-21	ALL

GROUND LIST

D280A351

91-21-21

Section GD04200

Page 2

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD04270		BACC50AN16				866/214/R067	YT101-YT120
ST..	1	W3751	0001	16		44-21-16	YT101-YT120
ST..	1	W3751	0002	16		44-21-16	YT101-YT120
I GD04274		ST				E9-2/ /	ALL

GROUND LIST

D280A351

91-21-21

Section GD04200

Page 3 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
I GD04300		ST-				OFSS 581/ /	ALL
I ST..	E	W1288	2009Z			27-81-22	ALL
I GD04302		ST-				OFSS 534/ /	ALL
I ST..	E	W1288	2010Z			27-81-22	ALL
I GD04308		ST-				655/165/L039	ALL
I ST..	GW	W5102	1203	20		33-44-11	ALL
I ST..	GW	W5102	1203Z			33-44-11	ALL

GROUND LIST

D280A351

91-21-21

Section GD04300

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No.		Part Number		Station / WL / BL		Effectivity
Term	Type	Bundle	Wire No.	GA	CO	
I	GD04402	ST-			IRSS 142/ /	ALL
I	ST..	E	W1134	1302Z	28-43-11	YT101-YT119, YT126-YT131
I	ST..	E	W1134	3601Z	28-23-11	YT101-YT119, YT126-YT131
I	GD04410	ST			IRSS/150/	ALL
I	ST..	E	W1136	1304Z	28-43-11	YT101-YT119, YT126-YT131
I	ST..	E	W1136	3601Z	28-23-11	YT101-YT119, YT126-YT131
I	ST..	E	W1722	0503	49-31-31	ALL
	GD04420	BACC50AN16		14	685/211/R066	YT101-YT120
	ST..	1	W3483	0011	44-21-16	YT101-YT120
	ST..	1	W3483	0012	44-21-16	YT101-YT120
	ST..	1	W3747	0001	44-21-16	YT101-YT120
	ST..	1	W3747	0002	44-21-16	YT101-YT120

GROUND LIST

D280A351

91-21-21

Section GD04400

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD04801		ST-				1086/236/L008	ALL
ST..	E	W3391	1016Z			22-13-11	YT106-YT133
ST..	E	W3391	FRAA			22-13-11	ALL
ST..	E	W3391	FRAB			22-13-11	YT101-YT105
ST..	E	W3391	FRAC			22-13-11	ALL
ST..	E	W3391	FRAD			22-13-11	ALL
ST..	E	W3391	YAAA			22-13-11	ALL
ST..	E	W4222	1004Z			27-41-12	ALL
ST..	E	W4222	1005Z			27-41-12	ALL
ST..	E	W4222	1006Z			27-41-12	ALL
ST..	E	W4222	1008Z			27-41-12	ALL
ST..	E	W4222	1009Z			27-41-12	ALL
ST..	E	W4222	YAAA			27-41-12	ALL
GD04805		ST-				1051/249/R044	ALL
ST..	E	W4726	1001Z			49-62-11	ALL
ST..	E	W4726	1002Z			49-62-11	ALL
ST..	E	W4726	1003Z			49-62-11	ALL
GD04807		ST-				1065/241/R036	ALL
ST..	E	W4726	1004Z			49-62-11	ALL
ST..	E	W4726	1005Z			49-62-11	ALL
GD04809		ST-				1163/273/RBL5	ALL
ST..	E	W3393	1013Z			22-18-11	ALL
ST..	E	W3393	1015Z			SPARE	ALL
ST..	E	W3393	1017Z			SPARE	ALL
ST..	E	W3393	1019Z			SPARE	ALL
ST..	E	W3393	2001Z			22-18-11	ALL
ST..	E	W3393	2006Z			22-18-11	ALL
ST..	E	W3393	2024Z			22-18-11	ALL
ST..	E	W3393	2026Z			22-18-11	ALL
GD04811		ST-				1162/266/RBL6	ALL
ST..	E	W3399	2003Z			22-12-41	ALL
ST..	E	W3399	2005Z			22-12-41	ALL
GD04813		ST-				1087/223/L022	ALL
ST..	E	W4726	1103Z			26-21-11	ALL
ST..	E	W4726	1105Z			26-21-11	ALL

GROUND LIST

D280A351

91-21-21

Section GD04800

Page 1

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	Ground No.	Type	Part Number	Wire No.	GA	CO	Station / WL / BL	Effectivity
	Term		Bundle				Diagram	
I	GD04834		DC-				533/187/L021	ALL
I	DC..	E	W5098	6011	20		26-23-11	ALL
I	GD04836		ST-				533/187/L020	ALL
I	ST..	E	W5098	6010	20		26-23-11	ALL
I	GD04838		ST-				533/173/L020	ALL
I	ST..	E	W5098	6014	20		26-23-11	ALL
I	ST..	E	W5098	6017	20		26-23-11	ALL
I	GD04840		DC-				533/173/L021	ALL
I	DC..	E	W5098	6013	20		26-23-11	ALL
I	DC..	E	W5098	6016	20		26-23-11	ALL

GROUND LIST

D280A351

91-21-21

Section GD04800

Page 2 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
I GD05002		BACC50AN16				807/297/R036	ALL
I GD05006		AC-				/ /	ALL
I GD05010		AC-				231/199/L014	ALL
I AC..	E	W0443	0014KY	20		33-11-11	ALL
I ST..	E	W5457	0002	22		22-11-31	ALL
I AC..	E	W6110	0005	20		33-34-11	ALL
I GD05014		AC-				196/203/R015	ALL
I AC..	E	W6110	0007	20		33-34-11	ALL
I GD05016		AC-				350/175/L030	ALL
I AC..	E	W6110	0073	20		33-34-11	ALL
I GD05018		AC-				351/181/R023	ALL
I AC..	E	W6110	0070	20		33-34-11	ALL
I GD05060		DC-				534/187/R015	ALL
I DC..	E	W5074	6002	20		26-23-11	ALL
I GD05062		ST-				534/187/R017	ALL
I ST..	E	W5074	6001	20		26-23-11	ALL
I GD05064		ST-				533/174/R017	ALL
I ST..	E	W5074	6005	20		26-23-11	ALL
I ST..	E	W5074	6008	20		26-23-11	ALL
I GD05066		DC-				533/173/R015	ALL
I DC..	E	W5074	6004	20		26-23-11	ALL
I DC..	E	W5074	6007	20		26-23-11	ALL

GROUND LIST

D280A351

91-21-21

Section GD05000

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD05101		BACC50AN16				540/188/R026	ALL
DC..	1	W6730	0592	22		32-41-11	ALL
DC..	1	W6732	0592	22		32-41-11	ALL
DC..	1	W6732	6006	20		78-34-21	ALL
DC..	1	W6732	6007	20		78-36-21	ALL
DC..	1	W6732	6008	20		78-36-21	ALL
GD05108		BACC50AN16				537/193/L025	ALL
DC..	1	W5222	0592	20		32-41-11	ALL
DC..	1	W5222	6002	20		78-34-11	ALL
DC..	1	W5222	6004	20		78-36-11	ALL
DC..	1	W5222	6005	20		78-36-11	ALL
DC..	1	W5234	0592	22		32-41-11	ALL
DC..	1	W5728	0512	20		32-35-11	ALL
DC..	1	W5728	0592	22		32-41-11	ALL
GD05120		ST				655/154/L040	ALL
ST..	GW	W5102	2081Z			21-51-13	ALL
ST..	GW	W5102	5544	20		21-51-13	ALL
GD05122		ST-				644/151/L008	ALL
ST..	GW	W5102	0015	20		21-51-12	ALL
ST..	GW	W5102	1027Z			21-51-12	ALL
ST..	GW	W5102	1028Z			21-51-12	ALL
ST..	GW	W5102	2076Z			21-51-12	ALL
ST..	GW	W5102	2077Z			21-51-12	ALL
ST..	GW	W5102	2078Z			21-51-12	ALL
GD05124		AC				653/152/L009	ALL
AC..	GW	W5102	1027	20		21-51-12	ALL
AC..	GW	W5102	1027Z			21-51-12	ALL
GD05126		ST-				581/165/L036	ALL
ST..	GW	W5102	2082Z			21-51-14	ALL
GD05128		AC				578/154/L039	ALL
AC..	GW	W5102	0011	20		33-33-11	ALL
GD05130		ST-				578/151/L040	ALL
ST..	GW	W5102	1001Z			21-51-15	ALL

GROUND LIST

D280A351

91-21-21

Section GD05100

Page 1

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD05130		ST- (continued)				578/151/L040	ALL
ST..	GW	W5102	1005Z			21-51-15	ALL
ST..	GW	W5102	1033Z			21-51-15	ALL
ST..	GW	W5102	1034Z			21-51-15	ALL
ST..	GW	W5102	1049Z			21-61-51	ALL
ST..	GW	W5102	1050Z			21-61-51	ALL
ST..	GW	W5102	2079Z			21-51-12	ALL
ST..	GW	W5102	2080Z			21-51-13	ALL

GROUND LIST

D280A351

91-21-21

Section GD05100

Page 2 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD05202		DC-				E005-02/ /	ALL
DC..	E	W0523	0313	22		34-21-21	ALL
DC..	E	W0523	0314	22		34-21-21	ALL
DC..	=	W0523	0315	22		34-21-21	YT101-YT104
DC..	E	W0523	0315	22		34-21-21	YT105-YT133
DC..	E	W0523	0334	20		34-21-21	ALL
DC..	E	W0523	0336	20		34-21-21	ALL
DC..	E	W0523	0338	22		34-61-18	ALL
DC..	E	W0523	0339	22		34-21-21	ALL
DC..	E	W0523	0340	22		34-21-21	ALL
DC..	E	W0523	0341	22		34-21-21	ALL
GD05205		AC-				E005-02/ /	ALL
AC..	E	W0523	0305	20		34-61-11	ALL
AC..	E	W0523	0331	20		34-21-21	ALL
AC..	E	W0523	0333	20		34-21-21	ALL
AC..	E	W0523	0353	22		34-21-21	YT101-YT105
AC..	E	W0523	0354	22		34-21-21	YT101-YT105
AC..	E	W0523	0355	22		34-21-21	YT101-YT105
AC..	=	W0523	0356	22		34-21-21	YT101-YT104
AC..	E	W0523	0356	22		34-21-21	YT105
GD05206		DC-				E005-02/ /	ALL
DC..	E	W0523	0306	20		34-61-11	ALL
DC..	E	W0523	0353	22		34-21-21	YT106-YT133
DC..	E	W0523	0354	22		34-21-21	YT106-YT133
DC..	E	W0523	0355	22		34-21-21	YT106-YT133
DC..	E	W0523	0356	22		34-21-21	YT106-YT133
GD05207		ST-				****/ /	ALL
GD05209		DC-				E005-02/ /	ALL
DC..	E	W0521	0008	22		34-61-12	ALL
DC..	E	W0521	0012	22		34-61-12	ALL
DC..	E	W0521	0016	22		34-61-12	ALL
DC..	E	W0521	0193	22		34-61-12	ALL
DC..	E	W0521	0195	22		34-61-12	ALL
DC..	E	W0521	0198	22		34-61-12	ALL
DC..	E	W0521	0279	22		34-61-18	ALL

GROUND LIST

D280A351

91-21-21

Section GD05200

Page 1

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD05210		ST-				E005-02/ /	ALL
ST..	E	W0521	0142	20		34-21-11	ALL
ST..	E	W0521	0306	22		46-13-11	YT104-YT133
GD05213		DC-				E005-02/ /	ALL
DC..	E	W0521	0004	20		34-61-11	ALL
DC..	E	W0521	0064	22		34-61-19	ALL
DC..	E	W0521	0065	22		34-61-19	ALL
DC..	E	W0521	0088	22		34-61-19	ALL
DC..	E	W0521	0146	20		34-21-11	ALL
GD05218		DC-				E005-02/ /	ALL
DC..	E	W0521	0240	20		34-61-22	ALL
DC..	E	W0521	0241	20		34-61-22	ALL
DC..	E	W0521	0308	22		46-13-11	YT104-YT133
DC..	E	W0521	0309	22		46-13-11	YT104-YT133
GD05220		AC-				E005-02/ /	ALL
AC..	E	W0521	0003	20		34-61-11	ALL
AC..	E	W0521	0141	20		34-21-11	ALL
AC..	E	W0521	0145	20		34-21-11	ALL
AC..	E	W0521	0239	20		34-61-22	ALL
AC..	E	W0521	0307	22		46-13-11	YT104-YT133
GD05221		DC-				E005-02/ /	ALL
DC..	E	W0521	0162	22		34-21-11	ALL
DC..	E	W0521	0163	22		34-21-11	ALL
DC..	E	W0521	0164	22		34-21-11	ALL
DC..	E	W0521	0174	22		34-21-11	ALL
DC..	E	W0521	0175	22		34-21-11	ALL
DC..	E	W0521	0176	22		34-21-11	ALL
DC..	=	W0521	0177	22		34-21-11	YT101-YT104
DC..	E	W0521	0177	22		34-21-11	YT105-YT133
DC..	E	W0521	0235	22		34-21-11	ALL
DC..	=	W0521	0236	22		34-21-11	YT101-YT104
DC..	E	W0521	0236	22		34-21-11	YT105-YT133
DC..	E	W0521	0237	22		34-21-11	ALL

GROUND LIST

D280A351

91-21-21

Section GD05200

Page 2 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
I GD05520		AC-				563/159/L007	ALL
I AC..	GW	W5502	0003	20		33-33-11	ALL
I AC..	GW	W5502	0004	20		33-33-11	YT101-YT111, YT126-YT130
I AC..	GW	W5502	1035	20		21-61-11	ALL
I AC..	GW	W5502	1035Z			21-61-11	ALL
I GD05522		ST-				570/155/L007	ALL
I GD05524		DC-				586/157/L007	ALL
I DC..	GW	W5502	1004	20		21-51-11	ALL
I DC..	GW	W5502	1004Z			21-51-11	ALL
I DC..	GW	W5502	1006	20		21-51-11	ALL
I DC..	GW	W5502	1006Z			21-51-11	ALL
I DC..	GW	W5502	1016	20		21-51-11	ALL
I DC..	GW	W5502	1016Z			21-51-11	ALL
I GD05526		ST-				570/155/L007	ALL
I ST..	GW	W5502	1004Z			21-51-11	YT116-YT120, YT132-YT133
I ST..	GW	W5502	1006Z			21-51-11	YT116-YT120, YT132-YT133
I ST..	GW	W5502	2001Z			21-51-11	ALL
I ST..	GW	W5502	2002Z			21-51-11	YT116-YT120, YT132-YT133

GROUND LIST

D280A351

91-21-21

Section GD05500

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
I GD06103		BACC50AN20				E006-01/ /	ALL
I GD06106		DC-				320/160/L029	ALL
I GD06120		AC				578/154/R039	ALL
I AC..	GW	W6202	0010	20		33-33-11	YT101-YT111, YT126-YT130
I AC..	GW	W6202	0011	20		33-33-11	ALL
I GD06122		ST-				581/165/R036	ALL
I ST..	GW	W6202	2082Z			21-51-24	ALL
I GD06124		ST-				645/150/R008	ALL
I ST..	GW	W6202	1032Z			21-51-22	ALL
I ST..	GW	W6202	1033Z			21-51-22	ALL
I ST..	GW	W6202	2076Z			21-51-22	ALL
I ST..	GW	W6202	2077Z			21-51-22	ALL
I ST..	GW	W6202	2078Z			21-51-22	ALL
I ST..	GW	W6202	5552	20		21-51-22	ALL
I GD06126		AC				659/162/R040	ALL
I AC..	GW	W6202	0013	20		33-33-11	ALL
I GD06127		ST-				536/148/L001	YT113-YT120, YT132-YT133
I ST..	GW	W6230	0045	24		21-51-22	YT116-YT120, YT132-YT133
I ST..	E	W6230	2005Z			21-51-22	YT116-YT120, YT132-YT133
I GD06128		ST-				653/155/R040	ALL
I ST..	GW	W6202	2081Z			21-51-23	ALL
I ST..	GW	W6202	5553	20		21-51-23	ALL
I GD06129		ST-				536/148/R002	YT113-YT120, YT132-YT133
I ST..	E	W5104	0019	24		21-51-12	YT116-YT120, YT132-YT133
I ST..	E	W5104	2006Z			21-51-12	YT116-YT120, YT132-YT133

GROUND LIST

D280A351

91-21-21

Section GD06100

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No.		Part Number		Station / WL / BL		Effectivity
Term	Type	Bundle	Wire No.	GA	CO	
GD06201		BACC50AN16		E006-02/ /		ALL
AC..	1	W0621	0008	20	23-11-11	ALL
ST..	1	W0621	0010	20	23-11-11	ALL
DC..	1	W0621	0069	22	23-11-11	ALL
DC..	1	W0621	0129	22	23-11-11	ALL
DC..	1	W0621	0130	22	23-11-11	ALL
DC..	1	W0621	0141	22	23-11-16	ALL
DC..	1	W0621	0180	22	23-11-16	ALL
GD06202		BACC50AN16		E006-02/ /		ALL
AC..	1	W0621	0149	20	23-11-21	ALL
ST..	1	W0621	0150	20	23-11-21	ALL
DC..	1	W0621	0162	22	23-11-21	ALL
DC..	1	W0621	0163	22	23-11-21	ALL
DC..	1	W0621	0164	22	23-11-21	ALL
DC..	1	W0621	0165	22	23-11-26	ALL
DC..	1	W0621	0167	22	23-11-26	ALL

GROUND LIST

D280A351

91-21-21

Section GD06200

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD06310		BACC50AN16				732/169/R009	ALL
ST..	1	W0063	1001Z			47-30-11	ALL
ST..	1	W0063	1002Z			47-30-11	ALL
ST..	1	W0063	1003Z			47-30-11	ALL
ST..	1	W0063	1004Z			47-30-11	ALL
ST..	1	W0063	1005Z			47-30-11	ALL
ST..	1	W0063	1006Z			47-30-11	ALL

GROUND LIST

D280A351

91-21-21

Section GD06300

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD06522		AC-				588/162/R007	ALL
AC..	GW	W6502	0002	20		33-33-11	ALL
GD06524		DC-				563/158/R007	ALL
DC..	GW	W6502	1006	20		21-51-21	ALL
DC..	GW	W6502	1006Z			21-51-21	ALL
DC..	GW	W6502	1008	20		21-51-21	ALL
DC..	GW	W6502	1008Z			21-51-21	ALL
DC..	GW	W6502	1009Z			21-61-15	ALL
DC..	GW	W6502	1013	20		21-51-21	ALL
DC..	GW	W6502	1013Z			21-51-21	ALL
DC..	GW	W6502	5519	20		21-61-15	ALL
GD06526		ST-				600/159/R007	ALL
ST..	GW	W6502	0014	24		21-51-22	YT116-YT120, YT132-YT133
ST..	GW	W6502	1002Z			26-12-11	ALL
ST..	GW	W6502	1003Z			26-12-11	ALL

GROUND LIST

D280A351

91-21-21

Section GD06500

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD07004		BACC50AN16				500C/218/L070	ALL
AC..	1	W3142	0061	18		33-41-11	ALL
ST..	1	W3142	0062	18		33-41-11	ALL
DC..	1	W3142	0501	16		33-51-11	ALL
ST..	1	W3142	0507	20		33-51-11	ALL
DC..	1	W3142	0554	20		33-51-21	ALL
DC..	1	W3142	0555	20		33-51-21	ALL

GROUND LIST

D280A351

91-21-21

Section GD07000

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD07103		AC-				887/303/L007	YT101-YT120
AC..	F	W3625	0002	12		44-21-10	YT101-YT120
GD07104		ST-				887/303/L008	YT101-YT120
ST..	F	W3625	0003	12		44-21-10	YT101-YT120
GD07120		AC-				500E/296/R028	YT101-YT120
AC..	F	W3623	0002	12		44-21-10	YT101-YT120
GD07122		ST-				500E/296/R029	YT101-YT120
ST..	F	W3623	0003	12		44-21-10	YT101-YT120

GROUND LIST

D280A351

91-21-21

Section GD07100

Page 1 End

Mar 14/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
I GD07226		BACC50AN16				727A/295/R031	ALL

GROUND LIST

D280A351

91-21-21

Section GD07200

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD08000		BACC50AN16				559/215/L067	ALL
DC..	1	W3142	0201	16		33-51-11	ALL
ST..	1	W3142	0207	20		33-51-11	ALL
DC..	1	W3142	0227	20		33-51-21	ALL
DC..	1	W3142	0228	20		33-51-21	ALL
DC..	1	W3142	0252	20		33-51-21	ALL
DC..	1	W3142	0437	20		52-71-13	ALL
AC..	1	W3142	5543	20		21-42-11	ALL
AC..	1	W3142	5545	20		21-42-11	ALL
GD08002		BACC50AN16				559/215/R067	ALL
DC..	1	W4142	0086	20		33-51-21	ALL
DC..	1	W4142	0301	16		33-51-11	ALL
ST..	1	W4142	0307	20		33-51-11	ALL
DC..	1	W4142	0441	20		52-71-14	ALL
AC..	1	W4142	5543	20		21-42-11	ALL
AC..	1	W4142	5545	20		21-42-11	ALL
GD08004		BACC50AN16				500C/216/R069	ALL
AC..	1	W4142	0071	18		33-41-11	ALL
ST..	1	W4142	0072	18		33-41-11	ALL
DC..	1	W4142	0501	16		33-51-11	ALL
ST..	1	W4142	0507	20		33-51-11	ALL
GD08006		BACC50AN16				727D/221/R069	ALL
DC..	1	W4142	0201	16		33-51-11	ALL
ST..	1	W4142	0207	20		33-51-11	ALL
GD08008		AC-				343/286/R035	ALL
AC..	P	W4256	0104	08		25-31-11	ALL
GD08010		BACC50AN16				500D/295/L030	ALL
DC..	1	W3142	0066	20		33-51-12	ALL
DC..	1	W3150	0924	18		33-27-21	ALL
AC..	1	W3166	0025	18		33-22-41	ALL
ST..	1	W3166	0026	18		33-22-41	ALL
AC..	1	W3166	0405	18		33-22-21	ALL
ST..	1	W3166	0406	18		33-22-21	ALL
DC..	1	W6288	0002	20		21-61-13	ALL
DC..	1	W6288	0012	20		21-61-51	ALL

GROUND LIST

D280A351

91-21-21

Section GD08000

Page 1

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD08012		BACC50AN16				500H/295/L030	ALL
DC..	1	W3142	0579	16		33-51-12	ALL
AC..	1	W3166	0035	18		33-22-41	ALL
ST..	1	W3166	0036	18		33-22-41	ALL
AC..	1	W3166	0045	18		33-22-41	ALL
ST..	1	W3166	0046	18		33-22-41	ALL
AC..	1	W3166	0255	18		33-22-21	ALL
ST..	1	W3166	0256	18		33-22-21	ALL
AC..	1	W3166	0265	18		33-22-21	ALL
ST..	1	W3166	0266	18		33-22-21	ALL
GD08014		BACC50AN16				500F/296/R031	ALL
AC..	1	W4166	0035	18		33-22-51	ALL
ST..	1	W4166	0036	18		33-22-51	ALL
AC..	1	W4166	0255	18		33-22-31	ALL
ST..	1	W4166	0256	18		33-22-31	ALL
GD08016		BACC50AN16				500G/296/R031	ALL
DC..	1	W4142	0555	20		33-51-12	ALL
GD08018		BACC50AN16				500I/296/R031	ALL
AC..	1	W3755	0009	20		44-35-20	YT101-YT120
ST..	1	W3755	0010	20		44-35-20	YT101-YT120
AC..	1	W3755	0015	20		44-35-20	YT126-YT133
ST..	1	W3755	0016	20		44-35-20	YT126-YT133
AC..	1	W4166	0045	18		33-22-51	ALL
ST..	1	W4166	0046	18		33-22-51	ALL
AC..	1	W4166	0265	18		33-22-31	ALL
ST..	1	W4166	0266	18		33-22-31	ALL
DC..	1	W6288	0007	20		21-61-14	ALL
DC..	1	W6288	0018	20		21-61-51	ALL
GD08020		BACC50AN16				727F/296/L028	ALL
DC..	1	W3142	0356	20		33-51-13	ALL
AC..	1	W3166	0145	18		33-22-41	ALL
ST..	1	W3166	0146	18		33-22-41	ALL
AC..	1	W3166	0545	18		33-22-22	ALL
ST..	1	W3166	0546	18		33-22-22	ALL
DC..	1	W3649	0002	20		44-30-11	YT101-YT120
ST..	1	W3649	0003	20		44-30-11	YT101-YT120

GROUND LIST

D280A351

91-21-21

Section GD08000

Page 2

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD08020		BACC50AN16 (continued)				727F/296/L028	ALL
AC..	1	W3755	0009	20		44-35-20	YT126-YT133
ST..	1	W3755	0010	20		44-35-20	YT126-YT133
GD08022		BACC50AN16				727F/295/R030	ALL
DC..	1	W4142	0627	20		33-51-14	ALL
AC..	1	W4166	0355	18		33-22-32	ALL
ST..	1	W4166	0356	18		33-22-32	ALL
AC..	1	W4166	0565	18		33-22-51	ALL
ST..	1	W4166	0566	18		33-22-51	ALL
GD08024		BACC50AN16				727H/297/L028	ALL
AC..	1	W3755	0015	20		44-35-20	YT101-YT120
ST..	1	W3755	0016	20		44-35-20	YT101-YT120
AC..	1	W3755	0029	20		44-35-20	YT126-YT133
ST..	1	W3755	0030	20		44-35-20	YT126-YT133
GD08026		BACC50AN16				727H/296/R031	ALL
AC..	1	W4166	0365	18		33-22-32	ALL
ST..	1	W4166	0366	18		33-22-32	ALL
AC..	1	W6288	0009	20		21-61-14	ALL
ST..	1	W6288	0010	20		21-61-14	ALL
DC..	1	W6288	0016	20		21-61-51	ALL
GD08028		BACC50AN16				727J/296/L028	ALL
AC..	1	W3166	0155	18		33-22-41	ALL
ST..	1	W3166	0156	18		33-22-41	ALL
AC..	1	W3166	0365	18		33-22-22	ALL
ST..	1	W3166	0366	18		33-22-22	ALL
DC..	1	W3649	0002	20		44-30-11	YT126-YT133
ST..	1	W3649	0003	20		44-30-11	YT126-YT133
GD08030		BACC50AN16				727J/296/R031	ALL
DC..	1	W4142	0408	16		33-51-14	ALL
AC..	1	W4166	0155	18		33-22-51	ALL
ST..	1	W4166	0156	18		33-22-51	ALL
GD08032		BACC50AN16				500F/221/R069	YT101-YT120
ST..	1	W3485	0001	16		44-21-16	YT101-YT120
ST..	1	W3485	0002	16		44-21-16	YT101-YT120

GROUND LIST

D280A351

91-21-21

Section GD08000

Page 3

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD08034		BACC50AN16				500F/214/L069	YT101-YT120
ST..	1	W3489	0001	16		44-21-16	YT101-YT120
ST..	1	W3489	0002	16		44-21-16	YT101-YT120
GD08036		BACC50AN16				787/204/L023	YT112-YT120, YT131-YT133
AC..	1	W6248	0268	20		33-36-12	YT112-YT120, YT131-YT133
GD08038		BACC50AN16				727F/204/L023	YT101-YT111, YT126-YT130
GD08038		BACC50AN16				727F/204/L030	YT112-YT120, YT131-YT133
DC..	1	W3142	0060	16		33-51-14	ALL
DC..	1	W3142	0353	16		33-51-13	ALL
AC..	1	W6248	0298	20		33-36-12	ALL
GD08040		BACC50AN16				727I/205/L020	ALL
AC..	1	W6248	0220	20		33-36-12	ALL
GD08042		BACC50AN16				500F/203/R004	ALL
ST..	1	W5086	6020	20		26-16-21	ALL
AC..	1	W5248	0054	20		33-36-11	ALL
GD08044		BACC50AN16				500G/202/L011	ALL
AC..	1	W5248	0036	20		33-36-11	ALL
GD08046		BACC50AN16				500B/203/R004	ALL
AC..	1	W5248	0080	20		33-36-11	ALL
GD08048		BACC50AN16				500D/203/L011	ALL
ST..	1	W5086	6010	20		26-16-21	ALL
AC..	1	W5248	0082	20		33-36-11	ALL
GD08050		BACC50AN16				926/219/R063	ALL
ST..	1	W4258	0092	18		25-29-11	ALL
AC..	1	W4258	0093	18		25-29-11	ALL
GD08054		BACC50AN16				380/296/L019	ALL
GD08057		BACC50AN16				380/298/L011	ALL
DC..	1	W3477	0004	20		44-21-12	ALL
AC..	1	W3477	0005	20		44-21-12	ALL
ST..	1	W3477	0006	20		44-21-12	ALL

GROUND LIST

D280A351

91-21-21

Section GD08000

Page 4

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD08057		BACC50AN16 (continued)				380/298/L011	ALL
DC..	1	W3477	0011	20		44-21-12	ALL
ST..	1	W3477	0012	20		44-21-12	ALL
DC..	1	W3477	0038	20		44-21-12	ALL
AC..	1	W3477	0039	20		44-21-12	ALL
ST..	1	W3477	0040	20		44-21-12	ALL
GD08058		BACC50AN16				419/299/R016	ALL
AC..	1	W4166	0215	18		33-22-31	ALL
ST..	1	W4166	0216	18		33-22-31	ALL

GROUND LIST

D280A351

91-21-21

Section GD08000

Page 5 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
I GD08102		BACC50AN16				E008-01/ /	ALL
I ST..	1	W0811	0065	16		25-29-12	ALL
I GD08104		BACC50AN20				E008-01/ /	ALL
I AC..	1A	W0811	0008	20		44-21-10	YT101-YT120
I AC..	1A	W0811	0088	20		44-21-10	ALL
I AC..	1A	W0811	0151	20		44-35-20	ALL
I GD08105		BACC50AN20				E008-01/ /	ALL
I ST..	1A	W0811	0009	20		44-21-10	YT101-YT120
I ST..	1A	W0811	0089	20		44-21-10	ALL
I ST..	1A	W0811	0103	22		44-21-22	ALL
I ST..	1A	W0811	0152	20		44-35-20	ALL
I GD08111		AC-				E8-1 312/184/R014	ALL

GROUND LIST

D280A351

91-21-21

Section GD08100

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No.		Part Number		Station / WL / BL		Effectivity
Term	Type	Bundle	Wire No.	GA	CO	
GD08200		BACC50AN20		AJ0039/ /		ALL
DC..	1A	W0082	0006	20	27-62-11	ALL
DC..	1A	W0082	0010	20	27-62-11	ALL
DC..	1A	W0082	0011	20	27-62-11	ALL
DC..	1A	W0082	0019	20	27-62-11	ALL
DC..	1A	W0082	0033	20	27-62-11	ALL
DC..	1A	W0082	0034	20	27-62-11	ALL
DC..	1A	W0082	0036	20	27-62-11	ALL
DC..	1A	W0082	0037	20	27-62-11	ALL
DC..	1A	W0082	0053	20	27-62-11	ALL
DC..	1A	W0082	0054	20	27-62-11	ALL
GD08202		BACC50AN20		AJ0039/ /		ALL
DC..	1A	W0082	1017	20	27-62-11	ALL
DC..	1A	W0082	1026	20	27-62-11	ALL

GROUND LIST

D280A351

91-21-21

Section GD08200

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No.		Part Number		Wire No.		Station / WL / BL	
Term	Type	Bundle		GA	CO	Diagram	Effectivity
GD08402		BACC50AN20				AJ0039B/ /	ALL
DC..	1A	W0084	0008	20		24-31-11	ALL
AC..	1A	W0084	0011	20		24-31-11	ALL

GROUND LIST

D280A351

91-21-21

Section GD08400

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD0901A		BACC50AN16				P009-00/ /	ALL
ST..	1	W0003	0512	16		31-62-21	ALL
ST..	1	W0003	0513	16		31-62-21	ALL
ST..	1	W0003	0514	16		31-62-21	ALL
ST..	1	W0003	0515	16		31-62-21	ALL
GD0901B		BACC50AN20				P009-00/ /	ALL
AC..	1A	W2889	0003	20		34-61-11	ALL
DC..	1A	W2889	0004	20		34-61-11	ALL
DC..	1A	W2889	0005	20		34-61-11	ALL
DC..	1A	W2889	0006	20		34-61-11	ALL
AC..	1A	W2889	0009	20		33-11-33	ALL
GD0901C		BACC50AN20				P009-00/ /	ALL
DC..	1A	W0003	0532	22		31-62-22	ALL
DC..	1A	W0003	0533	22		31-62-22	ALL
AC..	1A	W5202	5511	20		33-14-11	ALL
DC..	1A	W5202	5515	20		33-14-11	ALL
ST..	1A	W5202	5516	20		33-14-11	ALL
DC..	1A	W5202	5524	20		33-14-11	ALL
AC..	1A	W5202	5533	20		33-14-11	ALL
DC..	1A	W5202	5534	20		33-14-11	ALL
DC..	1A	W5202	5535	20		33-14-11	ALL
ST..	1A	W5202	5536	20		33-14-11	ALL

GROUND LIST

D280A351

91-21-21

Section GD09000

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD0911A		BACC50AN20				P009-00/ /	ALL
GD0911B		BACC50AN20				P009-00/ /	ALL
DC..	1A	W2705	0099	22		34-36-11	ALL
DC..	1A	W2705	0100	20		34-36-11	ALL
ST..	1A	W2705	0101	20		34-36-11	ALL
AC..	1A	W2873	0003	20		34-61-11	ALL
DC..	1A	W2873	0004	20		34-61-11	ALL
DC..	1A	W2873	0005	20		34-61-11	ALL
DC..	1A	W2873	0006	20		34-61-11	ALL
AC..	1A	W2873	0009	20		33-11-41	ALL
DC..	1A	W5514	5501	20		31-51-11	ALL
ST..	1A	W5514	5574	20		31-51-11	ALL
GD0911C		BACC50AN20				P009-00/ /	ALL
AC..	1A	W5202	5502	20		33-14-11	ALL
DC..	1A	W5202	5506	20		33-14-11	ALL
ST..	1A	W5202	5507	20		33-14-11	ALL
DC..	1A	W5202	5523	20		33-14-11	ALL

GROUND LIST

D280A351

91-21-21

Section GD09100

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number		Wire No.	GA	CO	Station / WL / BL		Effectivity
		Bundle					Diagram		
I GD09202		BACC50AN20					E9-2/ /		ALL

GROUND LIST

D280A351

91-21-21

Section GD09200

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No.		Part Number		Station / WL / BL			
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD10086		BACC50AN16				289/217/R057	ALL
DC..	1	W4142	0052	20		33-51-21	ALL
ST..	1	W6242	0051	18		25-29-11	ALL
AC..	1	W6242	0052	18		25-29-11	ALL

GROUND LIST

D280A351

91-21-21

Section GD10000

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD1010A		BACC50AN16				P001-00/ /	ALL
AC..	1	W0001	0204	16		33-11-31	ALL
AC..	1	W0001	0326	20		33-11-31	ALL
GD1010B		BACC50AN20				P001-00/ /	ALL
DC..	1A	W0001	0235	20		33-18-11	ALL
DC..	1A	W0001	0245	20		33-18-23	ALL
AC..	1A	W0001	0265	20		33-14-11	ALL
DC..	1A	W0001	0341	20		31-22-11	ALL
DC..	1A	W0003	0689	20		33-18-21	ALL
GD1010C		BACC50AN20				P001-00/ /	ALL
DC..	1A	W0001	0179	20		31-52-11	ALL
AC..	1A	W0001	0197	20		33-11-11	ALL
AC..	1A	W0001	0220	20		33-11-32	ALL
AC..	1A	W0001	0222	20		33-11-32	ALL
AC..	1A	W0001	0224	20		33-11-32	ALL
AC..	1A	W0001	0226	20		33-11-11	ALL
AC..	1A	W0001	0230	20		33-11-32	ALL
AC..	1A	W0001	0232	20		33-11-32	ALL
AC..	1A	W0001	1010	20		33-11-32	ALL
ST..	1A	W0001	1010Z			33-11-32	ALL
GD10185		DC-				//	ALL
GD10189		DC-				//	ALL

GROUND LIST

D280A351

91-21-21

Section GD10100

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD11002		BACC50AN16				747/205/L003	YT101-YT111, YT126-YT130
GD11002		BACC50AN16				747/205/L020	YT112-YT120, YT131-YT133
ST..	1	W5096	6025	20		26-16-22	ALL
AC..	1	W6248	0276	20		33-36-12	YT112-YT120, YT131-YT133
GD11004		BACC50AN16				727J/205/L030	ALL
ST..	1	W5096	6010	20		26-16-22	ALL
GD11098		BACC50AN16				986/300/L006	ALL
ST..	1	W3058	0102	18		33-24-22	YT101-YT131
AC..	1	W3058	0103	18		33-24-22	YT101-YT131

GROUND LIST

D280A351

91-21-21

Section GD11000

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD11100		BACC50AN16				294/288/L008	ALL
ST..	1	W3144	0101	18		33-26-31	ALL
DC..	1	W3144	0115	18		35-21-21	ALL
AC..	1	W3144	0128	18		33-25-11	ALL
ST..	1	W3144	0130	18		33-26-31	ALL
AC..	1	W3144	0139	18		33-26-31	ALL
AC..	1	W3144	0140	18		33-26-31	ALL
ST..	1	W3701	0001	22		23-70-11	ALL
GD11102		BACC50AN16				949/ /L	ALL
GD11104		BACC50AN16				1005/299/L013	ALL
DC..	1	W3377	1009	20		22-23-11	ALL
DC..	1	W3377	1009Z			22-23-11	ALL
DC..	1	W3379	1009	20		27-24-11	ALL
DC..	1	W3379	1009Z			27-24-11	ALL
GD11106		BACC50AN16				294/288/R009	ALL
ST..	1	W3058	0320	20		SPARE	YT101-YT131
DC..	1	W4142	0701	16		33-51-11	ALL
ST..	1	W4142	0707	20		33-51-11	ALL
AC..	1	W6242	0057	20		33-26-21	ALL
ST..	1	W6242	0058	20		33-26-21	ALL
GD11108		BACC50AN16				360/297/R006	ALL
ST..	1	W3805	0002	22		23-70-11	ALL
ST..	1	W3805	0004	22		23-70-11	ALL
AC..	1	W4166	0512	18		33-26-31	ALL
GD11110		BACC50AN16				480/ /	ALL

GROUND LIST

D280A351

91-21-21

Section GD11100

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
I	GD11306		BACC50AN16				300/263/L051	ALL
I	AC..	1	W5110	0101	20		52-71-11	ALL
I	GD11334		BACC50AN16				344/267/R055	ALL

GROUND LIST

D280A351

91-21-21

Section GD11300

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
I GD11728		BACC50AN16				727+18/205/R024	ALL
I AC..	1	W6248	0270	20		33-36-12	ALL
I GD11730		BACC50AN16				727B/205/L022	ALL
I ST..	1	W5096	6020	20		26-16-22	ALL
I AC..	1	W6248	0272	20		33-36-12	ALL
I GD11732		BACC50AN16				727C/204/L020	ALL
I ST..	1	W5096	6005	20		26-16-22	ALL
I GD11734		BACC50AN16				847/204/L023	ALL
I ST..	1	W5096	6030	20		26-16-22	ALL
I GD11774		BACC50AN16				767/205/L002	YT101-YT111, YT126-YT130
I AC..	1	W6248	0268	20		33-36-12	YT101-YT111, YT126-YT130
I AC..	1	W6248	0276	20		33-36-12	YT101-YT111, YT126-YT130
I GD11794		BACC50AN16				775/199/R064	ALL
I DC..	1	W6248	0146	20		52-71-12	ALL
I AC..	1	W6248	0280	20		33-36-12	ALL
I DC..	1	W6248	0286	20		33-36-12	ALL

GROUND LIST

D280A351

91-21-21

Section GD11700

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD11830		BACC50AN16				827/204/L030	ALL
ST..	1	W5096	6039	22		26-16-22	ALL
DC..	1	W5098	6019	22		26-16-22	ALL
DC..	1	W5098	6020	22		26-16-22	ALL
ST..	1	W5098	6021	22		26-16-22	ALL
AC..	1	W6248	0282	20		33-36-12	ALL
GD11894		BACC50AN16				887/204/R003	YT101-YT111, YT126-YT130
GD11894		BACC50AN16				887/204/L030	YT112-YT120, YT131-YT133
ST..	1	W5096	6015	20		26-16-22	ALL
DC..	1	W5146	0107	18		38-32-12	ALL
ST..	1	W5146	0110	18		38-32-12	ALL
DC..	1	W5146	0113	20		38-32-12	ALL
DC..	1	W5146	0115	20		38-32-12	ALL
DC..	1	W5146	0212	20		38-32-13	ALL
ST..	1	W5146	0213	20		38-32-13	ALL
DC..	1	W5146	0227	20		38-32-13	ALL
AC..	1	W6248	0284	20		33-36-12	ALL

GROUND LIST

D280A351

91-21-21

Section GD11800

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

	Ground No.	Type	Part Number		Wire No.	GA	CO	Station / WL / BL	Effectivity
	Term		Bundle					Diagram	
I	GD11996		BACC50AN16					991/197/L036	ALL
I	AC..	1	W6248	5501	20			30-71-11	ALL
I	AC..	1	W6248	5567	20			30-71-11	ALL
I	AC..	1	W6248	5569	20			30-71-11	ALL

GROUND LIST

D280A351

91-21-21

Section GD11900

Page 1 End

Jun 21/2016



737-800 WIRING DIAGRAM MANUAL

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD3010A		BACC50AN16				P003-00/ /	ALL
AC..	1	W0003	0328	20		33-11-21	ALL
ST..	1	W0003	1509Z			33-11-21	ALL
GD3010B		BACC50AN20				P003-00/ /	ALL
DC..	1A	W0003	0304	20		31-22-11	ALL
DC..	1A	W0003	0697	20		33-18-22	ALL
DC..	1A	W0003	0701	20		33-18-24	ALL
DC..	1A	W0003	0703	20		33-18-24	ALL
GD3010C		BACC50AN20				P003-00/ /	ALL
DC..	1A	W0003	0652	20		31-52-11	ALL
AC..	1A	W0003	0669	20		33-11-21	ALL
AC..	1A	W0003	0671	20		33-11-21	ALL
AC..	1A	W0003	0676	20		33-11-21	ALL
AC..	1A	W0003	0678	20		33-11-21	ALL
AC..	1A	W0003	0680	20		33-11-21	ALL
AC..	1A	W0003	1510	20		33-11-21	ALL
ST..	1A	W0003	1510Z			33-11-21	ALL

GROUND LIST

D280A351

91-21-21

Section GD30100

Page 1 End

Jun 21/2016