

1231VM

RESET

PACK 1 CTL, CPCS 1, AVS 1, VCS 1, TCS 1, TCS 2, SCS 1, ATC, FMC-A, FMC-C, SLATS 1, FLAPS 1, DTLNK ROUTER, TR 1, ESS TR, AESU 1, FWS 1, GCU, FOMS 1, LGCIS 1, BSCS 1, SDF 1, SDF 3, AICU 1, CIDS 1, CIDS 3, ENG 2 EIPM 1, ENG 4 EIPM 1

ELT

ON, ARMED, RESET/TEST

1221VM

APU

FIRE, AGENT, SQUIB, DISCH

IR1, IR2, IR3, NAV, OFF, ATT, ADR1, ADR2, ADR3, PROBE & WINDOW HEAT, AUTO

1211VM

F/CTL

PRIM 1, SEC 1, PRIM 3, SEC 3

FUEL

OUTR TK EMER XFR, JETTISON ARM, ACTIVE

RCDR, EVAC, CAPT & PURS, EMER ELEC PWR, RAT MAN ON, EMER GEN, ENTERTAINMENT, NSS MASTER SW, SMOKE

OXYGEN

CREW SUPPLY, MASK MAN ON, PAX, SYS ON

CALLS

PILOT REST, FWD, MAIN, ALL, EMER, MECH, UPPER, MAIN, PURS

WIPER

OFF, INTMT SLOW, INTMT MEDIUM, INTMT FAST, RAIN RPLNT

1255VM

OXYGEN

RESET, SVCE INT OVRD, ELEC PMP A, ELEC PMP B, GND HYD, ELEC PMP A, ELEC PMP B

FUEL

REFUEL, AUTO GND XFR, GND HF DATALINK

ENG

1, FADEC GND PWR 2, 3, 4

MAINT

GND CONNECTION

ELEC

REMOTE C/B CTL

BAT

APU, ESS, OFF, 1, 2, 88.8

AIR

OVHT COND FANS RESET

1265VU

1245VM

ENG 1, ENG 2, ENG 3, ENG 4

FIRE

AGENT 1, AGENT 2, SQUIB, DISCH, TEST

HYD

ENG1, ENG2, ENG3, ENG4, A, B, A+B, FAULT, OFF, DISC

CROSSFEED

1, 2, 3, 4, OPEN, ON

FUEL

FEED TK 1, MAIN, STBY, FEED TK 2, MAIN, STBY, FEED TK 3, MAIN, STBY, FEED TK 4, MAIN, STBY, L INTR TK, FWD, AFT, L MID TK, FWD, AFT, L OUTR TK, PMP, FWD, AFT, R INTR TK, FWD, AFT, R MID TK, FWD, AFT, R OUTR TK, PMP, FWD, AFT, TRIM TK, L, R, TRIM TK XFR, TRIM TK FEED, ISOL, AUTO, OPEN

1235VM

ELEC

BAT 1, ESS BAT, BAT 2, APU BAT, ELMU, AC ESS FEED, PAX SYS, GALLEY, COMMERCIAL 1, COMMERCIAL 2, AC BUS 1, AC BUS 2, AC BUS 3, AC BUS 4, EXT 1, EXT 2, EXT 3, EXT 4, DRIVE 1 GEN, DRIVE 2 GEN, DRIVE 3 GEN, DRIVE 4 GEN, AIR FLOW, HOT AIR 1, CKPT, RAM AIR, CABIN, HOT AIR 2, CABIN AIR EXTRACT, PACK 1, PACK 2, ENG 1 BLEED, ENG 2 BLEED, APU BLEED, ENG 3 BLEED, ENG 4 BLEED, X BLEED, AUTO, OPEN, CLOSE

1215VM

ANTI ICE

AUTO MODE, WING, 1, 2, 3, 4, EXT LT, STROBE, BEACON, NAV, LOGO, APU, MASTER SW, WING, RWY TURN OFF & CAMERA, LAND, NOSE, T.O, TAXI, OFF

ENG START

CRANK, NORM, IGN START

CABIN PRESS

CABIN ALT, MODE, TRGT, DEC, INC, CABIN V/S, MODE, UP, DN, DITCHING, INT LT, STBY COMPASS, ICE IND, STORM, ANN LT, TEST, DIM, SIGNS, SEAT BELTS, NO SMOKING, EMER EXIT LT, ON, ARM, OFF

1252VU

READING LT

OFF, BRT

1222VM

RESET

PACK 2 CTL, CPCS 2, AVS 2, VCS 2, SCS 2, FMC-B, SLATS 2, FLAPS 2, NSS CABIN, TR 2A, ARPT NAV, AESU 2, FWS 2, FOMS 2, LGCIS 2, BSCS 2, DSMS 2, SDF 2, AICU 2, CIDS 2, NSS AVNCS, NSS FLT OPS, ENG 1 EIPM 2, ENG 3 EIPM 2, NSS DATA TO AVNCS, AUTO, OFF

1235VM

CVR

TEST, BROADCAST, ERASE

VHF, HF, TEL, SQWK, MENU, NAV, 121.900, VHF1, STBY, 121.700, 118.100, VHF2, STBY, 123.450, DATA, VHF3, SQUAWK: 2523, MSG CLR, CALL, HF1, TEL1, 1, 2, 3, 4, 5, 6, 7, 8, 9, 0, CLR, VHF2, HF2, TEL2, MECH, ATT, CAB, PA, VOICE, VHF3, RAD, INT, CAB, LS, VOR, 1, 2, MKR, RAD NAV, ADF-2, 1, 2

1212VM

F/CTL

PRIM 2, SEC 2, TURB DAMPG

CARGO AIR COND

FWD, ISOL VALVES, FAULT, OFF, TEMP REGUL, 15, 5, OFF, 25, BULK, ISOL VALVES, FAULT, OFF, TEMP REGUL, 15, 5, OFF, 25, HEATER, FAULT, OFF

CARGO SMOKE

AGENT TO FWD, SMOKE, BTL 1, BTL 2, AGENT TO AFT, SMOKE, TEST, AVNCS SMOKE, AVNCS EXTRACT, CAB FANS, COOLG, AUTO, VENT, MAN START, 2, 3, 4, 1, 2, 3, 4, ALTN MODE

WIPER

OFF, INTMT SLOW, INTMT MEDIUM, INTMT FAST, RAIN RPLNT