

**CHAPTER**

**38**

**WATER / WASTE**



737-800

## WIRING DIAGRAM MANUAL

### CHAPTER 38 WATER / WASTE

CH-SC-SU	Schem	Page	Sheet	Date	CH-SC-SU	Schem	Page	Sheet	Date
38-EFFECTIVE PAGES									
		1		Jun 21/2016					
		2		BLANK					
38-CONTENTS									
R		1		Jun 21/2016					
		2		BLANK					
38-ALPHABETICAL INDEX									
		1		Aug 15/2013					
		2		BLANK					
38-21-11									
R		1		Jun 21/2016					
38-32-12									
R		1		Jun 21/2016					
A		2		Jun 21/2016					
38-32-13									
R		1		Jun 21/2016					
38-41-11									
R		1		Jun 21/2016					
38-41-13									
R		1		Jun 21/2016					

A = Added, R = Revised, D = Deleted, O = Overflow

### 38-EFFECTIVE PAGES

Page 1  
Jun 21/2016

D280A351



737-800

## WIRING DIAGRAM MANUAL

### CHAPTER 38 WATER / WASTE

	Title	CH-SC-SU	Schem	Page	Sheet	Date	Effectivity
	<b><u>LAVATORY WATER HEATERS</u></b>						
I	LAVATORY WATER HEATERS	38-21-11		1		Jun 21/2016	YT101-YT131
	<b><u>VACUUM WASTE SYSTEM</u></b>						
I	VACUUM WASTE SYSTEM CONTROL	38-32-12		1		Jun 21/2016	YT101-YT118 YT126-YT131
I				2		Jun 21/2016	YT119-YT120 YT132-YT133
I	VACUUM WASTE SYSTEM INDICATION	38-32-13		1		Jun 21/2016	ALL
	<b><u>WATER INDICATOR SYSTEM</u></b>						
I	WATER QUANTITY INDICATOR	38-41-11		1		Jun 21/2016	ALL
I	POTABLE WATER PRESSURE SYSTEM	38-41-13		1		Jun 21/2016	ALL

## 38-CONTENTS

D280A351

BOEING PROPRIETARY - Copyright © Unpublished Work - See title page for details

Page 1  
Jun 21/2016



737-800

## WIRING DIAGRAM MANUAL

### CHAPTER 38 WATER / WASTE


CH-SC-SU	Title
38-21-11	LAVATORY WATER HEATERS
38-41-13	POTABLE WATER PRESSURE SYSTEM
38-32-12	VACUUM WASTE SYSTEM CONTROL
38-32-13	VACUUM WASTE SYSTEM INDICATION
38-41-11	WATER QUANTITY INDICATOR

## 38-ALPHABETICAL INDEX

D280A351

BOEING PROPRIETARY - Copyright © Unpublished Work - See title page for details

Page 1  
Aug 15/2013




**38-21-11**

D280A351

**38-21-11**

Jun 21/2016



YT101-YT118, YT126-YT131

## VACUUM WASTE SYSTEM CONTROL

D280A351

### 38-32-12

Page 1


Jun 21/2016

### 38-32-12

Page 1

Jun 21/2016





NOTES:

1 CAP AND STOW CONNECTOR

ALL	VACUUM WASTE SYSTEM INDICATION
	D280A351

38-32-13

Page 1

Jun 21/2016

38-32-13


Page 1

Jun 21/2016





737-800 WIRING DIAGRAM MANUAL



NOTES:

1 THIS WIRE MAY BE BUNDLED WITH CATEGORY 1 WIRES FROM P91 TO DISCONNECT BRACKET (AB340A) FOR NO MORE THAN 40 FEET

NOTE:  
THE INTERNAL WIRING OF THE LAVATORY MODULE IS FOR REFERENCE ONLY. PLEASE REFER TO LAVATORY COMPONENT MAINTENANCE MANUAL (CMM) FOR COMPLETE FUNCTIONALITY. BOEING SHOWS ACCURATE WIRING UP TO DISCONNECT BRACKET ONLY.

ALL

WATER QUANTITY INDICATOR

38-41-11

Page 1


D280A351

Jun 21/2016

38-41-11

Page 1

Jun 21/2016



**NOTES:**

1 CATEGORY 1 WIRES MAY BE ROUTED WITH CATEGORY 2 WIRES FROM P91 TO E2-1 (NO MORE THAN 10 FEET).

ALL	POTABLE WATER PRESSURE SYSTEM
	D280A351

**38-41-13**

Page 1

Jun 21/2016

**38-41-13**

Page 1

Jun 21/2016