

**91-21-13**

**MASTER BUNDLE LIST**

91-21-13  
MASTER BUNDLE LIST

Section	Page	Date	Section	Page	Date	Section	Page	Date
EFFECTIVE PAGES			W0150 cont.			R W0730	1	Jun 21/2016
	1 thru 4	Jun 21/2016	R	2	Jun 21/2016	R W0760	1	Jun 21/2016
R W0000	1	Jun 21/2016	R W0160	1	Jun 21/2016	R W0810	1	Jun 21/2016
R	2	Jun 21/2016	R W0200	1	Jun 21/2016	R W1020	1	Jun 21/2016
R	3	Jun 21/2016	R W0210	1	Jun 21/2016	R W1030	1	Jun 21/2016
R W0010	1	Jun 21/2016	R	2	Jun 21/2016	R W1060	1	Jun 21/2016
R W0020	1	Jun 21/2016	R W0220	1	Jun 21/2016	R W1080	1	Jun 21/2016
R W0040	1	Jun 21/2016	R	2	Jun 21/2016	R W1120	1	Jun 21/2016
R	2	Jun 21/2016	R W0310	1	Jun 21/2016	R W1130	1	Jun 21/2016
R	3	Jun 21/2016	R	2	Jun 21/2016	R W1140	1	Jun 21/2016
R W0050	1	Jun 21/2016	R W0320	1	Jun 21/2016	R W1160	1	Jun 21/2016
R W0060	1	Jun 21/2016	R	2	Jun 21/2016	R W1170	1	Jun 21/2016
R W0070	1	Jun 21/2016	R	3	Jun 21/2016	R W1180	1	Jun 21/2016
R	2	Jun 21/2016	R W0330	1	Jun 21/2016	R W1240	1	Jun 21/2016
R W0080	1	Jun 21/2016	R	2	Jun 21/2016	R W1260	1	Jun 21/2016
R	2	Jun 21/2016	R	3	Jun 21/2016	R W1270	1	Jun 21/2016
R	3	Jun 21/2016	R W0340	1	Jun 21/2016	R W1280	1	Jun 21/2016
R W0090	1	Jun 21/2016	R W0350	1	Jun 21/2016	R W1660	1	Jun 21/2016
R W0100	1	Jun 21/2016	R W0410	1	Jun 21/2016	R W1720	1	Jun 21/2016
R W0110	1	Jun 21/2016	R	2	Jun 21/2016	R W2000	1	Jun 21/2016
R	2	Jun 21/2016	R W0420	1	Jun 21/2016	R W2010	1	Jun 21/2016
R	3	Jun 21/2016	R	2	Jun 21/2016	R W2020	1	Jun 21/2016
R W0120	1	Jun 21/2016	R W0440	1	Jun 21/2016	R W2030	1	Jun 21/2016
R	2	Jun 21/2016	R W0450	1	Jun 21/2016	R W2100	1	Jun 21/2016
R W0130	1	Jun 21/2016	R W0520	1	Jun 21/2016	R W2110	1	Jun 21/2016
R W0140	1	Jun 21/2016	R	2	Jun 21/2016	R W2130	1	Jun 21/2016
R	2	Jun 21/2016	D	3	Jun 21/2016	R W2140	1	Jun 21/2016
R W0150	1	Jun 21/2016	R W0620	1	Jun 21/2016	R W2150	1	Jun 21/2016

A = Added, R = Revised, D = Deleted, O = Overflow

## MASTER BUNDLE LIST

D280A351

## EFFECTIVE PAGES

Page 1  
Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

### 91-21-13 MASTER BUNDLE LIST

Section	Page	Date	Section	Page	Date	Section	Page	Date
R W2160	1	Jun 21/2016	R W3050	1	Jun 21/2016	R W3700	1	Jun 21/2016
R W2170	1	Jun 21/2016	D	2	Jun 21/2016	R W3710	1	Jun 21/2016
R W2200	1	Jun 21/2016	R W3140	1	Jun 21/2016	W3730	1	Mar 14/2016
R W2210	1	Jun 21/2016	R	2	Jun 21/2016	W3740	1	Mar 14/2016
R	2	Jun 21/2016	R	3	Jun 21/2016	R W3750	1	Jun 21/2016
R W2220	1	Jun 21/2016	R W3150	1	Jun 21/2016	R	2	Jun 21/2016
R W2230	1	Jun 21/2016	R	2	Jun 21/2016	R W3760	1	Jun 21/2016
R W2240	1	Jun 21/2016	R W3160	1	Jun 21/2016	R	2	Jun 21/2016
R W2250	1	Jun 21/2016	R	2	Jun 21/2016	R W3780	1	Jun 21/2016
R W2260	1	Jun 21/2016	R W3170	1	Jun 21/2016	R W3800	1	Jun 21/2016
R W2300	1	Jun 21/2016	R W3240	1	Jun 21/2016	R W3890	1	Jun 21/2016
R W2360	1	Jun 21/2016	R W3300	1	Jun 21/2016	R W3900	1	Jun 21/2016
R W2380	1	Jun 21/2016	R W3310	1	Jun 21/2016	R W4000	1	Jun 21/2016
R W2410	1	Jun 21/2016	R W3320	1	Jun 21/2016	R W4110	1	Jun 21/2016
R W2460	1	Jun 21/2016	R W3370	1	Jun 21/2016	R W4130	1	Jun 21/2016
R W2500	1	Jun 21/2016	R W3380	1	Jun 21/2016	R W4140	1	Jun 21/2016
R W2510	1	Jun 21/2016	R W3390	1	Jun 21/2016	R	2	Jun 21/2016
R W2520	1	Jun 21/2016	R W3410	1	Jun 21/2016	R W4160	1	Jun 21/2016
R W2530	1	Jun 21/2016	R W3450	1	Jun 21/2016	R	2	Jun 21/2016
R W2580	1	Jun 21/2016	R W3470	1	Jun 21/2016	R W4170	1	Jun 21/2016
R W2590	1	Jun 21/2016	R	2	Jun 21/2016	R W4220	1	Jun 21/2016
R W2650	1	Jun 21/2016	W3480	1	Mar 14/2016	R W4240	1	Jun 21/2016
R W2660	1	Jun 21/2016	R W3550	1	Jun 21/2016	R W4250	1	Jun 21/2016
R W2700	1	Jun 21/2016	W3580	1	Mar 14/2016	R	2	Jun 21/2016
R W2800	1	Jun 21/2016	R W3600	1	Jun 21/2016	R W4720	1	Jun 21/2016
R W2870	1	Jun 21/2016	W3620	1	Mar 14/2016	R W5000	1	Jun 21/2016
R W2880	1	Jun 21/2016	R W3640	1	Jun 21/2016	R W5030	1	Jun 21/2016
R W3000	1	Jun 21/2016	W3690	1	Mar 14/2016	R W5040	1	Jun 21/2016

A = Added, R = Revised, D = Deleted, O = Overflow

#### MASTER BUNDLE LIST

D280A351

#### EFFECTIVE PAGES

Page 2  
Jun 21/2016

91-21-13  
MASTER BUNDLE LIST

Section	Page	Date	Section	Page	Date	Section	Page	Date
R W5050	1	Jun 21/2016	R W5360	1	Jun 21/2016	R W6110	1	Jun 21/2016
R W5070	1	Jun 21/2016	R W5370	1	Jun 21/2016	R W6120	1	Jun 21/2016
R W5080	1	Jun 21/2016	R W5380	1	Jun 21/2016	R W6130	1	Jun 21/2016
R W5090	1	Jun 21/2016	R W5390	1	Jun 21/2016	R W6160	1	Jun 21/2016
R W5100	1	Jun 21/2016	R W5400	1	Jun 21/2016	R W6170	1	Jun 21/2016
R	2	Jun 21/2016	R W5410	1	Jun 21/2016	R W6180	1	Jun 21/2016
R W5110	1	Jun 21/2016	R W5430	1	Jun 21/2016	R W6200	1	Jun 21/2016
R W5120	1	Jun 21/2016	R W5450	1	Jun 21/2016	R	2	Jun 21/2016
R W5130	1	Jun 21/2016	R W5460	1	Jun 21/2016	R W6210	1	Jun 21/2016
R W5140	1	Jun 21/2016	R W5500	1	Jun 21/2016	R W6220	1	Jun 21/2016
R W5150	1	Jun 21/2016	R	2	Jun 21/2016	R W6230	1	Jun 21/2016
R	2	Jun 21/2016	A	3	Jun 21/2016	R W6240	1	Jun 21/2016
R W5160	1	Jun 21/2016	R W5510	1	Jun 21/2016	R	2	Jun 21/2016
R	2	Jun 21/2016	R W5520	1	Jun 21/2016	R W6280	1	Jun 21/2016
R W5170	1	Jun 21/2016	R W5530	1	Jun 21/2016	R W6410	1	Jun 21/2016
R W5180	1	Jun 21/2016	R W5550	1	Jun 21/2016	R W6420	1	Jun 21/2016
R W5190	1	Jun 21/2016	R W5560	1	Jun 21/2016	R W6430	1	Jun 21/2016
R W5200	1	Jun 21/2016	R W5570	1	Jun 21/2016	R W6490	1	Jun 21/2016
R W5220	1	Jun 21/2016	R W5580	1	Jun 21/2016	R W6500	1	Jun 21/2016
R W5230	1	Jun 21/2016	R W5590	1	Jun 21/2016	A	2	Jun 21/2016
R W5240	1	Jun 21/2016	R W5600	1	Jun 21/2016	R W6510	1	Jun 21/2016
R W5250	1	Jun 21/2016	R W5610	1	Jun 21/2016	R W6520	1	Jun 21/2016
R W5270	1	Jun 21/2016	R W5710	1	Jun 21/2016	R W6530	1	Jun 21/2016
R W5290	1	Jun 21/2016	R W5720	1	Jun 21/2016	R W6560	1	Jun 21/2016
R W5300	1	Jun 21/2016	R W5830	1	Jun 21/2016	R W6570	1	Jun 21/2016
R W5310	1	Jun 21/2016	R W6020	1	Jun 21/2016	R W6580	1	Jun 21/2016
R W5330	1	Jun 21/2016	R W6030	1	Jun 21/2016	R W6590	1	Jun 21/2016
R W5350	1	Jun 21/2016	R W6100	1	Jun 21/2016	R W6730	1	Jun 21/2016

A = Added, R = Revised, D = Deleted, O = Overflow

## MASTER BUNDLE LIST

D280A351

## EFFECTIVE PAGES

Page 3  
Jun 21/2016

**91-21-13  
MASTER BUNDLE LIST**

Section	Page	Date	Section	Page	Date	Section	Page	Date
R W7020	1	Jun 21/2016	R W8230	1	Jun 21/2016			
R W7030	1	Jun 21/2016	R W8480	1	Jun 21/2016			
R W7050	1	Jun 21/2016	R W8520	1	Jun 21/2016			
R W7060	1	Jun 21/2016	R W8530	1	Jun 21/2016			
R W7100	1	Jun 21/2016	A	2	BLANK			
R W7120	1	Jun 21/2016						
A	2	Jun 21/2016						
R W7130	1	Jun 21/2016						
R W7150	1	Jun 21/2016						
R W7180	1	Jun 21/2016						
R W7190	1	Jun 21/2016						
R W7200	1	Jun 21/2016						
R W7230	1	Jun 21/2016						
R W7350	1	Jun 21/2016						
R W7380	1	Jun 21/2016						
R W7500	1	Jun 21/2016						
R W7520	1	Jun 21/2016						
R W7530	1	Jun 21/2016						
R W7540	1	Jun 21/2016						
R W7580	1	Jun 21/2016						
R W7590	1	Jun 21/2016						
R W7760	1	Jun 21/2016						
R W8020	1	Jun 21/2016						
R W8030	1	Jun 21/2016						
R W8120	1	Jun 21/2016						
R W8130	1	Jun 21/2016						
R W8150	1	Jun 21/2016						
R W8220	1	Jun 21/2016						

A = Added, R = Revised, D = Deleted, O = Overflow

**MASTER BUNDLE LIST**

D280A351

**EFFECTIVE PAGES**Page 4  
Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W0001	NA2	P1 - CAPTAINS INSTRUMENT PANEL				
I D40738J				D40738P	W0104	ALL
I D03977A			P001-00/ /			ALL
I D03977B			P001-00/ /			ALL
I D03979A			P001-00/ /			ALL
I D03979B			P001-00/ /			ALL
I D03981A			P002-00/ /			ALL
I D03981B			P002-00/ /			ALL
I D04207J		AP0900A	POS 03	D04207P	W2207	ALL
I D40578J		AP0900A	POS 04	D40578P	W5156	ALL
I D04221J		AP0900A	POS 09	D04221P	W2221	ALL
I D40914J		AP0900A	POS 10	D40914P	W2022	ALL
I D40944J		AP0900A	POS 11	D40944P	W5202	ALL
I D40804J		AP0900A	POS 18	D40804P	W5506	ALL
I D41833J		AP0900A	POS 19	D41833P	W2651	ALL
I D10030J		AP0900A	POS 25	D10030P	W3704	ALL
I D10031		M01810	193/219/L007			ALL
I D10033		M01810	193/219/L007			ALL
I D10035		M01810	193/219/L007			ALL
I D10037		M01810	193/219/L007			ALL
I D10039		M01810	193/219/L007			ALL
I D10041		M01810	193/219/L007			ALL
I D10059		M01812	193/218/L007			ALL
I D10061		M01812	193/218/L007			ALL
I D10063		M01812	193/218/L007			ALL
I D10065		M01812	193/218/L007			ALL
I D10067		M01812	193/218/L007			ALL
I D10069		M01812	193/218/L007			ALL
I D11990		M01952	P002-03/ /			ALL
I D00686		N00054	P002-02/ /			ALL
I D00714		N00145	P001-01/ /			ALL
I D02435		N00170	P001-03/ /			ALL
I D02437		N00170	P001-03/ /			ALL
I D03977		N00187	P001-00/ /			ALL
I D03979		N00188	P001-00/ /			ALL
I D03981		N00189	P002-00/ /			ALL
I D00903		P001-01	P001-00/ /			ALL
I D00423		P001-03	P001-00/ /			ALL
I D01036		P001-05	P001-00/ /			ALL
I D02650		P001-09	P001-00/ /			ALL
I D00331		P002-02	P002-00/ /			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W0000

Page 1

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
<b>W0001</b>	<b>NA2</b>	<b>P1 - CAPTAINS INSTRUMENT PANEL (continued)</b>				
D00339		P002-02	P002-00/ /			ALL
D11732		P002-03	P002-00/ /			ALL
D03999		P003-01	P003-00/ /			ALL
D03993		P007-01	P007-01/ /			ALL
D11810		P041-00	P041-00/ /			ALL
D11812		P041-00	P041-00/ /			ALL
<b>W0003</b>	<b>NB2</b>	<b>P3 - F/O INSTRUMENT PANEL</b>				
D40740J				D40740P	W0204	ALL
D03983A			*/*/*			ALL
D03983B			*/*/*			ALL
D03985A			*/*/*			ALL
D03985B			*/*/*			ALL
D03987A			*/*/*			ALL
D03987B			*/*/*			ALL
D40824J		AP0900A	POS 05	D40824P	W5514	ALL
D04237J		AP0900A	POS 06	D04237P	W2237	ALL
D40580J		AP0900A	POS 07	D40580P	W5160	ALL
D40924J		AP0900A	POS 14	D40924P	W2030	ALL
D46033J		AP0900A	POS 16	D46033P	W2383	ALL
D04251J		AP0900A	POS 23	D04251P	W2251	ALL
D10032J		AP0900A	POS 26	D10032P	W3706	ALL
D10034J		AP0900A	POS 27	D10034P	W3705	ALL
D10045		M01811	197/218/R007			ALL
D10047		M01811	197/218/R007			ALL
D10049		M01811	197/218/R007			ALL
D10051		M01811	197/218/R007			ALL
D10053		M01811	197/218/R007			ALL
D10055		M01811	197/218/R007			ALL
D10073		M01813	197/216/R007			ALL
D10075		M01813	197/216/R007			ALL
D10077		M01813	197/216/R007			ALL
D10079		M01813	197/216/R007			ALL
D10081		M01813	197/216/R007			ALL
D10083		M01813	197/216/R007			ALL
D00716		N00146	P003-03/ /			ALL
D02678		N00158	P003-01/ /			ALL
D02439		N00171	P003-01/ /			ALL
D02441		N00171	P003-01/ /			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W0000

Page 2

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
<b>W0003</b>	<b>NB2</b>	<b>P3 - F/O INSTRUMENT PANEL (continued)</b>				
D03983		N00190	P009-00/ /			ALL
D03985		N00191	P003-00/ /			ALL
D03987		N00192	P003-00/ /			ALL
D00895		P001-03	P001-00/ /			ALL
D00333		P002-02	P002-00/ /			ALL
D03991		P003-01	P003-00/ /			ALL
D01038		P003-04	P003-00/ /			ALL
D01205		P003-07	P003-00/ /			ALL
D03995		P007-02	P007-02/ /			ALL
D11842		P042-00	P042-00/ /			ALL
D11844		P042-00	P042-00/ /			ALL
<b>W0008</b>	<b>SN2</b>	<b>CONTROL STAND (PURCHASED BUNDLE: DWG NO. 254A1221)</b>				
D05148J		AF0213A	POS 01	D05148P	W6208	ALL
D11286P		AF0213A	POS 03	D11286J		YT113-YT120, YT132-YT133
D05150J		AF0213A	POS 04	D05150P	W6208	ALL
D11290P		AF0222A	POS 02	D11290J		YT113-YT120, YT132-YT133
D02487		AF0222A	POS 03	D00417		ALL
D03524		AF0222A	POS 05	D00698		ALL
D02485		R00384	P008-00/ /			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W0000

Page 3 End

Jun 21/2016





## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W0010	NN2	FWD GALLEY LIGHT MODULE (M01839)				
I D11400				D11398		ALL
I D11396		M01838	324/291/R023			ALL
I W0018	*	P18				
I D40218P		AP0600A	POS 09	D40218J	W0044	ALL
I D40198J		AP1800A	POS 01	D40198P	W3150	ALL
I D48901J		AP1800A	POS 02	D48901P	W3381	ALL
I D40840J		AP1800A	POS 03	D40840P	W2112	ALL
I D40524J		AP1800A	POS 04	D40524P	W2212	ALL
I D40538J		AP1800A	POS 05	D40538P	W2218	ALL
I D40220J		AP1800A	POS 06	D40220P	W3144	ALL
I D40298J		AP1800A	POS 07	D40298P	W4250	ALL
I D40504J		AP1800A	POS 08	D40504P	W2104	YT101-YT131
I D40514J		AP1800A	POS 09	D40514P	W2112	ALL
I D40522J		AP1800A	POS 10	D40522P	W2114	ALL
I D40687J		AP1800A	POS 12	D40687P	W3004	ALL
I D40504J		AP1800A	POS POS 08	D40504P		YT132-YT133
I D41805J		AP1800B	POS 01	D41805P	W2201	ALL
I D40576J		AP1800B	POS 02	D40576P	W5156	ALL
I D41801J		AP1800B	POS 03	D41801P	W2101	ALL
I D40802J		AP1800B	POS 05	D40802P	W5506	ALL
I D41803J		AP1800B	POS 06	D41803P	W2175	ALL
I D40830J		AP1800B	POS 07	D40830P	W5514	ALL
I D41807J		AP1800B	POS 08	D41807P	W2651	ALL
I D41809J		AP1800B	POS 09	D41809P	W2653	ALL
I D15512		R01070	256/263/L33			ALL
I D15514		R01073	258/262/L33			ALL
I D13241		R01093	P018-00/ /			YT101-YT120
I D13243		R01094	P018-00/ /			YT101-YT120
I D13245		R01095	P018-00/ /			YT101-YT120

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W0010

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W0026	LN1*	FORWARD LEFT WINDSCREEN				
I D11724				D11722		YT126-YT133

---

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W0020

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W0041	NA2	P61 - DATA LOADER CONTROL PANEL				
I D40769J				D40769P	W2597	YT104-YT133
I D06069			2J-1869/ /			YT101-YT120
I D06035			P061-00/ /			ALL
I D06045			P061-00/ /			ALL
I D06069			P061-00/ /			YT126-YT133
I D40067J		AP0600B	POS 01	D40067P	W2709	ALL
I D40623J		AP0600B	POS 06	D40623P	W2135	ALL
I D40625J		AP0600B	POS 13	D40625P	W2597	ALL
I D04151J		AP0600C	POS 06	D04151P	W3327	ALL
I D02269		M1206-P1				ALL
I D02271		M1206-P2				ALL
I D02875		P061-01	P061-01/ /			ALL
I D02877		P061-01	P061-01/ /			ALL
I D02879		P061-01	P061-01/ /			ALL
I D10193		P061-01	P061-01/ /			ALL
I D01907		P061-02	P061-02/ /			ALL
I D10901		P061-03	P061-03/ /			YT102-YT133
I D10903		P061-03	P061-03/ /			YT102-YT133
I D06053		P061-07	P061-00/ /			ALL
I D15906		R01141	P006-00/ /			YT105-YT133
I W0044	*	P6 (LOAD WIRES)				
I D40744J				D40744P	W0044	ALL
I D40744P				D40744J	W0044	ALL
I D13730			279/284/R010			ALL
I D40088J		AP0600A	POS 01	D40088P	W4258	ALL
I D40444J		AP0600A	POS 04	D40444P	W6214	ALL
I D40226J		AP0600A	POS 05	D40226P	W3058	YT101-YT131
I D40218J		AP0600A	POS 09	D40218P	W0018	ALL
I D40226J		AP0600A	POS POS 05	D40226P		YT132-YT133
I D40750J		AP0600B	POS 02	D40750P	W5158	ALL
I D40822J		AP0600B	POS 03	D40822P	W5514	ALL
I D46063J		AP0600B	POS 04	D46063P	W2169	ALL
I D41430J		AP0600B	POS 05	D41430P	W2138	ALL
I D41832J		AP0600B	POS 07	D41832P	W6412	ALL
I D40800J		AP0600B	POS 08	D40800P	W5506	ALL
I D40368J		AP0600B	POS 09	D40368P	W6110	ALL
I D46067J		AP0600B	POS 10	D46067P	W2231	ALL
I D46052J		AP0600B	POS 11	D46052P	W2030	ALL

### MASTER BUNDLE LIST

D280A351

91-21-13

Section W0040

Page 1

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
W0044	*	P6 (LOAD WIRES) (continued)				
D40812J		AP0600B	POS 12	D40812P	W6506	ALL
D40386J		AP0600B	POS 14	D40386P	W6412	ALL
D46065J		AP0600B	POS 15	D46065P	W2383	ALL
D40352J		AP0600B	POS 16	D40352P	W5612	ALL
D40820J		AP0600B	POS 17	D40820P	W6208	ALL
D40816J		AP0600B	POS 18	D40816P	W6206	ALL
D40708J		AP0600B	POS 19	D40708P	W6212	ALL
D46069J		AP0600B	POS 20	D46069P	W2661	ALL
D40574J		AP0600B	POS 21	D40574P	W6222	ALL
D40396J		AP0600B	POS 22	D40396P	W6414	ALL
D46061J		AP0600B	POS 23	D46061P	W2103	ALL
D40654J		AP0600B	POS 24	D40654P	W6024	ALL
D40502J		AP0600C	POS 01	D40502P	W2104	YT101-YT120
D40526J		AP0600C	POS 02	D40526P	W2212	ALL
D40512J		AP0600C	POS 03	D40512P	W2112	ALL
D40532J		AP0600C	POS 04	D40532P	W2216	ALL
D40550J		AP0600C	POS 05	D40550P	W2508	ALL
D40558J		AP0600C	POS 08	D40558P	W2510	ALL
D40536J		AP0600C	POS 09	D40536P	W2218	ALL
D40582J		AP0600C	POS 10	D40582P	W2204	ALL
D40502J		AP0600C	POS POS 01	D40502P	W2104	YT126-YT131
D40502J		AP0600C	POS POS 01	D40502P		YT132-YT133
D01598		M00564	265/ /			ALL
D10046		M01456	P006-00/ /			ALL
D11712		M01720	P006-00/ /			ALL
D11712A		M01720	P006-00/ /			ALL
D11712B		M01720	P006-00/ /			ALL
D11714		M01720	P006-00/ /			ALL
D11714A		M01720	P006-00/ /			ALL
D11714B		M01720	P006-00/ /			ALL
D12006		M1957				ALL
D13790		P061-08	P061-00/ /			ALL
D13792		P061-08	P061-00/ /			ALL
D00944		R00011	P006-00/ /			ALL
D01620		R00025	P006-00/ /			ALL
D01622		R00026	P006-00/ /			ALL
D01614		R00033	P006-00/ /			ALL
D01616		R00034	P006-00/ /			ALL
D01640		R00047	P006-00/ /			ALL
D01618		R00087	P006-00/ /			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W0040

Page 2

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
<b>W0044</b>	<b>*</b>	<b>P6 (LOAD WIRES) (continued)</b>				
I D01826		R00155	P006-00/ /			ALL
I D02118		R00191	P006-00/ /			ALL
I D10762		R00550	P006-00/ /			ALL
I D10820		R00556	P006-00/ /			ALL
I D10822		R00557	P006-00/ /			ALL
I D10824		R00558	P006-00/ /			ALL
I D11756		R00634	P006-00/ /			ALL
I D13712		R00918	P006-00/ /			ALL
I D11939		R00919	P006-00/ /			ALL
I D11941		R00920	P006-00/ /			ALL
I D13840		R00943	P006-00/ /			ALL
<b>W0048</b>	<b>NN2</b>	<b>P19 (EXTERNAL POWER RECEPTACLE PANEL)</b>				
I D06009			P019-00/ /			ALL
I D40665		DM0035	230/187/R034			ALL
<b>W0049</b>	<b>NA2</b>	<b>THRUST LEVER ENGINE NO. 1</b>				
I D08313J		AF0213A	POS 05	D08313P	W5369	ALL
I D10171J		AF0213A	POS 06	D10171P		ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W0040

Page 3 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W0051	NB2	TITLE THRUST LEVER ENGINE NO. 2				
I D08315J		AF0222A	POS 04	D08315P	W5457	ALL
I D10173J		AF0222A	POS 06	D10173P		ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W0050

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W0063	NN2	NITROGEN GEN SYS - OPERABILITY INDICATOR				
I D14112		P63				ALL
I W0066	RN2	J46 INTEGRATION PANEL WIRING				
I D46130J		AJ0046A	POS 01	D46130P	W5510	ALL
I D46110J		AJ0046A	POS 04	D46110P	W6208	ALL
I D46128J		AJ0046A	POS 05	D46128P	W5506	ALL
I D46144J		AJ0046A	POS 07	D46144P	W6170	ALL
I D46146J		AJ0046A	POS 08	D46146P	W6172	ALL
I D40103J		AJ0046A	POS 09	D40103P	W2247	ALL
I D46104J		AJ0046A	POS 11	D46104P	W5514	ALL
I D46150J		AJ0046A	POS 12	D46150P	W6208	ALL
I D46116J		AJ0046A	POS 13	D46116P	W5156	ALL
I D46102J		AJ0046A	POS 14	D46102P	W5160	ALL
I D46108J		AJ0046A	POS 15	D46108P	W2508	ALL
I D46122J		AJ0046A	POS 16	D46122P	W5160	ALL
I D46124J		AJ0046B	POS 01	D46124P	W2212	ALL
I D46138J		AJ0046B	POS 02	D46138P	W6242	ALL
I D46120J		AJ0046B	POS 03	D46120P	W5158	ALL
I D46132J		AJ0046B	POS 04	D46132P	W6506	ALL
I D46136J		AJ0046B	POS 05	D46136P	W6528	ALL
I D40097J		AJ0046B	POS 06	D40097P	W5503	ALL
I D46142J		AJ0046B	POS 08	D46142P	W6414	ALL
I D46118J		AJ0046B	POS 09	D46118P	W6510	ALL
I D46106J		AJ0046B	POS 10	D46106P	W6506	ALL
I D46100J		AJ0046B	POS 11	D46100P	W5158	ALL
I D46112J		AJ0046B	POS 12	D46112P	W2216	ALL
I D46126J		AJ0046B	POS 13	D46126P	W2510	ALL
I D46114J		AJ0046B	POS 15	D46114P	W2218	ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W0060

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W0072	RB2*	J20 JUNCTION BOX-PLATE B (CONTAINS ENGINE 2 WIRING)				
I D40634J		AJ0020B	POS 01	D40634P	W5158	ALL
I D40638J		AJ0020B	POS 02	D40638P	W5158	ALL
I D40640J		AJ0020B	POS 03	D40640P	W5158	ALL
I D40636J		AJ0020B	POS 04	D40636P	W5156	ALL
I D40632J		AJ0020B	POS 05	D40632P	W5100	ALL
I D40642J		AJ0020B	POS 07	D40642P	W5156	ALL
I D40858J		AJ0020D	POS 01	D40858P	W5158	ALL
I D02375		R00361	J020-0B/ /			ALL
I D10924		R00567	J020-0B/ /			ALL
I D11010		R00588	J020-0B/ /			ALL
I D11014		R00590	J020-0B/ /			ALL
I D11016		R00591	J020-0B/ /			ALL
I D11024		R00595	J020-0B/ /			ALL
I D11026		R00596	J020-0B/ /			ALL
I D11868		R00645	J020-0B/ /			ALL
I D12250		R00682	J020-0B/ /			ALL
I D10569		R00708	J020-0B/ /			ALL
I D10573		R00710	J020-0B/ /			ALL
I D10575		R00711	J020-0B/ /			ALL
I D10577		R00712	J020-0B/ /			ALL
I D10579		R00713	J020-0B/ /			ALL
I D10581		R00714	J020-0B/ /			ALL
I D12466		R00735	J020-00/ /			ALL
I D13794		R00934	J020-0B/166/L025			ALL
I D13796		R00936	J020-0B/166/L025			ALL
I D12759		R01046	J020-0B/ /			YT106-YT120
I W0074	NA1	J20 JUNCTION BOX-PLATE A				
I D40884J		AJ0020A	POS 02	D40884P	W5158	ALL
I D40878J		AJ0020C	POS 02	D40878P	W5156	ALL
I D13688		R00903	J020-00/ /			ALL
I D13690		R00904	J020-00/ /			ALL
I D13842		R00951	J020-00/ /			ALL
I W0076	LA2*	J22 JUNCTION BOX (CONTAINS ENGINE 1 WIRING)				
I D40678J		AJ0022	POS 01	D40678P	W5156	ALL
I D40672J		AJ0022	POS 02	D40672P	W5510	ALL
I D40666J		AJ0022	POS 03	D40666P	W5156	ALL
I D40670J		AJ0022	POS 04	D40670P	W5156	ALL

### MASTER BUNDLE LIST

D280A351

91-21-13

Section W0070

Page 1

Jun 21/2016





## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
<b>W0076</b>	<b>LA2*</b>	<b>J22 JUNCTION BOX (CONTAINS ENGINE 1 WIRING) (continued)</b>				
D40676J		AJ0022	POS 05	D40676P	W5156	ALL
D40668J		AJ0022	POS 06	D40668P	W5100	ALL
D40674J		AJ0022	POS 07	D40674P	W5506	ALL
D40680J		AJ0022	POS 08	D40680P	W5156	ALL
D40147J		AJ0022	POS 09	D40147P	W6491	ALL
D02775		R00454	J022-00/ /			ALL
D10634		R00477	J022-00/ /			ALL
D10636		R00478	J022-00/ /			ALL
D03527		R00495	J022-00/ /			ALL
D10918		R00564	J022-00/ /			ALL
D10922		R00566	J022-00/ /			ALL
D10954		R00576	J022-00/ /			ALL
D11002		R00584	J022-00/ /			ALL
D11008		R00587	J022-00/ /			ALL
D11012		R00589	J022-00/ /			ALL
D11018		R00592	J022-00/ /			ALL
D11020		R00593	J022-00/ /			ALL
D11022		R00594	J022-00/ /			ALL
D11404		R00627	J022-00/ /			ALL
D11406		R00628	J022-00/ /			ALL
D10571		R00709	J022-00/ /			ALL
D12538		R00737	J022-00/ /			ALL
D12756		R00742	J022-00/ /			ALL
D10849		R00746	J022-00/ /			ALL
D13130		R00783	J022-00/ /			ALL
<b>W0078</b>	<b>SB2*</b>	<b>J23 (J-BOX)</b>				
D40686J		AJ0023	POS 02	D40686P	W5506	ALL
D40688J		AJ0023	POS 05	D40688P	W5510	ALL
D02880		R00322	J023-00/ /			ALL
D02882		R00323	J023-00/ /			ALL
D02884		R00324	J023-00/ /			ALL
D10920		R00565	J023-00/ /			ALL
D02886		S00813	J023-00/ /			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W0070

Page 2 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W0080	RA2	J24 BOX				
I D40696J		AJ0024	POS 02	D40696P	W6510	ALL
I D40698J		AJ0024	POS 03	D40698P	W5100	ALL
I D40692J		AJ0024	POS 04	D40692P	W5158	ALL
I D40700J		AJ0024	POS 05	D40700P	W5158	ALL
I D40702J		AJ0024	POS 06	D40702P	W5158	ALL
I D40694J		AJ0024	POS 07	D40694P	W5160	ALL
I D01805		R00263	J024-00/ /			ALL
I D10638		R00479	J024-00/ /			ALL
I D10640		R00480	J024-00/ /			ALL
I D03529		R00496	J024-00/ /			ALL
I D10916		R00563	J024-00/ /			ALL
I D10926		R00568	J024-00/ /			ALL
I D10952		R00575	J024-00/ /			ALL
I D11004		R00585	J024-00/ /			ALL
I D11154		R00613	J024-00/ /			ALL
I D11402		R00626	J024-00/ /			ALL
I D11866		R00644	J024-00/ /			ALL
I D11874		R00648	J024-00/ /			ALL
I D11876		R00649	J024-00/ /			ALL
I D11878		R00650	J024-00/ /			ALL
I D12248		R00678	J024-00/ /			ALL
I D12602		R00731	J024-00/ /			ALL
I D12604		R00732	J024-00/ /			ALL
I D12540		R00738	J024-00/ /			ALL
I D12758		R00743	J024-00/ /			ALL
I D10847		R00745	J024-00/ /			ALL
I D13132		R00784	J024-00/ /			ALL
I D12225		R00945	J024-00/ /			ALL
I D12227		R00946	J024-00/ /			ALL
I D12229		R00949	J024-00/ /			ALL
I D14156		R01001	J024-00/ /			ALL
I W0082	NN2	J39 JUNCTION BOX-PLATE A				
I D43900J		AJ0039A	POS 01	D43900P	W5506	ALL
I D43910J		AJ0039A	POS 03	D43910P	W5367	ALL
I D43906J		AJ0039A	POS 04	D43906P	W5160	ALL
I D43908J		AJ0039A	POS 05	D43908P	W5375	ALL
I D13940		R00964	J039-00/ /			ALL
I D13942		R00965	J039-00/ /			ALL

### MASTER BUNDLE LIST

D280A351

91-21-13

Section W0080

Page 1

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
<b>W0082</b>	<b>NN2</b>	<b>J39 JUNCTION BOX-PLATE A (continued)</b>				
D13944		R00966	J039-00/ /			ALL
D13946		R00967	J039-00/ /			ALL
D13948		R00968	J039-00/ /			ALL
D13950		R00969	J039-00/ /			ALL
D13952		R00970	J039-00/ /			ALL
<b>W0084</b>	<b>NN2</b>	<b>J39 JUNCTION BOX-PLATE B</b>				
D43926J		AJ0039B	POS 01	D43926P	W6212	ALL
D43924J		AJ0039B	POS 02	D43924P	W6212	ALL
D43922J		AJ0039B	POS 03	D43922P	W3058	YT101-YT131
D43922J		AJ0039B	POS POS 03	D43922P		YT132-YT133
D11028		R00597	J039-00/ /			ALL
D14258		R01047	J039-00/ /			ALL
D14260		R01048	J039-00/ /			ALL
D12945		R01066	J039-00/ /			ALL
<b>W0088</b>	<b>LN2</b>	<b>J48 INTEGRATION PANEL WIRING</b>				
D48100J		AJ0048A	POS 01	D48100P	W2104	YT101-YT129
D48126J		AJ0048A	POS 02	D48126P	W5122	ALL
D48122J		AJ0048A	POS 03	D48122P	W5510	ALL
D40095J		AJ0048A	POS 04	D40095P	W2149	ALL
D48102J		AJ0048A	POS 05	D48102P	W2112	ALL
D48110J		AJ0048A	POS 07	D48110P	W5170	ALL
D40087J		AJ0048A	POS 08	D40087P	W5501	ALL
D48120J		AJ0048A	POS 09	D48120P	W5506	ALL
D48116J		AJ0048A	POS 13	D48116P	W5158	ALL
D48106J		AJ0048A	POS 14	D48106P	W2508	ALL
D48108J		AJ0048A	POS 15	D48108P	W2532	ALL
D48112J		AJ0048A	POS 16	D48112P	W5156	ALL
D48114J		AJ0048A	POS 17	D48114P	W5156	ALL
D48124J		AJ0048A	POS 18	D48124P	W6110	ALL
D48136J		AJ0048A	POS 19	D48136P	W5172	ALL
D48104J		AJ0048A	POS 20	D48104P	W2114	ALL
D48134J		AJ0048A	POS 21	D48134P	W5162	ALL
D48118J		AJ0048A	POS 22	D48118P	W5506	ALL
D48130J		AJ0048A	POS 23	D48130P	W6510	ALL
D47600J		AJ0048A	POS 24	D47600P	W5558	YT110-YT120, YT130-YT133

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W0080

Page 2

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
W0088	LN2	J48 INTEGRATION PANEL WIRING (continued)				
D48128J		AJ0048A	POS 24	D48128P	W6570	YT101-YT109, YT126-YT129
D48138J		AJ0048A	POS 25	D48138P	W6506	ALL
D48132J		AJ0048A	POS 26	D48132P	W6506	ALL
D48100J		AJ0048A	POS POS 01	D48100P	W2104	YT130-YT131
D48100J		AJ0048A	POS POS 01	D48100P		YT132-YT133

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W0080

Page 3 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W0094	RN2	J4 JUNCTION BOX				
I D40602J		AJ0004	POS 01	D40602P	W6222	ALL
D41002J		AJ0004	POS 02	D41002P	W3450	YT101-YT120
D41004J		AJ0004	POS 03	D41004P	W6212	YT101-YT120
I D40612J		AJ0004	POS 05	D40612P	W5160	ALL
I D40658J		AJ0004	POS 06	D40658P	W5160	ALL
I D40616J		AJ0004	POS 08	D40616P	W6222	ALL
I D40614J		AJ0004	POS 09	D40614P	W6222	ALL
I D40610J		AJ0004	POS 10	D40610P	W5160	ALL
I D40662J		AJ0004	POS 12	D40662P	W3453	ALL
I D10254		R00444	J004-00/ /			ALL
I D11997		R00924	J004-00/ /			ALL
I D13798		R00935	J004-00/167/R025			ALL
I D13800		R00937	J004-00/167/R025			ALL
I D13423		R01119	J004-00/ /			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W0090

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W0104	SN2	P7-CAPTAIN'S GLARESHIELD PANEL (SN2)				
I D40738P				D40738J	W0001	ALL
I D14118		L00340	P007-00/250/L012			ALL
I D14114		L00341	P007-00/ /			ALL
I D11922		L01013	P007-00/ /			ALL
I D11924		L01013	P007-00/ /			ALL
I D11936		L01099	P007-00/ /			ALL
I D11938		L01099	P007-00/ /			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W0100

Page 1 End

Jun 21/2016



**MASTER BUNDLE LIST**

D280A351

BOEING PROPRIETARY - Copyright © Unpublished Work - See title page for details



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
W0111	NN2	E1-1 SHELF (continued)				
D45113J		AE0101A	POS 19	D45113P	W5111	ALL
D41155J		AE0101A	POS 20	D41155P	W5161	ALL
D43211J		AE0101A	POS 21	D43211P	W5461	ALL
D46461J		AE0101A	POS 22	D46461P	W5461	ALL
D04075J		AE0101A	POS 23	D04075P	W5369	ALL
D41821J		AE0101A	POS 24	D41821P	W2175	ALL
D41125J		AE0101A	POS 25	D41125P	W5719	ALL
D04083J		AE0101A	POS 26	D04083P	W3381	ALL
D04073J		AE0101A	POS 27	D04073P	W5367	ALL
D40510J		AE0101A	POS 28	D40510P	W2218	ALL
D04069J		AE0101A	POS 29	D04069P	W2363	ALL
D40019J		AE0101A	POS 30	D40019P	W2221	ALL
D45203J		AE0101A	POS 31	D45203P	W5205	ALL
D04079J		AE0101A	POS 32	D04079P	W3377	ALL
D40774J		AE0101A	POS 33	D40774P	W6214	ALL
D41023J		AE0101A	POS 34	D41023P	W2031	YT104-YT133
D45515J		AE0101A	POS 35	D45515P	W5463	ALL
D45551J		AE0101A	POS 36	D45551P	W5381	ALL
D41563J		AE0101B	POS 01	D41563P	W5463	ALL
D40464J		AE0101B	POS 02	D40464P	W5160	ALL
D41161J		AE0101B	POS 03	D41161P	W5397	ALL
D40142J		AE0101B	POS 04	D40142P	W6166	ALL
D40063J		AE0101B	POS 05	D40063P	W5723	ALL
D40948J		AE0101B	POS 06	D40948P	W6166	ALL
D40818J		AE0101B	POS 07	D40818P	W6208	ALL
D41163J		AE0101B	POS 08	D41163P	W5463	ALL
D46023J		AE0101B	POS 09	D46023P	W2383	ALL
D43317J		AE0101B	POS 10	D43317P	W5723	ALL
D41147J		AE0101B	POS 11	D41147P	W5163	ALL
D41157J		AE0101B	POS 12	D41157P	W5163	ALL
D46013J		AE0101B	POS 13	D46013P	W2103	ALL
D40160J		AE0101B	POS 14	D40160P	W6588	ALL
D04611J		AE0101B	POS 15	D04611P	W4001	ALL
D04609J		AE0101B	POS 16	D04609P	W4001	ALL
D04615J		AE0101B	POS 17	D04615P	W4001	ALL
D04613J		AE0101B	POS 18	D04613P	W4001	ALL
D04619J		AE0101B	POS 19	D04619P	W5001	ALL
D04617J		AE0101B	POS 20	D04617P	W5001	ALL
D04623J		AE0101B	POS 21	D04623P	W5001	ALL
D04621J		AE0101B	POS 22	D04621P	W5001	ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W0110

Page 2

Jun 21/2016





## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
W0111	NN2	E1-1 SHELF (continued)				
D40064J		AE0101B	POS 23	D40064P	W2218	ALL
D41021J		AE0101B	POS 24	D41021P	W6208	YT101-YT120
D01153		M00652	E001-01/ /			ALL
D00235		M01474	E001-01/ /			ALL
D02209		M01474	E001-01/ /			ALL
D02743		M01485	E001-01/ /			ALL
D10740		M01654	E001-01/ /			ALL
D00728		M01746	E001-01/ /			ALL
D10135		M01875	E001-01/ /			ALL
D10161		M01908	/ /			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W0110

Page 3 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W0121	NA2	-800 E1-2 SHELF				
I D00149A			*/ */ *			ALL
I D00149B			*/ */ *			ALL
I D00149C			*/ */ *			ALL
I D00161A			*/ */ *			ALL
I D00161B			*/ */ *			ALL
I D00161C			*/ */ *			ALL
I D03623A			*/ */ *			ALL
I D03623B			*/ */ *			ALL
I D03623C			*/ */ *			ALL
I D10719A			*/ */ *			ALL
I D10719B			*/ */ *			ALL
I D10719C			*/ */ *			ALL
I D41211P		AE0102A	POS 01	D41211J	W5719	ALL
I D45115P		AE0102A	POS 02	D45115J	W5111	ALL
I D04029P		AE0102A	POS 03	D04029J	W2149	ALL
I D41217P		AE0102A	POS 04	D41217J	W2177	ALL
I D04205P		AE0102A	POS 05	D04205J	W2205	ALL
I D41827P		AE0102A	POS 06	D41827J	W2651	ALL
I D04269P		AE0102A	POS 08	D04269J	W5189	ALL
I D45201P		AE0102A	POS 10	D45201J	W5205	ALL
I D45002P		AE0102A	POS 11	D45002J	W5121	ALL
I D41213P		AE0102A	POS 12	D41213J	W5723	ALL
I D41127P		AE0102A	POS 13	D41127J	W5721	ALL
I D04607P		AE0102B	POS 01	D04607J	W5039	ALL
I D41215P		AE0102B	POS 02	D41215J	W5183	ALL
I D04121P		AE0102B	POS 04	D04121J	W7187	ALL
I D04603P		AE0102B	POS 05	D04603J	W5363	ALL
I D04025P		AE0102B	POS 07	D04025J	W3141	ALL
I D42941P		AE0102B	POS 08	D42941J	W3607	ALL
I D41251P		AE0104B	POS 01	D41251J	W0521	ALL
I D00149		M00163	E001-02/ /			ALL
I D00161		M00164	E001-02/ /			ALL
I D02473		M01346	E001-02/ /			ALL
I D02475		M01346	E001-02/ /			ALL
I D02477		M01346	E001-02/ /			ALL
I D03623		M01724	E001-02/ /			ALL
I D03781		M01726	309/180/R021			ALL
I D10163		M01908	/ /			ALL
I D10719		M02104	E001-02/ /			ALL
I D02115		R00315	306/180/R021			ALL

### MASTER BUNDLE LIST

D280A351

91-21-13

Section W0120

Page 1

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W0122	LN1	J11 RELAY PANEL - LANDING GEAR HYDRAULICS (WITH E-6)				
I D46618J		AJ0011	POS 01	D46618P	W5124	ALL
I D46616J		AJ0011	POS 02	D46616P	W5124	ALL
I D46623J		AJ0011	POS 03	D46623P	W5431	ALL
I D12968		R00782	J011-00/ /			ALL
I D11179		R00813	J011-00/ /			ALL
I D13364		R00850	J011-00/ /			ALL
I D15706		R01123	J011-00/ /			ALL
I D13187		R1069				ALL
I D03254		R353				ALL
I D11370		R625				ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W0120

Page 2 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W0131	NA2	E001-03 SHELF				
I D00199A			*/ */ *			ALL
I D00199B			*/ */ *			ALL
I D00199C			*/ */ *			ALL
I D01040A			*/ */ *			ALL
I D01040B			*/ */ *			ALL
I D01040C			*/ */ *			ALL
I D02639A			*/ */ *			ALL
I D02639B			*/ */ *			ALL
I D02639C			*/ */ *			ALL
I D04133J		AE0103A	POS 02	D04133P	W5413	ALL
I D46051J		AE0103A	POS 03	D46051P	W2661	ALL
I D43048J		AE0103A	POS 04	D43048P	W6730	ALL
I D41400J		AE0103A	POS 06	D41400P	W2022	ALL
I D43040J		AE0103A	POS 07	D43040P	W6528	ALL
I D40488J		AE0103A	POS 08	D40488P	W5158	ALL
I D41337J		AE0103A	POS 09	D41337P	W3307	ALL
I D40344J		AE0103A	POS 10	D40344P	W5610	ALL
I D40498J		AE0103A	POS 11	D40498P	W5156	ALL
I D04123J		AE0103A	POS 12	D04123P	W5107	ALL
I D04149J		AE0103A	POS 13	D04149P	W2307	ALL
I D40466J		AE0103A	POS 14	D40466P	W5160	ALL
I D43010J		AE0103A	POS 15	D43010P	W5234	ALL
I D45227J		AE0103A	POS 16	D45227P	W3477	ALL
I D41831J		AE0103A	POS 17	D41831P	W2651	ALL
I D04195J		AE0103A	POS 18	D04195P	W5189	ALL
I D41509J		AE0103A	POS 19	D41509P	W5719	ALL
I D40810J		AE0103A	POS 20	D40810P	W6506	ALL
I D04181J		AE0103A	POS 21	D04181P	W3311	ALL
I D41131J		AE0103A	POS 22	D41131P	W5723	ALL
I D02639		M00063	E001-03/ /			ALL
I D00199		M00149	E001-03/ /			ALL
I D01040		M00162	E001-03/ /			ALL
I W0132	NN2	EMERGENCY AISLE LIGHTS - LED				
I D14816			MULTI/ /			ALL
I D14814		L01507	MULTI/ /			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W0130

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W0141	NB2	E1-4 SHELF - RIGHT				
I D10137A			*/ */ *			ALL
I D10137B			*/ */ *			ALL
I D10137C			*/ */ *			ALL
I D10721A			*/ */ *			ALL
I D10721B			*/ */ *			ALL
I D10721C			*/ */ *			ALL
I D03625A			E001-04/ /			ALL
I D03625B			E001-04/ /			ALL
I D03625C			E001-04/ /			ALL
I D42943P		AE0102B	POS 03	D42943J	W3609	ALL
I D04027P		AE0102B	POS 06	D04027J	W3143	ALL
I D08019P		AE0104A	POS 01	D08019J	W2465	ALL
I D05971P		AE0104A	POS 02	D05971J	W5457	ALL
I D04081P		AE0104A	POS 03	D04081J	W3379	ALL
I D45143P		AE0104A	POS 05	D45143J	W5121	ALL
I D04311P		AE0104A	POS 06	D04311J	W2251	ALL
I D40049P		AE0104A	POS 07	D40049J	W2205	ALL
I D40047P		AE0104A	POS 08	D40047J	W5723	ALL
I D46011P		AE0104A	POS 09	D46011J	W2103	ALL
I D46031P		AE0104A	POS 10	D46031J	W2383	ALL
I D41463P		AE0104A	POS 11	D41463J	W5463	ALL
I D45123P		AE0104A	POS 12	D45123J	W5121	ALL
I D45553P		AE0104A	POS 13	D45553J	W5383	ALL
I D40560P		AE0104A	POS 14	D40560J	W2510	ALL
I D04077P		AE0104A	POS 15	D04077J	W5375	ALL
I D04273P		AE0104A	POS 17	D04273J	W5191	ALL
I D41129P		AE0104A	POS 18	D41129J	W5721	ALL
I D40806P		AE0104A	POS 19	D40806J	W5506	ALL
I D40490P		AE0104A	POS 20	D40490J	W5158	ALL
I D40496P		AE0104A	POS 21	D40496J	W5510	ALL
I D43016P		AE0104A	POS 22	D43016J	W5526	ALL
I D40556P		AE0104A	POS 23	D40556J	W2508	ALL
I D40332P		AE0104A	POS 26	D40332J	W5204	ALL
I D40826P		AE0104A	POS 27	D40826J	W5514	ALL
I D40346P		AE0104A	POS 28	D40346J	W5610	ALL
I D45517P		AE0104B	POS 02	D45517J	W5463	ALL
I D41453P		AE0104B	POS 03	D41453J	W0523	ALL
I D00742		M00237	E001-04/ /			ALL
I D03625		M01725	E001-04/ /			ALL
I D03787		M01727	302/180/R020			ALL

### MASTER BUNDLE LIST

D280A351

91-21-13

Section W0140

Page 1

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
<b>W0141</b>	<b>NB2</b>	<b>E1-4 SHELF - RIGHT (continued)</b>				
D10137		M01876	E001-04/ /			ALL
D10721		M02105	E001-04/ /			ALL
D02123		R00316	300/178/R022			ALL
<b>W0142</b>	<b>LN2</b>	<b>FWD ENTRY LIGHT PANEL</b>				
D41082J				D41082P	W3058	YT101-YT131
D41082J			346/290/R010	D41082P		YT132-YT133
D03160		L01086	304/288/R002			ALL
D14774		M02810	314/289/L010			ALL
<b>W0144</b>	<b>NN2</b>	<b>FWD RECESSED LIGHT PANEL</b>				
D41088J				D41088P	W4166	ALL
<b>W0145</b>	<b>LA2</b>	<b>CAPT CONTROL SHAKER</b>				
D00281		M00232	210/220/L020			ALL
<b>W0147</b>	<b>RB2</b>	<b>F/O CONTROL SHAKER</b>				
D00367		M00424	210/220/R020			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W0140

Page 2 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
<b>I W0151</b>	<b>NB2</b>	<b>E1-5 SHELF</b>				
I D00155A			*/ */ *			ALL
I D00155B			*/ */ *			ALL
I D00155C			*/ */ *			ALL
I D00169A			*/ */ *			ALL
I D00169B			*/ */ *			ALL
I D00169C			*/ */ *			ALL
I D00201A			*/ */ *			ALL
I D00201B			*/ */ *			ALL
I D00201C			*/ */ *			ALL
I D04125P		AE0105A	POS 01	D04125J	W5107	ALL
I D04031P		AE0105A	POS 02	D04031J	W2151	ALL
I D41507P		AE0105A	POS 03	D41507J	W5723	ALL
I D04197P		AE0105A	POS 04	D04197J	W5191	ALL
I D41557P		AE0105A	POS 07	D41557J	W5163	ALL
I D41517P		AE0105A	POS 08	D41517J	W2247	ALL
I D45125P		AE0105A	POS 09	D45125J	W5121	ALL
I D41511P		AE0105A	POS 11	D41511J	W5099	ALL
I D41515P		AE0105A	POS 12	D41515J	W5185	ALL
I D04131P		AE0105A	POS 13	D04131J	W5411	ALL
I D00201		M00150	E001-05/ /			ALL
I D00169		M00165	E001-05/ /			ALL
I D00155		M00381	E001-05/ /			ALL
I D02849		M01347	E003-03/ /			ALL
I D02851		M01347	E003-03/ /			ALL
I D02853		M01347	E003-03/ /			ALL
I D02705		S00942	316/163/L025			ALL
I D02711		S00943	316/163/L025			ALL
<b>I W0152</b>	<b>SN2</b>	<b>AFT ENTRY LIGHT PANEL</b>				
I D40026J				D40026P	W3058	YT101-YT131
I D40032J				D40032P	W7359	ALL
I D40026J			949/290/R016	D40026P		YT132-YT133
I D06015			988/289/L000			ALL
I D10180		L01223	964/287/0000			ALL
I D11368		M01834	MULTI/ /			ALL
I D11480		M01834	MULTI/ /			ALL
I D14776		M02811	978/290/0			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W0150

Page 1

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W0156	NN1	FORWARD COVE LIGHTS				
I D41072J				D41072P	W3058	YT101-YT120
I D41072J			345/290/L010	D41072P	W3058	YT126-YT131
I D41072J			345/290/L010	D41072P		YT132-YT133
I D14478		M02806	MULTI/290/			ALL
I D14634		M02806	MULTI/290/			ALL
I D14650		M02806	MULTI/290/			ALL
I D14474		M02809	MULTI/290/			ALL
I D14610		M02809	MULTI/290/			ALL
I D14630		M02809	MULTI/290/			ALL
I W0158	NN1	AFT COVE LIGHTS - PANEL 1				
I D14546				D14550		ALL
I D14792				D14790		ALL
I D41074J				D41074P	W3058	YT101-YT120
I D41074J			910/290/L013	D41074P	W3058	YT126-YT131
I D41074J			910/290/L013	D41074P		YT132-YT133
I D14654		M02806	MULTI/290/			ALL
I D14540		M02807	MULTI/290/			ALL
I D14544		M02808	931/290/10			ALL
I D14568		M02808	931/290/10			ALL
I D14614		M02808	931/290/10			ALL
I D14626		M02808	931/290/10			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W0150

Page 2 End

Jun 21/2016





## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W0160	NN1	AFT COVE LIGHTS - PANEL 2				
I D14550				D14546		ALL
I D14790				D14792		ALL
I D41078J				D41078P	W3058	YT101-YT131
I D41078J			982/297/L014	D41078P		YT132-YT133
I D14788		M02808	931/290/10			ALL
I D14552		M02809	MULTI/290/			ALL
I D14556		M02809	MULTI/290/			ALL
I D14560		M02809	MULTI/290/			ALL
I D14564		M02809	MULTI/290/			ALL
I D14618		M02809	MULTI/290/			ALL
I D14622		M02809	MULTI/290/			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W0160

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W0204	SN2	P7 FIRST OFFICER'S GLARESHIELD PANEL (SN2)				
I D40740P				D40740J	W0003	ALL
I D11926		L00050	P007-00/ /			ALL
I D11928		L00050	P007-00/ /			ALL
I D14116		L00344	P007-00/ /			ALL
I D14120		L00345	P007-00/250/R012			ALL
I D11940		L01100	P007-00/ /			ALL
I D11942		L01100	P007-00/ /			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W0200

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W0210	LA2	E2-1 SHELF (WINDOW HEAT MODULES) LA2				
D01042A			E002-01/ /			YT101-YT116, YT126-YT131
D01042B			E002-01/ /			YT101-YT116, YT126-YT131
D01044A			E002-01/ /			YT101-YT116, YT126-YT131
D01044B			E002-01/ /			YT101-YT116, YT126-YT131
I D41432J		AE0201A	POS 15	D41432P	W2138	ALL
I D40070J		AE0201A	POS 20	D40070P	W2108	ALL
I D40518J		AE0201A	POS 21	D40518P	W2112	ALL
D01042		M00320	E002-01/ /			YT101-YT116, YT126-YT131
D01044		M00321	E002-01/ /			YT101-YT116, YT126-YT131
I D16230		M00321	E002-01/ /			YT117-YT120, YT132-YT133
I W0212	*	E2-1 SHELF				
I D49996J		AE0201A	POS 01	D49996P	W5112	ALL
I D40934J		AE0201A	POS 02	D40934P	W5112	ALL
I D40342J		AE0201A	POS 03	D40342P	W5112	ALL
I D40564J		AE0201A	POS 05	D40564P	W2702	ALL
I D40910J		AE0201A	POS 06	D40910P	W5726	ALL
I D40254J		AE0201A	POS 07	D40254P	W5726	ALL
I D40428J		AE0201A	POS 08	D40428P	W5510	ALL
I D40926J		AE0201A	POS 09	D40926P	W5726	ALL
I D40598J		AE0201A	POS 10	D40598P	W2112	ALL
I D40260J		AE0201A	POS 12	D40260P	W5110	ALL
I D40372J		AE0201A	POS 13	D40372P	W6210	ALL
I D40132J		AE0201A	POS 16	D40132P	W5164	ALL
I D40718J		AE0201A	POS 17	D40718P	W5164	ALL
I D40358J		AE0201A	POS 18	D40358P	W5612	ALL
I D40340J		AE0201A	POS 19	D40340P	W5110	ALL
I D40258J		AE0201A	POS 23	D40258P	W5568	ALL
I D40256J		AE0201A	POS 4	D40256P	W5112	ALL
I D10890		G00010	E002-01/ /			ALL
I D10890A		G00010	E002-01/ /			ALL
I D10896		G00014	E002-01/ /			ALL

### MASTER BUNDLE LIST

D280A351

91-21-13

Section W0210

Page 1

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
W0212	*	E2-1 SHELF (continued)				
D10896A		G00014	E002-01/ /			ALL
D10896B		G00014	E002-01/ /			ALL
D10890B		GD00010	378/168/R047			ALL
D00102		T00011	E002-01/ /			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W0210

Page 2 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W0220	LA2	E2-2 SHELF				
I D10738A			E002-02/ /			ALL
I D10738B			E002-02/ /			ALL
I D10738C			E002-02/ /			ALL
I D11114		AE0202A				ALL
I D11114A		AE0202A				ALL
I D11114B		AE0202A				ALL
I D11114C		AE0202A				ALL
I D11478		AE0202A				ALL
I D11478A		AE0202A				ALL
I D11478B		AE0202A				ALL
I D40246J		AE0202A	POS 01	D40246P	W5104	ALL
I D40586J		AE0202A	POS 02	D40586P	W5248	ALL
I D40942J		AE0202A	POS 03	D40942P	W5726	ALL
I D40928J		AE0202A	POS 04	D40928P	W5726	ALL
I D40656J		AE0202A	POS 05	D40656P	W7592	ALL
I D43050J		AE0202A	POS 06	D43050P	W6730	ALL
I D40136J		AE0202A	POS 07	D40136P	W5564	ALL
I D40138J		AE0202A	POS 08	D40138P	W5168	ALL
I D40456J		AE0202A	POS 09	D40456P	W5156	ALL
I D40348J		AE0202A	POS 10	D40348P	W5610	ALL
I D40506J		AE0202A	POS 11	D40506P	W2104	YT101-YT131
I D40506J		AE0202A	POS 11	D40506P		YT132-YT133
I D40520J		AE0202A	POS 12	D40520P	W2112	ALL
I D43084J		AE0202A	POS 13	D43084P	W5230	YT101-YT119, YT126-YT131 YT132-YT133
I D43084J		AE0202A	POS 13	D43084P		YT132-YT133
I D40118J		AE0202A	POS 14	D40118P	W5566	ALL
I D40430J		AE0202A	POS 15	D40430P	W5506	ALL
I D40360J		AE0202A	POS 16	D40360P	W5612	ALL
I D43060J		AE0202A	POS 17	D43060P	W6128	YT101-YT119, YT126-YT131 YT132-YT133
I D43060J		AE0202A	POS 17	D43060P		YT132-YT133
I D41012J		AE0202A	POS 18	D41012P	W6214	ALL
I D43008J		AE0202A	POS 19	D43008P	W5134	ALL
I D40240J		AE0202A	POS 20	D40240P	W6102	ALL
I D40012J		AE0202A	POS 21	D40012P	W7594	ALL
I D40912J		AE0202A	POS 22	D40912P	W5726	ALL
I D40946J		AE0202A	POS 23	D40946P	W5726	ALL
I D40450J		AE0202A	POS 24	D40450P	W5310	ALL
I D40130J		AE0202A	POS 25	D40130P	W5162	ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W0220

Page 1

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
<b>W0220</b>	<b>LA2</b>	<b>E2-2 SHELF (continued)</b>				
I D40380J		AE0202A	POS 26	D40380P	W6214	ALL
I D40126J		AE0202A	POS 27	D40126P	W3170	ALL
I D40724J		AE0202A	POS 28	D40724P	W5156	ALL
I D43024J		AE0202A	POS 29	D43024P	W5728	ALL
I D40646J		AE0202A	POS 30	D40646P	W2110	ALL
I D46022J		AE0202A	POS 31	D46022P	W2110	ALL
I D42014J		AE0202A	POS 32	D42014P	W5088	ALL
I D41840J		AE0202A	POS 33	D41840P	W5094	ALL
I D43084J		AE0202A	POS POS 13	D43084P		YT120
I D43060J		AE0202A	POS POS 17	D43060P		YT120
I D00998		M00279	E002-02/ /			ALL
I D01000		M00279	E002-02/ /			ALL
I D01002		M00279	E002-02/ /			ALL
I D10738		M01653	E002-02/ /			ALL
<b>W0224</b>	<b>RN1</b>	<b>MEDICAL OUTLET</b>				
I D13669			855/237/L068			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W0220

Page 2 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W0311	NA2	E3-1 ELECTRONIC SHELF - LEFT				
I D03651A			E003-01/ /			ALL
I D03651B			E003-01/ /			ALL
I D03651C			E003-01/ /			ALL
I D03667A			E003-01/ /			ALL
I D03667B			E003-01/ /			ALL
I D03667C			E003-01/ /			ALL
I D03973A			E003-01/ /			ALL
I D03973B			E003-01/ /			ALL
I D03973C			E003-01/ /			ALL
I D03973D			E003-01/ /			ALL
I D03973E			E003-01/ /			ALL
I D03973F			E003-01/ /			ALL
I D04271J		AE0301A	POS 01	D04271P	W5189	ALL
I D42163J		AE0301A	POS 02	D42163P	W5273	ALL
I D42026J		AE0301A	POS 03	D42026P	W5610	YT104-YT133
I D40101J		AE0301A	POS 04	D40101P	W2527	ALL
I D40301J		AE0301A	POS 05	D40301P	W2531	ALL
I D04267J		AE0301A	POS 06	D04267P	W2207	ALL
I D45111J		AE0301A	POS 07	D45111P	W5111	ALL
I D45131J		AE0301A	POS 08	D45131P	W5111	ALL
I D45151J		AE0301A	POS 09	D45151P	W5111	ALL
I D40448J		AE0301A	POS 11	D40448P	W5310	ALL
I D42005J		AE0301A	POS 12	D42005P	W2265	ALL
I D49994J		AE0301A	POS 14	D49994P	W3170	ALL
I D43145J		AE0301A	POS 15	D43145P	W5161	ALL
I D43155J		AE0301A	POS 16	D43155P	W5161	ALL
I D45205J		AE0301A	POS 18	D45205P	W5205	ALL
I D40460J		AE0301A	POS 19	D40460P	W5156	ALL
I D40516J		AE0301A	POS 20	D40516P	W2112	ALL
I D41817J		AE0301A	POS 21	D41817P	W2201	ALL
I D41837J		AE0301A	POS 22	D41837P	W2653	ALL
I D42047J		AE0301A	POS 26	D42047P	W5047	YT104-YT133
I D03651		M01731	E003-01/ /			ALL
I D03667		M01735	E003-01/ /			ALL
I D03973		M01808	E003-01/ /			ALL
I W0313	NB2	E3-1 ELECTRONIC SHELF - RIGHT				
I D03653A			E003-01/ /			ALL
I D03653B			E003-01/ /			ALL

### MASTER BUNDLE LIST

D280A351

91-21-13

Section W0310

Page 1

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
W0313	NB2	E3-1 ELECTRONIC SHELF - RIGHT (continued)				
D03653C			E003-01/ /			ALL
D03975A			E003-01/ /			ALL
D03975B			E003-01/ /			ALL
D03975C			E003-01/ /			ALL
D03975D			E003-01/ /			ALL
D03975E			E003-01/ /			ALL
D03975F			E003-01/ /			ALL
D46017J		AE0301A	POS 23	D46017P	W2231	ALL
D46035J		AE0301A	POS 24	D46035P	W2169	ALL
D42007J		AE0301A	POS 25	D42007P	W2267	ALL
D40544J		AE0301A	POS 27	D40544P	W2218	ALL
D43147J		AE0301A	POS 28	D43147P	W5163	ALL
D43157J		AE0301A	POS 29	D43157P	W5163	ALL
D04297J		AE0301A	POS 31	D04297P	W2237	ALL
D45121J		AE0301A	POS 32	D45121P	W5121	ALL
D45141J		AE0301A	POS 33	D45141P	W5121	ALL
D40394J		AE0301A	POS 34	D40394P	W6412	ALL
D40149J		AE0301A	POS 35	D40149P	W6491	ALL
D40732J		AE0301A	POS 36	D40732P	W4170	ALL
D04277J		AE0301A	POS 37	D04277P	W5191	ALL
D42165J		AE0301A	POS 38	D42165P	W5275	ALL
D42049J		AE0301A	POS 39	D42049P	W5049	YT104-YT133
D40201J		AE0301A	POS 40	D40201P	W2529	ALL
D40401J		AE0301A	POS 41	D40401P	W2533	ALL
D03653		M01732	E003-01/ /			ALL
D03975		M01809	E003-01/ /			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W0310

Page 2 End

Jun 21/2016





## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W0321	NN2	E3-2 SHELF				
I D01458A			*/*/*			ALL
I D01458B			*/*/*			ALL
I D02295A			*/*/*			ALL
I D02295B			*/*/*			ALL
I D02295C			*/*/*			ALL
I D02295D			*/*/*			ALL
I D02295E			*/*/*			ALL
I D02295F			*/*/*			ALL
I D03228A			*/*/*			ALL
I D03228B			*/*/*			ALL
I D03228C			*/*/*			ALL
I D03683A			*/*/*			ALL
I D03683B			*/*/*			ALL
I D03685A			*/*/*			ALL
I D03685B			*/*/*			ALL
I D43217J		AE0302A	POS 01	D43217P	W5461	ALL
I D40053J		AE0302A	POS 02	D40053P	W5367	ALL
I D49002J		AE0302A	POS 03	D49002P	W2031	YT104-YT133
I D40446J		AE0302A	POS 04	D40446P	W5310	ALL
I D40362J		AE0302A	POS 05	D40362P	W5612	ALL
I D40350J		AE0302A	POS 06	D40350P	W5610	ALL
I D40940J		AE0302A	POS 07	D40940P	W5610	ALL
I D40023J		AE0302A	POS 08	D40023P	W2705	ALL
I D43215J		AE0302A	POS 09	D43215P	W2805	YT101-YT103
I D40025J		AE0302A	POS 10	D40025P	W3377	ALL
I D43203J		AE0302A	POS 11	D43203P	W5603	YT101-YT103, YT126-YT131
I D43257J		AE0302A	POS 12	D43257P	W5257	ALL
I D43219J		AE0302A	POS 13	D43219P	W2419	ALL
I D45207J		AE0302A	POS 14	D45207P	W5205	ALL
I D40950J		AE0302A	POS 15	D40950P	W5506	ALL
I D40594J		AE0302A	POS 16	D40594P	W5156	ALL
I D43215J		AE0302A	POS 17	D43215P	W2805	YT104-YT133
I D45177J		AE0302A	POS 17	D45177P	W5111	YT101-YT103
I D45157J		AE0302A	POS 18	D45157P	W5111	ALL
I D45137J		AE0302A	POS 19	D45137P	W5111	ALL
I D45117J		AE0302A	POS 20	D45117P	W5111	ALL
I D40021J		AE0302A	POS 21	D40021P	W2705	ALL
I D43054J		AE0302A	POS 22	D43054P	W6732	ALL
I D40462J		AE0302A	POS 23	D40462P	W5156	ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W0320

Page 1

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
<b>W0321</b>	<b>NN2</b>	<b>E3-2 SHELF (continued)</b>				
D43022J		AE0302A	POS 24	D43022P	W5530	ALL
D46021J		AE0302A	POS 25	D46021P	W2231	ALL
D41839J		AE0302A	POS 26	D41839P	W2653	ALL
D41819J		AE0302A	POS 27	D41819P	W2201	ALL
D40426J		AE0302A	POS 28	D40426P	W5158	ALL
D45102J		AE0302A	POS 29	D45102P	W5121	ALL
D46043J		AE0302A	POS 30	D46043P	W2169	ALL
D40596J		AE0302A	POS 31	D40596P	W2112	ALL
D43046J		AE0302A	POS 32	D43046P	W6530	ALL
D40486J		AE0302A	POS 33	D40486P	W5158	ALL
D40027J		AE0302A	POS 34	D40027P	W2709	ALL
D40029J		AE0302A	POS 35	D40029P	W3379	ALL
D40468J		AE0302A	POS 36	D40468P	W5160	ALL
D40470J		AE0302A	POS 37	D40470P	W5160	ALL
D43205J		AE0302A	POS 38	D43205P	W5605	ALL
D40194J		AE0302A	POS 39	D40194P	W6134	ALL
D43261J		AE0302A	POS 40	D43261P	W5461	ALL
D42261J		AE0302A	POS 41	D42261P	W5461	ALL
D40952J		AE0302A	POS 42	D40952P	W5160	ALL
D42361J		AE0302A	POS 43	D42361P	W5461	ALL
D43263J		AE0302A	POS 44	D43263P	W5463	ALL
D40392J		AE0302A	POS 45	D40392P	W6412	ALL
D45127J		AE0302A	POS 46	D45127P	W5121	ALL
D42053J		AE0302A	POS 47	D42053P	W5375	ALL
D40276J		AE0302A	POS 48	D40276P	W6134	ALL
D43209J		AE0302A	POS 49	D43209P	W5409	ALL
D40232J		AE0302A	POS 50	D40232P	W2709	ALL
D43030J		AE0302A	POS 51	D43030P	W6034	ALL
D40908J		AE0302A	POS 52	D40908P	W5726	ALL
D42363J		AE0302A	POS 53	D42363P	W5463	ALL
D43080J		AE0302A	POS 54	D43080P	W6412	ALL
D43241J		AE0302A	POS 55	D43241P	W2201	YT101-YT103
D45147J		AE0302A	POS 56	D45147P	W5121	ALL
D40710J		AE0302A	POS 57	D40710P	W5047	YT104-YT133
D45006J		AE0302A	POS 59	D45006P	W5049	YT104-YT133
D49001J		AE0302A	POS 63	D49001P	W5049	YT104-YT133
D43203J		AE0302A	POS POS 11	D43203P	W5603	YT104-YT119
D43203J		AE0302A	POS POS 11	D43203P		YT120, YT132-YT133
D02295		M00675	E003-02/ /			ALL
D03669		M01736	E003-02/ /			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W0320

Page 2

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
W0321	NN2	E3-2 SHELF (continued)				
D03669A		M01736	E003-02/ /			ALL
D03669B		M01736	E003-02/ /			ALL
D03669C		M01736	E003-02/ /			ALL
D03228		M1240				ALL
D03683		M1747				ALL
D03685		M1748				ALL
D01458		M528				ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W0320

Page 3 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
<b>W0330</b>	<b>NB2</b>	<b>E3-3 SHELF (ZONE TEMP CONTROL) NB2</b>				
D41822J		AE0303A	POS 05	D41822P	W6412	YT104-YT133
D43056J		AE0303A	POS 10	D43056P	W5047	YT116-YT120, YT132-YT133
D41826J		AE0303A	POS 11	D41826P	W2218	YT104-YT133
D41800J		AE0303A	POS 24	D41800P	W5104	YT101-YT103
D41814J		AE0303A	POS 25	D41814P	W6214	ALL
D41802J		AE0303A	POS 26	D41802P	W6220	ALL
D41842J		AE0303A	POS 27	D41842P	W5526	ALL
D41824J		AE0303A	POS 30	D41824P	W5156	ALL
D41836J		AE0303A	POS 31	D41836P	W5104	ALL
D41818J		AE0303A	POS 32	D41818P	W6288	YT101-YT103
D41822J		AE0303A	POS 35	D41822P	W6412	YT101-YT103
D41826J		AE0303A	POS 36	D41826P	W2218	YT101-YT103
D41808J		AE0303A	POS 37	D41808P	W6420	ALL
D41812J		AE0303A	POS 40	D41812P	W2216	ALL
D41806J		AE0303A	POS 41	D41806P	W6230	ALL
D41818J		AE0303A	POS 46	D41818P	W6288	YT104-YT133
D03858		M01442	E003-03/ /			YT101-YT115, YT126-YT131
D03858A		M01442	E003-03/ /			YT101-YT115, YT126-YT131
D03858B		M01442	E003-03/ /			YT101-YT115, YT126-YT131
D03858C		M01442	E003-03/ /			YT101-YT115, YT126-YT131
D03860		M01443	E003-03/ /			YT101-YT115, YT126-YT131
D03860A		M01443	E003-03/ /			YT101-YT115, YT126-YT131
D03860B		M01443	E003-03/ /			YT101-YT115, YT126-YT131
D03860C		M01443	E003-03/ /			YT101-YT115, YT126-YT131
D15814		M02951	E003-03/ /			YT116-YT120, YT132-YT133
D15814A		M02951	E003-03/ /			YT116-YT120, YT132-YT133
D15814B		M02951	E003-03/ /			YT116-YT120, YT132-YT133

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W0330

Page 1

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
<b>W0330</b>	<b>NB2</b>	<b>E3-3 SHELF (ZONE TEMP CONTROL) NB2 (continued)</b>				
D15814C		M02951	E003-03/ /			YT116-YT120, YT132-YT133
D15816		M02952	E003-03/ /			YT116-YT120, YT132-YT133
D15816A		M02952	E003-03/ /			YT116-YT120, YT132-YT133
D15816B		M02952	E003-03/ /			YT116-YT120, YT132-YT133
D15816C		M02952	E003-03/ /			YT116-YT120, YT132-YT133
<b>W0331</b>	<b>NA2</b>	<b>E3-3 SHELF BUNDLE</b>				
D02643B			/ /			ALL
D00539A			*/*/*			ALL
D00539B			*/*/*			ALL
D00539C			*/*/*			ALL
D02643A			E003-03/ /			ALL
D02643C			E003-03/ /			ALL
D43301J		AE0303A	POS 01	D43301P	W5415	ALL
D43039J		AE0303A	POS 04	D43039P	W5121	ALL
D43306J		AE0303A	POS 05	D43306P	W5723	YT101-YT103
D43359J		AE0303A	POS 06	D43359P	W5103	ALL
D43367J		AE0303A	POS 07	D43367P	W5107	YT104-YT133
D43391J		AE0303A	POS 07	D43391P	W2417	YT101-YT103
D43314J		AE0303A	POS 08	D43314P	W5107	ALL
D43361J		AE0303A	POS 10	D43361P	W5105	YT101-YT103
D43367J		AE0303A	POS 11	D43367P	W5107	YT101-YT103
D43307J		AE0303A	POS 12	D43307P	W5111	ALL
D43321J		AE0303A	POS 13	D43321P	W5111	ALL
D43329J		AE0303A	POS 15	D43329P	W2417	ALL
D43345J		AE0303A	POS 17	D43345P	W5331	ALL
D43347J		AE0303A	POS 18	D43347P	W5331	ALL
D43305J		AE0303A	POS 20	D43305P	W5111	ALL
D43049J		AE0303A	POS 22	D43049P	W5461	ALL
D43391J		AE0303A	POS 24	D43391P	W2417	YT104-YT133
D43313J		AE0303A	POS 28	D43313P	W2201	ALL
D43309J		AE0303A	POS 29	D43309P	W2231	YT101-YT103
D43355J		AE0303A	POS 32	D43355P	W2415	YT104-YT133
D43363J		AE0303A	POS 33	D43363P	W2413	YT104-YT133

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W0330

Page 2

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
<b>W0331</b>	<b>NA2</b>	<b>E3-3 SHELF BUNDLE (continued)</b>				
D43361J		AE0303A	POS 34	D43361P	W5105	YT104-YT133
D43139J		AE0303A	POS 36	D43139P	W5049	YT104-YT133
D43331J		AE0303A	POS 38	D43331P	W5191	ALL
D43323J		AE0303A	POS 42	D43323P	W5121	ALL
D43379J		AE0303A	POS 43	D43379P	W5335	ALL
D43333J		AE0303A	POS 44	D43333P	W5723	YT101-YT103
D43355J		AE0303A	POS 46	D43355P	W2415	YT101-YT103
D43333J		AE0303A	POS 47	D43333P	W5723	YT104-YT133
D43357J		AE0303A	POS 47	D43357P	W2415	YT101-YT103
D43306J		AE0303A	POS 48	D43306P	W5723	YT104-YT133
D43363J		AE0303A	POS 48	D43363P	W2413	YT101-YT103
D43365J		AE0303A	POS 49	D43365P	W2413	YT101-YT103
D43309J		AE0303A	POS 52	D43309P	W2231	YT104-YT133
D00539		M00411	E003-03/ /			ALL
D02643		M00916	E003-03/ /			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W0330

Page 3 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W0342	SN2	FORWARD RIGHT HAND DOORWAY LINING				
I D40042J				D40042P	W4142	ALL
I D02968		L01063	318/280/R038			ALL
I D12606		M01834	MULTI/ /			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W0340

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W0352	SN2	FORWARD LEFT HAND DOORWAY LINING				
I D40040J				D40040P	W4142	ALL
I D02972		L01067	329/285/L030			ALL
I D11366		M01834	MULTI/ /			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W0350

Page 1 End

Jun 21/2016





## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W0410	RB2	E4-1 SHELF (ELECTRICAL EQUIPMENT) RB2				
I D00458A			*/ */ *			ALL
I D00458B			*/ */ *			ALL
I D10002A			*/ */ *			ALL
I D10002B			*/ */ *			ALL
I D41804J		AE0401A	POS 09	D41804P	W6220	ALL
I D41810J		AE0401A	POS 10	D41810P	W6420	ALL
I D41816J		AE0401A	POS 11	D41816P	W6288	ALL
I D41828J		AE0401A	POS 12	D41828P	W6214	ALL
I D41830J		AE0401A	POS 13	D41830P	W6412	ALL
I D44161J		AE0401A	POS 24	D44161P	W5461	ALL
I D40904J		AE0401A	POS 26	D40904P	W5726	ALL
I D40244J		AE0401A	POS 29	D40244P	W5104	ALL
I D40242J		AE0401A	POS 30	D40242P	W6102	ALL
I D40328J		AE0401A	POS 31	D40328P	W6214	ALL
I D41010J		AE0401A	POS 33	D41010P	W6412	ALL
I D40326J		AE0401A	POS 35	D40326P	W6412	ALL
I D40330J		AE0401A	POS 36	D40330P	W6230	ALL
I D43044J		AE0401A	POS 37	D43044P	W6528	ALL
I D40144J		AE0401A	POS 38	D40144P	W6168	ALL
I D40066J		AE0401A	POS 39	D40066P	W6204	ALL
I D40530J		AE0401A	POS 40	D40530P	W2214	ALL
I D40158J		AE0401A	POS 42	D40158P	W6564	ALL
I D40554J		AE0401A	POS 43	D40554P	W2508	ALL
I D43018J		AE0401A	POS 44	D43018P	W5526	ALL
I D40378J		AE0401A	POS 46	D40378P	W6214	ALL
I D40562J		AE0401A	POS 47	D40562P	W2510	ALL
I D40534J		AE0401A	POS 48	D40534P	W2216	ALL
I D43038J		AE0401A	POS 49	D43038P	W6230	ALL
I D40156J		AE0401A	POS 50	D40156P	W6162	ALL
I D40542J		AE0401A	POS 51	D40542P	W2218	ALL
I D40390J		AE0401A	POS 52	D40390P	W6412	ALL
I D43062J		AE0401A	POS POS 45	D43062P	W5230	YT101-YT119
I D43062J		AE0401A	POS POS 45	D43062P		YT120, YT132-YT133
I D43062J		AE0401A	POS POS 45	D43062P	W5230	YT126-YT131
I D00458		M00324	E004-01/ /			ALL
I D10002		M1455				ALL
I W0411	RA2	E4-1 ELCTRONIC SHELF				
I D02501A			*/ */ *			ALL

### MASTER BUNDLE LIST

D280A351

91-21-13

Section W0410

Page 1

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
W0411	RA2	E4-1 ELCTRONIC SHELF (continued)				
D02501B			*/ */ *			ALL
D02501C			*/ */ *			ALL
D02555A			*/ */ *			ALL
D02555B			*/ */ *			ALL
D02555C			*/ */ *			ALL
D10727A			*/ */ *			ALL
D10727B			*/ */ *			ALL
D10727C			*/ */ *			ALL
D04115J		AE0401A	POS 14	D04115P	W5331	ALL
D04117J		AE0401A	POS 15	D04117P	W5331	ALL
D04289J		AE0401A	POS 16	D04289P	W5191	ALL
D04287J		AE0401A	POS 17	D04287P	W5189	ALL
D04155J		AE0401A	POS 18	D04155P	W3323	ALL
D04285J		AE0401A	POS 19	D04285P	W5191	ALL
D04331J		AE0401A	POS 20	D04331P	W3319	ALL
D08123J		AE0401A	POS 21	D08123P	W5189	ALL
D04153J		AE0401A	POS 22	D04153P	W3327	ALL
D04371J		AE0401A	POS 23	D04371P	W5431	ALL
D04161J		AE0401A	POS 25	D04161P	W5337	ALL
D44139J		AE0401A	POS 27	D44139P	W3309	ALL
D04157J		AE0401A	POS 28	D04157P	W3329	ALL
D04007J		AE0401A	POS 32	D04007P	W5335	ALL
D04009J		AE0401A	POS 41	D04009P	W5335	ALL
D11281		M02100	E004-01/ /			ALL
D10727		M02127	E004-01/ /			ALL
D11813		M02502	E004-01/ /			ALL
D02501		M1353				ALL
D02555		M25				ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W0410

Page 2 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity	
I W0420	RB2	E4-2 SHELF (RIGHT WINDOW HEAT MODULES) RB2					
			D01046A	E004-02/ /		YT101-YT116, YT126-YT131	
			D01046B	E004-02/ /		YT101-YT116, YT126-YT131	
			D01048A	E004-02/ /		YT101-YT116, YT126-YT131	
			D01048B	E004-02/ /		YT101-YT116, YT126-YT131	
I		D42400J	AE0402A	POS 22	D42400P	W6412	ALL
I		D40068J	AE0402A	POS 34	D40068P	W2208	ALL
I		D41440J	AE0402A	POS 38	D41440P	W2218	ALL
		D01046	M00322	E004-02/ /			YT101-YT116, YT126-YT131
		D01048	M00323	E004-02/ /			YT101-YT116, YT126-YT131
I		D16232	M00323	E004-02/ /			YT117-YT120, YT132-YT133
I W0422		E4-2 SHELF					
I		D42111J	AE0402A	POS 01	D42111P	W5719	ALL
I		D40584J	AE0402A	POS 02	D40584P	W5248	ALL
I		D40338J	AE0402A	POS 07	D40338P	W5110	ALL
I		D40238J	AE0402A	POS 08	D40238P	W6134	ALL
I		D40714J	AE0402A	POS 09	D40714P	W6588	ALL
I		D40228J	AE0402A	POS 13	D40228P	W6208	ALL
I		D40222J	AE0402A	POS 14	D40222P	W6208	ALL
I		D40164J	AE0402A	POS 15	D40164P	W6586	ALL
I		D43028J	AE0402A	POS 16	D43028P	W6032	ALL
I		D40432J	AE0402A	POS 17	D40432P	W6222	ALL
I		D40742J	AE0402A	POS 19	D40742P	W6222	ALL
I		D40712J	AE0402A	POS 23	D40712P	W6412	ALL
I		D40388J	AE0402A	POS 24	D40388P	W6412	ALL
I		D40382J	AE0402A	POS 25	D40382P	W6410	ALL
I		D40140J	AE0402A	POS 26	D40140P	W6164	ALL
I		D40720J	AE0402A	POS 27	D40720P	W6164	ALL
I		D40938J	AE0402A	POS 28	D40938P	W6210	ALL
I		D40370J	AE0402A	POS 29	D40370P	W6210	ALL
I		D40484J	AE0402A	POS 30	D40484P	W5158	ALL
I		D40356J	AE0402A	POS 31	D40356P	W5612	ALL

### MASTER BUNDLE LIST

D280A351

91-21-13

Section W0420

Page 1

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
<b>W0422</b>						
<b>E4-2 SHELF (continued)</b>						
D40540J		AE0402A	POS 32	D40540P	W2218	ALL
D40472J		AE0402A	POS 33	D40472P	W5160	ALL
D40618J		AE0402A	POS 35	D40618P	W5158	ALL
D40930J		AE0402A	POS 36	D40930P	W5612	ALL
D40474J		AE0402A	POS 37	D40474P	W5160	ALL
D40169J		AE0402A	POS 40	D40169P	W5160	ALL
D10892		G00012	E004-02/ /			ALL
D10892A		G00012	E004-02/ /			ALL
D10892B		G00012	E004-02/ /			ALL
D10898		G00015	E004-02/ /			ALL
D10898A		G00015	E004-02/ /			ALL
D10898B		G00015	E004-02/ /			ALL
D02586		M00980	E004-02/ /			ALL
D02586A		M00980	E004-02/ /			ALL
D02586B		M00980	E004-02/ /			ALL
D00104		T00012	E004-02/ /			ALL
D00106		T00013	E004-02/ /			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W0420

Page 2 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W0442	NN2	AFT RIGHT HAND DOORWAY LINING				
I D40046J				D40046P	W4142	ALL
I D02986		L01079	972/279/R044			ALL
I W0444	LN1	CENTER OVERHEAD STOWAGE LIGHT				
I D14448			MULTI/ /			ALL
I D14682			MULTI/ /			ALL
I D14688			MULTI/ /			ALL
I D14404		M02804	MULTI/288/11			ALL
I D14684		M02804	MULTI/288/11			ALL
I D14686		M02804	MULTI/288/11			ALL
I W0446	LN1	CENTER OVERHEAD STOWAGE LIGHT - LEFT FWD				
I D14742			MULTI/ /			ALL
I D14746			MULTI/ /			ALL
I D14744		M02804	MULTI/288/11			ALL
I D14748		M02804	MULTI/288/11			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W0440

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W0452	NN2	AFT LEFT HAND DOORWAY LINING				
I D40044J				D40044P	W3142	ALL
I D02982		L01076	972/286/L037			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W0450

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W0521	NA2	E5-2 SHELF WIRE BUNDLE #1				
I D45221P				D45221J	W0737	YT104-YT133
I D02179A			E005-02/ /			ALL
I D02179B			E005-02/ /			ALL
I D02179C			E005-02/ /			ALL
I D03687A			E005-02/ /			ALL
I D03687B			E005-02/ /			ALL
I D03687C			E005-02/ /			ALL
I D13673			E005-02/ /			YT104-YT133
I D13673A			E005-02/ /			YT104-YT133
I D13673B			E005-02/ /			YT104-YT133
I D13673C			E005-02/ /			YT104-YT133
I D41251J		AE0104B	POS 01	D41251P	W0121	ALL
I D45209P		AE0502A	POS 01	D45209J	W5205	YT104-YT133
I D45221P		AE0502A	POS 01	D45221J	W0737	YT101-YT103
I D45245P		AE0502A	POS 02	D45245J	W5161	YT104-YT133
I D45209P		AE0502A	POS 03	D45209J	W5205	YT101-YT103
I D45255P		AE0502A	POS 03	D45255J	W5161	YT104-YT133
I D45265P		AE0502A	POS 04	D45265J	W5161	YT104-YT133
I D41561P		AE0502A	POS 05	D41561J	W5461	YT104-YT133
I D45261P		AE0502A	POS 06	D45261J	W5461	YT104-YT133
I D45235P		AE0502A	POS 07	D45235J	W2035	YT104-YT133
I D45239P		AE0502A	POS 08	D45239J	W5501	YT104-YT133
I D45225P		AE0502A	POS 09	D45225J	W2597	YT104-YT133
I D05925P		AE0502A	POS 10	D05925J	W2889	YT104-YT133
I D45293P		AE0502A	POS 11	D45293J	W2597	YT104-YT133
I D45211P		AE0502A	POS 12	D45211J	W5111	ALL
I D45319P		AE0502A	POS 13	D45319J	W5043	YT101-YT103
I D45245P		AE0502A	POS 14	D45245J	W5161	YT101-YT103
I D45319P		AE0502A	POS 14	D45319J	W5043	YT104-YT133
I D45255P		AE0502A	POS 15	D45255J	W5161	YT101-YT103
I D45204P		AE0502A	POS 16	D45204J	W2031	YT104-YT133
I D45265P		AE0502A	POS 16	D45265J	W5161	YT101-YT103
I D40761P		AE0502A	POS 17	D40761J	W5047	YT104-YT133
I D41561P		AE0502A	POS 17	D41561J	W5461	YT101-YT103
I D45261P		AE0502A	POS 18	D45261J	W5461	YT101-YT103
I D45235P		AE0502A	POS 19	D45235J	W2035	YT101-YT103
I D45239P		AE0502A	POS 20	D45239J	W5501	YT101-YT103
I D45225P		AE0502A	POS 21	D45225J	W2597	YT101-YT103
I D05925P		AE0502A	POS 22	D05925J	W2889	YT101-YT103
I D45293P		AE0502A	POS 23	D45293J	W2597	YT101-YT103

### MASTER BUNDLE LIST

D280A351

91-21-13

Section W0520

Page 1

Jun 21/2016



# 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
<b>W0521</b>	<b>NA2</b>	<b>E5-2 SHELF WIRE BUNDLE #1 (continued)</b>				
I D06063J		AE0502A	POS 24	D06063P		YT101-YT103
I D45563P		AE0502A	POS 24	D45563J	W5163	YT105-YT133
I D06063J		AE0502A	POS 34	D06063P		YT104-YT133
I D02179		M01175	E005-02/ /			ALL
I D03687		M01749	E005-02/ /			ALL
I D03263		R00475	E005-02/ /			ALL
I D03265		R00475	E005-02/ /			ALL
I D03267		R00475	E005-02/ /			ALL
<b>W0523</b>	<b>NB2</b>	<b>E5-2 SHELF WIRE BUNDLE #2</b>				
I D03261A			*/ */ *			ALL
I D03261B			*/ */ *			ALL
I D03261C			*/ */ *			ALL
I D03693A			*/ */ *			ALL
I D03693B			*/ */ *			ALL
I D03693C			*/ */ *			ALL
I D03261			E005-02/ /			ALL
I D41453J		AE0104B	POS 03	D41453P	W0141	ALL
I D45247P		AE0502A	POS 04	D45247J	W5163	YT101-YT103
I D45257P		AE0502A	POS 05	D45257J	W5163	YT101-YT103
I D45263P		AE0502A	POS 06	D45263J	W5463	YT101-YT103
I D45237P		AE0502A	POS 07	D45237J	W2135	YT101-YT103
I D45067P		AE0502A	POS 08	D45067J	W2135	YT101-YT103
I D08105P		AE0502A	POS 09	D08105J	W2873	YT101-YT103
I D45241P		AE0502A	POS 10	D45241J	W5503	YT101-YT103
I D45213P		AE0502A	POS 11	D45213J	W5121	YT101-YT103
I D40767P		AE0502A	POS 25	D40767J	W5049	YT104-YT133
I D45213P		AE0502A	POS 26	D45213J	W5121	YT104-YT133
I D45247P		AE0502A	POS 27	D45247J	W5163	YT104-YT133
I D45257P		AE0502A	POS 28	D45257J	W5163	YT104-YT133
I D45263P		AE0502A	POS 29	D45263J	W5463	YT104-YT133
I D45237P		AE0502A	POS 30	D45237J	W2135	YT104-YT133
I D45067P		AE0502A	POS 31	D45067J	W2135	YT104-YT133
I D08105P		AE0502A	POS 32	D08105J	W2873	YT104-YT133
I D45241P		AE0502A	POS 33	D45241J	W5503	YT104-YT133
I D03693		M01752	E005-02/ /			ALL
I D03423		R00476	E005-02/ /			ALL
I D03425		R00476	E005-02/ /			ALL
I D03427		R00476	E005-02/ /			ALL

## MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W0520

Page 2 End

Jun 21/2016





## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W0621	LA2	E6-2 SHELF				
I D00345A			*/*/*			ALL
I D00345B			*/*/*			ALL
I D00345C			*/*/*			ALL
I D00623A			*/*/*			ALL
I D00623B			*/*/*			ALL
I D00623C			*/*/*			ALL
I D00623			E006-02/ /			ALL
I D40127J		AE0602A	POS 01	D40127P	W3559	ALL
I D40123J		AE0602A	POS 02	D40123P	W3557	ALL
I D40111J		AE0602A	POS 03	D40111P	W2101	ALL
I D40621J		AE0602A	POS 04	D40621P	W2103	ALL
I D40117J		AE0602A	POS 05	D40117P	W5189	ALL
I D40119J		AE0602A	POS 07	D40119P	W5191	ALL
I D40115J		AE0602A	POS 08	D40115P	W5105	ALL
I D40113J		AE0602A	POS 10	D40113P	W5103	ALL
I D40125J		AE0602A	POS 11	D40125P	W3555	ALL
I D40121J		AE0602A	POS 12	D40121P	W3553	ALL
I D00345		M00226	E006-02/ /			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W0620

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W0737	NA2	E5-2 TO P59 FMC DIP SWITCH				
I D45221J				D45221P	W0521	YT104-YT133
D45221J		AE0502A	POS 01	D45221P	W0521	YT101-YT103

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W0730

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W0767	NN2	D43267J TO FLIGHT RECORDER M96				
I D43267J				D43267P	W5409	ALL
I D00183A			0923/294/000			ALL
I D00183B			0923/295/000			ALL
I D00183		M00096	942/290/0			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W0760

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W0811	NN2	E8-1 SHELF BUNDLE (IFE SYSTEM - BSI)				
		D12393A	//			YT101-YT120
		D12393B	//			YT101-YT120
		D12393C	//			YT101-YT120
I		D13429A	//			ALL
I		D13429B	//			ALL
I		D13429C	//			ALL
I		D12951A	E008-01//			ALL
I		D12951B	E008-01//			ALL
I		D12951C	E008-01//			ALL
I		D47031J	AE0801A POS 01	D47031P	W3477	ALL
I		D40489J	AE0801A POS 13	D40489P	W4258	ALL
I		D48323J	AE0801A POS 14	D48323P	W2103	ALL
		D45489J	AE0801A POS 20	D45489P	W3477	YT101-YT120
I		D45905J	AE0801B POS 01	D45905P	W3307	ALL
I		D45907J	AE0801B POS 02	D45907P	W5043	ALL
I		D45912J	AE0801B POS 06	D45912P	W3477	ALL
		D45183J	AE0801B POS 07	D45183P	W3477	YT101-YT120
I		D45167J	AE0801B POS 08	D45167P	W3477	ALL
		D45185J	AE0801B POS 09	D45185P	W3477	YT101-YT120
I		D45169J	AE0801B POS 12	D45169P	W3477	ALL
I		D45099J	AE0801B POS 13	D45099P	W3755	ALL
I		D45243J	AE0801B POS 14	D45243P	W3755	YT101-YT102, YT126-YT133
		D45193J	AE0801B POS 15	D45193P	W3477	YT101-YT120
		D12393	M02652 E008-01//			YT101-YT120
I		D12951	M02851 E008-01//			ALL
I		D13429	M02893 E008-01//			ALL
I		D14178	M02950 E008-01//			ALL
I		D14180	M02950 E008-01//			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W0810

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
<b>W1022</b>	<b>LC3</b>	<b>L WING TRAILNG EDGE:DISC BRACKET STA 254L TO W/W DISC &amp; AFT CARGO DISC</b>				
D42104P		AB0727L	POS 01	D42104J	W5032	YT101-YT119, YT126-YT131
D42102P		AL0720A	POS 02	D42102J	W5367	YT101-YT119, YT126-YT131
D42100P		AL0720A	POS 03	D42100J	W5375	YT101-YT119, YT126-YT131
D40024P		AW0254L	POS 01	D40024J	W1024	YT101-YT119, YT126-YT131
D11818		T00527	WING LBL/164/			YT101-YT119, YT126-YT131
D11820		T00528	WING LBL/65/			YT101-YT119, YT126-YT131
<b>W1024</b>	<b>LC3</b>	<b>LEFT TRAILING EDGE:STA 525 TO L. WING DISC STA 254L</b>				
D40024J		AW0254L	POS 01	D40024P	W1022	YT101-YT119, YT126-YT131
D01695		AW0742L	POS 1			YT101-YT119, YT126-YT131
D01699		AW0742L	POS 2			YT101-YT119, YT126-YT131
D13954		M2596				YT101-YT119, YT126-YT131
D13956		M2597				YT101-YT119, YT126-YT131
D13958		M2598				YT101-YT119, YT126-YT131
D14126		M2599				YT101-YT119, YT126-YT131
D00275		T00427	443/RSS/L			YT101-YT119, YT126-YT131
D03572		T00465	LWING505/ /			YT101-YT119, YT126-YT131
D11814		T00525	WING LBL/357/			YT101-YT119, YT126-YT131
D11816		T00526	WING LBL/254/			YT101-YT119, YT126-YT131
D10539		T00539	727+18.0/215/L287			YT101-YT119, YT126-YT131

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W1020

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
<b>W1032</b>	<b>RD3</b>	<b>R WING TRAILNG EDGE:DISC BRACKET STA 254R TO W/W DISC &amp; AFT CARGO DISC</b>				
D43104P		AB0727R	POS 01	D43104J	W6028	YT101-YT119, YT126-YT131
D43100P		AL0720C	POS 01	D43100J	W5367	YT101-YT119, YT126-YT131
D43102P		AL0720D	POS 02	D43102J	W5375	YT101-YT119, YT126-YT131
D40034P		AW0254R	POS 01	D40034J	W1034	YT101-YT119, YT126-YT131
D11822		T00529	WING RBL/65/			YT101-YT119, YT126-YT131
D11824		T00530	WING RBL/164/			YT101-YT119, YT126-YT131
<b>W1034</b>	<b>RD3</b>	<b>RIGHT WING TRAILING EDGE:STA 525 TO R. WING DISC STA 254R</b>				
D40034J		AW0254R	POS 01	D40034P	W1032	YT101-YT119, YT126-YT131
D01701		AW0742R	POS 1			YT101-YT119, YT126-YT131
D01697		AW0742R	POS 2			YT101-YT119, YT126-YT131
D14124		M2600				YT101-YT119, YT126-YT131
D13964		M2601				YT101-YT119, YT126-YT131
D13966		M2602				YT101-YT119, YT126-YT131
D13968		M2603				YT101-YT119, YT126-YT131
D00229		T00428	443/RSS/R			YT101-YT119, YT126-YT131
D03574		T00466	RWING505/ /			YT101-YT119, YT126-YT131
D11826		T00531	WING RBL/254/			YT101-YT119, YT126-YT131
D11828		T00532	WING RBL/357/			YT101-YT119, YT126-YT131
D10541		T00540	727+18.0/215/R287			YT101-YT119, YT126-YT131

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W1030

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W1062	NN1	ENGINE POWER FEEDER				
I D30038		AS0001	POS 10			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W1060

Page 1 End

Jun 21/2016



Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W1080	NA2	ENGINE-THRUST REVERSER LEFT SLEEVE CH-A				
I D30002		AS0002	POS 02			ALL
I D30072		T00396	ENG/ /			ALL
I D01008		V00148	ENG/ /			ALL
I W1082	NB2	ENGINE-THRUST REVERSER LEFT SLEEVE CH-B				
I D30008		AS0002	POS 01			ALL
I D30076		T00396	ENG/ /			ALL
I W1084	NB2	ENGINE-THRUST REVERSER RIGHT SLEEVE CH-B				
I D30010		AS0003	POS 01			ALL
I D30078		T00397	ENG/ /			ALL
I W1086	NA2	ENGINE-THRUST REVERSER RIGHT SLEEVE CH-A				
I D30006		AS0003	POS 02			ALL
I D30074		T00397	ENG/ /			ALL
I D01016		V00150	ENG/ /			ALL

## MASTER BUNDLE LIST

D280A351

91-21-13

Section W1080

Page 1 End

Jun 21/2016





## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W1126	RN1*	CENTER TANK R FUEL BOOST PUMP TO AB0500DR				
I D41850P		AB0500DR	POS 07	D41850J	W6588	ALL
I D05350P		AB0500DR	POS 11	D05350J	W6588	ALL
I D00804		M00235	WBL095/ /			ALL
I D00878		S00155	656/187/025R			ALL
I D00792		V00039	77/FSS/L			ALL
I W1128	LN1*	CENTER TANK L FUEL BOOST PUMP TO AB0500DL				
I D41854P		AB0500DL	POS 01	D41854J	W5568	ALL
I D05348P		AB0500DL	POS 02	D05348J	W5568	ALL
I D00802		M00234	WBL95/ /			ALL
I D00876		S00154	656/187/L026			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W1120

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
<b>W1134</b>	<b>LN1*</b>	<b>NO.2 AFT BOOST PUMP TO STA 520R</b>				
D05346P		AB0500DL	POS 03	D05346J	W5568	YT101-YT119, YT126-YT131
D41852P		AB0500DL	POS 10	D41852J	W5568	YT101-YT119, YT126-YT131
D00074		M00048	WBL135/ /			YT101-YT119, YT126-YT131
D00872		S00152	669/189/055			YT101-YT119, YT126-YT131
<b>W1136</b>	<b>RN1*</b>	<b>NO.1 AFT BOOST PUMP TO STA 520L</b>				
D41856P		AB0500DR	POS 09	D41856J	W6588	YT101-YT119, YT126-YT131
D05342P		AB0500DR	POS 10	D05342J	W6588	YT101-YT119, YT126-YT131
D00070		M00046	WBL140/ /			YT101-YT119, YT126-YT131
D00868		S00150	669/189/085L			YT101-YT119, YT126-YT131
<b>W1138</b>	<b>SN2</b>	<b>RIGHT WING BODY PRESSURE SEAL TANK 2 FUEL QUANTITY</b>				
D39916		AD0520				ALL
D11314		M01829	/ /			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W1130

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W1140	SN2	LEFT WING BODY PRESSURE SEAL TO TANK 1 FUEL QUANTITY				
I D39915		AC0520				ALL
I D11312		M01828	/ /			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W1140

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W1162	LA1	ENGINE STRUT-LEFT-FIREWALL TO AW0258L POWER FEEDER				
I D30238		AS0001L	POS 10			ALL
I D08094P		AW0258L	POS 01	D08094J	W1186	ALL
I W1164	SA1	ENGINE STRUT-LEFT FIREWALL TO AW0258L IDG CONTROLS				
I D30234		AS0001L	POS 09			ALL
I D30016		AW0258L	POS 04			ALL
I W1166	SB2	ENGINE STRUT-LEFT FIREWALL TO AW0258L EEC CH B				
I D30220		AS0001L	POS 05			ALL
I D30256		AS0001L	POS 07			ALL
I D30064		AW0258L	POS 05			ALL
I W1168	LB2	ENGINE STRUT-LEFT FIREWALL TO AW0258L EEC CH B				
I D30260		AS0001L	POS 01			ALL
I D30204		AS0001L	POS 08			ALL
I D30208		AS0002L	POS 01			ALL
I D30210		AS0003L	POS 01			ALL
I D30084		AW0258L	POS 03			ALL
I D00526		S00020	574/199/L184			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W1160

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W1170	LA2	ENGINE STRUT LEFT FIREWALL TO AW0258L EEC CH A				
I D30212		AS0001L	POS 03			ALL
I D30252		AS0001L	POS 04			ALL
I D30228		AS0001L	POS 06			ALL
I D08056P		AW0258L	POS 06	D08056J	W1178	ALL
I W1172	LA2	ENGINE STRUT-LEFT FIREWALL TO AW0258L EEC CH A				
I D30224		AS0001L	POS 02			ALL
I D30202		AS0002L	POS 02			ALL
I D30206		AS0003L	POS 02			ALL
I D30042		AW0258L	POS 02			ALL
I W1178	LN2	LEADING EDGE-LEFT WING EEC CH A				
I D39927		AC0520				ALL
I D08056J		AW0258L	POS 06	D08056P	W1170	ALL
I D00788		V00037	260/FSS/L			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W1170

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W1180	LN1	LEFT WING/BODY PRESSURE SEAL TO FRONT SPAR INBOARD				
I D39938		AC0520				ALL
I D00072		M00047	102/FSS/L			ALL
I W1182	SB2	LEADING EDGE-LEFT WING EEC CH B				
I D39931		AC0520				ALL
I D30062		AW0258L	POS 05			ALL
I D00834		M00268	FS198/ /			ALL
I W1184	SA1	LEADING EDGE-LEFT WING IDG CONTROLS				
I D39911		AC0520				ALL
I D30014		AW0258L	POS 04			ALL
I D39935		DM0017	520/ /			ALL
I W1186	LA1	LEADING EDGE-LEFT WING-POWER FEEDER				
I D08094J		AW0258L	POS 01	D08094P	W1162	ALL
I W1188	SN2	LEFT WING/BODY PRESSURE SEAL TO FRONT SPAR OUTBD				
I D39903		AC0520				ALL
I D00738		S00118	621/205/R213			ALL
I D10589		S1094				ALL
I D10591		S1095				ALL
I D10593		S1096				ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W1180

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W1242	LN2	L LEADING EDGE TO WING TIP				
I D40014J				D40014P		ALL
I D11042		M01743	727B/245/L634			ALL
I D11046		T00390	727B/245/L638			ALL
I W1244	LN2	R LEADING EDGE TO WING TIP				
I D40016J				D40016P		ALL
I D11040		M01742	727B/245/R634			ALL
I D11044		T00389	727B/245/R638			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W1240

Page 1 End

Jun 21/2016



Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W1262	RB1	ENGINE STRUT-RIGHT FIREWALL TO AW0258R POWER FEEDER				
I D30438		AS0001R	POS 10			ALL
I D08194P		AW0258R	POS 01	D08194J	W1286	ALL
I W1264	SN1	ENGINE STRUT-RIGHT FIREWALL TO AW0258R IDG CONTROLS				
I D30434		AS0001R	POS 09			ALL
I D30116		AW0258R	POS 04			ALL
I W1266	SB2	ENGINE STRUT-RIGHT FIREWALL TO AW0258R EEC CH B				
I D30420		AS0001R	POS 05			ALL
I D30456		AS0001R	POS 07			ALL
I D30164		AW0258R	POS 05			ALL
I W1268	RB2	ENGINE STRUT-RIGHT FIREWALL TO AW0258R EEC CH B				
I D30460		AS0001R	POS 01			ALL
I D30404		AS0001R	POS 08			ALL
I D30408		AS0002R	POS 01			ALL
I D30410		AS0003R	POS 01			ALL
I D30184		AW0258R	POS 03			ALL
I D00528		S00021	574/199/R184			ALL

## MASTER BUNDLE LIST

D280A351

91-21-13

Section W1260

Page 1 End

Jun 21/2016





## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W1270	RA2	ENGINE STRUT-RIGHT FIREWALL TO AW0258R EEC CH A				
I D30412		AS0001R	POS 03			ALL
I D30452		AS0001R	POS 04			ALL
I D30428		AS0001R	POS 06			ALL
I D08156P		AW0258R	POS 06	D08156J	W1278	ALL
I W1272	RA2	ENGINE STRUT-RIGHT FIREWALL TO AW0258R EEC CH A				
I D30424		AS0001R	POS 02			ALL
I D30402		AS0002R	POS 02			ALL
I D30406		AS0003R	POS 02			ALL
I D30142		AW0258R	POS 02			ALL
I W1278	RN2	LEADING EDGE-RIGHT WING EEC CH A				
I D39928		AD0520				ALL
I D08156J		AW0258R	POS 06	D08156P	W1270	ALL
I D00790		V00038	W156/LE/R			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W1270

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W1280	RN1	RIGHTWING/BODY PRESSURE SEAL TO FRONT SPAR INBOARD				
I D39940		AD0520				ALL
I D00076		M00049	FS104/ /			ALL
I W1282	SB2*	LEADING EDGE-RIGHT WING EEC CH B				
I D39932		AD0520				ALL
I D30162		AW0258R	POS 05			ALL
I D00838		M00269	FS195/ /			ALL
I W1284	SN1	LEADING EDGE-RIGHT WING IDG CONTROLS				
I D39912		AD0520				ALL
I D39936		AD0520				ALL
I D30114		AW0258R	POS 04			ALL
I W1286	RB1	LEADING EDGE-RIGHT WING POWER FEEDERS				
I D08194J		AW0258R	POS 01	D08194P	W1262	ALL
I W1288	SN2	RIGHT WING BODY PRESSURE SEAL TO FRONT SPAR OUTBD				
I D39904		AD0520				ALL
I D00736		S00117	621/205/R213			ALL
I D10595		S1097				ALL
I D10597		S1098				ALL
I D10599		S1099				ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W1280

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W1662	LB1	LEFT WING/BODY PRESSURE SEAL TO FRONT SPAR				
I D39907		AC0520				ALL
I D15948		M03079	528/200/L084			YT113-YT120, YT131-YT133
I D00870		S00151	547/198/083L			ALL
I D00732		V00029	611/205/L208			ALL
I W1664	SA1	RIGHT WING-WING/BODY TO FRONT SPAR AND P15 REFUELING PANEL				
I D04578J				D04578P		ALL
I D39908		AD0520				ALL
I D15934		M03078	528/200/R084			YT113-YT120, YT131-YT133
I D06013		REFUELING				ALL
I D00874		S00153	547/195/083			ALL
I D00734		V00030	611/205/R208			ALL
I D00890		V00044	124/ /			ALL
I D00894		V00045	135/ /			ALL
I D00892		V00046	127/ /			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W1660

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W1722	SN1	APU FUEL BOOST PUMP CONTROL				
I D01828		M00668	689/148/148			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W1720

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W2004	NN2	WINDOW NO.2 WINDSHIELD HEAT BUNDLE (NN2)				
I D10572		M02675	230/ /			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W2000

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W2012	NN2	WINDOW NO.2 WINDSHIELD HEAT BUNDLE (NN2)				
I D10560		M02675	230/ /			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W2010

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W2022	NN2*	P9 TO E1-3				
I D41400P		AE0103A	POS 06	D41400J	W0131	ALL
I D40914P		AP0900A	POS 10	D40914J	W0001	ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W2020

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W2030	SN2	AP0900A DISC BRKT TO AP0600B DISC BRKT (SN2)				
I D46052P		AP0600B	POS 11	D46052J	W0044	ALL
I D40924P		AP0900A	POS 14	D40924J	W0003	ALL
I W2031	NN2	NETWORK FILE SERVER QUADRAX WIRING				
I D41023P		AE0101A	POS 34	D41023J	W0111	YT104-YT133
I D49002P		AE0302A	POS 03	D49002J	W0321	YT104-YT133
I D45204J		AE0502A	POS 16	D45204P	W0521	YT104-YT133
I D40747P		M02979	/ /	D40747J		YT104-YT133
I W2035	NA2	P5, E5-2				
I D06067J			264/255/L042	D06067P		ALL
I D45235J		AE0502A	POS 07	D45235P	W0521	YT104-YT133
I D45235J		AE0502A	POS 19	D45235P	W0521	YT101-YT103
I D00553		P005-28	P005-00/ /			ALL
I D02171		P005-69	P005-69/ /			ALL
I D02169		P005-70	P005-70/ /			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W2030

Page 1 End

Jun 21/2016





## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W2101	LA2	LEFT AC ELEX PWR FROM P18 TO E1.				
I D41811P		AE0101A	POS 13	D41811J	W0111	ALL
I D40111P		AE0602A	POS 03	D40111J	W0621	ALL
I D41801P		AP1800B	POS 03	D41801J	W0018	ALL
I W2102	LN2	P18 (L CAB CEILING) DISC TO L CONTROL CABIN AREA (LN2)				
I D12106		L01103	224/223/L040			ALL
I D12108		L01103	224/223/L040			ALL
I D00796		P021-01	215/213/L034			ALL
I W2103	RB2	RIGHT AC ELEX PWR FROM P6 TO E1.				
I D46013P		AE0101B	POS 13	D46013J	W0111	ALL
I D46011J		AE0104A	POS 09	D46011P	W0141	ALL
I D40621P		AE0602A	POS 04	D40621J	W0621	ALL
I D48323P		AE0801A	POS 14	D48323J	W0811	ALL
I D46061P		AP0600B	POS 23	D46061J	W0044	ALL
I W2104	LA1	P5 OVHD PANEL TO EE BAY (E2-2) LA1				
		D07711J		D07711P	W5506	YT113-YT120
		D31018J		D31018P		YT101-YT120
I D40506P		AE0202A	POS 11	D40506J	W0220	YT101-YT131
I D48100P		AJ0048A	POS 01	D48100J	W0088	YT101-YT131
I D40502P		AP0600C	POS 01	D40502J	W0044	YT101-YT131
I D40504P		AP1800A	POS 08	D40504J	W0018	YT101-YT131
		D13237	M02879	P021-00/ /		YT101-YT120
I D00624		P005-03	P005-00/ /			YT101-YT131
I D02486		P005-08	P005-00/ /			YT101-YT131
I D11988		S00007	P005-00/ /			YT101-YT131
I W2108	LA1	WINDSHIELD HEAT DISCONNECT TO E2-1 (LA1)				
I D40070P		AE0201A	POS 20	D40070J	W0210	ALL
I D00062		M00021	191/241/L011			ALL
I D10564		M02675	230/ /			ALL

### MASTER BUNDLE LIST

D280A351

91-21-13

Section W2100

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W2110	SA2	<b>CARGO SMOKE DETECTION &amp; FIRE SUPPRESSION MODULE (P8-75) E2-2 SHELF</b>				
I D40646P		AE0202A	POS 30	D40646J	W0220	ALL
I D46022P		AE0202A	POS 31	D46022J	W0220	ALL
I D12760		P008-75	P008-00/ /			ALL
I W2112	LA2*	<b>P5 OVHD PANEL TO EE BAY (E2-1/E2-2/E3-1) LA2</b>				
I D40598P		AE0201A	POS 10	D40598J	W0212	ALL
I D40518P		AE0201A	POS 21	D40518J	W0210	ALL
I D40520P		AE0202A	POS 12	D40520J	W0220	ALL
I D40516P		AE0301A	POS 20	D40516J	W0311	ALL
I D40596P		AE0302A	POS 31	D40596J	W0321	ALL
I D48102P		AJ0048A	POS 05	D48102J	W0088	ALL
I D40512P		AP0600C	POS 03	D40512J	W0044	ALL
I D40840P		AP1800A	POS 03	D40840J	W0018	ALL
I D40514P		AP1800A	POS 09	D40514J	W0018	ALL
I D00722		P005-04	P005-00/ /			ALL
I D10724		P005-06	P005-00/ /			ALL
I D00638		P005-09	P005-00/ /			ALL
I D00462		P005-11	P005-00/ /			ALL
I D02349		P005-18	P005-00/ /			ALL
I D02952		P005-68	P005-00/ /			ALL
I D10550		P005-83	P005-00/ /			ALL
I D10552		P005-83	P005-00/ /			ALL
I W2114	LB2	<b>P5 OVHD TO AB0340A/AB0340B AND AE0101A DISC BRACKET (LB2)</b>				
I D40196P		AB0340A	POS 03	D40196J	W3142	ALL
I D41838P		AB0340B	POS 03	D41838J	W6288	ALL
I D40296P		AB0340B	POS 07	D40296J	W4142	ALL
I D48104P		AJ0048A	POS 20	D48104J	W0088	ALL
I D40522P		AP1800A	POS 10	D40522J	W0018	ALL
I D02970		L00273	270/274/L017			ALL
I D02992		L00273	270/274/L017			ALL
I D00090		N00011	P005-17/ /			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W2110

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W2132	LA1	P91 TO P6 (115V AC XFR BUS 1 SEC 2)				
I D11414		P0091				ALL
I W2134	LA1	P91 TO P18 (115V AC XFR BUS 1 SEC 2 AND 115V AC MAIN BUS).				
I D11412		P0091				ALL
I W2135	RB2	P5, E5-2				
D45237J		AE0502A	POS 07	D45237P	W0523	YT101-YT103
D45067J		AE0502A	POS 08	D45067P	W0523	YT101-YT103
I D45237J		AE0502A	POS 30	D45237P	W0523	YT104-YT133
I D45067J		AE0502A	POS 31	D45067P	W0523	YT104-YT133
I D40623P		AP0600B	POS 06	D40623J	W0041	ALL
I D01817		P005-28	P005-00/ /			ALL
I D02173		P005-69	P005-69/ /			ALL
I D02183		P005-70	P005-70/ /			ALL
I W2136	LA1	P91 TO P6 AND P18.				
I D11424		P0091				ALL
I W2138	LA1	AP0600B TO AE0201A (LA1)				
I D41432P		AE0201A	POS 15	D41432J	W0210	ALL
I D41430P		AP0600B	POS 05	D41430J	W0044	ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W2130

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W2149	NA2	CAPTAINS NAV ELEX PANEL TO E/E BAY				
I D04029J		AE0102A	POS 03	D04029P	W0121	ALL
I D40095P		AJ0048A	POS 04	D40095J	W0088	ALL
I D00263		P008-25				YT120
I D00303		P008-25				YT120
I D00263		P008-25	P008-25/ /			YT101-YT119, YT126-YT133
I D00303		P008-25	P008-25/ /			YT101-YT119, YT126-YT133

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W2140

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W2151	NB2	F/O'S NAV ELEX PANEL TO E/E BAY				
I D04031J		AE0105A	POS 02	D04031P	W0151	ALL
I D00265		P008-26				YT120
I D00305		P008-26				YT120
I D00265		P008-26	P008-26/ /			YT101-YT119, YT126-YT133
I D00305		P008-26	P008-26/ /			YT101-YT119, YT126-YT133

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W2150

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W2169	RB2	RIGHT DC ELEX PWR FROM P6 TO E3.				
I D46035P		AE0301A	POS 24	D46035J	W0313	ALL
I D46043P		AE0302A	POS 30	D46043J	W0321	ALL
I D46063P		AP0600B	POS 04	D46063J	W0044	ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W2160

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W2175	LA2	LEFT DC ELEX PWR FROM P18 TO E1.				
I D41821P		AE0101A	POS 24	D41821J	W0111	ALL
I D41823P		AP0900A	POS 17	D41823J		ALL
I D41803P		AP1800B	POS 06	D41803J	W0018	ALL
I W2177	NA2	DUAL ATC ELEC PNL TO E1-2				
I D41217J		AE0102A	POS 04	D41217P	W0121	ALL
I D00211		P008-29	P008-29/ /			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W2170

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W2201	LA2	LEFT AC ELEX PWR FROM P18 TO E3.				
I D31016J		AC0235A	POS 01	D31016P		YT101-YT120
I D41817P		AE0301A	POS 21	D41817J	W0311	ALL
I D41819P		AE0302A	POS 27	D41819J	W0321	ALL
I D43241P		AE0302A	POS 55	D43241J	W0321	YT101-YT103
I D43313P		AE0303A	POS 28	D43313J	W0331	ALL
I D41805P		AP1800B	POS 01	D41805J	W0018	ALL
I W2204	RN2	P6 (R CAB CEILING) DISC TO R CONTROL CABIN AREA (RN2)				
I D40582P		AP0600C	POS 10	D40582J	W0044	ALL
I D12110		L01104	224/223/R040			ALL
I D12112		L01104	224/223/R040			ALL
I D13239		M02880	P023-00/ /			YT101-YT120
I D00798		P023-01	215/213/R034			ALL
I W2205	SN2	INTEGRATED STANDBY FLIGHT DISPLAY (ISFD) 20 GAGE				
I D04205J		AE0102A	POS 05	D04205P	W0121	ALL
I D40049J		AE0104A	POS 07	D40049P	W0141	ALL
I D10853		N00226	P002-01/ /			ALL
I W2207	NA2	PRIMARY CDS-DEU TO P1				
I D04267P		AE0301A	POS 06	D04267J	W0311	ALL
I D04207P		AP0900A	POS 03	D04207J	W0001	ALL
I W2208	RB1	WINDSHIELD HEAT DISCONNECT TO E4-2. (RB1)				
I D40068P		AE0402A	POS 34	D40068J	W0420	ALL
I D00064		M00022	191/241/R011			ALL
I D10568		M02675	230/ /			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W2200

Page 1 End

Jun 21/2016





## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W2212	RA1	P5 OVHD PANEL (RA1)				
I D46124P		AJ0046B	POS 01	D46124J	W0066	ALL
I D40528P		AP0600A	POS 08	D40528J	W6208	ALL
I D40526P		AP0600C	POS 02	D40526J	W0044	ALL
I D40524P		AP1800A	POS 04	D40524J	W0018	ALL
I D00630		P005-03	P005-00/ /			ALL
I D00642		P005-08	P005-00/ /			ALL
I W2214	RB1	P5 OVHD PANEL TO EE BAY (E4-1) RB1				
I D40530P		AE0401A	POS 40	D40530J	W0410	ALL
I W2216	RA2	P5 OVHD PANEL TO EE BAY (E4-1) RA2				
I D41812P		AE0303A	POS 40	D41812J	W0330	ALL
I D40534P		AE0401A	POS 48	D40534J	W0410	ALL
I D46112P		AJ0046B	POS 12	D46112J	W0066	ALL
I D40532P		AP0600C	POS 04	D40532J	W0044	ALL
I D10956		M1718				ALL
I D10958		M1718				ALL
I D00786		N00051	P005-16/ /			ALL
I D00794		N00055	P005-16/ /			ALL
I D00646		P005-10	P005-00/ /			ALL
I D03996		P005-17	P005-00/ /			ALL
I D03998		P005-17	P005-00/ /			ALL
I D01406		P005-20	P005-00/ /			ALL
I W2218	RB2	P5 OVHD PANEL TO EE BAY (E3-1/E4-1/E4-2) RB2				
I D40170P		AB0340A	POS 04	D40170J	W3058	YT101-YT131
I D40170P		AB0340A	POS POS 04	D40170J		YT132-YT133
I D40510P		AE0101A	POS 28	D40510J	W0111	ALL
I D40064P		AE0101B	POS 23	D40064J	W0111	ALL
I D40544P		AE0301A	POS 27	D40544J	W0313	ALL
I D41826P		AE0303A	POS 11	D41826J	W0330	YT104-YT133
I D41826P		AE0303A	POS 36	D41826J	W0330	YT101-YT103
I D40542P		AE0401A	POS 51	D40542J	W0410	ALL
I D40540P		AE0402A	POS 32	D40540J	W0422	ALL
I D41440P		AE0402A	POS 38	D41440J	W0420	ALL
I D46114P		AJ0046B	POS 15	D46114J	W0066	ALL
I D40536P		AP0600C	POS 09	D40536J	W0044	ALL
I D40538P		AP1800A	POS 05	D40538J	W0018	ALL
I D00096		N00012	P005-10/ /			ALL

### MASTER BUNDLE LIST

D280A351

91-21-13

Section W2210

Page 1

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
W2218	RB2	P5 OVHD PANEL TO EE BAY (E3-1/E4-1/E4-2) RB2 (continued)				
D00616		N00042	P005-02/ /			ALL
D00648		P005-011				ALL
D00634		P005-04	P005-00/ /			ALL
D00730		P005-04	P005-00/ /			ALL
D00636		P005-05	P005-00/ /			ALL
D10726		P005-06	P005-00/ /			ALL
D00644		P005-09	P005-00/ /			ALL
D00680		P005-10	P005-00/ /			ALL
D00650		P005-12	P005-00/ /			ALL
D02351		P005-18	P005-00/ /			ALL
D03172		P005-68	P005-00/ /			ALL
D03072		R00334	P005-00/ /			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W2210

Page 2 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W2221	SA2	AUTOPILOT P9 TO E1-1				
I D40133P		AE0101A	POS 09	D40133J	W0111	ALL
I D40019P		AE0101A	POS 30	D40019J	W0111	ALL
I D04221P		AP0900A	POS 09	D04221J	W0001	ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W2220

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W2231	RB2	RIGHT AC ELEX PWR FROM P6 TO E3.				
I D46017P		AE0301A	POS 23	D46017J	W0313	ALL
I D46021P		AE0302A	POS 25	D46021J	W0321	ALL
I D43309P		AE0303A	POS 29	D43309J	W0331	YT101-YT103
I D43309P		AE0303A	POS 52	D43309J	W0331	YT104-YT133
I D46067P		AP0600B	POS 10	D46067J	W0044	ALL
I W2237	NB2	SECONDARY CDS-DEU TO P3				
I D04297P		AE0301A	POS 31	D04297J	W0313	ALL
I D04237P		AP0900A	POS 06	D04237J	W0003	ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W2230

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W2247	NB2	ATC NO.2 (E1-5 TO P8-29)				
I D41517J		AE0105A	POS 08	D41517P	W0151	ALL
I D40103P		AJ0046A	POS 09	D40103J	W0066	ALL
I D00519		P008-29	P008-29/ /			ALL
I D10204		S00942	316/163/L025			ALL
I D10206		S00943	316/163/L025			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W2240

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W2251	RF2	AUTOPILOT P3 TO E1-4				
I D04311J		AE0104A	POS 06	D04311P	W0141	ALL
I D04251P		AP0900A	POS 23	D04251J	W0003	ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W2250

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W2265	NA2	ADF-1 ELEX PNL TO E3-1				
I D42005P		AE0301A	POS 12	D42005J	W0311	ALL
I D03659		P008-70	P008-00/ /			ALL
I W2267	NB2	ADF-2 ELEX PNL TO E3-1				
I D42007P		AE0301A	POS 25	D42007J	W0313	ALL
I D03661		P008-70	P008-00/ /			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W2260

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W2307	SN2	HANDSET/MIC JACK - CONTROL STAND (P8)				
I D06019			P008-00/ /			ALL
I D07015		66-16842				ALL
I D07017		66-16842				ALL
I D07019		66-16842				ALL
I D07021		66-16842				ALL
I D04149P		AE0103A	POS 13	D04149J	W0131	ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W2300

Page 1 End

Jun 21/2016





## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W2363	LE2	AUTO PILOT CONTROL PANEL SYSTEM A				
I D04069P		AE0101A	POS 29	D04069J	W0111	ALL
I D00299		M00198	P007-00/ /			ALL
I D00301		M00198	P007-00/ /			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W2360

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W2383	RB2	RIGHT DC ELEX PWR FROM P6 TO E1 AND P9.				
I D46023P		AE0101B	POS 09	D46023J	W0111	ALL
I D46031J		AE0104A	POS 10	D46031P	W0141	ALL
I D46065P		AP0600B	POS 15	D46065J	W0044	ALL
I D46033P		AP0900A	POS 16	D46033J	W0003	ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W2380

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W2413	NA2	RADIO TUNING PANEL 1 (P8-71) TO E3-3				
I D43363P		AE0303A	POS 33	D43363J	W0331	YT104-YT133
I D43363P		AE0303A	POS 48	D43363J	W0331	YT101-YT103
I D43365P		AE0303A	POS 49	D43365J	W0331	YT101-YT103
I D00203		P008-71	P008-00/ /			ALL
I D10601		P008-71	P008-00/ /			ALL
I W2415	NB2	RADIO COMM 2 CONTROL PNL				
I D43355P		AE0303A	POS 32	D43355J	W0331	YT104-YT133
I D43355P		AE0303A	POS 46	D43355J	W0331	YT101-YT103
I D43357P		AE0303A	POS 47	D43357J	W0331	YT101-YT103
I D00209		P008-72	P008-72/ /			ALL
I D10603		P008-72	P008-72/ /			ALL
I W2417	NC2	RADIO COMM 3 CONTROL PNL				
I D43391P		AE0303A	POS 07	D43391J	W0331	YT101-YT103
I D43329P		AE0303A	POS 15	D43329J	W0331	ALL
I D43391P		AE0303A	POS 24	D43391J	W0331	YT104-YT133
I D00549		P008-73	P008-73/ /			ALL
I D10605		P008-73	P008-73/ /			ALL
I W2419	NN2	FLIGHT RECORDER E3-2 SHELF TO TEST CONNECTOR				
I D43219P		AE0302A	POS 13	D43219J	W0321	ALL
I D01637		M01252	P018-02/ /			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W2410

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W2465	RF2	AUTOPILOT CONTROL PANEL SYSTEM - B				
I D08019J		AE0104A	POS 01	D08019P	W0141	ALL
I D01815		M00198	P007-00/ /			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W2460

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W2508	SA2*	P5 OVHD PANEL TO EE BAY (E1-4/E4-1) SA2				
I D40556J		AE0104A	POS 23	D40556P	W0141	ALL
I D40554P		AE0401A	POS 43	D40554J	W0410	ALL
I D46108P		AJ0046A	POS 15	D46108J	W0066	ALL
I D48106P		AJ0048A	POS 14	D48106J	W0088	ALL
I D40550P		AP0600C	POS 05	D40550J	W0044	ALL
I D00432		N00020	P005-14/ /			ALL
I D00918		N00074	212/258/000			ALL
I D00626		P005-02	P005-00/ /			ALL
I D01086		P005-05	P005-00/ /			ALL
I D00652		P005-13	P005-00/ /			ALL
I D10596		P005-13	P005-00/ /			ALL
I D00440		P005-14	P005-00/ /			ALL
I D00654		P005-16	P005-00/ /			ALL
I D00483		P005-19	P005-19/ /			ALL
I D00482		P005-20	P005-00/ /			ALL
I D02921		P005-81	P005-00/ /			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W2500

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W2510	SB2*	P5 OVHD PANEL TO EE BAY (E1-4/E4-1) SB2				
I D40560J		AE0104A	POS 14	D40560P	W0141	ALL
I D40562P		AE0401A	POS 47	D40562J	W0410	ALL
I D46126P		AJ0046B	POS 13	D46126J	W0066	ALL
I D40558P		AP0600C	POS 08	D40558J	W0044	ALL
I D00628		P005-02	P005-00/ /			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W2510

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W2527	NA2	CDS - DEU 1 OUTPUT 1 TO COAX SPLITTER 1				
I D40101P		AE0301A	POS 04	D40101J	W0311	ALL
I D10029		M01810	193/219/L007			ALL
I W2529	NB2	CDS - DEU 1 OUTPUT 2 TO COAX SPLITTER 2				
I D40201P		AE0301A	POS 40	D40201J	W0313	ALL
I D10043		M01811	197/218/R007			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W2520

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W2531	ND2	CDS - DEU 2 OUTPUT 2 TO COAX SPLITTER 3				
I D40301P		AE0301A	POS 05	D40301J	W0311	ALL
I D10057		M01812	193/218/L007			ALL
I W2532	SN2	J9 BATTERY SHIELD				
I D48108P		AJ0048A	POS 15	D48108J	W0088	ALL
I W2533	NC2	CDS - DEU 2 OUTPUT 1 TO COAX SPLITTER 4				
I D40401P		AE0301A	POS 41	D40401J	W0313	ALL
I D10071		M01813	197/216/R007			ALL
I W2536	SN2	J9 BATTERY SHIELD				
I D00046		M00009	E002-02/184/L040			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W2530

Page 1 End

Jun 21/2016





## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W2589	NN2	ELT CONTROL PANEL(LEFT SIDE)				
I D04889P		AB0288	POS 03	D04889J	W3419	ALL
I D02889		P005-80	P005-00/ /			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W2580

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W2597	NA2	E5-2, P61 (DATA LOADER)				
I D40769P				D40769J	W0041	YT104-YT133
I D45225J		AE0502A	POS 09	D45225P	W0521	YT104-YT133
I D45293J		AE0502A	POS 11	D45293P	W0521	YT104-YT133
		AE0502A	POS 21	D45225P	W0521	YT101-YT103
		AE0502A	POS 23	D45293P	W0521	YT101-YT103
I D40625P		AP0600B	POS 13	D40625J	W0041	ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W2590

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W2651	SA2	STBY ELEX PWR FROM P18 TO E1 AND P9.				
I D41827J		AE0102A	POS 06	D41827P	W0121	ALL
I D41831P		AE0103A	POS 17	D41831J	W0131	ALL
I D41833P		AP0900A	POS 19	D41833J	W0001	ALL
I D41807P		AP1800B	POS 08	D41807J	W0018	ALL
I W2653	SA2	STBY ELEX PWR FROM P18 TO E3.				
I D41837P		AE0301A	POS 22	D41837J	W0311	ALL
I D41839P		AE0302A	POS 26	D41839J	W0321	ALL
I D41809P		AP1800B	POS 09	D41809J	W0018	ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W2650

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W2661	SB2	STBY ELEX PWR FROM P6 TO E1.				
I D46051P		AE0103A	POS 03	D46051J	W0131	ALL
I D46069P		AP0600B	POS 20	D46069J	W0044	ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W2660

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W2702	AN2	P5 OVHD PANEL TO EE BAY (E2-1) AN2				
I D40564P		AE0201A	POS 05	D40564J	W0212	ALL
I D00446		N00024	P005-04/ /			ALL
I W2705	NA2	HGS OVERHEAD UNIT TO E1-3 (DEU) AND E4-1 (HGS COMPUTER)				
I D00803		AB0237A	POS 03			ALL
I D40023P		AE0302A	POS 08	D40023J	W0321	ALL
I D40021P		AE0302A	POS 21	D40021J	W0321	ALL
I D00403		AE0401D	POS 03			ALL
I D00414		AE0401D	POS 04			ALL
I D00405		AE0401D	POS 05			ALL
I D00406		AE0401D	POS 06			ALL
I D00416		AE0401D	POS 09			ALL
I D00409		AE0401D	POS 16			ALL
I D00308		AP0900A	POS 08			ALL
I D00901		OVHD DISC				ALL
I W2709	NB2	HUD SYSTEM P3, P61, AND E4-1 (HGS COMPUTER) RIGHT SIDE				
I D40027P		AE0302A	POS 34	D40027J	W0321	ALL
I D40232P		AE0302A	POS 50	D40232J	W0321	ALL
I D00413		AE0401D	POS 13			ALL
I D00404		AE0401D	POS 14			ALL
I D00415		AE0401D	POS 15			ALL
I D40067P		AP0600B	POS 01	D40067J	W0041	ALL
I D00322		AP0900A	POS 22			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W2700

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W2805	NN2	ACMS PRINTER				
I D43215P		AE0302A	POS 09	D43215J	W0321	YT101-YT103
I D43215P		AE0302A	POS 17	D43215J	W0321	YT104-YT133
I D02649		M02195	P008-54/ /			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W2800

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W2873	NB2	FROM FMC TO CONTROL STAND MCDU - NO.2				
I D08105J		AE0502A	POS 09	D08105P	W0523	YT101-YT103
I D08105J		AE0502A	POS 32	D08105P	W0523	YT104-YT133
I D02221		P009-66	P009-66/ /			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W2870

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W2889	NA2	FROM FMC TO CONTROL STAND MCDU - NO.1				
I D02803		AB0237A	POS 03			ALL
I D05925J		AE0502A	POS 10	D05925P	W0521	YT104-YT133
I D05925J		AE0502A	POS 22	D05925P	W0521	YT101-YT103
I D02181		P009-65	P009-65/ /			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W2880

Page 1 End

Jun 21/2016





## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W3004	NN2	-800 CVR/RIPS				
I D40751J				D40751P	W5431	ALL
I D40687P		AP1800A	POS 12	D40687J	W0018	ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W3000

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W3058	RN2	ATT PANEL SHIP WIRE BUNDLE				
I D07164J				D07164P	W5124	YT101-YT131
I D07166J				D07166P	W4258	YT101-YT131
I D07168J				D07168P	W4258	YT101-YT131
I D40026P				D40026J	W0152	YT101-YT131
I D40148P				D40148J	W5146	YT101-YT131
I D41062P				D41062J	W4166	YT101-YT131
I D41070P				D41070J	W4246	YT101-YT131
I D41072P				D41072J	W0156	YT101-YT131
I D41074P				D41074J	W0158	YT101-YT131
I D41076P				D41076J	W3166	YT101-YT131
I D41078P				D41078J	W0160	YT101-YT131
I D41082P				D41082J	W0142	YT101-YT131
I D40054J		AB0340A	POS 01	D40054P	W5142	YT101-YT131
I D40170J		AB0340A	POS 04	D40170P	W2218	YT101-YT131
I D40050J		AB0340A	POS 05	D40050P	W6242	YT101-YT131
I D43922P		AJ0039B	POS 03	D43922J	W0084	YT101-YT131
I D40226P		AP0600A	POS 05	D40226J	W0044	YT101-YT131
I D12416		M01415	//			YT101-YT118, YT126-YT131
I D14364		M01415	//			YT101-YT131
I D14368		M01415	//			YT101-YT131
I D14370		M01415	//			YT101-YT131
I D14372		M01418	948/236/L014			YT101-YT131
I D14376		M01418	948/236/L014			YT101-YT131
I D14378		M01418	948/236/L014			YT101-YT131
I D14612		M02809	MULTI/290/			YT101-YT131

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W3050

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
<b>I W3141</b>	<b>NA2</b>	<b>GLIDE SLOPE ANT LEFT - STA 178 TO E1-2 SHELF</b>				
I D03317				D02621		ALL
I D04025J		AE0102B	POS 07	D04025P	W0121	ALL
<b>I W3142</b>	<b>LN2</b>	<b>EMERGENCY EXIT LIGHT - LEFT</b>				
I D14698				D14816		ALL
I D14702				D14816		ALL
I D14828				D14816		ALL
I D14834				D14816		ALL
I D14838				D14816		ALL
I D40009J				D40009P	W3309	ALL
I D40044P				D40044J	W0452	ALL
I D40098J				D40098P	W4142	ALL
I D46438P				D46438J	W4142	ALL
I D46440P				D46440J	W4142	ALL
I D12350			360/284/L031			ALL
I D12748			368/214/L068			ALL
I D14694			461/295/L025			ALL
I D14712			727B+2/289/L018			ALL
I D40196J		AB0340A	POS 03	D40196P	W2114	ALL
I D40096P		AB0340B	POS 01	D40096J	W4142	ALL
I D12036		L00006	651/227/L074			ALL
I D11082		L00547	727F+11/169/L051			ALL
I D11080		L00548	727F+11/170/R052			ALL
I D11074		L00731	365/226/L072			ALL
I D11086		L00732	1000/242/L060			ALL
I D15242		L01070	620/288/0000			ALL
I D03670		L01189	614/224/L062			ALL
I D03672		L01189	614/224/L062			ALL
I D10082		L01190	993/244/L053			ALL
I D10084		L01190	993/244/L053			ALL
I D12068		L01208	576/224/L062			ALL
I D12072		L01208	576/224/L062			ALL
I D12032		L01210	608/227/L074			ALL
I D12434		L01359				ALL
I D12436		L01359				ALL
I D12442		L01365	MULTI/ /			ALL
I D12444		L01365	MULTI/ /			ALL
I D12448		L01365	MULTI/ /			ALL
I D12450		L01365	MULTI/ /			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W3140

Page 1

Jun 21/2016



Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
<b>W3142</b>	<b>LN2</b>	<b>EMERGENCY EXIT LIGHT - LEFT (continued)</b>				
D14692		L01506	462/289/L006			ALL
D14710		L01515	727A+10/289/L006			ALL
D14720		L01520				ALL
D12052		M01386				ALL
D13124		M01389				ALL
D10716		M01670	727C+13/212/L068			ALL
D10746		M01673	952/290/L014			ALL
D12008		M01694	565/213/L068			ALL
D12552		M02176	617/251/L066			ALL
D12554		M02176	617/251/L066			ALL
D12576		M02182	579/251/L066			ALL
D12578		M02182	579/251/L066			ALL
D12664		M02204	638/251/L066			ALL
D12666		M02204	638/251/L066			ALL
D12668		M02205	581/229/L069			ALL
D12670		M02205	581/229/L069			ALL
D12672		M02206	639/229/L069			ALL
D12674		M02206	639/229/L069			ALL
D12700		M02213	600/251/L066			ALL
D12702		M02213	600/251/L066			ALL
D12704		M02214	543/229/L069			ALL
D12706		M02214	543/229/L069			ALL
D12708		M02215	560/229/L069			ALL
D12710		M02215	560/229/L069			ALL
D12802		M02253				ALL
D12828		M02267				ALL
D13018		M02335	500C+7/213/L067			ALL
D13258		M02400				ALL
D14842		M02837	637/269/59			ALL
D14726		M02838	627/269/59			ALL
<b>W3143</b>	<b>NB2</b>	<b>GLIDE SLOPE ANT RIGHT - STA 178 TO E1-3 SHELF</b>				
D03319				D02625		ALL
D04027J		AE0102B	POS 06	D04027P	W0141	ALL
<b>W3144</b>	<b>LN2*</b>	<b>P18 TO FWD AND AFT LAVATORY</b>				
D07106J				D07106P	W5124	ALL
D07108J				D07108P	W5124	ALL
D07162P				D07162J	W4166	ALL

## MASTER BUNDLE LIST

D280A351

91-21-13

Section W3140

Page 2

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
<b>W3144</b>	<b>LN2*</b>	<b>P18 TO FWD AND AFT LAVATORY (continued)</b>				
D07170J				D07170P	W4142	ALL
D07172J				D07172P	W7359	ALL
D07176P				D07176J	W3150	ALL
D11722				D11724		YT126-YT133
D40116J				D40116P	W3158	ALL
D40150P				D40150J	W5146	ALL
D40270J				D40270P	W3150	ALL
D40272J				D40272P	W4250	ALL
D03802			1000/295/R024			ALL
D11722			352/279/L030			YT101-YT120
D40216P		AB0340A	POS 02	D40216J	W3158	ALL
D40349J		AB0358	POS 09	D40349P	W3805	ALL
D40220P		AP1800A	POS 06	D40220J	W0018	ALL
D03732		M01415	/ /			ALL
D03738		M01418	948/236/L014			ALL
D03740		M01419	/ /			ALL
D10770		M01681	975/297/R010			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W3140

Page 3 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W3150	LN2*	P18 AND AB0340A DISC TO LEFT PSU'S				
I D07176J				D07176P	W3144	ALL
I D40104J				D40104P	W3158	ALL
I D40109J				D40109P	W3158	ALL
I D40270P				D40270J	W3144	ALL
I D11500			367/272/L055			ALL
I D11502			374/272/L056			ALL
I D11504			402/278/L050			ALL
I D11506			430/274/L051			ALL
I D11508			450/274/L051			ALL
I D11510			470/274/L051			ALL
I D11512			490/274/L051			ALL
I D11514			500+10/274/L051			ALL
I D11516			500A+12/274/L051			ALL
I D11518			500B+12/274/L051			ALL
I D11520			500C+12/274/L051			ALL
I D11522			500D+12/274/L051			ALL
I D11524			500E+16/274/L051			ALL
I D11526			500F+14/274/L051			ALL
I D11528			500G+10/274/L051			ALL
I D11530			500H+6/274/L052			ALL
I D11532			500I+16/273/L054			ALL
I D11534			531/273/L054			ALL
I D11536			565/274/L051			ALL
I D11538			588/274/L051			ALL
I D11540			611/274/L051			ALL
I D11542			630/274/L051			ALL
I D11544			660/274/L051			ALL
I D11546			680/274/L051			ALL
I D11548			700/274/L051			ALL
I D11550			726/272/L054			ALL
I D11552			727+10/274/L051			ALL
I D11554			727A+16/272/L054			ALL
I D11556			727B+10/274/L051			ALL
I D11558			727C+10/274/L051			ALL
I D11560			727D+10/274/L051			ALL
I D11562			727E+10/274/L051			ALL
I D11564			727F+10/274/L051			ALL
I D11566			727G+12/272/L054			ALL
I D11568			727H+8/272/L054			ALL
I D11570			727I+16/272/L054			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W3150

Page 1

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
<b>W3150</b>	<b>LN2*</b>	<b>P18 AND AB0340A DISC TO LEFT PSU'S (continued)</b>				
D11572			727J+8/272/L054			ALL
D11574			763/272/L054			ALL
D11576			775/272/L054			ALL
D11578			802/274/L051			ALL
D11580			822/274/L051			ALL
D11582			842/274/L051			ALL
D11584			865/274/L051			ALL
D11586			898/274/L056			ALL
D11588			924/274/L051			ALL
D11590			943/277/L050			ALL
D40108P		AB0340A	POS 06	D40108J	W3158	ALL
D40198P		AP1800A	POS 01	D40198J	W0018	ALL
<b>W3154</b>	<b>LN1*</b>	<b>P91 TO AFT GALLEY POWER</b>				
D10076			1000/295/R024			ALL
D03800			998/295/R025			ALL
D11430		P0091				ALL
<b>W3158</b>	<b>LN1*</b>	<b>AB0340A DISCONNECT TO LEFT AFT OVERHEAD</b>				
D40104P				D40104J	W3150	ALL
D40109P				D40109J	W3150	ALL
D40116P				D40116J	W3144	ALL
D41064P				D41064J	W3166	ALL
D41066P				D41066J	W4166	ALL
D41084P				D41084J	W4166	ALL
D41086P				D41086J	W3166	ALL
D40216J		AB0340A	POS 02	D40216P	W3144	ALL
D40108J		AB0340A	POS 06	D40108P	W3150	ALL
D40102J		AB0340A	POS 09	D40102P	W5142	ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W3150

Page 2 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W3166	LN2*	LED LIGHTING - CEILING/WASH LEFT				
I D14804				D14682		ALL
I D14806				D14448		ALL
I D14808				D14688		ALL
I D14866				D14682		ALL
I D14868				D14448		ALL
I D14870				D14688		ALL
I D14896				D14742		ALL
I D14898				D14746		ALL
I D41064J				D41064P	W3158	ALL
I D41076J				D41076P	W3058	YT101-YT131
I D41086J				D41086P	W3158	ALL
I D41076J			466/296/L024	D41076P		YT132-YT133
I D14464		M02801	MULTI/296/27			ALL
I D14810		M02801	MULTI/296/27			ALL
I D14856		M02801	MULTI/296/27			ALL
I D14858		M02801	MULTI/296/27			ALL
I D14872		M02801	MULTI/296/27			ALL
I D14876		M02801	MULTI/296/27			ALL
I D14878		M02801	MULTI/296/27			ALL
I D14880		M02801	MULTI/296/27			ALL
I D14882		M02801	MULTI/296/27			ALL
I D14884		M02801	MULTI/296/27			ALL
I D14960		M02801	MULTI/296/27			ALL
I D14962		M02801	MULTI/296/27			ALL
I D14964		M02801	MULTI/296/27			ALL
I D14966		M02801	MULTI/296/27			ALL
I D14968		M02801	MULTI/296/27			ALL
I D14980		M02801	MULTI/296/27			ALL
I D14982		M02801	MULTI/296/27			ALL
I D14468		M02826	MULTI/296/27			ALL
I D14492		M02826	MULTI/296/27			ALL
I D15394		M02868	MULTI/296/27			ALL
I D15416		M02868	MULTI/296/27			ALL
I D15258		M02872	MULTI/296/27			ALL
I D15374		M02872	MULTI/296/27			ALL
I D15396		M02872	MULTI/296/27			ALL
I D15398		M02872	MULTI/296/27			ALL
I D14798		M02876	MULTI/296/27			ALL
I D15378		M02876	MULTI/296/27			ALL
I D15390		M02876	MULTI/296/27			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W3160

Page 1

Jun 21/2016





## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
W3166	LN2*	LED LIGHTING - CEILING/WASH LEFT (continued)				
D15392		M02876	MULTI/296/27			ALL
D15282		M02877	MULTI/296/27			ALL
D15304		M02877	MULTI/296/27			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W3160

Page 2 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W3170	LA2*	AB0420A TO E2-2 SHELF				
I D40734P		AB0420A	POS 01	D40734J	W5170	ALL
I D40736P		AB0420A	POS 02	D40736J	W5172	ALL
I D40126P		AE0202A	POS 27	D40126J	W0220	ALL
I D49994P		AE0301A	POS 14	D49994J	W0311	ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W3170

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W3246	RN2	LED LIGHTING - SIDEWALL LEFT				
I D07178J				D07178P	W4258	ALL
I D14578			419/269/L059			ALL
I D14580			419/269/L059			ALL
I D14590			419/269/L059			ALL
I D14582			590/269/L059			ALL
I D14584			628/269/L059			ALL
I D14586			866/269/L059			ALL
I D14588			866/269/L059			ALL
I D14668		M02807	MULTI/290/			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W3240

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W3307	NN2	INPH, ELEX PNL AND FWD ATTD PNL				
I D41337P		AE0103A	POS 09	D41337J	W0131	ALL
I D45905P		AE0801B	POS 01	D45905J	W0811	ALL
I D14366		M01415	/ /			ALL
I D13363		M02932	347/299/R010			ALL
I W3309	NN2	ATTENDANTS SPEAKERS				
I D40005P				D40005J	W4142	ALL
I D40007P				D40007J	W4142	ALL
I D40009P				D40009J	W3142	ALL
I D44139P		AE0401A	POS 27	D44139J	W0411	ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W3300

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W3311	SN2	AFT ATTENDANTS HANDSET (P14)				
I D14407J				D14407P	W3377	YT107-YT133
I D14409J				D14409P	W3377	YT107-YT133
I D04181P		AE0103A	POS 21	D04181J	W0131	ALL
I D14374		M01418	948/236/L014			ALL
I D11815		M02931	920/295/L034			ALL
I D11173		M1419				ALL
I W3319	NB3	F/O AUDIO SEL PNL TO INPH				
I D04331P		AE0401A	POS 20	D04331J	W0411	ALL
I D00129		M00078	226/268/R020			ALL
I D06043		M244				ALL
I D06033		M295				ALL
I D06029		M429				ALL
I D00135		P008-07	P008-07/ /			ALL
I D00137		P008-07	P008-07/ /			ALL
I D06051		P23-7				ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W3310

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W3323	NA3	CAPT AUDIO SEL PNL TO INPH				
I D04155P		AE0401A	POS 18	D04155J	W0411	ALL
I D00127		M00077	226/268/L015			ALL
I D06041		M00243	/ /			ALL
I D06027		M00428	254/ /			ALL
I D00131		P008-06	P008-06/ /			ALL
I D00133		P008-06	P008-06/ /			ALL
I D06031		P008-06	P008-06/ /			ALL
I D06049		P21-7 OXY				ALL
I W3327	NC3	F/OBS FLIGHT INPH				
I D04153P		AE0401A	POS 22	D04153J	W0411	ALL
I D04151P		AP0600C	POS 06	D04151J	W0041	ALL
I D00139		P005-15	P005-00/ /			ALL
I D00141		P5-15				ALL
I W3329	NN2	VOICE RECORDER CONTROL PNL				
I D04157P		AE0401A	POS 28	D04157J	W0411	ALL
I D00179		P005-07	P005-00/ /			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W3320

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W3377	LA3	AUTOPILOT E1-1 TO AB1050L				
I D14407P				D14407J	W3311	YT107-YT133
I D14409P				D14409J	W3311	YT107-YT133
I D43397P		AB1050L	POS 03	D43397J	W3397	ALL
I D04079P		AE0101A	POS 32	D04079J	W0111	ALL
I D40025P		AE0302A	POS 10	D40025J	W0321	ALL
I W3379	RB3	AUTOPILOT E1-4 TO AB1050R				
I D43399P		AB1050R	POS 04	D43399J	W3399	ALL
I D04081J		AE0104A	POS 03	D04081P	W0141	ALL
I D40029P		AE0302A	POS 35	D40029J	W0321	ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W3370

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W3381	LE2	AUTOPILOT STAB TRIM CIRCUIT, E1-1 TO AB1050L				
I D44381P		AB1050L	POS 04	D44381J	W3391	ALL
I D04083P		AE0101A	POS 26	D04083J	W0111	ALL
I D48901P		AP1800A	POS 02	D48901J	W0018	ALL
I W3387	NA2	AUTOPILOT AB0180, PRESS. SEAL TO ELEV AND RUD PCU A SYSTEM - A				
I D43387P		AB1080	POS 02	D43387J	W3397	ALL
I D00291		M00175	1087/ /			ALL
I W3389	NB2	AUTOPILOT AB1080, PRESS. SEAL TO ELEV AND RUD PCU A SYSTEM - B				
I D43389P		AB1080	POS 03	D43389J	W3399	ALL
I D10013		M1831				ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W3380

Page 1 End

Jun 21/2016





## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W3391	LE2	AUTOPILOT AB1050L, STAB TRIM CIRCUIT				
I D44381J		AB1050L	POS 04	D44381P	W3381	ALL
I D00381		M01659	1076/264/R005			ALL
I W3393	LG2	MACH TRIM SERVO, AB1050L TO STA 1156				
I D43393J		AB1050L	POS 02	D43393P	W5301	ALL
I D00545		M00414	1164/276/			ALL
I W3397	LA3	AUTOPILOT AB1050L TO ELEV AND RUD PCU SYSTEM -A				
I D43397J		AB1050L	POS 03	D43397P	W3377	ALL
I D43387J		AB1080	POS 02	D43387P	W3387	ALL
I D01711		M00929	1158/258/R010			ALL
I D01829		M00958	1160/274/R005			ALL
I D01681		M01020	1165/278/L007			ALL
I D02205		M01192	1164/268/L008			ALL
I D11409		M02373	1085/264/L027			ALL
I D01861		S00771	1165/282/L010			ALL
I W3399	RB3	AUTOPILOT AB1050R ELEV AND STANDBY RUDDER PCU, SYSTEM - B				
I D43399J		AB1050R	POS 04	D43399P	W3379	ALL
I D43389J		AB1080	POS 03	D43389P	W3389	ALL
I D01679		M00929	1158/258/R010			ALL
I D01677		M00958	1160/274/R005			ALL
I D01687		M01022	1161/287/L007			ALL
I D02207		M01193	1164/268/R008			ALL
I D01857		S00773	1158/287/L010			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W3390

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W3419	NN2	EMERGENCY LOCATOR TRANSMITTER				
I D04889J		AB0288	POS 03	D04889P	W2589	ALL
I D03003		M01523	794/301/L010			ALL
I D11993		M02114	794/301/L010			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W3410

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
<b>W3450</b>	<b>RN1</b>	<b>IFE - (BSI) FWD MCU POWER FEEDER J4 TO STA 500</b>				
D45465J		AB0450R	POS 01	D45465P	W3623	YT101-YT120
D41002P		AJ0004	POS 02	D41002J	W0094	YT101-YT120
<b>W3453</b>	<b>NN2</b>	<b>IFE - SPLICE BUNDLE FROM J4 JUNCTION BOX DISC. TO W6222 AND W3477</b>				
D07099J				D07099P	W6222	ALL
D07113P				D07113J	W3755	ALL
D47019J				D47019P	W6222	ALL
D47029P				D47029J	W3477	ALL
D47035P				D47035J	W3477	ALL
D40662P		AJ0004	POS 12	D40662J	W0094	ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W3450

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W3477	NN2	IFE -(BSI) DIGITAL VIDEO SYSTEM INTEGRATION (-800)				
I D47029J				D47029P	W3453	ALL
I D47035J				D47035P	W3453	ALL
			390/216/L068			YT101-YT120
			390/216/R068			YT101-YT120
			500A+11/217/L068			YT101-YT104
			500A+11A/217/R068			YT101-YT104
			500A/217/L068			YT105-YT120
			500A/217/R068			YT105-YT120
		AA0375R	POS 01	D45011J	W3587	YT101-YT120
		AA0375R	POS 02	D45431J	W3587	YT101-YT120
		AA0375R	POS 03	D45447J	W3587	YT101-YT120
I D12897J		AB0366	POS 01	D12897P		YT126-YT133
I D45449J		AB0366	POS 02	D45449P		YT126-YT133
I D40011J		AB0366	POS 03	D40011P		YT126-YT133
I D12899J		AB0373	POS 01	D12899P	W3649	ALL
I D12887J		AB0373	POS 02	D12887P	W3639	ALL
I D45485J		AB0373	POS 04	D45485P	W3639	ALL
		AB0373	POS 05	D12883P	W3695	YT101-YT120
I D12883J		AB0373	POS 05	D12883P	W3639	YT126-YT133
I D12885J		AB0373	POS 06	D12885P	W3639	ALL
		AB0373	POS 07	D12889P	W3695	YT101-YT120
I D12889J		AB0373	POS 07	D12889P		YT126-YT133
		AB0373	POS 08	D12891P	W3639	YT101-YT120
I D12891J		AB0373	POS 08	D12891P		YT126-YT133
		AB0373	POS 09	D12893P	W3755	YT101
I D12893J		AB0373	POS 09	D12893P		YT105-YT133
I D12895J		AB0373	POS 10	D12895P	W3649	ALL
		AB0373	POS POS 09	D12893P	W3755	YT102
		AB0373	POS POS 09	D12893P	W3755	YT102
		AB0373	POS POS 09	D12893P	W3755	YT102
		AB0373	POS POS 09	D12893P		YT103-YT104
		AB0450R	POS 04	D45403P	W3623	YT101-YT120
		AB0450R	POS 05	D45463P	W3623	YT101-YT120
		AB0857L	POS 05	D40335P	W3625	YT101-YT120
I D45227P		AE0103A	POS 16	D45227J	W0131	ALL
I D47031P		AE0801A	POS 01	D47031J	W0811	ALL
		AE0801A	POS 20	D45489J	W0811	YT101-YT120
I D45912P		AE0801B	POS 06	D45912J	W0811	ALL
		AE0801B	POS 07	D45183J	W0811	YT101-YT120
I D45167P		AE0801B	POS 08	D45167J	W0811	ALL

### MASTER BUNDLE LIST

D280A351

91-21-13

Section W3470

Page 1

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
<b>W3477</b>	<b>NN2</b>	<b>IFE -(BSI) DIGITAL VIDEO SYSTEM INTEGRATION (-800) (continued)</b>				
D45185P		AE0801B	POS 09	D45185J	W0811	YT101-YT120
D45169P		AE0801B	POS 12	D45169J	W0811	ALL
D45193P		AE0801B	POS 15	D45193J	W0811	YT101-YT120
D45489P		AE0801B	POS 15	D45489J		YT126-YT133
<b>W3479</b>	<b>NN2</b>	<b>IFE - (BSI) FWD MCU DISCONNECT TO SIDEWALL DISCONNECTS</b>				
D12923			390/ /			YT105-YT120
D12903			390/210/L070			YT101-YT120
D12923			390/215/R068			YT101-YT104
D45411J		AB0450R	POS 02	D45411P	W3623	YT101-YT120

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W3470

Page 2 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
<b>W3483</b>	<b>NN2</b>	<b>IFE - (BSI) AFT MCU DISCONNECT TO SIDEWALL DISCONNECTS</b>				
D13541			500A+10/210/L070			YT101-YT120
D13539			500A+10/210/R069			YT105-YT120
D13539			500A+10/210/R69			YT101-YT104
D12913			675/210/L070			YT105-YT120
D12933			675/210/R069			YT101-YT120
D12913			680/210/L070			YT101-YT104
D45415J		AB0857L	POS 02	D45415P	W3625	YT101-YT120
D45417J		AB0857L	POS 03	D45417P	W3625	YT101-YT120
<b>W3485</b>	<b>RN1</b>	<b>IFE - (BSI) SIDEWALL TO SEAT INTERFACE RH (STA 500E+15) GROUND</b>				
D12925			500E+15/ /			YT101-YT120
<b>W3489</b>	<b>RN1</b>	<b>IFE - (BSI) SIDEWALL TO SEAT INTERFACE LH (STA 500E+15) GROUND</b>				
D12905			500E+15/217/L068			YT101-YT120

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W3480

Page 1 End

Mar 14/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W3553	LN2	HF-1 E6-2 TO STA 1030				
I D04227J		AB1030A	POS 03	D04227P	W7057	ALL
I D40121P		AE0602A	POS 12	D40121J	W0621	ALL
I W3555	RN2	HF-2 E6-2 TO STA 1030				
I D04245J		AB1030A	POS 01	D04245P	W7061	ALL
I D40125P		AE0602A	POS 11	D40125J	W0621	ALL
I W3557	NA2	HF-1 E6-2 TO STA 1030 ANT FEED				
I D04217J		AB1030A	POS 04	D04217P	W7761	ALL
I D40123P		AE0602A	POS 02	D40123J	W0621	ALL
I W3559	NA2	HF-2 E6-2 COAX TO STA 1030 ANT FEED				
I D04713J		AB1030A	POS 02	D04713P	W7763	ALL
I D40127P		AE0602A	POS 01	D40127J	W0621	ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W3550

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
<b>W3587</b>	<b>NN2</b>	<b>IFE - HDD-OML IN GALLEY G2 WITH INTEGRAL CLOSET (STA336-381R)</b>				
DB13513			500B+9/ /			YT101-YT120
D45011J		AA0375R	POS 01	D45011P	W3477	YT101-YT120
D45431J		AA0375R	POS 02	D45431P	W3477	YT101-YT120
D45447J		AA0375R	POS 03	D45447P	W3477	YT101-YT120
DA13513		M02886	G2/ /			YT101-YT120

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W3580

Page 1 End

Mar 14/2016





## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W3607	NA2	GPS ANT-1				
I D42941J		AE0102B	POS 08	D42941P	W0121	ALL
I D02941		M02103	500A/316/L005			ALL
I W3609	NB2	GPS ANT-2				
I D42943J		AE0102B	POS 03	D42943P	W0141	ALL
I D02947		M02102	500A/316/R005			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W3600

Page 1 End

Jun 21/2016



Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
<b>W3623</b>	<b>NN2</b>	<b>IFE-(BSI) IVS ENTERTAINMENT SYS - FWD MCU DISCONNECT TO FWD MCU</b>				
D45465P		AB0450R	POS 01	D45465J	W3450	YT101-YT120
D45411P		AB0450R	POS 02	D45411J	W3479	YT101-YT120
D45403P		AB0450R	POS 04	D45403J	W3477	YT101-YT120
D45463P		AB0450R	POS 05	D45463J	W3477	YT101-YT120
D12355		M02647	500D/304/R001			YT101-YT120
D12357		M02647	500D/304/R001			YT101-YT120
D12365		M02647	500D/304/R001			YT101-YT120
D12369		M02647	500D/304/R001			YT101-YT120
D12371		M02647	500D/304/R001			YT101-YT120
<b>W3625</b>	<b>NN2</b>	<b>IFE-(BSI) IVS ENTERTAINMENT SYS - AFT MCU DISCONNECT TO AFT MCU</b>				
D40297P		AB0857L	POS 01	D40297J	W6212	YT101-YT120
D45415P		AB0857L	POS 02	D45415J	W3483	YT101-YT120
D45417P		AB0857L	POS 03	D45417J	W3483	YT101-YT120
D40335P		AB0857L	POS 05	D40335J	W3477	YT101-YT120
D12373		M02649	907/303/L004			YT101-YT120
D12375		M02649	907/303/L004			YT101-YT120
D12377		M02649	907/303/L004			YT101-YT120
D12379		M02649	907/303/L004			YT101-YT120
D12383		M02649	907/303/L004			YT101-YT120
D12387		M02649	907/303/L004			YT101-YT120
D12389		M02649	907/303/L004			YT101-YT120

## MASTER BUNDLE LIST

D280A351

91-21-13

Section W3620

Page 1 End

Mar 14/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W3649	NN1	IFE -EXTERNAL COMMUNICATION SYSTEM,AB0373 TO M2702 GSM DATA MODEM -800				
I D12899P		AB0373	POS 01	D12899J	W3477	ALL
I D12895P		AB0373	POS 10	D12895J	W3477	ALL
I D11879		M02558	727I+15/305/L008			YT126-YT133
D12857		M02702				YT101-YT104
D12857		M02702	727E+15/305/L008			YT105-YT120

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W3640

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
<b>W3695</b>	<b>NN2</b>	<b>IFE -(BSI) BRKT AB0373 JUMPER BUNDLE FOR HDD-OML</b>				
D12883P		AB0373	POS 05	D12883J	W3477	YT101-YT120
D12889P		AB0373	POS 07	D12889J	W3477	YT101-YT120

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W3690

Page 1 End

Mar 14/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W3701	NN2	VIU/CIU BRACKET STA 344 TO CAMERA 1 BRACKET STA 2XX.				
I D37001J		AB0288	POS 04	D37001P	W3801	ALL
I D40351J		AB0358	POS 02	D40351P	W3805	ALL
I W3702	NN2	VIU/CIU BRACKET STA 344 TO CAMERA 2 BRACKET STA 2XX				
I D40353J		AB0358	POS 01	D40353P	W3805	ALL
I D37002J		AB0358	POS 05	D37002P	W3802	ALL
I W3703	NN2	VIU/CIU BRACKET STA 344 TO CAMERA 3 BRACKET STA 2XX				
I D40355J		AB0358	POS 06	D40355P	W3805	ALL
I D37003J		DISC BRKT		D37003P	W3803	ALL
I W3704	NN2	TRANSFORMER BKT STA 340 TO AP0900A (CAPT. VIDEO DISPLAY)				
I D10030P		AP0900A	POS 25	D10030J	W0001	ALL
I D14818		T3028				ALL
I W3705	NN2	TRANSFORMER BKT STA 340 TO AP0900A (CTR. VIDEO DISPLAY)				
I D10034P		AP0900A	POS 27	D10034J	W0003	ALL
I D14820		T3029				ALL
I W3706	NN2	TRANSFORMER BKT STA 340 TO AP0900A (F/O VIDEO DISPLAY)				
I D10032P		AP0900A	POS 26	D10032J	W0003	ALL
I D14822		T3030				ALL
I W3709	NN2	VIU/CIU BRACKET STA 344 TO THE CAMERA CONTROL PANEL IN THE P8 PANEL				
I D40357J		AB0358	POS 07	D40357P	W3805	ALL
I D12237		M3000				ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W3700

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W3710	NN2	VIU/CIU BRACKET STA 344 TO THE TRANSFORMER'S BRACKETS STA 340				
I D40365J		AB0358	POS 08	D40365P	W3805	ALL
I D12877		T3028				ALL
I D12879		T3029				ALL
I D12881		T3030				ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W3710

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
<b>W3739</b>	<b>NN2</b>	<b>IFE -RIGHT SIDEWALL DISC. (STA430 WL215) TO AB0376R</b>				
D13479J			430/215/R045	D13479P		YT101-YT120
D13481J		AB0376R	POS 04	D13481P		YT101-YT120

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W3730

Page 1 End

Mar 14/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
<b>W3745</b>	<b>NN2</b>	<b>IFE -LEFT SIDEWALL DISC. (STA430 WL215) TO AB0369L</b>				
D13491J			430/215/L69	D13491P		YT101-YT120
D13493J		AB0369L	POS 04	D13493P		YT101-YT120
<b>W3747</b>	<b>LN1</b>	<b>IFE - (BSI) SIDEWALL TO SEAT INTERFACE RH (STA 670) GROUND</b>				
D13561			675/210/R068			YT101-YT120
<b>W3749</b>	<b>LN1</b>	<b>IFE - (BSI) SIDEWALL TO SEAT INTERFACE LH (STA 670) GROUND</b>				
D13559			670/ /L			YT101-YT120

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W3740

Page 1 End

Mar 14/2016





## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
<b>W3751</b>	<b>LN1</b>	<b>IFE - (BSI) SIDEWALL TO SEAT INTERFACE RH (STA 840) GROUND</b>				
D13619			860/68/214R			YT101-YT120
<b>W3753</b>	<b>LN1</b>	<b>IFE - (BSI) SIDEWALL TO SEAT INTERFACE LH (STA 860) GROUND</b>				
D13617			836/215/-69			YT101-YT120
<b>W3755</b>	<b>NN2</b>	<b>IFE - E8-1 SHELF TO WAP TRAYS 1,2, &amp; 3 AND DISC. BRKT AB0373</b>				
D07113J				D07113P	W3453	ALL
D13473P				D13473J		YT101-YT120
D13475P				D13475J		YT101-YT120
D13477P				D13477J		YT101-YT120
D45493P				D45493J	W3755	YT101-YT105
D45493J			727B+10/296/L028	D45493P	W3755	YT101-YT105
D45487J		AB0373	POS 03	D45487P	W3639	YT101-YT102, YT126-YT133
D12893P		AB0373	POS 09	D12893J	W3477	YT101-YT102
D45099P		AE0801B	POS 13	D45099J	W0811	ALL
D45243P		AE0801B	POS 14	D45243J	W0811	YT101-YT102, YT126-YT133
D15908		M02947	500H/ /			YT126-YT133
D16034		M02947	500H/ /			YT126-YT133
D15910		M02948	727E/ /			YT126-YT133
D16024		M02948	727E/ /			YT126-YT133
D13467		M02961				YT101-YT105
D13467		M02961	500C+10/ /			YT106-YT133
D15930		M02961	500C+10/ /			YT126-YT133
D13469		M02962				YT101-YT105
D13469		M02962	500H+16/ /			YT106-YT120
D13471		M02963				YT101-YT105
D13471		M02963	727G+16/ /			YT106-YT120
D15928		M03073	727G/ /			YT126-YT133
D15932		M03073	727G/ /			YT126-YT133
<b>W3757</b>	<b>NN2</b>	<b>IFE - CABIN WIRELESS, WAP TRAY 1 TO FWD CABIN ANTENNA TRAY DISC.</b>				
D13571		AA500BRB	500B+10/304/R002			ALL
D13563		M02961	500C+10/ /			ALL
<b>W3759</b>	<b>NN2</b>	<b>IFE - CABIN WIRELESS, WAP TRAY 2 TO MID CABIN ANTENNA TRAY DISC.</b>				
D13587		AA0589L	POS 01			YT101-YT120
D16066		AA0589L	POS 01			YT126-YT133

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W3750

Page 1

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
<b>W3759</b>	<b>NN2</b>	<b>IFE - CABIN WIRELESS, WAP TRAY 2 TO MID CABIN ANTENNA TRAY DISC. (continued)</b>				
D16036		M02947	500H/ /			YT126-YT133
D13579		M02962				YT101-YT104
D13579		M02962	500H+16/ /			YT105-YT120

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W3750

Page 2 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
<b>I W3761</b>	<b>NN2</b>	<b>IFE - CABIN WIRELESS, WAP TRAY 3 TO AFT CABIN ANTENNA TRAY DISC.</b>				
D13603		AA727FLB	727F+12/303/L011			YT101-YT120
D16058		AA727FLB	727F+12/303/L011			YT126-YT133
D16026		M02948	727E/ /			YT126-YT133
D13595		M02963	727G+16/ /			YT101-YT120
<b>I W3765</b>	<b>NN2</b>	<b>IFE - CABIN WIRELESS, WAP TRAY 1 TO FWD CABIN ANTENNA TRAY DISC.</b>				
D13573		AA500BRA	500B+10/303/R011			ALL
D13575		AA500BRA	500B+10/303/R011			ALL
D13577		AA500BRA	500B+10/303/R011			ALL
D13565		M02961	500C+10/ /			ALL
D13567		M02961	500C+10/ /			ALL
D13569		M02961	500C+10/ /			ALL
<b>I W3767</b>	<b>NN2</b>	<b>IFE - CABIN WIRELESS, WAP TRAY 2 TO MID CABIN ANTENNA TRAY DISC.</b>				
D13589		AA0569L	POS 01			YT101-YT120
D16068		AA0569L	POS 01			YT126-YT133
D13591		AA0569L	POS 02			YT101-YT120
D16070		AA0569L	POS 02			YT126-YT133
D13593		AA0569L	POS 03			YT101-YT120
D16072		AA0569L	POS 03			YT126-YT133
D16038		M02947	500H/ /			YT126-YT133
D16040		M02947	500H/ /			YT126-YT133
D16042		M02947	500H/ /			YT126-YT133
D13581		M02962				YT101-YT104
D13583		M02962				YT101-YT104
D13585		M02962				YT101-YT104
D13581		M02962	500H+16/ /			YT105-YT120
D13583		M02962	500H+16/ /			YT105-YT120
D13585		M02962	500H+16/ /			YT105-YT120
<b>I W3769</b>	<b>NN2</b>	<b>IFE - CABIN WIRELESS, WAP TRAY 3 TO AFT CABIN ANTENNA TRAY DISC.</b>				
D13605		AA727FLA	727F+12/301/L020			YT101-YT120
D13607		AA727FLA	727F+12/301/L020			YT101-YT120
D13609		AA727FLA	727F+12/301/L020			YT101-YT120
D16060		AA727FLA	727F+12/301/L020			YT126-YT133
D16062		AA727FLA	727F+12/301/L020			YT126-YT133
D16064		AA727FLA	727F+12/301/L020			YT126-YT133
D16028		M02948	727E/ /			YT126-YT133
D16030		M02948	727E/ /			YT126-YT133

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W3760

Page 1

Jun 21/2016



Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
<b>W3769</b>	<b>NN2</b>	<b>IFE - CABIN WIRELESS, WAP TRAY 3 TO AFT CABIN ANTENNA TRAY DISC. (continued)</b>				
D16032		M02948	727E/ /			YT126-YT133
D13597		M02963	727G+16/ /			YT101-YT120
D13599		M02963	727G+16/ /			YT101-YT120
D13601		M02963	727G+16/ /			YT101-YT120



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W3783	NN2	IFE - CABIN WIRELESS, WAP TRAY 4 TO WAP 4 ANTENNA TRAY DISC.				
I D15920		AA727JLB	727J/ /			YT126-YT133
I D15918		M03073	727G/ /			YT126-YT133
I W3785	NN2	IFE - CABIN WIRELESS, WAP TRAY 4 TO CABIN ANTENNA TRAY DISC.				
I D15922		AA727JLA	727J/301/L020			YT126-YT133
I D15924		AA727JLA	727J/301/L020			YT126-YT133
I D15926		AA727JLA	727J/301/L020			YT126-YT133
I D15912		M03073	727G/ /			YT126-YT133
I D15914		M03073	727G/ /			YT126-YT133
I D15916		M03073	727G/ /			YT126-YT133

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W3780

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W3801	NN2	CAMERA 1 BRACKET STA 288 TO CAMERA 1 STA 285				
I D37001P		AB0288	POS 04	D37001J	W3701	ALL
I D12491		M3005				ALL
I W3802	NN2	VIU/CIU BRACKET STA 358 TO CAMERA 2 STA 340				
I D37002P		AB0358	POS 05	D37002J	W3702	ALL
I D12947		M3030				ALL
I W3803	NN2	CAMERA 3 BRACKET STA 352 TO CAMERA 3 STA 333				
I D37003P		DISC BRKT		D37003J	W3703	ALL
I D12495		M3009				ALL
I W3805	NN2	VIU/CIU BRACKET STA 358 TO VIDEO CONTROL UNIT STA 344				
I D40353P		AB0358	POS 01	D40353J	W3702	ALL
I D40351P		AB0358	POS 02	D40351J	W3701	ALL
I D40355P		AB0358	POS 06	D40355J	W3703	ALL
I D40357P		AB0358	POS 07	D40357J	W3709	ALL
I D40365P		AB0358	POS 08	D40365J	W3710	ALL
I D40349P		AB0358	POS 09	D40349J	W3144	ALL
I DA12949		M03029	390/295/L011			ALL
I DB12949		M3029				ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W3800

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W3895	NA2	ATC TOP ANT E1 RACK (S942) TO STA 430.25 (M1406)				
I D02529		M01406	430/ /			ALL
I D02703		S00942	316/163/L025			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W3890

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W3901	NN2	COAX ASSY - ELT ANTENNA				
I D02907		M01522	797/306/L005			ALL
I D02905		M01523	794/301/L010			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W3900

Page 1 End

Jun 21/2016





## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W4001	NN2	TCAS TOP ANTENNA (E1-1 SHELF)				
I D04625P		AB0387	POS 01	D04625J	W4009	ALL
I D04627P		AB0387	POS 02	D04627J	W4009	ALL
I D04629P		AB0387	POS 03	D04629J	W4009	ALL
I D04633P		AB0387	POS 04	D04633J	W4009	ALL
I D04611P		AE0101B	POS 15	D04611J	W0111	ALL
I D04609P		AE0101B	POS 16	D04609J	W0111	ALL
I D04615P		AE0101B	POS 17	D04615J	W0111	ALL
I D04613P		AE0101B	POS 18	D04613J	W0111	ALL
I W4009	NN2	TCAS TOP ANTENNA				
I D04625J		AB0387	POS 01	D04625P	W4001	ALL
I D04627J		AB0387	POS 02	D04627P	W4001	ALL
I D04629J		AB0387	POS 03	D04629P	W4001	ALL
I D04633J		AB0387	POS 04	D04633P	W4001	ALL
I D02745		M01486	385/ /			ALL
I D02747		M01486	385/ /			ALL
I D02749		M01486	385/ /			ALL
I D02751		M01486	385/ /			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W4000

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W4116	NN2	FWD PASS CAB TEMP SENSOR (M2847) TO STA 410 (CEILING)				
I D41027J				D41027P	W6288	ALL
I D15016		M02847	410/274/R044			ALL
I D15018		M02847	410/274/R044			ALL
I D15020		M02847	410/274/R044			ALL
I W4118	NN2	AFT PASS CAB TEMP SENSOR (M2848) TO STA 410 (CEILING)				
I D41028J				D41028P	W6288	ALL
I D15022		M02848	727G+11/274/R044			ALL
I D15024		M02848	727G+11/274/R044			ALL
I D15026		M02848	727G+11/274/R044			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W4110

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W4134	LA2	AB1050R TO VERTICAL STAB				
I D40842J		AB1050L	POS 01	D40842P	W6134	ALL
I D40268J		AB1080	POS 01	D40268P	W6136	ALL
I D00756		S00126	1084/266/R018			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W4130

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W4142	LB2*	EMERGENCY EXIT LIGHT - RIGHT				
I D07170P				D07170J	W3144	ALL
I D07180P				D07180J	W4250	ALL
I D14700				D14816		ALL
I D14826				D14816		ALL
I D14830				D14816		ALL
I D14836				D14816		ALL
I D40005J				D40005P	W3309	ALL
I D40007J				D40007P	W3309	ALL
I D40040P				D40040J	W0352	ALL
I D40042P				D40042J	W0342	ALL
I D40046P				D40046J	W0442	ALL
I D40098P				D40098J	W3142	ALL
I D46438J				D46438P	W3142	ALL
I D46440J				D46440P	W3142	ALL
I D14824			500+18/298/R007			ALL
I D14708			727+10/295/R023			ALL
I D14832			727F+5/295/R023			ALL
I D40096J		AB0340B	POS 01	D40096P	W3142	ALL
I D40292J		AB0340B	POS 06	D40292P	W5160	ALL
I D40296J		AB0340B	POS 07	D40296P	W2114	ALL
I D12018		L00007	651/226/R074			ALL
I D11072		L00730	348/227/R068			ALL
I D11084		L00733	1000/242/R060			ALL
I D03658		L01186	293/233/R051			ALL
I D03660		L01186	293/233/R051			ALL
I D03662		L01187	304/230/L051			ALL
I D03664		L01187	304/230/L051			ALL
I D03666		L01188	614/224/R062			ALL
I D03668		L01188	614/224/R062			ALL
I D10086		L01191	993/244/R053			ALL
I D10088		L01191	993/244/R053			ALL
I D12064		L01207	576/224/R062			ALL
I D12066		L01207	576/224/R062			ALL
I D12050		L01209	608/227/R074			ALL
I D12430		L01358				ALL
I D12432		L01358				ALL
I D12454		L01365	MULTI/ /			ALL
I D12456		L01365	MULTI/ /			ALL
I D12460		L01365	MULTI/ /			ALL
I D12462		L01365	MULTI/ /			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W4140

Page 1

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
W4142	LB2*	EMERGENCY EXIT LIGHT - RIGHT (continued)				
D14690		L01505	403/289/R006			ALL
D14706		L01513	697/289/R006			ALL
D14714		L01517	727D+8/289/R006			ALL
D14722		L01521	875/289/R006			ALL
D12004		M01671	727C+13/212/R068			ALL
D10744		M01672	952/290/R014			ALL
D10750		M01675	317/290/L010			ALL
D12002		M01676	500C+7/213/R067			ALL
D12010		M01695	565/213/R068			ALL
D11048		M01744	568/297/R031			ALL
D12544		M02174	617/251/R066			ALL
D12546		M02174	617/251/R066			ALL
D12560		M02178	579/251/R066			ALL
D12562		M02178	579/251/R066			ALL
D12652		M02201	638/251/R066			ALL
D12654		M02201	638/251/R066			ALL
D12656		M02202	581/229/R069			ALL
D12658		M02202	581/229/R069			ALL
D12660		M02203	598/229/R069			ALL
D12662		M02203	598/229/R069			ALL
D12676		M02207	600/251/R066			ALL
D12678		M02207	600/251/R066			ALL
D12680		M02208	543/229/R069			ALL
D12682		M02208	543/229/R069			ALL
D12684		M02209	560/229/R069			ALL
D12686		M02209	560/229/R069			ALL
D14812		M02816	310/290/R006			ALL
D14840		M02837	637/269/59			ALL
D14724		M02838	627/269/59			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W4140

Page 2 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W4166	LN2*	LED LIGHTING - CEILING/WASH RIGHT				
I D07162J				D07162P	W3144	ALL
I D14902				D14682		ALL
I D14904				D14448		ALL
I D14906				D14688		ALL
I D14930				D14682		ALL
I D14932				D14448		ALL
I D15244				D14688		ALL
I D15246				D14682		ALL
I D15248				D14448		ALL
I D15250				D14688		ALL
I D41062J				D41062P	W3058	YT101-YT131
I D41066J				D41066P	W3158	ALL
I D41084J				D41084P	W3158	ALL
I D41088P				D41088J	W0144	ALL
I D41062J			425/295/L021	D41062P		YT132-YT133
I D14760		M02801	MULTI/296/27			ALL
I D14784		M02801	MULTI/296/27			ALL
I D14916		M02801	MULTI/296/27			ALL
I D14918		M02801	MULTI/296/27			ALL
I D14920		M02801	MULTI/296/27			ALL
I D14922		M02801	MULTI/296/27			ALL
I D14924		M02801	MULTI/296/27			ALL
I D14942		M02801	MULTI/296/27			ALL
I D14944		M02801	MULTI/296/27			ALL
I D14990		M02801	MULTI/296/27			ALL
I D14992		M02801	MULTI/296/27			ALL
I D15004		M02801	MULTI/296/27			ALL
I D15006		M02801	MULTI/296/27			ALL
I D15008		M02801	MULTI/296/27			ALL
I D15010		M02801	MULTI/296/27			ALL
I D15012		M02801	MULTI/296/27			ALL
I D15368		M02801	MULTI/296/27			ALL
I D14752		M02826	MULTI/296/27			ALL
I D14758		M02826	MULTI/296/27			ALL
I D15408		M02868	MULTI/296/27			ALL
I D15410		M02868	MULTI/296/27			ALL
I D15384		M02871	MULTI/296/27			ALL
I D15386		M02871	MULTI/296/27			ALL
I D15406		M02871	MULTI/296/27			ALL
I D15418		M02871	MULTI/296/27			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W4160

Page 1

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
<b>W4166</b>	<b>LN2*</b>	<b>LED LIGHTING - CEILING/WASH RIGHT (continued)</b>				
D15380		M02875	MULTI/296/27			ALL
D15382		M02875	MULTI/296/27			ALL
D15412		M02875	MULTI/296/27			ALL
D15296		M02878	MULTI/296/27			ALL
D15306		M02878	MULTI/296/27			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W4160

Page 2 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W4170	RA2*	AB0420A TO E3-1 SHELF				
I D40728P		AB0405B	POS 01	D40728J	W6170	ALL
I D40730P		AB0405B	POS 02	D40730J	W6172	ALL
I D40732P		AE0301A	POS 36	D40732J	W0313	ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W4170

Page 1 End

Jun 21/2016





## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W4222	RN1	AB1050R DISCONNECT BRACKET TO STAB TRIM ACTUATOR				
I D40836J		AB1050R	POS 05	D40836P	W6222	ALL
I D00700		M01659	1076/264/R005			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W4220

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W4246	RN2	LED LIGHTING - SIDEWALL RIGHT				
I D07177J				D07177P	W4258	ALL
I D41070J				D41070P	W3058	YT101-YT131
I D41070J				D41070P		YT132-YT133
I D14594			419/269/R059			ALL
I D14596			419/269/R059			ALL
I D14606			419/269/R059			ALL
I D14598			590/269/R059			ALL
I D14600			628/269/R059			ALL
I D14602			866/269/R059			ALL
I D14604			866/269/R059			ALL
I D14608			866/269/R059			ALL
I D14656		M02806	MULTI/290/			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W4240

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W4250	RN2*	P18 AND AB0340B DISC TO RIGHT PSU'S				
I D07180J				D07180P	W4142	ALL
I D40072P				D40072J		ALL
I D40205J				D40205P	W4258	ALL
I D40207J				D40207P	W4258	ALL
I D40272P				D40272J	W3144	ALL
I D11600			360/274/R051			ALL
I D11602			391/273/R051			ALL
I D11604			410/273/R052			ALL
I D11606			431/273/R052			ALL
I D11608			450/274/R051			ALL
I D11610			470/274/R051			ALL
I D11612			490/274/R051			ALL
I D11614			500+10/274/R051			ALL
I D11616			500A+12/274/R051			ALL
I D11618			500B+12/273/R051			ALL
I D11620			500C+12/274/R051			ALL
I D11622			500D+12/274/R051			ALL
I D11624			500E+16/274/R051			ALL
I D11626			500F+14/274/R051			ALL
I D11628			500G+10/274/R051			ALL
I D11630			500H+10/274/R051			ALL
I D11632			500I+16/273/R054			ALL
I D11634			545/274/R051			ALL
I D11636			565/274/R051			ALL
I D11638			588/274/R051			ALL
I D11640			611/274/R051			ALL
I D11642			630/274/R051			ALL
I D11644			660/274/R051			ALL
I D11646			680/274/R051			ALL
I D11648			700/274/R051			ALL
I D11650			726/273/R054			ALL
I D11652			727+10/274/R051			ALL
I D11654			727A+16/272/R054			ALL
I D11656			727B+10/274/R051			ALL
I D11658			727C+18/272/R054			ALL
I D11660			727D+10/274/R051			ALL
I D11662			727E+18/272/R054			ALL
I D11664			727F+10/274/R051			ALL
I D11666			727G+18/272/R054			ALL
I D11668			727H+10/274/R051			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W4250

Page 1

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
<b>W4250</b>	<b>RN2*</b>	<b>P18 AND AB0340B DISC TO RIGHT PSU'S (continued)</b>				
D11670			727I+16/272/R054			ALL
D11672			727J+10/274/R051			ALL
D11674			763/272/R054			ALL
D11676			785/274/R051			ALL
D11678			802/274/R051			ALL
D11680			822/274/R051			ALL
D11682			842/274/R051			ALL
D11684			865/274/R051			ALL
D11686			890/274/R051			ALL
D11688			924/274/R051			ALL
D11690			937/274/R051			ALL
D40084P		AB0340B	POS 04	D40084J	W4258	ALL
D40298P		AP1800A	POS 07	D40298J	W0018	ALL
<b>W4256</b>	<b>RN1*</b>	<b>P92 TO FWD GALLEY POWER</b>				
D00570		AB0288	POS 01			ALL
D11458		P0092				ALL
D01218		VENDOR				ALL
<b>W4258</b>	<b>RN1</b>	<b>AB0340B DISCONNECT TO RIGHT AFT OVERHEAD</b>				
D07166P				D07166J	W3058	YT101-YT120
D07168P				D07168J	W3058	YT101-YT131
D07177P				D07177J	W4246	ALL
D07178P				D07178J	W3246	ALL
D13667				D13669		ALL
D40205P				D40205J	W4250	ALL
D40207P				D40207J	W4250	ALL
D07166P			351/294/R011	D07166J	W3058	YT126-YT131
D07166P			351/294/R011	D07166J		YT132-YT133
D07168P			950/302/R009	D07168J		YT132-YT133
D40084J		AB0340B	POS 04	D40084P	W4250	ALL
D40202J		AB0340B	POS 09	D40202P	W6242	ALL
D40489P		AE0801A	POS 13	D40489J	W0811	ALL
D40088P		AP0600A	POS 01	D40088J	W0044	ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W4250

Page 2 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W4724	AD1	APU FIREWALL TO DISC BRACKET AB1050R				
I D44582P				D44582J	W7152	ALL
I D44584P				D44584J	W7150	ALL
I D40854J		AB1050R	POS 03	D40854P	W5726	ALL
I D10434		AB1088				ALL
I D10436		AB1088				ALL
I D40060J		AB1088	POS 05	D40060P	W7538	ALL
I D16276		L00015	1064/285/L036			YT112-YT120, YT131-YT133
I D16278		L00016	1040/285/R038			YT112-YT120, YT131-YT133
I W4726	AD1	AB1050R TO APU FIREWALL				
I D40790J		AB1050R	POS 01	D40790P	W5726	ALL
I D40876J		AB1050R	POS 02	D40876P	W5726	ALL
I D10912		AB1088				ALL
I D11118		AB1088				ALL
I D00922		M00299	1055/240/R037			ALL
I D01176		M00404	1025/ /			ALL
I D00594		M01146	713/ /			ALL
I D01246		S00284	1055/240/R037			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W4720

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W5001	NN2	TCAS BOTTOM ANTENNA (E1-1 SHELF)				
I D04619P		AE0101B	POS 19	D04619J	W0111	ALL
I D04617P		AE0101B	POS 20	D04617J	W0111	ALL
I D04623P		AE0101B	POS 21	D04623J	W0111	ALL
I D04621P		AE0101B	POS 22	D04621J	W0111	ALL
I D02753		M01487	305/ /			ALL
I D02755		M01487	305/ /			ALL
I D02757		M01487	305/ /			ALL
I D02759		M01487	305/ /			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W5000

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W5030	LA1	P91 TO T10 ANDP92				
I D03472		M01323	368/184/R049			ALL
I D11420		P0091				ALL
I D11800		P0091				ALL
I D11446		P0092				ALL
I W5032	SN2	MAIN WHEEL WELL TO E/E BAY VIA CROWN				
I D42104J		AB0727L	POS 01	D42104P	W1022	YT101-YT119, YT126-YT131
I D42104J		AB0727L	POS POS 01	D42104P		YT120, YT132-YT133
I D40162P		AE0101A	POS 15	D40162J	W0111	ALL
I W5036		P91/P92 TO TRU'S 1,2 & 3.				
I D11426		P0091				ALL
I D11736		P0092				ALL
I W5039	NA2	E1-2 TO S943 (D2709) COAX				
I D04607J		AE0102B	POS 01	D04607P	W0121	ALL
I D02709		S00943	316/163/L025			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W5030

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
<b>I W5043</b>	<b>NN2</b>	<b>IFE - (BSI) SERVER BASED SYSTEM ARINC INTERFACES (E5-2 TO E8-1)</b>				
I D45319J		AE0502A	POS 13	D45319P	W0521	YT101-YT103
I D45319J		AE0502A	POS 14	D45319P	W0521	YT104-YT133
I D45907P		AE0801B	POS 02	D45907J	W0811	ALL
<b>I W5047</b>	<b>NA2</b>	<b>E3-1, E3-2, E5-2</b>				
I D42047P		AE0301A	POS 26	D42047J	W0311	YT104-YT133
I D40710P		AE0302A	POS 57	D40710J	W0321	YT104-YT133
I D43056P		AE0303A	POS 10	D43056J	W0330	YT116-YT120, YT132-YT133
I D40761J		AE0502A	POS 17	D40761P	W0521	YT104-YT133
<b>I W5049</b>	<b>NB2</b>	<b>E3-2, E3-3</b>				
I D07721J				D07721P	W6506	YT113-YT120, YT132-YT133
I D42049P		AE0301A	POS 39	D42049J	W0313	YT104-YT133
I D45006P		AE0302A	POS 59	D45006J	W0321	YT104-YT133
I D49001P		AE0302A	POS 63	D49001J	W0321	YT104-YT133
I D43139P		AE0303A	POS 36	D43139J	W0331	YT104-YT133
I D40767J		AE0502A	POS 25	D40767P	W0523	YT104-YT133

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W5040

Page 1 End

Jun 21/2016





## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W5054	NN2	CARGO COMPT SMOKE DETECTOR JUMPER BUNDLE				
I D13844			MULTI/ /			ALL
I D13846			MULTI/ /			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W5050

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W5074	SB2	CARGO FIRE EXTINGUISHER BOTTLE 2 (M2263) TO AB500DL (POS 6)				
I D46608P		AB0500DL	POS 06	D46608J	W5088	ALL
I D12820		M02263	540/180/R019			ALL
I D12816		M2263				ALL
I D12818		M2263				ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W5070

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W5086	NA2	FWD CARGO COMPT TO FWD CARGO SMOKE DETECTORS				
I D12766				D13846		ALL
I D12768				D13846		ALL
I D12770				D13846		ALL
I D12772				D13846		ALL
I D12764		M2236				ALL
I W5088	NB2	FWD CARGO COMPARTMENT TO E2-2 SHELF				
I D46608J		AB0500DL	POS 06	D46608P	W5074	ALL
I D42014P		AE0202A	POS 32	D42014J	W0220	ALL
I D12762		M2236				ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W5080

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W5094	NC2	AB500DL (POS 12) TO E2-2 SHELF				
I D46606J		AB0500DL	POS 12	D46606P	W5098	ALL
I D41840P		AE0202A	POS 33	D41840J	W0220	ALL
I W5096	NC2	AFT CARGO COMPART TO AFT CARGO SMOKE DETECTORS				
I D12778				D13846		ALL
I D12780				D13846		ALL
I D12782				D13846		ALL
I D12784				D13846		ALL
I D12786				D13846		ALL
I D12788				D13846		ALL
I D12776		M2237				ALL
I W5098	NC2	AFT CARGO COMPT TO E2-2 SHELF				
I D46606P		AB0500DL	POS 12	D46606J	W5094	ALL
I D12774		M2237				ALL
I D12792		M2248				ALL
I D12794		M2248				ALL
I D12796		M2248				ALL
I W5099	NB2	TCAS SUPPRESSION E1-5 TO M1908 (E1 RACK)				
I D41511J		AE0105A	POS 11	D41511P	W0151	ALL
I D10159		M01908	/ /			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W5090

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
<b>I W5100</b>	<b>SB2*</b>	<b>J24 TO J20 &amp; J22: J-BOX INTERCONNECT BUNDLE</b>				
I D40632P		AJ0020B	POS 05	D40632J	W0072	ALL
I D40668P		AJ0022	POS 06	D40668J	W0076	ALL
I D40698P		AJ0024	POS 03	D40698J	W0080	ALL
I D02864		M1177				ALL
<b>I W5102</b>	<b>SA2</b>	<b>LEFT A/C PACK (STA 536L) DISC TO A/C PACK (SA2)</b>				
I D04580J		AB0536L	POS 01	D04580P	W5526	ALL
I D40056J		AB0536L	POS 02	D40056P	W5104	ALL
I D16254		L00176	533/150/L023			YT112-YT120, YT131-YT133
I D16256		L00177	579/155/L038			YT112-YT120, YT131-YT133
I D16258		L00178	654/152/L039			YT112-YT120, YT131-YT133
I D00858		M00355	540/ /			ALL
I D00832		M00370	540/170/L025			ALL
I D11050		M01745	650/144/L027			ALL
I D00532		S00002	576/158/L024			ALL
I D10056		S00938	577/162/L031			ALL
I D00100		T00405	538/165/L 30			ALL
I D03866		T00471	573/154/L030			ALL
I D03916		T00481	584/162/L032			ALL
I D03930		T00488	573/152/L033			ALL
I D03862		V00139	655/147/L009			ALL
I D03864		V00140	653/154/L028			ALL
<b>I W5103</b>	<b>NA2</b>	<b>HF 1 E3-3 TO E6-2</b>				
I D43359P		AE0303A	POS 06	D43359J	W0331	ALL
I D40113P		AE0602A	POS 10	D40113J	W0621	ALL
<b>I W5104</b>	<b>LA2</b>	<b>E/E BAY TO L AC PACK (STA 536L) DISC. (LA2)</b>				
I D40056P		AB0536L	POS 02	D40056J	W5102	ALL
I D40246P		AE0202A	POS 01	D40246J	W0220	ALL
I D41800P		AE0303A	POS 24	D41800J	W0330	YT101-YT103
I D41836P		AE0303A	POS 31	D41836J	W0330	ALL
I D40244P		AE0401A	POS 29	D40244J	W0410	ALL
I D14386		M02795	500I+15/171/L60			ALL
I D14388		M02795	500I+15/171/L60			ALL
I D14390		M02796	656.5/151/L32			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W5100

Page 1

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
<b>W5104</b>	<b>LA2</b>	<b>E/E BAY TO L AC PACK (STA 536L) DISC. (LA2) (continued)</b>				
D14392		M02796	656.5/151/L32			ALL
D03856		M1440				ALL
D15826		M2955				YT116-YT120, YT132-YT133
D03868		T00472	500I+7/192/L003			ALL
<b>W5105</b>	<b>NB2</b>	<b>HF 2, TO E3-3 TO E6-2</b>				
D43361P		AE0303A	POS 10	D43361J	W0331	YT101-YT103
D43361P		AE0303A	POS 34	D43361J	W0331	YT104-YT133
D40115P		AE0602A	POS 08	D40115J	W0621	ALL
<b>W5107</b>	<b>NA2</b>	<b>VHF-1 &amp; VHF-2 TO E3-3</b>				
D04123P		AE0103A	POS 12	D04123J	W0131	ALL
D04125J		AE0105A	POS 01	D04125P	W0151	ALL
D43367P		AE0303A	POS 07	D43367J	W0331	YT104-YT133
D43314P		AE0303A	POS 08	D43314J	W0331	ALL
D43367P		AE0303A	POS 11	D43367J	W0331	YT101-YT103

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W5100

Page 2 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
<b>I W5110</b>	<b>LA2</b>	<b>P91 (AFT DISC) TO E/E BAY.</b>				
I D40260P		AE0201A	POS 12	D40260J	W0212	ALL
I D40340P		AE0201A	POS 19	D40340J	W0212	ALL
I D40338P		AE0402A	POS 07	D40338J	W0422	ALL
I D10330		M03054	378/158/L005			ALL
I D10342		M3055				ALL
I D11432		P0091				ALL
<b>I W5111</b>	<b>NA2</b>	<b>EE INTER-RACK - LEFT (E1-X TO E3-X)</b>				
I D10175		AB0372				ALL
I D45133P		AE0101A	POS 03	D45133J	W0111	ALL
I D41153P		AE0101A	POS 11	D41153J	W0111	ALL
I D45113P		AE0101A	POS 19	D45113J	W0111	ALL
I D45115J		AE0102A	POS 02	D45115P	W0121	ALL
I D45111P		AE0301A	POS 07	D45111J	W0311	ALL
I D45131P		AE0301A	POS 08	D45131J	W0311	ALL
I D45151P		AE0301A	POS 09	D45151J	W0311	ALL
I D45177P		AE0302A	POS 17	D45177J	W0321	YT101-YT103
I D45157P		AE0302A	POS 18	D45157J	W0321	ALL
I D45137P		AE0302A	POS 19	D45137J	W0321	ALL
I D45117P		AE0302A	POS 20	D45117J	W0321	ALL
I D43307P		AE0303A	POS 12	D43307J	W0331	ALL
I D43321P		AE0303A	POS 13	D43321J	W0331	ALL
I D43305P		AE0303A	POS 20	D43305J	W0331	ALL
I D45211J		AE0502A	POS 12	D45211P	W0521	ALL
<b>I W5112</b>	<b>LA1</b>	<b>P91 (AFT DISC) TO E/E BAY.</b>				
I D49996P		AE0201A	POS 01	D49996J	W0212	ALL
I D40934P		AE0201A	POS 02	D40934J	W0212	ALL
I D40342P		AE0201A	POS 03	D40342J	W0212	ALL
I D40256P		AE0201A	POS 4	D40256J	W0212	ALL
I D01986		M00753	855/179/L049			ALL
I D11434		P0091				ALL
I D01990		S00692	958/205/R003			ALL
I D12346		S00945	915/165/R010			ALL
I D12348		S00945	915/165/R010			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W5110

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W5121	NB2	EE INTER-RACK - RIGHT (E1-X TO E3-X)				
I D11804		AB0372				ALL
I D31022J		AC0235A	POS 05	D31022P		YT101-YT120
I D45002J		AE0102A	POS 11	D45002P	W0121	ALL
I D45143J		AE0104A	POS 05	D45143P	W0141	ALL
I D45123J		AE0104A	POS 12	D45123P	W0141	ALL
I D45125J		AE0105A	POS 09	D45125P	W0151	ALL
I D45121P		AE0301A	POS 32	D45121J	W0313	ALL
I D45141P		AE0301A	POS 33	D45141J	W0313	ALL
I D45102P		AE0302A	POS 29	D45102J	W0321	ALL
I D45127P		AE0302A	POS 46	D45127J	W0321	ALL
I D45147P		AE0302A	POS 56	D45147J	W0321	ALL
I D43039P		AE0303A	POS 04	D43039J	W0331	ALL
I D43323P		AE0303A	POS 42	D43323J	W0331	ALL
I D45213J		AE0502A	POS 11	D45213P	W0523	YT101-YT103
I D45213J		AE0502A	POS 26	D45213P	W0523	YT104-YT133
I W5122	LA1*	P91 TO TB1802, TB1804,& TB5180.				
I D48126P		AJ0048A	POS 02	D48126J	W0088	ALL
I D11416		P091-00	371/181/L016			ALL
I W5124	LN1*	AB0727 TO J11 (WITH E6)				
I D07106P				D07106J	W3144	ALL
I D07108P				D07108J	W3144	ALL
I D07164P				D07164J	W3058	YT101-YT131
I D07164P			880/295/L023	D07164J		YT132-YT133
I D46602J		AB0727R	POS 02	D46602P	W6124	ALL
I D46618P		AJ0011	POS 01	D46618J	W0122	ALL
I D46616P		AJ0011	POS 02	D46616J	W0122	ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W5120

Page 1 End

Jun 21/2016





## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W5134	LA1	DISC AB0500DL TO E2-2				
I D40312J		AB0500DL	POS 07	D40312P	W5224	ALL
I D43008P		AE0202A	POS 19	D43008J	W0220	ALL
I W5137	NA2	VOR ANTENNA LEFT - RF PWR DIV-1 TO R315 LOC ANTENNA SWITCH RELAY-1				
I D03779		M01726	309/180/R021			ALL
I D02113		R00315	306/180/R021			ALL
I W5139	NB2	VOR ANTENNA RIGHT - RF PWR DIV-2 TO R316 LOC ANTENNA SWITCH RELAY-2				
I D03785		M01727	302/180/R020			ALL
I D02121		R00316	300/178/R022			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W5130

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W5142	LN1*	P91 TO AB0340A DISCONNECT BRACKET				
I D40054P		AB0340A	POS 01	D40054J	W3058	YT101-YT131
I D40054P		AB0340A	POS 01	D40054J		YT132-YT133
I D40102P		AB0340A	POS 09	D40102J	W3158	ALL
I W5146	LN2	SEC 46 TO WTR QTY AND MISC				
I D40148J				D40148P	W3058	YT101-YT131
I D40150J				D40150P	W3144	ALL
I D40152P				D40152J	W5230	YT101-YT111, YT126-YT130
I D40152P			849/188/L050	D40152J	W5230	YT112-YT119
I D40152P			849/188/L050	D40152J		YT120, YT132-YT133
I D40152P			849/188/L050	D40152J	W5230	YT131
I D40148J			853/294/L034	D40148P		YT132-YT133
I D11702		M01722	860/198/L013			ALL
I D11788		M01723				ALL
I D11786		S01033	1039/231/L046			ALL
I D11716		S01034	860/177/L030			ALL
I D00192		T00408	951/186/R036			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W5140

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W5156	SA2*	PSEU & AIR/GND SYS: M2061 & J22,J20 TO E/E BAY (ROUTE LEFT)				
I D40458P		AE0101A	POS 01	D40458J	W0111	ALL
I D40454P		AE0101A	POS 02	D40454J	W0111	ALL
I D40452P		AE0101A	POS 05	D40452J	W0111	ALL
I D40498P		AE0103A	POS 11	D40498J	W0131	ALL
I D40456P		AE0202A	POS 09	D40456J	W0220	ALL
I D40724P		AE0202A	POS 28	D40724J	W0220	ALL
I D40460P		AE0301A	POS 19	D40460J	W0311	ALL
I D40594P		AE0302A	POS 16	D40594J	W0321	ALL
I D40462P		AE0302A	POS 23	D40462J	W0321	ALL
I D41824P		AE0303A	POS 30	D41824J	W0330	ALL
I D40636P		AJ0020B	POS 04	D40636J	W0072	ALL
I D40642P		AJ0020B	POS 07	D40642J	W0072	ALL
I D40878P		AJ0020C	POS 02	D40878J	W0074	ALL
I D40678P		AJ0022	POS 01	D40678J	W0076	ALL
I D40666P		AJ0022	POS 03	D40666J	W0076	ALL
I D40670P		AJ0022	POS 04	D40670J	W0076	ALL
I D40676P		AJ0022	POS 05	D40676J	W0076	ALL
I D40680P		AJ0022	POS 08	D40680J	W0076	ALL
I D46116P		AJ0046A	POS 13	D46116J	W0066	ALL
I D48112P		AJ0048A	POS 16	D48112J	W0088	ALL
I D48114P		AJ0048A	POS 17	D48114J	W0088	ALL
I D40578P		AP0900A	POS 04	D40578J	W0001	ALL
I D40576P		AP1800B	POS 02	D40576J	W0018	ALL
I D10982		M02061	212/180/R020			ALL
I D11138		M02061	212/180/R020			ALL
I D11142		M02061	212/180/R020			ALL
I D00164		M100				ALL
I W5158	SB2*	PSEU & AIR/GND SYS: M2061 & J24,J20 TO E/E BAY (ROUTE RIGHT)				
I D40488P		AE0103A	POS 08	D40488J	W0131	ALL
I D40490J		AE0104A	POS 20	D40490P	W0141	ALL
I D40426P		AE0302A	POS 28	D40426J	W0321	ALL
I D40486P		AE0302A	POS 33	D40486J	W0321	ALL
I D40484P		AE0402A	POS 30	D40484J	W0422	ALL
I D40618P		AE0402A	POS 35	D40618J	W0422	ALL
I D40884P		AJ0020A	POS 02	D40884J	W0074	ALL
I D40634P		AJ0020B	POS 01	D40634J	W0072	ALL
I D40638P		AJ0020B	POS 02	D40638J	W0072	ALL
I D40640P		AJ0020B	POS 03	D40640J	W0072	ALL

### MASTER BUNDLE LIST

D280A351

91-21-13

Section W5150

Page 1

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
W5158	SB2*	PSEU & AIR/GND SYS: M2061 & J24,J20 TO E/E BAY (ROUTE RIGHT) (continued)				
D40858P		AJ0020D	POS 01	D40858J	W0072	ALL
D40692P		AJ0024	POS 04	D40692J	W0080	ALL
D40700P		AJ0024	POS 05	D40700J	W0080	ALL
D40702P		AJ0024	POS 06	D40702J	W0080	ALL
D46120P		AJ0046B	POS 03	D46120J	W0066	ALL
D46100P		AJ0046B	POS 11	D46100J	W0066	ALL
D48116P		AJ0048A	POS 13	D48116J	W0088	ALL
D40750P		AP0600B	POS 02	D40750J	W0044	ALL
D03464		M01915	213/191/R025			ALL
D11140		M02061	212/180/R020			ALL
D14212		M02566	360/160/25			ALL
D00434		N00021	357/166/R014			ALL
D00438		T00404	391/166/R011			YT101-YT106
D00438		T00404	395/167/7			YT107-YT133
D11880		V157				ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W5150

Page 2 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
<b>I W5160</b>	<b>RB2*</b>	<b>PSEU &amp; AIR/GND SYS: M2061 &amp; J4,J24 TO E/E BAY (ROUTE RIGHT)</b>				
I	D11134	AB0250A	POS 01			ALL
I	D40292P	AB0340B	POS 06	D40292J	W4142	ALL
I	D40464P	AE0101B	POS 02	D40464J	W0111	ALL
I	D40466P	AE0103A	POS 14	D40466J	W0131	ALL
I	D40468P	AE0302A	POS 36	D40468J	W0321	ALL
I	D40470P	AE0302A	POS 37	D40470J	W0321	ALL
I	D40952P	AE0302A	POS 42	D40952J	W0321	ALL
I	D40472P	AE0402A	POS 33	D40472J	W0422	ALL
I	D40474P	AE0402A	POS 37	D40474J	W0422	ALL
I	D40169P	AE0402A	POS 40	D40169J	W0422	ALL
I	D40612P	AJ0004	POS 05	D40612J	W0094	ALL
I	D40658P	AJ0004	POS 06	D40658J	W0094	ALL
I	D40610P	AJ0004	POS 10	D40610J	W0094	ALL
I	D40694P	AJ0024	POS 07	D40694J	W0080	ALL
I	D43906P	AJ0039A	POS 04	D43906J	W0082	ALL
I	D46102P	AJ0046A	POS 14	D46102J	W0066	ALL
I	D46122P	AJ0046A	POS 16	D46122J	W0066	ALL
I	D40580P	AP0900A	POS 07	D40580J	W0003	ALL
I	D02537	M01439	186/203/L005			ALL
I	D10984	M02061	212/180/R020			ALL
I	D10986	M02061	212/180/R020			ALL
I	D10988	M02061	212/180/R020			ALL
I	D44278	M02604	192/200/L007			ALL
<b>I W5161</b>	<b>LA2</b>	<b>E1-1, E3-1, E5-2</b>				
I	D41145P	AE0101A	POS 04	D41145J	W0111	ALL
I	D41155P	AE0101A	POS 20	D41155J	W0111	ALL
I	D43145P	AE0301A	POS 15	D43145J	W0311	ALL
I	D43155P	AE0301A	POS 16	D43155J	W0311	ALL
I	D45245J	AE0502A	POS 02	D45245P	W0521	YT104-YT133
I	D45255J	AE0502A	POS 03	D45255P	W0521	YT104-YT133
I	D45265J	AE0502A	POS 04	D45265P	W0521	YT104-YT133
I	D45245J	AE0502A	POS 14	D45245P	W0521	YT101-YT103
I	D45255J	AE0502A	POS 15	D45255P	W0521	YT101-YT103
I	D45265J	AE0502A	POS 16	D45265P	W0521	YT101-YT103
I	D03691	M01751	409/205/R002			ALL
<b>I W5162</b>	<b>LB2*</b>	<b>LEFT WING/BODY PRESSURE SEAL DISC TO E/E BAY</b>				
I	D11160	AB0237A	POS 01			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W5160

Page 1

Jun 21/2016

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
<b>W5162</b>	<b>LB2*</b>	<b>LEFT WING/BODY PRESSURE SEAL DISC TO E/E BAY (continued)</b>				
D39921		AC0520				ALL
D40130P		AE0202A	POS 25	D40130J	W0220	ALL
D48134P		AJ0048A	POS 21	D48134J	W0088	ALL
<b>W5163</b>	<b>RB2*</b>	<b>E1-1, E1-5, E3-1, E5-2</b>				
D41147P		AE0101B	POS 11	D41147J	W0111	ALL
D41157P		AE0101B	POS 12	D41157J	W0111	ALL
D41557J		AE0105A	POS 07	D41557P	W0151	ALL
D43147P		AE0301A	POS 28	D43147J	W0313	ALL
D43157P		AE0301A	POS 29	D43157J	W0313	ALL
D45247J		AE0502A	POS 04	D45247P	W0523	YT101-YT103
D45257J		AE0502A	POS 05	D45257P	W0523	YT101-YT103
D45563J		AE0502A	POS 24	D45563P	W0521	YT105-YT133
D45247J		AE0502A	POS 27	D45247P	W0523	YT104-YT133
D45257J		AE0502A	POS 28	D45257P	W0523	YT104-YT133
D03697		M01754	430.415/205/R035			ALL
D02127		R00316	300/178/R022			ALL
<b>W5164</b>	<b>LA1*</b>	<b>LEFT WING PRESS SEAL CONN TO E/E BAY</b>				
D39933		AC0520				ALL
D40132P		AE0201A	POS 16	D40132J	W0212	ALL
D40718P		AE0201A	POS 17	D40718J	W0212	ALL
<b>W5166</b>	<b>SN2</b>	<b>LEFT WING BODY PRESS SEAL TO E1-1</b>				
D39901		AC0520				ALL
D40122P		AE0101A	POS 18	D40122J	W0111	ALL
<b>W5168</b>	<b>SB2*</b>	<b>LEFT WING/BODY PRESS SEAL TO E/E BAY</b>				
D39929		AC0520				ALL
D40138P		AE0202A	POS 08	D40138J	W0220	ALL

**MASTER BUNDLE LIST**

D280A351

**91-21-13**

Section W5160

Page 2 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W5170	SA2*	LEFT WING/BODY PRESS SEAL TO E/E BAY				
I D40266P				D40266J	W5222	ALL
I D40734J		AB0420A	POS 01	D40734P	W3170	ALL
I D39925		AC0520				ALL
I D48110P		AJ0048A	POS 07	D48110J	W0088	ALL
I W5172	LA2*	LEFT WING/BODY PRESS SEAL TO E/E BAY				
I D11158		AB0237A	POS 02			ALL
I D40736J		AB0420A	POS 02	D40736P	W3170	ALL
I D39917		AC0520				ALL
I D48136P		AJ0048A	POS 19	D48136J	W0088	ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W5170

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W5181	NB2	ATC BOTTOM ANT E1 RACK (S943) TO STA 355 (M44)				
I D00099		M00044	355/ /			ALL
I D02707		S00943	316/163/L025			ALL
I W5182	NN2	ISPC TO P18(EE-BAY TO PC POWER OUTLET(P18)				
I D14012		DISC BRKT				ALL
I D14008		M02566	360/160/25			ALL
I W5183	NA2	DME 1 E1-2 TO DME LEFT BOTTOM ANTENNA				
I D41215J		AE0102B	POS 02	D41215P	W0121	ALL
I D00093		M00042	580/144/0000			ALL
I W5185	NB2	DME 2 E1-5 TO DME RIGHT BOTTOM ANTENNA				
I D41515J		AE0105A	POS 12	D41515P	W0151	ALL
I D00095		M00043	641/143/0			ALL
I W5189	NA3	E4-1 AUDIO NO. 1				
I D04269J		AE0102A	POS 08	D04269P	W0121	ALL
I D04195P		AE0103A	POS 18	D04195J	W0131	ALL
I D04271P		AE0301A	POS 01	D04271J	W0311	ALL
I D04287P		AE0401A	POS 17	D04287J	W0411	ALL
I D08123P		AE0401A	POS 21	D08123J	W0411	ALL
I D40117P		AE0602A	POS 05	D40117J	W0621	ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W5180

Page 1 End

Jun 21/2016





## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W5191	NB3	E4-1 AUDIO NO. 2				
I D04273J		AE0104A	POS 17	D04273P	W0141	ALL
I D04197J		AE0105A	POS 04	D04197P	W0151	ALL
I D04277P		AE0301A	POS 37	D04277J	W0313	ALL
I D43331P		AE0303A	POS 38	D43331J	W0331	ALL
I D04289P		AE0401A	POS 16	D04289J	W0411	ALL
I D04285P		AE0401A	POS 19	D04285J	W0411	ALL
I D40119P		AE0602A	POS 07	D40119J	W0621	ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W5190

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W5202	RN2	AP0900A BRKT TO GLARESHIELD DIMMER CONTROL UNITS (P9) RN2				
I D40944P		AP0900A	POS 11	D40944J	W0001	ALL
I D11930		M01916	P009-00/ /			ALL
I D11932		M01917	P009-00/ /			ALL
I D12592		M02186	/ /			ALL
I W5204	NN2	NITROGEN GEN SYSTEM E1-4 TO AC0538				
I D13928				D13832		ALL
I D40332J		AE0104A	POS 26	D40332P	W0141	ALL
I D13838		P63				ALL
I W5205	SA2	EE INTER-RACK-LEFT (E1-1,E1-2,E3-1,E3-2,E5-2)				
I D45203P		AE0101A	POS 31	D45203J	W0111	ALL
I D45201J		AE0102A	POS 10	D45201P	W0121	ALL
I D45205P		AE0301A	POS 18	D45205J	W0311	ALL
I D45207P		AE0302A	POS 14	D45207J	W0321	ALL
I D45209J		AE0502A	POS 01	D45209P	W0521	YT104-YT133
I D45209J		AE0502A	POS 03	D45209P	W0521	YT101-YT103
I D02119		R00315	306/180/R021			ALL
I W5208	NN2	NGS CONTROLLER TO PRESS SEALS AND AC0538				
I D13832				D13928		ALL
I D13934		DM0032	536/164/L036			ALL
I D13970		DM0044	536/166/R037			ALL
I D13804		M02559	500I+8/201/R012			ALL
I D13806		M02559	500I+8/201/R012			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W5200

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W5222	SA2*	DISC AB0500DL TO MAIN WHEEL WELL				
I D40266J				D40266P	W5170	ALL
I D40318P		AB0500DL	POS 04	D40318J	W5530	ALL
I D40302P		AB0500DL	POS 09	D40302J	W5526	ALL
I D46030J		AL0675B	POS 03	D46030P	W7522	ALL
I D46032J		AL0720B	POS 02	D46032P	W7128	YT101-YT104
I D46032J		AL0720B	POS POS 02	D46032P	W7128	YT105-YT119
I D46032J		AL0720B	POS POS 02	D46032P		YT120, YT132-YT133
I D46032J		AL0720B	POS POS 02	D46032P	W7128	YT126-YT131
I W5224	RA1	MAIN WHEEL WELL TO AB0500DL AND CROWN				
I D40248P				D40248J	W6222	ALL
I D43404P				D43404J	W6222	ALL
I D40312P		AB0500DL	POS 07	D40312J	W5134	ALL
I D40416P		AB0500DR	POS 08	D40416J	W6032	ALL
I D46010J		AL0675A	POS 04	D46010P	W7122	YT101-YT119
I D46010J		AL0675A	POS POS 04	D46010P		YT120, YT132-YT133
I D46010J		AL0675A	POS POS 04	D46010P	W7122	YT126-YT131
I D46036J		AL0720B	POS 03	D46036P	W7128	YT101-YT119, YT126-YT131
I D46036J		AL0720B	POS POS 03	D46036P		YT120, YT132-YT133

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W5220

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W5230	RB1	E/E BAY TO MWW-SYS B ELEC HYD PUMP (VICKERS ONLY)				
I D40152J				D40152P	W5146	YT101-YT119, YT126-YT131
I D43084P		AE0202A	POS 13	D43084J	W0220	YT101-YT119, YT126-YT131
I D43062P		AE0401A	POS 45	D43062J	W0410	YT101-YT119, YT126-YT131
I D01782		L00322	500A+10/150/L032			YT101-YT112, YT126-YT130
I D11718		M01721	857/196/L050			YT101-YT119, YT126-YT131
I D02666		M1104				YT101-YT119, YT126-YT131
I D11428		P0091				YT101-YT119, YT126-YT131
I D02690		S799				YT101-YT119, YT126-YT131
I W5234	RB2	DISC AL0720A TO E1-3				
I D43010P		AE0103A	POS 15	D43010J	W0131	ALL
I D46024J		AL0720A	POS 01	D46024P	W7126	ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W5230

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W5248	LN2*	E/E BAY TO FWD AND AFT CARGO AREA				
I D40500J		AB0500DL	POS 05	D40500P	W6248	ALL
I D40586P		AE0202A	POS 02	D40586J	W0220	ALL
I D40584P		AE0402A	POS 02	D40584J	W0422	ALL
D11758		L00185	433/203/L010			YT101-YT111, YT126-YT130
I D16288		L00185	433/203/L010			YT112-YT120, YT131-YT133
D11760		L00186	473/203/L005			YT101-YT111, YT126-YT130
I D16290		L00186	476/201/L005			YT112-YT120, YT131-YT133
I D16294		L00187	504/201/L010			YT112-YT120, YT131-YT133
D11764		L00187	513/203/L010			YT101-YT111, YT126-YT130
D11994		L01205	500F+15/203/R010			YT101-YT111, YT126-YT130
I D16284		L01205	500F+4/201/R04			YT112-YT120, YT131-YT133
D11996		L01314	500G+15/205/L010			YT101-YT111, YT126-YT130
I D16286		L01314	500G+4/201/L010			YT112-YT120, YT131-YT133
D12170		L01321	500B+13/203/R010			YT101-YT111, YT126-YT130
I D16280		L01321	500B+4/201/R010			YT112-YT120, YT131-YT133
D12172		L01322	500D+15/203/R010			YT101-YT111, YT126-YT130
I D16282		L01322	500D+4/201/L016			YT112-YT120, YT131-YT133

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W5240

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W5257	NN2	FLIGHT RECORDER E3-2 SHELF TO CONTROL POSITION SENSORS				
I D43257P		AE0302A	POS 12	D43257J	W0321	ALL
I D00815		M00520	215/180/L020			ALL
I D00819		M00522	227/194/L020			ALL
I D00817		M01983	228/202/L011			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W5250

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W5273	NA3	ADF ANTENNA -1				
I D42163P		AE0301A	POS 02	D42163J	W0311	ALL
I D03663		M01733	694/ /R004			ALL
I W5275	NB3	ADF ANTENNA -2				
I D42165P		AE0301A	POS 38	D42165J	W0313	ALL
I D03665		M01734	/ /			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W5270

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W5293	NA2	RADIO ALTM XMTR ANT -1 (R/T) STA 450 TO E3-1				
I D03671		M01737	450/148/0000			ALL
I W5295	NA2	RADIO ALTM RCVR ANT -1 (R/T) STA 430 TO E3-1				
I D03675		M01739	430/148/0000			ALL
I W5297	NB2	RADIO ALTM XMTR ANT -2 (R/T) STA 390 TO E3-2				
I D03673		M01738	390/148/0000			ALL
I W5299	NB2	RADIO ALTM RCVER ANT -2 (R/T) STA 410 TO E3-2				
I D03677		M01740	410/148/0000			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W5290

Page 1 End

Jun 21/2016





## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W5301	LG2	MACH TRIM SERVO, E1-1 TO AB1050L				
I D43393P		AB1050L	POS 02	D43393J	W3393	ALL
I D04425P		AE0101A	POS 08	D04425J	W0111	ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W5300

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W5310	LB2*	E2 TO E3				
I D40450P		AE0202A	POS 24	D40450J	W0220	ALL
I D40448P		AE0301A	POS 11	D40448J	W0311	ALL
I D40446P		AE0302A	POS 04	D40446J	W0321	ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W5310

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W5331	NA2	CMU INTERFACES E3-3 (LEFT)				
I D43345P		AE0303A	POS 17	D43345J	W0331	ALL
I D43347P		AE0303A	POS 18	D43347J	W0331	ALL
I D04115P		AE0401A	POS 14	D04115J	W0411	ALL
I D04117P		AE0401A	POS 15	D04117J	W0411	ALL
I W5335	NB2	CMU INTERFACES E3-3 (RIGHT)				
I D43379P		AE0303A	POS 43	D43379J	W0331	ALL
I D04007P		AE0401A	POS 32	D04007J	W0411	ALL
I D04009P		AE0401A	POS 41	D04009J	W0411	ALL
I W5337	SN2	SERVICE INTERPHONE, TB205, E RACK, P19				
I D06025			358/165/R006			ALL
I D04161P		AE0401A	POS 25	D04161J	W0411	ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W5330

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W5353	NA2	AUTOTHROTTLE SERVO MOTOR 1 TO E1-1				
I D41159P		AE0101A	POS 07	D41159J	W0111	ALL
I D10025		M01836	/ /			ALL
I W5355	SN2	INTERPHONE - L WHEEL WELL				
I D06011			664/161/L071			ALL
I W5357	SN2	INTERPHONE - RIGHT WHEEL WELL				
I D06057			664/161/R072			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W5350

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W5363	NA2	ATC TOP ANT E1-2 TO S942 D2701 (COAX)				
I D04603J		AE0102B	POS 05	D04603P	W0121	ALL
I D02701		S00942	316/163/L025			ALL
I W5367	LC3	AUTOPILOT E1-1 TO ACCEL PCU SYSTEM - A				
I D04073P		AE0101A	POS 27	D04073J	W0111	ALL
I D40053P		AE0302A	POS 02	D40053J	W0321	ALL
I D43910P		AJ0039A	POS 03	D43910J	W0082	ALL
I D42102J		AL0720A	POS 02	D42102P	W1022	YT101-YT106
I D42102J		AL0720A	POS POS 02	D42102P	W1022	YT107-YT119
I D42102J		AL0720A	POS POS 02	D42102P		YT120, YT132-YT133
I D42102J		AL0720A	POS POS 02	D42102P	W1022	YT126-YT131
I D43100J		AL0720C	POS 01	D43100P	W1032	YT101-YT119, YT126-YT131
I D43100J		AL0720C	POS POS 01	D43100P		YT120, YT132-YT133
I D01709		M00937	666/187/L020			ALL
I D01827		M00943	670/193/L040			ALL
I D01863		S00774	668/192/L040			ALL
I W5369	LE2	AUTOPILOT E1-1 TO ELEX PANEL AND TB803 - SYSTEM A				
I D04075P		AE0101A	POS 23	D04075J	W0111	ALL
I D08313P		AF0213A	POS 05	D08313J	W0049	ALL
I D00417		AF0222A	POS 03			ALL
I D00383		M00219	223/202/L014			ALL
I D00385		M00220	215/190/R015			ALL
I D00397		M00221	215/196/L024			ALL
I D02257		M01201	206/200/R015			ALL
I D10553		M01201	206/200/R015			ALL
I D10551		M01967	215/180/R020			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W5360

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W5375	RD3	AUTOPILOT E1-4 TO ACCEC/PCU - SYSTEM B				
I D04077J		AE0104A	POS 15	D04077P	W0141	ALL
I D42053P		AE0302A	POS 47	D42053J	W0321	ALL
I D43908P		AJ0039A	POS 05	D43908J	W0082	ALL
I D42100J		AL0720A	POS 03	D42100P	W1022	YT101-YT106, YT126-YT131
I D42100J		AL0720A	POS POS 03	D42100P	W1022	YT107-YT119
I D42100J		AL0720A	POS POS 03	D42100P		YT120, YT132-YT133
I D43102J		AL0720D	POS 02	D43102P	W1032	YT101-YT119, YT126-YT131
I D43102J		AL0720D	POS POS 02	D43102P		YT120, YT132-YT133
I D01707		M00937	666/187/L020			ALL
I D01691		M01024	670/193/L050			ALL
I D01859		S00772	673/192/L049			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W5370

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W5381	LE2	AUTOPILOT E1-1 TO AB1050L				
I D45501J		AB1050L	POS 05	D45501P	W7381	ALL
I D45551P		AE0101A	POS 36	D45551J	W0111	ALL
I W5383	RF2	AUTOPILOT E1-4 TO AB1050R				
I D45503J		AB1050R	POS 06	D45503P	W7383	ALL
I D45553J		AE0104A	POS 13	D45553P	W0141	ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W5380

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W5397	NB2	AUTOTHROTTLE SERVO MOTOR 2 TO E1-1				
I D41161P		AE0101B	POS 03	D41161J	W0111	ALL
I D10027		M01837	//			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W5390

Page 1 End

Jun 21/2016





## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W5409	NN2	DFDAU E3-2 SHELF TO DISCONNECT PANEL OF FLIGHT RECORDER				
I D43267P				D43267J	W0767	ALL
I D43209P		AE0302A	POS 49	D43209J	W0321	ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W5400

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W5411	NB2	VHF-2 ANTENNA-E/E TO STA 506 BOTTOM				
I D04137J				D04137P	W5417	ALL
I D04131J		AE0105A	POS 13	D04131P	W0151	ALL
I W5413	NA2	VHF-1 ANTENNA-E/E TO STA 630.36				
I D04133P		AE0103A	POS 02	D04133J	W0131	ALL
I D00115		M00057	630/305/R005			ALL
I W5415	NC2	VHF-3 ANTENNA-E/E TO STA 470.88 BOTTOM				
I D43301P		AE0303A	POS 01	D43301J	W0331	ALL
I D00335		M00225	471/150/0000			ALL
I W5417	NB2	VHF-2 ANTENNA BOTTOM				
I D04137P				D04137J	W5411	ALL
I D00117		M00058	727D+11/148/0000			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W5410

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W5431	NN2	<b>-800 CVR(E6) W/RIPS(PROV) &amp; CMU DATA LINK</b>				
I D40751P				D40751J	W3004	ALL
I D10101			955/301/L008			ALL
I D04371P		AE0401A	POS 23	D04371J	W0411	ALL
I D46623P		AJ0011	POS 03	D46623J	W0122	ALL
I D00177		M00383	E006-01/195/R045			ALL
I D13185		M02862				ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W5430

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W5457	RF2	AUTOPILOT E1-4 TO CONTROL STAND - SYSTEM B				
I D05971J		AE0104A	POS 02	D05971P	W0141	ALL
I D08315P		AF0222A	POS 04	D08315J	W0051	ALL
I D01673		M00219	223/202/L014			ALL
I D01675		M00220	215/190/R015			ALL
I D01713		M00221	215/196/L024			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W5450

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W5461	LA2	FLIGHT RECORDER E3-2 SHELF TO E1-1 AND E3-3 SHELF				
I D42311P		AE0101A	POS 06	D42311J	W0111	ALL
I D43211P		AE0101A	POS 21	D43211J	W0111	ALL
I D46461P		AE0101A	POS 22	D46461J	W0111	ALL
I D43217P		AE0302A	POS 01	D43217J	W0321	ALL
I D43261P		AE0302A	POS 40	D43261J	W0321	ALL
I D42261P		AE0302A	POS 41	D42261J	W0321	ALL
I D42361P		AE0302A	POS 43	D42361J	W0321	ALL
I D43049P		AE0303A	POS 22	D43049J	W0331	ALL
I D44161P		AE0401A	POS 24	D44161J	W0410	ALL
I D41561J		AE0502A	POS 05	D41561P	W0521	YT104-YT133
I D45261J		AE0502A	POS 06	D45261P	W0521	YT104-YT133
D41561J		AE0502A	POS 17	D41561P	W0521	YT101-YT103
D45261J		AE0502A	POS 18	D45261P	W0521	YT101-YT103
I W5463	RB2	FLIGHT RECORDER E3-2 SHELF TO E/E BAY SHELF				
I D45515P		AE0101A	POS 35	D45515J	W0111	ALL
I D41563P		AE0101B	POS 01	D41563J	W0111	ALL
I D41163P		AE0101B	POS 08	D41163J	W0111	ALL
I D41463J		AE0104A	POS 11	D41463P	W0141	ALL
I D45517J		AE0104B	POS 02	D45517P	W0141	ALL
I D43263P		AE0302A	POS 44	D43263J	W0321	ALL
I D42363P		AE0302A	POS 53	D42363J	W0321	ALL
D45263J		AE0502A	POS 06	D45263P	W0523	YT101-YT103
I D45263J		AE0502A	POS 29	D45263P	W0523	YT104-YT133

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W5460

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
<b>W5501</b>	<b>LA2</b>	<b>ADIRU NO.1 TO AOA-L,ADM-L PITOT, AND TAT PROBE</b>				
D11294		A00023	192/225/L034			ALL
D45239J		AE0502A	POS 08	D45239P	W0521	YT104-YT133
D45239J		AE0502A	POS 20	D45239P	W0521	YT101-YT103
D40087P		AJ0048A	POS 08	D40087J	W0088	ALL
D00277		M00171	268/191/L050			ALL
D03689		M01750	199.816/175/L013			ALL
D00365		T00433	192/204/			ALL
D10015		T433 J2				ALL
<b>W5502</b>	<b>SA2</b>	<b>LEFT A/C PACK (STA 536L) DISC TO A/C PACK (SA2)</b>				
D40844P				D40844J	W5504	YT116-YT120, YT132-YT133
D40844P		DISC BRKT		D40844J	W5504	YT101-YT115, YT126-YT131
D41500		DM0050	536/163/L009			ALL
D16252		L00182	554/158/L007			YT112-YT120, YT131-YT133
D16260		L00183	615/158/L009			YT112-YT120, YT131-YT133
D00856		M00355	540/ /			ALL
D15822		M02953	624/156/L11			YT116-YT120, YT132-YT133
D00398		V00016	540/166/R001			ALL
D00392		V00018	581/158/L009			YT101-YT115, YT126-YT131
D00488		V00018	581/158/L009			YT101-YT115, YT126-YT131
D00962		V00018	581/158/L009			YT101-YT115, YT126-YT131
D03886		V00143	542/157/L012			ALL
D15818		V00184	STA581/158/LBL9			YT116-YT120, YT132-YT133
D15830		V00184	STA581/158/LBL9			YT116-YT120, YT132-YT133
<b>W5503</b>	<b>NB2</b>	<b>ADIRU NO.2 TO AOA-R AND ADM-R PITOT</b>				
D11298		A00025	192/213/R034			ALL
D11300		A00026	192/224/R034			ALL
D45241J		AE0502A	POS 10	D45241P	W0523	YT101-YT103

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W5500

Page 1

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
<b>W5503</b>	<b>NB2</b>	<b>ADIRU NO.2 TO AOA-R AND ADM-R PITOT (continued)</b>				
D45241J		AE0502A	POS 33	D45241P	W0523	YT104-YT133
D40097P		AJ0046B	POS 06	D40097J	W0066	ALL
D03695		M01753	200.618/177/R018			ALL
D14284		S1153				ALL
D00287		T00437	192/204/			ALL
D10017		T437 J2				ALL
<b>W5504</b>	<b>SA2</b>	<b>LEFT A/C PACK (STA 536L) DISC TO A/C PACK (SA2)</b>				
D40844J				D40844P	W5502	YT116-YT120, YT132-YT133
D40844J		DISC BRKT		D40844P	W5502	YT101-YT115, YT126-YT131
D00486		V00018	581/158/L009			YT101-YT115, YT126-YT131
D15832		V00184	STA581/158/LBL9			YT116-YT120, YT132-YT133
<b>W5506</b>	<b>SB2*</b>	<b>P8 TO E/E BAY</b>				
D07711P				D07711J	W2104	YT113-YT120
D07711P				D07711J		YT132-YT133
D11130		AB0250A	POS 04			ALL
D10167		AB0250A	POS 06			ALL
D40806J		AE0104A	POS 19	D40806P	W0141	ALL
D40430P		AE0202A	POS 15	D40430J	W0220	ALL
D40950P		AE0302A	POS 15	D40950J	W0321	ALL
D11288		AF0213A	POS 02			ALL
D10171		AF0213A	POS 06			ALL
D40674P		AJ0022	POS 07	D40674J	W0076	ALL
D40686P		AJ0023	POS 02	D40686J	W0078	ALL
D43900P		AJ0039A	POS 01	D43900J	W0082	ALL
D46128P		AJ0046A	POS 05	D46128J	W0066	ALL
D48120P		AJ0048A	POS 09	D48120J	W0088	ALL
D48118P		AJ0048A	POS 22	D48118J	W0088	ALL
D40800P		AP0600B	POS 08	D40800J	W0044	ALL
D40804P		AP0900A	POS 18	D40804J	W0001	ALL
D40802P		AP1800B	POS 05	D40802J	W0018	ALL
D10578		M01616	248/188/L044			ALL
D44276		M02604	192/200/L007			ALL
D00576		P008-01	P008-00/ /			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W5500

Page 2

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
<b>W5506</b>	<b>SB2*</b>	<b>P8 TO E/E BAY (continued)</b>				
D01078		P008-01	P008-00/ /			ALL
D15510		S01186	247/206/R013			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W5500

Page 3 End

Jun 21/2016





## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W5510	SA2*	P8 TO E/E BAY AND J BOX.				
I D11128		AB0250A	POS 05			ALL
I D40496J		AE0104A	POS 21	D40496P	W0141	ALL
I D40428P		AE0201A	POS 08	D40428J	W0212	ALL
I D11286		AF0213A	POS 03			ALL
I D40672P		AJ0022	POS 02	D40672J	W0076	ALL
I D40688P		AJ0023	POS 05	D40688J	W0078	ALL
I D46130P		AJ0046A	POS 01	D46130J	W0066	ALL
I D48122P		AJ0048A	POS 03	D48122J	W0088	ALL
I W5514	SA2	FLIGHT DECK PANEL LIGHTING (SA2)				
I D40826J		AE0104A	POS 27	D40826P	W0141	ALL
I D46104P		AJ0046A	POS 11	D46104J	W0066	ALL
I D40822P		AP0600B	POS 03	D40822J	W0044	ALL
I D40824P		AP0900A	POS 05	D40824J	W0003	ALL
I D40830P		AP1800B	POS 07	D40830J	W0018	ALL
I D00940		M00315	205/209/R006			ALL
I D01172		M00315	205/209/R006			ALL
I D01344		M00469	J019-00/ /			ALL
I D01346		M00469	J019-00/ /			ALL
I D02866		M00469	J019-00/ /			ALL
I D00776		S00128	190/208/R002			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W5510

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W5526	SA2	DISC AB0500DL TO E1-4, E4-1 (SA2)				
I D40302J		AB0500DL	POS 09	D40302P	W5222	ALL
I D04580P		AB0536L	POS 01	D04580J	W5102	ALL
I D43016J		AE0104A	POS 22	D43016P	W0141	ALL
I D41842P		AE0303A	POS 27	D41842J	W0330	ALL
I D43018P		AE0401A	POS 44	D43018J	W0410	ALL
I D03940		S00934	520/160/L017			ALL
I D41502		STA0536L				ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W5520

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W5530	SA2*	DISC AB0500DL TO E3-2				
I D40318J		AB0500DL	POS 04	D40318P	W5222	ALL
I D43022P		AE0302A	POS 24	D43022J	W0321	ALL
I D46028J		AL0675B	POS 04	D46028P	W7230	ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W5530

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W5558	SN2	J48 AND TB1806 TO RADAR BAY.(FQIS TANK 1 PWR)				
D47600P		AJ0048A	POS 24	D47600J	W0088	YT110-YT120, YT130-YT133
D11352		M01827	228/182/R020			YT110-YT120, YT130-YT133
D15806		M01827	228/182/R020			YT110-YT120, YT130-YT133

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W5550

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
<b>I W5562</b>	<b>SN2</b>	<b>WING BODY PRESS SEAL TO RADAR BAY</b>				
I D39913		AC0520				ALL
I D11304		M01827	228/182/R020			ALL
I D11352		M01827	228/182/R020			YT101-YT109, YT126-YT129
<b>I W5564</b>	<b>SN2*</b>	<b>WING BODY PRESS SEAL TO E/E BAY</b>				
I D39909		AC0520				ALL
I D40136P		AE0202A	POS 07	D40136J	W0220	ALL
<b>I W5566</b>	<b>LB1</b>	<b>P18 LEFT CAB CEILING TO WING/BODY DISCBUNDLE A</b>				
I D41106P				D41106J	W6586	YT113-YT120, YT131-YT133
I D41284J				D41284P	W5570	YT113-YT120, YT131-YT133
I D41286J				D41286P	W5570	YT113-YT120, YT131-YT133
I D39905		AC0520				ALL
I D40118P		AE0202A	POS 14	D40118J	W0220	ALL
<b>I W5568</b>	<b>LN1*</b>	<b>LEFT WING BODY PRESS SEAL TO E/E BAY</b>				
I D41854J		AB0500DL	POS 01	D41854P	W1128	ALL
I D05348J		AB0500DL	POS 02	D05348P	W1128	ALL
I D05346J		AB0500DL	POS 03	D05346P	W1134	YT101-YT119
I D41852J		AB0500DL	POS 10	D41852P	W1134	YT101-YT119, YT126-YT131
I D05346J		AB0500DL	POS POS 03	D05346P		YT120, YT132-YT133
I D05346J		AB0500DL	POS POS 03	D05346P	W1134	YT126-YT131
I D41852J		AB0500DL	POS POS 10	D41852P		YT120, YT132-YT133
I D39937		AC0520				ALL
I D40120P		AE0101A	POS 14	D40120J	W0111	ALL
I D40258P		AE0201A	POS 23	D40258J	W0212	ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W5560

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W5570	LN1*	LEFT WING BODY PRESS SEAL TO E/E BAY (LTRTL)				
D41284P				D41284J	W5566	YT113-YT120, YT131-YT133
D41286P				D41286J	W5566	YT113-YT120, YT131-YT133

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W5570

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W5580	SN2	RADAR BAY TO WHEEL WELL DISC STA 675L-CENTER TANK.(FQIS)				
I D04850J		AL0675B	POS 02	D04850P	W7580	ALL
I D11308		M01827	228/182/R020			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W5580

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W5592	SN2	SEC 47 OVHT DETECTION TO SEC 48 OVHT DETECTION				
I D00862		M00275	1016/202/L011			ALL
I D00864		M00276	1045/ /			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W5590

Page 1 End

Jun 21/2016





## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
<b>I W5603</b>	<b>NN2</b>	<b>E3-2 SHELF (DFDAU) TO LH BRAKE PRESSURE XMTRS</b>				
I D43203P		AE0302A	POS 11	D43203J	W0321	YT101-YT119, YT126-YT131
I D00821		M00517	666/193/R048			YT101-YT119, YT126-YT131
I D02909		T00492	727/187/L020			YT101-YT119, YT126-YT131
I D02913		T00494	685/195/L065			YT101-YT119, YT126-YT131
<b>I W5605</b>	<b>NN2</b>	<b>E1-3 SHELF (DFDAU) TO RH BRAKE PRESSURE XMTRS</b>				
I D43205P		AE0302A	POS 38	D43205J	W0321	ALL
I D02911		T00493	727/189/L008			ALL
I D02915		T00495	692/192/L065			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W5600

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W5610	SA2*	E1 TO E2, E3				
I D40344P		AE0103A	POS 10	D40344J	W0131	ALL
I D40346J		AE0104A	POS 28	D40346P	W0141	ALL
I D40348P		AE0202A	POS 10	D40348J	W0220	ALL
I D42026P		AE0301A	POS 03	D42026J	W0311	YT104-YT133
I D40350P		AE0302A	POS 06	D40350J	W0321	ALL
I D40940P		AE0302A	POS 07	D40940J	W0321	ALL
I W5612	SN2*	AP0600B TO E/E BAY.				
I D40358P		AE0201A	POS 18	D40358J	W0212	ALL
I D40360P		AE0202A	POS 16	D40360J	W0220	ALL
I D40362P		AE0302A	POS 05	D40362J	W0321	ALL
I D40356P		AE0402A	POS 31	D40356J	W0422	ALL
I D40930P		AE0402A	POS 36	D40930J	W0422	ALL
I D40352P		AP0600B	POS 16	D40352J	W0044	ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W5610

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W5719	LA2	INTERRACK E1-1 TO E1-2,E1-3 AND E4-2				
I D41125P		AE0101A	POS 25	D41125J	W0111	ALL
I D41211J		AE0102A	POS 01	D41211P	W0121	ALL
I D41509P		AE0103A	POS 19	D41509J	W0131	ALL
I D42111P		AE0402A	POS 01	D42111J	W0422	ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W5710

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W5721	LE2	E1-1 TO E1-2 TO E1-4				
I D41121P		AE0101A	POS 17	D41121J	W0111	ALL
I D41127J		AE0102A	POS 13	D41127P	W0121	ALL
I D41129J		AE0104A	POS 18	D41129P	W0141	ALL
I W5723	RB2*	INTERRACK E1-4 TO E1-1,E1-2,E1-3				
I D40063P		AE0101B	POS 05	D40063J	W0111	ALL
I D43317P		AE0101B	POS 10	D43317J	W0111	ALL
I D41213J		AE0102A	POS 12	D41213P	W0121	ALL
I D41131P		AE0103A	POS 22	D41131J	W0131	ALL
I D40047J		AE0104A	POS 08	D40047P	W0141	ALL
I D41507J		AE0105A	POS 03	D41507P	W0151	ALL
I D43306P		AE0303A	POS 05	D43306J	W0331	YT101-YT103
I D43333P		AE0303A	POS 44	D43333J	W0331	YT101-YT103
I D43333P		AE0303A	POS 47	D43333J	W0331	YT104-YT133
I D43306P		AE0303A	POS 48	D43306J	W0331	YT104-YT133
I W5726	AD1	ECU TO E/E BAY AND AB1050R DISCONNECT BRACKET				
I D40790P		AB1050R	POS 01	D40790J	W4726	ALL
I D40876P		AB1050R	POS 02	D40876J	W4726	ALL
I D40854P		AB1050R	POS 03	D40854J	W4724	ALL
I D40910P		AE0201A	POS 06	D40910J	W0212	ALL
I D40254P		AE0201A	POS 07	D40254J	W0212	ALL
I D40926P		AE0201A	POS 09	D40926J	W0212	ALL
I D40942P		AE0202A	POS 03	D40942J	W0220	ALL
I D40928P		AE0202A	POS 04	D40928J	W0220	ALL
I D40912P		AE0202A	POS 22	D40912J	W0220	ALL
I D40946P		AE0202A	POS 23	D40946J	W0220	ALL
I D40908P		AE0302A	POS 52	D40908J	W0321	ALL
I D40904P		AE0401A	POS 26	D40904J	W0410	ALL
I D03599		M01709	E6 880/177/R032			ALL
I D03599A		M01709	E6 880/177/R032			ALL
I D03599B		M01709	E6 880/177/R032			ALL
I D03599C		M01709	E6 880/177/R032			ALL
I D11436		P0091				ALL
I D11438		P0091				ALL
I W5728	AA2*	DISC AL0675ATO E2-2 (WITH E-6)				
I D43024P		AE0202A	POS 29	D43024J	W0220	ALL
I D46026J		AL0675B	POS 01	D46026P	W7026	ALL

### MASTER BUNDLE LIST

D280A351

91-21-13

Section W5720

Page 1

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W5837	NA2	LOC ANT LEFT - STA 178 TO R315 - LOC ANTENNA SWITCH RELAY-1				
I D03321				D02623		ALL
I D02117		R00315	306/180/R021			ALL
I W5839	RB2	LOC ANT RIGHT - R316 - LOC ANTENNA SWITCH RELAY-2				
I D03323				D02627		ALL
I D02125		R00316	300/178/R022			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W5830

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W6024	NN2	P19 (EXTERNAL POWER RECP PANEL) TO P6 DISC.				
I D40654P		AP0600B	POS 24	D40654J	W0044	ALL
I D40664		DM0035	230/187/R034			ALL
I D16234		L00171	228/177/L004			YT112-YT120, YT131-YT133
I W6028	SN2	MAIN WHEEL WELL TO E/E BAY VIA CROWN				
I D43104J		AB0727R	POS 01	D43104P	W1032	YT101-YT119
I D43104J		AB0727R	POS POS 01	D43104P		YT120, YT132-YT133
I D43104J		AB0727R	POS POS 01	D43104P	W1032	YT126-YT131
I D40180P		AE0101A	POS 16	D40180J	W0111	ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W6020

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W6032	RB1	DISC AB0500DR TO E4-2.				
I D07787J				D07787P	W6420	YT116-YT120, YT132-YT133
I D08384J				D08384P	W6412	YT116-YT120, YT132-YT133
I D08387J				D08387P	W6420	YT116-YT120, YT132-YT133
I D40402J		AB0500DR	POS 06	D40402P	W6124	ALL
I D40416J		AB0500DR	POS 08	D40416P	W5224	ALL
I D43028P		AE0402A	POS 16	D43028J	W0422	ALL
I W6034	NA2	DISC AB0500DR TO E3-2				
I D40404J		AB0500DR	POS 05	D40404P	W6124	ALL
I D43030P		AE0302A	POS 51	D43030J	W0321	ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W6030

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle	Sep	Description	Location	MW Connector	MW Bundle	Effectivity
Equip		Matewith				
I W6102	LA2	CABIN PRESSURE OUTFLOW VALVE TO E/E BAY (LA2).				
I D40240P		AE0202A	POS 20	D40240J	W0220	ALL
I D40242P		AE0401A	POS 30	D40242J	W0410	ALL
I D10728		V00048	980/185/R026			ALL
I D10730		V00048	980/185/R026			ALL
I D10732		V00048	980/185/R026			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W6100

Page 1 End

Jun 21/2016





## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W6110	LA2*	P91 (FWD DISC) TO E/E BAY.				
I D40364P		AE0101A	POS 12	D40364J	W0111	ALL
I D48124P		AJ0048A	POS 18	D48124J	W0088	ALL
I D40368P		AP0600B	POS 09	D40368J	W0044	ALL
I D16262		L00199	218/206/L005			YT112-YT120, YT131-YT133
I D16264		L00200	218/206/R005			YT112-YT120, YT131-YT133
I D16266		L00201	201/204/R008			YT112-YT120, YT131-YT133
I D16268		L00202	354/200/L020			YT112-YT120, YT131-YT133
I D16270		L00203	354/200/R014			YT112-YT120, YT131-YT133
I D16272		L01307	350/181/R020			YT112-YT120, YT131-YT133
I D16274		L01313	350/177/L028			YT112-YT120, YT131-YT133
I D00160		M00098	362/164/R027			ALL
I D10884		M01708	273/189/L022			ALL
I D11418		P0091				ALL
I D11422		P0091				ALL
I D11450		P0092				ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W6110

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W6122	SB2*	DISC AB0500DR TO MAIN WHEEL WELL				
I D40410P		AB0500DR	POS 02	D40410J	W6528	ALL
I D40400P		AB0500DR	POS 03	D40400J	W6530	ALL
I D46042J		AL0675C	POS 02	D46042P	W8222	ALL
I D40004J		AL0720C	POS 02	D40004P	W8224	ALL
I W6124	LA2	MAIN WHEEL WELL TO AB0500DR AND CROWN				
I D40264P				D40264J	W6134	ALL
I D43400P				D43400J	W6134	ALL
I D40404P		AB0500DR	POS 05	D40404J	W6034	ALL
I D40402P		AB0500DR	POS 06	D40402J	W6032	ALL
I D46602P		AB0727R	POS 02	D46602J	W5124	ALL
I D46038J		AL0675C	POS 03	D46038P	W8122	ALL
I D46020J		AL0720B	POS POS 04	D46020P	W7128	YT101-YT119
I D46020J		AL0720B	POS POS 04	D46020P		YT120, YT132-YT133
I D46020J		AL0720B	POS POS 04	D46020P	W7128	YT126-YT131
I D46044J		AL0720C	POS 03	D46044P	W8226	ALL
I D40006J		AL0720C	POS 04	D40006P	W8226	ALL
I D46040J		AL0720D	POS 01	D46040P	W8124	ALL
I W6128	LA1	E/E BAY TO MWW-SYS A ELEC HYD PUMP (VICKERS ONLY)				
I D43060P		AE0202A	POS 17	D43060J	W0220	YT101-YT119, YT126-YT131
I D00476		L00323	500A+10/150/R032			YT101-YT112, YT126-YT130
I D02664		M1103				YT101-YT119, YT126-YT131
I D11456		P0092				YT101-YT119, YT126-YT131
I D02688		S798				YT101-YT119, YT126-YT131

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W6120

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W6134	LA2	E/E BAY TO AB1050R DISCONNECT BRACKET				
I D40236J				D40236P	W7030	ALL
I D40264J				D40264P	W6124	ALL
I D43400J				D43400P	W6124	ALL
I D40192J		AB1030C	POS 01	D40192P	W8030	ALL
I D04826J		AB1030C	POS 04	D04826P	W7102	ALL
I D40842P		AB1050L	POS 01	D40842J	W4134	ALL
I D40194P		AE0302A	POS 39	D40194J	W0321	ALL
I D40276P		AE0302A	POS 48	D40276J	W0321	ALL
I D40238P		AE0402A	POS 08	D40238J	W0422	ALL
I W6136	RN1	RUDDER EQUIP (VERTICAL STAB) TO DISC AB1080				
I D40268P		AB1080	POS 01	D40268J	W4134	ALL
I D10197		M00175	1087/ /			ALL
I D02932		M01125	RUD STA/51./4			ALL
I D03576		T00469	RUD80.00/ /			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W6130

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W6162	RB2*	RIGHT WING BODY PRESS SEAL TO E/E BAY				
I D11164		AB0237B	POS 01			ALL
I D39922		AD0520				ALL
I D40156P		AE0401A	POS 50	D40156J	W0410	ALL
I W6164	RB1*	RIGHT WING BODY PRESS SEAL TO E/E BAY				
I D39934		AD0520				ALL
I D40140P		AE0402A	POS 26	D40140J	W0422	ALL
I D40720P		AE0402A	POS 27	D40720J	W0422	ALL
I W6166	SN2*	RIGHT WING BODY PRESS SEAL TO E/E BAY				
I D39902		AD0520				ALL
I D40142P		AE0101B	POS 04	D40142J	W0111	ALL
I D40948P		AE0101B	POS 06	D40948J	W0111	ALL
I W6168	SB2*	RIGHT WING BODY PRESS SEAL TO E/E BAY				
I D39930		AD0520				ALL
I D40144P		AE0401A	POS 38	D40144J	W0410	ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W6160

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W6170	RA2*	RIGHT WING BODY PRESS SEAL TO E/E BAY				
I D40728J		AB0405B	POS 01	D40728P	W4170	ALL
I D39926		AD0520				ALL
I D46144P		AJ0046A	POS 07	D46144J	W0066	ALL
I W6172	RA2*	RIGHT WING BODY PRESS SEAL TOE/E BAY				
I D11162		AB0237B	POS 02			ALL
I D40730J		AB0405B	POS 02	D40730P	W4170	ALL
I D39918		AD0520				ALL
I D46146P		AJ0046A	POS 08	D46146J	W0066	ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W6170

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W6182	NN2	ISPC TO P6 (EE-BAY TO PC POWER OUTLET(P6))				
I D14010		DISC BRKT				ALL
I D14006		M02566	360/160/25			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W6180

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
<b>W6202</b>	<b>SB2</b>	<b>RIGHT A/C PACK (STA 536R) DISC TO A/C PACK (SB2)</b>				
D04582J		AB0536R	POS 01	D04582P	W6528	ALL
D40058J		AB0536R	POS 02	D40058P	W6230	ALL
D16244		L00179	533/150/R023			YT112-YT120, YT131-YT133
D16246		L00180	579/154/R038			YT112-YT120, YT131-YT133
D16248		L00181	654/151/R039			YT112-YT120, YT131-YT133
D00844		M00356	580/155/R040			ALL
D00836		M00371	540/170/R025			ALL
D11920		M1849				YT101-YT112, YT126-YT130
D16694		M3236				YT113-YT120, YT131-YT133
D00538		S00005	577/157/R026			ALL
D10058		S00939	578/165/R031			ALL
D00098		T00403	558/160/R042			ALL
D03876		T00474	573/154/R030			ALL
D03918		T00482	584/162/R032			ALL
D03982		T00489	574/152/R033			ALL
D03188		V00132	643/162/R049			ALL
D03190		V00132	643/162/R049			ALL
D03872		V00141	656/145/R010			ALL
D03874		V00142	653/151/R035			ALL
D03888		V00144	540/152/R012			ALL
D03890		V00145	546/153/R016			ALL
<b>W6204</b>	<b>RB2</b>	<b>CABIN PRESSURE OUTFLOW VALVE TO E/E BAY (RB2).</b>				
D40066P		AE0401A	POS 39	D40066J	W0410	ALL
D10734		V00048	980/185/R026			ALL
D10736		V00048	980/185/R026			ALL
<b>W6206</b>	<b>RN2</b>	<b>P8 TO MISC EQUIPMENT (RN2)</b>				
D40816P		AP0600B	POS 18	D40816J	W0044	ALL
D03428		P008-47	P008-00/ /			ALL
D03432		P008-50	P008-00/ /			ALL
D03768		R00425	J019-00/ /			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W6200

Page 1

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W6208	RA2	P8 TO MISC EQUIPMENT				
I D31020J		AC0235A	POS 06	D31020P		YT101-YT120
I D40818P		AE0101B	POS 07	D40818J	W0111	ALL
I D41021P		AE0101B	POS 24	D41021J	W0111	YT101-YT120
I D40228P		AE0402A	POS 13	D40228J	W0422	ALL
I D40222P		AE0402A	POS 14	D40222J	W0422	ALL
I D05148P		AF0213A	POS 01	D05148J	W0008	ALL
I D05150P		AF0213A	POS 04	D05150J	W0008	ALL
I D00698		AF0222A	POS 05			ALL
I D10537		AF0222A	POS 07			ALL
I D46110P		AJ0046A	POS 04	D46110J	W0066	ALL
I D46150P		AJ0046A	POS 12	D46150J	W0066	ALL
I D40528J		AP0600A	POS 08	D40528P	W2212	ALL
I D40820P		AP0600B	POS 17	D40820J	W0044	ALL
I D01084		M00359	199/205/L006			ALL
I D03116		M01126	P008-43/ /			ALL
I D03124		M01201	206/200/R015			ALL
I D12156		M01983	228/202/L011			ALL
I D02934		N00159	P008-43/ /			ALL
I D02930		P008-43	P008-00/ /			ALL
I D10199		S00276	178/200/L030			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W6200

Page 2 End

Jun 21/2016





## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W6210	RB1	P92 (AFT DISC) TO E/E BAY.				
I D40372P		AE0201A	POS 13	D40372J	W0212	ALL
I D40938P		AE0402A	POS 28	D40938J	W0422	ALL
I D40370P		AE0402A	POS 29	D40370J	W0422	ALL
I D00042		M00005	E002-01/ /			ALL
I D02936		M00006	390/158/L005			ALL
I D11738		P0092				ALL
I W6212	NN2	J39 (B) TO MISC EQUIPMENT				
I D40297J		AB0857L	POS 01	D40297P	W3625	YT101-YT120
I D41004P		AJ0004	POS 03	D41004J	W0094	YT101-YT120
I D43926P		AJ0039B	POS 01	D43926J	W0084	ALL
I D43924P		AJ0039B	POS 02	D43924J	W0084	ALL
I D40708P		AP0600B	POS 19	D40708J	W0044	ALL
I W6214	LA2*	P6A TO E2-2, E4-1 (LA2)				
I D40774P		AE0101A	POS 33	D40774J	W0111	ALL
I D41012P		AE0202A	POS 18	D41012J	W0220	ALL
I D40380P		AE0202A	POS 26	D40380J	W0220	ALL
I D41814P		AE0303A	POS 25	D41814J	W0330	ALL
I D41828P		AE0401A	POS 12	D41828J	W0410	ALL
I D40328P		AE0401A	POS 31	D40328J	W0410	ALL
I D40378P		AE0401A	POS 46	D40378J	W0410	ALL
I D40444P		AP0600A	POS 04	D40444J	W0044	ALL
I D03892		S00931	373/194/L058			ALL
I D03882		T00477	372/196/L057			ALL
I D03884		T00478	372/196/L057			ALL
I D03924		T00485	371/194/L058			ALL

### MASTER BUNDLE LIST

D280A351

91-21-13

Section W6210

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W6220	SA2	E3-3 TO E4-1 (SA2)				
I D41802P		AE0303A	POS 26	D41802J	W0330	ALL
I D41804P		AE0401A	POS 09	D41804J	W0410	ALL
I W6222	RN1	J4 TO E/E BAY AND DISCONNECT BRACKET AB1050R				
I D07099P				D07099J	W3453	ALL
I D40248J				D40248P	W5224	ALL
I D43404J				D43404P	W5224	ALL
I D47019P				D47019J	W3453	ALL
I D40836P		AB1050R	POS 05	D40836J	W4222	ALL
I D40432P		AE0402A	POS 17	D40432J	W0422	ALL
I D40742P		AE0402A	POS 19	D40742J	W0422	ALL
I D40602P		AJ0004	POS 01	D40602J	W0094	ALL
I D40616P		AJ0004	POS 08	D40616J	W0094	ALL
I D40614P		AJ0004	POS 09	D40614J	W0094	ALL
I D40574P		AP0600B	POS 21	D40574J	W0044	ALL
I W6228	RB2	DISC AB0500DR TO MAIN WHEEL WELL				
I D40406P		AB0500DR	POS 01	D40406J	W6528	ALL
I D46048J		AL0720D	POS 03	D46048P	W8230	ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W6220

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W6230	RB2	DISC AB0500DR TO E1-3, E4-1 (RB2)				
I D40058P		AB0536R	POS 02	D40058J	W6202	ALL
I D41806P		AE0303A	POS 41	D41806J	W0330	ALL
I D40330P		AE0401A	POS 36	D40330J	W0410	ALL
I D43038P		AE0401A	POS 49	D43038J	W0410	ALL
I D14394		M02797	500I+16/172/R60			ALL
I D14396		M02797	500I+16/172/R60			ALL
I D14398		M02798	657/147/R33			ALL
I D14400		M02798	657/147/R33			ALL
I D15828		M02956	537/150/R2			YT116-YT120, YT132-YT133
I D03854		M1441				ALL
I D03878		T00475	5002+7/192/R003			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W6230

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W6242	RN1	P92 TO AB0340B DISCONNECT BRACKET				
I D11398				D11400		ALL
I D01128		AB0288	POS 02			ALL
I D40050P		AB0340A	POS 05	D40050J	W3058	YT101-YT120
I D40050P		AB0340A	POS POS 05	D40050J	W3058	YT126-YT131
I D40050P		AB0340A	POS POS 05	D40050J		YT132-YT133
I D40202P		AB0340B	POS 09	D40202J	W4258	ALL
I D46138P		AJ0046B	POS 02	D46138J	W0066	ALL
I D11452		P0092				ALL
I W6248	LN2*	AFT CARGO LIGHTS				
I D40500P		AB0500DL	POS 05	D40500J	W5248	ALL
D11772		L00189	727B+7/205/L011			YT101-YT111, YT126-YT130
D16298		L00189	727B+7/205/L011			YT112-YT120, YT131-YT133
D11770		L00190	727A+10/205/R019			YT101-YT111, YT126-YT130
D16296		L00190	727A+10/205/R019			YT112-YT120, YT131-YT133
D11776		L00191	754/205/L010			YT101-YT111, YT126-YT130
D16302		L00191	754/205/L010			YT112-YT120, YT131-YT133
D11778		L00192	774/205/R010			YT101-YT111, YT126-YT130
D16304		L00192	790/202/R009			YT112-YT120, YT131-YT133
D16312		L00193	823/202/L07			YT112-YT120, YT131-YT133
D11782		L00193	834/205/L019			YT101-YT111, YT126-YT130
D11784		L00461	894/205/R010			YT101-YT111, YT126-YT130
D16314		L00461	894/205/R010			YT112-YT120, YT131-YT133
D11774		L01021	727D+17/205/R011			YT101-YT111, YT126-YT130
D16300		L01021	727D+4/202/R011			YT112-YT120, YT131-YT133

### MASTER BUNDLE LIST

D280A351

91-21-13

Section W6240

Page 1

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
<b>W6248</b>	<b>LN2*</b>	<b>AFT CARGO LIGHTS (continued)</b>				
D11998		L01206	727F+7/205/L010			YT101-YT111, YT126-YT130
D16306		L01206	727F+7/205/L010			YT112-YT120, YT131-YT133
D12000		L01315	727H+7/205/R010			YT101-YT111, YT126-YT130
D16308		L01315	727H+7/205/R010			YT112-YT120, YT131-YT133
D00866		M00276	1045/ /			ALL
D01070		M00348	727/201/L009			ALL
D11470		M01848	868/179/L043			ALL
D12180		M01906	923/173/R014			ALL
D12182		M01906	923/173/R014			ALL
D12204		M01975	911/207/R057			ALL
D12206		M01975	911/207/R057			ALL
D12208		M01976				ALL
D12210		M01976				ALL
D12212		M01977				ALL
D12214		M01977				ALL
D12216		M01978				ALL
D12218		M01978				ALL
D12224		M01980	932/207/L059			ALL
D12226		M01980	932/207/L059			ALL
D12228		M01981	942/207/R062			ALL
D12230		M01981	942/207/R062			ALL
D12232		M01982				ALL
D12234		M01982				ALL
D12188		M02763	968/198/R030			ALL
D12190		M02763	968/198/R030			ALL
D12192		M02764	1002/207/R044			ALL
D12194		M02764	1002/207/R044			ALL
D12184		M02765	957/179/L001			ALL
D12186		M02765	957/179/L001			ALL
D12200		M02766	965/203/R027			ALL
D12202		M02766	965/203/R027			ALL
D12196		M02767				ALL
D12198		M02767				ALL
D12220		M02768	967/194/R023			ALL
D12222		M02768	967/194/R023			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W6240

Page 2 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W6288	NN2	AB0340B, E3-3, E4-1 TO TEMPERATURE SENSORS.				
I D41027P				D41027J	W4116	ALL
I D41028P				D41028J	W4118	ALL
I D41838J		AB0340B	POS 03	D41838P	W2114	ALL
D41818P		AE0303A	POS 32	D41818J	W0330	YT101-YT103
I D41818P		AE0303A	POS 46	D41818J	W0330	YT104-YT133
I D41816P		AE0401A	POS 11	D41816J	W0410	ALL
I D11834		S01076	500F+10/298/L014			ALL
I D11836		S01077	534/298/R014			ALL
I D11830		T00533	500F+7/299/L012			ALL
I D11832		T00534	500F+9/300/L012			ALL
I D11838		T00535	535/299/R012			ALL
I D11840		T00536	537/299/R012			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W6280

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W6410	RB2	P92 (AFT DISC) TO E/E BAY				
I D40382P		AE0402A	POS 25	D40382J	W0422	ALL
I D11454		P0092				ALL
I W6412	RB2*	AP0600B TO E3 AND E4 (RB2)				
I D08384P				D08384J	W6032	YT116-YT120, YT132-YT133
I D40394P		AE0301A	POS 34	D40394J	W0313	ALL
I D40392P		AE0302A	POS 45	D40392J	W0321	ALL
I D43080P		AE0302A	POS 54	D43080J	W0321	ALL
I D41822P		AE0303A	POS 05	D41822J	W0330	YT104-YT133
I D41822P		AE0303A	POS 35	D41822J	W0330	YT101-YT103
I D41830P		AE0401A	POS 13	D41830J	W0410	ALL
I D41010P		AE0401A	POS 33	D41010J	W0410	ALL
I D40326P		AE0401A	POS 35	D40326J	W0410	ALL
I D40390P		AE0401A	POS 52	D40390J	W0410	ALL
I D42400P		AE0402A	POS 22	D42400J	W0420	ALL
I D40712P		AE0402A	POS 23	D40712J	W0422	ALL
I D40388P		AE0402A	POS 24	D40388J	W0422	ALL
I D41832P		AP0600B	POS 07	D41832J	W0044	ALL
I D40386P		AP0600B	POS 14	D40386J	W0044	ALL
I W6414	RB2	AP0600B TO E/E BAY (RB2)				
I D46142P		AJ0046B	POS 08	D46142J	W0066	ALL
I D40396P		AP0600B	POS 22	D40396J	W0044	ALL
I D00162		M00099	370/164/R027			ALL
I D11448		P0092				ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W6410

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W6420	SB2	E3-3 TO E4-1 (SB2)				
I D07787P				D07787J	W6032	YT116-YT120, YT132-YT133
I D08387P				D08387J	W6032	YT116-YT120, YT132-YT133
I D41808P		AE0303A	POS 37	D41808J	W0330	ALL
I D41810P		AE0401A	POS 10	D41810J	W0410	ALL
I W6424	RB1	P92 TO P6 & P18 (115V AC XTR BUS 2 IFE/PASS SEAT).				
I D11440		P0092				ALL
I D11442		P0092				ALL
I D11444		P0092				ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W6420

Page 1 End

Jun 21/2016





## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W6430	RB2	P92 TO EQUIPMENT COOLING SUPPLY FAN (RB2)				
I D03470		M1322				ALL
I D11802		P0092				ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W6430

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W6491	NN2	WEATHER RADAR SCOPE, CONT, R/T				
I D01411				D01407		ALL
I D01437				D11681		ALL
I D01443				D11683		ALL
I D40149P		AE0301A	POS 35	D40149J	W0313	ALL
I D40147P		AJ0022	POS 09	D40147J	W0076	ALL
I D14316		M02771	188/ /			ALL
I D14316A		M02771	188/ /			ALL
I D14316B		M02771	188/ /			ALL
I D14316C		M02771	188/ /			ALL
I D14324		M02775	188/170/R008			ALL
I D00193		P008-52	P008-00/ /			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W6490

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
<b>W6502</b>	<b>SB2</b>	<b>RIGHT A/C PACK (STA 536R) DISC TO A/C PACK (SB2)</b>				
D40846P				D40846J	W6504	YT116-YT120, YT132-YT133
D40846P		DISC BRKT		D40846J	W6504	YT101-YT115, YT126-YT131
D41600		DM0060	536/159/R026			ALL
D16250		L00184	572/155/R008			YT112-YT120, YT131-YT133
D00846		M00356	580/155/R040			ALL
D15824		M02954	624/156/R012			YT116-YT120, YT132-YT133
D00394		V00019	581/158/R015			YT101-YT115, YT126-YT131
D00492		V00019	581/158/R015			YT101-YT115, YT126-YT131
D00964		V00019	581/158/R015			YT101-YT115, YT126-YT131
D03914		V00146	557/148/R014			ALL
D15820		V00185	STA581/158/R15			YT116-YT120, YT132-YT133
D15834		V00185	STA581/158/R15			YT116-YT120, YT132-YT133
<b>W6504</b>	<b>SB2</b>	<b>RIGHT A/C PACK (STA 536R) DISC TO A/C PACK (SB2)</b>				
D40846J				D40846P	W6502	YT116-YT120, YT132-YT133
D40846J		DISC BRKT		D40846P	W6502	YT101-YT115, YT126-YT131
D00490		V00019	581/158/R015			YT101-YT115, YT126-YT131
D15836		V00185	STA581/158/R15			YT116-YT120, YT132-YT133
<b>W6506</b>	<b>SB2*</b>	<b>P8 TO E/E BAY</b>				
D07721P				D07721J	W5049	YT113-YT120, YT132-YT133
D11132		AB0250A	POS 02			ALL
D10169		AB0250A	POS 03			ALL
D40810P		AE0103A	POS 20	D40810J	W0131	ALL
D11292		AF0222A	POS 01			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W6500

Page 1

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
<b>W6506</b>	<b>SB2*</b>	<b>P8 TO E/E BAY (continued)</b>				
D46132P		AJ0046B	POS 04	D46132J	W0066	ALL
D46106P		AJ0046B	POS 10	D46106J	W0066	ALL
D48138P		AJ0048A	POS 25	D48138J	W0088	ALL
D48132P		AJ0048A	POS 26	D48132J	W0088	ALL
D40812P		AP0600B	POS 12	D40812J	W0044	ALL
D00578		P008-01	P008-00/ /			ALL
D01080		P008-01	P008-00/ /			ALL
D00580		S00010	P008-01/220/000			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W6500

Page 2 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W6510	RA2*	P8 TO E/E BAY AND J BOX				
I D11290		AF0222A	POS 02			ALL
I D10173		AF0222A	POS 06			ALL
I D40696P		AJ0024	POS 02	D40696J	W0080	ALL
I D46118P		AJ0046B	POS 09	D46118J	W0066	ALL
I D48130P		AJ0048A	POS 23	D48130J	W0088	ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W6510

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W6528	SB2	DISC AB0500DR TO E1-3, E1-4, E4-1 (SB2)				
I D40406J		AB0500DR	POS 01	D40406P	W6228	ALL
I D40410J		AB0500DR	POS 02	D40410P	W6122	ALL
I D04582P		AB0536R	POS 01	D04582J	W6202	ALL
I D43040P		AE0103A	POS 07	D43040J	W0131	ALL
I D43044P		AE0401A	POS 37	D43044J	W0410	ALL
I D46136P		AJ0046B	POS 05	D46136J	W0066	ALL
I D00848		M00272	545/160/			ALL
I D03942		S00935	521/160/R015			ALL
I D41602		STA0536R				ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W6520

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W6530	SB1	DISC AB0500DR TO E3-2 SHELF.				
I D40400J		AB0500DR	POS 03	D40400P	W6122	ALL
I D43046P		AE0302A	POS 32	D43046J	W0321	ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W6530

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W6564	SN2*	RIGHT WING BODY PRESS SEAL TO E/E BAY				
I D39910		AD0520				ALL
I D40158P		AE0401A	POS 42	D40158J	W0410	ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W6560

Page 1 End

Jun 21/2016





## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W6570	SN2	RIGHT WING BODY PRESS SEAL TO RADAR BAY				
I D39914 D48128P		AD0520 AJ0048A	POS 24	D48128J	W0088	ALL YT101-YT109, YT126-YT129
I D11306 D11354		M01827 M01827	228/182/R020 228/182/R020			ALL YT101-YT109, YT126-YT129
I W6578	SN2	TB1806 TO FQPU RADAR BAY.(FQIS DC PWR 2)				
I D11354		M01827	228/182/R020			YT110-YT120, YT130-YT133

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W6570

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W6586	RA1	RIGHT WING BODY PRESS SEAL TO E/E BAY				
I D41106J				D41106P	W5566	YT113-YT120, YT131-YT133
I D41280J				D41280P	W6590	YT113-YT120, YT131-YT133
I D41282J				D41282P	W6590	YT113-YT120, YT131-YT133
I D39906		AD0520				ALL
I D40164P		AE0402A	POS 15	D40164J	W0422	ALL
I W6588	RN1*	RIGHT WING BODY PRESS SEAL TO E/E BAY				
I D41850J		AB0500DR	POS 07	D41850P	W1126	ALL
I D41856J		AB0500DR	POS 09	D41856P	W1136	YT101-YT119
I D05342J		AB0500DR	POS 10	D05342P	W1136	YT101-YT119, YT126-YT131
I D05350J		AB0500DR	POS 11	D05350P	W1126	ALL
I D41856J		AB0500DR	POS POS 09	D41856P		YT120, YT132-YT133
I D41856J		AB0500DR	POS POS 09	D41856P	W1136	YT126-YT131
I D05342J		AB0500DR	POS POS 10	D05342P		YT120, YT132-YT133
I D39939		AD0520				ALL
I D40160P		AE0101B	POS 14	D40160J	W0111	ALL
I D40714P		AE0402A	POS 09	D40714J	W0422	ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W6580

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W6590	RN1*	RIGHT WING BODY PRESS SEAL TO E/E BAY (LTRTL)				
D41280P				D41280J	W6586	YT113-YT120, YT131-YT133
D41282P				D41282J	W6586	YT113-YT120, YT131-YT133

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W6590

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W6730	SA2	DISC AL0720D TO E1-3, E2-2				
I D43048P		AE0103A	POS 04	D43048J	W0131	ALL
I D43050P		AE0202A	POS 06	D43050J	W0220	ALL
I D46050J		AL0720D	POS 04	D46050P	W8524	ALL
I W6732	SA2*	DISC AL0675C TO E1-3, E3-2				
I D43054P		AE0302A	POS 22	D43054J	W0321	ALL
I D46046J		AL0675C	POS 01	D46046P	W8228	ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W6730

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W7022	NA2	#1 LEFT GEAR DOWN AND LOCKED SENSOR				
I D46002P		AL0694L	POS 01	D46002J	W7230	ALL
I W7024	NB2	#2 LEFT GEAR DOWN AND LOCKED SENSOR				
I D46008P		AL0711L	POS 01	D46008J	W7126	ALL
I W7026	AA2	FWD LEFT SIDE, WHEEL WELL AREA				
I D46026P		AL0675B	POS 01	D46026J	W5728	ALL
I D16236		L00172	725/194/L033			YT112-YT120, YT131-YT133
I D16238		L00173	698/200/R018			YT112-YT120, YT131-YT133
I D16240		L00174	666/182/L072			YT112-YT120, YT131-YT133
I D16242		L00175	667/182/R072			YT112-YT120, YT131-YT133
I D00920		V00043	663/ /L043			ALL
I D02874		V00125	663/200/L070			ALL
I D11734		V00154	685/200/L050			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W7020

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W7030	LE2	AB1030C DISC (STA 1038) TO LEFT ELEVATOR DISC				
I D40236P				D40236J	W6134	ALL
I D10531		V00160	1158/285/R006			ALL
I W7038	LN2	L ELEV DISC TO L ELEVPOS XMTR AND LOGO LIGHT				
I D40188J		AB1156L	POS 01	D40188P	W8030	ALL
I D11110		L818				ALL
I D03578		T467				ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W7030

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W7057	LA2	HF-1 COUPLER				
I D04227P		AB1030A	POS 03	D04227J	W3553	ALL
I D00341		M00227	/ /			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W7050

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W7061	LA2	HF-2 COUPLER				
I D04245P		AB1030A	POS 01	D04245J	W3555	ALL
I D00629		M00440				ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W7060

Page 1 End

Jun 21/2016





## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W7102	NN2	ELEVATOR PITOT HEATERS (NN2)				
I D11296		A00024	1070/387/L008			ALL
I D11302		A00027	1070/387/R008			ALL
I D04826P		AB1030C	POS 04	D04826J	W6134	ALL
I D10845		T00541	51/ /0000			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W7100

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
<b>W7122</b>	<b>LA1</b>	<b>FWD LEFT SIDE, WHEEL WELL AREA</b>				
D46010P		AL0675A	POS 04	D46010J	W5224	YT101-YT119, YT126-YT131
D02928		M1124				YT101-YT119, YT126-YT131
D00814		S00141	666/179/L053			YT101-YT119, YT126-YT131
D00760		V00032	665/180/L057			YT101-YT119, YT126-YT131
D00818		V00040	665/180/L050			YT101-YT119, YT126-YT131
D03244		V00133	666/150/L017			YT101-YT119, YT126-YT131
<b>W7126</b>	<b>RB2</b>	<b>WHEEL WELL AREA</b>				
D46006J		AL0706L	POS 01	D46006P	W7136	ALL
D46008J		AL0711L	POS 01	D46008P	W7024	ALL
D46024P		AL0720A	POS 01	D46024J	W5234	ALL
D02564		S00762	727/195/L030			ALL
D02566		S00763	727/193/L020			ALL
D02870		S00811	706/200/L025			ALL
D00924		V00007	727/190/L045			ALL
<b>W7128</b>	<b>SA2</b>	<b>AFT LEFT SIDE WHEEL WELL AREA</b>				
D46032P		AL0720B	POS 02	D46032J	W5222	YT101-YT119, YT126-YT131
D46036P		AL0720B	POS 03	D46036J	W5224	YT101-YT119, YT126-YT131
D46020P		AL0720B	POS 04	D46020J	W6124	YT101-YT119, YT126-YT131
D00854		M00273	722/151/R004			YT101-YT119, YT126-YT131
D01012		M00339	727/195/0000			YT101-YT119, YT126-YT131
D00678		S00049	715/171/00			YT101-YT119, YT126-YT131
D00824		S00143	723/163/L003			YT101-YT119, YT126-YT131
D00674		T00436	679/196/R008			YT101-YT119, YT126-YT131

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W7120

Page 1

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
<b>W7128</b>	<b>SA2</b>	<b>AFT LEFT SIDE WHEEL WELL AREA (continued)</b>				
D11995		T03019	727/187/			YT101-YT119, YT126-YT131
D00926		V00009	727/190/L045			YT101-YT119, YT126-YT131
D00822		V00042	725/169/L014			YT101-YT119, YT126-YT131
D01010		V00051	722/169/L007			YT101-YT119, YT126-YT131
D10535		V00163	701/199/L010			YT101-YT119, YT126-YT131
D00928		V11				YT101-YT119, YT126-YT131

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W7120

Page 2 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W7134	NA2	#1 LEFT GEAR ON GROUND/OUTBD ANTISKID XDCR				
I D46004P		AL0694L	POS 02	D46004J	W7230	ALL
I D11120		T392				ALL
I W7136	NB2	#2 LEFT GEAR ON GROUND/INBD ANTISKID XDCR				
I D46006P		AL0706L	POS 01	D46006J	W7126	ALL
I D11122		T394				ALL
I W7137	NA2	VOR ANTENNA LEFT - STA 1035 TO RF PWR DIV-1				
I D04435J				D04435P	W7153	ALL
I D03699		M01726	309/180/R021			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W7130

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W7150	LN1	TAIL CONE DISC. TO TAIL NAV LIGHT				
I D44584J				D44584P	W4724	ALL
I W7152	LN1	TAIL STROBE DISC. TO TAIL NAV LIGHT				
I D44582J				D44582P	W4724	ALL
I D00148		L00046	1216/284/0000			ALL
I W7153	NA2	VOR ANT LEFT - XMSN CABLE				
I D04435P				D04435J	W7137	ALL
I D00089		M00041	FIN/274/0000			ALL
I W7157	NA2	LOCALIZER ANTENNA LEFT - STA 178 TO ANTENNA				
I D03313				D02623		ALL
I D02129		M01102	178/187/			ALL
I W7159	NA2	G/S ANT LEFT - STA 178 TO ANT				
I D03309				D02621		ALL
I D00085		M00040	178/237/000			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W7150

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W7187	NA2	MARKER BEACON ANTENNA - EE BAY TO STA 610 (D4119)				
I D04119J				D04119P	W7193	ALL
I D04121J		AE0102B	POS 04	D04121P	W0121	ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W7180

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W7193	NA2	MARKER BEACON ANTENNA - STA 610 (D4119) TO ANTENNA				
I D04119P				D04119J	W7187	ALL
I D00057		M00027	610/143/0			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W7190

Page 1 End

Jun 21/2016



Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W7202	NN2	BULKHEAD PRESS SEAL TO NGS EQUIPMENT				
I D13932		DM0032	536/164/L036			ALL
I D13814		M02561	642/163/L048			ALL
I D13818		M02562	656/158/L047			ALL
I D13824		M02564	602/161/L060			ALL
I D13830		M02565	539/167/L034			ALL
I D14200		M02692	577/155/L044			ALL
I D13816		S01129	654/161/L066			ALL
I D13828		T03020	657/161/L066			ALL
I D13810		V00172	543/162/L032			ALL
I D13812		V00173	644/160/L054			ALL
I D13820		V00174	605/162/L059			ALL
I D13826		V00175	653/162/L061			ALL
I W7208	NN2	BULKHEAD PRESS SEAL TO NGS BITE DISPLAY UNIT				
I D13972		DM0044	536/166/R037			ALL
I D13808		M02560	543/157/R038			ALL

## MASTER BUNDLE LIST

D280A351

91-21-13

Section W7200

Page 1 End

Jun 21/2016





## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W7230	RA2	FWD LEFT SIDE WHEEL WELL AREA				
I D46028P		AL0675B	POS 04	D46028J	W5530	ALL
I D46002J		AL0694L	POS 01	D46002P	W7022	ALL
I D46004J		AL0694L	POS 02	D46004P	W7134	ALL
I D00662		T424				ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W7230

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W7359	SN2	AFT CAB/APU SERVICE INTERPHONE				
I D07172P				D07172J	W3144	ALL
I D40032P				D40032J	W0152	ALL
I D06017			1042/175/L042			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W7350

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W7381	LE2	AB1050L TO RUDDER POSN SENSOR, RUDDER ACTUATOR				
I D45501P		AB1050L	POS 05	D45501J	W5381	ALL
I D11613		M02445	//			ALL
I D11617		M02446	//			ALL
I W7383	RF2	AB1050R TO RUDDER POSN SENSOR, RUDDER ACTUATOR				
I D45503P		AB1050R	POS 06	D45503J	W5383	ALL
I D11615		M02445	//			ALL
I D11619		M02446	//			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W7380

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W7500	SN2	KEELBEAM OVERHEAT DETECTION				
I D00850		M00272	545/160/			ALL
I D00852		M00273	722/151/R004			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W7500

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W7522	SA2	FWD LEFT SIDE, WHEEL WELL AREA				
I D46030P		AL0675B	POS 03	D46030J	W5222	ALL
I D03052		M1173				ALL
I D03054		M1173				ALL
I D02680		S00794	666/171/L043			ALL
I D02684		S00796	666/171/L047			ALL
I D00762		V00033	673/190/L064			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W7520

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W7538	SN2	APU FIRE DETECTION AND LIGHTING				
I D40062J				D40062P	W7540	ALL
I D40060P		AB1088	POS 05	D40060J	W4724	ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W7530

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W7540	SN2	APU FIRE DETECTION				
I D40062P				D40062J	W7538	ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W7540

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W7580	SN2	WHEEL WELL DISC STS 675L TO CENTER TANK DISC M1830				
I D04850P		AL0675B	POS 02	D04850J	W5580	ALL
I D11316		M01830	666/185/L043			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W7580

Page 1 End

Jun 21/2016





## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W7592	SN2*	P8 (FIRE SW PNL) TO FIRE EXTINGUISHER BOTTLES+VALVES,SYSTEM NO 1				
I D40010P				D40010J	W7594	ALL
I D40652P				D40652J	W7596	ALL
I D40656P		AE0202A	POS 05	D40656J	W0220	ALL
I W7594	SN2*	P8(FIRE SW PNL AREA) TO FIRE EXT BOTTLE SYSTEM NO.2				
I D40008P				D40008J	W7598	ALL
I D40010J				D40010P	W7592	ALL
I D40012P		AE0202A	POS 21	D40012J	W0220	ALL
I W7596	SN2	JUMPER BUNDLE-LEFT BOTTLE				
I D40652J				D40652P	W7592	ALL
I D00586		M00194	727/190/L070			ALL
I D01322		M01142	713/ /			ALL
I D00582		M01143	713/ /			ALL
I W7598	SN2	JUMPER BUNDLE-RIGHT BOTTLE				
I D40008J				D40008P	W7594	ALL
I D00588		M00195	727/190/L070			ALL
I D00584		M01144	713/ /			ALL
I D01324		M01145	713/ /			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W7590

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W7761	NA2	HF-1 COUPLER ANT FEED				
I D04217P		AB1030A	POS 04	D04217J	W3557	ALL
I D00337		M00227	/ /			ALL
I W7763	NA2	HF-1 COUPLER ANT FEED				
I D04713P		AB1030A	POS 02	D04713J	W3559	ALL
I D00625		M00440				ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W7760

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W8022	NA2	#1 RIGHT GEAR DOWN AND LOCKED SENSOR				
I D46012P		AL0694R	POS 01	D46012J	W8228	ALL
I W8024	NB2	#2 RIGHT GEAR DOWN AND LOCKED SENSOR				
I D46018P		AL0711R	POS 01	D46018J	W8224	ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W8020

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W8030	LE2*	AB1030C DISC (STA 1038) TO RIGHT AND LEFT ELEV DISC (W/O FLAT BLKHD)				
I D40192P		AB1030C	POS 01	D40192J	W6134	ALL
I D40188P		AB1156L	POS 01	D40188J	W7038	ALL
I D40190P		AB1156R	POS 01	D40190J	W8038	ALL
I D01249		M1192				ALL
I D10529		V00159	1158/285/R006			ALL
I W8038	RN2	R ELEV DISC TO R ELEV POS XMTR AND R LOGO LIGHT				
I D40190J		AB1156R	POS 01	D40190P	W8030	ALL
I D11108		L819				ALL
I D03580		T468				ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W8030

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W8122	LA2	FWD RIGHT SIDE WHEEL WELL AREA				
I D46038P		AL0675C	POS 03	D46038J	W6124	ALL
I D00816		S00142	666/179/R053			ALL
I D03242		S00855	667/179/R031			ALL
I D11728		S01050	596/194/R067			ALL
I D00758		V00031	665/180/R050			ALL
I D00820		V00041	665/180/R057			ALL
I D02860		V00123	674/159/L001			ALL
I D10533		V00162	632/162/R060			ALL
I W8124	LA2	AFT RIGHT SIDE WHEEL WELL AREA -FLAP POS IND- SHORT FIELD PERFORMANCE				
I D46040P		AL0720D	POS 01	D46040J	W6124	ALL
I D14730		S00138	635/201/R051			ALL
I D14360		S01051	634/195/R052			ALL
I D01014		V00052	723/200/R021			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W8120

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W8137	NB2	VOR ANTENNA RIGHT - STA 1035 TO RF PWR DIV-2				
I D04437J		AB1030B	POS 03	D04437P	W8153	ALL
I D03783		M01727	302/180/R020			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W8130

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W8153	NB2	VOR ANT RIGHT-XMSN CABLE				
I D04437P		AB1030B	POS 03	D04437J	W8137	ALL
I D00091		M00041	FIN/274/0000			ALL
I W8157	NB2	GLIDE SLOPE ANT RIGHT - STA 178 TO ANT				
I D03315				D02627		ALL
I D02131		M01102	178/187/			ALL
I W8159	NB2	G/S ANT RIGHT-STA 178 TO ANT				
I D03311				D02625		ALL
I D00087		M00040	178/237/000			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W8150

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W8222	SB2	FWD RIGHT SIDE WHEEL WELL AREA				
I D46042P		AL0675C	POS 02	D46042J	W6122	ALL
I D02682		S00795	666/181/R022			ALL
I D02686		S00797	666/181/R027			ALL
I D00660		T00423	666/181/R014			ALL
I D00764		V00034	680/190/R064			ALL
I W8224	SB2	AFT RIGHT SIDE WHEEL WELL AREA				
I D46016J		AL0706R	POS 01	D46016P	W8236	ALL
I D46018J		AL0711R	POS 01	D46018P	W8024	ALL
I D40004P		AL0720C	POS 02	D40004J	W6122	ALL
I D02674		T00184	678/194/R043			ALL
I W8226	LN2	AFT RIGHT SIDE, WHEEL WELL				
I D46044P		AL0720C	POS 03	D46044J	W6124	ALL
I D40006P		AL0720C	POS 04	D40006J	W6124	ALL
I D14362		S00245	714/195/R057			ALL
I D01582		V00094	720/198/R056			ALL
I W8228	SA2	FWD LEFT SIDE WHEEL WELL AREA				
I D46046P		AL0675C	POS 01	D46046J	W6732	ALL
I D46012J		AL0694R	POS 01	D46012P	W8022	ALL
I D46014J		AL0694R	POS 02	D46014P	W8234	ALL
I D03056		M01174	//			ALL
I D03058		M01174	//			ALL
I D13938		S01131	675/194/R068			ALL
I D11730		S1049				ALL
I D02872		V00124	665/190/R070			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W8220

Page 1 End

Jun 21/2016





## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W8230	NB2	AFT LEFT SIDE WHEEL WELL AREA				
I D46048P		AL0720D	POS 03	D46048J	W6228	ALL
I D00930		V00008	727/180/R040			ALL
I D02570		V00122	711/200/			ALL
I D02572		V00122	711/200/			ALL
I D02574		V00122	711/200/			ALL
I D02576		V00122	711/200/			ALL
I W8234	NA2	#1 RIGHT GEAR ON GROUND/OUTBD ANTISKID XDCR				
I D46014P		AL0694R	POS 02	D46014J	W8228	ALL
I D11126		T395				ALL
I W8236	NB2	#2 RIGHT GEAR ON GROUND/INBD ANTISKID XDCR				
I D46016P		AL0706R	POS 01	D46016J	W8224	ALL
I D11124		T393				ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W8230

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W8489	NN2	WEATHER RADAR ANTENNA HONEYWELL				
I D01409				D01407		ALL
I D01433				D11681		ALL
I D01441				D11683		ALL
I D14320		M02773	178/200/R005			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W8480

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W8524	SA2	AFT RIGHT SIDE WHEEL WELL AREA				
I D46050P		AL0720D	POS 04	D46050J	W6730	ALL
I D48080P		AP2800A	POS 01	D48080J		ALL
I D02676		T00185	725/166/R028			ALL
I D00932		V00010	727/180/R040			ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W8520

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bundle Equip	Sep	Description Matewith	Location	MW Connector	MW Bundle	Effectivity
I W8538	RB1	STANDBY HYD PUMP				
I D00812		M00242	727+18/150/R027			ALL
I D11740		P0092				ALL

### MASTER BUNDLE LIST

D280A351

**91-21-13**

Section W8530

Page 1 End

Jun 21/2016