

**91-04-00**

**DISCONNECT BRACKET  
LIST**



91-04-00  
DISCONNECT BRACKET LIST

Section	Page	Date	Section	Page	Date	Section	Page	Date
EFFECTIVE PAGES			R AE0400	1	Jun 21/2016			
	1	Jun 21/2016	R	2	Jun 21/2016			
	2	BLANK	R	3	Jun 21/2016			
R AA0300	1	Jun 21/2016	R AE0500	1	Jun 21/2016			
R AA0500	1	Jun 21/2016	R	2	Jun 21/2016			
R AB0200	1	Jun 21/2016	R AE0600	1	Jun 21/2016			
R AB0300	1	Jun 21/2016	R AE0800	1	Jun 21/2016			
R	2	Jun 21/2016	R AE1100	1	Jun 21/2016			
R AB0400	1	Jun 21/2016	R AF0200	1	Jun 21/2016			
R AB0500	1	Jun 21/2016	R AJ0000	1	Jun 21/2016			
R AB0700	1	Jun 21/2016	R	2	Jun 21/2016			
R AB0800	1	Jun 21/2016	R	3	Jun 21/2016			
R AB1000	1	Jun 21/2016	R AL0600	1	Jun 21/2016			
R	2	Jun 21/2016	R AL0700	1	Jun 21/2016			
R AB1100	1	Jun 21/2016	R AP0600	1	Jun 21/2016			
R AC0200	1	Jun 21/2016	R	2	Jun 21/2016			
R AC0500	1	Jun 21/2016	R AP0700	1	Jun 21/2016			
R AD0500	1	Jun 21/2016	R AP0900	1	Jun 21/2016			
R AE0100	1	Jun 21/2016	R AP1800	1	Jun 21/2016			
R	2	Jun 21/2016	R AP2800	1	Jun 21/2016			
R	3	Jun 21/2016	R AS0000	1	Jun 21/2016			
R	4	Jun 21/2016	R	2	Jun 21/2016			
R AE0200	1	Jun 21/2016	R AW0200	1	Jun 21/2016			
R	2	Jun 21/2016	R AW0700	1	Jun 21/2016			
R AE0300	1	Jun 21/2016		2	BLANK			
R	2	Jun 21/2016						
R	3	Jun 21/2016						
R	4	Jun 21/2016						

A = Added, R = Revised, D = Deleted, O = Overflow

## DISCONNECT BRACKET LIST

D280A351

## EFFECTIVE PAGES

Page 1  
Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bracket No.	Description Position	Receptacle	Bundle	Plug	Bundle	Max Pos	Station / WL / BL	Effectivity
I AA0375R	DISCONNECT BRACKET - GALLEY G2					000	375/ /R	ALL
	01	D45011J	W3587	D45011P	W3477			YT101-YT120
	02	D45431J	W3587	D45431P	W3477			YT101-YT120
	03	D45447J	W3587	D45447P	W3477			YT101-YT120

### DISCONNECT BRACKET LIST

D280A351

**91-04-00**

Section AA0300

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bracket No.	Description Position	Receptacle	Bundle	Plug	Bundle	Max Pos	Station / WL / BL	Effectivity
I AA0569L	MID WAP ANTENNAS DISCONNECT					000	569/301/L020	ALL
	01	D13589	W3767					YT101-YT120
I	01	D16068	W3767					YT126-YT133
	02	D13591	W3767					YT101-YT120
I	02	D16070	W3767					YT126-YT133
	03	D13593	W3767					YT101-YT120
I	03	D16072	W3767					YT126-YT133
I AA0589L	MID WAP ANTENNAS DISCONNECT					000	590/301/L020	ALL
	01	D13587	W3759					YT101-YT120
I	01	D16066	W3759					YT126-YT133

### DISCONNECT BRACKET LIST

D280A351

**91-04-00**

Section AA0500

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bracket No.	Description Position	Receptacle	Bundle	Plug	Bundle	Max Pos	Station / WL / BL	Effectivity
I AB0237A	DISCONNECT BRACKET					003	237/201/L004	ALL
I	01	D11160	W5162					ALL
I	02	D11158	W5172					ALL
I	03	D00803	W2705					ALL
I	03			D02803	W2889			ALL
I AB0237B	DISCONNECT BRACKET					003	241/203/L005	ALL
I	01	D11164	W6162					ALL
I	02	D11162	W6172					ALL
I AB0250A	DISCONNECT BRACKET-					006	250/195/L002	ALL
I	01	D11134	W5160					ALL
I	02	D11132	W6506					ALL
I	03	D10169	W6506					ALL
I	04	D11130	W5506					ALL
I	05	D11128	W5510					ALL
I	06	D10167	W5506					ALL
I AB0288	DISCONNECT BRACKET					005	288/289/0	ALL
I	01	D00570	W4256					ALL
I	02	D01128	W6242					ALL
I	03	D04889P	W2589	D04889J	W3419			ALL
I	03	D04889J	W3419	D04889P	W2589			ALL
I	04	D37001J	W3701	D37001P	W3801			ALL

### DISCONNECT BRACKET LIST

D280A351

**91-04-00**

Section AB0200

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bracket No.	Description Position	Receptacle	Bundle	Plug	Bundle	Max Pos	Station / WL / BL	Effectivity
I AB0340A	DISCONNECT BRACKET-LEFT					009	340/295/L006	ALL
I	01	D40054J	W3058	D40054P	W5142			YT101-YT131
I	01			D40054P	W5142			YT132-YT133
I	02	D40216J	W3158	D40216P	W3144			ALL
I	03	D40196J	W3142	D40196P	W2114			ALL
I	04	D40170J	W3058	D40170P	W2218			YT101-YT131
I	04			D40170P	W2218			YT132-YT133
I	05	D40050J	W3058	D40050P	W6242			YT101-YT131
I	05			D40050P	W6242			YT132-YT133
I	06	D40108J	W3158	D40108P	W3150			ALL
I	09	D40102J	W3158	D40102P	W5142			ALL
I AB0340B	DISCONNECT BRACKET-RIGHT					009	340/295/R006	ALL
I	01	D40096J	W4142	D40096P	W3142			ALL
I	03	D41838J	W6288	D41838P	W2114			ALL
I	04	D40084J	W4258	D40084P	W4250			ALL
I	06	D40292J	W4142	D40292P	W5160			ALL
I	07	D40296J	W4142	D40296P	W2114			ALL
I	09	D40202J	W4258	D40202P	W6242			ALL
I AB0358	DISCONNECT BRACKET					009	358/296/L003	ALL
I	01	D40353J	W3702	D40353P	W3805			ALL
I	02	D40351J	W3701	D40351P	W3805			ALL
I	05	D37002J	W3702	D37002P	W3802			ALL
I	06	D40355J	W3703	D40355P	W3805			ALL
I	07	D40357J	W3709	D40357P	W3805			ALL
I	08	D40365J	W3710	D40365P	W3805			ALL
I	09	D40349J	W3144	D40349P	W3805			ALL
I AB0366	DISCONNECT BRACKET					000	360/290/L032	YT126-YT133
I	01	D12897J	W3477					YT126-YT133
I	02	D45449J	W3477					YT126-YT133
I	03	D40011J	W3477					YT126-YT133
I AB0369L	DISCONNECT BRACKET					000	369/280/L047	ALL
I	04	D13493J	W3745					YT101-YT120
I AB0372	DISCONNECT BRACKET-TEST RECEPTACLES					003	372/184/R050	ALL

### DISCONNECT BRACKET LIST

D280A351

91-04-00

Section AB0300

Page 1

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bracket No.	Description Position	Receptacle	Bundle	Plug	Bundle	Max Pos	Station / WL / BL	Effectivity
I AB0373	DISCONNECT BRACKET					003	373/296/L013	ALL
I	01	D12899J	W3477	D12899P	W3649			ALL
I	02	D12887J	W3477	D12887P	W3639			ALL
I	03	D45487J	W3755	D45487P	W3639			YT101-YT102, YT126-YT133
	03			D45487P	W3639			YT103-YT120
	04	D45485P	W3639	D45485J	W3477			YT101-YT104
I	04	D45485J	W3477	D45485P	W3639			ALL
I	04	D45485P	W3639					YT105-YT133
	05	D12883J	W3477	D12883P	W3695			YT101-YT120
I	05	D12883J	W3477	D12883P	W3639			YT126-YT133
I	06	D12885J	W3477	D12885P	W3639			ALL
	07	D12889J	W3477	D12889P	W3695			YT101-YT120
I	07	D12889J	W3477					YT126-YT133
	08	D12891J	W3477	D12891P	W3639			YT101-YT120
I	08	D12891J	W3477					YT126-YT133
	09	D12893J	W3477	D12893P	W3755			YT101-YT102
I	09	D12893J	W3477					YT103-YT133
I	10	D12895J	W3477	D12895P	W3649			ALL
I AB0376R	DISCONNECT BRACKET					000	376/280/R047	ALL
	04	D13481J	W3739					YT101-YT120
I AB0387	DISCONNECT BRACKET-UPR TCAS ANT					004	387/298/R010	ALL
I	01	D04625J	W4009	D04625P	W4001			ALL
I	02	D04627J	W4009	D04627P	W4001			ALL
I	03	D04629J	W4009	D04629P	W4001			ALL
I	04	D04633J	W4009	D04633P	W4001			ALL

### DISCONNECT BRACKET LIST

D280A351

**91-04-00**

Section AB0300

Page 2 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bracket No.	Description Position	Receptacle	Bundle	Plug	Bundle	Max Pos	Station / WL / BL	Effectivity
I AB0405B	DISCONNECT BRACKET					002	410/288/R040	ALL
I	01	D40728J	W6170	D40728P	W4170			ALL
I	02	D40730J	W6172	D40730P	W4170			ALL
I AB0420A	DISCONNECT BRACKET					002	424/293/L033	ALL
I	01	D40734J	W5170	D40734P	W3170			ALL
I	02	D40736J	W5172	D40736P	W3170			ALL
I AB0450R	DISCONNECT BRACKET					000	450/295/R030	ALL
	01	D45465J	W3450	D45465P	W3623			YT101-YT120
	02	D45411J	W3479	D45411P	W3623			YT101-YT120
	04	D45403J	W3477	D45403P	W3623			YT101-YT120
	05	D45463J	W3477	D45463P	W3623			YT101-YT120

### DISCONNECT BRACKET LIST

D280A351

**91-04-00**

Section AB0400

Page 1 End

Jun 21/2016





## 737-800 WIRING DIAGRAM MANUAL

Bracket No.	Description Position	Receptacle	Bundle	Plug	Bundle	Max Pos	Station / WL / BL	Effectivity
I AB0500DL	DISCONNECT BRACKET-LEFT WING					010	500I/201/L040	ALL
I	01	D41854J	W5568	D41854P	W1128			ALL
I	02	D05348J	W5568	D05348P	W1128			ALL
I	03	D05346J	W5568	D05346P	W1134			YT101-YT119, YT126-YT131
I	03	D05346J	W5568					YT120, YT132-YT133
I	04	D40318J	W5530	D40318P	W5222			ALL
I	05	D40500J	W5248	D40500P	W6248			ALL
I	06	D46608J	W5088	D46608P	W5074			ALL
I	07	D40312J	W5134	D40312P	W5224			ALL
I	09	D40302J	W5526	D40302P	W5222			ALL
I	10	D41852J	W5568	D41852P	W1134			YT101-YT119, YT126-YT131
I	10	D41852J	W5568					YT120, YT132-YT133
I	12	D46606J	W5094	D46606P	W5098			ALL
I AB0500DR	DISCONNECT BRACKET-RIGHT WING					010	500I/201/R061	ALL
I	01	D40406J	W6528	D40406P	W6228			ALL
I	02	D40410J	W6528	D40410P	W6122			ALL
I	03	D40400J	W6530	D40400P	W6122			ALL
I	05	D40404J	W6034	D40404P	W6124			ALL
I	06	D40402J	W6032	D40402P	W6124			ALL
I	07	D41850J	W6588	D41850P	W1126			ALL
I	08	D40416J	W6032	D40416P	W5224			ALL
I	09	D41856J	W6588	D41856P	W1136			YT101-YT119, YT126-YT131
I	09	D41856J	W6588					YT120, YT132-YT133
I	10	D05342J	W6588	D05342P	W1136			YT101-YT119, YT126-YT131
I	10	D05342J	W6588					YT120, YT132-YT133
I	11	D05350J	W6588	D05350P	W1126			ALL
I AB0501DL	DISCONNECT BRACKET-LEFT WING					006	500D+7/180/L058	ALL
I AB0501DR	DISCONNECT BRACKET-RIGHT WING					006	500D+7/180/R058	ALL
I AB0536L	DISCONNECT BRACKET-LEFT AC BAY					002	541/159/L025	ALL
I	01	D04580J	W5102	D04580P	W5526			ALL
I	02	D40056J	W5102	D40056P	W5104			ALL
I AB0536R	DISCONNECT BRACKET-RIGHT AC BAY					002	541/159/R025	ALL
I	01	D04582J	W6202	D04582P	W6528			ALL
I	02	D40058J	W6202	D40058P	W6230			ALL

### DISCONNECT BRACKET LIST

D280A351

**91-04-00**

Section AB0500

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bracket No.	Description Position	Receptacle	Bundle	Plug	Bundle	Max Pos	Station / WL / BL	Effectivity
I AB0727L	DISCONNECT BRACKET-AFT CARGO COMPT					002	727/193/L038	ALL
I	01	D42104J	W5032	D42104P	W1022			YT101-YT119, YT126-YT131
I	01	D42104J	W5032					YT120, YT132-YT133
I AB0727R	DISCONNECT BRACKET-AFT CARGO COMPT					002	727/193/R045	ALL
I	01	D43104J	W6028	D43104P	W1032			YT101-YT119, YT126-YT131
I	01	D43104J	W6028					YT120, YT132-YT133
I	02	D46602J	W5124	D46602P	W6124			ALL

### DISCONNECT BRACKET LIST

D280A351

**91-04-00**

Section AB0700

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bracket No.	Description Position	Receptacle	Bundle	Plug	Bundle	Max Pos	Station / WL / BL	Effectivity
I AB0857L	DISCONNECT BRACKET					000	857/301/L014	ALL
	01	D40297J	W6212	D40297P	W3625			YT101-YT120
	01	D40297P	W3625	D40297J	W6212			YT101-YT120
	02	D45415J	W3483	D45415P	W3625			YT101-YT120
	03	D45417J	W3483	D45417P	W3625			YT101-YT120
	05	D40335J	W3477	D40335P	W3625			YT101-YT120

### DISCONNECT BRACKET LIST

D280A351

**91-04-00**

Section AB0800

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bracket No.	Description Position	Receptacle	Bundle	Plug	Bundle	Max Pos	Station / WL / BL	Effectivity
AB1030A	DISCONNECT BRACKET-AFT PRESSURE BLKHD.					004	1030/301/R012	ALL
	01	D04245J	W3555	D04245P	W7061			ALL
	02	D04713J	W3559	D04713P	W7763			ALL
	03	D04227J	W3553	D04227P	W7057			ALL
	04	D04217J	W3557	D04217P	W7761			ALL
AB1030B	DISCONNECT BRACKET-AFT PRESSURE BLKHD.					004	1030/301/0000	ALL
	03	D04437J	W8137					ALL
AB1030C	DISCONNECT BRACKET-AFT PRESSURE BLKHD.					004	1030/301/L011	ALL
	01	D40192J	W6134	D40192P	W8030			ALL
	04	D04826J	W6134					ALL
AB1042L	DISCONNECT BRACKET -SEC 48 R					000	1042/297/L008	ALL
AB1050L	DISCONNECT BRACKET-SEC 48 L					005	1050/296/L015	ALL
	01	D40842J	W4134	D40842P	W6134			ALL
	02	D43393J	W3393	D43393P	W5301			ALL
	03	D43397J	W3397	D43397P	W3377			ALL
	04	D44381J	W3391	D44381P	W3381			ALL
	05	D45501J	W5381	D45501P	W7381			ALL
AB1050R	DISCONNECT BRACKET-SEC 48 R					006	1050/297/R008	ALL
	01	D40790J	W4726	D40790P	W5726			ALL
	02	D40876J	W4726	D40876P	W5726			ALL
	03	D40854J	W4724	D40854P	W5726			ALL
	04	D43399J	W3399	D43399P	W3379			ALL
	05	D40836J	W4222	D40836P	W6222			ALL
	06	D45503J	W5383	D45503P	W7383			ALL
AB1080	DISCONNECT BRACKET-STA 1080					003	1080/299/0	ALL
	01	D40268J	W4134	D40268P	W6136			ALL
	02	D43387J	W3397	D43387P	W3387			ALL
	03	D43389J	W3399	D43389P	W3389			ALL
AB1088	DISCONNECT BRACKET-STA 1088					001	1088/ /	ALL
		D10434	W4724					ALL
		D10436	W4724					ALL
		D10912	W4726					ALL
		D11118	W4726					ALL

### DISCONNECT BRACKET LIST

D280A351

91-04-00

Section AB1000

Page 1

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bracket No.	Description Position	Receptacle	Bundle	Plug	Bundle	Max Pos	Station / WL / BL	Effectivity
AB1088	DISCONNECT BRACKET-ST A 1088 (continued)					001	1088/ /	ALL
	05	D40060J	W4724	D40060P	W7538			ALL

### DISCONNECT BRACKET LIST

D280A351

**91-04-00**

Section AB1000

Page 2 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bracket No.	Description Position	Receptacle	Bundle	Plug	Bundle	Max Pos	Station / WL / BL	Effectivity
I AB1156L	DISCONNECT BRACKET-SEC 48 L					001	1156/ /	ALL
I	01	D40188J	W7038	D40188P	W8030			ALL
I AB1156R	DISCONNECT BRACKET SEC 48 R					001	1156/ /	ALL
I	01	D40190J	W8038	D40190P	W8030			ALL

### DISCONNECT BRACKET LIST

D280A351

**91-04-00**

Section AB1100

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bracket No.	Description Position	Receptacle	Bundle	Plug	Bundle	Max Pos	Station / WL / BL	Effectivity
I AC0235A	DISCONNECT BRACKET - EFB CLASS 2					000	235/179/L032	ALL
	01	D31016J	W2201					YT101-YT120
	02	D31018J	W2104					YT101-YT120
	05	D31022J	W5121					YT101-YT120
	06	D31020J	W6208					YT101-YT120

### DISCONNECT BRACKET LIST

D280A351

**91-04-00**

Section AC0200

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bracket No.	Description Position	Receptacle	Bundle	Plug	Bundle	Max Pos	Station / WL / BL	Effectivity
AC0520	DISCONNECT BRACKET					021	500I+15/180/L059	ALL
				D39901	W5166			ALL
				D39903	W1188			ALL
				D39905	W5566			ALL
				D39907	W1662			ALL
				D39909	W5564			ALL
				D39911	W1184			ALL
				D39913	W5562			ALL
				D39915	W1140			ALL
				D39917	W5172			ALL
				D39919	W1174			ALL
				D39921	W5162			ALL
				D39923	W1176			ALL
				D39925	W5170			ALL
				D39927	W1178			ALL
				D39929	W5168			ALL
				D39931	W1182			ALL
				D39933	W5164			ALL
				D39937	W5568			ALL
				D39938	W1180			ALL
AC0538	DISCONNECT BRACKET					000	537/199/R055	ALL

### DISCONNECT BRACKET LIST

D280A351

**91-04-00**

Section AC0500

Page 1 End

Jun 21/2016





## 737-800 WIRING DIAGRAM MANUAL

Bracket No.	Description Position	Receptacle	Bundle	Plug	Bundle	Max Pos	Station / WL / BL	Effectivity
AD0520	DISCONNECT BRACKET					022	500D+10/194/R067	ALL
				D39902	W6166			ALL
				D39904	W1288			ALL
				D39906	W6586			ALL
				D39908	W1664			ALL
				D39910	W6564			ALL
				D39912	W1284			ALL
				D39914	W6570			ALL
				D39916	W1138			ALL
				D39918	W6172			ALL
				D39920	W1274			ALL
				D39922	W6162			ALL
				D39924	W1276			ALL
				D39926	W6170			ALL
				D39928	W1278			ALL
				D39930	W6168			ALL
				D39932	W1282			ALL
				D39934	W6164			ALL
				D39936	W1284			ALL
				D39939	W6588			ALL
				D39940	W1280			ALL

### DISCONNECT BRACKET LIST

D280A351

**91-04-00**

Section AD0500

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bracket No.	Description Position	Receptacle	Bundle	Plug	Bundle	Max Pos	Station / WL / BL	Effectivity
AE0101A	DISCONNECT BRACKET - E1-1 SHELF					036	310/178/L022	ALL
	01	D40458J	W0111	D40458P	W5156			ALL
	02	D40454J	W0111	D40454P	W5156			ALL
	03	D45133J	W0111	D45133P	W5111			ALL
	04	D41145J	W0111	D41145P	W5161			ALL
	05	D40452J	W0111	D40452P	W5156			ALL
	06	D42311J	W0111	D42311P	W5461			ALL
	07	D41159J	W0111	D41159P	W5353			ALL
	08	D04425J	W0111	D04425P	W5301			ALL
	09	D40133J	W0111	D40133P	W2221			ALL
	11	D41153J	W0111	D41153P	W5111			ALL
	12	D40364J	W0111	D40364P	W6110			ALL
	13	D41811J	W0111	D41811P	W2101			ALL
	14	D40120J	W0111	D40120P	W5568			ALL
	15	D40162J	W0111	D40162P	W5032			ALL
	16	D40180J	W0111	D40180P	W6028			ALL
	17	D41121J	W0111	D41121P	W5721			ALL
	18	D40122J	W0111	D40122P	W5166			ALL
	19	D45113J	W0111	D45113P	W5111			ALL
	20	D41155J	W0111	D41155P	W5161			ALL
	21	D43211J	W0111	D43211P	W5461			ALL
	22	D46461J	W0111	D46461P	W5461			ALL
	23	D04075J	W0111	D04075P	W5369			ALL
	24	D41821J	W0111	D41821P	W2175			ALL
	25	D41125J	W0111	D41125P	W5719			ALL
	26	D04083J	W0111	D04083P	W3381			ALL
	27	D04073J	W0111	D04073P	W5367			ALL
	28	D40510J	W0111	D40510P	W2218			ALL
	29	D04069J	W0111	D04069P	W2363			ALL
	30	D40019J	W0111	D40019P	W2221			ALL
	31	D45203J	W0111	D45203P	W5205			ALL
	32	D04079J	W0111	D04079P	W3377			ALL
	33	D40774J	W0111	D40774P	W6214			ALL
	34	D41023J	W0111	D41023P	W2031			YT104-YT133
	35	D45515J	W0111	D45515P	W5463			ALL
	36	D45551J	W0111	D45551P	W5381			ALL
AE0101B	DISCONNECT BRACKET - E1-1 SHELF					023	310/178/R017	ALL
	01	D41563J	W0111	D41563P	W5463			ALL
	02	D40464J	W0111	D40464P	W5160			ALL
	03	D41161J	W0111	D41161P	W5397			ALL

### DISCONNECT BRACKET LIST

D280A351

**91-04-00**

Section AE0100

Page 1

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bracket No.	Description Position	Receptacle	Bundle	Plug	Bundle	Max Pos	Station / WL / BL	Effectivity
AE0101B	DISCONNECT BRACKET - E1-1 SHELF (continued)					023	310/178/R017	ALL
	04	D40142J	W0111	D40142P	W6166			ALL
	05	D40063J	W0111	D40063P	W5723			ALL
	06	D40948J	W0111	D40948P	W6166			ALL
	07	D40818J	W0111	D40818P	W6208			ALL
	08	D41163J	W0111	D41163P	W5463			ALL
	09	D46023J	W0111	D46023P	W2383			ALL
	10	D43317J	W0111	D43317P	W5723			ALL
	11	D41147J	W0111	D41147P	W5163			ALL
	12	D41157J	W0111	D41157P	W5163			ALL
	13	D46013J	W0111	D46013P	W2103			ALL
	14	D40160J	W0111	D40160P	W6588			ALL
	15	D04611J	W0111	D04611P	W4001			ALL
	16	D04609J	W0111	D04609P	W4001			ALL
	17	D04615J	W0111	D04615P	W4001			ALL
	18	D04613J	W0111	D04613P	W4001			ALL
	19	D04619J	W0111	D04619P	W5001			ALL
	20	D04617J	W0111	D04617P	W5001			ALL
	21	D04623J	W0111	D04623P	W5001			ALL
	22	D04621J	W0111	D04621P	W5001			ALL
	23	D40064J	W0111	D40064P	W2218			ALL
	24	D41021J	W0111	D41021P	W6208			YT101-YT120
AE0102A	DISCONNECT BRACKET - E1-2 SHELF					015	312/169/R023	ALL
	01	D41211J	W5719	D41211P	W0121			ALL
	02	D45115J	W5111	D45115P	W0121			ALL
	03	D04029J	W2149	D04029P	W0121			ALL
	04	D41217J	W2177	D41217P	W0121			ALL
	05	D04205J	W2205	D04205P	W0121			ALL
	06	D41827J	W2651	D41827P	W0121			ALL
	08	D04269J	W5189	D04269P	W0121			ALL
	10	D45201J	W5205	D45201P	W0121			ALL
	11	D45002J	W5121	D45002P	W0121			ALL
	12	D41213J	W5723	D41213P	W0121			ALL
	13	D41127J	W5721	D41127P	W0121			ALL
AE0102B	DISCONNECT BRACKET - E1-2 SHELF					008	304/178/R036	ALL
	01	D04607J	W5039	D04607P	W0121			ALL
	02	D41215J	W5183	D41215P	W0121			ALL
	03	D42943J	W3609	D42943P	W0141			ALL
	04	D04121J	W7187	D04121P	W0121			ALL

### DISCONNECT BRACKET LIST

D280A351

91-04-00

Section AE0100

Page 2

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bracket No.	Description Position	Receptacle	Bundle	Plug	Bundle	Max Pos	Station / WL / BL	Effectivity
AE0102B	<b>DISCONNECT BRACKET - E1-2 SHELF (continued)</b>					008	304/178/R036	ALL
	05	D04603J	W5363	D04603P	W0121			ALL
	06	D04027J	W3143	D04027P	W0141			ALL
	07	D04025J	W3141	D04025P	W0121			ALL
	08	D42941J	W3607	D42941P	W0121			ALL
AE0103A	<b>DISCONNECT BRACKET - E1-3 SHELF</b>					022	312/170/L025	ALL
	02	D04133J	W0131	D04133P	W5413			ALL
	03	D46051J	W0131	D46051P	W2661			ALL
	04	D43048J	W0131	D43048P	W6730			ALL
	06	D41400J	W0131	D41400P	W2022			ALL
	07	D43040J	W0131	D43040P	W6528			ALL
	08	D40488J	W0131	D40488P	W5158			ALL
	09	D41337J	W0131	D41337P	W3307			ALL
	10	D40344J	W0131	D40344P	W5610			ALL
	11	D40498J	W0131	D40498P	W5156			ALL
	12	D04123J	W0131	D04123P	W5107			ALL
	13	D04149J	W0131	D04149P	W2307			ALL
	14	D40466J	W0131	D40466P	W5160			ALL
	15	D43010J	W0131	D43010P	W5234			ALL
	16	D45227J	W0131	D45227P	W3477			ALL
	17	D41831J	W0131	D41831P	W2651			ALL
	18	D04195J	W0131	D04195P	W5189			ALL
	19	D41509J	W0131	D41509P	W5719			ALL
	20	D40810J	W0131	D40810P	W6506			ALL
	21	D04181J	W0131	D04181P	W3311			ALL
	22	D41131J	W0131	D41131P	W5723			ALL
AE0104A	<b>DISCONNECT BRACKET - E1-4 SHELF</b>					030	312/160/R023	ALL
	01	D08019J	W2465	D08019P	W0141			ALL
	02	D05971J	W5457	D05971P	W0141			ALL
	03	D04081P	W0141	D04081J	W3379			ALL
	03	D04081J	W3379	D04081P	W0141			ALL
	05	D45143J	W5121	D45143P	W0141			ALL
	06	D04311J	W2251	D04311P	W0141			ALL
	07	D40049J	W2205	D40049P	W0141			ALL
	08	D40047J	W5723	D40047P	W0141			ALL
	09	D46011J	W2103	D46011P	W0141			ALL
	10	D46031J	W2383	D46031P	W0141			ALL
	11	D41463J	W5463	D41463P	W0141			ALL
	12	D45123J	W5121	D45123P	W0141			ALL

### DISCONNECT BRACKET LIST

D280A351

**91-04-00**

Section AE0100

Page 3

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bracket No.	Description Position	Receptacle	Bundle	Plug	Bundle	Max Pos	Station / WL / BL	Effectivity
AE0104A	<b>DISCONNECT BRACKET - E1-4 SHELF (continued)</b>					030	312/160/R023	ALL
	13	D45553J	W5383	D45553P	W0141			ALL
	14	D40560J	W2510	D40560P	W0141			ALL
	15	D04077J	W5375	D04077P	W0141			ALL
	17	D04273J	W5191	D04273P	W0141			ALL
	18	D41129J	W5721	D41129P	W0141			ALL
	19	D40806J	W5506	D40806P	W0141			ALL
	20	D40490J	W5158	D40490P	W0141			ALL
	21	D40496J	W5510	D40496P	W0141			ALL
	22	D43016J	W5526	D43016P	W0141			ALL
	23	D40556J	W2508	D40556P	W0141			ALL
	26	D40332J	W5204	D40332P	W0141			ALL
	27	D40826J	W5514	D40826P	W0141			ALL
	28	D40346J	W5610	D40346P	W0141			ALL
AE0104B	<b>DISCONNECT BRACKET - E1-4 SHELF</b>					003	320/170/R030	ALL
	01	D41251J	W0521	D41251P	W0121			ALL
	02	D45517J	W5463	D45517P	W0141			ALL
	03	D41453J	W0523	D41453P	W0141			ALL
AE0105A	<b>DISCONNECT BRACKET - E1-5 SHELF</b>					013	312/160/R025	ALL
	01	D04125J	W5107	D04125P	W0151			ALL
	02	D04031J	W2151	D04031P	W0151			ALL
	03	D41507J	W5723	D41507P	W0151			ALL
	04	D04197J	W5191	D04197P	W0151			ALL
	07	D41557J	W5163	D41557P	W0151			ALL
	08	D41517J	W2247	D41517P	W0151			ALL
	09	D45125J	W5121	D45125P	W0151			ALL
	11	D41511J	W5099	D41511P	W0151			ALL
	12	D41515J	W5185	D41515P	W0151			ALL
	13	D04131J	W5411	D04131P	W0151			ALL

### DISCONNECT BRACKET LIST

D280A351

**91-04-00**

Section AE0100

Page 4 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bracket No.	Description Position	Receptacle	Bundle	Plug	Bundle	Max Pos	Station / WL / BL	Effectivity
AE0201A	DISCONNECT BRACKET - E2-1 SHELF					023	E002-01/ /0023	ALL
	01	D49996J	W0212	D49996P	W5112			ALL
	02	D40934J	W0212	D40934P	W5112			ALL
	03	D40342J	W0212	D40342P	W5112			ALL
	4	D40256J	W0212	D40256P	W5112			ALL
	05	D40564J	W0212	D40564P	W2702			ALL
	06	D40910J	W0212	D40910P	W5726			ALL
	07	D40254J	W0212	D40254P	W5726			ALL
	08	D40428J	W0212	D40428P	W5510			ALL
	09	D40926J	W0212	D40926P	W5726			ALL
	10	D40598J	W0212	D40598P	W2112			ALL
	12	D40260J	W0212	D40260P	W5110			ALL
	13	D40372J	W0212	D40372P	W6210			ALL
	15	D41432J	W0210	D41432P	W2138			ALL
	16	D40132J	W0212	D40132P	W5164			ALL
	17	D40718J	W0212	D40718P	W5164			ALL
	18	D40358J	W0212	D40358P	W5612			ALL
	19	D40340J	W0212	D40340P	W5110			ALL
	20	D40070J	W0210	D40070P	W2108			ALL
	21	D40518J	W0210	D40518P	W2112			ALL
	23	D40258J	W0212	D40258P	W5568			ALL
AE0202A	DISCONNECT BRACKET - E2-2 SHELF					033	E002-02/ /0033	ALL
	01	D40246J	W0220	D40246P	W5104			ALL
	02	D40586J	W0220	D40586P	W5248			ALL
	03	D40942J	W0220	D40942P	W5726			ALL
	04	D40928J	W0220	D40928P	W5726			ALL
	05	D40656J	W0220	D40656P	W7592			ALL
	06	D43050J	W0220	D43050P	W6730			ALL
	07	D40136J	W0220	D40136P	W5564			ALL
	08	D40138J	W0220	D40138P	W5168			ALL
	09	D40456J	W0220	D40456P	W5156			ALL
	10	D40348J	W0220	D40348P	W5610			ALL
	11	D40506J	W0220	D40506P	W2104			YT101-YT131
	11	D40506J	W0220					YT132-YT133
	12	D40520J	W0220	D40520P	W2112			ALL
	13	D43084J	W0220	D43084P	W5230			YT101-YT119, YT126-YT131
	13	D43084J	W0220					YT120, YT132-YT133
	14	D40118J	W0220	D40118P	W5566			ALL
	15	D40430J	W0220	D40430P	W5506			ALL
	16	D40360J	W0220	D40360P	W5612			ALL

### DISCONNECT BRACKET LIST

D280A351

**91-04-00**

Section AE0200

Page 1

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bracket No.	Description Position	Receptacle	Bundle	Plug	Bundle	Max Pos	Station / WL / BL	Effectivity
AE0202A	DISCONNECT BRACKET - E2-2 SHELF (continued)					033	E002-02/ /0033	ALL
	17	D43060J	W0220	D43060P	W6128			YT101-YT119, YT126-YT131
	17	D43060J	W0220					YT120, YT132-YT133
	18	D41012J	W0220	D41012P	W6214			ALL
	19	D43008J	W0220	D43008P	W5134			ALL
	20	D40240J	W0220	D40240P	W6102			ALL
	21	D40012J	W0220	D40012P	W7594			ALL
	22	D40912J	W0220	D40912P	W5726			ALL
	23	D40946J	W0220	D40946P	W5726			ALL
	24	D40450J	W0220	D40450P	W5310			ALL
	25	D40130J	W0220	D40130P	W5162			ALL
	26	D40380J	W0220	D40380P	W6214			ALL
	27	D40126J	W0220	D40126P	W3170			ALL
	28	D40724J	W0220	D40724P	W5156			ALL
	29	D43024J	W0220	D43024P	W5728			ALL
	30	D40646J	W0220	D40646P	W2110			ALL
	31	D46022J	W0220	D46022P	W2110			ALL
	32	D42014J	W0220	D42014P	W5088			ALL
	33	D41840J	W0220	D41840P	W5094			ALL

### DISCONNECT BRACKET LIST

D280A351

**91-04-00**

Section AE0200

Page 2 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bracket No.	Description Position	Receptacle	Bundle	Plug	Bundle	Max Pos	Station / WL / BL	Effectivity
AE0301A	DISCONNECT BRACKET - E3-1					041	E003-01/ /0041	ALL
	01	D04271J	W0311	D04271P	W5189			ALL
	02	D42163J	W0311	D42163P	W5273			ALL
	03	D42026J	W0311	D42026P	W5610			YT104-YT133
	04	D40101J	W0311	D40101P	W2527			ALL
	05	D40301J	W0311	D40301P	W2531			ALL
	06	D04267J	W0311	D04267P	W2207			ALL
	07	D45111J	W0311	D45111P	W5111			ALL
	08	D45131J	W0311	D45131P	W5111			ALL
	09	D45151J	W0311	D45151P	W5111			ALL
	11	D40448J	W0311	D40448P	W5310			ALL
	12	D42005J	W0311	D42005P	W2265			ALL
	14	D49994J	W0311	D49994P	W3170			ALL
	15	D43145J	W0311	D43145P	W5161			ALL
	16	D43155J	W0311	D43155P	W5161			ALL
	18	D45205J	W0311	D45205P	W5205			ALL
	19	D40460J	W0311	D40460P	W5156			ALL
	20	D40516J	W0311	D40516P	W2112			ALL
	21	D41817J	W0311	D41817P	W2201			ALL
	22	D41837J	W0311	D41837P	W2653			ALL
	23	D46017J	W0313	D46017P	W2231			ALL
	24	D46035J	W0313	D46035P	W2169			ALL
	25	D42007J	W0313	D42007P	W2267			ALL
	26	D42047J	W0311	D42047P	W5047			YT104-YT133
	27	D40544J	W0313	D40544P	W2218			ALL
	28	D43147J	W0313	D43147P	W5163			ALL
	29	D43157J	W0313	D43157P	W5163			ALL
	31	D04297J	W0313	D04297P	W2237			ALL
	32	D45121J	W0313	D45121P	W5121			ALL
	33	D45141J	W0313	D45141P	W5121			ALL
	34	D40394J	W0313	D40394P	W6412			ALL
	35	D40149J	W0313	D40149P	W6491			ALL
	36	D40732J	W0313	D40732P	W4170			ALL
	37	D04277J	W0313	D04277P	W5191			ALL
	38	D42165J	W0313	D42165P	W5275			ALL
	39	D42049J	W0313	D42049P	W5049			YT104-YT133
	40	D40201J	W0313	D40201P	W2529			ALL
	40	D40201P	W2529	D40201J	W0313			ALL
	41	D40401J	W0313	D40401P	W2533			ALL
	41	D40401P	W2533	D40401J	W0313			ALL

### DISCONNECT BRACKET LIST

D280A351

91-04-00

Section AE0300

Page 1

Jun 21/2016





## 737-800 WIRING DIAGRAM MANUAL

Bracket No.	Description Position	Receptacle	Bundle	Plug	Bundle	Max Pos	Station / WL / BL	Effectivity
AE0302A	DISCONNECT BRACKET - E3-2 SHELF					056	E003-02/ /0056	ALL
	01	D43217J	W0321	D43217P	W5461			ALL
	02	D40053J	W0321	D40053P	W5367			ALL
	03	D49002J	W0321	D49002P	W2031			YT104-YT133
	04	D40446J	W0321	D40446P	W5310			ALL
	05	D40362J	W0321	D40362P	W5612			ALL
	06	D40350J	W0321	D40350P	W5610			ALL
	07	D40940J	W0321	D40940P	W5610			ALL
	08	D40023J	W0321	D40023P	W2705			ALL
	09	D43215J	W0321	D43215P	W2805			YT101-YT103
	10	D40025J	W0321	D40025P	W3377			ALL
	11	D43203J	W0321	D43203P	W5603			YT101-YT119, YT126-YT131
	11	D43203J	W0321					YT120, YT132-YT133
	12	D43257J	W0321	D43257P	W5257			ALL
	13	D43219J	W0321	D43219P	W2419			ALL
	14	D45207J	W0321	D45207P	W5205			ALL
	15	D40950J	W0321	D40950P	W5506			ALL
	16	D40594J	W0321	D40594P	W5156			ALL
	17	D45177J	W0321	D45177P	W5111			YT101-YT103
	17	D43215J	W0321	D43215P	W2805			YT104-YT133
	18	D45157J	W0321	D45157P	W5111			ALL
	19	D45137J	W0321	D45137P	W5111			ALL
	20	D45117J	W0321	D45117P	W5111			ALL
	21	D40021J	W0321	D40021P	W2705			ALL
	22	D43054J	W0321	D43054P	W6732			ALL
	23	D40462J	W0321	D40462P	W5156			ALL
	24	D43022J	W0321	D43022P	W5530			ALL
	25	D46021J	W0321	D46021P	W2231			ALL
	26	D41839J	W0321	D41839P	W2653			ALL
	27	D41819J	W0321	D41819P	W2201			ALL
	28	D40426J	W0321	D40426P	W5158			ALL
	29	D45102J	W0321	D45102P	W5121			ALL
	30	D46043J	W0321	D46043P	W2169			ALL
	31	D40596J	W0321	D40596P	W2112			ALL
	32	D43046J	W0321	D43046P	W6530			ALL
	33	D40486J	W0321	D40486P	W5158			ALL
	34	D40027J	W0321	D40027P	W2709			ALL
	35	D40029J	W0321	D40029P	W3379			ALL
	36	D40468J	W0321	D40468P	W5160			ALL
	37	D40470J	W0321	D40470P	W5160			ALL
	38	D43205J	W0321	D43205P	W5605			ALL

### DISCONNECT BRACKET LIST

D280A351

**91-04-00**

Section AE0300

Page 2

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bracket No.	Description Position	Receptacle	Bundle	Plug	Bundle	Max Pos	Station / WL / BL	Effectivity
AE0302A	DISCONNECT BRACKET - E3-2 SHELF (continued)					056	E003-02/ /0056	ALL
	39	D40194J	W0321	D40194P	W6134			ALL
	40	D43261J	W0321	D43261P	W5461			ALL
	41	D42261J	W0321	D42261P	W5461			ALL
	42	D40952J	W0321	D40952P	W5160			ALL
	43	D42361J	W0321	D42361P	W5461			ALL
	44	D43263J	W0321	D43263P	W5463			ALL
	45	D40392J	W0321	D40392P	W6412			ALL
	46	D45127J	W0321	D45127P	W5121			ALL
	47	D42053J	W0321	D42053P	W5375			ALL
	48	D40276J	W0321	D40276P	W6134			ALL
	49	D43209J	W0321	D43209P	W5409			ALL
	50	D40232J	W0321	D40232P	W2709			ALL
	51	D43030J	W0321	D43030P	W6034			ALL
	52	D40908J	W0321	D40908P	W5726			ALL
	53	D42363J	W0321	D42363P	W5463			ALL
	54	D43080J	W0321	D43080P	W6412			ALL
	55	D43241J	W0321	D43241P	W2201			YT101-YT103
	56	D45147J	W0321	D45147P	W5121			ALL
	57	D40710J	W0321	D40710P	W5047			YT104-YT133
	59	D45006J	W0321	D45006P	W5049			YT104-YT133
	63	D49001J	W0321	D49001P	W5049			YT104-YT133
AE0303A	DISCONNECT BRACKET - E3-3 SHELF					049	384/173/L005	ALL
	01	D43301J	W0331	D43301P	W5415			ALL
	04	D43039J	W0331	D43039P	W5121			ALL
	05	D43306J	W0331	D43306P	W5723			YT101-YT103
	05	D41822J	W0330	D41822P	W6412			YT104-YT133
	06	D43359J	W0331	D43359P	W5103			ALL
	07	D43391J	W0331	D43391P	W2417			YT101-YT103
	07	D43367J	W0331	D43367P	W5107			YT104-YT133
	08	D43314J	W0331	D43314P	W5107			ALL
	10	D43361J	W0331	D43361P	W5105			YT101-YT103
	10	D43056J	W0330	D43056P	W5047			YT116-YT120, YT132-YT133
	11	D43367J	W0331	D43367P	W5107			YT101-YT103
	11	D41826J	W0330	D41826P	W2218			YT104-YT133
	12	D43307J	W0331	D43307P	W5111			ALL
	13	D43321J	W0331	D43321P	W5111			ALL
	15	D43329J	W0331	D43329P	W2417			ALL
	17	D43345J	W0331	D43345P	W5331			ALL
	18	D43347J	W0331	D43347P	W5331			ALL

### DISCONNECT BRACKET LIST

D280A351

**91-04-00**

Section AE0300

Page 3

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bracket No.	Description Position	Receptacle	Bundle	Plug	Bundle	Max Pos	Station / WL / BL	Effectivity
AE0303A	DISCONNECT BRACKET - E3-3 SHELF (continued)					049	384/173/L005	ALL
	20	D43305J	W0331	D43305P	W5111			ALL
	22	D43049J	W0331	D43049P	W5461			ALL
	24	D41800J	W0330	D41800P	W5104			YT101-YT103
	24	D43391J	W0331	D43391P	W2417			YT104-YT133
	25	D41814J	W0330	D41814P	W6214			ALL
	26	D41802J	W0330	D41802P	W6220			ALL
	27	D41842J	W0330	D41842P	W5526			ALL
	28	D43313J	W0331	D43313P	W2201			ALL
	29	D43309J	W0331	D43309P	W2231			YT101-YT103
	30	D41824J	W0330	D41824P	W5156			ALL
	31	D41836J	W0330	D41836P	W5104			ALL
	32	D41818J	W0330	D41818P	W6288			YT101-YT103
	32	D43355J	W0331	D43355P	W2415			YT104-YT133
	33	D43363J	W0331	D43363P	W2413			YT104-YT133
	34	D43361J	W0331	D43361P	W5105			YT104-YT133
	35	D41822J	W0330	D41822P	W6412			YT101-YT103
	36	D41826J	W0330	D41826P	W2218			YT101-YT103
	36	D43139J	W0331	D43139P	W5049			YT104-YT133
	37	D41808J	W0330	D41808P	W6420			ALL
	38	D43331J	W0331	D43331P	W5191			ALL
	40	D41812J	W0330	D41812P	W2216			ALL
	41	D41806J	W0330	D41806P	W6230			ALL
	42	D43323J	W0331	D43323P	W5121			ALL
	43	D43379J	W0331	D43379P	W5335			ALL
	44	D43333J	W0331	D43333P	W5723			YT101-YT103
	46	D43355J	W0331	D43355P	W2415			YT101-YT103
	46	D41818J	W0330	D41818P	W6288			YT104-YT133
	47	D43357J	W0331	D43357P	W2415			YT101-YT103
	47	D43333J	W0331	D43333P	W5723			YT104-YT133
	48	D43363J	W0331	D43363P	W2413			YT101-YT103
	48	D43306J	W0331	D43306P	W5723			YT104-YT133
	49	D43365J	W0331	D43365P	W2413			YT101-YT103

### DISCONNECT BRACKET LIST

D280A351

**91-04-00**

Section AE0300

Page 4 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bracket No.	Description Position	Receptacle	Bundle	Plug	Bundle	Max Pos	Station / WL / BL	Effectivity
AE0401A	DISCONNECT BRACKET - E4-1 SHELF					052	E004-01/ /0052	ALL
	09	D41804J	W0410	D41804P	W6220			ALL
	10	D41810J	W0410	D41810P	W6420			ALL
	11	D41816J	W0410	D41816P	W6288			ALL
	12	D41828J	W0410	D41828P	W6214			ALL
	13	D41830J	W0410	D41830P	W6412			ALL
	14	D04115J	W0411	D04115P	W5331			ALL
	15	D04117J	W0411	D04117P	W5331			ALL
	16	D04289J	W0411	D04289P	W5191			ALL
	17	D04287J	W0411	D04287P	W5189			ALL
	18	D04155J	W0411	D04155P	W3323			ALL
	19	D04285J	W0411	D04285P	W5191			ALL
	20	D04331J	W0411	D04331P	W3319			ALL
	21	D08123J	W0411	D08123P	W5189			ALL
	22	D04153J	W0411	D04153P	W3327			ALL
	23	D04371J	W0411	D04371P	W5431			ALL
	24	D44161J	W0410	D44161P	W5461			ALL
	25	D04161J	W0411	D04161P	W5337			ALL
	26	D40904J	W0410	D40904P	W5726			ALL
	27	D44139J	W0411	D44139P	W3309			ALL
	28	D04157J	W0411	D04157P	W3329			ALL
	29	D40244J	W0410	D40244P	W5104			ALL
	30	D40242J	W0410	D40242P	W6102			ALL
	31	D40328J	W0410	D40328P	W6214			ALL
	32	D04007J	W0411	D04007P	W5335			ALL
	33	D41010J	W0410	D41010P	W6412			ALL
	35	D40326J	W0410	D40326P	W6412			ALL
	36	D40330J	W0410	D40330P	W6230			ALL
	37	D43044J	W0410	D43044P	W6528			ALL
	38	D40144J	W0410	D40144P	W6168			ALL
	39	D40066J	W0410	D40066P	W6204			ALL
	40	D40530J	W0410	D40530P	W2214			ALL
	41	D04009J	W0411	D04009P	W5335			ALL
	42	D40158J	W0410	D40158P	W6564			ALL
	43	D40554J	W0410	D40554P	W2508			ALL
	44	D43018J	W0410	D43018P	W5526			ALL
	45	D43062J	W0410	D43062P	W5230			YT101-YT119, YT126-YT131
	45	D43062J	W0410					YT120, YT132-YT133
	46	D40378J	W0410	D40378P	W6214			ALL
	47	D40562J	W0410	D40562P	W2510			ALL
	48	D40534J	W0410	D40534P	W2216			ALL

### DISCONNECT BRACKET LIST

D280A351

**91-04-00**

Section AE0400

Page 1

Jun 21/2016



# 737-800 WIRING DIAGRAM MANUAL

Bracket No.	Description Position	Receptacle	Bundle	Plug	Bundle	Max Pos	Station / WL / BL	Effectivity
<b>AE0401A</b>	<b>DISCONNECT BRACKET - E4-1 SHELF (continued)</b>					<b>052</b>	<b>E004-01/ /0052</b>	<b>ALL</b>
	49	D43038J	W0410	D43038P	W6230			ALL
	50	D40156J	W0410	D40156P	W6162			ALL
	51	D40542J	W0410	D40542P	W2218			ALL
	52	D40390J	W0410	D40390P	W6412			ALL
<b>AE0401B</b>	<b>DISCONNECT BRACKET - E4-1 SHELF</b>					<b>002</b>	<b>E004-01/ /</b>	<b>ALL</b>
<b>AE0401D</b>	<b>DISCONNECT BRACKET - E4-1 SHELF</b>					<b>010</b>	<b>E004-01/ /0052</b>	<b>ALL</b>
	03			D00403	W2705			ALL
	04			D00414	W2705			ALL
	05			D00405	W2705			ALL
	06			D00406	W2705			ALL
	09			D00416	W2705			ALL
	13			D00413	W2709			ALL
	14			D00404	W2709			ALL
	15			D00415	W2709			ALL
	16			D00409	W2705			ALL
<b>AE0402A</b>	<b>DISCONNECT BRACKET - E4-2 SHELF</b>					<b>041</b>	<b>E004-02/ /0041</b>	<b>ALL</b>
	01	D42111J	W0422	D42111P	W5719			ALL
	02	D40584J	W0422	D40584P	W5248			ALL
	07	D40338J	W0422	D40338P	W5110			ALL
	08	D40238J	W0422	D40238P	W6134			ALL
	09	D40714J	W0422	D40714P	W6588			ALL
	13	D40228J	W0422	D40228P	W6208			ALL
	14	D40222J	W0422	D40222P	W6208			ALL
	15	D40164J	W0422	D40164P	W6586			ALL
	16	D43028J	W0422	D43028P	W6032			ALL
	17	D40432J	W0422	D40432P	W6222			ALL
	19	D40742J	W0422	D40742P	W6222			ALL
	22	D42400J	W0420	D42400P	W6412			ALL
	23	D40712J	W0422	D40712P	W6412			ALL
	24	D40388J	W0422	D40388P	W6412			ALL
	25	D40382J	W0422	D40382P	W6410			ALL
	26	D40140J	W0422	D40140P	W6164			ALL
	27	D40720J	W0422	D40720P	W6164			ALL
	28	D40938J	W0422	D40938P	W6210			ALL
	29	D40370J	W0422	D40370P	W6210			ALL
	30	D40484J	W0422	D40484P	W5158			ALL
	31	D40356J	W0422	D40356P	W5612			ALL

## DISCONNECT BRACKET LIST

D280A351

**91-04-00**

Section AE0400

Page 2

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bracket No.	Description Position	Receptacle	Bundle	Plug	Bundle	Max Pos	Station / WL / BL	Effectivity
AE0402A	DISCONNECT BRACKET - E4-2 SHELF (continued)					041	E004-02/ /0041	ALL
	32	D40540J	W0422	D40540P	W2218			ALL
	33	D40472J	W0422	D40472P	W5160			ALL
	34	D40068J	W0420	D40068P	W2208			ALL
	35	D40618J	W0422	D40618P	W5158			ALL
	36	D40930J	W0422	D40930P	W5612			ALL
	37	D40474J	W0422	D40474P	W5160			ALL
	38	D41440J	W0420	D41440P	W2218			ALL
	40	D40169J	W0422	D40169P	W5160			ALL

### DISCONNECT BRACKET LIST

D280A351

**91-04-00**

Section AE0400

Page 3 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bracket No.	Description Position	Receptacle	Bundle	Plug	Bundle	Max Pos	Station / WL / BL	Effectivity
AE0502A	DISCONNECT BRACKET - E5-2 SHELF					024	E005-02 /	ALL
I	01	D45221J	W0737	D45221P	W0521			YT101-YT103
I	01	D45209J	W5205	D45209P	W0521			YT104-YT133
I	02	D45245J	W5161	D45245P	W0521			YT104-YT133
	03	D45209J	W5205	D45209P	W0521			YT101-YT103
I	03	D45255J	W5161	D45255P	W0521			YT104-YT133
	04	D45247J	W5163	D45247P	W0523			YT101-YT103
I	04	D45265J	W5161	D45265P	W0521			YT104-YT133
	05	D45257J	W5163	D45257P	W0523			YT101-YT103
I	05	D41561J	W5461	D41561P	W0521			YT104-YT133
	06	D45263J	W5463	D45263P	W0523			YT101-YT103
I	06	D45261J	W5461	D45261P	W0521			YT104-YT133
	07	D45237J	W2135	D45237P	W0523			YT101-YT103
I	07	D45235J	W2035	D45235P	W0521			YT104-YT133
	08	D45067J	W2135	D45067P	W0523			YT101-YT103
I	08	D45239J	W5501	D45239P	W0521			YT104-YT133
	09	D08105J	W2873	D08105P	W0523			YT101-YT103
I	09	D45225J	W2597	D45225P	W0521			YT104-YT133
	10	D45241J	W5503	D45241P	W0523			YT101-YT103
I	10	D05925J	W2889	D05925P	W0521			YT104-YT133
	11	D45213J	W5121	D45213P	W0523			YT101-YT103
I	11	D45293J	W2597	D45293P	W0521			YT104-YT133
I	12	D45211J	W5111	D45211P	W0521			ALL
	13	D45319J	W5043	D45319P	W0521			YT101-YT103
	14	D45245J	W5161	D45245P	W0521			YT101-YT103
I	14	D45319J	W5043	D45319P	W0521			YT104-YT133
	15	D45255J	W5161	D45255P	W0521			YT101-YT103
	16	D45265J	W5161	D45265P	W0521			YT101-YT103
I	16	D45204J	W2031	D45204P	W0521			YT104-YT133
	17	D41561J	W5461	D41561P	W0521			YT101-YT103
I	17	D40761J	W5047	D40761P	W0521			YT104-YT133
	18	D45261J	W5461	D45261P	W0521			YT101-YT103
	19	D45235J	W2035	D45235P	W0521			YT101-YT103
	20	D45239J	W5501	D45239P	W0521			YT101-YT103
	21	D45225J	W2597	D45225P	W0521			YT101-YT103
	22	D05925J	W2889	D05925P	W0521			YT101-YT103
	23	D45293J	W2597	D45293P	W0521			YT101-YT103
	24	D06063J	W0521					YT101-YT103
I	24	D45563J	W5163	D45563P	W0521			YT105-YT133
I	25	D40767J	W5049	D40767P	W0523			YT104-YT133
I	26	D45213J	W5121	D45213P	W0523			YT104-YT133

### DISCONNECT BRACKET LIST

D280A351

91-04-00

Section AE0500

Page 1

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bracket No.	Description Position	Receptacle	Bundle	Plug	Bundle	Max Pos	Station / WL / BL	Effectivity
AE0502A	DISCONNECT BRACKET - E5-2 SHELF (continued)					024	E005-02/ /	ALL
	27	D45247J	W5163	D45247P	W0523			YT104-YT133
	28	D45257J	W5163	D45257P	W0523			YT104-YT133
	29	D45263J	W5463	D45263P	W0523			YT104-YT133
	30	D45237J	W2135	D45237P	W0523			YT104-YT133
	31	D45067J	W2135	D45067P	W0523			YT104-YT133
	32	D08105J	W2873	D08105P	W0523			YT104-YT133
	33	D45241J	W5503	D45241P	W0523			YT104-YT133
	34	D06063J	W0521					YT104-YT133

### DISCONNECT BRACKET LIST

D280A351

**91-04-00**

Section AE0500

Page 2 End

Jun 21/2016





## 737-800 WIRING DIAGRAM MANUAL

Bracket No.	Description Position	Receptacle	Bundle	Plug	Bundle	Max Pos	Station / WL / BL	Effectivity
I AE0602A	DISCONNECT BRACKET - E6-2 SHELF					012	E006-02/ /	ALL
I	01	D40127J	W0621	D40127P	W3559			ALL
I	02	D40123J	W0621	D40123P	W3557			ALL
I	03	D40111J	W0621	D40111P	W2101			ALL
I	04	D40621J	W0621	D40621P	W2103			ALL
I	05	D40117J	W0621	D40117P	W5189			ALL
I	07	D40119J	W0621	D40119P	W5191			ALL
I	08	D40115J	W0621	D40115P	W5105			ALL
I	10	D40113J	W0621	D40113P	W5103			ALL
I	11	D40125J	W0621	D40125P	W3555			ALL
I	12	D40121J	W0621	D40121P	W3553			ALL

### DISCONNECT BRACKET LIST

D280A351

**91-04-00**

Section AE0600

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bracket No.	Description Position	Receptacle	Bundle	Plug	Bundle	Max Pos	Station / WL / BL	Effectivity
I AE0801A	DISCONNECT BRACKET - E8-1 SHELF					000	E008-01/ /	ALL
I	01	D47031J	W0811	D47031P	W3477			ALL
I	13	D40489J	W0811	D40489P	W4258			ALL
I	14	D48323J	W0811	D48323P	W2103			ALL
	20	D45489J	W0811	D45489P	W3477			YT101-YT120
I AE0801B	DISCONNECT BRACKET E08-01 SHELF					000	E008-01/ /	ALL
I	01	D45905J	W0811	D45905P	W3307			ALL
I	02	D45907J	W0811	D45907P	W5043			ALL
I	06	D45912J	W0811	D45912P	W3477			ALL
	07	D45183J	W0811	D45183P	W3477			YT101-YT120
I	08	D45167J	W0811	D45167P	W3477			ALL
	09	D45185J	W0811	D45185P	W3477			YT101-YT120
I	12	D45169J	W0811	D45169P	W3477			ALL
I	13	D45099J	W0811	D45099P	W3755			ALL
I	14	D45243J	W0811	D45243P	W3755			YT101-YT102, YT126-YT133
	15	D45193J	W0811	D45193P	W3477			YT101-YT120
I	15			D45489P	W3477			YT126-YT133

### DISCONNECT BRACKET LIST

D280A351

**91-04-00**

Section AE0800

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bracket No.	Description					Max Pos	Station / WL / BL	Effectivity
	Position	Receptacle	Bundle	Plug	Bundle			
I AE1100A	DISCONNECT BRACKET - E11 SHELF					006	212/180/R020	ALL

### DISCONNECT BRACKET LIST

D280A351

**91-04-00**

Section AE1100

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bracket No.	Description Position	Receptacle	Bundle	Plug	Bundle	Max Pos	Station / WL / BL	Effectivity
AF0213A	DISCONNECT BRACKET-AISLE CONTROL STAND					006	210/208/BL0	ALL
	01	D05148J	W0008	D05148P	W6208			ALL
	02			D11288	W5506			ALL
	03			D11286	W5510			ALL
	03			D11286P	W0008			YT113-YT120, YT132-YT133
	04	D05150J	W0008	D05150P	W6208			ALL
	05	D08313J	W0049	D08313P	W5369			ALL
	06			D10171	W5506			ALL
	06	D10171J	W0049					ALL
AF0222A	DISCONNECT BRACKET-AISLE CONTROL STAND					007	210/208/	ALL
	01			D11292	W6506			ALL
	02			D11290	W6510			ALL
	02			D11290P	W0008			YT113-YT120, YT132-YT133
	03			D00417	W5369			ALL
	04	D08315J	W0051	D08315P	W5457			ALL
	05			D00698	W6208			ALL
	06			D10173	W6510			ALL
	06	D10173J	W0051					ALL
	07			D10537	W6208			ALL

### DISCONNECT BRACKET LIST

D280A351

**91-04-00**

Section AF0200

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bracket No.	Description Position	Receptacle	Bundle	Plug	Bundle	Max Pos	Station / WL / BL	Effectivity
<b>AJ0004</b>	<b>DISCONNECT BRACKET-J4</b>					<b>010</b>	<b>273/168/R024</b>	<b>ALL</b>
	01	D40602J	W0094	D40602P	W6222			ALL
	02	D41002J	W0094	D41002P	W3450			YT101-YT120
	03	D41004J	W0094	D41004P	W6212			YT101-YT120
	05	D40612J	W0094	D40612P	W5160			ALL
	06	D40658J	W0094	D40658P	W5160			ALL
	08	D40616J	W0094	D40616P	W6222			ALL
	09	D40614J	W0094	D40614P	W6222			ALL
	10	D40610J	W0094	D40610P	W5160			ALL
	12	D40662J	W0094	D40662P	W3453			ALL
<b>AJ0011</b>	<b>DISCONNECT BRACKET-J11</b>					<b>002</b>	<b>J011-00/ /</b>	<b>ALL</b>
	01	D46618J	W0122	D46618P	W5124			ALL
	02	D46616J	W0122	D46616P	W5124			ALL
	03	D46623J	W0122	D46623P	W5431			ALL
<b>AJ0020</b>	<b>DISCONNECT BRACKET-J20</b>					<b>000</b>	<b>J020-0B/ /</b>	<b>ALL</b>
<b>AJ0020A</b>	<b>DISCONNECT BRACKET-J20-A</b>					<b>004</b>	<b>J020-0A/ /</b>	<b>ALL</b>
	02	D40884J	W0074	D40884P	W5158			ALL
<b>AJ0020B</b>	<b>DISCONNECT BRACKET-J20-B</b>					<b>007</b>	<b>J020-0B/ /</b>	<b>ALL</b>
	01	D40634J	W0072	D40634P	W5158			ALL
	02	D40638J	W0072	D40638P	W5158			ALL
	03	D40640J	W0072	D40640P	W5158			ALL
	04	D40636J	W0072	D40636P	W5156			ALL
	05	D40632J	W0072	D40632P	W5100			ALL
	07	D40642J	W0072	D40642P	W5156			ALL
<b>AJ0020C</b>	<b>DISCONNECT BRACKET-J20-C</b>					<b>003</b>	<b>J020-0A/ /</b>	<b>ALL</b>
	02	D40878J	W0074	D40878P	W5156			ALL
<b>AJ0020D</b>	<b>DISCONNECT BRACKET-J20-D</b>					<b>001</b>	<b>J020-0D/ /</b>	<b>ALL</b>
	01	D40858J	W0072	D40858P	W5158			ALL
<b>AJ0022</b>	<b>DISCONNECT BRACKET-J22</b>					<b>009</b>	<b>J022-00/ /</b>	<b>ALL</b>
	01	D40678J	W0076	D40678P	W5156			ALL
	02	D40672J	W0076	D40672P	W5510			ALL
	03	D40666J	W0076	D40666P	W5156			ALL
	04	D40670J	W0076	D40670P	W5156			ALL

### DISCONNECT BRACKET LIST

D280A351

**91-04-00**

Section AJ0000

Page 1

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bracket No.	Description Position	Receptacle	Bundle	Plug	Bundle	Max Pos	Station / WL / BL	Effectivity
AJ0022	DISCONNECT BRACKET-J22 (continued)					009	J022-00/ /	ALL
	05	D40676J	W0076	D40676P	W5156			ALL
	06	D40668J	W0076	D40668P	W5100			ALL
	07	D40674J	W0076	D40674P	W5506			ALL
	08	D40680J	W0076	D40680P	W5156			ALL
	09	D40147J	W0076	D40147P	W6491			ALL
AJ0023	DISCONNECT BRACKET-J23					007	J023-00/ /	ALL
	02	D40686J	W0078	D40686P	W5506			ALL
	05	D40688J	W0078	D40688P	W5510			ALL
AJ0024	DISCONNECT BRACKET-J24					007	J024-00/ /	ALL
	02	D40696J	W0080	D40696P	W6510			ALL
	03	D40698J	W0080	D40698P	W5100			ALL
	04	D40692J	W0080	D40692P	W5158			ALL
	05	D40700J	W0080	D40700P	W5158			ALL
	06	D40702J	W0080	D40702P	W5158			ALL
	07	D40694J	W0080	D40694P	W5160			ALL
AJ0039A	DISCONNECT BRACKET-J39-A					000	J039-0A/ /	ALL
AJ0039B	DISCONNECT BRACKET-J39-B					000	J039-0B/ /	ALL
	01	D43926J	W0084	D43926P	W6212			ALL
	02	D43924J	W0084	D43924P	W6212			ALL
	03	D43922J	W0084	D43922P	W3058			YT101-YT131
	03	D43922J	W0084					YT132-YT133
AJ0046A	DISCONNECT BRACKET - J46A					016	263/177/R031	ALL
	01	D46130J	W0066	D46130P	W5510			ALL
	04	D46110J	W0066	D46110P	W6208			ALL
	05	D46128J	W0066	D46128P	W5506			ALL
	07	D46144J	W0066	D46144P	W6170			ALL
	08	D46146J	W0066	D46146P	W6172			ALL
	09	D40103J	W0066	D40103P	W2247			ALL
	11	D46104J	W0066	D46104P	W5514			ALL
	12	D46150J	W0066	D46150P	W6208			ALL
	13	D46116J	W0066	D46116P	W5156			ALL
	14	D46102J	W0066	D46102P	W5160			ALL
	15	D46108J	W0066	D46108P	W2508			ALL
	16	D46122J	W0066	D46122P	W5160			ALL

### DISCONNECT BRACKET LIST

D280A351

91-04-00

Section AJ0000

Page 2

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bracket No.	Description Position	Receptacle	Bundle	Plug	Bundle	Max Pos	Station / WL / BL	Effectivity
<b>AJ0046B</b>	<b>DISCONNECT BRACKET - J46B</b>					<b>015</b>	<b>263/177/R031</b>	<b>ALL</b>
	01	D46124J	W0066	D46124P	W2212			ALL
	02	D46138J	W0066	D46138P	W6242			ALL
	03	D46120J	W0066	D46120P	W5158			ALL
	04	D46132J	W0066	D46132P	W6506			ALL
	05	D46136J	W0066	D46136P	W6528			ALL
	06	D40097J	W0066	D40097P	W5503			ALL
	08	D46142J	W0066	D46142P	W6414			ALL
	09	D46118J	W0066	D46118P	W6510			ALL
	10	D46106J	W0066	D46106P	W6506			ALL
	11	D46100J	W0066	D46100P	W5158			ALL
	12	D46112J	W0066	D46112P	W2216			ALL
	13	D46126J	W0066	D46126P	W2510			ALL
	15	D46114J	W0066	D46114P	W2218			ALL
<b>AJ0048A</b>	<b>DISCONNECT BRACKET - J48A</b>					<b>026</b>	<b>263/177/L033</b>	<b>ALL</b>
	01	D48100J	W0088	D48100P	W2104			YT101-YT131
	01	D48100J	W0088					YT132-YT133
	02	D48126J	W0088	D48126P	W5122			ALL
	03	D48122J	W0088	D48122P	W5510			ALL
	04	D40095J	W0088	D40095P	W2149			ALL
	05	D48102J	W0088	D48102P	W2112			ALL
	07	D48110J	W0088	D48110P	W5170			ALL
	08	D40087J	W0088	D40087P	W5501			ALL
	09	D48120J	W0088	D48120P	W5506			ALL
	13	D48116J	W0088	D48116P	W5158			ALL
	14	D48106J	W0088	D48106P	W2508			ALL
	15	D48108J	W0088	D48108P	W2532			ALL
	16	D48112J	W0088	D48112P	W5156			ALL
	17	D48114J	W0088	D48114P	W5156			ALL
	18	D48124J	W0088	D48124P	W6110			ALL
	19	D48136J	W0088	D48136P	W5172			ALL
	20	D48104J	W0088	D48104P	W2114			ALL
	21	D48134J	W0088	D48134P	W5162			ALL
	22	D48118J	W0088	D48118P	W5506			ALL
	23	D48130J	W0088	D48130P	W6510			ALL
	24	D48128J	W0088	D48128P	W6570			YT101-YT109, YT126-YT129
	24	D47600J	W0088	D47600P	W5558			YT110-YT120, YT130-YT133
	25	D48138J	W0088	D48138P	W6506			ALL
	26	D48132J	W0088	D48132P	W6506			ALL

### DISCONNECT BRACKET LIST

D280A351

**91-04-00**

Section AJ0000

Page 3 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bracket No.	Description Position	Receptacle	Bundle	Plug	Bundle	Max Pos	Station / WL / BL	Effectivity
I AL0675A	DISCONNECT BRACKET-MAIN WHEEL WELL					004	676/198/L040	ALL
I	04	D46010J	W5224	D46010P	W7122			YT101-YT119, YT126-YT131
I	04	D46010J	W5224					YT120, YT132-YT133
I AL0675B	DISCONNECT BRACKET-MAIN WHEEL WELL					004	675/198/L036	ALL
I	01	D46026J	W5728	D46026P	W7026			ALL
I	02	D04850J	W5580	D04850P	W7580			ALL
I	03	D46030J	W5222	D46030P	W7522			ALL
I	04	D46028J	W5530	D46028P	W7230			ALL
I AL0675C	DISCONNECT BRACKET-MAIN WHEEL WELL					003	675/198/R036	ALL
I	01	D46046J	W6732	D46046P	W8228			ALL
I	02	D46042J	W6122	D46042P	W8222			ALL
I	03	D46038J	W6124	D46038P	W8122			ALL
I AL0694L	DISCONNECT BRACKET-STA 694					002	/ /	ALL
I	01	D46002J	W7230	D46002P	W7022			ALL
I	02	D46004J	W7230	D46004P	W7134			ALL
I AL0694R	DISCONNECT BRACKET-STA 694					002	/ /	ALL
I	01	D46012J	W8228	D46012P	W8022			ALL
I	02	D46014J	W8228	D46014P	W8234			ALL

### DISCONNECT BRACKET LIST

D280A351

**91-04-00**

Section AL0600

Page 1 End

Jun 21/2016





## 737-800 WIRING DIAGRAM MANUAL

Bracket No.	Description Position	Receptacle	Bundle	Plug	Bundle	Max Pos	Station / WL / BL	Effectivity
I AL0706L	DISCONNECT BRACKET-STA 706					001	/ /	ALL
I	01	D46006J	W7126	D46006P	W7136			ALL
I AL0706R	DISCONNECT BRACKET-STA 706					001	/ /	ALL
I	01	D46016J	W8224	D46016P	W8236			ALL
I AL0711L	DISCONNECT BRACKET-STA 711					000	/ /	ALL
I	01	D46008J	W7126	D46008P	W7024			ALL
I AL0711R	DISCONNECT BRACKET-STA 711					001	/ /	ALL
I	01	D46018J	W8224	D46018P	W8024			ALL
I AL0720A	DISCONNECT BRACKET-MAIN WHEEL WELL					004	717/200/L032	ALL
I	01	D46024J	W5234	D46024P	W7126			ALL
I	02	D42102J	W5367	D42102P	W1022			YT101-YT119, YT126-YT131
I	02	D42102J	W5367					YT120, YT132-YT133
I	03	D42100J	W5375	D42100P	W1022			YT101-YT119, YT126-YT131
I	03	D42100J	W5375					YT120, YT132-YT133
I AL0720B	DISCONNECT BRACKET-MAIN WHEEL WELL					003	717/200/L027	ALL
I	02	D46032J	W5222	D46032P	W7128			YT101-YT119, YT126-YT131
I	02	D46032J	W5222					YT120, YT132-YT133
I	03	D46036J	W5224	D46036P	W7128			YT101-YT119, YT126-YT131
I	03	D46036J	W5224					YT120, YT132-YT133
I	04	D46020J	W6124	D46020P	W7128			YT101-YT119, YT126-YT131
I	04	D46020J	W6124					YT120, YT132-YT133
I AL0720C	DISCONNECT BRACKET-MAIN WHEEL WELL					004	717/200/R032	ALL
I	01	D43100J	W5367	D43100P	W1032			YT101-YT119, YT126-YT131
I	01	D43100J	W5367					YT120, YT132-YT133
I	02	D40004J	W6122	D40004P	W8224			ALL
I	03	D46044J	W6124	D46044P	W8226			ALL
I	04	D40006J	W6124	D40006P	W8226			ALL
I AL0720D	DISCONNECT BRACKET-MAIN WHEEL WELL					004	717/200/R027	ALL
I	01	D46040J	W6124	D46040P	W8124			ALL
I	02	D43102J	W5375	D43102P	W1032			YT101-YT119, YT126-YT131
I	02	D43102J	W5375					YT120, YT132-YT133
I	03	D46048J	W6228	D46048P	W8230			ALL
I	04	D46050J	W6730	D46050P	W8524			ALL

### DISCONNECT BRACKET LIST

D280A351

91-04-00

Section AL0700

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bracket No.	Description Position	Receptacle	Bundle	Plug	Bundle	Max Pos	Station / WL / BL	Effectivity
AP0600A	DISCONNECT BRACKET-P5-P6 INTEGRATION					010	270/280/R005	ALL
	01	D40088J	W0044	D40088P	W4258			ALL
	04	D40444J	W0044	D40444P	W6214			ALL
	05	D40226J	W0044	D40226P	W3058			YT101-YT131
	05	D40226J	W0044					YT132-YT133
	08	D40528J	W6208	D40528P	W2212			ALL
	09	D40218J	W0044	D40218P	W0018			ALL
AP0600B	DISCONNECT BRACKET-LOWER P6 PANEL					024	260/215/R040	ALL
	01	D40067J	W0041	D40067P	W2709			ALL
	02	D40750J	W0044	D40750P	W5158			ALL
	03	D40822J	W0044	D40822P	W5514			ALL
	04	D46063J	W0044	D46063P	W2169			ALL
	05	D41430J	W0044	D41430P	W2138			ALL
	06	D40623J	W0041	D40623P	W2135			ALL
	07	D41832J	W0044	D41832P	W6412			ALL
	08	D40800J	W0044	D40800P	W5506			ALL
	09	D40368J	W0044	D40368P	W6110			ALL
	10	D46067J	W0044	D46067P	W2231			ALL
	11	D46052J	W0044	D46052P	W2030			ALL
	12	D40812J	W0044	D40812P	W6506			ALL
	13	D40625J	W0041	D40625P	W2597			ALL
	14	D40386J	W0044	D40386P	W6412			ALL
	15	D46065J	W0044	D46065P	W2383			ALL
	16	D40352J	W0044	D40352P	W5612			ALL
	17	D40820J	W0044	D40820P	W6208			ALL
	18	D40816J	W0044	D40816P	W6206			ALL
	19	D40708J	W0044	D40708P	W6212			ALL
	20	D46069J	W0044	D46069P	W2661			ALL
	21	D40574J	W0044	D40574P	W6222			ALL
	22	D40396J	W0044	D40396P	W6414			ALL
	23	D46061J	W0044	D46061P	W2103			ALL
	24	D40654J	W0044	D40654P	W6024			ALL
AP0600C	DISCONNECT BRACKET-UPPER P6 PANEL					010	260/275/R015	ALL
	01	D40502J	W0044	D40502P	W2104			YT101-YT131
	01	D40502J	W0044					YT132-YT133
	02	D40526J	W0044	D40526P	W2212			ALL
	03	D40512J	W0044	D40512P	W2112			ALL
	04	D40532J	W0044	D40532P	W2216			ALL
	05	D40550J	W0044	D40550P	W2508			ALL

### DISCONNECT BRACKET LIST

D280A351

91-04-00

Section AP0600

Page 1

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bracket No.	Description Position	Receptacle	Bundle	Plug	Bundle	Max Pos	Station / WL / BL	Effectivity
AP0600C	DISCONNECT BRACKET-UPPER P6 PANEL (continued)					010	260/275/R015	ALL
	06	D04151J	W0041	D04151P	W3327			ALL
	08	D40558J	W0044	D40558P	W2510			ALL
	09	D40536J	W0044	D40536P	W2218			ALL
	10	D40582J	W0044	D40582P	W2204			ALL

### DISCONNECT BRACKET LIST

D280A351

**91-04-00**

Section AP0600

Page 2 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

	Bracket No.	Description					Max Pos	Station / WL / BL	Effectivity
		Position	Receptacle	Bundle	Plug	Bundle			
I	AP0700A	DISCONNECT BRACKET-P7 PANEL					002	P007-00/250/L005	ALL
I	AP0700B	DISCONNECT BRACKET-P7 PANEL					002	P007-00/250/R005	ALL

### DISCONNECT BRACKET LIST

D280A351

**91-04-00**

Section AP0700

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bracket No.	Description Position	Receptacle	Bundle	Plug	Bundle	Max Pos	Station / WL / BL	Effectivity
AP0900A	DISCONNECT BRACKET-P9-FWD INSTR PANEL					027	190/214/0	ALL
I	03	D04207J	W0001	D04207P	W2207			ALL
I	04	D40578J	W0001	D40578P	W5156			ALL
I	05	D40824J	W0003	D40824P	W5514			ALL
I	06	D04237J	W0003	D04237P	W2237			ALL
I	07	D40580J	W0003	D40580P	W5160			ALL
I	08			D00308	W2705			ALL
I	09	D04221J	W0001	D04221P	W2221			ALL
I	10	D40914J	W0001	D40914P	W2022			ALL
I	11	D40944J	W0001	D40944P	W5202			ALL
I	14	D40924J	W0003	D40924P	W2030			ALL
I	16	D46033J	W0003	D46033P	W2383			ALL
I	17			D41823P	W2175			ALL
I	18	D40804J	W0001	D40804P	W5506			ALL
I	19	D41833J	W0001	D41833P	W2651			ALL
I	22			D00322	W2709			ALL
I	23	D04251J	W0003	D04251P	W2251			ALL
I	25	D10030J	W0001	D10030P	W3704			ALL
I	26	D10032J	W0003	D10032P	W3706			ALL
I	27	D10034J	W0003	D10034P	W3705			ALL

### DISCONNECT BRACKET LIST

D280A351

**91-04-00**

Section AP0900

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bracket No.	Description Position	Receptacle	Bundle	Plug	Bundle	Max Pos	Station / WL / BL	Effectivity
I AP1800A	DISCONNECT BRACKET-P5-P18 INTEGRATION					010	270/280/L005	ALL
I	01	D40198J	W0018	D40198P	W3150			ALL
I	02	D48901J	W0018	D48901P	W3381			ALL
I	03	D40840J	W0018	D40840P	W2112			ALL
I	04	D40524J	W0018	D40524P	W2212			ALL
I	05	D40538J	W0018	D40538P	W2218			ALL
I	06	D40220J	W0018	D40220P	W3144			ALL
I	07	D40298J	W0018	D40298P	W4250			ALL
I	08	D40504J	W0018	D40504P	W2104			YT101-YT131
I	08	D40504J	W0018					YT132-YT133
I	09	D40514J	W0018	D40514P	W2112			ALL
I	10	D40522J	W0018	D40522P	W2114			ALL
I	12	D40687J	W0018	D40687P	W3004			ALL
I AP1800B	DISCONNECT BRACKET-LOWER P18 PANEL					009	255/215/L040	ALL
I	01	D41805J	W0018	D41805P	W2201			ALL
I	02	D40576J	W0018	D40576P	W5156			ALL
I	03	D41801J	W0018	D41801P	W2101			ALL
I	05	D40802J	W0018	D40802P	W5506			ALL
I	06	D41803J	W0018	D41803P	W2175			ALL
I	07	D40830J	W0018	D40830P	W5514			ALL
I	08	D41807J	W0018	D41807P	W2651			ALL
I	09	D41809J	W0018	D41809P	W2653			ALL

### DISCONNECT BRACKET LIST

D280A351

**91-04-00**

Section AP1800

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bracket No.	Description Position	Receptacle	Bundle	Plug	Bundle	Max Pos	Station / WL / BL	Effectivity
I AP2800A	DISCONNECT BRACKET-P28 PANEL					001	724/172/R018	ALL
I	01			D48080P	W8524			ALL

### DISCONNECT BRACKET LIST

D280A351

**91-04-00**

Section AP2800

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bracket No.	Description Position	Receptacle	Bundle	Plug	Bundle	Max Pos	Station / WL / BL	Effectivity
AS0001	DISCONNECT BRACKET-FIRE WALL					010	NS175/ /	ALL
	10			D30038	W1062			ALL
AS0001L	DISCONNECT BRACKET-FIRE WALL(STRUT SIDE)					010	NS175/135/L	ALL
	01	D30260	W1168					ALL
	02	D30224	W1172					ALL
	03	D30212	W1170					ALL
	04	D30252	W1170					ALL
	05	D30220	W1166					ALL
	06	D30228	W1170					ALL
	07	D30256	W1166					ALL
	08	D30204	W1168					ALL
	09	D30234	W1164					ALL
	10	D30238	W1162					ALL
AS0001R	DISCONNECT BRACKET-FIRE WALL(STRUT SIDE)					010	NS175/135/R	ALL
	01	D30460	W1268					ALL
	02	D30424	W1272					ALL
	03	D30412	W1270					ALL
	04	D30452	W1270					ALL
	05	D30420	W1266					ALL
	06	D30428	W1270					ALL
	07	D30456	W1266					ALL
	08	D30404	W1268					ALL
	09	D30434	W1264					ALL
	10	D30438	W1262					ALL
AS0002	DISCONNECT BRACKET-LEFT SLEEVE					002	NR201/136/	ALL
	01			D30008	W1082			ALL
	02			D30002	W1080			ALL
AS0002L	DISCONNECT BRACKET-T/R LEFT STRUT					002	NS201/136/L	ALL
	01	D30208	W1168					ALL
	02	D30202	W1172					ALL
AS0002R	DISCONNECT BRACKET-T/R RIGHT STRUT					002	NS201/136/R	ALL
	01	D30408	W1268					ALL
	02	D30402	W1272					ALL

### DISCONNECT BRACKET LIST

D280A351

**91-04-00**

Section AS0000

Page 1

Jun 21/2016





## 737-800 WIRING DIAGRAM MANUAL

Bracket No.	Description Position	Receptacle	Bundle	Plug	Bundle	Max Pos	Station / WL / BL	Effectivity
I AS0003	DISCONNECT BRACKET RIGHT SLEEVE					002	NS201/136/	ALL
I	01			D30010	W1084			ALL
I	02			D30006	W1086			ALL
I AS0003L	DISCONNECT BRACKET T/R LEFT STRUT					002	NS201/136/L	ALL
I	01	D30210	W1168					ALL
I	02	D30206	W1172					ALL
I AS0003R	DISCONNECT BRACKET-T/R RIGHT STRUT					002	NS201/136/R	ALL
I	01	D30410	W1268					ALL
I	02	D30406	W1272					ALL

### DISCONNECT BRACKET LIST

D280A351

**91-04-00**

Section AS0000

Page 2 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bracket No.	Description Position	Receptacle	Bundle	Plug	Bundle	Max Pos	Station / WL / BL	Effectivity
I AW0219L	DISCONNECT BRACKET-CLOSURE RIB(L-WING)					003	LES219/ /	ALL
I AW0219R	DISCONNECT BRACKET-CLOSURE RIB(R-WING)					003	/ /	ALL
I AW0254L	DISCONNECT BRACKET-LEFT WING STA 254					002	/ /	ALL
I	01	D40024J	W1024	D40024P	W1022			YT101-YT119, YT126-YT131
I AW0254R	DISCONNECT BRACKET-RIGHT WING STA 254					002	/ /	ALL
I	01	D40034J	W1034	D40034P	W1032			YT101-YT119, YT126-YT131
I AW0258L	DISCONNECT BRACKET					006	IFSS 217/ /	ALL
I	01	D08094J	W1186	D08094P	W1162			ALL
I	02			D30040	W1174			ALL
I	02			D30042	W1172			ALL
I	03			D30082	W1176			ALL
I	03			D30084	W1168			ALL
I	04			D30014	W1184			ALL
I	04			D30016	W1164			ALL
I	05			D30062	W1182			ALL
I	05			D30064	W1166			ALL
I	06	D08056J	W1178	D08056P	W1170			ALL
I AW0258R	DISCONNECT BRACKET					006	IFSS 217/ /	ALL
I	01	D08194J	W1286	D08194P	W1262			ALL
I	02			D30140	W1274			ALL
I	02			D30142	W1272			ALL
I	03			D30182	W1276			ALL
I	03			D30184	W1268			ALL
I	04			D30114	W1284			ALL
I	04			D30116	W1264			ALL
I	05			D30162	W1282			ALL
I	05			D30164	W1266			ALL
I	06	D08156J	W1278	D08156P	W1270			ALL

### DISCONNECT BRACKET LIST

D280A351

**91-04-00**

Section AW0200

Page 1 End

Jun 21/2016



## 737-800 WIRING DIAGRAM MANUAL

Bracket No.	Description Position	Receptacle	Bundle	Plug	Bundle	Max Pos	Station / WL / BL	Effectivity
I AW0742L	DISCONNECT BRACKET-LEFT WING STA 742					002	/ /	ALL
I	1	D01695	W1024					YT101-YT119, YT126-YT131
I	2	D01699	W1024					YT101-YT119, YT126-YT131
I AW0742R	DISCONNECT BRACKET-RIGHT WING STA 742					002	/ /	ALL
I	1	D01701	W1034					YT101-YT119, YT126-YT131
I	2	D01697	W1034					YT101-YT119, YT126-YT131

### DISCONNECT BRACKET LIST

D280A351

**91-04-00**

Section AW0700

Page 1 End

Jun 21/2016