


Flying Squad Vehicle Do's & Don'ts

CHECK LIST ITEM	
• Installation	
• Battery	• 4mm SQUARE 2 CORE Cable for Battery Connection
• BATTERY TERMINAL	• PTZ Antenna
• GPS With Sim and Cable	• PTZ STEEL PLATE
• DC to AC Converter	• 1.5mm Square Cable for PTZ Camera
• Electric Power Strip (6+1)	• Cable Tie 6 for internal Cable Fitting
• PTZ Camera + Power Supply	• 1mm Square 3 core cable for LCD power cable
• NVR with HDD + Adapter	• LAN cable (10 mtr)
• Internet Router + Adapter	• LAN cable (5 mtr)
• SIM Card	• LCD Stand
• LCD + Adapter	• VGA Cable

Troubleshooting

- First take power from battery
- Connect DC to AC Converter to Battery
- Attach Power strip to DC to AC Converter
- After connection power strip connect camera and turn ON Camera and open NVR After than you will see the camera on LCD
- Once you plug the router it's LED light should stable for 2 LAN cable and power.
- Do not press a Black switch behind the router. Do not remove LAN Cable from anywhere.
- Once you ON the Camera and see view on LCD please make sure it has recording symbol of RED COLOR 
- If your LCD, NVR or router restart then wait for camera view and check recording symbol.
- For PTZ moment you must right click and select PTZ Control option.
- To check power first check light of DC to AC Converter, then check power strip light.
- Don't Stop vehicle more than 30 minutes at any place.
- Speed limit for VAN will be 20 to 20 km
- When Power is OFF check convert light and connection.
- Don't touch GPS cable.
- To check Laptop charging status from DC, click on notification from laptop battery
- Don't mix or joint + and – of battery
- GPS indicate 3 Line that it's working properly

Car Do's

- While starting VAN check proper fuel is there in vehicle
- Check all the camera, power adapters and dc pin.
- How to rotate camera, how to focus on incident

Car Don'ts

- Driver should try to avoid bumps: While VAN roaming around city driver should avoid bumps and keep moving the vehicle
- What to do if video jerks on screen: While video jerks' driver should slow down the vehicle
- How to tighten screws of camera & clamp: For Camera mount stand and camera make sure it's screw is tighten before driver start his vehicle every day.

PUNJABI

ਫਲਾਇੰਗ ਸਕੂਐਡ ਵਹੀਕਲ ਕੀ ਕਰਨਾ ਅਤੇ ਕੀ ਨਹੀਂ

ਸੂਚੀ ਆਈਟਮ ਦੀ ਜਾਂਚ ਕਰੋ

- ਇੰਸਟਾਲੇਸ਼ਨ • ਪਾਵਰ ਸਟ੍ਰਿਪ
- ਬੈਟਰੀ • NVR + ਸਾਫਟਵੇਅਰ
- 4mm ਕੇਬਲ • ਕੈਮਰਾ + ਚਾਰਜਰ
- DC ਤੋਂ AC ਪਰਿਵਰਤਕ • LCD + ਚਾਰਜਰ
- ਰਾਊਟਰ + ਚਾਰਜਰ + LAN ਕੇਬਲ • ਸਿਮ ਕਾਰਡ

ਸਮੱਸਿਆ ਨਿਪਟਾਰਾ

- ਪਹਿਲਾਂ ਬੈਟਰੀ ਤੋਂ ਪਾਵਰ ਲਓ
- DC ਤੋਂ AC ਕਨਵਰਟਰ ਨੂੰ ਬੈਟਰੀ ਨਾਲ ਕਨੈਕਟ ਕਰੋ
- ਪਾਵਰ ਸਟ੍ਰਿਪ ਨੂੰ DC ਤੋਂ AC ਕਨਵਰਟਰ ਨਾਲ ਜੋੜੋ
- ਪਾਵਰ ਸਟ੍ਰਿਪ ਕੁਨੈਕਸ਼ਨ ਤੋਂ ਬਾਅਦ ਕੈਮਰਾ ਕਨੈਕਟ ਕਰੋ ਅਤੇ ਕੈਮਰਾ ਚਾਲੂ ਕਰੋ ਅਤੇ NVR ਖੋਲ੍ਹੋ ਇਸ ਤੋਂ ਬਾਅਦ ਤੁਸੀਂ LCD 'ਤੇ ਕੈਮਰਾ ਦੇਖੋਗੇ।

- ਇੱਕ ਵਾਰ ਜਦੋਂ ਤੁਸੀਂ ਰਾਊਟਰ ਨੂੰ ਪਲੱਗ ਕਰਦੇ ਹੋ ਤਾਂ ਇਸਦੀ LED ਲਾਈਟ 2 LAN ਕੇਬਲ ਅਤੇ ਪਾਵਰ ਲਈ ਸਥਿਰ ਹੋਣੀ ਚਾਹੀਦੀ ਹੈ।
- ਰਾਊਟਰ ਦੇ ਪਿੱਛੇ ਕਾਲੇ ਸਵਿੱਚ ਨੂੰ ਨਾ ਦਬਾਓ। LAN ਕੇਬਲ ਨੂੰ ਕਿਤੇ ਵੀ ਨਾ ਹਟਾਓ।
- ਇੱਕ ਵਾਰ ਜਦੋਂ ਤੁਸੀਂ ਕੈਮਰਾ ਚਾਲੂ ਕਰਦੇ ਹੋ ਅਤੇ LCD 'ਤੇ ਦ੍ਰਿਸ਼ ਦੇਖਦੇ ਹੋ ਤਾਂ ਕਿਰਪਾ ਕਰਕੇ ਯਕੀਨੀ ਬਣਾਓ ਕਿ ਇਸ ਵਿੱਚ ਲਾਲ ਰੰਗ ਦਾ ਰਿਕਾਰਡਿੰਗ ਚਿੰਨ੍ਹ ਹੈ
- ਜੇਕਰ ਤੁਹਾਡਾ LCD, NVR ਜਾਂ ਰਾਊਟਰ ਰੀਸਟਾਰਟ ਹੁੰਦਾ ਹੈ ਤਾਂ ਕੈਮਰਾ ਦ੍ਰਿਸ਼ ਦੀ ਉਡੀਕ ਕਰੋ ਅਤੇ ਰਿਕਾਰਡਿੰਗ ਚਿੰਨ੍ਹ ਦੀ ਜਾਂਚ ਕਰੋ।
- PTZ ਪਲ ਲਈ ਤੁਹਾਨੂੰ ਸੱਜਾ ਕਲਿੱਕ ਕਰਨਾ ਚਾਹੀਦਾ ਹੈ ਅਤੇ PTZ ਕੰਟਰੋਲ ਵਿਕਲਪ ਚੁਣਨਾ ਚਾਹੀਦਾ ਹੈ।
- ਪਾਵਰ ਦੀ ਜਾਂਚ ਕਰਨ ਲਈ ਪਹਿਲਾਂ DC ਤੋਂ AC ਕਨਵਰਟਰ ਦੀ ਲਾਈਟ ਚੈੱਕ ਕਰੋ, ਫਿਰ ਪਾਵਰ ਸਟ੍ਰਿਪ ਲਾਈਟ ਦੀ ਜਾਂਚ ਕਰੋ।
- ਕਿਸੇ ਵੀ ਥਾਂ 'ਤੇ ਵਾਹਨ ਨੂੰ 30 ਮਿੰਟਾਂ ਤੋਂ ਵੱਧ ਨਾ ਰੋਕੋ।
- ਵੈਨ ਲਈ ਸਪੀਡ ਸੀਮਾ 20 ਤੋਂ 20 ਕਿਲੋਮੀਟਰ ਹੋਵੇਗੀ
- ਜਦੋਂ ਪਾਵਰ ਬੰਦ ਹੋਵੇ ਤਾਂ ਕਨਵਰਟ ਲਾਈਟ ਅਤੇ ਕਨੈਕਸ਼ਨ ਦੀ ਜਾਂਚ ਕਰੋ।
- GPS ਕੇਬਲ ਨੂੰ ਨਾ ਛੂਹੋ।
- DC ਤੋਂ ਲੈਪਟਾਪ ਚਾਰਜਿੰਗ ਸਥਿਤੀ ਦੀ ਜਾਂਚ ਕਰਨ ਲਈ, ਲੈਪਟਾਪ ਬੈਟਰੀ ਤੋਂ ਸੂਚਨਾ 'ਤੇ ਕਲਿੱਕ ਕਰੋ
- ਬੈਟਰੀ ਨੂੰ + ਅਤੇ - ਨੂੰ ਮਿਲਾਓ ਜਾਂ ਜੋੜੋ ਨਾ
- GPS 3 ਲਾਈਨ ਦਰਸਾਉਂਦਾ ਹੈ ਕਿ ਇਹ ਸਹੀ ਢੰਗ ਨਾਲ ਕੰਮ ਕਰ ਰਹੀ ਹੈ

ਕਾਰ ਕਰੋ

- ਵੈਨ ਸ਼ੁਰੂ ਕਰਦੇ ਸਮੇਂ ਜਾਂਚ ਕਰੋ ਕਿ ਵਾਹਨ ਵਿੱਚ ਸਹੀ ਬਾਲਣ ਹੈ
- ਸਾਰੇ ਕੈਮਰੇ, ਪਾਵਰ ਅਡਾਪਟਰ ਅਤੇ ਡੀਸੀ ਪਿੰਨ ਦੀ ਜਾਂਚ ਕਰੋ।
- ਕੈਮਰੇ ਨੂੰ ਕਿਵੇਂ ਘੁੰਮਾਉਣਾ ਹੈ, ਘਟਨਾ 'ਤੇ ਕਿਵੇਂ ਫੋਕਸ ਕਰਨਾ ਹੈ

ਕਾਰ ਨਹੀਂ

- ਡਰਾਈਵਰ ਨੂੰ ਟੱਕਰਾਂ ਤੋਂ ਬਚਣ ਦੀ ਕੋਸ਼ਿਸ਼ ਕਰਨੀ ਚਾਹੀਦੀ ਹੈ: ਵੈਨ ਸ਼ਹਿਰ ਦੇ ਆਲੇ-ਦੁਆਲੇ ਘੁੰਮਦੇ ਹੋਏ ਡਰਾਈਵਰ ਨੂੰ ਬੰਪਰਾਂ ਤੋਂ ਬਚਣਾ ਚਾਹੀਦਾ ਹੈ ਅਤੇ ਵਾਹਨ ਚਲਾਉਂਦੇ ਰਹਿਣਾ ਚਾਹੀਦਾ ਹੈ।
- ਜੇਕਰ ਵੀਡੀਓ ਸਕਰੀਨ 'ਤੇ ਝਟਕਾ ਦਿੰਦੀ ਹੈ ਤਾਂ ਕੀ ਕਰਨਾ ਹੈ: ਜਦੋਂ ਵੀਡੀਓ ਝਟਕਾ ਦੇਣ ਵਾਲੇ ਡਰਾਈਵਰ ਨੂੰ ਵਾਹਨ ਨੂੰ ਹੌਲੀ ਕਰਨਾ ਚਾਹੀਦਾ ਹੈ
- ਕੈਮਰੇ ਅਤੇ ਕਲੈੱਪ ਦੇ ਪੇਚਾਂ ਨੂੰ ਕਿਵੇਂ ਕੱਸਣਾ ਹੈ: ਕੈਮਰਾ ਮਾਊਂਟ ਸਟੈਂਡ ਅਤੇ ਕੈਮਰੇ ਲਈ ਇਹ ਯਕੀਨੀ ਬਣਾਓ ਕਿ ਡਰਾਈਵਰ ਹਰ ਰੋਜ਼ ਆਪਣਾ ਵਾਹਨ ਚਾਲੂ ਕਰਨ ਤੋਂ ਪਹਿਲਾਂ ਇਹ ਪੇਚ ਨੂੰ ਕੱਸਦਾ ਹੈ।