

Case termination

Table of Contents

Steady state

Transient

By default, cases will run until the time settings are achieved in the case **controlDict** dictionary. Alternatively, the `residualControl` object can be added to the **fvSolution** dictionary to enable additional controls. This operates in two modes:

Steady state

To terminate the case when the initial residual of the field equations falls below user-specified threshold values for SIMPLE-based solvers:

```
residualControl
{
    p                1e-2;
    "(Ux Uy)"        1e-4;
    "(k|epsilon|omega)" 1e-4;
}
```

Transient

To control the number of outer corrector iterations for PIMPLE-based solvers:

```
// Maximum number of outer correctors
nOuterCorrectors    50;

residualControl
{
    "(U|k|epsilon|omega)"
    {
        relTol        0;
        tolerance      1e-4;
    }
}
```

Would you like to suggest an improvement to this page?

Create an issue

Copyright © 2016-2017 OpenCFD Ltd.

Licensed under the Creative Commons License BY-NC-ND  [Creative Commons License](https://creativecommons.org/licenses/by-nc-nd/4.0/)

