

210- *LineTest Management Commands*

210.1 LineTest Management Command Tree	210-7216
210.2 MELT reset Status Command	210-7217
210.3 MELT Selftest Status Command	210-7218

210.1 LineTest Management Command Tree

Description

This chapter gives an overview of nodes that are handled by "LineTest Management Commands".

Command Tree

```
----admin
  ----linetest
    ----single
      - (if-index)
      - melt-reset
      ----melt-selftest
        - (self-test-status)
```

210.2 MELT reset Status Command

Command Description

This command is to triggers the reset operation on MELT board.

User Level

The command can be accessed by operators with sip , xdsl privileges, and executed by operators with sip , xdsl privileges.

Command Syntax

The command has the following syntax:

```
> admin linetest single (if-index) melt-reset <LineTest::ResetStatus>
```

Command Parameters

Table 210.2-1 "MELT reset Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> Possible values: - lt : lt-slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number	interface index of the port

Table 210.2-2 "MELT reset Status Command" Command Parameters

Parameter	Type	Description
melt-reset	Parameter type: <LineTest::ResetStatus> Format: resetstart Possible values: - resetstart : the MELT reset operation is triggered	<i>optional parameter</i> Trigger the reset operation on the MELT board.

210.3 MELT Selftest Status Command

Command Description

This command is to triggers the self test operation on MELT board.

User Level

The command can be accessed by operators with sip , xdsl privileges, and executed by operators with sip , xdsl privileges.

Command Syntax

The command has the following syntax:

> admin linetest single (if-index) melt-selftest (self-test-status)

Command Parameters

Table 210.3-1 "MELT Selftest Status Command" Resource Parameters

Resource Identifier	Type	Description
(if-index)	Format: lt : <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> Possible values: - lt : lt-slot Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number	interface index of the port

Table 210.3-2 "MELT Selftest Status Command" Command Parameters

Parameter	Type	Description
(self-test-status)	Format: teststart Possible values: - teststart : test start state	<i>optional parameter</i> Trigger the selftest operation on the MELT board.