

201- *Distributed Service Management Commands*

201.1 Distributed Service Management Command Tree	201-7152
201.2 APIPE-PVC Statistics Command	201-7153

201.1 Distributed Service Management Command Tree

Description

This chapter gives an overview of nodes that are handled by "Distributed Service Management Commands".

Command Tree

```
----admin
  ----dist-service
    ----statistics
      ----apipe-pvc
        - (port-index)
        - (clear)
```

201.2 APIPE-PVC Statistics Command

Command Description

This command is to reset the APIPE-PVC statistics counters.

User Level

The command can be executed by operators with drouter privileges.

Command Syntax

The command has the following syntax:

```
> admin dist-service statistics apipe-pvc (port-index) (clear)
```

Command Parameters

Table 201.2-1 "APIPE-PVC Statistics Command" Resource Parameters

Resource Identifier	Type	Description
(port-index)	Format: <Eqpt::RackId> / <Eqpt::ShelfId> / <Eqpt::SlotId> / <Eqpt::PortId> : <Eqpt::VpiMandatoryId> : <Eqpt::VciMandatoryId> Field type <Eqpt::RackId> - the rack number Field type <Eqpt::ShelfId> - the shelf number Field type <Eqpt::SlotId> - the LT slot number Field type <Eqpt::PortId> - the port number Field type <Eqpt::VpiMandatoryId> - atm VPI Field type <Eqpt::VciMandatoryId> - atm VCI	the ATM PVC

Table 201.2-2 "APIPE-PVC Statistics Command" Command Parameters

Parameter	Type	Description
(clear)	Format: clear Possible values: - clear : reset statistics counters	<i>optional parameter</i> optional parameter reset APIPE-PVC counters