

217- Protection Group Management Commands

| | |
|--|----------|
| 217.1 Protection Group Management Command Tree | 217-7255 |
| 217.2 Protection Group NT switchover Command | 217-7256 |

217.1 Protection Group Management Command Tree

Description

This chapter gives an overview of nodes that are handled by "Protection Group Management Commands".

Command Tree

```
----admin
  ----equipment
    ----protection-group
      - (prot-group-id)
      - [no] switchover
```

217.2 Protection Group NT switchover Command

Command Description

This command allows the operator to switchover in protection group of NT

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> admin equipment protection-group (prot-group-id) [ [ no ] switchover ]
```

Command Parameters

Table 217.2-1 "Protection Group NT switchover Command" Resource Parameters

| Resource Identifier | Type | Description |
|---------------------|--|-----------------------------|
| (prot-group-id) | Format: - index of protection group - range: [1...109] | Index in NT ProtGroup Table |

Table 217.2-2 "Protection Group NT switchover Command" Command Parameters

| Parameter | Type | Description |
|-----------------|-------------------------|--|
| [no] switchover | Parameter type: boolean | <i>optional parameter</i> NT switchover |