

78- CLI Alias Configuration Command

78.1 CLI Alias Configuration Command Tree
78.2 CLI Alias Configuration Command

78-1882
78-1883

78.1 CLI Alias Configuration Command Tree

Description

This chapter gives an overview of nodes that are handled by "CLI Alias Configuration Command".

Command Tree

```
----configure
----[no] alias
  - (name)
  - (value)
```

78.2 CLI Alias Configuration Command

Command Description

This command allows the operator to configure CLI alias commands for the system.

Alias names may not match any of the reserved cli node keywords. Alias names may not contain whitespace or chars '?' or '#'. Alias names may not match an existing alias value.

Alias values may not contain chars '?' or '#'. '\n' or '\r' are disallowed unless they are used within literal string parameters. An alias value may not match an existing alias name.

Cli command parameters entered as part of the alias value will not be validated until the alias is executed.

The order of the displayed alias commands when executing the 'info configure alias' command does not persist after an NT switchover or reset.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

> configure alias (name) (value)

Command Parameters

Table 78.2-1 "CLI Alias Configuration Command" Resource Parameters

Resource Identifier	Type	Description
(name)	Format: - alias name for the command - range: [a-z0-9] - length: 2<=x<=8	alias name

Table 78.2-2 "CLI Alias Configuration Command" Command Parameters

Parameter	Type	Description
(value)	Format: - command string for alias - length: 2<=x<=128	<i>mandatory parameter</i> command string for alias