

# **76- BCMP Configuration Commands**

---

76.1 BCMP Configuration Command Tree  
76.2 BCMP system Configuration Commands

76-1861  
76-1862

## 76.1 BCMP Configuration Command Tree

### Description

This chapter gives an overview of nodes that are handled by "BCMP Configuration Commands".

### Command Tree

```
----configure
  ----bcmp
    ----system
      - [no] adminstate
      - [no] serveripaddr
      - [no] serverudpport
```

## 76.2 BCMP system Configuration Commands

### Command Description

*This command allows the operator to manage the BCMP system parameters.*

### User Level

*The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.*

### Command Syntax

The command has the following syntax:

```
> configure bcmp system [ no adminstate | adminstate <bcmp::bcmpAdminState> ] [ no serveripaddr | serveripaddr <Ip::V4Address> ] [ no serverudpport | serverudpport <bcmp::bcmpServerUdpPort> ]
```

### Command Parameters

**Table 76.2-2 "BCMP system Configuration Commands" Command Parameters**

Parameter	Type	Description
[no] adminstate	Parameter type: <bcmp::bcmpAdminState> Format: ( enable-bcmp   disable-bcmp ) Possible values: - enable-bcmp : start bcmp protocol handling in the system - disable-bcmp : stop bcmp protocol handling in the system	<i>optional parameter with default value: "disable-bcmp"</i> the switch to specify the admin state of BCMP subsystem
[no] serveripaddr	Parameter type: <Ip::V4Address> Format: - IPv4-address	<i>optional parameter with default value: "192.168.100.100"</i> the IP address of BCMP server
[no] serverudpport	Parameter type: <bcmp::bcmpServerUdpPort> Format: - the Bcmp Server Udp port - range: [1...65535]	<i>optional parameter with default value: 5000</i> the Socket UDP port of BCMP server