

80- Cwmp platform Configuration Commands

80.1 Cwmp platform Configuration Command Tree
80.2 Cwmp Platform Configuration Commands

80-1888
80-1889

80.1 Cwmp platform Configuration Command Tree

Description

This chapter gives an overview of nodes that are handled by "Cwmp platform Configuration Commands".

Command Tree

```
----configure
  ----cwmp
    ----plt
      - [no] adminstate
```

80.2 Cwmp Platform Configuration Commands

Command Description

This command configure cwmp platform for nat function.

Note: Once the remaining-lease timer has expired, esponding user interface.

User Level

The command can be accessed by operators with xdsl privileges, and executed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

```
> configure cwmp plt [ no adminstate | adminstate <CWMP::AdminStatus> ]
```

Command Parameters

Table 80.2-2 "Cwmp Platform Configuration Commands" Command Parameters

Parameter	Type	Description
[no] adminstate	Parameter type: <CWMP::AdminStatus> Format: (unlocked locked) Possible values: - unlocked : the identified resource is allowed to be used - locked : the identified resource is not allowed to be used	<i>optional parameter with default value: "locked"</i> enable or disable the cwmp platform