

NOTE:
INSTALL LIMIT SWITCH AT CLOSED POSITION OF VALVE
AND CONNECT TO (N.O.) NORMALLY OPENED CONTACT.

