


# Main Menu Bar

# Main Menu Bar



# Home

# Home

Home

Schedule Installation  
for multiple hosts

14 Schedule Batch Installs

Information

CSM Server	
Server Time	05/13/2015 12:21 PM
Version	1.0
Login User	root
Privilege	Admin

Total Managed Hosts: 41		
Platform	Software	# Host
asr9k-px	4.3.1	1
asr9k-px	4.3.4	1
asr9k-px	5.1.1.53U	1
asr9k-px	5.1.1	1

Managed Hosts

Jump Servers

Regions

Server Repositories

Create

Filter

10 records per page

Search:

Hostname	Region	TS or IP	Platform	Software	Last Successful Retrieval	Action
9010 Cluster (dsegovia)		185 172.28.22.23	ASR9K	5.1.1 (asr9k-px)	78d 11h 20m ago	Install
ASR9K-PE3	Cisco Telecom West Coast	172.28.98.6	ASR9K	5		Install
ASR9K-PE4	Cisco Telecom West Coast	172.28.98.3	ASR9K	4.3.4 (asr9k-px)	12h 20m 46s ago	Install
ASR9K-PE5	Cisco Telecom West Coast	172.28.98.5	ASR9K	5.1.3 (asr9k-px)	12h 20m 23s ago	Install

Showing 1 to 10 of 41 entries

← Previous

1

2

3

4

5

Next →

Number of  
Managed Hosts

Edit Host

Host that Failed Last  
Software Retrieval

Page Navigation

# Home Tab Options



Managed Hosts

Jump Servers

Regions

Server Repositories

Create ▾

## ▪ Managed Hosts

- Managed hosts are Cisco IOS-XR devices on which scheduling tasks can be performed.
- Each row represents one Cisco device.

## ▪ Jump Servers (Optional)

- A jump server is the server that CSM logs into in order to connect to the managed hosts.
- Many service provider environments place their devices behind a jump server. CSM first logs into the jump server, then to the router.

## ▪ Regions

- A region is mapped to multiple server repositories.
- All devices from the same region share the same set of TFTP, FTP, SFTP servers.

## ▪ Server Repositories

- Where you define the TFTP, FTP, and SFTP server repositories.

## ▪ Create

- Where you go to create managed hosts, jump servers, regions, and server repositories.

# Create a Server Repository

- Specify a unique server repository name.
- Select a server type for the server repository where the software packages reside.
- For TFTP server, specify the TFTP server path (e.g. tftp://202.153.144.25/auto/tftpboot). A TFTP server path usually has a corresponding Unix file directory (e.g. /auto/tftpboot). Specify that directory in the File Directory so that CSM Server can browse the software packages.
- For FTP/SFTP server, specify the FTP/SFTP server address (e.g. [ftp.easycgi.com](http://ftp.easycgi.com) or an IP address). If applicable, specify the remote directory. The remote directory is optional and should be relative to the default directory where FTP/SFTP client first connects.
- When scheduling an install, CSM Server uses this server repository information to provide the file and directory browsing function.

## Create Server Repository

Server Repository Name

East Coast TFTP

Server Type

TFTP ▼

TFTP Server Path

tftp://202.153.144.25/auto/tftpboot

File Directory (Used by CSM Server)

/auto/tftpboot

Check Reachability

Save

Cancel

## Create Server Repository

Server Repository Name

West Coast FTP

Server Type

FTP ▼

FTP Server Address

172.20168.19

Remote Directory

Username

johnsmith

Password

.....



Check Reachability

Save

Cancel

# Create a Region

- Specify a unique region name.
- Assign server repositories to the region.
- When creating a new host, a region is attached to the host.
- When scheduling an install, CSM Server uses the host's region to lookup server repositories and provide the file and directory browsing function.

### Edit Region

**Region Name**

### Server Repositories

**Available Servers** - showing 28

ACE server

Alberto ftp

BJ-RP-FTP

Cisco Telecom East Coast TFTP zeppelin-3

Cisco Telecom East Coast TFTP zeppelin-5

Dennis TFTP

Dsegovia Bldg 20

SJ20-4\_3\_1-CCO

SJ20-4\_3\_2-CCO

SJ20-4\_3\_4-CCO

≡ >

>

<

< ≡

**Selected Servers** - showing 11

Alex TFTP Server

Dsegovia Bldg 18

Eddie SFTP

SJ18-4\_3\_1-CCO

SJ18-4\_3\_2-CCO

SJ18-4\_3\_4-CCO

SJ18-5\_1\_1-CCO

SJ18-5\_1\_2-CCO

SJ18-5\_1\_3-CCO

SJ18-5\_2\_0-CCO

Save

Cancel

# Create a Jump Server

- Specify a unique jump server name.
- Specify a connection type.
- Specify a sever name or the IP address of the server.
- Specify a telnet or ssh port number.
- A jump server may be assigned to a managed host if the managed host is behind the jump server.

## Create Jump Server

Server Name

sj20lab-as1

## Connection Parameters

Connection Type

telnet ▼

Server or IP

sj20lab-as1


Port Number

Leave Blank for Default

Username

root

Password

..... 

Check Reachability

Save

Cancel



# Create a Host

- Specify a unique host name.
- Select a platform and region for the managed host. Optionally, you may specify the role of the device. This will enable further filtering when creating batch schedule installs.
- If the device is attached to a terminal server, specify the terminal server IP.
- If the device is on the management network, specify the management IP.
- Multiple management IPs (i.e. RSP0 and RSP1) can be entered in the Terminal Server or Mgmt. IP field. Use a comma as the delimiter.
- Multiple terminal server ports can be entered in the Port Number field. Use a comma as the delimiter.

## Create Host

Hostname	<input type="text" value="ASR9-PE2-R1"/>
Platform	<input type="text" value="ASR9K"/>
Region	<input type="text" value="Pleasanton"/>
Roles	<input type="text" value="PE Router"/>

## Connection Parameters

Connection Type	<input type="text" value="telnet"/>
Terminal Server or Mgmt. IP	<input type="text" value="172.27.82.122"/>
Port Number	<input type="text" value="Leave Blank for Default"/>
Username	<input type="text" value="root"/>
Password	<input type="password" value="...."/>
Jump Server	<input type="text" value="None"/>

# Connect via Host Console Port

When a host console port is used for the connection, the syslog logging on the console should be disabled. Otherwise, it will interfere with the CSM Server operations as it interacts with the device.

- **To disable logging**
  - RP/0/RSP0/CPU0:GW# config
  - RP/0/RSP0/CPU0:GW(config)# logging console disable
  - RP/0/RSP0/CPU0:GW(config)# commit