



TALLY SHEET



T00AT5BE

Check Name:

HM-WP-MHE-09NOV2016-01 [C6+Redelivery] MPD

Work Order No:

WO - 85597080

Station:

AUH/ADAT HGR

Start Date:

09-Nov-2016 16:06

Aircraft:

A320-200 - PR-MHE

Flight Hours:

TSN: 34714,56

TSO: 34714,56

Flight Cycles:

CSN: 22753

CSO: 22753

Task List

Line	Zone	Task Name	Barcode	Checked
1	334,344	200002-01-1-INSP(JIC) (GENERAL VISUAL INSPECTION OF ELEMENTS FITTED ON THE FOLLOWING HARNESSSES :- 405VB, 406VB, 407VB, 408VB, 409VB, LH SIDE- 400VB, 401VB, 402VB, 403VB, 404VB, RH SIDE)	T0099BRL	
2	334,344	200002-01-1-REINS(JIC) (GENERAL VISUAL INSPECTION OF ELEMENTS FITTED ON THE FOLLOWING HARNESSSES: 400VB, 401VB, 402VB, 403VB, 404VB, 405VB, 406VB, 407VB, 408VB, 409VB)	T0099BRN	
3	334,344	200002-01-1-REM(JIC) (GENERAL VISUAL INSPECTION OF ELEMENTS FITTED ON THE FOLLOWING HARNESSSES: 400VB, 401VB, 402VB, 403VB, 404VB, 405VB, 406VB, 407VB, 408VB, 409VB)	T0099BRM	
4	121,122	200121-01-1-CLN(JIC) (CLEANING OF ALL WIRING INSTALLED IN THE FORWARD AVIONIC COMPARTMENT (ONLY CONTAMINATED WIRING))	T0098BT0	
5	127,128	200127-04-1-INSP(JIC) (GENERAL VISUAL INSPECTION OF ALL WIRING INSTALLED IN THE REAR AVIONIC COMPARTMENT)	T0099BSC	
6	316,315	200315-01-1-INSP(JIC) (GENERAL VISUAL INSPECTION OF G AND P ROUTE WIRING INSTALLED IN THE TAIL CONE AND APU ACCESSORY COMPARTMENT)	T0098BS4	
7	413,414	200413-01-1-ENG1-INSP(JIC) (DETAILED INSPECTION OF ALL WIRING INSTALLED IN THE UPPER FORWARD PYLON)	T0098BS8	
8	413,414	200413-01-1-ENG1-REINS(JIC) (DETAILED INSPECTION OF ALL WIRING INSTALLED IN THE UPPER FORWARD PYLON)	T0098BS7	
9	413,414	200413-01-1-ENG1-REM(JIC) (DETAILED INSPECTION OF ALL WIRING INSTALLED IN THE UPPER FORWARD PYLON)	T0098BS6	
10	424,423	200413-01-1-ENG2-INSP(JIC) (DETAILED INSPECTION OF ALL WIRING INSTALLED IN THE UPPER FORWARD PYLON)	T0098BSC	
11	424,423	200413-01-1-ENG2-REINS(JIC) (DETAILED INSPECTION OF ALL WIRING INSTALLED IN THE UPPER FORWARD PYLON)	T0098BSB	
12	423,424	200413-01-1-ENG2-REM(JIC) (DETAILED INSPECTION OF ALL WIRING INSTALLED IN THE UPPER FORWARD PYLON)	T0098BSA	
13	435,436	200435-01-1-ENG1-INSP-CFM(JIC) (DETAILED INSPECTION OF EWIS IN THE FAN AND ACCESSORY GEAR BOX (EWIS))	T0098BT2	

T00AT5BE

14	445,446	200435-01-1-ENG2-INSP-CFM(JIC) (DETAILED INSPECTION OF EWIS IN THE FAN AND ACCESSORY GEAR BOX (EWIS))	T0098BT7	
15	453,454	200453-01-1-2-ENG1-INSP(JIC) (DETAILED INSPECTION OF ALL WIRING INSTALLED IN THE HOT SECTION)	T009R1YB	
16	453,454	200453-01-1-2-ENG1-REINS(JIC) (DETAILED INSPECTION OF ALL WIRING INSTALLED IN THE HOT SECTION)	T0098BT4	
17	454,453	200453-01-1-2-ENG1-REM1(JIC) (DETAILED INSPECTION OF ALL WIRING INSTALLED IN THE HOT SECTION)	T0098BT5	
18	463,464	200453-01-1-2-ENG2-INSP(JIC) (DETAILED INSPECTION OF ALL WIRING INSTALLED IN THE HOT SECTION)	T0098BTB	
19	453,454	200453-01-1-2-ENG2-REINS(JIC) (DETAILED INSPECTION OF ALL WIRING INSTALLED IN THE HOT SECTION)	T0098BTA	
20	453,454	200453-01-1-2-ENG2-REM1(JIC) (DETAILED INSPECTION OF ALL WIRING INSTALLED IN THE HOT SECTION)	T0098BT9	
21	,300,573,	202800-01-1-INSP(JIC) (DETAILED INSPECTION OF BONDING LEADS LOCATED ON THE FOLLOWING MOVABLE SURFACES: ELEVATOR, RUDDER, FLAPS, FLAP TRACK FAIRINGS, SLATS, SPOILERS, AILERONS, LANDING GEAR DOORS AND PASSENGER/CREW DOORS)	T0098BUR	
22	210	212600-02-1-OP(JIC) (OPERATIONAL CHECK OF OVERRIDE FUNCTION (BLOWER AND EXTRACT))	T0099C0A	
23	210	212600-03-1-OP(JIC) (OPERATIONAL CHECK OF SMOKE CONFIGURATION CONTROL CIRCUIT)	T00ADMKN	
24	210	212600-04-1-OP(JIC) (OPERATIONAL CHECK OF DITCHING CONFIGURATION CONTROL CIRCUIT)	T0099C0E	
25	127	212600-08-1-OP(JIC) (OPERATIONAL CHECK OF AIR INLET CHECK VALVE 2150 HM)	T009YSV0	
26	210	213100-01-1-OP(JIC) (OPERATIONAL CHECK OF SYSTEM VIA MCDU)	T0099BSS	
27	210	213100-02-1-OP(JIC) (OPERATIONAL CHECK OF MANUAL MODE SELECTION AND MANUAL MODE PRESSURE CONTROL AND FUNCTIONAL CHECK OF MANUAL MODE CABIN ALTITUDE INDICATION AND OUTFLOW VALVE POSITION INDICATION)	T0099BSU	
28	190	215000-03-2-INSP(JIC) (DETAILED INSPECTION OF ACTUATOR MECHANISM AND INLET FLAP FOR EXCESSIVE PLAY AND CHECK GAP BETWEEN INLET NOSE AND DIFFUSER RAMP)	T0099BTM	
29	191,192	215222-01-1-1-INSP(JIC) (DETAILED INSPECTION OF INTERIOR AND EXTERIOR OF PLENUM CHAMBER (10HM5 AND 11HM5) FOR SIGNS OF DELAMINATION)	T0099BT7	
30	191,192	215222-01-1-FC(JIC) (DETAILED INSPECTION OF INTERIOR AND EXTERIOR OF PLENUM CHAMBER (10HM5 AND 11HM5) FOR SIGNS OF DELAMINATION)	T0099BT5	
31	191,192	215222-01-1-INST(JIC) (DETAILED INSPECTION OF INTERIOR AND EXTERIOR OF PLENUM CHAMBER (10HM5 AND 11HM5) FOR SIGNS OF DELAMINATION)	T0099BT4	
32	191,192	215222-01-1-REM(JIC) (DETAILED INSPECTION OF INTERIOR AND EXTERIOR OF PLENUM CHAMBER (10HM5 AND 11HM5) FOR SIGNS OF DELAMINATION)	T0099BT6	
33	210	215500-01-1-OP(JIC) (OPERATIONAL CHECK OF EMERGENCY RAM AIR INLET SYSTEM)	T0099BTD	
34	210	215500-02-1-OP(JIC) (OPERATIONAL CHECK OF EMERGENCY RAM AIR INLET AND FLOWCONTROL VALVE CLOSING IN DITCHING CONFIGURATION)	T0099BTF	
35	200	216000-01-1-INSP(JIC) (CLEANING OF CABIN SENSOR DUCT AND TEMPERATURE SENSOR.)	T0099C29	
36	130	216000-03-2-SVC(JIC) (DISCARD TRIM AIR PRESSURE REGULATING VALVE FILTER)	T00AEPXD	

T00AT5BE

37	191	216242-01-1-1-INSP(JIC) (DETAILED INSPECTION OF TRIM AIR CHECK VALVES FLAPPERS FOR CONDITION AND OPERATION)	T009P7F5	
38	210	221000-01-1-OP(JIC) (OPERATIONAL CHECK OF AP DISENGAGEMENT AND LOCKING DEVICES OF SIDE STICK CONTROLLER AND RUDDER PEDALS)	T00ADMBE	
39	210	235100-01-1-OP(JIC) (OPERATIONAL CHECK OF CAPT AND F/O AUDIO CONTROL PANELS SWITCHING TO THIRD AUDIO CONTROL PANEL)	T0098C9X	
40	210	237100-01-1-OP(JIC) (OPERATIONAL CHECK OF CVR AND CVR-CHANNEL RECORDING)	T009WRNR	
41	210	237100-02-1-OP(JIC) (OPERATIONAL CHECK OF CVR RECORDING LOGIC INCLUDING TIME DELAY RELAY)	T0098CA1	
42	312	237135-02-1-OP(JIC) (OPERATIONAL CHECK OF ULB)	T0098CA3	
43	521	240000-04-1-LH-INSP(JIC) (APPLY TEMPORARY PROTECTION TO END FITTINGS OF ELECTRICAL CONDUITS IN WING INBOARD LEADING EDGE)	T0098BTD	
44	521	240000-04-1-LH-SVC(JIC) (APPLY TEMPORARY PROTECTION TO END FITTINGS OF ELECTRICAL CONDUITS IN WING INBOARD LEADING EDGE)	T0098BTE	
45	621	240000-04-1-RH-INSP(JIC) (APPLY TEMPORARY PROTECTION TO END FITTINGS OF ELECTRICAL CONDUITS IN WING INBOARD LEADING EDGE)	T0098BTR	
46	621	240000-04-1-RH-SVC(JIC) (APPLY TEMPORARY PROTECTION TO END FITTINGS OF ELECTRICAL CONDUITS IN WING INBOARD LEADING EDGE)	T0098BTS	
47	522	240000-05-1-LH-INSP(JIC) (APPLY TEMPORARY PROTECTION TO END FITTINGS OF ELECTRICAL CONDUITS IN WING OUTBOARD LEADING EDGE)	T0098BTH	
48	522	240000-05-1-LH-SVC(JIC) (APPLY TEMPORARY PROTECTION TO END FITTINGS OF ELECTRICAL CONDUITS IN WING OUTBOARD LEADING EDGE)	T0098BTG	
49	622	240000-05-1-RH-INSP(JIC) (APPLY TEMPORARY PROTECTION TO END FITTINGS OF ELECTRICAL CONDUITS IN WING OUTBOARD LEADING EDGE)	T0098BTP	
50	622	240000-05-1-RH-SVC(JIC) (APPLY TEMPORARY PROTECTION TO END FITTINGS OF ELECTRICAL CONDUITS IN WING OUTBOARD LEADING EDGE)	T0098BTN	
51		240000-06-1-1-LH-CLOSE(JIC) (APPLY TEMPORARY PROTECTION TO END FITTINGS OF ELECTRICAL CONDUITS IN MAIN LANDING GEAR BAY AND FALSE SPAR BOX)	T0098BTW	
52	571,574	240000-06-1-1-LH-INSP(JIC) (APPLY TEMPORARY PROTECTION TO END FITTINGS OF ELECTRICAL CONDUITS IN MAIN LANDING GEAR BAY AND FALSE SPAR BOX)	T0098BTU	
53		240000-06-1-1-LH-OPEN(JIC) (APPLY TEMPORARY PROTECTION TO END FITTINGS OF ELECTRICAL CONDUITS IN MAIN LANDING GEAR BAY AND FALSE SPAR BOX)	T0098BTX	
54	574,571	240000-06-1-1-LH-SVC(JIC) (APPLY TEMPORARY PROTECTION TO END FITTINGS OF ELECTRICAL CONDUITS IN MAIN LANDING GEAR BAY AND FALSE SPAR BOX)	T0098BTV	
55		240000-06-1-1-RH-CLOSE(JIC) (APPLY TEMPORARY PROTECTION TO END FITTINGS OF ELECTRICAL CONDUITS IN MAIN LANDING GEAR BAY AND FALSE SPAR BOX)	T0098BU2	
56	671,674	240000-06-1-1-RH-INSP(JIC) (APPLY TEMPORARY PROTECTION TO END FITTINGS OF ELECTRICAL CONDUITS IN MAIN LANDING GEAR BAY AND FALSE SPAR BOX)	T0098BTZ	
57		240000-06-1-1-RH-OPEN(JIC) (APPLY TEMPORARY PROTECTION TO END FITTINGS OF ELECTRICAL CONDUITS IN MAIN LANDING GEAR BAY AND FALSE SPAR BOX)	T0098BU0	
58	671,674	240000-06-1-1-RH-SVC(JIC) (APPLY TEMPORARY PROTECTION TO END FITTINGS OF ELECTRICAL CONDUITS IN MAIN LANDING GEAR BAY AND FALSE SPAR BOX)	T0098BU1	

T00AT5BE

59	575	240000-07-1-LH-INSP(JIC) (APPLY TEMPORARY PROTECTION TO END FITTINGS OF ELECTRICAL CONDUITS IN WING OUTBOARD TRAILING EDGE)	T0098BUD	
60	575	240000-07-1-LH-SVC(JIC) (APPLY TEMPORARY PROTECTION TO END FITTINGS OF ELECTRICAL CONDUITS IN WING OUTBOARD TRAILING EDGE)	T0098BUE	
61	675	240000-07-1-RH-INSP(JIC) (APPLY TEMPORARY PROTECTION TO END FITTINGS OF ELECTRICAL CONDUITS IN WING OUTBOARD TRAILING EDGE)	T0098BUA	
62	675	240000-07-1-RH-SVC(JIC) (APPLY TEMPORARY PROTECTION TO END FITTINGS OF ELECTRICAL CONDUITS IN WING OUTBOARD TRAILING EDGE)	T0098BUB	
63	531	240000-08-1-LH-INSP(JIC) (APPLY TEMPORARY PROTECTION TO END FITTINGS OF ELECTRICAL CONDUITS IN FLAP TRACK NUMBER 2 FAIRING)	T0098BU4	
64	531	240000-08-1-LH-SVC(JIC) (APPLY TEMPORARY PROTECTION TO END FITTINGS OF ELECTRICAL CONDUITS IN FLAP TRACK NUMBER 2 FAIRING)	T0098BU5	
65	631	240000-08-1-RH-INSP(JIC) (APPLY TEMPORARY PROTECTION TO END FITTINGS OF ELECTRICAL CONDUITS IN FLAP TRACK NUMBER 2 FAIRING)	T0098BU7	
66	631	240000-08-1-RH-SVC(JIC) (APPLY TEMPORARY PROTECTION TO END FITTINGS OF ELECTRICAL CONDUITS IN FLAP TRACK NUMBER 2 FAIRING)	T0098BU8	
67	311,312	240000-12-1-INSP(JIC) (APPLY TEMPORARY PROTECTION TO END FITTINGS OF ELECTRICAL CONDUITS IN FUSELAGE TAIL AREA)	T0098BTK	
68	311,312	240000-12-1-SVC(JIC) (APPLY TEMPORARY PROTECTION TO END FITTINGS OF ELECTRICAL CONDUITS IN FUSELAGE TAIL AREA)	T0098BTL	
69	325	240000-13-1-INSP(JIC) (APPLY TEMPORARY PROTECTION TO END FITTINGS OF ELECTRICAL CONDUITS IN VERTICAL STABILIZER TRAILING EDGE)	T0098BUG	
70	325	240000-13-1-SVC(JIC) (APPLY TEMPORARY PROTECTION TO END FITTINGS OF ELECTRICAL CONDUITS IN VERTICAL STABILIZER TRAILING EDGE)	T0098BUH	
71	334	240000-16-1-LH-INSP.(JIC) (APPLY TEMPORARY PROTECTION TO END FITTINGS OF ELECTRICAL CONDUITS IN TRIMMABLE HORIZONTAL STABILIZER)	T0098BUL	
72	334	240000-16-1-LH-SVC(JIC) (APPLY TEMPORARY PROTECTION TO END FITTINGS OF ELECTRICAL CONDUITS IN TRIMMABLE HORIZONTAL STABILIZER)	T0098BUK	
73	344	240000-16-1-RH-INSP.(JIC) (APPLY TEMPORARY PROTECTION TO END FITTINGS OF ELECTRICAL CONDUITS IN TRIMMABLE HORIZONTAL STABILIZER)	T0098BUN	
74	344	240000-16-1-RH-SVC(JIC) (APPLY TEMPORARY PROTECTION TO END FITTINGS OF ELECTRICAL CONDUITS IN TRIMMABLE HORIZONTAL STABILIZER)	T0098BUP	
75	100,200	240000-17-1-INSP(JIC) (ELECTRICAL POWER, OPENING AND CLOSING OF ALL CIRCUIT BREAKERS)	T0099C1T	
76	448,438	242100-02-1-ENG1-INSP(JIC) (INTEGRATED DRIVE GENERATOR)	T00ATFPG	
77	210	242200-01-1-OP(JIC) (OPERATIONAL CHECK OF TRANSFER INHIBITION)	T0099C27	
78	210	242400-02-1-OP(JIC) (OPERATIONAL CHECK OF EMERGENCY GCU VIA CFDS)	T0099C2Q	
79	210	242500-01-1-OP(JIC) (OPERATIONAL CHECK OF AC ESS GENERATION SWITCHING)	T0099C2S	
80	210	242600-02-1-OP(JIC) (OPERATIONAL CHECK OF MANUAL AND AUTOMATIC GALLEY AND BUS SHEDDING)	T00ADMYR	
81	210	243200-01-1-OP(JIC) (DC GENERATION)	T0099C2Y	

T00AT5BE

82	210	243400-01-1-OP(JIC) (OPERATIONAL CHECK OF "DC EMERG. CONFIG" CAUTION)	T0099C30	
83	210	245100-01-1-OP(JIC) (OPERATIONAL CHECK OF GENERATOR LINE CONTACTOR OPENING)	T00ADN06	
84	210	245100-02-1-OP(JIC) (OPERATIONAL CHECK OF COMMERCIAL ELECTRIC LOAD SHEDDING)	T0098BVM	
85	200	252100-02-1-INSP(JIC) (DETAILED INSPECTION OF SEAT BELT ATTACHMENT, SEAT BELT AND LOCK CHECK OF LOCK)	T0098C5Q	
86	200	252200-01-1-INSP(JIC) (DETAILED INSPECTION OF SEAT ATTACHMENT AND GENERAL VISUAL INSPECTION OF SEAT STRUCTURE)	T0098C5S	
87	200	252200-02-1-INSP(JIC) (DETAILED INSPECTION OF SEAT BELT ATTACHMENT, SEAT BELT AND LOCK CHECK OF LOCK)	T0098C5U	
88	200	252331-01-1-INSP(JIC) (DETAILED INSPECTION OF LOWER SIDE WALL PANEL AND OF AREA BEHIND LOWER SIDE WALL PANEL FOR FOREIGN MATERIAL ACCUMULATION)	T0098C5Y	
89	200	252331-01-1-REINS(JIC) (DETAILED INSPECTION OF LOWER SIDE WALL PANEL AND OF AREA BEHIND LOWER SIDE WALL PANEL FOR FOREIGN MATERIAL ACCUMULATION)	T0098C5X	
90	200	252331-01-1-REM(JIC) (DETAILED INSPECTION OF LOWER SIDE WALL PANEL AND OF AREA BEHIND LOWER SIDE WALL PANEL FOR FOREIGN MATERIAL ACCUMULATION)	T0098C5W	
91	200	253000-02-1-REPL(JIC) (BUFFET AND GALLEY)	T0098C62	
92	200	254000-04-2-DI(JIC) (DETAILED INSPECTION OF LAVATORY FLOOR PAN)	T0098C6A	
93	262	256241-05-1-RH-AFT-SVC(JIC) (RH AFT DOOR ESCAPE SLIDE)	T00A3APH	
94	200,260	256535-01-1-OP(JIC) (OPERATIONAL CHECK OF ELT SYSTEM BY MANUAL ACTIVATION)	T00ADNHH	
95	200	256551-02-1-OP(JIC) (OPERATIONAL CHECK OF MEGAPHONE)	T0099BU9	
96	210	262100-02-1-ENG1-OP(JIC) (OPERATIONAL CHECK OF BOTTLE LOW PRESSURE INDICATING CIRCUIT)	T0099BUS	
97	210	262100-02-1-ENG2-OP(JIC) (OPERATIONAL CHECK OF BOTTLE LOW PRESSURE INDICATING CIRCUIT)	T0099BUU	
98	415	262100-03-1-ENG1-OP(JIC) (CHECK FIRING CIRCUIT CONTINUITY)	T0099BUW	
99	425	262100-03-1-ENG2-OP(JIC) (CHECK FIRING CIRCUIT CONTINUITY)	T0099BUX	
100	415	262100-04-1-ENG1-FC(JIC) (ENGINE FIRE EXTINGUISHING CHECK DISTRIBUTION PIPING FOR LEAKAGE AND OBSTRUCTION)	T0099BV1	
101	425	262100-04-1-ENG2-FC(JIC) (ENGINE FIRE EXTINGUISHING CHECK DISTRIBUTION PIPING FOR LEAKAGE AND OBSTRUCTION)	T0099BV3	
102	210	262100-05-1-OP(JIC) (OPERATIONAL CHECK OF FIRE CONTROL PUSH BUTTON SWITCH SUB FUNCTIONS RELATED TO ENGINE SHUTDOWN AND ISOLATION)	T0099BV5	
103	210	262200-03-1-INSP(JIC) (CHECK FIRING CIRCUIT CONTINUITY)	T0099BV7	
104	313	262200-04-1-INSP(JIC) (DETAILED INSPECTION OF DISTRIBUTION PIPING)	T0099BV9	
105	210	262200-05-1-OP(JIC) (OPERATIONAL CHECK OF LOW PRESSURE INDICATING CIRCUIT)	T00ADP50	

T00AT5BE

106	132	262300-02-3-OP(JIC)-TAM (CHECK FIRING CIRCUIT CONTINUITY)	T00AN6PG	
107	132	262300-03-3-FC(JIC) (CHECK FIRE EXTINGUISHING LINES FOR LEAKAGE AND OBSTRUCTION)	T0099BVK	
108	200	262541-01-1-INSP(JIC) (GENERAL VISUAL INSPECTION OF LAVATORY FIRE EXTINGUISHER FOR SIGNS OF LEAKAGE/DISCHARGE)	T0099BVP	
109	200	262541-04-1-INSP(JIC) (VISUAL CHECK OF FIRE EXTINGUISHER BOTTLE PRESSURE READING)	T0099BVR	
110	575	271400-02-2-LH-INSP(JIC) (CHECK AILERON SERVO CONTROL AND HINGE BEARINGS FOR EXCESSIVE PLAY AND CONDITION)	T0099BVV	
111	675	271400-02-2-RH-INSP(JIC) (CHECK AILERON SERVO CONTROL AND HINGE BEARINGS FOR EXCESSIVE PLAY AND CONDITION)	T0099BVX	
112	575	271400-03-1-LH-INSP(JIC) (CHECK AILERON SERVO CONTROLS FLUID RESERVE PISTON POSITION WITH HYDRAULIC RESERVOIR DEPRESSURIZED)	T0099BVZ	
113	675	271400-03-1-RH-INSP(JIC) (CHECK AILERON SERVO CONTROLS FLUID RESERVE PISTON POSITION WITH HYDRAULIC RESERVOIR DEPRESSURIZED)	T0099BW0	
114	210	272100-01-1-OP(JIC) (RUDDER MECHANICAL CONTROL)	T009TDZ5	
115	210	272100-08-1-LUB(JIC) (RUDDER MECHANICAL CONTROL)	T0099BMW	
116	125	272145-01-1-INSP(JIC) (CHECK TENSION REGULATOR POINTER IS WITHIN THE LIMITS)	T00A6A49	
117	325	272400-02-1-FC(JIC) (RUDDER HYDRAULIC ACTUATION)	T0099BN0	
118	210	273400-01-1-OP(JIC) (OPERATIONAL CHECK OF DAMPING MEASUREMENT BY BITE)	T0099BNE	
119	334	273400-02-1-LH-FC(JIC-TAM) (CHECK ELEVATOR SERVOCONTROL AND HINGE BEARINGS FOR EXCESSIVE PLAY AND CONDITION)	T009VBQF	
120	334,822	273400-02-1-LH-FC.(JIC) (CHECK ELEVATOR SERVOCONTROL AND HINGE BEARINGS FOR EXCESSIVE PLAY AND CONDITION)	T00AS5QU	
121	334	273400-02-1-RH-FC(JIC-TAM) (CHECK ELEVATOR SERVOCONTROL AND HINGE BEARINGS FOR EXCESSIVE PLAY AND CONDITION)	T009VBQ3	
122	822,344	273400-02-1-RH-FC.(JIC) (CHECK ELEVATOR SERVOCONTROL AND HINGE BEARINGS FOR EXCESSIVE PLAY AND CONDITION)	T00ARZQQ	
123	334,344	273400-03-1-INSP(JIC) (CHECK FLUID RESERVE PISTON POSITION WITH HYDRAULIC RESERVOIR DEPRESSURIZED)	T0099BNK	
124	334,344	273400-06-1-INSP(JIC) (ELEVATOR AND HYDRAULIC ACTUATION)	T0099BN8	
125	344,334	273400-08-1-LUB(JIC) (LUBRICATION OF ELEVATOR SERVOCONTROL ROD EYE END BEARING)	T0099BNM	
126	310	274000-01-1-LUB(JIC) (TRIMMABLE HORIZONTAL STABILIZER)	T0099BZN	
127	210	274000-03-1-OP(JIC)-TAM (TRIMMABLE HORIZONTAL STABILIZER (THS))	T0099BP8	
128	210	274000-04-1-OP(JIC) (OPERATIONAL CHECK OF THS ACTUATOR WITH ELECTRICAL MOTOR NO 3)	T0098BVP	
129	120,310	274100-03-1-LUB(JIC) (LUBRICATION OF THS MECHANICAL CONTROL CHAINS)	T0099BXN	

T00AT5BE

130	310	274142-01-1-INSP(JIC) (CHECK POINTER ON TENSION COMPENSATOR SCALE WITHIN LIMITS)	T009ZSM1	
131	310	274400-03-1-OP(JIC) (OPERATIONAL CHECK OF THS ACTUATOR NO-BACK DEVICE)	T00APYNR	
132	310	274451-01-1-LUB(JIC) (THS ACTUATOR)	T009TDZS	
133	310	274451-02-1-SVC(JIC)-TAM (THS ACTUATOR)	T0099BPS	
134	310	274451-03-1-INSP(JIC) (CHECK INDICATOR OF THS ACTUATOR NO-BACK WEAR DETECTION DEVICE)	T0099BPC	
135	310	274451-04-1-INSP(JIC) (DETAILED INSPECTION OF THS ACTUATOR BALL SCREW NUT BODY AND SCREW AND CLAW STOPS)	T0099BPE	
136	310	274451-05-1-INSP(JIC) (THS ACTUATOR)	T00ADPZD	
137	310	274451-06-1-INSP(JIC) (VISUAL CHECK OF THS ACTUATOR THREADED NUT (FAIL SAFE NUT))	T00ADPT9	
138	310	274451-07-1-INSP(JIC) (CHECK BACKLASH BETWEEN THS ACTUATOR BALL SCREW NUT AND SCREW)	T00ADPP0	
139	310	274451-08-1-INSP(JIC) (CHECK INTEGRITY OF THS ACTUATOR BALL SCREW SHAFT (PRIMARY AND SECONDARY LOAD PATH))	T00A114T	
140	310	274451-09-1-SVC(JIC) (DRAIN AND REFILL THS ACTUATOR GEARBOX)	T0099BPQ	
141	210	275100-01-2-OP(JIC) (OPERATIONAL CHECK OF WTB/POB)	T00APMLR	
142	210	275100-02-1-A321-LH-INSP(JIC) (OPERATIONAL CHECK OF FLAP INTERCONNECTING STRUT AND FLAP DISCONNECT PROXIMITY SENSORS)	T00APMLK	
143	210	275100-02-1-A321-RH-INSP(JIC) (OPERATIONAL CHECK OF FLAP INTERCONNECTING STRUT AND FLAP DISCONNECT PROXIMITY SENSORS)	T00APMLW	
144	575	275100-03-1-LH-INSP(JIC) (CHECK OF FLAPS TRANSMISSION SHAFTING INTEGRITY, INCLUDING INSPECTION OF SEAL WITNESS DRAINS.)	T00ADPPW	
145	675	275100-03-1-RH-INSP(JIC) (CHECK OF FLAPS TRANSMISSION SHAFTING INTEGRITY, INCLUDING INSPECTION OF SEAL WITNESS DRAINS.)	T00ADPXT	
146	580	275144-01-1-LH-FC(JIC) (DETAILED INSPECTION OF INTERCONNECTING STRUT AND ATTACHMENTS)	T0099C3L	
147	580	275144-01-1-LH-INSP(JIC) (DETAILED INSPECTION OF INTERCONNECTING STRUT AND ATTACHMENTS)	T00AEBLX	
148	680	275144-01-1-RH-FC(JIC) (DETAILED INSPECTION OF INTERCONNECTING STRUT AND ATTACHMENTS)	T0099C3P	
149	680	275144-01-1-RH-INSP(JIC) (DETAILED INSPECTION OF INTERCONNECTING STRUT AND ATTACHMENTS)	T00AEBP8	
150	630	275446-01-1-RH-LUB(JIC) (FLAP TRACKS)	T00A5T0A	
151	630,530	275446-02-1-LH-CLN(JIC) (DETAILED INSPECTION OF TRACKS AND ROLLERS (AS FAR AS VISIBLE))	T0099C49	
152	530,580	275446-02-1-LH-INSP(JIC) (DETAILED INSPECTION OF TRACKS AND ROLLERS (AS FAR AS VISIBLE))	T0099C44	
153	530,580	275446-02-1-LH-LUB(JIC) (DETAILED INSPECTION OF TRACKS AND ROLLERS (AS FAR AS VISIBLE))	T0099C46	
154	630,530	275446-02-1-RH-CLN(JIC) (DETAILED INSPECTION OF TRACKS AND ROLLERS (AS FAR AS VISIBLE))	T0099C47	

T00AT5BE

155	680,630	275446-02-1-RH-INSP(JIC) (DETAILED INSPECTION OF TRACKS AND ROLLERS (AS FAR AS VISIBLE))	T0099C45	
156	680,630	275446-02-1-RH-LUB(JIC) (DETAILED INSPECTION OF TRACKS AND ROLLERS (AS FAR AS VISIBLE))	T0099C48	
157	147	275451-01-1-SVC(JIC) (REPLENISH PCU GEARBOX TO CONFIRM FLUID LEVEL)	T0099BX3	
158	675	276400-01-1-RH-LUB(JIC) (SPOILER AND HYDRAULIC ACTUATION)	T00A5T38	
159	575	276400-02-1-LH-FC(JIC) (SPOILER AND HYDRAULIC ACTUATION)	T0099C4B	
160	675	276400-02-1-RH-FC(JIC) (SPOILER AND HYDRAULIC ACTUATION)	T0099C4D	
161	520	278100-03-1-OP(JIC) (SLATS)	T00AF93B	
162	520,521	278100-04-1-LH-INSP(JIC)-TAM (CHECK OF SLATS TRANSMISSION SHAFTING INTEGRITY, INCLUDING INSPECTION OF SEAL WITNESS DRAINS)	T0099BWU	
163	620,621	278100-04-1-RH-INSP(JIC)-TAM (CHECK OF SLATS TRANSMISSION SHAFTING INTEGRITY, INCLUDING INSPECTION OF SEAL WITNESS DRAINS)	T0099BWW	
164	147	278451-01-1-SVC(JIC) (REPLENISH PCU GEARBOX TO CONFIRM FLUID LEVEL)	T0099BX5	
165	620	278468-01-1-RH-LUB(JIC) (SLAT TRACKS)	T009VPH3	
166		278468-02-1-LH-CLN(JIC) (DETAILED INSPECTION OF TRACK ROLLERS, PINIONS AND CURVED RACK GEARS)	T0099BWM	
167	520	278468-02-1-LH-INSP(JIC) (DETAILED INSPECTION OF TRACK ROLLERS, PINIONS AND CURVED RACK GEARS)	T0099BWN	
168		278468-02-1-LH-LB(JIC) (DETAILED INSPECTION OF TRACK ROLLERS, PINIONS AND CURVED RACK GEARS)	T0099BWL	
169		278468-02-1-RH-CLN(JIC) (DETAILED INSPECTION OF TRACK ROLLERS, PINIONS AND CURVED RACK GEARS)	T0099BWR	
170	620	278468-02-1-RH-INSP(JIC) (DETAILED INSPECTION OF TRACK ROLLERS, PINIONS AND CURVED RACK GEARS)	T0099BWS	
171		278468-02-1-RH-LB(JIC) (DETAILED INSPECTION OF TRACK ROLLERS, PINIONS AND CURVED RACK GEARS)	T0099BWQ	
172	550	281247-01-1-LH-INSP(JIC) (VISUAL CHECK OF NACA INTAKE FOR SIGNS OF BLOCKAGE)	T0098CPT	
173	650	281247-01-1-RH-INSP(JIC) (VISUAL CHECK OF NACA INTAKE FOR SIGNS OF BLOCKAGE)	T0098CPV	
174	210	281500-01-1-OP(JIC) (INTERCELL TRANSFER SYSTEM)	T00AF8YD	
175	471	281600-01-1-ENG1-OP-CFM(JIC) (OPERATIONAL CHECK OF PYLON CHECK VALVE TO ENSURE VALVE NOT FAILED OPEN)	T00AGWFY	
176	471	281600-01-1-ENG2-OP-CFM(JIC) (OPERATIONAL CHECK OF PYLON CHECK VALVE TO ENSURE VALVE NOT FAILED OPEN)	T00AGVZZ	
177	140	282100-02-1-OP(JIC) (OPERATIONAL CHECK OF CENTER TANK PUMP CANISTER CHECK VALVES)	T00AGWEC	
178	210	282100-03-1-OP(JIC) (OPERATIONAL CHECK OF AIR RELEASE VALVES TO ENSURE ADEQUATE FUEL FLOW UNDER SUCTION FEED CONDITIONS)	T00AF8R0	
179	210	282100-04-1-OP(JIC) (OPERATIONAL CHECK TO ENSURE THAT BOTH CENTER TANK PUMPS FEED FOR 2 MINUTES AFTER ENGINE START)	T00AF93J	

T00AT5BE

180	420	282100-05-1-ENG1-INSP(JIC) (VISUAL CHECK OF PIPES, COUPLINGS AND LP VALVE EXTERNAL TO TANK FROM FRONT SPAR TO HP VALVE FOR LEAKS WITH BOOSTER PUMP ON AND LP VALVE OPEN)	T0098CRL	
181	520	282100-05-1-ENG2-INSP(JIC) (VISUAL CHECK OF PIPES, COUPLINGS AND LP VALVE EXTERNAL TO TANK FROM FRONT SPAR TO HP VALVE FOR LEAKS WITH BOOSTER PUMP ON AND LP VALVE OPEN)	T0098CRJ	
182	210	282300-01-2-OP(JIC) ("OPERATIONAL CHECK OF CROSSFEED VALVE USING INDIVIDUAL MOTORS AND CHECK FUEL FLOW IN "OPEN" AND FUEL SHUT OFF IN "CLOSED" POSITIONS")	T00AF98Q	
183	40,520,62	282400-01-1-OP(JIC) (OPERATIONAL CHECK OF LP SHUT OFF VALVES AND THEIR CONTROLS TO ENSURE NO FLOW WHEN SELECTED CLOSED WITH BOOSTER PUMP ON)	T00AGWAF	
184	622	282541-01-1-INSP(JIC) (DETAILED INSPECTION OF COUPLING REFUEL/DEFUEL.)	T0098CU3	
185	100	291000-02-1-INSP(JIC) (MAIN HYDRAULIC POWER)	T00ASQ77	
186	210	291000-04-1-OP(JIC) (OPERATIONAL CHECK OF PTU GREEN TO YELLOW)	T0098CSX	
187	210	291000-06-1-FC(JIC) (FUNCTIONAL CHECK OF PTU YELLOW TO GREEN)	T0098CSZ	
188	74,674,21	291000-09-1-OP(JIC) (OPERATIONAL CHECK OF HYDRAULIC FIRE SHUT OFF VALVES AND ASSOCIATED INDICATING SYSTEM.)	T00AGWLT	
189	100	291000-15-1-SRVC(JIC) (MAIN HYDRAULIC POWER)	T009R1CM	
190	148	291000-18-1-SVC(JIC) (MAIN HYDRAULIC POWER)	T009TE2Q	
191	210	291000-20-1-OP(JIC) (OPERATIONAL CHECK OF EDP DEPRESSURIZATION)	T0098CSG	
192	210	291900-02-1-1-FC(JIC) (FUNCTIONAL CHECK TO MONITOR INTERNAL LEAK RATE OF BLUE HYDRAULIC SYSTEM)	T0098CSL	
193	190	292000-04-1-FC(JIC) (OPERATIONAL CHECK OF RAT MANUAL DEPLOYMENT AND FUNCTIONAL CHECK OF RAT USING GROUND TEST UNIT, FOLLOWED BY CHECK OF FILTER INDICATOR)	T00AJE7A	
194	210,197	292000-05-1-OP(JIC) (OPERATIONAL CHECK OF RAM AIR TURBINE (RAT) AUTOMATIC DEPLOYMENT)	T0098C6J	
195	195	292251-02-1-INSP(JIC)-TAM (RAM AIR TURBINE)	T009VPF0	
196	35,196,19	293400-01-1-OP(JIC) (OPERATIONAL CHECK OF RESERVOIR LOW AIR PRESSURE WARNING)	T0098CT3	
197	522,622	301151-02-1-SVC(JIC) (REMOVE WING ANTI-ICING FILTER FOR IN SHOP CLEANING)	T0098CEP	
198	210	302100-01-1-ENG1-OP(JIC) (OPERATIONAL CHECK OF ENGINE ANTI-ICE SYSTEM FAULT WARNING)	T0098CER	
199	210	302100-01-1-ENG2-OP(JIC) (OPERATIONAL CHECK OF ENGINE ANTI-ICE SYSTEM FAULT WARNING)	T0098CES	
200	120	303100-01-1-FC(JIC) (PROBE ICE PROTECTION)	T0098CF0	
201	312	313300-03-1-OP(JIC) (OPERATIONAL CHECK OF ULB)	T0098CF8	
202	210	315000-01-1-OP(JIC) (OPERATIONAL CHECK OF CORRECT OPERATION OF PFD-ND AND ECAM-ND MANUAL TRANSFER)	T0099C36	

T00AT5BE

203	210	315000-02-1-OP(JIC) (OPERATIONAL CHECK OF CORRECT OPERATION OF EFIS AND ECAM DMC AUTOMATIC AND MANUAL TRANSFER)	T0099C38	
204	210	315000-04-1-OP(JIC) (OPERATIONAL CHECK OF DMC3 POWER SUPPLY TRANSFER WHEN BUSBAR 101XP IS LOST)	T0099C3A	
205	731	321000-01-1-LH-LUB(JIC) (LH MAIN LANDING GEAR AND DOORS)	T00A0PW9	
206	741	321000-01-1-RH-LUB(JIC) (RH MAIN LANDING GEAR AND DOORS)	T00A0M2T	
207	741,731	321111-03-1-RH-FC(JIC) (MAIN LANDING GEAR)	T009TE33	
208	731	321113-03-1-LH-SVC(JIC) (CHECK FLUID LEVEL OF MAIN LANDING GEAR SHOCK ABSORBER)	T0099BX0	
209	741	321113-03-1-RH-SVC(JIC) (CHECK FLUID LEVEL OF MAIN LANDING GEAR SHOCK ABSORBER)	T0099BX1	
210	731	321113-04-1-LH-FC(JIC) (CHECK OF MLG SHOCK ABSORBER CHARGE PRESSURE)	T0099BXF	
211	741	321113-04-1-RH-FC(JIC) (CHECK OF MLG SHOCK ABSORBER CHARGE PRESSURE)	T0099BXJ	
212	731	321127-01-1-LH-CLN(JIC) (CHECK TORQUE LINKS FOR EXCESSIVE PLAY)	T0098CGN	
213	731	321127-01-1-LH-INSP(JIC) (CHECK TORQUE LINKS FOR EXCESSIVE PLAY)	T0098CGQ	
214	731	321127-01-1-LH-REINS(JIC) (CHECK TORQUE LINKS FOR EXCESSIVE PLAY)	T0098CGM	
215	731	321127-01-1-LH-REM(JIC) (CHECK TORQUE LINKS FOR EXCESSIVE PLAY)	T0098CGL	
216	731	321127-01-1-LH-TEST(JIC) (CHECK TORQUE LINKS FOR EXCESSIVE PLAY)	T0098CGP	
217	741	321127-01-1-RH-CLN(JIC) (CHECK TORQUE LINKS FOR EXCESSIVE PLAY)	T0098CGU	
218	741	321127-01-1-RH-INSP(JIC) (CHECK TORQUE LINKS FOR EXCESSIVE PLAY)	T0098CGW	
219	741	321127-01-1-RH-REINS(JIC) (CHECK TORQUE LINKS FOR EXCESSIVE PLAY)	T0098CGT	
220		321127-01-1-RH-REM(JIC) (CHECK TORQUE LINKS FOR EXCESSIVE PLAY)	T0098CGS	
221	741	321127-01-1-RH-TEST(JIC) (CHECK TORQUE LINKS FOR EXCESSIVE PLAY)	T0098CGV	
222	711	322113-01-1-INSP(JIC) (CHECK SHOCK ABSORBER CHARGE PRESSURE)	T0099BXC	
223	711	322113-01-1-SVC(JIC) (CHECK SHOCK ABSORBER CHARGE PRESSURE)	T0099BXB	
224	711	322127-01-1-CLN(JIC) (CHECK TORQUE LINKS FOR EXCESSIVE PLAY)	T0098CJ1	
225	711	322127-01-1-INSP(JIC) (CHECK TORQUE LINKS FOR EXCESSIVE PLAY)	T0098CJ0	
226	711	322127-01-1-SVC(JIC) (CHECK TORQUE LINKS FOR EXCESSIVE PLAY)	T0098CJ2	
227	711	323100-02-1-NLG-INSP(JIC) (NORMAL EXTENSION AND RETRACTION)	T00APXQ7	

T00AT5BE

228	741	323100-02-1-RH-INSP(JIC) (NORMAL EXTENSION AND RETRACTION)	T00APXPS	
229	210	323100-04-1-OP(JIC) (OPERATIONAL CHECK TO ENSURE SAFETY VALVE CLOSING AT 260 KTS)	T00AGXJX	
230	120	323100-05-1-INSP(JIC) (DETAILED INSPECTION OF NOSE GEAR DOOR OPERATING MECHANISM)	T00AGX9Y	
231	210	323100-06-1-OP(JIC) (BITE CHECK USING MCDU TO ENSURE "GEAR NOT DOWN FOR LANDING" WARNINGS OPERATIVE)	T0098CP7	
232	731	323105-04-1-LH-FC(JIC) (FUNCTIONAL CHECK OF THE MLG DOOR ACTUATING CYLINDER.)	T00AFB1F	
233	741	323105-04-1-RH-FC(JIC) (FUNCTIONAL CHECK OF THE MLG DOOR ACTUATING CYLINDER.)	T00AFB43	
234	711	323105-05-1-FC(JIC)-LAN (FUNCTIONAL CHECK OF THE NLG DOOR ACTUATING CYLINDER.)	T00AFX7P	
235	700	323300-03-1-FC(JIC) (FUNCTIONAL CHECK OF FREE FALL EXTENSION WITH ONE DOWNLOCK SPRING REMOVED)	T0098C82	
236	14,734,74	323300-05-1-OP(JIC) (OPERATIONAL CHECK OF FREE-FALL MECHANICAL CONTROL)	T00AGYAM	
237	730,744	324000-14-1-FC(JIC) (FUNCTIONAL CHECK OF AUTOMATICALLY REACTIVATION OF THENORMAL BRAKING MODE (PARKING BRAKE APPLIED))	T00AGXJD	
238	,210,730,	324000-17-1-FC(JIC) (FUNCTIONAL CHECK OF BRAKE ACCUMULATOR SYSTEM)	T0098C8A	
239	10,740,73	324300-01-3-OP(JIC) (OPERATIONAL CHECK OF ALTERNATE BRAKING SYSTEM)	T0098CP1	
240	210	324300-02-1-OP(JIC) (OPERATIONAL CHECK OF ANTISKID INHIBITION)	T0098CNX	
241	,711,730,	324500-01-2-OP(JIC) (OPERATIONAL CHECK OF THE PARKING BRAKE SYSTEM)	T0098CP5	
242	220	335100-03-1-1-OP(JIC) (CHECK BATTERY CAPACITY)	T00AH0MH	
243	200	335100-05-1-OP(JIC) (CHECK MANUAL OPERATION FROM BOTH CONTROL PANELS AND CHECK ALL CABIN LIGHTS AND SIGNS ILLUMINATED BY BATTERIES)	T0098CA5	
244	210	341300-01-1-OP(JIC) (OPERATIONAL CHECK OF OVERSPEED WARNING VMO/MMO USING CFDS)	T0098CAM	
245	210	341300-02-1-OP(JIC) (OPERATIONAL CHECK OF AIR DATA SWITCHING FUNCTION)	T0098CAP	
246	210	341300-03-1-OP(JIC) (OPERATIONAL CHECK OF OVERSPEED WARNINGS VFE/VLE USING CFDS)	T0098CAR	
247	210	341300-05-1-OP(JIC) (OPERATIONAL CHECK OF THE 5-MINUTE TIME DELAY OF ADIRU2 AND 3 POWER DISCONNECTION IN EMERGENCY CONFIGURATION)	T00AGX3E	
248	210	341300-07-1-SVC(JIC) (AIR DATA)	T0098CAD	
249	125,126	341300-11-1-PART3-SVC-TAM(JIC) (CLEANING OF PITOT PROBE #3)	T00APB3J	
250	121,122	341300-13-1-FC(JIC) (FUNCTIONAL TEST OF THE ADM ACCURACY)	T0098CAV	
251	210	342000-03-1-OP(JIC) (OPERATIONAL CHECK OF ISIS DC HOT BUS SUPPLY)	T0098CM3	
252	210	342200-01-1-OP(JIC) (STANDBY COMPASS)	T0098CLZ	

T00AT5BE

253	120	342200-02-1-SVC(JIC) (DRAINING AND FLUSHING OF STANDBY PNEUMATIC CIRCUITS)	T00A5T43	
254	152	344200-01-1-INSP(JIC) (RADIO ALTIMETER)	T0098CM7	
255	150	344200-03-1-SVC(JIC) (RADIO ALTIMETER)	T00AEUDA	
256	210	344800-01-1-OP(JIC) (OPERATIONAL CHECK OF GROUND SELF TEST SYSTEM)	T0098CMB	
257	210	345200-02-1-OP(JIC) (FUNCTIONAL CHECK OF ATC ANTENNAS)	T0098CMF	
258	210	351000-01-1-OP(JIC) (CREW OXYGEN SYSTEM)	T00AGX9W	
259	210	351000-08-1-FC(JIC)-TAM (CREW OXYGEN - FUNCTIONAL CHECK OF ECAM INDICATION COMPARED WITH CYLINDER PRESSURE GAUGE INDICATION)	T0098CBG	
260	210	351241-01-1-INSP(JIC) (DETAILED INSPECTION OF OXYGEN MASKS (OUT OF BOX) WITH HARNESS INFLATED)	T0098CBL	
261	210	351351-01-1-FC(JIC) (FUNCTIONAL CHECK OF LOW PRESSURE SWITCH)	T0098CBJ	
262	200	352000-01-1-OP(JIC) (OPERATIONAL CHECK OF MANUAL MASK RELEASE)	T00AGXJC	
263	200	352000-02-1-FC(JIC) (FUNCTIONAL CHECK OF AUTOMATIC MASK RELEASE, DETAILED INSPECTION OF MASKS AND VISUAL CHECK OF CHEMICAL OXYGEN GENERATORS)	T0098CBV	
264	200	352142-01-1-REPL-A320(JIC) (OXYGEN GENERATORS)	T009TRX4	
265	200	353000-07-1-INSP(JIC) (DETAILED INSPECTION OF PORTABLE OXYGEN MASK)	T0098CBZ	
266	410	361100-06-1-ENG1-OPCFM(JIC) (PERFORM LEAK CHECK ON THE COMBO SEALS ON THE PYLON DUCT SLEEVES (DOWNSTREAM PRECOOLER))	T00AK4SL	
267	420	361100-06-1-ENG2-OPCFM(JIC) (PERFORM LEAK CHECK ON THE COMBO SEALS ON THE PYLON DUCT SLEEVES (DOWNSTREAM PRECOOLER))	T00AK9RS	
268	460	361100-08-2-ENG2-INSP(JIC) (ENGINE BLEED AIR SUPPLY SYSTEM)	T00A5T41	
269	453	361141-03-1-ENG1-INSP(JIC) (IP BLEED CHECK VALVE)	T0098CCF	
270	463	361141-03-1-ENG2-INSP(JIC) (IP BLEED CHECK VALVE)	T0098CCH	
271	423	361143-01-1-ENG2-SVC(JIC) (THERMOSTAT - FAN AIR VALVE CONTROL)	T0098CCM	
272	138	381000-02-1-INSP(JIC) (GENERAL VISUAL INSPECTION OF POTABLE WATER TANK)	T0098CDG	
273	170	383100-02-1-INSP-TAM(JIC) (VACUUM TOILET SYSTEM)	T009P47S	
274	172	383100-05-1-INSP(JIC) (VACUUM TOILET SYSTEM)	T0098CDW	
275	200	383100-07-1-CLN(JIC) (HIGH PRESSURE CLEANING OF THE WASTE LINES.)	T0098CDP	
276	ZONE2	383100-07-1-FC(JIC) (HIGH PRESSURE CLEANING OF THE WASTE LINES.)	T0098CDN	
277	200	383100-07-1-INSP(JIC) (HIGH PRESSURE CLEANING OF THE WASTE LINES.)	T0098CDR	

T00AT5BE

278	200	383100-07-1-SVC(JIC) (HIGH PRESSURE CLEANING OF THE WASTE LINES.)	T0098CDQ	
279	200	383155-01-1-FC(JIC) (REMOVE, CLEAN AND INSPECT TOILET RINSE VALVES FROM ALL TOILETS)	T0098CDU	
280	200	383155-01-1-SVC(JIC) (REMOVE, CLEAN AND INSPECT TOILET RINSE VALVES FROM ALL TOILETS)	T0098CDT	
281	137	384241-01-1-SVC(JIC) (DETAILED INSPECTION OF COMPRESSOR INLET FILTER)	T0098CE4	
282	315	491200-B1-1-INSP(JIC) (APU MOUNTS)	T009VFQB	
283	315,316	491200-B2-1-INSP(JIC) (APU MOUNTS)	T00A7B23	
284	310	491300-B1-1-INSP(JIC) (FIRE SEALS)	T0098CPP	
285	313,315	491600-B1-1-INSP(JIC) (DETAILED INSPECTION OF APU AIR INTAKE, DIFFUSER ELBOW, SEALS AND FELT METAL)	T0098CPR	
286	315	493000-B1-1-LUB(JIC) (ENGINE FUEL AND CONTROL DISCARD FUEL INLET FILTER ELEMENT)	T00A0U3C	
287	210	493400-B1-1-OP(JIC) (OPERATIONAL CHECK OF APU FUEL LOW PRESSURE CIRCUIT)	T0098CEF	
288	315	494000-B2-1-INSP(JIC) (IGNITION AND STARTING)	T00A0U3T	
289	310	498000-B1-1-INSP(JIC) (VISUAL CHECK OF APU COMPARTMENT EXHAUST MUFFLER INSULATION COVERS AND BELLOWS)	T0098CEM	
290	315	499100-B2-1-REPL(JIC) (STORAGE AND DISTRIBUTION)	T00A0U4V	
291	310	499100-B4-1-VC(JIC) (STORAGE AND DISTRIBUTION)	T0098CPH	
292	,831,842,	521000-02-1-FC(JIC) (FUNCTIONAL CHECK OF DOOR SUSPENSION)	T0098CMH	
293	,841,832,	521000-03-1-INSP(JIC) (DETAILED INSPECTION OF DOOR SEALS)	T0098CMK	
294	,832,841,	521000-04-1-INSP(JIC) (DETAILED INSPECTION OF PASSENGER/CREW DOOR FOR INTEGRITY AND GOOD ADJUSTMENT OF MECHANISMS (INCLUDING GIRT BAR))	T0098CMM	
295	,841,842,	521000-05-1-FC(JIC) (FUNCTIONAL CHECK OF LOCKING MECHANISM)	T0098CMP	
296	ZONE2	521000-06-1-OP(JIC) (FUNCTIONAL CHECK OF ESCAPE SLIDE RELEASE MECHANISM)	T0098CMR	
297	,842,841,	521000-07-1-INSP(JIC) (CHECK OF DOOR STOPS ADJUSTMENT)	T0098CMT	
298	,842,841,	521000-08-1-OP(JIC) (OPERATIONAL CHECK OF INTERLOCK MECHANISM TO ENSURE THAT EMERGENCY ESCAPE HANDLE STAYS IN DISARMED POSITION WHEN DOOR IS UP AND OUTSIDE OF FRAME)	T0098CMV	
299	,841,832,	521000-09-1-INSP(JIC) (FUNCTIONAL CHECK OF MECHANICAL LOCKING INDICATION)	T0098CN7	
300	,842,841,	521000-10-1-OP(JIC) (OPERATIONAL CHECK OF DAMPING DURING OPENING/CLOSING)	T0098CN9	
301	,842,831,	521000-11-1-INSP(JIC) (OPERATIONAL CHECK OF STRIKER MECHANISM)	T0098CMX	
302	,831,832,	521000-12-1-OP(JIC) (OPERATIONAL CHECK OF ESCAPE SLIDE DISARMING WHEN DOOR IS OPENED FROM THE OUTSIDE)	T0098CNB	

T00AT5BE

303	832	521000-14-1-LUB-LH-AFT(JIC) (LUBRICATION OF HINGE ARM SUPPORT FITTING BEARINGS)	T0099BYN	
304	831	521000-14-1-LUB-LH-FWD(JIC) (LUBRICATION OF HINGE ARM SUPPORT FITTING BEARINGS)	T0099BYQ	
305	842	521000-14-1-LUB-RH-AFT(JIC) (LUBRICATION OF HINGE ARM SUPPORT FITTING BEARINGS)	T0099BYS	
306	841	521000-14-1-LUB-RH-FWD(JIC) (LUBRICATION OF HINGE ARM SUPPORT FITTING BEARINGS)	T0099BYU	
307	832	521121-01-1-LH-AFT-LUB(JIC) (PASSENGER / CREW DOOR)	T0099BYY	
308	831	521121-01-1-LH-FWD-LUB(JIC) (PASSENGER / CREW DOOR)	T0099BYW	
309	842	521121-01-1-RH-AFT-LUB(JIC) (PASSENGER / CREW DOOR)	T0099BZ0	
310	841	521121-01-1-RH-FWD-LUB(JIC) (PASSENGER / CREW DOOR)	T0099BZ2	
311		521121-02-1-CLOSE(JIC) (LUBRICATION OF SAFETY PIN GUIDE FITTING AND DOOR ARMING/DISARMING MECHANISM)	T0099BYC	
312	,832,841,	521121-02-1-LUB(JIC) (LUBRICATION OF SAFETY PIN GUIDE FITTING AND DOOR ARMING/DISARMING MECHANISM)	T0099BYA	
313		521121-02-1-OPEN(JIC) (LUBRICATION OF SAFETY PIN GUIDE FITTING AND DOOR ARMING/DISARMING MECHANISM)	T0099BYB	
314	,152,833,	522100-01-1-OP(JIC) (OPERATIONAL CHECK OF UNLOCKING AND OPENING FROM INSIDE IN ARMED MODE)	T00AGZ3F	
315	,843,844,	522100-02-5-FC(JIC) (FUNCTIONAL CHECK OF MANUAL AND AUTOMATIC SLIDE RELEASE SIGNAL.)	T00AGZ2Y	
316	,843,844,	522100-07-5-OP(JIC) (OPERATIONAL CHECK OF UNLOCKING AND OPENING FROM OUTSIDE IN ARMED MODE.)	T00AGZ3V	
317	44,152,84	522100-08-1-OP(JIC) (OPERATIONAL CHECK OF UNLOCKING AND OPENING FROM INSIDE AND OUTSIDE IN DISARMED POSITION - OPERATIONAL CHECK OF CLOSING AND LOCKING FROM INSIDE - OPERATIONAL CHECK OF ESCAPE SLIDE ARMING AND DISARMING)	T0098CND	
318	826	523000-01-1-AFT-LUB(JIC) (LUBRICATION OF CARGO DOOR)	T0099BZ8	
319	825	523000-01-1-FWD-LUB(JIC) (LUBRICATION OF CARGO DOOR)	T0099BZ4	
320	826	523000-03-1-AFT-LUB(JIC) (CARGO COMPARTMENT DOOR)	T0099BZ6	
321	825	523000-03-1-FWD-LUB(JIC) (CARGO COMPARTMENT DOOR)	T0099BZJ	
322	826	523119-02-2-INSP(JIC) (GENERAL VISUAL INSPECTION OF LOCKING HOOKS AND FORK FITTINGS OF AFT CARGO COMPARTMENT DOOR AT ALL FRAMES,BETWEEN LONGERON 4 AND LONGERON 5 (6 PLACES))	T0098CNV	
323	827	523300-01-1-LUB(JIC) (BULK CARGO COMPARTMENT DOOR)	T0099BZL	
324	,824,811,	524100-01-1-INSP(JIC) (DETAILED INSPECTION OF DOOR SEALS)	T0098C6Q	
325	824	524100-02-1-AFT-LUB(JIC) (LUBRICATION OF EXTERIOR AVIONIC COMPARTMENT DOOR HANDLE.)	T0099BZC	
326	811	524100-02-1-FWD-LUB(JIC) (LUBRICATION OF EXTERIOR FORWARD AVIONIC COMPARTMENT DOOR HANDLE)	T0099BZG	

T00AT5BE

327	812	524100-02-1-LH-LUB(JIC) (LUBRICATION OF EXTERIOR LATERAL LEFT AVIONIC COMPARTMENT DOOR HANDLE .)	T0099BZA	
328	822	524100-02-1-RH-LUB(JIC) (LUBRICATION OF EXTERIOR LATERAL RIGHT AVIONIC COMPARTMENT DOOR HANDLE.)	T0099BZE	
329	220	525111-01-1-INSP(JIC) (DETAILED INSPECTION OF MECHANICAL PARTS OF DOOR LOCKING SYSTEMS)	T0098C6U	
330	220	525111-02-1-OP(JIC) (OPERATIONAL CHECK OF ALL PRESSURE SENSING CHANNELS FOR RAPID DECOMPRESSION)	T0098C6W	
331	220	525111-04-1-OP(JIC) (OPERATIONAL CHECK OF DOOR OPENING IN CASE OF POWER OFF)	T0098C6Y	
332	220	525111-05-1-OP(JIC) (OPERATIONAL CHECK OF DOOR OPENING BY USING THE EMERGENCY CODE)	T0098C70	
333	210	527100-01-1-OP(JIC) (OPERATIONAL CHECK OF DOOR WARNING SYSTEM)	T0098C74	
334	,262,261,	527100-02-1-LH-AFT-LUB(JIC) (LUBRICATION OF DOOR WARNING)	T0099BYG	
335	,222,831,	527100-02-1-LH-FWD-LUB(JIC) (LUBRICATION OF DOOR WARNING)	T0099BYE	
336	,261,832,	527100-02-1-RH-AFT-LUB(JIC) (LUBRICATION OF DOOR WARNING)	T0099BYJ	
337	,222,831,	527100-02-1-RH-FWD-LUB(JIC) (LUBRICATION OF DOOR WARNING)	T0099BYL	
338	210	527300-01-1-OP(JIC) (OPERATIONAL CHECK OF EMERGENCY ESCAPE SLIDE RELEASE WARNING)	T0098C76	
339	715,716	528223-01-1-CLOSE(JIC) (NOSE GEAR DOORS DETAILED INSPECTION OF NLG AFT DOOR AFT FITTINGS, LH/RH)	T009A700	
340	715,716	528223-01-1-INSP(JIC) (NOSE GEAR DOORS DETAILED INSPECTION OF NLG AFT DOOR AFT FITTINGS, LH/RH)	T009A6ZY	
341	715,716	528223-01-1-OPEN(JIC) (NOSE GEAR DOORS DETAILED INSPECTION OF NLG AFT DOOR AFT FITTINGS, LH/RH)	T009A6ZZ	
342	220	531102-01-1-INSP(JIC) (DETAILED INSPECTION OF FORWARD PASSENGER/CREW DOOR FRAME, UPPER CORNERS, EXTERNAL SURFACE, LH/RH)	T0098CLD	
343	211	531105-01-1-LH-INSP(JIC) (MAIN STRUCTURE)	T009A71J	
344	212	531105-01-1-RH-INSP(JIC) (MAIN STRUCTURE)	T009A71L	
345	221,222	531106-01-1-INSP(JIC) (FUSELAGE SKIN AND DOOR FRAME AROUND FORWARD PASSENGER/CREW DOOR)	T009MJC1	
346	100	531111-01-1-INSP(JIC) (AVIONICS DOORS SURROUND)	T00A3BLT	
347	00,831,84	531113-01-1-INSP(JIC) (GENERAL VISUAL INSPECTION OF ATTACHMENT TO SKIN PANEL, FR 16, STRINGER 3 LH/RH)	T009A6VT	
348	200	531114-01-1-INSP(JIC) (DETAILED INSPECTION OF FUSELAGE SKIN ABOVE WINDSHIELD, BETWEEN FR 4 AND FR 12, EXTERNAL SURFACE, LH/RH)	T0098CK1	
349	200	531117-01-1-INSP(JIC) (GENERAL VISUAL INSPECTION OF FUSELAGE SIDE PANEL, BELOW COCKPIT SIDE WINDOWS, BETWEEN FR 1 AND FR 12, EXTERNAL SURFACE, LH/RH)	T0098CK3	
350	200	531118-01-1-INSP(JIC) (FUSELAGE SIDE PANEL)	T0098CLK	
351	211,212	531133-01-1-INSP(JIC) (DETAILED INSPECTION OF WINDSHIELD SIDE POST AT FR 4, LOWER ATTACHMENT, INTERNAL SIDE, LH/RH)	T009HZLJ	

T00AT5BE

352	221,222	531155-02-1-LH-INSP(JIC) (SPECIAL DETAILED INSPECTION (ROTO) OF DOOR FR 20, AT DOUBLE JOGGLE AREA IN OUTER FLANGE OF FRAME, AT DOOR STOPS NUMBER 1 AND 7 LOCATION, LH/RH)	T009A71C	
353	221,222	531155-02-1-RH-INSP(JIC) (SPECIAL DETAILED INSPECTION (ROTO) OF DOOR FR 20, AT DOUBLE JOGGLE AREA IN OUTER FLANGE OF FRAME, AT DOOR STOPS NUMBER 1 AND 7 LOCATION, LH/RH)	T009A71B	
354	28,127,82	531157-01-2-INSP(JIC) (DETAILED INSPECTION OF CONTINUITY FITTING BETWEEN FR 20 AND FR 21, AND ANGLE FITTING, BOTH SIDES OF FR 21, AT STRINGER 41 LOCATION, LH/RH)	T0098CK8	
355	27,128,82	531157-01-2-INST(JIC) (DETAILED INSPECTION OF CONTINUITY FITTING BETWEEN FR 20 AND FR 21, AND ANGLE FITTING, BOTH SIDES OF FR 21, AT STRINGER 41 LOCATION, LH/RH)	T0098CK7	
356	27,128,82	531157-01-2-REM(JIC) (DETAILED INSPECTION OF CONTINUITY FITTING BETWEEN FR 20 AND FR 21, AND ANGLE FITTING, BOTH SIDES OF FR 21, AT STRINGER 41 LOCATION, LH/RH)	T0098CK9	
357	,212,231,	531189-01-2-INSP(JIC) (DETAILED INSPECTION OF CABIN FLOOR STRUCTURE BETWEEN FR 12 AND FR 21)	T0098CJN	
358	120	531900-02-1-CLOSE(JIC) (OPERATIONAL CHECK OF THE COCKPIT DRAINAGE PIPE)	T0098CLS	
359	120,130	531900-02-1-INSP(JIC) (OPERATIONAL CHECK OF THE COCKPIT DRAINAGE PIPE)	T0098CLR	
360	120	531900-02-1-OPEN(JIC) (OPERATIONAL CHECK OF THE COCKPIT DRAINAGE PIPE)	T0098CLT	
361	,150,160,	531900-03-1-OP(JIC) (OPERATIONAL CHECK OF PISTON TYPE DRAIN VALVES IN LOWER FUSELAGE SHELL FROM OUTSIDE)	T0098CLV	
362	132,100	532132-01-1-INSP(JIC) (DETAILED INSPECTION OF FUSELAGE FORWARD CARGO DOOR HINGE FITTING AND EXTERNAL ATTACHMENT AREA)	T009A6U1	
363	131,132	532135-01-2-OP(JIC) (FWD CARGO DOOR CUTOUT LATERAL FRAMES)	T0098CXK	
364	100	532165-01-1-INSP(JIC) (GENERAL VISUAL INSPECTION OF FUSELAGE EXTERNAL SURFACE, BETWEEN FR 24 AND FR 35, FROM STRINGER 23 LH/RH TO BOTTOM CENTERLINE, EXCEPT AREAS COVERED BY BELLY FAIRING)	T0098CXH	
365	147,148	533111-01-1-INSP(JIC) (DETAILED INSP OF LOWER SURFACE OF PRESS DECK MEMBRANES, BETWEEN FR42 & FR46, INCLUDING CONNECTIONS TO LONGITUDINAL BEAMS, SIDE BOXES, SUPPORT RIBS, REAR SPAR OF CENTER WING BOX AND PRESSURE BULKHEAD)	T0098D37	
366	241,242	533139-01-1-INSP(JIC) (DETAILED INSP OF FRAME FLANGES AT FR38 & FR39, AND FR40 & FR41 BETWEEN STRINGER 12 & STRINGER 21, LH/RH, AND LONGITUDINAL BEAM FLANGE AT STRINGER 20A LH AND STRINGER 20A RH, BETWEEN FR 38 AND FR 39 A)	T009A6KA	
367	191,192	533153-02-1-INSP(JIC) (GENERAL VISUAL INSPECTION OF PRESSURE BULKHEAD AFT FACE AT FR 35 AND LOWER SKIN OF PRESSURE DECK LOWER SURFACE, BETWEEN FR 35 AND FR 36)	T0098D3L	
368	191,192	533189-01-1-INSP(JIC) (ANGLE FITTING ATTACHMENT AT FR 36 AT STRINGER STR 30 SPECIAL DETAILED INSPECTION (LFEC) OF ANGLE FITTING FORWARD ATTACHMENT, AT FRAME 36 AT STRINGER 30, LH/RH)	T009A6K5	
369	140	533900-01-1-INSP(JIC) (OPERATIONAL CHECK OF RUBBER FLAP DRAIN VALVE HOLES IN PRESSURE FLOOR FROM MLG BAY)	T0098D3Q	

T00AT5BE

370	160,150	534107-01-1-INSP(JIC) (DETAILED INSPECTION OF FUSELAGE INTERNAL STRUCTURE, BETWEEN FR 46 AND FR 65, INCLUDING AFT FACE OF PRESSURE BULKHEAD FROM STRINGER 38, LH/RH TO BOTTOM CENTER LINE)	T0098D3U	
371	100	534108-01-2-INSP(JIC) (FUSELAGE EXTERNAL SURFACE FR 47-70)	T0098D58	
372	260	534132-01-4-INSP(JIC) (DETAILED INSPECTION OF AFT PASSENGER/CREW DOOR CUTOUT, UPPER CORNERS, INCLUDING SKIN AND INTERNALLY THE VISIBLE PORTION OF THE INTERNAL DOUBLER, LH/RH)	T0098D56	
373	152	534160-02-1-INSP(JIC) (AFT CARGO DOOR CUTOUT LATERAL FRAMES)	T00AS1GB	
374	162	534172-01-2-INSP(JIC) (GENERAL VISUAL INSPECTION OF SEALING PROFILE OF BULK CARGO DOOR CUTOUT AT UPPER CORNERS)	T0098D4Y	
375	827	535900-02-1-INSP(JIC) (OPERATIONAL CHECK OF RUBBER FLAP DRAIN VALVE AT BULK CARGO COMPARTMENT DOOR FROM OUTSIDE)	T0098D2N	
376	410	545000-01-1-ENG1-INSP-CFM(JIC) (GENERAL VISUAL INSPECTION OF PYLON DRAIN SYSTEM)	T00AN6B1	
377	420	545000-01-1-ENG2-INSP-CFM(JIC) (GENERAL VISUAL INSPECTION OF PYLON DRAIN SYSTEM)	T00AN6J1	
378	410	545000-02-1-ENG1-INSP(JIC) (FLOW CHECK OF INDIVIDUAL DRAIN LINES OF PYLON SYSTEM)	T00AN65M	
379	420	545000-02-1-ENG2-INSP(JIC) (FLOW CHECK OF INDIVIDUAL DRAIN LINES OF PYLON SYSTEM)	T00AN6BD	
380	410	545000-03-1-ENG1-INSP-CFM(JIC) (DETAILED INSPECTION OF THE CAF4 SEALANT IN PYLON CANTILEVER ZONE "A")	T0098D2Z	
381	420	545000-03-1-ENG2-INSP-CFM(JIC) (DETAILED INSPECTION OF THE CAF4 SEALANT IN PYLON CANTILEVER ZONE "A")	T0098D31	
382	410	545000-04-1-ENG1-INSP-CFM(JIC) (DETAILED INSPECTION OF PYLON COMPARTMENT C DRAIN SYSTEM.)	T00AMPES	
383	420	545000-04-1-ENG2-INSP-CFM(JIC) (DETAILED INSPECTION OF PYLON COMPARTMENT C DRAIN SYSTEM.)	T00AMPEY	
384	325	553600-01-1-FC(JIC) (CHECK OF RUDDER ATTACHMENT FITTINGS FOR WEAR)	T009A6UF	
385	300	554008-01-1-INSP(JIC) (RUDDER SIDE PANELS)	T00916M1	
386	300	554009-01-1-INSP(JIC) (RUDDER SIDE PANELS)	T00916M3	
387	210	561200-01-1-LH-INSP(JIC) (DETAILED INSPECTION OF WINDOW SEALS)	T0098CZ9	
388	210	561200-01-1-RH-INSP(JIC) (DETAILED INSPECTION OF WINDOW SEALS)	T0098CZ8	
389	210	561200-02-1-LUB(JIC) (SLIDING WINDOWS)	T00AGYL3	
390	571	572007-01-2-LH-INSP(JIC) (DETAILED INSPECTION OF OUTER WING, REAR SPAR AFT FACE, BETWEEN RIB 1 AND GEAR SUPPORT RIB 5, INCLUDING REAR SPAR ANGLE)	T0098D0X	
391	671	572007-01-2-RH-INSP(JIC) (DETAILED INSPECTION OF OUTER WING, REAR SPAR AFT FACE, BETWEEN RIB 1 AND GEAR SUPPORT RIB 5, INCLUDING REAR SPAR ANGLE)	T0098D0W	
392	500,540	572049-03-1-LH-INSP(JIC) (DETAILED INSPECTION OF OUTER WING, BOTTOM SKIN, LOWER SURFACE AT DRAIN HOLES FOR TRACK CANS, 1,2,3 AND 4 (RIB BAYS 1-2, 2-3, 4-5, 5-6))	T009A6J6	

T00AT5BE

393	600,640	572049-03-1-RH-INSP(JIC) (DETAILED INSPECTION OF OUTER WING, BOTTOM SKIN, LOWER SURFACE AT DRAIN HOLES FOR TRACK CANS, 1,2,3 AND 4 (RIB BAYS 1-2, 2-3, 4-5, 5-6))	T009A6J5	
394	500	572054-02-1-LH-INSP(JIC) (DETAILED INSPECTION OF OUTER WING, BOTTOM SKIN, LOWER SURFACE AT HOLES ADJACENT TO FUEL PUMP APERTURES BETWEEN RIB 1 AND RIB 2)	T0098D0U	
395	600	572054-02-1-RH-INSP(JIC) (DETAILED INSPECTION OF OUTER WING, BOTTOM SKIN, LOWER SURFACE AT HOLES ADJACENT TO FUEL PUMP APERTURES BETWEEN RIB 1 AND RIB 2)	T0098D0T	
396	500	575158-01-5-LH-INSP(JIC) (OUTER WING BOTTOM SKIN LOWER SURFACE)	T009A6RM	
397	600	575158-01-5-RH-INSP(JIC) (OUTER WING BOTTOM SKIN LOWER SURFACE)	T009A6RN	
398	570,574	575167-01-1-LH-INSP(JIC) (DETAILED INSPECTION OF OUTER WING, BOTTOM SKIN PANELNO 3, UPPER SURFACE, BETWEEN REAR SPAR AND FALSE REAR SPAR, AND BETWEEN GEAR SUPPORT RIB 5 AND RIB 8)	T0098CVT	
399	674,670	575167-01-1-RH-INSP(JIC) (DETAILED INSPECTION OF OUTER WING, BOTTOM SKIN PANELNO 3, UPPER SURFACE, BETWEEN REAR SPAR AND FALSE REAR SPAR, AND BETWEEN GEAR SUPPORT RIB 5 AND RIB 8)	T0098CVU	
400	430	711000-C1-1-ENG1-INSP(JIC) (GENERAL VISUAL INSPECTION OF AIR INTAKE COWL AFT BULKHEAD)	T00AH4XH	
401	440	711000-C1-1-ENG2-INSP(JIC) (GENERAL VISUAL INSPECTION OF AIR INTAKE COWL AFT BULKHEAD)	T00AH56J	
402	430	711000-C4-2-ENG1-INSP(JIC) (GENERAL VISUAL INSPECTION OF FAN COWL DOORS)	T00AH4TV	
403	440	711000-C4-2-ENG2-INSP(JIC) (GENERAL VISUAL INSPECTION OF FAN COWL DOORS)	T00AH506	
404	430	711000-C5-1-ENG1-FC(JIC) (FUNCTIONAL CHECK OF PRESSURE RELIEF DOOR LATCH TENSION.)	T00AH58Y	
405	430	711000-C5-1-ENG2-FC(JIC) (FUNCTIONAL CHECK OF PRESSURE RELIEF DOOR LATCH TENSION.)	T00AH517	
406	430	711000-C6-1-ENG1-INSP(JIC) (GENERAL VISUAL INSPECTION OF FAN COWL LATCHES AND ADJACENT STRUCTURE)	T00AH59C	
407	440	711000-C6-1-ENG2-INSP(JIC) (GENERAL VISUAL INSPECTION OF FAN COWL LATCHES AND ADJACENT STRUCTURE)	T00AH4TP	
408	430	711000-C7-1-ENG1-INSP(JIC) (GENERAL VISUAL INSPECTION OF FAN COWL DOOR FIRE SEALS)	T00AH51D	
409	440	711000-C7-1-ENG2-INSP(JIC) (GENERAL VISUAL INSPECTION OF FAN COWL DOOR FIRE SEALS)	T00AH593	
410	437,438	711300-01-1-ENG1-INSP(JIC) (GENERAL VISUAL INSPECTION OF FAN COWL DOOR HINGE FITTINGS)	T0098C8U	
411	447,448	711300-01-1-ENG2-INSP(JIC) (GENERAL VISUAL INSPECTION OF FAN COWL DOOR HINGE FITTINGS)	T0098C8W	
412	440	711300-C1-1-ENG2-FC(JIC)-TAM (FAN COWLINGS)	T009VNGA	
413	440	711300-C2-1-ENG2-INSP(JIC) (FAN COWLINGS)	T00AEUTZ	
414	36,435,4€	712111-01-1-ENG1-INSP(JIC) (DETAILED INSPECTION OF FORWARD ENGINE MOUNT INSTALLATION)	T00ATG01	
415	45,446,4€	712111-01-1-ENG2-INSP(JIC) (DETAILED INSPECTION OF FORWARD ENGINE MOUNT INSTALLATION)	T00ATG03	

T00AT5BE

416	450	712111-05-4-ENG1-INSP(JIC) (SPECIAL DETAILED INSPECTION (TC) OF FORWARD ENGINE MOUNT PYLON BOLTS)	T00ATANT	
417	460	712111-05-4-ENG2-INSP(JIC) (SPECIAL DETAILED INSPECTION (TC) OF FORWARD ENGINE MOUNT PYLON BOLTS)	T0098D5U	
418	450	712112-01-1-ENG1-INSP(JIC) (FORWARD ENGINE MOUNT SPECIAL DETAILED INSPECTION (ENDOSCOPE) OF FORWARD ENGINE MOUNT LINK LUGS)	T00ATAQE	
419	460	712112-01-1-ENG2-INSP(JIC) (FORWARD ENGINE MOUNT SPECIAL DETAILED INSPECTION (ENDOSCOPE) OF FORWARD ENGINE MOUNT LINK LUGS)	T00ALA1V	
420	51,453,46	712211-03-1-ENG1-INSP(JIC) (DETAILED INSPECTION OF AFT ENGINE MOUNT INSTALLATION)	T0098C9Q	
421	51,463,46	712211-03-1-ENG2-INSP(JIC) (DETAILED INSPECTION OF AFT ENGINE MOUNT INSTALLATION)	T0098C9S	
422	450	712211-05-1-ENG1-INSP(JIC) (SPECIAL DETAILED INSPECTION (TC) OF AFT ENGINE MOUNT)	T00ATANL	
423	460	712211-05-1-ENG2-INSP(JIC) (SPECIAL DETAILED INSPECTION (TC) OF AFT ENGINE MOUNT)	T0098C9F	
424	450	712212-01-1-ENG1-INSP(JIC) (AFT ENGINE MOUNT SPECIAL DETAILED INSPECTION (ENDOSCOPE) OF AFT ENGINE MOUNT LINK LUGS)	T00ATAR6	
425	460	712212-01-1-ENG2-INSP(JIC) (AFT ENGINE MOUNT SPECIAL DETAILED INSPECTION (ENDOSCOPE) OF AFT ENGINE MOUNT LINK LUGS)	T00APZJA	
426	450	712213-01-1-ENG1-INSP(JIC) (DETAILED INSPECTION OF AFT ENGINE MOUNT PINS)	T00ATAR8	
427	460	712213-01-1-ENG2-INSP(JIC) (DETAILED INSPECTION OF AFT ENGINE MOUNT PINS)	T0098C9K	
428	440	722000-C1-1-ENG2-INSP(JIC) (FAN SECTION)	T009TDZF	
429		722000-C2-1-INSP(JIC) (DETAILED INSPECTION AND RELUBRICATION OF FAN BLADE DOVETAILS, MIDSPAN SHROUDS, RETAINERS, SPACERS, DAMPERS AND FAN DISC DOVETAIL SLOTS)	T00ATG0B	
430		722000-C2-1-INSP(JIC) (DETAILED INSPECTION AND RELUBRICATION OF FAN BLADE DOVETAILS, MIDSPAN SHROUDS, RETAINERS, SPACERS, DAMPERS AND FAN DISC DOVETAIL SLOTS)	T009KBAL	
431		723100-C2-1-INSP(JIC) (BORESCOPE INSPECTION OF HP COMPRESSOR STAGES 1, 4 AND 8)	T009KA3G	
432		723100-C2-1-INSP(JIC) (BORESCOPE INSPECTION OF HP COMPRESSOR STAGES 1, 4 AND 8)	T009KA51	
433		724000-C1-1-INSP(JIC) (BORESCOPE INSPECTION OF COMBUSTION CHAMBER LINERS, DOME AREAS, HPT NOZZLE VANES AND SHROUDS (AS FAR AS VISIBLE THROUGH TWO OPPOSITE PORTS))	T00AHLMV	
434		724000-C1-1-INSP(JIC) (BORESCOPE INSPECTION OF COMBUSTION CHAMBER LINERS, DOME AREAS, HPT NOZZLE VANES AND SHROUDS (AS FAR AS VISIBLE THROUGH TWO OPPOSITE PORTS))	T00AFNDV	
435		725000-C1-3-INSP(JIC) (BORESCOPE INSPECTION OF HPT BLADES (FROM THE FRONT AND THE REAR))	T00AHLRB	
436		725000-C1-3-INSP(JIC) (BORESCOPE INSPECTION OF HPT BLADES (FROM THE FRONT AND THE REAR))	T00AFNDD	
437		730000-C4-1-REPL(JIC) (REMOVE, INSPECT AND REPLACE FUEL FILTER ELEMENT)	T009KB3V	
438		730000-C4-1-REPL(JIC) (REMOVE, INSPECT AND REPLACE FUEL FILTER ELEMENT)	T009KAXH	

T00AT5BE

439		752000-C1-1-OP(JIC) (CHECK ECU AIR COOLING PIPE INLET/OUTLET FOR BLOCKAGE)	T009KBBU	
440		752000-C1-1-OP(JIC) (CHECK ECU AIR COOLING PIPE INLET/OUTLET FOR BLOCKAGE)	T009KAQP	
441		752000-C3-1-INSP(JIC) (GENERAL VISUAL INSPECTION OF LPT CASE AIR COOLING PIPING)	T009KB2Z	
442		752000-C3-1-INSP(JIC) (GENERAL VISUAL INSPECTION OF LPT CASE AIR COOLING PIPING)	T009KBAU	
443	460	781100-C2-1-ENG2-INSP(JIC)-TAM (HOT EXHAUST)	T0098CU9	
444	450	783000-C2-1-ENG1-INSP(JIC) (GENERAL VISUAL INSPECTION OF BLOCKER DOOR SEALS (BLOCKER DOORS DEPLOYED))	T0098CVD	
445	460	783000-C2-1-ENG2-INSP(JIC) (GENERAL VISUAL INSPECTION OF BLOCKER DOOR SEALS (BLOCKER DOORS DEPLOYED))	T0098CVF	
446	450	783000-C4-1-ENG1-INSP(JIC) (GENERAL VISUAL INSPECTION OF THRUST REVERSER HALF TENSION HOOK LATCH AND ADJACENT STRUCTURE (C DUCTS OPEN))	T00APMPG	
447	460	783000-C4-1-ENG2-INSP(JIC) (GENERAL VISUAL INSPECTION OF THRUST REVERSER HALF TENSION HOOK LATCH AND ADJACENT STRUCTURE (C DUCTS OPEN))	T00APMPL	
448	450	783000-C8-1-ENG1-INSP(JIC) (GENERAL VISUAL INSPECTION OF INNER BARREL HEATSHIELD, FIRE PROTECTIVE COATING AND FIRE SEALS (C DUCTS OPEN))	T00APZ2R	
449	460	783000-C8-1-ENG2-INSP(JIC) (GENERAL VISUAL INSPECTION OF INNER BARREL HEATSHIELD, FIRE PROTECTIVE COATING AND FIRE SEALS (C DUCTS OPEN))	T00APZ2W	
450	437,438	783100-C5-1-ENG1(JIC) (DETAILED INSPECTION OF ACTUATOR ROD END ATTACHMENTS (BLOCKER DOORS DEPLOYED))	T0098CUB	
451	447,448	783100-C5-1-ENG2(JIC) (DETAILED INSPECTION OF ACTUATOR ROD END ATTACHMENTS (BLOCKER DOORS DEPLOYED))	T0098CUD	
452	450	783100-C6-1-ENG1-FC(JIC) (OPERATIONAL CHECK OF ACTUATOR SECONDARY LOCK MECHANISM)	T00APZPV	
453	450	783100-C6-1-ENG1-OP(JIC) (OPERATIONAL CHECK OF ACTUATOR SECONDARY LOCK MECHANISM)	T00APZ2K	
454	460	783100-C6-1-ENG2-FC(JIC) (OPERATIONAL CHECK OF ACTUATOR SECONDARY LOCK MECHANISM)	T00APZ70	
455	460	783100-C6-1-ENG2-OP(JIC) (OPERATIONAL CHECK OF ACTUATOR SECONDARY LOCK MECHANISM)	T00APZ6X	
456	437,438	783100-C7-1-ENG1-INSP(JIC) (THRUST REVERSER CONTROL AND INDICATING)	T0098CWT	
457	437,447	783200-01-1-ENG1-INSP(JIC) ("C" DUCT HINGE FITTING)	T0098CUR	
458	451,461	783200-01-1-ENG2-INSP(JIC) ("C" DUCT HINGE FITTING)	T0098CUT	
459		792000-C4-2-REPL(JIC) (REMOVE AND DISCARD OIL SUPPLY FILTER)	T009KBCR	
460		792000-C7-1-INSP(JIC) (CHECK OF FWD SUMP, AFT SUMP, AGB, AND TGB SCAVENGE SCREENS)	T009KB9E	
461		792000-C8-1-INSP(JIC) (CHECK MASTER MAGNETIC CHIP DETECTOR FOR PARTICLES)	T00ATFSB	
462		792000-C8-1-INSP(JIC) (CHECK MASTER MAGNETIC CHIP DETECTOR FOR PARTICLES)	T00ANR5P	
463		IH-A320FAM-57-A4308 (JIC) (Slat End Seal Inspection)	T009WEPG	

T00AT5BE

464		T-510011-01-1-INSP(JIC) (EXTERNAL REPAIRS AND DAMAGES SURVEY)	T0098CDA	
465	110	ZL-110-01-1-INSP(JIC) (GENERAL VISUAL INSPECTION OF RADOME)	T0098BVZ	
466	122,121	ZL-121-01-1-INSP(JIC) (GENERAL VISUAL INSPECTION OF AVIONIC COMPARTMENT)	T0098BW1	
467	29,126,12	ZL-125-01-1-INSP(JIC) (GENERAL VISUAL INSPECTION OF LATERAL AVIONIC COMPARTMENT)	T0098BWD	
468	127,128	ZL-127-01-1-INSP(JIC) (GENERAL VISUAL INSPECTION OF REAR AVIONIC COMPARTMENT)	T0098BW7	
469	172,171	ZL-171-01-2-INSP(JIC) (GENERAL VISUAL INSPECTION OF AFT CABIN UNDERFLOOR COMPARTMENT)	T0098BXP	
470	191,192	ZL-191-01-1-INSP(JIC) (GENERAL VISUAL INSPECTION OF AIR CONDITIONING COMPARTMENT AND FAIRINGS)	T0098BXV	
471	195	ZL-195-01-1-LH-INSP(JIC) (GENERAL VISUAL INSPECTION OF HYDRAULIC COMPARTMENT AND FAIRINGS)	T0098BY1	
472		ZL-195-01-1-RH-INSP(JIC) (GENERAL VISUAL INSPECTION OF HYDRAULIC COMPARTMENT AND FAIRINGS)	T0098BY3	
473	200	ZL-200-02-1-INSP(JIC) (GENERAL VISUAL INSPECTION OF UPPER HALF OF FUSELAGE)	T0098BY7	
474	211,212	ZL-211-01-1-CLOSE(JIC) (GENERAL VISUAL INSPECTION OF COCKPIT)	T0098BYA	
475	212,211	ZL-211-01-1-INSP(JIC) (GENERAL VISUAL INSPECTION OF COCKPIT)	T0098BY9	
476	211,212	ZL-211-01-1-OPEN(JIC) (GENERAL VISUAL INSPECTION OF COCKPIT)	T0098BYB	
477	300	ZL-300-02-1-INSP(JIC) (GENERAL VISUAL INSPECTION OF STABILIZERS AND CONE/REAR FUSELAGE)	T0098BZ1	
478	311,312	ZL-311-01-1-INSP(JIC) (GENERAL VISUAL INSPECTION OF AFT FUSELAGE TAIL SECTION)	T0098BZ3	
479	314,313	ZL-313-01-1-INSP(JIC) (GENERAL VISUAL INSPECTION OF TAIL CONE APU AIR INTAKEAREA)	T0098BZ7	
480	315,316	ZL-315-01-1-INSP(JIC) (GENERAL VISUAL INSPECTION OF TAIL CONE APU AND ACCESSORY COMPARTMENT (EWIS))	T0098BZ5	
481	317	ZL-317-01-1-INSP(JIC) (GENERAL VISUAL INSPECTION OF TAIL CONE APU EXHAUST AREA)	T0098BZ9	
482	325	ZL-325-01-1-INSP(JIC) (GENERAL VISUAL INSPECTION OF VERTICAL STABILIZER TRAILING EDGE)	T0098BZB	
483	334	ZL-334-01-1-LH-INSP(JIC) (GENERAL VISUAL INSPECTION OF TRIMMABLE HORIZONTAL STABILIZER TRAILING EDGE)	T0098C08	
484	344	ZL-334-01-1-RH-INSP(JIC) (GENERAL VISUAL INSPECTION OF TRIMMABLE HORIZONTAL STABILIZER TRAILING EDGE)	T0098C0A	
485	11,413,41	ZL-411-01-1-ENG1-INSP(JIC) (GENERAL VISUAL INSPECTION OF UPPER FORWARD PYLON (EWIS))	T009VPVZ	
486	21,423,42	ZL-411-01-1-ENG2-INSP(JIC) (GENERAL VISUAL INSPECTION OF UPPER FORWARD PYLON (EWIS))	T009XEVS	
487	,435,445,	ZL-435-01-1-RH-INSP(JIC) (FAN AND ACCESSORY GEAR BOX)	T00AJF15	
488	437,438	ZL-437-01-1-ENG1-INSP(JIC) (FAN COWL)	T009TE6U	
489	447,448	ZL-437-01-1-ENG2-INSP(JIC) (FAN COWL)	T0098C10	

T00AT5BE

490	462,461	ZL-451-01-1-ENG2-INSP(JIC) (THRUST REVERSER)	T0098C14	
491	453,454	ZL-453-01-1-ENG1-INSP(JIC) (HOT SECTION)	T009TE74	
492	463,464	ZL-453-01-1-ENG2-INSP(JIC) (HOT SECTION)	T0098C18	
493	,473,475,	ZL-471-01-1-LH-INSP(JIC) (GENERAL VISUAL INSPECTION OF PYLON LEADING EDGE AND LOWER FAIRING (EWIS))	T0098C1A	
494	,483,485,	ZL-471-01-1-RH-INSP(JIC) (GENERAL VISUAL INSPECTION OF PYLON LEADING EDGE AND LOWER FAIRING (EWIS))	T0098C1C	
495	500	ZL-500-02-1-LH-INSP(JIC) (GENERAL VISUAL INSPECTION OF WING LOWER SURFACE INCLUDING UPPER AND LOWER SURFACES OF SLATS AND FLAPS)	T0098C1E	
496	600	ZL-500-02-1-RH-INSP(JIC) (GENERAL VISUAL INSPECTION OF WING LOWER SURFACE INCLUDING UPPER AND LOWER SURFACES OF SLATS AND FLAPS)	T0098C1G	
497	500	ZL-500-03-1-LH-INSP(JIC) (GENERAL VISUAL INSPECTION OF WING UPPER SURFACE INCLUDING SLATS, FLAPS AND SPOILERS)	T0098C1J	
498	600	ZL-500-03-1-RH-INSP(JIC) (GENERAL VISUAL INSPECTION OF WING UPPER SURFACE INCLUDING SLATS, FLAPS AND SPOILERS)	T0098C1L	
499	521	ZL-521-01-1-LH-INSP(JIC) (GENERAL VISUAL INSPECTION OF INBOARD FIXED LEADING EDGE STRUCTURE)	T0098C1N	
500	621	ZL-521-01-1-RH-INSP(JIC) (GENERAL VISUAL INSPECTION OF INBOARD FIXED LEADING EDGE STRUCTURE)	T0098C1Q	
501	522	ZL-522-01-1-LH-INSP(JIC) (GENERAL VISUAL INSPECTION OF OUTBOARD FIXED LEADING EDGE STRUCTURE)	T0098C1S	
502	622	ZL-522-01-1-RH-INSP(JIC) (GENERAL VISUAL INSPECTION OF OUTBOARD FIXED LEADING EDGE STRUCTURE)	T0098C1T	
503	531	ZL-531-01-1-LH-INSP(JIC) (GENERAL VISUAL INSPECTION OF FLAP TRACK NO 2 AND FAIRING)	T0098C27	
504	631	ZL-531-01-1-RH-INSP(JIC) (GENERAL VISUAL INSPECTION OF FLAP TRACK NO 2 AND FAIRING)	T0098C29	
505	532	ZL-532-01-1-LH-INSP(JIC) (GENERAL VISUAL INSPECTION OF FLAP TRACK NO 3 AND FAIRING)	T0098C2B	
506	632	ZL-532-01-1-RH-INSP(JIC) (GENERAL VISUAL INSPECTION OF FLAP TRACK NO 3 AND FAIRING)	T0098C2D	
507	533	ZL-533-01-1-LH-INSP(JIC) (GENERAL VISUAL INSPECTION OF FLAP TRACK NO 4 AND FAIRING)	T0098C2F	
508	633	ZL-533-01-1-RH-INSP(JIC) (GENERAL VISUAL INSPECTION OF FLAP TRACK NO 4 AND FAIRING)	T0098C2H	
509	571	ZL-571-02-1-LH-INSP(JIC) (GENERAL VISUAL INSPECTION OF MLG BAY)	T0098C31	
510	671	ZL-571-02-1-RH-INSP(JIC) (GENERAL VISUAL INSPECTION OF MLG BAY)	T0098C33	
511	572	ZL-572-01-2-LH-INSP(JIC) (GENERAL VISUAL INSPECTION OF SHROUD BOX)	T0098C35	
512	672	ZL-572-01-2-RH-INSP(JIC) (GENERAL VISUAL INSPECTION OF SHROUD BOX)	T0098C36	
513	573	ZL-573-01-1-LH-INSP(JIC) (GENERAL VISUAL INSPECTION OF INBOARD FIXED TRAILING EDGE STRUCTURE FROM SHROUD BOX TO RIB 9)	T0098C38	
514	673	ZL-573-01-1-RH-INSP(JIC) (GENERAL VISUAL INSPECTION OF INBOARD FIXED TRAILING EDGE STRUCTURE FROM SHROUD BOX TO RIB 9)	T0098C3A	

T00AT5BE

515	574	ZL-574-01-1-LH-INSP(JIC) (GENERAL VISUAL INSPECTION OF FALSE SPAR BOX)	T0098C3C	
516	674	ZL-574-01-1-RH-INSP(JIC) (GENERAL VISUAL INSPECTION OF FALSE SPAR BOX)	T0098C3E	
517	575	ZL-575-01-1-LH-INSP(JIC) (GENERAL VISUAL INSPECTION OF OUTBOARD FIXED TRAILING EDGE STRUCTURE FROM RIB 9 TO RIB 27)	T0098C3G	
518	675	ZL-575-01-1-RH-INSP(JIC) (GENERAL VISUAL INSPECTION OF OUTBOARD FIXED TRAILING EDGE STRUCTURE FROM RIB 9 TO RIB 27)	T0098C3J	
519	590	ZL-590-01-1-LH-INSP(JIC) (GENERAL VISUAL INSPECTION OF AILERON)	T0098C3L	
520	690	ZL-590-01-1-RH-INSP(JIC) (GENERAL VISUAL INSPECTION OF AILERON)	T0098C3N	
521	811	ZL-811-01-1-INSP(JIC) (GENERAL VISUAL INSPECTION OF FWD AVIONICS COMPARTMENTDOOR (INCLUDING EXTERNAL SURFACE))	T0098C4E	
522	812	ZL-812-01-1-LH-INSP(JIC) (GENERAL VISUAL INSPECTION OF LATERAL AVIONICS COMPARTMENT DOORS (INCLUDING EXTERNAL SURFACE))	T0098C48	
523	822	ZL-812-01-1-RH-INSP(JIC) (GENERAL VISUAL INSPECTION OF LATERAL AVIONICS COMPARTMENT DOORS (INCLUDING EXTERNAL SURFACE))	T0098C4A	
524	824	ZL-824-01-1-INSP(JIC) (GENERAL VISUAL INSPECTION OF REAR AVIONIC COMPARTMENTDOOR (INCLUDING EXTERNAL SURFACE))	T0098C4J	
525	,844,834,	ZL-833-01-1-INSP(JIC) (GENERAL VISUAL INSPECTION OF FWD AND AFT EMERGENCY EXITS INCLUDING DOOR SURROUND ON FUSELAGE DOOR FRAMESAND DOOR SEALS, EXTERNAL SURFACE)	T0098C5A	
526		OPEN-A320-FAM ZONA500 (Master Panel Card A320-FAM ZONA 500)	T00ATW2P	
527		CLOSE-A320-FAM ZONA500 (Master Panel Card A320-FAM ZONA 500)	T00ATW2Q	
528		OPEN-A320-FAM ZONA400 (Master Panel Card A320-FAM ZONA 400)	T00ATW2R	
529		CLOSE-A320-FAM ZONA400 (Master Panel Card A320-FAM ZONA 400)	T00ATW2S	
530		OPEN-A320-FAM ZONA200 (Master Panel Card A320-FAM ZONA 200)	T00ATW3D	
531		CLOSE-A320-FAM ZONA200 (Master Panel Card A320-FAM ZONA 200)	T00ATW3E	
532		OPEN-A320-FAM ZONA100 (Master Panel Card A320-FAM ZONA 100)	T00ATW3F	
533		CLOSE-A320-FAM ZONA100 (Master Panel Card A320-FAM ZONA 100)	T00ATW3G	
534		OPEN-A320-FAM ZONA300 (Master Panel Card A320-FAM ZONA 300)	T00ATW3H	
535		CLOSE-A320-FAM ZONA300 (Master Panel Card A320-FAM ZONA 300)	T00ATW3J	

536	120	212643-09-1-OP(JIC) (OPERATIONAL CHECK OF NRV FOR FREE MOVEMENT AND CONFIRM THE BOWL IS CLEAN.)	T00AEV45	
537	210	261600-03-1-OP(JIC) (CARGO COMPARTMENT SMOKE DETECTION)	T00APW1N	

T00AT5BE

538	210	271400-01-1-OP(JIC) (OPERATIONAL CHECK OF DAMPING MEASUREMENT BY BITE)	T009J88M	
539	210	272400-01-1-OP(JIC) (RUDDER HYDRAULIC ACTUATION)	T00APVPA	
540	210	274000-02-1-OP(JIC) (TRIMMABLE HORIZONTAL STABILIZER (THS))	T00APX7M	
541	448	302149-01-1-ENG2-INSP(JIC) (CFM ENGINE AIR INTAKE ANTI-ICE DUCT)	T0098CEW	
542	210	323000-17-1-FC(JIC) (NORMAL EXTENSION AND RETRACTION)	T00AS2DX	
543	210,148	324411-01-1-FC(JIC) (FUNCTIONAL CHECK OF PARKING/EMERGENCY BRAKE ACCUMULATOR BY READING THE CHARGE PRESSURE ON THE ACCUMULATOR GAUGE)	T00AF0QY	
544	447,448	783100-C7-1-ENG2-INSP(JIC) (THRUST REVERSER CONTROL AND INDICATING)	T0098CWV	
545	445	792000-C9-1-ENG2-OP(JIC) (DISTRIBUTION)	T00AS2NX	
546	200	R-256535-02-1-INSP(JIC) (INSPECTION OF ELT INSTALLATION CONDITION AND BITE TEST (CHECK OF ENOUGH ENERGY FROM ANTENNA))	T00AML0T	

Signatures:

Skill	Hours	Performed By (Print)	Signature	Date