




TALLY SHEET



T00E1SEN

Check Name:

HM-WP CC-N418LA DEC2018
[1C+2C+3C+4C+SC1+SC2]

Work Order No:

WO - 103866615

Station:

AUH/ADAT HGR

Start Date:

26-Dec-2018 05:00

Aircraft:

B767F - N418LA

Flight Hours:

TSN: 57247,26

SO: 57247,26

Flight Cycles:

CSN: 14849

CSO: 14849

Task List

Line	Zone	Task Name	Barcode	Checked
1	113,114	20-001-00-01-CLN(JIC) (CONTROL CABLES TURNS - FUSELAGE)	T009Z5LX	
2	113,114	20-001-00-01-INSP(JIC) (CONTROL CABLES TURNS - FUSELAGE)	T009Z5LY	
3	113,114	20-001-00-01-LUB(JIC) (CONTROL CABLES TURNS - FUSELAGE)	T009Z5LZ	
4	117,118,119	20-001-00-02-CLN(JIC) (CONTROL CABLES TURNS - FUSELAGE)	T009Z5L6	
5	117,118,119	20-001-00-02-INSP(JIC) (CONTROL CABLES TURNS - FUSELAGE)	T009Z5L5	
6	117,118,119	20-001-00-02-LUB(JIC) (CONTROL CABLES TURNS - FUSELAGE)	T009Z5LT	
7	125,126	20-001-00-04-CLN(JIC) (CONTROL CABLES TURNS - FUSELAGE)	T009Z5NJ	
8	125,126	20-001-00-04-INSP(JIC) (CONTROL CABLES TURNS - FUSELAGE)	T009Z5NQ	
9	125,126	20-001-00-04-LUB(JIC) (CONTROL CABLES TURNS - FUSELAGE)	T009Z5NR	
10	131,141,142,ZONE2	20-001-00-05-CLN(JIC) (CONTROL CABLES TURNS - FUSELAGE)	T00A1NN4	
11	131,141,142,ZONE2	20-001-00-05-INSP(JIC) (CONTROL CABLES TURNS - FUSELAGE)	T00A1NN3	
12	131,141,142,ZONE2	20-001-00-05-LUB(JIC) (CONTROL CABLES TURNS - FUSELAGE)	T00A1NN5	
13	152	20-001-00-06-CLN(JIC) (CONTROL CABLES TURNS - FUSELAGE)	T009Z5N3	
14	152	20-001-00-06-INSP(JIC) (CONTROL CABLES TURNS - FUSELAGE)	T009Z5N2	
15	152	20-001-00-06-LUB(JIC) (CONTROL CABLES TURNS - FUSELAGE)	T009Z5N4	
16	161	20-001-00-07-CLN(JIC) (CONTROL CABLES TURNS - FUSELAGE)	T009Z5QG	

T00E1SEN

17	161	20-001-00-07-INSP(JIC) (CONTROL CABLES TURNS - FUSELAGE)	T009Z5PV	
18	161	20-001-00-07-LUB(JIC) (CONTROL CABLES TURNS - FUSELAGE)	T009Z5QH	
19	165	20-001-00-08-CLN(JIC) (CONTROL CABLES TURNS - FUSELAGE)	T009Z5MV	
20	165	20-001-00-08-INSP(JIC) (CONTROL CABLES TURNS - FUSELAGE)	T009Z5MU	
21	165	20-001-00-08-LUB(JIC) (CONTROL CABLES TURNS - FUSELAGE)	T009Z5MW	
22	221,222,223,224	20-001-00-10-CLN(JIC) (CONTROL CABLES TURNS - FUSELAGE)	T00A07QP	
23	221,222,223,224	20-001-00-10-INSP(JIC) (CONTROL CABLES TURNS - FUSELAGE)	T00A07QN	
24	221,222,223,224	20-001-00-10-LUB(JIC) (CONTROL CABLES TURNS - FUSELAGE)	T00A07QQ	
25	253,254	20-001-00-13-CLN(JIC) (CONTROL CABLES TURNS - FUSELAGE)	T00A07RT	
26	253,254	20-001-00-13-INSP(JIC) (CONTROL CABLES TURNS - FUSELAGE)	T00A07RS	
27	253,254	20-001-00-13-LUB(JIC) (CONTROL CABLES TURNS - FUSELAGE)	T00A07RU	
28	311,312	20-001-00-14-CLN(JIC) (CONTROL CABLES TURNS - FUSELAGE)	T00A0QLP	
29	311,312	20-001-00-14-INSP(JIC) (CONTROL CABLES TURNS - FUSELAGE)	T00A0QLM	
30	311,312	20-001-00-14-LUB(JIC) (CONTROL CABLES TURNS - FUSELAGE)	T00A0QLN	
31	313,314	20-001-00-15-CLN(JIC) (CONTROL CABLES TURNS - FUSELAGE)	T00A0QM5	
32	313,314	20-001-00-15-INSP(JIC) (CONTROL CABLES TURNS - FUSELAGE)	T00A0QLH	
33	313,314	20-001-00-15-LUB(JIC) (CONTROL CABLES TURNS - FUSELAGE)	T00A0QLJ	
34	323	20-001-00-16-CLN(JIC) (CONTROL CABLES TURNS - FUSELAGE)	T009ZQJJ	
35	323	20-001-00-16-INSP(JIC) (CONTROL CABLES TURNS - FUSELAGE)	T009ZQJH	
36	323	20-001-00-16-LUB(JIC) (CONTROL CABLES TURNS - FUSELAGE)	T009ZQJK	
37	324	20-001-00-17-CLN(JIC) (CONTROL CABLES TURNS - FUSELAGE)	T00A0TTC	
38	324	20-001-00-17-INSP(JIC) (CONTROL CABLES TURNS - FUSELAGE)	T00A0TTB	
39	324	20-001-00-17-LUB(JIC) (CONTROL CABLES TURNS - FUSELAGE)	T00A0TUE	
40	ZONE3	20-001-00-18-CLN(JIC) (CONTROL CABLES TURNS - FUSELAGE)	T00A0QLT	
41	335	20-001-00-18-INSP(JIC) (CONTROL CABLES TURNS - FUSELAGE)	T00A0QLR	
42	ZONE3	20-001-00-18-LUB(JIC) (CONTROL CABLES TURNS - FUSELAGE)	T00A0QLS	
43	ZONE3	20-001-00-19-CLN(JIC) (CONTROL CABLES TURNS - FUSELAGE)	T00A0SZL	
44	345	20-001-00-19-INSP(JIC) (CONTROL CABLES TURNS - FUSELAGE)	T00A0SZ4	

T00E1SEN

45	ZONE3	20-001-00-19-LUB(JIC) (CONTROL CABLES TURNS - FUSELAGE)	T00A0SZM	
46	117,118,119	20-003-00-01-CLN(JIC) (DET - CONTROL CABLES - STRAIGHT RUNS)	T006KN1D	
47	117,118,119	20-003-00-01-INSP(JIC) (DET - CONTROL CABLES - STRAIGHT RUNS)	T006KN1C	
48	117,118,119	20-003-00-01-LUB(JIC) (DET - CONTROL CABLES - STRAIGHT RUNS)	T006KN1K	
49	121,122	20-003-00-02-CLN(JIC) ("DET - CONTROL CABLES - STRAIGHT RUNS)	T004RB0W	
50	121,122	20-003-00-02-INSP(JIC) ("DET - CONTROL CABLES - STRAIGHT RUNS)	T004RB0X	
51	121,122	20-003-00-02-LUB(JIC) ("DET - CONTROL CABLES - STRAIGHT RUNS)	T004RB0V	
52	125,126	20-003-00-03-CLN(JIC) ("DET - CONTROL CABLES - STRAIGHT RUNS)	T004RB1U	
53	125,126	20-003-00-03-INSP(JIC) ("DET - CONTROL CABLES - STRAIGHT RUNS)	T004RB1S	
54	125,126	20-003-00-03-LUB(JIC) ("DET - CONTROL CABLES - STRAIGHT RUNS)	T004RB1T	
55	131,132,141,142,ZONE2	20-003-00-04-CLN(JIC) ("DET - CONTROL CABLES - STRAIGHT RUNS)	T004Q80U	
56	131,132,141,142,ZONE2	20-003-00-04-INSP(JIC) ("DET - CONTROL CABLES - STRAIGHT RUNS)	T004Q80V	
57	ZONE2	20-003-00-04-LUB(JIC) ("DET - CONTROL CABLES - STRAIGHT RUNS)	T004Q80W	
58	153	20-003-00-05-CLN(JIC) ("DET - CONTROL CABLES - STRAIGHT RUNS)	T004RB0L	
59	153	20-003-00-05-INSP(JIC) ("DET - CONTROL CABLES - STRAIGHT RUNS)	T004RB0J	
60	153	20-003-00-05-LUB(JIC) ("DET - CONTROL CABLES - STRAIGHT RUNS)	T004RB0K	
61	161	20-003-00-06-CLN(JIC) ("DET - CONTROL CABLES - STRAIGHT RUNS)	T004RB0G	
62	161	20-003-00-06-INSP(JIC) ("DET - CONTROL CABLES - STRAIGHT RUNS)	T004RB0F	
63	161	20-003-00-06-LUB(JIC) ("DET - CONTROL CABLES - STRAIGHT RUNS)	T004RB0E	
64	165	20-003-00-07-CLN(JIC) ("DET - CONTROL CABLES - STRAIGHT RUNS)	T004RB1W	
65	165	20-003-00-07-INSP(JIC) ("DET - CONTROL CABLES - STRAIGHT RUNS)	T004RB1Y	
66	165	20-003-00-07-LUB(JIC) ("DET - CONTROL CABLES - STRAIGHT RUNS)	T004RB1X	
67	223,224	20-003-00-08-CLN(JIC) ("DET - CONTROL CABLES - STRAIGHT RUNS)	T004Q80J	
68	223,224	20-003-00-08-INSP(JIC) ("DET - CONTROL CABLES - STRAIGHT RUNS)	T004Q80H	
69	223,224	20-003-00-08-LUB(JIC) ("DET - CONTROL CABLES - STRAIGHT RUNS)	T004Q80K	
70	233,234	20-003-00-09-CLN(JIC) ("DET - CONTROL CABLES - STRAIGHT RUNS)	T004Q82E	
71	233,234	20-003-00-09-INSP(JIC) ("DET - CONTROL CABLES - STRAIGHT RUNS)	T004Q82F	

T00E1SEN

72	233,234	20-003-00-09-LUB(JIC) ("DET - CONTROL CABLES - STRAIGHT RUNS)	T004Q82G	
73	243,244	20-003-00-10-CLN(JIC) ("DET - CONTROL CABLES - STRAIGHT RUNS)	T004QEFE	
74	243,244	20-003-00-10-INSP(JIC) ("DET - CONTROL CABLES - STRAIGHT RUNS)	T004QEFC	
75	243,244	20-003-00-10-LUB(JIC) ("DET - CONTROL CABLES - STRAIGHT RUNS)	T004QEFD	
76	253,254	20-003-00-11-CLN(JIC) ("DET - CONTROL CABLES - STRAIGHT RUNS)	T004Q80Z	
77	253,254	20-003-00-11-INSP(JIC) ("DET - CONTROL CABLES - STRAIGHT RUNS)	T004Q810	
78	253,254	20-003-00-11-LUB(JIC) ("DET - CONTROL CABLES - STRAIGHT RUNS)	T004Q811	
79	143	20-005-00-01-CLN(JIC) (CONTROL CABLES - EXPOSED)	T00D6TTB	
80	143	20-005-00-01-INSP(JIC) (CONTROL CABLES - EXPOSED)	T00D6TT9	
81	143	20-005-00-01-LUB(JIC) (CONTROL CABLES - EXPOSED)	T00D6TTA	
82	144	20-005-00-02-CLN(JIC) (CONTROL CABLES - EXPOSED)	T00D6TU7	
83	144	20-005-00-02-INSP(JIC) (CONTROL CABLES - EXPOSED)	T00D6TTL	
84	144	20-005-00-02-LUB(JIC) (CONTROL CABLES - EXPOSED)	T00D6TU8	
85	551	20-005-00-03-CLN(JIC) (CONTROL CABLES - EXPOSED)	T00D6VRH	
86	551	20-005-00-03-INSP(JIC) (CONTROL CABLES - EXPOSED)	T00D6VQL	
87	551	20-005-00-03-LUB(JIC) (CONTROL CABLES - EXPOSED)	T00D6VRJ	
88	552	20-005-00-04-CLN(JIC) (CONTROL CABLES - EXPOSED)	T00D6VS0	
89	552	20-005-00-04-INSP(JIC) (CONTROL CABLES - EXPOSED)	T00D6VRZ	
90	552	20-005-00-04-LUB(JIC) (CONTROL CABLES - EXPOSED)	T00D6VS1	
91	561	20-005-00-05-CLN(JIC) (CONTROL CABLES - EXPOSED)	T00D747B	
92	561	20-005-00-05-INSP(JIC) (CONTROL CABLES - EXPOSED)	T00D7474	
93	561	20-005-00-05-LUB(JIC) (CONTROL CABLES - EXPOSED)	T00D747A	
94	651	20-005-00-06-CLN(JIC) (CONTROL CABLES - EXPOSED)	T00D6NDV	
95	651	20-005-00-06-INSP(JIC) (CONTROL CABLES - EXPOSED)	T00D6NDT	
96	651	20-005-00-06-LUB(JIC) (CONTROL CABLES - EXPOSED)	T00D6NDU	
97	652	20-005-00-07-CLN(JIC) (CONTROL CABLES - EXPOSED)	T00D6NE0	
98	652	20-005-00-07-INSP(JIC) (CONTROL CABLES - EXPOSED)	T00D6NDZ	
99	652	20-005-00-07-LUB(JIC) (CONTROL CABLES - EXPOSED)	T00D6NE1	

T00E1SEN

100	661	20-005-00-08-CLN(JIC) (CONTROL CABLES - EXPOSED)	T00D6NE8	
101	661	20-005-00-08-INSP(JIC) (CONTROL CABLES - EXPOSED)	T00D6NDS	
102	661	20-005-00-08-LUB(JIC) (CONTROL CABLES - EXPOSED)	T00D6NE9	
103	133,134,ZO NE5	20-012-02-01-INSP(JIC)-LAN (WING CENTER SECTION)	T004RYKT	
104	133,134	20-012-02-01-REINS(JIC)-LAN (WING CENTER SECTION)	T004RYKU	
105	133,134	20-012-02-01-REM(JIC)-LAN (WING CENTER SECTION)	T004RYKV	
106	119	20-059-00-01-CLN(JIC) (MAIN EQUIPMENT CENTER)	T004QMML	
107	119	20-060-00-01-INSP(JIC) (MAIN EQUIPMENT CENTER)	T004QJMW	
108	119	20-061-00-01-INSP(JIC) (MAIN EQUIPMENT CENTER)	T004QFQD	
109	121,122	20-062-00-01-CLN(JIC) (FORWARD CARGO COMPARTMENT)	T004RYL9	
110	121,122	20-062-00-01-REINS(JIC) (FORWARD CARGO COMPARTMENT)	T004RYL7	
111	121,122	20-062-00-01-REM(JIC) (FORWARD CARGO COMPARTMENT)	T004RYL8	
112	121,122	20-063-00-01-INSP(JIC) (FORWARD CARGO COMPARTMENT)	T004QFQP	
113	122	20-064-00-01-INSP(JIC) (FORWARD CARGO COMPARTMENT)	T004QFSJ	
114	123,124	20-065-00-01-CLN(JIC) (AREA BELOW FWD CARGO COMPARTMENT)	T004QKK1	
115	125,126	20-066-00-01-CLN(JIC) (AREA AFT FWD CARGO COMPARTMENT)	T004QKK9	
116	125,126	20-067-00-01-INSP(JIC) (AREA AFT OF FWD CARGO COMPARTMENT)	T004QFPV	
117	131,132	20-068-00-01-CLN(JIC) (AREA ABOVE WING CENTER SECTION)	T004QU7E	
118	131,132	20-068-00-01-REINS(JIC) (AREA ABOVE WING CENTER SECTION)	T004QU7D	
119	131,132	20-068-00-01-REM(JIC) (AREA ABOVE WING CENTER SECTION)	T004QU7F	
120	143,144	20-071-00-01-INSP(JIC) (MAIN WHEEL WELL)	T009YGYT	
121	153,154	20-074-00-01-CLN(JIC) (AFT CARGO COMPARTMENT)	T004RYL3	
122	153,154	20-074-00-01-REINS(JIC) (AFT CARGO COMPARTMENT)	T004RYL1	
123	153,154	20-074-00-01-REM(JIC) (AFT CARGO COMPARTMENT)	T004RYL2	
124	153,154	20-075-00-01-INSP(JIC) (AFT CARGO COMPARTMENT)	T004QLLU	
125	153,154	20-075-00-01-REINS(JIC) (AFT CARGO COMPARTMENT)	T004QLLV	
126	153,154	20-075-00-01-REM(JIC) (AFT CARGO COMPARTMENT)	T004QLLW	
127	153,154	20-076-00-01-INSP(JIC) (AFT CARGO COMPARTMENT)	T004QFPZ	

T00E1SEN

128	155,156	20-077-00-01-CLN(JIC) (AREA BELOW AFT CARGO COMPARTMENT)	T004RMYN	
129	163,164	20-080-00-01-CLN(JIC) (AREA BELOW BULK CARGO COMPARTMENT)	T004QHHH	
130	165,166	20-082-00-01-INSP(JIC) (AREA AFT OF BULK CARGO COMPARTMENT)	T004QGXS	
131	211,212	20-083-00-01-CLN(JIC) (CONTROL CABIN)	T004QKLU	
132	211,212	20-083-00-01-REINS(JIC) (CONTROL CABIN)	T004QKLV	
133	211,212	20-083-00-01-REM(JIC) (CONTROL CABIN)	T004QKLT	
134	211,212	20-084-00-01-INSP(JIC) (CONTROL CABIN)	T004QU5X	
135	211,212	20-084-00-01-REINS(JIC) (CONTROL CABIN)	T004QU5Y	
136	211,212	20-084-00-01-REM(JIC) (CONTROL CABIN)	T004QU5Z	
137	311,312	20-098-00-01-INSP(JIC) (AREA AFT OF PRESS B/H TO BS 1725.5)	T004QWF0	
138	313,314	20-099-00-01-INSP(JIC) (STABILIZER TORSION BOX COMPARTMENT)	T004QW7S	
139	315,316	20-100-00-01-INSP(JIC) (APU COMPARTMENT)	T009YGDJ	
140	315,316	20-101-00-01-INSP(JIC) (APU COMPARTMENT)	T009YGY2	
141	411	20-102-00-01-INSP(JIC) (ENGINE 1)	T009YGDF	
142	421	20-103-00-01-INSP(JIC) (ENGINE 2)	T009YGDP	
143	431	20-104-00-01-INSP(JIC) (FORWARD FAIRING - STRUT 1)	T004QKQR	
144	441	20-105-00-01-INSP(JIC) (FORWARD FAIRING - STRUT 2)	T004QKN6	
145	511	20-108-00-01-INSP(JC) (L WING LE TO FRONT SPAR - INBOARD)	T004QLMC	
146	611	20-109-00-01-INSP(JIC) (R WING LE TO FRONT SPAR - INBOARD)	T004QLPV	
147	135	21-001-00-01-INSP-LH(JIC) (CABIN AIR SUPPLY CHECK VALVE)	T00E5VBK	
148	136	21-001-00-01-INSP-RH(JIC) (CABIN AIR SUPPLY CHECK VALVE)	T004RM3Z	
149	220,230,240,250	21-002-00-04-CLN(JIC) (RETURN AIR GRILLES)	T00D61P8	
150	220,230,240,250	21-002-00-04-REINS(JIC) (RETURN AIR GRILLES)	T00D61P9	
151	220,230,240,250	21-002-00-04-REM(JIC) (RETURN AIR GRILLES)	T00D61PA	
152	221	21-006-01-02-SVC(JIC) (GALLEY VENTILATION FILTERS)	T00A0PM6	
153	165	21-007-00-01-INSP(JIC) (CABIN PRESSURE OUTFLOW VALVE)	T00D50ZN	
154	165	21-008-00-01-CLN(JIC) (CABIN PRESSURE OUTFLOW VALVE)	T00D50ZU	
155	165,212	21-009-00-01-OP(JIC) (CABIN PRESSURE OUTFLOW VALVE)	T00D4GKM	

T00E1SEN

156	121	21-010-00-01-OP(JIC) (POSITIVE PRESSURE RELIEF VALVES)	T009X6BU	
157	121	21-011-00-01-SVC(JIC) (POSITIVE PRESS RELIEF VALVE FILTERS)	T004QMMB	
158	119,211,212	21-012-00-01-OP(JIC) (CABIN ALTITUDE WARNING SWITCH)	T004PPC8	
159	120,211	21-013-00-03-OP(JIC) (FWD CARGO HEATING SHUTOFF VALVE)	T006SKQ3	
160	211,212,162,156,155,153	21-013-01-04-OP(JIC) (AFT/BULK CARGO HEATING SHUTOFF VALVE)	T0057G7J	
161	124,136	21-014-00-01-FC(JIC) (FWD CARGO OVERHEAT TEMP SWITCH)	T00ARWPV	
162	119,153,155,163	21-014-01-01-FC(JIC) (AFT CARGO OVERHEAT TEMP SWITCH)	T00ARWUB	
163	155,163	21-014-01-02-FC(JIC) (BULK CARGO OVERHEAT TEMPERATURE SWITCHES)	T00ARWWF	
164	150,160,211,212	21-014-01-05-FC(JIC) (AFT/BULK CARGO OVERHEAT TEMP SWITCH)	T0057FHD	
165	119,212	21-015-00-01-OP-LH(JIC) (PACK TEMPERATURE CONTROLLERS)	T00D4GLJ	
166	119,212	21-015-00-01-OP-RH(JIC) (PACK TEMPERATURE CONTROLLERS)	T00E5VJ1	
167	119,135,136,212	21-016-00-01-OP(JIC) (STANDBY PACK TEMPERATURE CONTROLLER)	T00D5M6Z	
168	135	21-017-00-01-SVC-LH(JIC) (LH COOLING PACK HEAT EXCHANGERS)	T00A1J3R	
169	136	21-017-00-01-SVC-RH(JIC) (RH COOLING PACK HEAT EXCHANGERS)	T00D0LNC	
170	135	21-018-00-01-FC-LH(JIC) (COMPRESSOR OUTLET OVERHEAT SWITCH)	T004RHV4	
171	136	21-018-00-01-FC-RH(JIC) (COMPRESSOR OUTLET OVERHEAT SWITCH)	T00E5VGM	
172	135,190	21-019-00-01-FC-LH(JIC) (PACK OVERHEAT SWITCH)	T004QJGP	
173	136,190	21-019-00-01-FC-RH(JIC) (PACK OVERHEAT SWITCH)	T00E5W0H	
174	118,121,212	21-020-00-07-OP(JIC) (MANIFOLD INTERCONNECT VALVE)	T009X8SG	
175	121,122	21-021-00-01-INSP(JIC) (E/E COOLING SUP/EXH FAN CHECK VALVES)	T004RUKH	
176	121,122	21-021-00-01-INST(JIC) (E/E COOLING SUP/EXH FAN CHECK VALVES)	T004RUKJ	
177	121,122	21-021-00-01-REM(JIC) (E/E COOLING SUP/EXH FAN CHECK VALVES)	T004RUKK	
178	121,122	21-021-00-01-TEST(JIC) (E/E COOLING SUP/EXH FAN CHECK VALVES)	T004RUKL	
179		21-022-00-07-OP(JIC) (E/E COOLING OVERRIDE VALVE)	T009X8SP	
180	121	21-023-00-01-FC(JIC) (E/E COOLING SKIN TEMPERATURE SENSOR)	T004RA5S	
181	121	21-023-00-01-REINS(JIC) (E/E COOLING SKIN TEMPERATURE SENSOR)	T004RA5U	
182	121	21-023-00-01-REM(JIC) (E/E COOLING SKIN TEMPERATURE SENSOR)	T004RA5T	

T00E1SEN

183	121,122	21-024-00-01-INSP(JIC) (E/E COOLING SYSTEM CONICAL SCREENS)	T009Y471	
184	117,233,234	21-025-00-05-FC(JIC) (ZONE DUCT OVERHEAT SWITCH)	T0057HJ8	
185	233,234,117	21-025-00-05-REINS(JIC) (ZONE DUCT OVERHEAT SWITCH)	T0057HJG	
186	117,233,234	21-025-00-05-REM.(JIC) (ZONE DUCT OVERHEAT SWITCH)	T0057HJF	
187	212	21-026-01-01-OP(JIC) (E/E COOLING SYSTEM EQUIP COOL TEST)	T00D4GLM	
188	121	21-029-00-01-CLN(JIC) (FWD E / E COOLING AIR CLEANER)	T00D6N4U	
189	119,212	21-031-01-07-FC(JIC) (E/E COOLING SYSTEM DIFF PRESS SWITCH)	T00D50ZH	
190	135,211	21-035-02-01-OP-LH(JIC) (PACK LOW LIMIT VALVE PNEUMATIC CHECK)	T009X7RA	
191	136,211	21-035-02-01-OP-RH(JIC) (PACK LOW LIMIT VALVE PNEUMATIC CHECK)	T00E5W27	
192	123,211,212	21-038-01-01-CLN(JIC) (E/E COOLING OVERHEAT SWITCH)	T00D5JRU	
193	123,211,212	21-038-01-01-REINS(JIC) (E/E COOLING OVERHEAT SWITCH)	T00D5JRT	
194	123,211,212	21-038-01-01-REM(JIC) (E/E COOLING OVERHEAT SWITCH)	T00D5JRV	
195	121,122	21-041-01-01-CLN(JIC) (E/E COOLING SUPPLY AND EXHAUST FAN)	T009ZXUE	
196	121,122	21-041-01-01-FC(JIC) (E/E COOLING SUPPLY AND EXHAUST FAN)	T009ZXU2	
197	121,122	21-041-01-01-REINS(JIC) (E/E COOLING SUPPLY AND EXHAUST FAN)	T009ZXU3	
198	121,122	21-041-01-01-REM(JIC) (E/E COOLING SUPPLY AND EXHAUST FAN)	T009ZXU1	
199	122	21-041-01-02-CLN(JIC) (RST - E/E COOLING EXHAUST FANS)	T009ZXU6	
200	135	21-043-01-01-INSP-LH(JIC) (TRIM AIR SUPPLY CHECK VALVES)	T00D788L	
201	136	21-043-01-01-INSP-RH(JIC) (TRIM AIR SUPPLY CHECK VALVES)	T00E5WDS	
202	125,126,211,212	21-051-00-01-OP(JIC) (MAIN DECK AIR DISTRIBUTION SHUTOFF)	T00D4B2B	
203	118,123	21-058-01-01-CLN(JIC) (E/E COOLING LOW FLOW DETECTORS)	T00D6N4Z	
204	118,123	21-058-01-01-FC(JIC) (E/E COOLING LOW FLOW DETECTORS)	T00D6N50	
205	118,123	21-058-01-01-REINS(JIC) (E/E COOLING LOW FLOW DETECTORS)	T00D6N4Y	
206	118,123	21-058-01-01-REM(JIC) (E/E COOLING LOW FLOW DETECTORS)	T00D6N51	
207	119,211,212,ZONE3	22-008-01-01-OP(JIC) (YAW DAMPER SERVO SOLENOID VALVE)	T009X8U7	
208	644,667,544,567,325,326,336,337,338,346,347,348	23-002-00-01-INSP(JIC) (STATIC DISCHARGERS)	T006NTTH	

T00E1SEN

209	119	24-004-00-01-OP(JIC) ("FNC - BUS POWER CONTROL UNIT (BPCU))	T00D4J91	
210	212	24-009-00-01-OP(JIC) (OPERATIONAL CHECK - DC TIE CONTROL UNIT & DC TIE RELAY)	T00D49AB	
211	212	24-010-01-01-FC(JIC) (STANBY POWER SYSTEM)	T00D49A4	
212	144,119,ZO NE3,212	24-014-00-01-FC(JIC) (FUNCTIONAL CHECK - HYDRAULIC MOTOR GENERATOR SYSTEM)	T009X8RR	
213	212	24-014-01-01-OP(JIC) (INSTRUMENT BUS VOLTAGE SENSING UNIT)	T00D49AD	
214	119,212	24-015-02-01-OP(JIC) (OPERATIONAL CHECK - AUTOLAND DC TIE)	T00D4B2X	
215	411	24-020-02-01-SVC(JIC) (RESTORE - ENGINE 1 IDG HEAT EXCHANGER AIR SHUT-OFF VALVE FILTER (CF6-80C ENGINES))	T00D5SPM	
216	421	24-020-02-02-SVC(JIC) (RESTORE - ENGINE 2 IDG HEAT EXCHANGER AIR SHUT-OFF VALVE FILTER (CF6-80C ENGINES))	T00D6GUQ	
217	124	24-041-01-01-INSP(JIC) (GENERAL VISUAL INSPECTION - EXTERNAL POWER RECEPTACLE PINS)	T00D5N38	
218	100	24-041-02-01-FNC(JIC) (AIRPLANE EXTERNAL POWER RECEPTACLE NEUTRAL PIN CONTINUITY TO AIRFRAME GROUND)	T00E0EKG	
219	210	25-001-00-01-OP(JIC) (OPERATIONAL - CREW SEAT ADJUSTMENT / LOCK MECHANISM)	T00D5102	
220	210	25-002-00-01-OP(JIC) (OPERATIONAL - CREW SEAT HARNESS / INERTIA REEL)	T00D5107	
221	121,122,15 3,154	25-007-00-01-LUB(JIC) (ROLLOUT STOP SHAFT/CAM FOLLOWER/PAWL)	T00D66Y3	
222	210	25-012-00-01-INSP(JIC) (VISUAL CHECK - FLIGHT COMPARTMENT ESCAPE ROPES)	T009X73T	
223	221	25-012-01-01-INSP(JIC) (CREW ENTRY DOOR ESCAPE ROPE)	T00D4J94	
224	200	25-018-00-01-GRP01-INSP(JIC) (CHECK/INSP - DETACHABLE EMERGENCY EQUIPMENT)	T00EEBRQ	
225	200	25-038-01-01-CLN(JIC) (GALLEY OVEN)	T00D4GM9	
226	210	25-041-01-01-INSP(JIC) (EMERGENCY ESCAPE DESCENT DEVICES)	T00D4J9B	
227	200	25-044-00-01-OP(JIC) (SUPERNUMERARY SEATS RESTRAINT)	T00D4B3B	
228	437,447,12 0,122,212	26-004-00-01-OP(JIC) (OPERATIONAL CHECK - ENGINE FIRE SWITCHES)	T009Y26Y	
229	122,212	26-006-00-01-OP(JIC) (ENG FIRE EXT BOTTLE PRESSURE SWITCH)	T00D4B3W	
230	120,143,21 2,314	26-007-00-01-OP(JIC) (OPERATIONAL CHECK - APU FIRE SWITCH)	T009X1JP	
231	212,314	26-009-00-01-OP(JIC) (OPERATIONAL CHECK - APU FIRE EXT BOTTLE PRESSURE SWITCH)	T00D49AY	
232	122,211	26-010-00-01-OP(JIC) (CARGO FIRE EXTINGUISHING ARMED SWITCHES)	T00D7DXS	
233	122,212	26-012-00-01-OP-BOTTLE 1(JIC) (CARGO FIRE EXTINGUISHER BOTTLE PRESSURE SWITCHES)	T00E5XUJ	
234	122,212	26-012-00-01-OP-BOTTLE 2(JIC) (CARGO FIRE EXTINGUISHER BOTTLE PRESSURE SWITCHES)	T00E5Y27	
235	122,212	26-012-00-01-OP-BOTTLE 2A(JIC) (CARGO FIRE EXTINGUISHER BOTTLE PRESSURE SWITCHES)	T00D4B4R	

T00E1SEN

236	200	26-013-00-01-INSP(JIC) (PORTABLE HALON FIRE EXTINGUISHERS)	T00D4B5F	
237	220,230,240,250	26-014-00-01-INSP(JIC) (LAV WASTE COMPT FIRE EXTINGUISHERS)	T00D510H	
238	122,211	26-016-00-01-OP(JIC) (CARGO FIRE EXTINGUISHER BOTTLE RELAYS)	T00D7AVS	
239	121,122,212	26-017-00-01-FC-AFT(JIC) (CARGO FIRE EXT DISCHARGE SYSTEM)	T004QHHP	
240	121,122,212	26-017-00-01-FC-FWD(JIC) (CARGO FIRE EXT DISCHARGE SYSTEM)	T00E5XV8	
241	200	26-018-00-01-OP(JIC) (OPERATIONAL - LAVATORY SMOKE DETECTORS)	T00D4B5U	
242	119,120,161,212	26-020-01-01-OP(JIC) (FIRE DETECTION SYSTEM FAIL LIGHT)	T00D747X	
243	233,223,224,234,243,244,253,254	26-025-00-01-INSP(JIC) (SMOKE DETECTOR SAMPLING ORIFICES)	T00D510Y	
244	121,122,153,154,211,212	26-026-00-01-OP(JIC) (SMOKE DETECTOR VACUUM EJECTOR)	T009X8TD	
245	212,223,211,224,233,234,243,244,253,254	26-027-00-01-OP(JIC) (SMOKE DETECTOR SAMPLING TUBE ORIFICE)	T009X8S2	
246	126,211,125,212	26-028-00-01-OP(JIC) (VACUUM PRESSURE SWITCH)	T009X8SJ	
247	211,212,223,224,233,234,243,244,253,254	26-029-00-01-OP(JIC) (SMOKE DETECTOR SAMPLING TUBES)	T009X8S3	
248	121,122,153,154,161,162,211,212	26-030-00-01-OP(JIC) (LOWER LOBE CARGO SMOKE DETECTION)	T009X1K9	
249	121,122,153,154,161,162,211,212	26-031-00-01-INSP(JIC) (SMOKE DETECTOR SAMPLING ORIFICES)	T00D49AT	
250		26-032-00-01-OP(JIC) (SMOKE DETECTOR SAMPLING TUBES)	T009X1JM	
251	121,153	26-033-01-01-CLN(JIC) (CLEAN CARGO SMOKE DET HEATER TUBES)	T0057HMJ	
252	121,153	26-033-01-01-FC(JIC) (CLEAN CARGO SMOKE DET HEATER TUBES)	T0057HMK	
253	121,153	26-034-00-01-OP(JIC) (CARGO DETECTOR HEATERS/CONTROLLERS)	T00D73YG	
254	211,ZONE5	27-007-00-01-OP(JIC) (DUAL AILERON CONTROL OVERRIDE SYSTEM)	T006N36Y	
255	ZONE3,211	27-015-00-02-OP(JIC) (RUDDER RATIO CHANGER BYPASS VALVE)	T00D73ZM	
256	211,ZONE3	27-017-00-01-OP(JIC) (ELEVATOR DUAL CONTROL PATH OVERRIDE)	T006N51K	
257	119,211,212	27-022-00-01-OP(JIC) (OPERATIONAL - STALL WARNING SYSTEM)	T00D74VM	
258	211,212,312	27-024-00-01-FC(JIC) (STABILIZER TRIM POSITION TRANSMITTER)	T006N48J	

T00E1SEN

259	211,ZONE3	27-025-00-01-OP(JIC) (STAB TRIM CNTRL COL CUTOFF SWITCHES)	T006N485	
260	211	27-026-00-01-OP(JIC) (STAB TRIM CUTOOTPEDESTAL)	T00D73ZZ	
261	312,311	27-028-00-01-INSP(JIC) (GVI - STAB TRIM ACTUATOR ATTACHMENT GIMBAL)	T00D6EK9	
262	212	27-036-00-01-OP(JIC) (ALT TE FLAP POWER DRIVE SYSTEM)	T00D74ZT	
263	144,212,ZO NE5	27-037-00-02-OP(JIC) (OPERATIONAL - TE FLAP FAILURE PROTECTION SYSTEM)	T00D74Z9	
264	144,211,21 2,730,740,5 55,566	27-038-00-01-LUB(JIC) (LEFT TE FLAP COMPONENTS)	T00D67GW	
265	144,211,21 2,655,666,7 30,740	27-038-00-02-LUB(JIC) (RIGHT TE FLAP COMPONENTS)	T00D67HA	
266	144,212,ZO NE5	27-042-00-01-OP(JIC) (TE FLAP ASYMMETRY PROTECTION SYSTEM)	T006N36F	
267	610,510,21 2	27-043-00-01-OP(JIC) (OPERATIONAL - LE SLAT FAILURE PROTECTION SYSTEM)	T00D77VC	
268	510,610,21 2	27-044-00-01-OP(JIC) (LE SLAT ASYMMETRY PROTECTION SYSTEM)	T006N3JC	
269	211,212	27-045-00-01-OP(JIC) (AUTO SPEEDBRAKE)	T00D7502	
270	212	27-047-00-01-OP(JIC) (LE SLAT ALTERNATE DRIVE SYSTEM)	T00D7506	
271	144,211,21 2,710,730,7 40	27-047-01-01-FC(JIC) (LE SLAT ALTERNATE DRIVE MOTORS)	T00A1S2F	
272	144,211,21 2,710,730,7 40	27-047-01-01-INSP(JIC) (LE SLAT ALTERNATE DRIVE MOTORS)	T00A1S2D	
273	710,730,74 0,144,211,2 12	27-047-01-01-SVC(JIC) (LE SLAT ALTERNATE DRIVE MOTORS)	T00A1S2E	
274	520,125,51 0,126	27-048-01-01-LUB(JIC) (LEFT LE SLAT DRIVE SHAFT COUPLINGS)	T00D67H4	
275	610,620	27-048-01-02-LUB(JIC) (RIGHT LE SLAT DRIVE SHAFT COUPLINGS)	T00D67HN	
276	211	27-052-00-01-OP(JIC) (ALTERNATE HORIZ STAB TRIM SYSTEM)	T00D7403	
277	311,312	27-053-01-01-SVC(JIC) (SERVICE - STABILIZER TRIM BALL-SCREW ACTUATOR)	T00D6VSE	
278	212	27-054-01-01-OP(JIC) (TE FLAP / LE SLAT SHUTOFF VALVE MODULE)	T00D751K	
279	211,212	27-055-00-01-OP(JIC) (STAB TRIM OVERRIDE WITH SPLIT COLUMN)	T009WSPV	
280	512,522,52 3,524,525,1 43,211	27-055-01-01-FC(JIC) (FUNCTIONAL - LE SLAT RETRACT/EXTEND STOP GAPS -L)	T009XMEX	
281	143,211,61 2,622,623,6 24,625	27-055-01-02-FC(JIC) (FUNCTIONAL - LE SLAT RETRACT/EXTEND STOP GAPS - R)	T009XMD8	
282	211,212,31 1,312	27-056-00-01-OP(JIC) (STABILIZER TRIM SECONDARY BRAKES)	T004QCB1	
283	211,212,31 2,313,314,3 41	27-059-00-01-FC(JIC) (ELEVATOR HYDRAULIC RATE FUSES)	T004RB6Q	
284	311	27-060-00-01-FC(JIC) (RUDDER HYDRAULIC RATE FUSES)	T004RB63	

T00E1SEN

285	119	27-064-00-02-OP(JIC) (OPERATIONAL - TE FLAP LOAD RELIEF ACTUATOR/RELAY)	T00D5BUS	
286	119	27-065-00-02-FC(JIC) (FUNCTIONAL - TE FLAP LOAD RELIEF SYSTEM)	T00BFFP8	
287	211,212,73 0,740,510,5 20,610,620	27-068-00-01-FC(JIC) (LE SLAP DRIVE OFFSET GEARBOX)	T00A1S1Z	
288	730,740,51 0,520,610,6 20,211,212	27-068-00-01-SVC(JIC) (LE SLAP DRIVE OFFSET GEARBOX)	T00A1S1Y	
289	521	27-068-01-01-LUB(JIC) (L OUTBD LE SLAT TRK HOUSING/DRAIN TUBE)	T00D7AVK	
290	621	27-068-01-02-LUB(JIC) (R OUTBD LE SLAT TRK HOUSING/DRAIN TUBE)	T00D77W3	
291	211,212,51 0,520	27-069-00-01-FC(JIC)-LAN (LE SLAT DRIVE NO-BACK BRAKES)	T004RX6M	
292	211,212,51 0,520	27-069-00-01-INSP(JIC)-LAN (LE SLAT DRIVE NO-BACK BRAKES)	T004RX6N	
293	211,212,51 0,520	27-069-00-01-REINS(JIC)-LAN (LE SLAT DRIVE NO-BACK BRAKES)	T004RX6Q	
294	211,212,51 0,520	27-069-00-01-REM(JIC)-LAN (LE SLAT DRIVE NO-BACK BRAKES)	T004RX6P	
295	211,212,61 0,620	27-069-00-02-FC(JIC)-LAN (LE SLAT DRIVE NO-BACK BRAKES)	T004RX78	
296	211,212,61 0,620	27-069-00-02-INSP(JIC)-LAN (LE SLAT DRIVE NO-BACK BRAKES)	T004RX79	
297	211,212,61 0,620	27-069-00-02-REINS(JIC)-LAN (LE SLAT DRIVE NO-BACK BRAKES)	T004RX7B	
298	211,212,61 0,620	27-069-00-02-REM(JIC)-LAN (LE SLAT DRIVE NO-BACK BRAKES)	T004RX7A	
299	211,212,73 0,740,510,5 20,610,620	27-071-01-01-FC(JIC) (ALT TE FLAP POWER DRIVE MOTOR)	T00A1S2P	
300	730,740,51 0,520,610,6 20,211,212	27-071-01-01-SVC(JIC) (ALT TE FLAP POWER DRIVE MOTOR)	T00A1S2Q	
301	561	27-082-01-01-LUB(JIC) (OUTBOARD AILERON HINGES - LEFT)	T00D6EKF	
302	661	27-082-01-02-LUB(JIC) (OUTBOARD AILERON HINGES - RIGHT)	T00D6TUB	
303	143,144,73 0,ZONE5	27-086-01-01-LUB(JIC) (LH LCCA TORQUE TUBE ASSEMBLY)	T00D67HQ	
304	542	28-003-00-01-INSP(JIC) (DET-SURGE TANK FLAME ARRESTOR - L)	T0071D54	
305	642	28-003-00-02-INSP(JIC) (DET - SURGE TANK FLAME ARRESTOR - R)	T0071D4X	
306	542	28-004-00-01-OP(JIC)-LAN (SURGE TANK PRESSURE RELIEF VALVE - L)	T000C96Y	
307	642	28-004-00-02-OP(JIC)-LAN (SURGE TANK PRESSURE RELIEF VALVE - R)	T000C970	
308	531,532	28-005-00-01-CLN(JIC) (AUTO SUMPING MOTIVE FLOW SCREENS - L)	T00A125C	
309	631,632	28-005-00-02-CLN(JIC) (AUTO SUMPING MOTIVE FLOW SCREENS - R)	T00A1248	

T00E1SEN

310	155,135,ZONE3	28-006-00-01-FC(JIC) (FUNCTIONAL - APU FUEL SUPPLY LINE SHROUD)	T009WSY7	
311	212,ZONE5	28-009-01-01-OP(JIC) (FUEL CROSSFEED VALVE)	T00D49BP	
312	212,ZONE5	28-010-00-01-OP(JIC) (CENTER AUX TANK FUEL SCAVENGE SYSTEM)	T009WSYK	
313	212,ZONE5	28-011-00-01-OP(JIC)-LAN (CTR AUX TANK SCAVENGE SHUTOFF VALVE)	T004RY20	
314	531,541,631,641,210	28-013-00-01-OP(JIC) (FUEL JETTISON SYSTEM - FULL CAPACITY)	T00A185Q	
315	125,126,144,511,521,531,541,542	28-022-01-01-INSP(JIC) (LEFT WING CUSHION CLAMPS AND TEFLON SLEEVING INSTALLED ON OUT-OF-TANK WIRE BUNDLES)	T00E08N4	
316	611,621,631,641,642,125,126,144	28-022-01-02-INSP(JIC) (RIGHT WING CUSHION CLAMPS AND TEFLON SLEEVING INSTALLED ON OUT-OF-TANK WIRE BUNDLES)	T00E08J2	
317	211	28-040-00-01-OP-LH(JIC) (OPERATIONAL - ENGINE FUEL SUCTION FEED SYSTEM)	T00D7BH7	
318	212	28-040-00-01-OP-RH(JIC) (OPERATIONAL - ENGINE FUEL SUCTION FEED SYSTEM)	T00E5XQE	
319	437,ZONE3	29-002-00-01-FC(JIC) (SYS L HYD RESERVOIR PRESS AIR FILTER)	T006QE5K	
320	437,ZONE3	29-002-00-01-SVC(JIC) (SYS L HYD RESERVOIR PRESS AIR FILTER)	T006QE5L	
321	447,ZONE3	29-002-00-02-FC(JIC) (SYS R HYD RESERVOIR PRESS AIR FILTER)	T006QE68	
322	447,ZONE3	29-002-00-02-SVC(JIC) (SYS R HYD RESERVOIR PRESS AIR FILTER)	T006QE69	
323	437,211,447,119,120,144,149,212	29-003-00-01-OP(JIC) (OPERATIONAL - HYDRAULIC SYSTEMS GROSS INTERNAL LEAKAGE)	T00D6GUU	
324	324,119,211,120,144,149,212,437,447	29-003-01-01-OP(JIC) (OPERATIONAL - ELEVATOR AND RUDDER PCA'S INTERNAL LEAKAGE)	T00D6TVS	
325	144,ZONE3	29-007-00-01-FC(JIC) (SYS C HYD RESERVOIR PRESS AIR FILTER)	T006QE5F	
326	144,ZONE3	29-007-00-01-SVC(JIC) (SYS C HYD RESERVOIR PRESS AIR FILTER)	T006QE5M	
327	195,211	29-010-00-01-OP(JIC) (ADP SPEED TOPPING SHUTDOWN CIRCUITRY)	T006N80J	
328		29-011-00-01-INSP(JIC) (SYS L HYD RETURN FILTER MODULE)	T00D5116	
329	ZONE3	29-013-00-01-OP(JIC) (ISOLATED ACMP SUPPLY SHUTOFF VALVE)	T00D5BUD	
330	198,ZONE3	29-014-00-01-LUB(JIC) (LUB - RAT DEPLOYMENT SYSTEM)	T00D6N5A	
331	144,ZONE3	29-018-00-01-INSP(JIC) (INSPECTION - RAT CHECKOUT MODULE FILTERS)	T009X8Z4	
332	144,ZONE3	29-018-00-01-SVC(JIC)-LAN (RAT CHECKOUT MODULE FILTERS)	T009X8ZA	
333	437,447,144,198,212,ZONE3	29-019-01-01-OP(JIC) (HYDRAULIC RESERVOIR QUANTITY - L, R, C.)	T00D77W5	
334	ZONE3	29-020-01-01-DIS(JIC) (DISCARD - RAM AIR TURBINE ISOLATION CHK VALVE)	T004RAFW	

T00E1SEN

335	ZONE3	29-020-01-01-FC(JIC)-LAN (RAM AIR TURBINE ISOLATION CHK VALVE)	T004RAFX	
336	143	29-020-01-01-INST(JIC)-LAN (RAM AIR TURBINE ISOLATION CHK VALVE)	T004RAFY	
337	143	29-020-01-01-REM(JIC)-LAN (RAM AIR TURBINE ISOLATION CHK VALVE)	T004RAFV	
338	211,312	29-021-00-01-OP(JIC) (POWER TRANSFER UNITPTU)	T00D70QE	
339	211,312	29-022-00-01-FC(JIC) (PTU SYSTEM RETURN COMPENSATOR MODULE)	T004QFNX	
340	ZONE3	29-023-00-01-FC(JIC) (PTU CASE DRAIN FILTER)	T004R6M8	
341	312	29-023-00-01-SVC(JIC) (PTU CASE DRAIN FILTER)	T004R6M7	
342	211,312	29-024-00-01-FC(JIC) (STABILIZER TRIM RATE RELIEF VALVE)	T004RPWV	
343	521,211	30-001-00-01-FC(JIC) (LEFT WING TAI TEMPERATURE SWITCH)	T004RJ7L	
344	621,211	30-001-00-02-FC(JIC) (RIGHT WING TAI TEMPERATURA SWITCH)	T004RJ81	
345	511,521,211	30-002-00-01-FC(JIC) (LEFT WING TAI PRESSURE SWITCH)	T004RKKL	
346	611,621,211	30-002-00-02-FC(JIC) (RIGHT WING TAI PRESSURE SWITCH)	T004RKKU	
347	211,212,431	30-003-00-03-OP(JIC) (ENGINE 1 INLET TAI PRESSURE SWITCHGENERAL ELECTRIC)	T009WXX4	
348	212,211,441	30-003-00-04-OP(JIC) (ENGINE 2 INLET TAI PRESSURE SWITCHGENERAL ELECTRIC)	T009WXWH	
349	119,211	31-004-00-01-OP(JIC) (WARNING ELECTRONICS UNIT CARD MODULE)	T00D4B8A	
350	212	31-008-01-01-OP(JIC) (OPERATIONAL - RIGHT EICAS COMPUTER (CMR))	T00D4B9N	
351	119,211,212,312	31-009-00-01-OP(JIC) (TAKE-OFF WARNING SYSTEM)	T00D4J9Y	
352	211,212,741,731	32-025-00-02-OP(JIC) (OPC-ALT BRAKE SYSTEM/SELECTOR VALVE)	T00D77VT	
353	651,731,741,551,211,212	32-026-00-01-OP(JIC) (ANTISKID MODULE HYDRAULIC FUSES)	T004QFDB	
354	117,118,ZONE3	32-035-00-01-INSP(JIC) (CENTERING&RUDDER INTERCONNECT MECH)	T006N8PM	
355	211,731,741,119	32-037-01-01-FC(JIC) (ANTI-SKID/AUTOBRAKE CONTROL UNIT)	T00DH4E4	
356	212,731,741	32-040-01-02-OP(JIC) (AUTOMATIC GEAR RETRACTION BRAKE)	T00D6WM8	
357	551,ZONE3	32-040-02-01-SVC(JIC) (LEFT BRAKE SURGE ACCUMULATOR)	T009Z4W3	
358	651,ZONE3	32-040-02-02-SVC(JIC) (RIGHT BRAKE SURGE ACCUMULATOR)	T009Z4WN	
359	212,311,312	32-041-00-01-OP(JIC) (TAIL SKID WARNING SYSTEM)	T009X8UG	
360	311,312	32-041-01-01-FC(JIC) (TAIL SKID HYDRAULIC FUSE)	T004QFFD	
361	119,312	32-042-00-01-OP(JIC) (TAIL SKID WARNING PSEU BITE TEST)	T00D6WMP	

T00E1SEN

362	552,ZONE3	32-046-04-01-OP(JIC) (TRUCK POSITIONER HYDRAULIC FUSES)	T004PZ3Q	
363	652	32-046-04-02-OP(JIC) (TRUCK POSITIONER HYDRAULIC FUSES)	T004PZ3A	
364	731	32-048-01-01-INSP(JIC) (LEFT MAIN GEAR SHOCK STRUT)	T00D6EKY	
365	ZONE3	32-048-01-01-SVC(JIC) (LEFT MAIN GEAR SHOCK STRUT)	T00D6EKX	
366	741	32-048-01-02-INSP(JIC) (RIGHT MAIN GEAR SHOCK STRUT)	T00D6EKR	
367	ZONE3	32-048-01-02-SVC(JIC) (RIGHT MAIN GEAR SHOCK STRUT)	T00D6EKQ	
368	711	32-048-02-01-INSP(JIC) (NOSE GEAR SHOCK STRUT)	T00D6ELQ	
369	ZONE3	32-048-02-01-SVC(JIC) (NOSE GEAR SHOCK STRUT)	T00D6ELP	
370	731,741,11 9,144,211,2 12	32-050-00-01-FC(JIC) (FUNCTIONAL - PARKING BRAKE SYSTEM TEST)	T009XMDE	
371	711	32-404-00-01-CLN(JIC) (NOSE LANDING GEAR ASSEMBLY)	T00D6NEL	
372	711	32-404-00-01-INSP(JIC) (NOSE LANDING GEAR ASSEMBLY)	T00D6NEJ	
373	711	32-404-00-01-LUB(JIC)-LAN (NOSE LANDING GEAR ASSEMBLY)	T00D6NEK	
374	731	32-414-00-01-CLN(JIC) (DETAILED INSPECTION - EXTERNAL - LEFT MAIN LANDING GEAR ASSEMBLY)	T00D6GVB	
375	731	32-414-00-01-INSP(JIC) (DETAILED INSPECTION - EXTERNAL - LEFT MAIN LANDING GEAR ASSEMBLY)	T00D6GVA	
376	731	32-414-00-01-LUB(JIC) (DETAILED INSPECTION - EXTERNAL - LEFT MAIN LANDING GEAR ASSEMBLY)	T00D6GVC	
377	741	32-414-00-02-CLN(JIC) (DETAILED INSPECTION - EXTERNAL - RIGHT MAIN LANDING GEAR ASSEMBLY)	T00D6TWK	
378	741	32-414-00-02-INSP(JIC) (DETAILED INSPECTION - EXTERNAL - RIGHT MAIN LANDING GEAR ASSEMBLY)	T00D6TWL	
379	741	32-414-00-02-LUB(JIC)-LAN (RIGHT MAIN LANDING GEAR ASSEMBLY)	T00D6TWJ	
380	732	32-422-00-01-CLN(JIC) (DETAILED INSPECTION - EXTERNAL - LEFT MAIN GEAR DOOR CENTER HINGE BEAM)	T00D6NEQ	
381	732	32-422-00-01-INSP(JIC) (DETAILED INSPECTION - EXTERNAL - LEFT MAIN GEAR DOOR CENTER HINGE BEAM)	T00D6NER	
382	732	32-422-00-01-LUB(JIC)-LAN (LEFT MAIN GEAR DOOR CENTER HINGE BEAM)	T00D6NEP	
383	742	32-422-00-02-CLN(JIC) (DETAILED INSPECTION - EXTERNAL - RIGHT MAIN GEAR DOOR CENTER HINGE BEAM)	T00D6NFB	
384	742	32-422-00-02-INSP(JIC) (DETAILED INSPECTION - EXTERNAL - RIGHT MAIN GEAR DOOR CENTER HINGE BEAM)	T00D6NFC	
385	742	32-422-00-02-LUB(JIC)-LAN (RIGHT MAIN GEAR DOOR CENTER HINGE BEAM)	T00D6NFA	
386	714,713	32-802-00-01-INSP(JIC) (GVI EXT - NOSE LANDING GEAR (NLG) FORWARD DOORS)	T00D6NP1	
387	716,715	32-802-00-02-INSP(JIC) (GVI EXT - NOSE LANDING GEAR (NLG) AFT DOORS)	T00D6NQ0	
388	732	32-802-00-03-LH-INSP(JIC) (GVI - LEFT MAIN LANDING GEAR (MLG) BODY DOOR)	T00D6NP6	

T00E1SEN

389	742	32-802-00-03-RH-INSP(JIC) (GVI - RIGHT MAIN LANDING GEAR (MLG) BODY DOOR)	T00D6NPS	
390	733	32-802-00-04-LH-INSP(JIC) (GVI - LEFT MAIN LANDING GEAR (MLG) DRAG BRACE DOOR)	T00D5HS3	
391	743	32-802-00-04-RH-INSP(JIC) (GVI - RIGHT MAIN LANDING GEAR (MLG) DRAG BRACE DOOR)	T00D5HS1	
392	734	32-802-00-05-LH-INSP(JIC) (GVI - LEFT MAIN LANDING GEAR (MLG) OLEO DOOR)	T00D6NF6	
393	744	32-802-00-05-RH-INSP(JIC) (GVI - RIGHT MAIN LANDING GEAR (MLG) OLEO DOOR)	T00D5HRT	
394	735	32-802-00-06-LH-INSP(JIC) (GVI - LEFT MAIN LANDING GEAR (MLG) TRUNNION DOOR)	T00D6NR0	
395	745	32-802-00-06-RH-INSP(JIC) (GVI - RIGHT MAIN LANDING GEAR (MLG) TRUNNION DOOR)	T00D6NQY	
396	200	33-003-00-01-FC(JIC) (FUNCTIONAL - EMERGENCY LIGHT POWER SUPPLIES)	T00DH4DG	
397	212	34-009-00-01-OP(JIC) (INSTRUMENT SOURCE SELECT SWITCHING)	T00D49C2	
398	211	34-010-00-01-OP(JIC) (CENTER EFIS SYMBOL GENERATOR)	T00D73BA	
399	119,120	34-015-00-01-INSP(JIC) (INTEGRATED STANDBY FLIGHT DISPLAY)	T00D49CD	
400	117,118,121,122	34-018-00-01-INSP(JIC) (DETAILED - ALTERNATE STATIC PORTS)	T009Y1NE	
401	114,122	35-017-00-01-FC(JIC) (FNC - CREW OXYGEN CYLINDER REGULATOR(S))	T005VLX4	
402	212,ZONE1	36-002-00-01-FC(JIC) (AIR SUPPLY DISTRIBUTION)	T00D511H	
403	212	36-003-00-01-OP(JIC) (CENTER ISOLATION VALVE)	T00D49C0	
404	135,136	36-004-00-01-INSP(JIC) (ISOLATION BYPASS CHECK VALVES)	T004RL7Z	
405	312	36-007-00-01-INSP(JIC) (APU AIR SUPPLY CHECK VALVE)	T004RJ7D	
406	119	36-008-00-01-OP(JIC) (OPERATIONAL CHECK - AIR SUPPLY BITE MODULE)	T00D49CM	
407	444,434	36-009-00-01-FC(JIC) (AIR SUPPLY THERMAL OVERTEMP SWITCH)	T004RC5W	
408	434,444	36-009-00-02-FC(JIC) (AIR SUPPLY THERMAL OVERTEMP SWITCH)	T004RAG4	
409	411	36-011-02-05-SVC(JIC) ("DIS - ENGINE 1 HP CONTROLLER AIR FILTER (CF6-80C))	T00D6ELX	
410	421	36-011-02-06-SVC(JIC) ("DIS - ENGINE 2 HP CONTROLLER AIR FILTER (CF6-80C))	T00D67J2	
411	434	36-012-01-03-SVC(JIC) ("DIS - ENGINE 1 PRSOV AIR FILTERS (CF6-80C))	T00D74A5	
412	444	36-012-01-04-SVC(JIC) ("DIS - ENGINE 2 PRSOV AIR FILTERS (CF6-80C))	T00D67JJ	
413	411	36-013-01-07-SVC(JIC) ("DIS - FAN AIR MODULATING VALVE AIR FILTER (CF6-80C))	T00D6GW3	
414	421	36-013-01-08-SVC(JIC) ("DIS - FAN AIR MODULATING VALVE AIR FILTER (CF6-80C))	T00D66YD	
415	413	36-014-01-01-SVC(JIC) ("DIS - ENGINE 1 PRV CONTROLLER AIR FILTER (CF6-80C))	T00D6EML	
416	423	36-014-01-02-SVC(JIC) ("DIS - ENGINE 2 PRV CONTROLLER AIR FILTER (CF6-80C))	T00D67JL	

T00E1SEN

417		CANCELLED - 36-11-01-03-090-INST (HP SHUTOFF VALVE-INST)	T00ER02G	
418		CANCELLED - 36-11-01-03-090-RMVL (HP SHUTOFF VALVE-RMVL)	T00ER02D	
419	124	38-006-00-01-OP(JIC) (OPERATIONAL CHECK - SERVICE PANEL WASTE DRAIN FTG SEAL)	T00D7C2E	
420	315	49-013-00-01-INSP(JIC) (APU DRAIN MAST)	T00D5HX7	
421	100	51-001-00-01-INSP(JIC) (FUSELAGE DRAIN VALVES)	T00DP11H	
422	831,833,84 1,843	52-007-00-01-LUB(JIC) (LUB - ENTRY/SERVICE COMPONENTS LUBRICATION)	T00D66YH	
423	811,ZONE1	52-017-07-01-LUB(JIC) (BULK CARGO DOOR PRESS STOP PINS/PLATES LATCH ROLLERS AND LIFT ASSIST CABLE)	T00D6TX6	
424	113	52-018-01-01-LUB(JIC) (FWD EQUIPMENT BAY/ EE BAY ACCESS DOORS)	T004RDEK	
425	113,119	52-020-00-01-INSP(JIC) (VCK - MAIN EE AND FWD ACCESS DOOR SEALS)	T00D5BXU	
426	821,ZONE1	52-030-01-01-LUB(JIC) (FWD/AFT LARGE LOWER CARGO DOOR COMPONENTS LUBRICATION)	T00D77VF	
427	811,113,11 9,212	52-035-02-01-OP(JIC) (FWD/E&E BAY, BULK CARGO DOOR WARNING)	T009WXXT	
428	811	52-039-00-01-FC(JIC) (FNC - BULK CARGO DOOR SNUBBER)	T00722UQ	
429	221	52-041-00-01-INSP(JIC) (CREW ENTRY DOOR HANDLE MECHANISM)	T004PZQ4	
430	838	52-047-00-01-OP(JIC) (MAIN DECK CARGO DOOR MANUAL DRIVE)	T009WT0H	
431	838	52-048-00-01-FC(JIC) (MAIN DECK CARGO DOOR RATCHET BRAKE)	T00D4GN8	
432		52-049-00-01-OP(JIC) (MAIN DECK CARGO DOOR POWER UNIT)	T009WT06	
433		52-050-00-01-FC(JIC) (MAIN DECK CARGO DOOR LATCH/HOOK)	T009WT04	
434	838	52-057-00-01-OP(JIC) (MAIN DECK CARGO DOOR WARNING SYSTEM)	T00D4GND	
435	821	52-058-00-01-FC(JIC) (FUNCTIONAL - LARGE FWD CARGO DOOR WARNING SYSTEM)	T00D7BAP	
436	822	52-059-00-01-OP(JIC) (LARGE AFT CARGO DOOR WARNING SYSTEM)	T00D70QA	
437	821,ZONE1	52-060-00-01-OP(JIC) (LARGE FWD CARGO DOOR MANUAL DRIVE)	T009X1FC	
438	822,ZONE1	52-061-00-01-OP(JIC) (LARGE AFT CARGO DOOR MANUAL DRIVE)	T009X1G6	
439		52-062-00-01-OP(JIC) (LARGE FWD CARGO DOOR POWER UNIT)	T009X1FK	
440		52-063-00-01-OP(JIC) (LARGE AFT CARGO DOOR POWER UNIT)	T009X1GG	
441		52-064-00-01-FC(JIC) (FUNCTIONAL - LARGE FWD CARGO DOOR LATCH/HOOK)	T009X41Q	
442		52-065-00-01-FC(JIC) (LARGE AFT CARGO DOOR LATCH/HOOK)	T009X1FS	
443	821,ZONE1	52-066-00-01-OP(JIC) (LARGE FWD CARGO DOOR NO-BACK BRAKES)	T00D6WNG	
444	822,ZONE1	52-067-00-01-OP(JIC) (LARGE AFT CARGO DOOR NO-BACK BRAKES)	T00D6WNM	

T00E1SEN

445	821	52-072-00-01-OP(JIC) (FWD LG CARGO DOOR LATCH LOCK HANDLE)	T00D6WNZ	
446	822	52-073-00-01-OP(JIC) (AFT LG CARGO DOOR LATCH LOCK HANDLE)	T00D6WP1	
447	838	52-082-01-01-LUB(JIC) (MAIN DECK CARGO DOOR)	T00D66YV	
448	811,ZONE1	52-402-00-01-CLN(JIC) (BULK CARGO COMPARTMENT DOOR)	T00D5LTH	
449	811,ZONE1	52-402-00-01-INSP(JIC) (BULK CARGO COMPARTMENT DOOR)	T00D5LTJ	
450	811,ZONE1	52-402-00-01-LUB(JIC) (BULK CARGO COMPARTMENT DOOR)	T00D5LTB	
451	821,ZONE1	52-406-00-01-CLN(JIC) (FWD CARGO COMPARTMENT DOOR)	T00D5SQ1	
452	821,ZONE1	52-406-00-01-INSP(JIC) (FWD CARGO COMPARTMENT DOOR)	T00D5SQ2	
453	821,ZONE1	52-406-00-01-LUB(JIC) (FWD CARGO COMPARTMENT DOOR)	T00D5SQ0	
454	822,ZONE1	52-410-00-01-CLN(JIC) (AFT CARGO DOOR)	T00D61NZ	
455	822,ZONE1	52-410-00-01-INSP(JIC) (AFT CARGO DOOR)	T00D61P0	
456	837	52-428-00-01-INSP(JIC) (CREW ENTRY DOOR)	T00D4H9V	
457	838	52-430-00-01-CLN(JIC) (MAIN DECK CARGO DOOR)	T00D515K	
458	838	52-430-00-01-INSP(JIC) (MAIN DECK CARGO DOOR)	T00D515L	
459	811,ZONE1	52-800-00-01-INSP(JIC) (BULK CARGO COMPARTMENT DOOR)	T004QMPZ	
460	811,ZONE1	52-802-00-01-INSP(JIC) (BULK CARGO COMPARTMENT DOOR)	T00D5D4Q	
461	821,ZONE1	52-804-00-01-INSP(JIC) (FORWARD CARGO COMPARTMENT DOOR)	T00D5D41	
462	821,ZONE1	52-806-00-01-INSP(JIC) (FORWARD CARGO COMPARTMENT DOOR)	T004QMPW	
463	822,ZONE1	52-810-00-01-INSP(JIC) (AFT CARGO COMPARTMENT DOOR)	T00D5TY3	
464	822	52-814-00-01-INSP(JIC) (AFT CARGO COMPARTMENT DOOR)	T004PZM5	
465	831,ZONE2	52-818-00-01-INSP(JIC) (CREW ENTRY DOOR - FORWARD ENTRY)	T00D4GPP	
466	838	52-838-00-01-INSP(JIC) (MAIN DECK CARGO COMPARTMENT DOOR)	T00D511T	
467	838	52-840-00-01-INSP(JIC) (MAIN DECK CARGO COMPARTMENT DOOR)	T004PZ93	
468	100	53-408-00-01-CLN(JIC) (DETAILED INSPECTION - EXTERNAL - LARGE FWD CARGO DOOR HINGES)	T00D6GKC	
469	100	53-408-00-01-INSP(JIC) (DETAILED INSPECTION - EXTERNAL - LARGE FWD CARGO DOOR HINGES)	T00D6GKB	
470	100	53-408-00-01-LUB(JIC)-LAN (LARGE FWD CARGO DOOR HINGES)	T00D6GKA	
471	100	53-412-00-01-CLN(JIC) (DETAILED INSPECTION - EXTERNAL - DOOR STOPS AND CUTOUTS)	T00D5TXN	
472	100	53-412-00-01-INSP(JIC) (DETAILED INSPECTION - EXTERNAL - DOOR STOPS AND CUTOUTS)	T00D5TXP	

T00E1SEN

473	113,114	53-416-00-01-CLN(JIC) (FUSELAGE LOWER LOBE)	T00A0MR9	
474	113,114	53-416-00-01-INSP(JIC) (FUSELAGE LOWER LOBE)	T00A0MR8	
475	111,113,114	53-420-00-01-CLN(JIC) (FUSELAGE EXTERIOR SURFACE)	T009Y250	
476	111,113,114	53-420-00-01-INSP(JIC) (FUSELAGE EXTERIOR SURFACE)	T009Y251	
477	119	53-444-00-01-CLN(JIC) (MAIN EQUIPMENT CENTER ACCESS DOOR)	T00D6GKW	
478	119	53-444-00-01-INSP(JIC) (MAIN EQUIPMENT CENTER ACCESS DOOR)	T00D6GKX	
479	119	53-444-00-01-LUB(JIC) (MAIN EQUIPMENT CENTER ACCESS DOOR)	T00D6GKV	
480	ZONE1	53-456-00-01-INSP(JIC) (INTERNAL DETAILED - FORWARD CARGO DOOR LOWER SILL)	T00A1P7F	
481	132,131	53-496-00-01-INSP(JIC) (DETAILED INSPECTION - INTERNAL - WING CENTER SECTION UPPER SURFACE)	T00EUNM2	
482	139	53-502-00-01-CLN(JIC) (KEEL BEAM&WING CENTER SECTION)	T00D5TWX	
483	139	53-502-00-01-INSP(JIC) (KEEL BEAM&WING CENTER SECTION)	T00D5TWY	
484	139	53-502-00-01-LUB(JIC) (KEEL BEAM&WING CENTER SECTION)	T00D5TWW	
485	139	53-504-00-01-CLN(JIC) (DETAILED INSPECTION - INTERNAL - WING CENTER SECTION TENSION FITTING)	T00D5TX5	
486	139	53-504-00-01-INSP(JIC) (DETAILED INSPECTION - INTERNAL - WING CENTER SECTION TENSION FITTING)	T00D5TX4	
487	139	53-504-00-01-LUB(JIC) (DETAILED INSPECTION - INTERNAL - WING CENTER SECTION TENSION FITTING)	T00D5TX6	
488	142,141	53-508-00-01-INSP(JIC) (DETAILED INSPECTION - INTERNAL - BELOW FLOOR STRUCTURE - BODY STATION 955 TO 1065)	T00EUNMY	
489	143,ZONE3	53-520-00-01-CLN(JIC) (DETAILED INSPECTION - INTERNAL - TRANSVERSE BEAMS)	T00D61NJ	
490	143,ZONE3	53-520-00-01-INSP(JIC) (DETAILED INSPECTION - INTERNAL - TRANSVERSE BEAMS)	T00D61MW	
491	143,ZONE3	53-520-00-01-LUB(JIC) (DETAILED INSPECTION - INTERNAL - TRANSVERSE BEAMS)	T00D61NH	
492	ZONE3,144	53-520-00-02-CLN(JIC) (DETAILED INSPECTION - INTERNAL - TRANSVERSE BEAMS)	T00D5TX0	
493	144,ZONE3	53-520-00-02-INSP(JIC) (DETAILED INSPECTION - INTERNAL - TRANSVERSE BEAMS)	T00D5TWN	
494	144,ZONE3	53-520-00-02-LUB(JIC) (DETAILED INSPECTION - INTERNAL - TRANSVERSE BEAMS)	T00D5TWZ	
495	143	53-524-00-01-CLN(JIC) (DETAILED INSPECTION - INTERNAL - REAR SPAR BULKHEAD AT WHEEL WELL)	T00D5TWS	
496	143	53-524-00-01-INSP(JIC) (DETAILED INSPECTION - INTERNAL - REAR SPAR BULKHEAD AT WHEEL WELL)	T00D5TWQ	
497	143,ZONE3	53-524-00-01-LUB(JIC) (DETAILED INSPECTION - INTERNAL - REAR SPAR BULKHEAD AT WHEEL WELL)	T00D5TWR	
498	144	53-524-00-02-CLN(JIC) (DETAILED INSPECTION - INTERNAL - REAR SPAR BULKHEAD AT WHEEL WELL)	T00D6TNG	
499	ZONE3,144	53-524-00-02-INSP(JIC) (DETAILED INSPECTION - INTERNAL - REAR SPAR BULKHEAD AT WHEEL WELL)	T00D6TN0	
500	144,ZONE3	53-524-00-02-LUB(JIC) (DETAILED INSPECTION - INTERNAL - REAR SPAR BULKHEAD AT WHEEL WELL)	T00D6TNH	

T00E1SEN

501	143	53-524-01-01-INSP(JIC) (GVI - LH-WING CENTER SECTION (WCS) REAR SPAR WEB AND REAR SPAR BULKHEAD FITTINGS)	T00DEAR5	
502	144	53-524-01-02-INSP(JIC) (GENERAL VISUAL INSPECTION - RH-WING CENTER SECTION (WCS) REAR SPAR WEB AND REAR SPAR BULKHEAD FITTINGS)	T00DEALV	
503	143,144,ZO NE3	53-528-00-01-CLN(JIC) (DETAILED INSPECTION - INTERNAL - REAR SPAR AT KEEL BEAM)	T00D5LQ0	
504	143,144,ZO NE3	53-528-00-01-INSP(JIC) (DETAILED INSPECTION - INTERNAL - REAR SPAR AT KEEL BEAM)	T00D5LPH	
505	143,144,ZO NE3	53-528-00-01-LUB(JIC) (DETAILED INSPECTION - INTERNAL - REAR SPAR AT KEEL BEAM)	T00D5LPZ	
506	151	53-544-00-01-CLN(JIC) (DETAILED INSPECTION - INTERNAL - BODY FORWARD OF AFT CARGO COMPARTMENT)	T00A0SWZ	
507	151	53-544-00-01-INSP(JIC) (DETAILED INSPECTION - INTERNAL - BODY FORWARD OF AFT CARGO COMPARTMENT)	T00A0SWY	
508	152	53-548-00-01-CLN(JIC) (DETAILED INSPECTION - INTERNAL - BODY FORWARD OF AFT CARGO COMPARTMENT)	T00A0SX4	
509	152	53-548-00-01-INSP(JIC) (DETAILED INSPECTION - INTERNAL - BODY FORWARD OF AFT CARGO COMPARTMENT)	T00A0SX3	
510	153	53-552-01-01-INSP(JIC) (GENERAL VISUAL INSPECTION - INTERNAL - AFT CARGO COMPARTMENT)	T00DRH7F	
511	154	53-554-00-01-INSP(JIC) (INTERNAL DETAILED - AFT CARGO DOOR MAIN LOWER SILL)	T00A1Z8Z	
512	155	53-564-00-01-INSP(JIC) (FUSELAGE EXTERIOR SURFACE)	T009X0S7	
513	161	53-574-00-01-INSP(JIC) (INTERNAL DETAILED - BULK CARGO DOOR LOWER SILL)	T00A18M4	
514	165	53-594-00-01-INSP(JIC) (FUSELAGE EXTERIOR)	T009YBD2	
515	191	53-602-00-01-INSP(JIC) (UPPER WING / SIDE OF BODY SPLICE)	T009Z5ER	
516	192	53-602-00-02-INSP(JIC) (UPPER WING / SIDE OF BODY SPLICE)	T009Z5EP	
517	191	53-606-00-01-CLN(JIC) (DETAILED INSPECTION - INTERNAL - OVERWING LONGERON)	T009ZNMU	
518	191	53-606-00-01-INSP(JIC) (DETAILED INSPECTION - INTERNAL - OVERWING LONGERON)	T009ZNMV	
519	192	53-606-00-02-CLN(JIC)-LAN (OVERWING LONGERON)	T009ZNN4	
520	192	53-606-00-02-INSP(JIC) (DETAILED INSPECTION - INTERNAL - OVERWING LONGERON)	T009ZNN5	
521	193	53-614-00-01-INSP(JIC) (WING LOWER SURFACE BUTTOCK LINE 62 - FAIRING EDGE)	T009Z5EU	
522	194	53-614-00-02-INSP(JIC) (WING LOWER SURFACE BUTTOCK LINE 62 - FAIRING EDGE)	T009Z5F1	
523	193	53-616-00-01-CLN(JIC) (DETAILED INSPECTION - INTERNAL - LOWER SIDE OF BODY SPLICE PLATES)	T00D61M0	
524	193	53-616-00-01-INSP(JIC) (DETAILED INSPECTION - INTERNAL - LOWER SIDE OF BODY SPLICE PLATES)	T00D61LY	
525	193	53-616-00-01-LUB(JIC) (DETAILED INSPECTION - INTERNAL - LOWER SIDE OF BODY SPLICE PLATES)	T00D61LZ	
526	194	53-616-00-02-CLN(JIC) (DETAILED INSPECTION - INTERNAL - LOWER SIDE OF BODY SPLICE PLATES)	T00D61KU	
527	194	53-616-00-02-INSP(JIC) (DETAILED INSPECTION - INTERNAL - LOWER SIDE OF BODY SPLICE PLATES)	T00D61KT	

T00E1SEN

528	194	53-616-00-02-LUB(JIC) (DETAILED INSPECTION - INTERNAL - LOWER SIDE OF BODY SPLICE PLATES)	T00D61L0	
529	193	53-618-00-01-CLN(JIC) (DETAILED INSPECTION - INTERNAL - LOWER WING SURFACE AT REAR SPAR CHORD)	T00D6TMC	
530	193	53-618-00-01-INSP(JIC) (DETAILED INSPECTION - INTERNAL - LOWER WING SURFACE AT REAR SPAR CHORD)	T00D6TME	
531	193	53-618-00-01-LUB(JIC) (DETAILED INSPECTION - INTERNAL - LOWER WING SURFACE AT REAR SPAR CHORD)	T00D6TMD	
532	194	53-618-00-02-CLN(JIC) (DETAILED INSPECTION - INTERNAL - LOWER WING SURFACE AT REAR SPAR CHORD)	T00D61KF	
533	194	53-618-00-02-INSP(JIC) (DETAILED INSPECTION - INTERNAL - LOWER WING SURFACE AT REAR SPAR CHORD)	T00D61KE	
534	194	53-618-00-02-LUB(JIC) (DETAILED INSPECTION - INTERNAL - LOWER WING SURFACE AT REAR SPAR CHORD)	T00D61KG	
535	193	53-620-00-01-CLN(JIC) (DETAILED INSPECTION - INTERNAL - WING LOWER REAR SPAR SPLICE FITTING)	T00D5TVZ	
536	193	53-620-00-01-INSP(JIC) (DETAILED INSPECTION - INTERNAL - WING LOWER REAR SPAR SPLICE FITTING)	T00D5TVX	
537	193	53-620-00-01-LUB(JIC) (DETAILED INSPECTION - INTERNAL - WING LOWER REAR SPAR SPLICE FITTING)	T00D5TVY	
538	194	53-620-00-02-CLN(JIC) (DETAILED INSPECTION - INTERNAL - WING LOWER REAR SPAR SPLICE FITTING)	T00D5TVT	
539	194	53-620-00-02-INSP(JIC) (DETAILED INSPECTION - INTERNAL - WING LOWER REAR SPAR SPLICE FITTING)	T00D5TVV	
540	194	53-620-00-02-LUB(JIC) (DETAILED INSPECTION - INTERNAL - WING LOWER REAR SPAR SPLICE FITTING)	T00D5TVU	
541	193	53-622-00-01-CLN(JIC) (DETAILED INSPECTION - INTERNAL - BUTTOCK LINE 70 UNDERWING LONGERON FITTING)	T00D5TVJ	
542	193	53-622-00-01-INSP(JIC) (DETAILED INSPECTION - INTERNAL - BUTTOCK LINE 70 UNDERWING LONGERON FITTING)	T00D5TVG	
543	193	53-622-00-01-LUB(JIC) (DETAILED INSPECTION - INTERNAL - BUTTOCK LINE 70 UNDERWING LONGERON FITTING)	T00D5TVH	
544	194	53-622-00-02-CLN(JIC) (DETAILED INSPECTION - INTERNAL - BUTTOCK LINE 70 UNDERWING LONGERON FITTING)	T00D5TVE	
545	194	53-622-00-02-INSP(JIC) (DETAILED INSPECTION - INTERNAL - BUTTOCK LINE 70 UNDERWING LONGERON FITTING)	T00D5TVC	
546	194	53-622-00-02-LUB(JIC) (DETAILED INSPECTION - INTERNAL - BUTTOCK LINE 70 UNDERWING LONGERON FITTING)	T00D5TVD	
547	197,195	53-634-00-01-INSP(JIC) (LEFT WING-TO-BODY FAIRING)	T009Z19F	
548	198,196	53-634-00-02-INSP(JIC) (RIGHT WING-TO-BODY FAIRING)	T009Z19M	
549	200	53-650-00-01-CLN(JIC) (DETAILED INSPECTION - EXTERNAL - DOOR STOPS AND CUTOUTS)	T00D5TV4	
550	200	53-650-00-01-INSP(JIC) (DETAILED INSPECTION - EXTERNAL - DOOR STOPS AND CUTOUTS)	T00D5TV5	
551	200	53-650-00-01-LUB(JIC)-LAN (DOOR STOPS AND CUTOUTS)	T00D5TV3	
552	211,212	53-656-00-01-CLN(JIC) (CONTROL CABIN FLOOR STRUCTURE)	T00A1NNF	
553	211,212	53-656-00-01-INSP(JIC) (CONTROL CABIN FLOOR STRUCTURE)	T00A1NNG	
554	231	53-686-00-01-INSP(JIC) (MAIN DECK CARGO DOOR CUTOUT SILL)	T00A1Z62	
555	311,312,313,314	53-726-00-01-INSP(JIC) (INTERNAL DETAILED - FORWARD AND AFT SIDES OF BODY STATION 1702 - 1725.5 BULKHEADS)	T00A0ZNL	

T00E1SEN

556	311,312	53-728-00-01-INSP(JIC) (INTERNAL DETAILED - HORIZONTAL STABILIZER TRIM ACTUATOR SUPPORT)	T00A0ZQ1	
557	311,313	53-730-00-01-INSP(JIC) (SECTION 48, LEFT SIDE)	T009YJ7J	
558	312,314	53-730-00-02-INSP(JIC) (SECTION 48, RIGHT SIDE)	T00A06WN	
559	311,312	53-732-00-01-CLN(JIC) (DETAILED INSPECTION - INTERNAL - AFT PRESSURE BULKHEAD - BODY STATION 1582)	T00A0ZMS	
560	311,312	53-732-00-01-INSP(JIC) (DETAILED INSPECTION - INTERNAL - AFT PRESSURE BULKHEAD - BODY STATION 1582)	T00A0ZMR	
561	313,314	53-746-00-01-CLN(JIC) (DETAILED INSPECTION - INTERNAL - HORIZONTAL STABILIZER PIVOT FITTINGS)	T00A0ZPK	
562	313,314	53-746-00-01-INSP(JIC) (DETAILED INSPECTION - INTERNAL - HORIZONTAL STABILIZER PIVOT FITTINGS)	T00A0ZPL	
563	313,314	53-748-00-01-INSP(JIC) (INTERNAL DETAILED - BODY LONGERONS AT HORIZONTAL STABILIZER CUTOFF)	T00A0ZP7	
564	315,316	53-758-00-01-CLN(JIC) (APU COMPARTMENT EXTERNAL SURFACE)	T00D66VX	
565	315,316	53-758-00-01-INSP(JIC) (APU COMPARTMENT EXTERNAL SURFACE)	T00D66VY	
566	315,316	53-758-00-01-LUB(JIC) (APU COMPARTMENT EXTERNAL SURFACE)	T00D66VW	
567	100	53-800-00-01-INSP(JIC) (LOWER HALF OF FUSELAGE)	T00D6GKZ	
568	111	53-802-00-01-INSP(JIC) (RADOME)	T00D5HRC	
569	113,114	53-804-00-01-CLN(JIC) (AREAS FORWARD OF NOSE LANDING GEAR WHEEL WELL)	T00D6GLE	
570	113,114	53-804-00-01-INSP(JIC) (AREAS FORWARD OF NOSE LANDING GEAR WHEEL WELL)	T00D6GLD	
571	115,116,ZO NE3	53-806-00-01-CLN(JIC) (NOSE LANDING GEAR WHEEL WELL)	T00D6NFL	
572	115,116,ZO NE3	53-806-00-01-INSP(JIC) (NOSE LANDING GEAR WHEEL WELL)	T00D6NFK	
573	117,118	53-808-00-01-INSP(JIC) (AREA OUTBOARD AND ABOVE NOSE LANDING GEAR WHEEL WELL)	T00D5CJE	
574	119	53-810-00-01-CLN(JIC) (MAIN EQUIPMENT CENTER)	T00D5TUA	
575	119	53-810-00-01-INSP(JIC) (MAIN EQUIPMENT CENTER)	T00D5TU9	
576	119	53-812-00-01-INSP(JIC) (MAIN EQUIPMENT CENTER)	T00D5TTA	
577	121,122	53-814-00-01-INSP(JIC) (FORWARD CARGO COMPARTMENT)	T00D5TT5	
578	121,122	53-816-00-01-INSP(JIC) (FORWARD CARGO COMPARTMENT)	T004QU7Q	
579	123,124	53-820-00-01-INSP(JIC) (GENERAL VISUAL INTERNAL - AREAS BELOW FORWARD CARGO COMPARTMENT)	T004QT2V	
580	125,126	53-822-00-01-INSP(JIC) (AREAS AFT OF FORWARD CARGO COMPARTMENT)	T00D5CJZ	
581	131,132	53-826-00-01-INSP(JIC) (AREAS ABOVE WING CENTER SECTION)	T004Q6QE	
582	133,134,ZO NE5	53-830-00-01-INSP(JIC) (WING CENTER SECTION)	T004QSZ6	
583	135,136	53-832-00-01-INSP(JIC) (ENVIRONMENTAL CONTROL SYSTEM BAYS)	T00D5BTZ	

T00E1SEN

584	141,142,ZONE2	53-836-00-01-INSP(JIC) (AREAS ABOVE MAIN LANDING GEAR WHEEL WELL)	T004QHP0	
585	143,ZONE3	53-838-00-01-CLN(JIC) (LEFT MAIN WHEEL WELL)	T00D6NR9	
586	143,ZONE3	53-838-00-01-INSP(JIC) (LEFT MAIN WHEEL WELL)	T00D6NR3	
587	144,ZONE3	53-838-00-02-CLN(JIC) (RIGHT MAIN WHEEL WELL)	T00D6NRQ	
588	144,ZONE3	53-838-00-02-INSP(JIC) (RIGHT MAIN WHEEL WELL)	T00D6NRR	
589	151,152	53-840-00-01-INSP(JIC) (AREAS FORWARD OF AFT CARGO COMPARTMENT)	T00D5TT0	
590	151,152	53-842-00-01-INSP(JIC) (AREAS FORWARD OF AFT CARGO COMPARTMENT)	T004QMP0	
591	151,152	53-846-00-01-INSP(JIC) (AREAS FWD OF AFT CARGO COMPARTMENT)	T004QJG7	
592	153	53-850-00-01-INSP(JIC) (AFT CARGO COMPARTMENT - LEFT)	T00D5TSQ	
593	154	53-850-00-02-INSP(JIC) (AFT CARGO COMPARTMENT - RIGHT)	T00D5TS6	
594	153	53-852-00-01-INSP(JIC) (AFT CARGO COMPARTMENT - LEFT)	T004QMNJ	
595	154	53-852-00-02-INSP(JIC) (AFT CARGO COMPARTMENT - RIGHT)	T004QMNP	
596	155,156	53-856-00-01-INSP(JIC) (AREAS BELOW AFT CARGO COMPARTMENT)	T004QHP2	
597	161	53-858-00-01-INSP(JIC) (BULK CARGO COMPARTMENT - LEFT)	T00D5TSF	
598	162	53-858-00-02-INSP(JIC) (BULK CARGO COMPARTMENT - RIGHT)	T00D5TS1	
599	161	53-860-00-01-INSP(JIC) (BULK CARGO COMPARTMENT - LEFT)	T004QMMD	
600	162	53-860-00-02-INSP(JIC) (BULK CARGO COMPARTMENT - RIGHT)	T004QMMG	
601	163,164	53-864-00-01-INSP(JIC) (AREAS BELOW BULK CARGO COMPARTMENT)	T004QKM0	
602	165,166	53-866-00-01-INSP(JIC) (AREAS AFT OF BULK CARGO COMPARTMENT)	T00D5TRG	
603	191,193	53-868-00-01-INSP(JIC) (WING TO BODY FAIRINGS - FWD LEFT)	T009XLK9	
604	192,194	53-868-00-02-INSP(JIC) (WING TO BODY FAIRINGS - FWD RIGHT)	T009XLJV	
605	195,197	53-870-00-01-CLN(JIC) (WING TO BODY FAIRINGS - AFT LEFT)	T009Z8DK	
606	195,197	53-870-00-01-INSP(JIC) (WING TO BODY FAIRINGS - AFT LEFT)	T009Z8DL	
607	196,198	53-870-00-02-CLN(JIC) (WING TO BODY FAIRINGS - AFT RIGHT)	T009Z8D1	
608	196,198	53-870-00-02-INSP(JIC) (WING TO BODY FAIRINGS - AFT RIGHT)	T009Z8DT	
609	200	53-872-00-01-INSP(JIC) (UPPER HALF OF FUSELAGE)	T00D6GLS	
610	211,212	53-874-00-01-INSP(JIC) (CONTROL CABIN)	T00D4JA3	
611	221,222	53-878-00-01-CLN(JIC) (MAIN DECK CARGO COMPARTMENT - SECTION 41)	T00D61JW	

T00E1SEN

612	221,222	53-878-00-01-INSP(JIC) (MAIN DECK CARGO COMPARTMENT - SECTION 41)	T00D61JV	
613	221,223	53-880-00-01-INSP(JIC) (AREAS AROUND CREW ENTRY DOOR)	T004PLAD	
614	223,224	53-884-00-01-INSP(JIC) (AREA ABOVE CEILING - SECTION 41)	T004Q6AM	
615	231,232	53-888-00-01-INSP(JIC) (MAIN DECK CARGO COMPARTMENT - SECTION 43)	T00D5HXS	
616	233,234	53-892-00-01-INSP(JIC) (AREA ABOVE CEILING - SECTION 43)	T004Q241	
617	241,242	53-896-00-01-CLN(JIC) (MAIN DECK CARGO COMPARTMENT - SECTION 45)	T00D61JQ	
618	241,242	53-896-00-01-INSP(JIC) (MAIN DECK CARGO COMPARTMENT - SECTION 45)	T00D61JP	
619	243,244	53-900-00-01-INSP(JIC) (AREA ABOVE CEILING - SECTION 45)	T004Q23P	
620	251,252	53-904-00-01-INSP(JIC) (MAIN DECK CARGO COMPARTMENT - SECTION 46)	T00D4NN5	
621	253,254	53-908-00-01-INSP(JIC) (AREA ABOVE CEILING SECTION 46)	T004Q1VS	
622	437	54-001-01-01-LUB(JIC) (LEFT WING NACELLE ATTACH FITTING)	T00D61JK	
623	447	54-001-01-02-LUB(JIC) (RIGHT WING NACELLE ATTACH FITTINGS)	T00D5N2M	
624	430	54-002-01-07-FC(JIC) (ENGINE 1 STRUT DRAIN LEAK TESTCF6-80C)	T004QFC3	
625	440	54-002-01-08-FC(JIC) (ENGINE 2 STRUT DRAIN LEAK TESTCF6-80C)	T004QFB5	
626	430	54-408-00-01-CLN(JIC) (NO. 1 NACELLE STRUT)	T00D5M6H	
627	430	54-408-00-01-INSP(JIC) (NO. 1 NACELLE STRUT)	T00D5M6G	
628	430	54-408-00-01-LUB(JIC) (NO. 1 NACELLE STRUT)	T00D5M6F	
629	440	54-408-00-02-CLN(JIC) (NO. 2 NACELLE STRUT)	T00D5N23	
630	440	54-408-00-02-INSP(JIC) (NO. 2 NACELLE STRUT)	T00D5N24	
631	ZONE4	54-408-00-02-LUB(JIC) (NO. 2 NACELLE STRUT)	T00D5N22	
632	430	54-410-00-01-INSP(JIC) (EXTERNAL DETAILED - NACELLE STRUT NO. 1)	T00A0G9P	
633	440	54-410-00-02-INSP(JIC) (EXTERNAL DETAILED - NACELLE STRUT NO. 2)	T00A06ZG	
634	433	54-438-00-01-CLN(JIC) (DETAILED INSPECTION - INTERNAL - NACELLE STRUT NO. 1 UPPER LINK)	T00D5MZP	
635	433	54-438-00-01-INSP(JIC) (DETAILED INSPECTION - INTERNAL - NACELLE STRUT NO. 1 UPPER LINK)	T00D5MYW	
636	433	54-438-00-01-LUB(JIC)-LAN (NACELLE STRUT NO. 1 UPPER LINK)	T00D5MZN	
637	443	54-438-00-02-CLN(JIC) (DETAILED INSPECTION - INTERNAL - NACELLE STRUT NO. 2 UPPER LINK)	T00D6EN7	
638	443	54-438-00-02-INSP(JIC) (DETAILED INSPECTION - INTERNAL - NACELLE STRUT NO. 2 UPPER LINK)	T00D6EN6	
639	ZONE4	54-438-00-02-LUB(JIC)-LAN (NACELLE STRUT NO. 2 UPPER LINK)	T00D6EN5	

T00E1SEN

640	436,434	54-446-00-01-INSP(JIC) (NACELLE STRUT 1 - MID&AFT TORQUE BOX)	T00A06RS	
641	444,446	54-446-00-02-INSP(JIC) (NACELLE STRUT 2 - MID&AFT TORQUE BOX)	T00A06YJ	
642	436,434	54-448-00-01-INSP(JIC) (INTERNAL DETAILED - STRUT NO. 1 AFT ENGINE MOUNT BULKHEAD)	T00A0GA7	
643	444,446	54-448-00-02-INSP(JIC) (INTERNAL DETAILED - STRUT NO. 2 AFT ENGINE MOUNT BULKHEAD)	T00A0701	
644		54-466-00-01-CLN(JIC) (LEFT NACELLE STRUT / WING LOWER SURFACE)	T00D5HZY	
645	437	54-466-00-01-INSP(JIC) (LEFT NACELLE STRUT / WING LOWER SURFACE)	T00D5J00	
646		54-466-00-01-LUB(JIC) (LEFT NACELLE STRUT / WING LOWER SURFACE)	T00D5HZZ	
647	447	54-466-00-02-CLN(JIC) (RIGHT NACELLE STRUT / WING LOWER SURFACE)	T00D5MWF	
648	447	54-466-00-02-INSP(JIC) (RIGHT NACELLE STRUT / WING LOWER SURFACE)	T00D5MWE	
649	ZONE4	54-466-00-02-LUB(JIC) (RIGHT NACELLE STRUT / WING LOWER SURFACE)	T00D5MW8	
650	437	54-468-00-01-CLN(JIC) (DETAILED INSPECTION - INTERNAL - LEFT NACELLE STRUT / WING LOWER SURFACE)	T00D5J12	
651	437	54-468-00-01-INSP(JIC) (DETAILED INSPECTION - INTERNAL - LEFT NACELLE STRUT / WING LOWER SURFACE)	T00D5J11	
652	ZONE4	54-468-00-01-LUB(JIC)-LAN (LEFT NACELLE STRUT / WING LOWER SURFACE)	T00D5J18	
653	447	54-468-00-02-CLN(JIC) (DETAILED INSPECTION - INTERNAL - RIGHT NACELLE STRUT / WING LOWER SURFACE)	T00D5MVN	
654	447	54-468-00-02-INSP(JIC) (DETAILED INSPECTION - INTERNAL - RIGHT NACELLE STRUT / WING LOWER SURFACE)	T00D5MW0	
655	ZONE4	54-468-00-02-LUB(JIC)-LAN (RIGHT NACELLE STRUT / WING LOWER SURFACE)	T00D5MVZ	
656	431	54-812-00-01-INSP(JIC) (FORWARD NACELLE STRUT FAIRING - STRUT 1)	T00D5J1A	
657	441	54-812-00-02-INSP(JIC) (FORWARD NACELLE STRUT FAIRING - STRUT 2)	T00D5J1G	
658	432	54-814-00-01-INSP(JIC) (FORWARD TORQUE BOX - STRUT 1)	T00D5J20	
659	442	54-814-00-02-INSP(JIC) (FORWARD TORQUE BOX - STRUT 2)	T00D5J2G	
660	433	54-816-00-01-INSP(JIC) (UNDERWING FAIRING - STRUT 1)	T00D5U4M	
661	443	54-816-00-02-INSP(JIC) (UNDERWING FAIRING - STRUT 2)	T00D60TA	
662	436,434	54-818-00-01-INSP(JIC) (MID AND AFT TORQUE BOXES - STRUT 1)	T00D5J2L	
663	444,446	54-818-00-02-INSP(JIC) (MID AND AFT TORQUE BOXES - STRUT 2)	T00D5JGS	
664	435	54-820-00-01-INSP(JIC) (CORE COWL SKIRT FAIRINGS - STRUT 1)	T00D5J7V	
665	445	54-820-00-02-INSP(JIC) (CORE COWL SKIRT FAIRINGS - STRUT 2)	T00D5M5E	
666	437	54-822-00-01-INSP(JIC) (AFT NACELLE STRUT FAIRINGS - STRUT 1)	T00D5J8A	
667	447	54-822-00-02-INSP(JIC) (AFT NACELLE STRUT FAIRINGS - STRUT 2)	T00D5J8M	

T00E1SEN

668	321	55-402-00-01-INSP(JIC) (VERTICAL STABILIZER REMOVABLE LEADING EDGE)	T00D6NFU	
669	322	55-408-00-01-INSP(JIC) (VERT STAB AUX SPAR TO FRONT SPAR)	T00A05EJ	
670	323	55-412-00-01-INSP(JIC) (INTERNAL DETAILED - VERTICAL STABILIZER FIN-TO-BODY FITTINGS)	T00A12CH	
671	323	55-414-00-01-INSP(JIC) (LEFT AND RIGHT VERTICAL STABILIZER INSPAR STRUCTURE)	T00D6NFJ	
672	323	55-416-00-01-INSP(JIC) (VERTICAL STABILIZER FRONT SPAR TO REAR SPAR)	T00A05CJ	
673	323	55-418-00-01-INSP(JIC) (EXTERNAL DETAILED - VERTICAL STABILIZER INSPAR STRUCTURE)	T00D6TWZ	
674	324	55-420-00-01-INSP(JIC) (VERTICAL STABILIZER TRAILING EDGE)	T00A0ZH8	
675	325	55-424-00-01-CLN(JIC) (DETAILED INSPECTION - EXTERNAL - RUDDER)	T00D70R0	
676	325	55-424-00-01-INSP(JIC) (DETAILED INSPECTION - EXTERNAL - RUDDER)	T00D70QZ	
677	325	55-424-00-01-LUB(JIC)-LAN (RUDDER)	T00D70R1	
678	325	55-426-00-01-INSP(JIC) (EXTERNAL - DETAILED - RUDDER)	T00A05DS	
679	331,341	55-434-00-01-INSP(JIC) (HORIZONTAL STABILIZER CENTER SECTION)	T00A12DB	
680	332	55-446-00-01-INSP(JIC) (HORIZONTAL STABILIZER REMOVABLE LEADING EDGE - LEFT)	T00D6NGD	
681	342	55-446-00-02-INSP(JIC) (HORIZONTAL STABILIZER REMOVABLE LEADING EDGE - RIGHT)	T00D5KKJ	
682	333	55-450-00-01-INSP(JIC) (HORIZONTAL STABILIZER FIXED LEADING EDGE - LOWER LEFT)	T009XCGA	
683	343	55-450-00-02-INSP(JIC) (HORIZONTAL STABILIZER FIXED LEADING EDGE - LOWER RIGHT)	T009YA9D	
684	333	55-452-00-01-INSP(JIC) (HORIZONTAL STABILIZER FIXED LEADING EDGE - UPPER LEFT)	T00D5MUP	
685	343	55-452-00-02-INSP(JIC) (HORIZONTAL STABILIZER FIXED LEADING EDGE - UPPER RIGHT)	T00D5KKW	
686	334	55-458-00-01-INSP(JIC) (HORIZONTAL STABILIZER UPPER OUTBOARD SURFACE - LEFT)	T00D5M4Z	
687	344	55-458-00-02-INSP(JIC) (HORIZONTAL STABILIZER UPPER OUTBOARD SURFACE - RIGHT)	T00D5KKY	
688	334	55-460-00-01-INSP(JIC) (HORIZONTAL STABILIZER LOWER OUTBOARD SURFACE - LEFT)	T009YBFA	
689	344	55-460-00-02-INSP(JIC) (HORIZONTAL STABILIZER LOWER OUTBOARD SURFACE - RIGHT)	T009YBFJ	
690	334	55-462-00-01-INSP(JIC) (EXTERNAL DETAILED - HORIZONTAL STABILIZER UPPER OUTBOARD SURFACE - LEFT)	T00D6TZ5	
691	344	55-462-00-02-INSP(JIC) (EXTERNAL DETAILED - HORIZONTAL STABILIZER UPPER OUTBOARD SURFACE - RIGHT)	T00D5KLC	
692	335	55-466-00-01-INSP(JIC) (HORIZONTAL STABILIZER TRAILING EDGE - LEFT)	T009ZKZ0	
693	345	55-466-00-02-INSP(JIC) (HORIZONTAL STABILIZER TRAILING EDGE - RIGHT)	T009ZJBX	
694	335	55-468-00-01-INSP(JIC) (HORIZONTAL STABILIZER TRAILING EDGE UPPER SURFACE - LEFT)	T00D6NGS	
695	345	55-468-00-02-INSP(JIC) (HORIZONTAL STABILIZER TRAILING EDGE UPPER SURFACE - RIGHT)	T00D5KLJ	

T00E1SEN

696	336,337	55-474-00-01-INSP(JIC) (EXTERNAL DETAILED - ELEVATOR SPAR&HINGE FITTINGS - LEFT)	T009ZT10	
697	346,347	55-474-00-02-INSP(JIC) (EXTERNAL DETAILED - ELEVATOR SPAR&HINGE FITTINGS - RIGHT)	T009ZJCH	
698	337	55-478-00-01-INSP(JIC) (LEFT ELEVATOR - INBOARD / OUTBOARD)	T00D6NGN	
699	347	55-478-00-02-INSP(JIC) (RIGHT ELEVATOR - INBOARD / OUTBOARD)	T00D5KLT	
700	337,347	55-480-00-01-CLN(JIC) (DETAILED INSPECTION - EXTERNAL - ELEVATOR - OUTBOARD)	T00D67K0	
701	337,347	55-480-00-01-INSP(JIC) (DETAILED INSPECTION - EXTERNAL - ELEVATOR - OUTBOARD)	T00D67JZ	
702	337,347	55-480-00-01-LUB(JIC)-LAN (ELEVATOR - OUTBOARD)	T00D67JY	
703	ZONE3	55-490-00-01-CLN(JIC)-LAN (HORIZONTAL STABILIZER CENTER SECTION)	T00A12CK	
704	331,341	55-490-00-01-INSP(JIC) (DETAILED INSPECTION - INTERNAL - HORIZONTAL STABILIZER CENTER SECTION)	T00A12CL	
705	331,341	55-492-00-01-CLN(JIC) (DETAILED INSPECTION - EXTERNAL - HORIZONTAL STABILIZER JACKSCREW FITTING)	T00D70RA	
706	331,341	55-492-00-01-INSP(JIC) (DETAILED INSPECTION - EXTERNAL - HORIZONTAL STABILIZER JACKSCREW FITTING)	T00D70R9	
707	331,341	55-492-00-01-LUB(JIC)-LAN (HORIZONTAL STABILIZER JACKSCREW FITTING)	T00D70R8	
708	331,341	55-494-00-01-CLN(JIC) (DETAILED INSPECTION - EXTERNAL - HORIZONTAL STABILIZER PIVOT FITTINGS)	T00D6TQY	
709	331,341	55-494-00-01-INSP(JIC) (DETAILED INSPECTION - EXTERNAL - HORIZONTAL STABILIZER PIVOT FITTINGS)	T00D6TQX	
710	331,341	55-494-00-01-LUB(JIC)-LAN (HORIZONTAL STABILIZER PIVOT FITTINGS)	T00D6TR9	
711	331,341	55-496-00-01-INSP(JIC) (EXTERNAL DETAILED - HORIZONTAL STABILIZER CENTER SECTION REAR SPAR)	T00D5SRA	
712	311,312	55-800-00-01-CLN(JIC) (AREAS AFT OF PRESS B/H TO BS 1725.5)	T00D6EPG	
713	311,312	55-800-00-01-INSP(JIC) (AREAS AFT OF PRESS B/H TO BS 1725.5)	T00D6EPF	
714	311,312	55-802-00-01-INSP(JIC) (AREAS AFT OF PRESS B/H TO BS 1725.5)	T00D5M35	
715	313	55-804-00-01-CLN(JIC) (STABILIZER TORSION BOX COMPT - LEFT)	T00D66VC	
716	313	55-804-00-01-INSP(JIC) (STABILIZER TORSION BOX COMPT - LEFT)	T00D66VD	
717	314	55-804-00-02-CLN(JIC) (STABILIZER TORSION BOX COMPT-RIGHT)	T00D66UZ	
718	314	55-804-00-02-INSP(JIC) (STABILIZER TORSION BOX COMPT-RIGHT)	T00D66V0	
719	315,316	55-806-00-01-CLN(JIC) (APU COMPARTMENT)	T00D5U51	
720	315,316	55-806-00-01-INSP(JIC) (APU COMPARTMENT)	T00D5U5C	
721	323	55-816-00-01-INSP(JIC) (VERTICAL STABILIZER - FRONT SPAR TO REAR SPAR)	T00A0ZGR	
722	324	55-820-00-01-CLN(JIC) (REAR SPAR TO TRAILING EDGE)	T00D6NGQ	
723	324	55-820-00-01-INSP(JIC) (REAR SPAR TO TRAILING EDGE)	T00D6NH1	

T00E1SEN

724	324	55-822-00-01-INSP(JIC) (REAR SPAR TO TRAILING EDGE)	T009XLJ2	
725	325	55-824-00-01-INSP(JIC) (RUDDER)	T00D6NH8	
726	326	55-826-00-01-INSP(JIC) (VERTICAL STABILIZER - TIP)	T00D6NHH	
727	331,341	55-828-00-01-INSP(JIC) (HORIZONTAL STAB CENTER SECTION)	T00A0ZN5	
728	331,341	55-830-00-01-CLN(JIC) (HORIZONTAL STAB CENTER SECTION)	T00D6NRJ	
729	331,341	55-830-00-01-INSP(JIC) (HORIZONTAL STAB CENTER SECTION)	T00D6NRV	
730	334,344	55-832-00-01-INSP(JIC) (HORIZONTAL STABILIZER - FRONT TO REAR SPAR)	T004Q6AX	
731	335,345	55-834-00-01-INSP(JIC) (HORIZONTAL STABILIZER - REAR SPAR TO STABILIZER TRAILING EDGE)	T00D6NJ9	
732	335,345	55-838-00-01-INSP(JIC) (HORIZONTAL STABILIZER - REAR SPAR TO STABILIZER TRAILING EDGE)	T009ZNNL	
733	338,348	55-840-00-01-INSP(JIC) (HORIZONTAL STABILIZER - TIP)	T00D6NRY	
734	210	56-001-00-01-OP(JIC) (No.2 OPENING WINDOW HANDLE)	T009WSSN	
735	211,212	56-001-01-01-LUB(JIC) (No. 2 SLIDING WINDOW - FLIGHT DECK)	T00D66YL	
736	600,500	57-002-01-01-INSP(JIC) (WING VORTEX GENERATOR)	T00D49EE	
737	666,566	57-003-01-01-INSP(JIC) (OUTBOARD FLAP VORTEX GENERATORS)	T00D62E5	
738	135,136	57-458-00-01-CLN(JIC) (WING CENTER SECTION LOWER SURFACE)	T00D5LLZ	
739	135,136	57-458-00-01-INSP(JIC) (WING CENTER SECTION LOWER SURFACE)	T00D5LM0	
740	135,136	57-458-00-01-LUB(JIC) (WING CENTER SECTION LOWER SURFACE)	T00D5LLY	
741	195,196	57-460-00-01-INSP(JIC) (INBOARD FLAP SUPPORT STRUCTURE - LEFT / RIGHT)	T00EUNE2	
742	511,521	57-468-00-01-CLN(JIC) (NACELLE STRUT NO. 1 AFT UPPER SPAR)	T00D5U5M	
743	511,521	57-468-00-01-INSP(JIC) (NACELLE STRUT NO. 1 AFT UPPER SPAR)	T00D5U5Z	
744	511,521	57-468-00-01-LUB(JIC) (NACELLE STRUT NO. 1 AFT UPPER SPAR)	T00D5U5Y	
745	611,621	57-468-00-02-CLN(JIC) (NACELLE STRUT NO. 2 AFT UPPER SPAR)	T00D5U6E	
746	611,621	57-468-00-02-INSP(JIC) (NACELLE STRUT NO. 2 AFT UPPER SPAR)	T00D5U6F	
747	611,621	57-468-00-02-LUB(JIC) (NACELLE STRUT NO. 2 AFT UPPER SPAR)	T00D5U6D	
748	511,521,ZO NE4	57-470-00-01-INSP(JIC) (NACELLE STRUT NO. 1 UPPER LINK)	T00EUP83	
749	611,621	57-470-00-02-INSP(JIC) (NACELLE STRUT NO. 2 UPPER LINK)	T00EUP8K	
750	511	57-472-00-01-CLN(JIC) (SLAT 6 LINK BRACE & ACTUATOR SUPPORT)	T00D67K5	
751	511	57-472-00-01-INSP(JIC) (SLAT 6 LINK BRACE & ACTUATOR SUPPORT)	T00D67K7	

T00E1SEN

752	511	57-472-00-01-LUB(JIC) (SLAT 6 LINK BRACE & ACTUATOR SUPPORT)	T00D67K6	
753	611	57-472-00-02-CLN(JIC) (NO. 7 SLAT LINK BRACE&ACTUATOR SUPPORT)	T00D67LE	
754	611	57-472-00-02-INSP(JIC) (NO. 7 SLAT LINK BRACE&ACTUATOR SUPPORT)	T00D67LG	
755	611	57-472-00-02-LUB(JIC) (NO. 7 SLAT LINK BRACE&ACTUATOR SUPPORT)	T00D67LF	
756	511,521	57-476-00-01-CLN(JIC) (LEFT WING FIXED LEADING EDGE STRUCTURE)	T00D67LP	
757	511,521	57-476-00-01-INSP(JIC) (LEFT WING FIXED LEADING EDGE STRUCTURE)	T00D67MB	
758	511,521	57-476-00-01-LUB(JIC) (LEFT WING FIXED LEADING EDGE STRUCTURE)	T00D67MA	
759		57-476-00-02-CLN(JIC) (RIGHT WING FIXED LEADING EDGE STRUCTURE)	T00D67M2	
760	611,621	57-476-00-02-INSP(JIC) (RIGHT WING FIXED LEADING EDGE STRUCTURE)	T00D67M4	
761		57-476-00-02-LUB(JIC) (RIGHT WING FIXED LEADING EDGE STRUCTURE)	T00D67M3	
762	521,511	57-478-00-01-CLN(JIC) (DETAILED INSPECTION - INTERNAL - NACELLE STRUT NO. 1 UPPER LINK)	T00A06LZ	
763	511,521	57-478-00-01-INSP(JIC) (DETAILED INSPECTION - INTERNAL - NACELLE STRUT NO. 1 UPPER LINK)	T00A06LY	
764	611,621	57-478-00-02-CLN(JIC) (DETAILED INSPECTION - INTERNAL - NACELLE STRUT NO. 2 UPPER LINK)	T00A09CT	
765	611,621	57-478-00-02-INSP(JIC) (DETAILED INSPECTION - INTERNAL - NACELLE STRUT NO. 2 UPPER LINK)	T00A09CU	
766	521	57-488-00-01-CLN(JIC) (NO. 4 SLAT MAIN AND AUXILIARY TRACKS)	T00D6EP5	
767	521	57-488-00-01-INSP(JIC) (NO. 4 SLAT MAIN AND AUXILIARY TRACKS)	T00D6EP7	
768	521	57-488-00-01-LUB(JIC) (NO. 4 SLAT MAIN AND AUXILIARY TRACKS)	T00D6EP6	
769	621	57-488-00-02-CLN(JIC) (NO. 9 SLAT MAIN AND AUXILIARY TRACKS)	T00D67MG	
770	621	57-488-00-02-INSP(JIC) (NO. 9 SLAT MAIN AND AUXILIARY TRACKS)	T00D67MJ	
771	621	57-488-00-02-LUB(JIC) (NO. 9 SLAT MAIN AND AUXILIARY TRACKS)	T00D67MH	
772	530,540	57-506-00-01-INSP(JIC) (LEFT WING INSPAR LWR SURFACE)	T00D5U6P	
773	630,640	57-506-00-02-INSP(JIC) (RIGHT WING INSPAR LOWER SURFACE)	T00D5M1Y	
774	530,540	57-508-00-01-INSP(JIC) (LEFT WING INSPAR UPPER SURFACE)	T009Y264	
775	630,640	57-508-00-02-INSP(JIC) (RIGHT WING INSPAR UPPER SURFACE)	T009Y25G	
776	530	57-510-00-01-INSP(JIC) (EXTERNAL DETAILED - LEFT WING INSPAR UPPER SURFACE)	T00D60MV	
777	630	57-510-00-02-INSP(JIC) (EXTERNAL DETAILED - RIGHT WING INSPAR UPPER SURFACE)	T00D5M0B	
778	530,540	57-512-00-01-INSP(JIC) (EXTERNAL DETAILED - LEFT WING INSPAR LWR SURFACE)	T00D5U74	
779	630,640	57-512-00-02-INSP(JIC) (EXTERNAL DETAILED - RIGHT WING INSPAR LOWER SURFACE)	T00D5LZJ	

T00E1SEN

780	530,540	57-514-00-01-INSP(JIC) (EXTERNAL DETAILED - LEFT WING INSPAR UPPER SURFACE)	T009Y2UP	
781	630,640	57-514-00-02-INSP(JIC) (EXTERNAL DETAILED - RIGHT WING INSPAR UPPER SURFACE)	T009Y2UD	
782	533	57-544-00-01-CLN(JIC) (DETAILED INSPECTION - INTERNAL - NACELLE STRUT NO. 1 BACKUP STRUCTURE)	T00D5MTY	
783	533	57-544-00-01-INSP(JIC) (DETAILED INSPECTION - INTERNAL - NACELLE STRUT NO. 1 BACKUP STRUCTURE)	T00D5MTX	
784	533	57-544-00-01-LUB(JIC)-LAN (NACELLE STRUT NO. 1 BACKUP STRUCTURE)	T00D5MTZ	
785	633	57-544-00-02-CLN(JIC) (DETAILED INSPECTION - INTERNAL - NACELLE STRUT NO. 2 BACKUP STRUCTURE)	T00D5U73	
786	633	57-544-00-02-INSP(JIC) (DETAILED INSPECTION - INTERNAL - NACELLE STRUT NO. 2 BACKUP STRUCTURE)	T00D5U72	
787	633	57-544-00-02-LUB(JIC) (DETAILED INSPECTION - INTERNAL - NACELLE STRUT NO. 2 BACKUP STRUCTURE)	T00D5U71	
788	533	57-546-00-01-INSP(JIC) (INTERNAL DETAILED - L WING SPANWISE SPLICE STRINGER L-15)	T00D6U1G	
789	633	57-546-00-02-INSP(JIC) (INTERNAL DETAILED - R WING SPANWISE SPLICE STRINGER L-15)	T00D6U0L	
790	533	57-548-00-01-INSP(JIC) (INTERNAL DETAILED - LEFT WING FRONT SPAR LOWER CHORD, RIB 7&9)	T00D5U7D	
791	633	57-548-00-02-INSP(JIC) (INTERNAL DETAILED - RIGHT WING FRONT SPAR LOWER CHORD, RIB 7&9)	T00D6U2R	
792		57-564-00-01-CLN(JIC) (LEFT WING TRAILING EDGE SUPPORT STRUCTURE&REAR SPAR)	T00D67MD	
793	552,551,55 3,554,555,5 56,571	57-564-00-01-INSP(JIC) (LEFT WING TRAILING EDGE SUPPORT STRUCTURE&REAR SPAR)	T00D67ML	
794		57-564-00-01-LUB(JIC) (LEFT WING TRAILING EDGE SUPPORT STRUCTURE&REAR SPAR)	T00D67ME	
795	651,652,65 3,654,655,6 56,671	57-564-00-02-CLN(JIC) (RIGHT WING TRAILING EDGE SUPPORT STRUCTURE&REAR SPAR)	T00D6EPT	
796	651,652,65 3,654,655,6 56,671	57-564-00-02-INSP(JIC) (RIGHT WING TRAILING EDGE SUPPORT STRUCTURE&REAR SPAR)	T00D6EPR	
797	651,652,65 3,654,655,6 56,671	57-564-00-02-LUB(JIC) (RIGHT WING TRAILING EDGE SUPPORT STRUCTURE&REAR SPAR)	T00D6EPS	
798	551	57-566-00-01-INSP(JIC) (INTERNAL DETAILED - LEFT UPPER WING / SIDE OF BODY SPLICE)	T009ZQCJ	
799	651	57-566-00-02-INSP(JIC) (INTERNAL DETAILED - RIGHT UPPER WING / SIDE OF BODY SPLICE)	T009ZQ3A	
800	551,552,56 1	57-572-00-01-INSP(JIC) (LEFT WING TRAILING EDGE)	T009Z1EN	
801	651,652,66 1	57-572-00-02-INSP(JIC) (RIGHT WING TRAILING EDGE)	T009Y1JC	
802	553,554,56 2,563,564,5 65	57-576-00-01-INSP(JIC) (LEFT WING SPOILERS)	T00D626V	
803	653,654,66 2,663,664,6 65	57-576-00-02-INSP(JIC) (RIGHT WING SPOILERS)	T00D626H	
804	555	57-580-00-01-INSP(JIC) (LEFT WING INBOARD TRAILING EDGE)	T009ZQBY	
805	655	57-580-00-02-INSP(JIC) (RIGHT WING INBOARD TRAILING EDGE)	T009ZQG0	

T00E1SEN

806	556	57-592-00-01-INSP(JIC) (LEFT INBOARD AILERON)	T00D60MY	
807	656	57-592-00-02-INSP(JIC) (RIGHT INBOARD AILERON)	T00D626F	
808	556	57-594-00-01-INSP(JIC) (EXTERNAL DETAILED - LEFT INBOARD AILERON)	T009ZQEW	
809	656	57-594-00-02-INSP(JIC) (EXTERNAL DETAILED - RIGHT INBOARD AILERON)	T009ZQQ1	
810	561,562,563,564,565,566,567,572,573	57-596-00-01-INSP(JIC) (LEFT WING TRAILING EDGE SUPPORT STRUCTURE / REAR SPAR)	T009ZQGG	
811	661,662,663,664,665,666,667,672,673	57-596-00-02-INSP(JIC) (RIGHT WING TRAILING EDGE SUPPORT STRUCTURE / REAR SPAR)	T009ZQRS	
812	566	57-600-00-01-INSP(JIC) (LEFT WING OUTBOARD TRAILING EDGE FLAP BOX)	T009ZQ5S	
813	666	57-600-00-02-INSP(JIC) (RIGHT WING OUTBOARD TRAILING EDGE FLAP BOX)	T009ZQ3D	
814	566	57-606-00-01-INSP(JIC) (LEFT WING OUTBOARD TRAILING EDGE FLAP)	T00D66YY	
815	666	57-606-00-02-INSP(JIC) (RIGHT WING OUTBOARD TRAILING EDGE FLAP)	T00D60MG	
816		57-612-00-01-CLN(JIC)-LAN (LEFT OUTBOARD AILERON)	T00D67MZ	
817	567	57-612-00-01-INSP(JIC) (DETAILED INSPECTION - EXTERNAL - LEFT OUTBOARD AILERON)	T00D67N6	
818		57-612-00-01-LUB(JIC)-LAN (LEFT OUTBOARD AILERON)	T00D67N0	
819	667	57-612-00-02-CLN(JIC) (DETAILED INSPECTION - EXTERNAL - RIGHT OUTBOARD AILERON)	T00D66Z9	
820	667	57-612-00-02-INSP(JIC) (DETAILED INSPECTION - EXTERNAL - RIGHT OUTBOARD AILERON)	T00D66ZA	
821	667	57-612-00-02-LUB(JIC)-LAN (RIGHT OUTBOARD AILERON)	T00D66Z8	
822		57-614-00-01-CLN(JIC)-LAN (LEFT OUTBOARD AILERON SPAR, HINGES, ACTUATOR)	T009ZQE0	
823	567	57-614-00-01-INSP(JIC) (DETAILED INSPECTION - EXTERNAL - LEFT OUTBOARD AILERON SPAR, HINGES, ACTUATOR)	T009ZQE1	
824	667	57-614-00-02-CLN(JIC) (DETAILED INSPECTION - EXTERNAL - RIGHT OUTBOARD AILERON SPAR, HINGES, ACTUATOR)	T009ZQPP	
825	667	57-614-00-02-INSP(JIC) (DETAILED INSPECTION - EXTERNAL - RIGHT OUTBOARD AILERON SPAR, HINGES, ACTUATOR)	T009ZQPQ	
826	571	57-616-00-01-INSP(JIC) (LEFT WING INBOARD TRAILING EDGE FLAP)	T00EUNAW	
827	671	57-616-00-02-INSP(JIC) (RIGHT WING INBOARD TRAILING EDGE FLAP)	T00EUNEV	
828	611	57-800-00-01-CLN(JIC) (R WING LE TO FRONT SPAR-INBOARD)	T00D62GD	
829	611	57-800-00-01-INSP(JIC) (R WING LE TO FRONT SPAR-INBOARD)	T00D62GE	
830	511,ZONE4	57-800-01-01-CLN(JIC) (L WING LE TO FRONT SPAR - INBOARD)	T00D623K	
831	511	57-800-01-01-INSP(JIC) (L WING LE TO FRONT SPAR - INBOARD)	T00D623L	

T00E1SEN

832	611	57-802-00-01-INSP(JIC) (R WING LE TO FRONT SPAR - INBOARD)	T000GEL0	
833	511	57-802-01-01-INSP(JIC) ("GVI INT - LEFT WING LEADING EDGE TO FRONT SPAR - INBOARD)	T00A0ZS7	
834	511	57-804-00-01-INSP(JIC) (L WING LE FRONT SPAR - INBOARD)	T00D5KMZ	
835	611	57-804-00-02-INSP(JIC) (R WING LE TO FRONT SPAR - INBOARD)	T00D623P	
836	512	57-806-00-01-INSP(JIC) (INBOARD SLAT N? 6)	T00D5JFV	
837	612	57-806-00-02-INSP(JIC) (INBOARD SLATN? 7)	T00D6235	
838	513	57-808-00-01-INSP(JIC) (KREUGER FLAP - LEFT WING)	T00D622N	
839	613	57-808-00-02-INSP(JIC) (KREUGER FLAP - RIGHT WING)	T00D622B	
840	621	57-810-00-01-INSP(JIC) (R WING LE TO FRONT SPAR - OUTBOARD)	T00D60M0	
841	521	57-810-01-01-INSP(JIC) (L WING LE TO FRONT SPAR - OUTBOARD)	T00D6225	
842	621	57-812-00-01-INSP(JIC) (R WING LE TO FRONT SPAR - OUTBOARD)	T000GEL6	
843	521	57-812-01-01-INSP(JIC) ("GVI INT - LEFT WING LEADING EDGE TO FRONT SPAR - OUTBOARD)	T009ZTZ9	
844	522	57-814-00-01-INSP(JIC) (OUTBOARD SLAT NO. 5)	T00D5KNA	
845	622	57-814-00-02-INSP(JIC) (OUTBOARD SLATNO. 8)	T00D6NK0	
846	522	57-816-00-01-INSP(JIC) (OUTBOARD SLATNo. 5)	T004QG83	
847	622	57-816-00-02-INSP(JIC) (OUTBOARD SLATNo. 8)	T004QG6W	
848	523	57-818-00-01-INSP(JIC) (OUTBOARD SLAT NO. 4)	T00D66Z7	
849	623	57-818-00-02-INSP(JIC) (OUTBOARD SLAT NO. 9)	T00D6M3H	
850	523	57-820-00-01-INSP(JIC) (OUTBOARD SLATNo. 4)	T004QG73	
851	623	57-820-00-02-INSP(JIC) (OUTBOARD SLATNo. 9)	T004QG6C	
852	524	57-822-00-01-INSP(JIC) (OUTBOARD SLATNO. 3)	T00D5KNV	
853	624	57-822-00-02-INSP(JIC) (OUTBOARD SLATNO. 10)	T00D621N	
854	524	57-824-00-01-INSP(JIC) (OUTBOARD SLATNo. 3)	T004QG76	
855	624	57-824-00-02-INSP(JIC) (OUTBOARD SLATNo. 10)	T004QG6M	
856	525	57-826-00-01-INSP(JIC) (OUTBOARD SLATNO. 2)	T00D5KPM	
857	625	57-826-00-02-INSP(JIC) (OUTBOARD SLATNO. 11)	T00D61ZM	
858	525	57-828-00-01-INSP(JIC) (OUTBOARD SLATNo. 2)	T004QG7P	
859	625	57-828-00-02-INSP(JIC) (OUTBOARD SLATNo. 11)	T004QG5X	

T00E1SEN

860	526	57-830-00-01-INSP(JIC) (OUTBOARD SLATNO. 1)	T00D5SRJ	
861	626	57-830-00-02-INSP(JIC) (OUTBOARD SLATNO. 12)	T00D6NK9	
862	526	57-832-00-01-INSP(JIC) (OUTBOAR SLATNo. 1)	T004QG7Y	
863	626	57-832-00-02-INSP(JIC) (OUTBOARD SLATNo. 12)	T004QG5M	
864	531	57-834-00-01-INSP(JIC) (CENTER AUXILIARY TANK - LEFT WING)	T004QSZ3	
865	631	57-834-00-02-INSP(JIC) (CENTER AUXILIARY TANK - RIGHT WING)	T004QSYC	
866	532	57-836-00-01-INSP(JIC) (MAIN TANK INBD OF RIB 10)	T004QSYE	
867	632	57-836-00-02-INSP(JIC) (MAIN TANKINBD OF RIB 10)	T004QSZ9	
868	533	57-838-00-01-INSP(JIC) (DRY BAY - INBOARD LEFT WING)	T00D5SRV	
869	633	57-838-00-02-INSP(JIC) (DRY BAY - INBOARD RIGHT WING)	T00D5SS3	
870	541	57-840-00-01-INSP(JIC) (MAIN TANKOB OF RIB 10)	T004QSY9	
871	641	57-840-00-02-INSP(JIC) (MAIN TANK OB OF RIB 10)	T004QSZC	
872	542	57-842-00-01-INSP(JIC) (SURGE TANK - LEFT WING)	T004QSY2	
873	642	57-842-00-02-INSP(JIC) (SURGE TANK - RIGHT WING)	T004QSZE	
874	551	57-846-00-01-INSP(JIC) (REAR SPAR TO MLG SUPPORT BEAM -L WING)	T00D60M3	
875	651	57-846-00-02-INSP(JIC) (REAR SPAR TO MLG SUPPORT BEAM-R WING)	T00D61Y6	
876	552,ZONE3	57-848-00-01-INSP(JIC) (L MLG SUPT BEAM & REAR SPAR TO TE)	T00D5KTP	
877	652,ZONE3	57-848-00-02-INSP(JIC) (R MLG SUPT BEAM & REAR SPAR TO TE)	T00D61YJ	
878	555	57-850-00-01-INSP(JIC) (INBOARD TRAILING EDGE FLAP - L WING)	T00D66UF	
879	655	57-850-00-02-INSP(JIC) (INBOARD TRAILING EDGE FLAP - R WING)	T00D61YD	
880	556	57-852-00-01-INSP(JIC) (INBOARD AILERON - LEFT WING)	T00D60LQ	
881	656	57-852-00-02-INSP(JIC) (INBOARD AILERON - RIGHT WING)	T00D6U2U	
882	561	57-854-00-01-CLN(JIC) (REAR SPAR TO WING TE - LEFT WING)	T00D6NKP	
883	561	57-854-00-01-INSP(JIC) (REAR SPAR TO WING TE - LEFT WING)	T00D6NKC	
884	661	57-854-00-02-CLN(JIC) (REAR SPAR TO WING TE - RIGHT WING)	T00D6EQB	
885	661	57-854-00-02-INSP(JIC) (REAR SPAR TO WING TE - RIGHT WING)	T00D6EQC	
886	567	57-856-00-01-INSP(JIC) (OUTBOARD AILERON - LEFT WING)	T00D61X4	
887	667	57-856-00-02-INSP(JIC) (OUTBOARD AILERON - RIGHT WING)	T00D61XX	

T00E1SEN

888	567	57-858-00-01-INSP(JIC) (OUTBOARD AILERON - LEFT WING)	T00D6NL3	
889	667	57-858-00-02-INSP(JIC) (OUTBOARD AILERON - RIGHT WING)	T00D6NLW	
890	571	57-860-00-01-CLN(JIC) (OB FLAP SUPPORT FAIRING - L IB FLAP)	T00D66ZE	
891	571	57-860-00-01-INSP(JIC) (OB FLAP SUPPORT FAIRING - L IB FLAP)	T00D66ZF	
892	671	57-860-00-02-CLN(JIC) (OB FLAP SUPPORT FAIRING - R IB FLAP)	T00D62GK	
893	671	57-860-00-02-INSP(JIC) (OB FLAP SUPPORT FAIRING - R IB FLAP)	T00D62H1	
894	572	57-862-00-01-CLN(JIC) (IB FLAP SUPPORT FAIRING - L OB FLAP)	T00D66ZJ	
895	572	57-862-00-01-INSP(JIC) (IB FLAP SUPPORT FAIRING - L OB FLAP)	T00D66ZC	
896	672	57-862-00-02-CLN(JIC) (IB FLAP SUPPORT FAIRING - R OB FLAP)	T00D6NM8	
897	672	57-862-00-02-INSP(JIC) (IB FLAP SUPPORT FAIRING - R OB FLAP)	T00D6NM7	
898	573	57-864-00-01-CLN(JIC) (OB FLAP SUPPORT FAIRING - L OB FLAP)	T00D6NMS	
899	573	57-864-00-01-INSP(JIC) (OB FLAP SUPPORT FAIRING - L OB FLAP)	T00D6NMR	
900	673	57-864-00-02-CLN(JIC) (OB FLAP SUPPORT FAIRING - R OB FLAP)	T00D62H3	
901	673	57-864-00-02-INSP(JIC) (OB FLAP SUPPORT FAIRING - R OB FLAP)	T00D62H4	
902	432	71-317-00-01-INSP(JIC) (STRUT DRAIN INLETS -- ENG 1)	T00D5J93	
903	442	71-317-00-02-INSP(JIC) (STRUT DRAIN INLETS - ENG 2)	T00D5JA9	
904	410,430	71-329-01-01-INSP(JIC) (ENGINE 1 STRUT DRAINS)	T00D6GW7	
905	440,420	71-329-01-02-INSP(JIC) (ENGINE 2 STRUT DRAINS)	T00D5U88	
906	410	71-600-00-03-CLN(JIC) (DETAILED INSPECTION - INTERNAL - NO. 1 POWER PLANT)	T00D66U8	
907	410	71-600-00-03-INSP(JIC) (DETAIL INSPECTION - INTERNAL - NO. 1 POWER PLANT)	T00D66U2	
908	420	71-600-00-04-CLN(JIC) (DETAILED INSPECTION - INTERNAL - NO. 2 POWER PLANT)	T00D5U8L	
909	420	71-600-00-04-INSP(JIC) (DETAIL INSPECTION - INTERNAL - NO. 2 POWER PLANT)	T00D5U8M	
910	411	71-820-00-01-INSP(JIC) (ENGINE 1)	T00D5JBJ	
911	421	71-820-00-02-INSP(JIC) (ENGINE 2)	T00D5JB6	
912	412	71-824-00-01-INSP(JIC) (NOSE COWL - ENGINE 1)	T00D4JAX	
913	422	71-824-00-02-INSP(JIC) (NOSE COWL - ENGINE 2)	T00D512M	
914	413,414	71-826-00-01-INSP(JIC) (FAN COWL PANELS - ENGINE 1)	T00D4BKD	
915	423,424	71-826-00-02-INSP(JIC) (FAN COWL PANELS - ENGINE 2)	T00D512D	

T00E1SEN

916	415,416	71-828-00-01-INSP(JIC) (THRUST REVERSERS - ENGINE 1)	T00D60LT	
917	425,426	71-828-00-02-INSP(JIC) (THRUST REVERSERS - ENGINE 2)	T00D5SS9	
918	415,416	71-830-00-01-INSP(JIC) (THRUST REVERSERS - ENGINE 1)	T00D5JFH	
919	425,426	71-830-00-02-INSP(JIC) (THRUST REVERSERS - ENGINE 2)	T00D5SSM	
920	417,418	71-832-00-01-INSP(JIC) (CORE COWL PANNELS - ENGINE 1)	T00D5JBR	
921	427,428	71-832-00-02-INSP(JIC) (CORE COWL PANNELS - ENGINE 2)	T00D512U	
922	417,418	71-834-00-01-INSP(JIC) (CORE COWL PANNELS - ENGINE 1)	T00D5SSP	
923	427,428	71-834-00-02-INSP(JIC) (CORE COWL PANELS - ENGINE 2)	T00D5JBT	
924	411	73-303-00-01-SVC(JIC) (FUEL FILTER ELEMENT - ENG 1)	T00D6702	
925	421	73-303-00-02-SVC(JIC) (FUEL FILTER ELEMENT - ENG 2)	T00D6704	
926	ZONE4	73-306-01-01-FC(JIC) (FUEL FILTER BYPASS WARNING SYSTEM - L)	T00A1S9G	
927	211,411	73-306-01-01-OP(JIC) (FUEL FILTER BYPASS WARNING SYSTEMS - L)	T00A1S9F	
928	ZONE4	73-306-01-02-FC(JIC) (FUEL FILTER BYPASS WARNING SYSTEM - R)	T00A1S94	
929	211,421	73-306-01-02-OP(JIC) (FUEL FILTER BYPASS WARNING SYSTEM - R)	T00A1S95	
930	211	74-302-01-02-OP(JIC) (IGNITION CONTROL SYSTEMS)	T009WSWD	
931	415,416	78-312-00-01-INSP(JIC) (THRUST REVERSER BLOCKER DOORS)	T00D5HR6	
932	425,426	78-312-00-02-INSP(JIC) (THRUST REVERSER BLOCKER DOORS)	T00D5HQ1	
933	413,414	78-320-00-01-FC(JIC) (T/R ROTARY FLEXIBLE DRIVE SHAFTS - L)	T00D7492	
934	413,414	78-320-00-01-INSP(JIC) (T/R ROTARY FLEXIBLE DRIVE SHAFTS - L)	T00D7493	
935	413,414	78-320-00-01-LUB(JIC) (T/R ROTARY FLEXIBLE DRIVE SHAFTS - L)	T00D7496	
936	413,414	78-320-00-01-REINS(JIC) (T/R ROTARY FLEXIBLE DRIVE SHAFTS - L)	T00D7494	
937	413	78-320-00-01-REM(JIC) (T/R ROTARY FLEXIBLE DRIVE SHAFTS - L)	T00D7495	
938	423,424	78-320-00-02-FC(JIC) (T/R ROTARY FLEXIBLE DRIVE SHAFTS - R)	T00D74AF	
939	423,424	78-320-00-02-INSP(JIC) (T/R ROTARY FLEXIBLE DRIVE SHAFTS - R)	T00D74AE	
940	423,424	78-320-00-02-LUB(JIC) (T/R ROTARY FLEXIBLE DRIVE SHAFTS - R)	T00D74AH	
941	423,424	78-320-00-02-REINS(JIC) (T/R ROTARY FLEXIBLE DRIVE SHAFTS - R)	T00D74AD	
942	414	78-320-00-02-REM(JIC) (T/R ROTARY FLEXIBLE DRIVE SHAFTS - R)	T00D74AG	
943	415,416	78-322-00-01-INSP(JIC) (L T/R BALLSCREW ACTUATOR ATTACH PT)	T00D5ST2	

T00E1SEN

944	425,426	78-322-00-02-INSP(JIC) (R T/R BALLSCREW ACTUATOR ATTACH PT)	T00D5STC	
945	411	78-323-00-01-FC(JIC) (FNC - ENGINE 1 T/R BLOCKER DOOR HINGES)	T00D74AV	
946	411	78-323-00-01-INSP(JIC) (FNC - ENGINE 1 T/R BLOCKER DOOR HINGES)	T00D74AW	
947	421	78-323-00-02-FC(JIC) (FNC - ENGINE 2 T/R BLOCKER DOOR HINGES)	T00D74B4	
948	421	78-323-00-02-INSP(JIC) (FNC - ENGINE 2 T/R BLOCKER DOOR HINGES)	T00D74AY	
949	211,212,410	78-328-00-01-OP(JIC) (ENGINE 1 T/R DISAGREEMENT CIRCUIT)	T00D751F	
950	211,212,420	78-328-00-02-OP(JIC) (OPERATIONAL CHECK - ENGINE 2 T/R DISAGREEMENT CIRCUIT)	T00D74P9	
951	211,212,410	78-329-00-01-FC(JIC) (ENG 1 T/R STOW/NOT-STOWED SWITCHES&WIRES)	T00D74BL	
952	211,212,410	78-329-00-01-OP(JIC) (ENG 1 T/R STOW/NOT-STOWED SWITCHES&WIRES)	T00D74BM	
953	211,212,420	78-329-00-02-FC(JIC) (ENG 2 T/R STOW/NOT-STOWED SWITCHES&WIRES)	T00D7BAC	
954	211,212,420	78-329-00-02-OP(JIC) (ENG 2 T/R STOW/NOT-STOWED SWITCHES&WIRES)	T00D7BAB	
955	411	78-330-00-01-INSP(JIC) (ENG 1 THRUST REVERSER BULL-NOSE SEAL)	T00D5LYW	
956	421	78-330-00-02-INSP(JIC) (ENG 2 THRUST REVERSER BULL-NOSE SEAL)	T00D5STF	
957	411	78-337-01-01-FC(JIC) (ENG 1 DIRECTIONAL PILOT VALVE FILTER)	T00D74BS	
958	411	78-337-01-01-SVC(JIC) (ENG 1 DIRECTIONAL PILOT VALVE FILTER)	T00D74BT	
959	421	78-337-01-02-FC(JIC) (ENG 2 DIRECTIONAL PILOT VALVE FILTER)	T00D74CB	
960	421	78-337-01-02-SVC(JIC) (ENG 2 DIRECTIONAL PILOT VALVE FILTER)	T00D74CC	
961	ZONE4	79-310-01-01-FC(JIC) (OIL FILTER BYPASS WARNING SYSTEM - L)	T00A1S8V	
962	ZONE4	79-310-01-01-OP.(JIC) (OIL FILTER BYPASS WARNING SYSTEM - L)	T00A1S8W	
963	ZONE4	79-310-01-02-FC(JIC) (OIL FILTER BYPASS WARNING SYSTEM - R)	T00A1S9N	
964	ZONE4	79-310-01-02-OP.(JIC) (OIL FILTER BYPASS WARNING SYSTEM - R)	T00A1S9P	
965	411	80-304-01-01-SVC(JIC) (START VALVE FILTER - ENG 1)	T00D74FA	
966	421	80-304-01-02-SVC(JIC) (START VALVE FILTER - ENG 2)	T00D74FP	
967		AASR-B767-C(JIC-L7) (AGING AIRPLANE SAFETY RULE - REPAIRS AND ALTERATIONS CONTROL LIST)	T00D7AW8	
968	200	B767-019-INSP(JIC) (MAXIMUM LOAD PLACARD INSTALLATION IN MAIN DECK)	T00D4JB3	
969	430,410	B767-040-M1-OP(JIC) (PNEUMATIC SYS HEALTH CHECK- OPERATIONAL TEST - ENGINE 1)	T00D70RF	
970	420,440	B767-040-M2-OP(JIC) (PNEUMATIC SYS HEALTH CHECK- OPERATIONAL TEST - ENGINE 2)	T00D70C0	
971	300	B767-045-INSP(JIC) (INSPECT TILT SENSOR ZONE OF MLG)	T00D6GWP	

T00E1SEN

972	ZONE3	B767-045-SVC(JIC) (INSPECT TILT SENSOR ZONE OF MLG)	T00D6GWN	
973	300	B767-061-INSP(JIC) (CHECK ATTACHMENT FROM THE P40 APU)	T00D5U98	
974	100	B767-070-INSP(JIC) (COAXIAL CABLE CHECK)	T00D6GMC	
975	500,531,600	B767-072-INSP(JIC) (FUEL MICROORGANISM CONTROL)	T00D74Q0	
976	731,741	B767-079-SVC(JIC) (MAIN LANDING GEAR FLUSHING SHOCK STRUT)	T00D6GX8	
977	711	B767-080-SVC(JIC) (NOSE LANDING GEAR FLISHING SHOCK STRUT)	T00D6EQA	
978	211,212	B767-081-BOEING-OP(JIC) (OPERATIONAL TEST ENHANCED GROUND PROXIMITY WARNING)	T00D4FQW	
979	300	B767-127-INSP(JIC) (BRAKE HYDRAULIC TUBING INSPECTION - REPAIR)	T00D5HPM	
980	730,740	B767-138-INSP(JIC) (AILERON CONTROL QUADRANT INSPECTION)	T004QWK0	
981	212,811	B767-139-OP(JIC) (EQUIPMENT COOLING SYSTEM GROUND CLEANING)	T00D7C2J	
982	211,221,232,251,252	B767-140-OP(JIC) (CREW REST AREA SMOKE DETECTOR)	T00D4FSQ	
983	731,741	B767-143-FC(JIC) (INSPECTION AND REMOVAL OF THE ANTISKID WIRE BUNDLE FROM LANDING GEAR)	T006Q7AY	
984	741,731	B767-143-INSP(JIC) (INSPECTION AND REMOVAL OF THE ANTISKID WIRE BUNDLE FROM LANDING GEAR)	T006Q7B4	
985	731,741	B767-143-INST(JIC) (INSPECTION AND REMOVAL OF THE ANTISKID WIRE BUNDLE FROM LANDING GEAR)	T006Q7AX	
986	731,741	B767-143-REM(JIC) (INSPECTION AND REMOVAL OF THE ANTISKID WIRE BUNDLE FROM LANDING GEAR)	T006Q7AW	
987	731,741	B767-144-INSP(JIC) (LANDING GEAR - INSPECTION OF THE WIRE BUNDLE ANTISKID & TRANSDUCER CONNECTOR EXPOSED)	T00D74VR	
988	731,741	B767-144-INST(JIC) (LANDING GEAR - INSPECTION OF THE WIRE BUNDLE ANTISKID & TRANSDUCER CONNECTOR EXPOSED)	T00D74VP	
989	731,741	B767-144-REM(JIC) (LANDING GEAR - INSPECTION OF THE WIRE BUNDLE ANTISKID & TRANSDUCER CONNECTOR EXPOSED)	T00D74VQ	
990	400	B767-147-ENG1-FC(JIC) (WIRE AND CONNECTOR REPLACEMENT)	T00A1S9Z	
991	400	B767-147-ENG1-INSP(JIC) (IWIRE AND CONNECTOR REPLACEMENT)	T00A1S9M	
992	400	B767-147-ENG1-REINS(JIC) (WIRE AND CONNECTOR REPLACEMENT)	T00A1S9Y	
993	400	B767-147-ENG1-REM(JIC) (WIRE AND CONNECTOR REPLACEMENT)	T00A1S9L	
994	400	B767-147-ENG1-RPCL(JIC) (WIRE AND CONNECTOR REPLACEMENT)	T00A1S9K	
995	400	B767-147-ENG2-FC(JIC) (WIRE AND CONNECTOR REPLACEMENT)	T00A1S9I	
996	400	B767-147-ENG2-INSP(JIC) (WIRE AND CONNECTOR REPLACEMENT)	T00A1S8Y	
997	400	B767-147-ENG2-REINS(JIC) (WIRE AND CONNECTOR REPLACEMENT)	T00A1S8Z	
998	400	B767-147-ENG2-REM(JIC) (WIRE AND CONNECTOR REPLACEMENT)	T00A1S90	

T00E1SEN

999	400	B767-147-ENG2-RPCL(JIC) (WIRE AND CONNECTOR REPLACEMENT)	T00A1S92	
1000	ZONE2	B767-151-MAS-INSP(JIC) (VISUALLY CHECK DESCENT DEVICE ROPES FOR CONDITION AND SECURITY)	T00D4N5V	
1001	ZONE2	B767-157-INSP(JIC) (ANTENNA CONNECTOR HOLELFEC)	T00D6GXJ	
1002	200	B767-157-INST(JIC) (ANTENNA CONNECTOR HOLELFEC)	T00D6GXK	
1003	200	B767-157-RMVL(JIC) (ANTENNA CONNECTOR HOLELFEC)	T00D6GXL	
1004		B767-209-INSP(JIC) (INSPECT DECAL P/N LA-11-302 (COCKPIT EMERGENCY EXIT PLACARD))	T00D4GQ7	
1005	212,211	B767-217-TEST(JIC) (Indicating System For The Hydraulic Pressure)	T00D740N	
1006		B767-222-LH-INSP(JIC) (Adjustment - Thrust Reverser Actuation System)	T00D6NUC	
1007		B767-222-RH-INSP(JIC) (Adjustment - Thrust Reverser Actuation System)	T00D741N	
1008	ZONE1	B767-FS-002-INSP(JIC) (VERIFY PATHS OF DRAINAGE)	T00D6GM4	
1009	ZONE1	B767-FS-006-CLN(JIC) (MAKE DEEP CLEANING TO CARGO COMPARTMENT)	T00D6GMH	
1010	ZONE2	B767-FS-012-INSP(JIC) (CORRECT LEAKAGE OF PRESSURIZATION)	T00D7C21	
1011	193,194,53 1,532,541,6 31,632,641	B767-FS-036-INSP(JIC) (FIND THE FUEL QUANTITY)	T00D5BTP	
1012	521,531,53 2,541,631,6 32,641	B767-FS-038-INSP(JIC) (COMPARISON CHECK - FUEL QUANTITY INDICATING SYSTEM (FQIS) WITH THE FUEL MEASURING STICKS)	T00D5BSQ	
1013	ZONE1	B767-IMG-01-INSP(JIC) (VERIFY CONDITION OF EXTERNAL PAINTING)	T00D6N7T	
1014		B767-IMG-02-INSP(JIC) (VERIFY CONDITION OF EXTERNAL PAINTING)	T00D6N85	
1015	ZONE3	B767-IMG-03-INSP(JIC) (VERIFY CONDITION OF EXTERNAL PAINTING IN EMPENAJE)	T00D6N7R	
1016	ZONE5	B767-IMG-04-INSP(JIC) (VERIFY CONDITION OF EXTERNAL PAINTING IN WINGS (SOFTNESS))	T00D6N8T	
1017	120	BE0016784-INSP(JIC) (FWD CARGO COMPARTMENT INSPECTION)	T00D5JED	
1018	150	BE0026784-INSP(JIC) (AFT CARGO COMPARTMENT INSPECTION)	T00D5LXG	
1019	ZONE4	BE0300552-INSP(JIC) (TABLE FOR MAXIMUM OIL CONSUMPTION)	T00D5HM5	
1020	200	BE0300558-INSP(JIC) (TOILETS INSPECTION)	T00D4GR0	
1021	ZONE2	BE0300562-CLN(JIC) (MAIN DECK CARGO COMPARTMENT INSPECTION)	T00D60K8	
1022	200	BE0300562-FC(JIC) (MAIN DECK CARGO COMPARTMENT INSPECTION)	T00D60K9	
1023	ZONE2	BE0300562-INSP(JIC) (MAIN DECK CARGO COMPARTMENT INSPECTION)	T00D60KF	
1024	100,ZONE3	BE0300566-INSP(JIC) (APU OIL COOLER INSPECTION AND CLEAN)	T00D5U9F	
1025	123,124,15 5,156	BE0300579-INSP(JIC) (INSPECTION BLANKETS LOWER DECK)	T00D5C1D	

T00E1SEN

1026	315	BE0503946-INSP(JIC) (INSPECTION A.P.U)	T00D5LWW	
1027	200	BE300497-INSP(JIC) (CHECK - REGISTER IDENTIFICATION PLATE)	T00D4GR3	
1028	211,212	IH-B767-51-A5115(JIC) (No. 2 WINDOW LEAK CHECK)	T00D7C2B	
1029	211	IH-B767-56-A5007-LH(JIC) (NO. 2 WINDOW SEAL - REMOVAL/INSTALLATION)	T00AN79F	
1030	212	IH-B767-56-A5007-RH(JIC) (NO. 2 WINDOW SEAL - REMOVAL/INSTALLATION)	T00AN79G	
1031	410,430,510	L-28-B767-236-ENG1-INSP(JIC) (RST - REPLACE STRUT COUPLING O-RINGS)	T004RZHE	
1032	410,430,510	L-28-B767-236-ENG1-OP(JIC) (RST - REPLACE STRUT COUPLING O-RINGS)	T004RZHF	
1033	410,430,510	L-28-B767-236-ENG1-SVC(JIC) (RST - REPLACE STRUT COUPLING O-RINGS)	T004RZHG	
1034	420,440,610	L-28-B767-236-ENG2-INSP(JIC) (RST - REPLACE STRUT COUPLING O-RINGS)	T004RZH6	
1035	420,440,610	L-28-B767-236-ENG2-OP(JIC) (RST - REPLACE STRUT COUPLING O-RINGS)	T004RZH5	
1036	420,440,610	L-28-B767-236-ENG2-SVC(JIC) (RST - REPLACE STRUT COUPLING O-RINGS)	T004RZH7	
1037	ZONE2	MP-B767-25-072-INSP(JIC) (INSP - LIFE JACKETS INSPECTION)	T00EDVMP	
1038	200	MP-B767-25-083-CLN(JIC) (CLEAN & VISUAL INSPECTION - MAIN DECK CARGO COMPARTMENT)	T00D6N90	
1039	ZONE5	MP-B767-27-094(JIC) (FNC - SPEEDBRAKE AUTOSTOW SYSTEM)	T00D77UY	
1040	ZONE5	MP-B767-27-095-INSP(JIC) (GVI - WINGLET FORWARD POSITION LIGHT LENS)	T009YH2A	
1041	200	MP-B767-56-092-LH-ADJUSTMENT(JIC) (No.2 WINDOW - ADJUSTMENTS)	T00D60E8	
1042	200	MP-B767-56-092-RH-ADJUSTMENT(JIC) (No.2 WINDOW - ADJUSTMENTS)	T00D60C7	
1043	645	MP-B767-57-106-INSP(JIC) (DETAIL INSPECTION - INTERNAL - RIGHT WINGLET)	T00D74GQ	
1044	545	MP-B767-57-107-INSP(JIC) (DETAIL INSPECTION - INTERNAL - LEFT WINGLET)	T00D74GV	
1045		RP-B767-11-A1932 PART 3 (JIC-INSPECTION) (DENT AND REPAIRS CHART UP DATE 767 FLEET)	T00D74GY	
1046		SI-54-0232-00 (REQ) (INSPECTION PER SHIM MIGRATED AT NACCELLE STRUT NR.1, UPPER LINK FAN COWL SUPPORT NEAR	T00D5SUE	
1047		OPEN-B767 ZONA400 (Master Panel Card B767 ZONA 400)	T00F09FK	
1048		CLOSE-B767 ZONA400 (Master Panel Card B767 ZONA 400)	T00F09FL	
1049		OPEN-B767 ZONA500 (Master Panel Card B767 ZONA 500)	T00F09FM	
1050		CLOSE-B767 ZONA500 (Master Panel Card B767 ZONA 500)	T00F09FN	
1051		OPEN-B767 ZONA200 (Master Panel Card B767 ZONA 200)	T00F09FP	
1052		CLOSE-B767 ZONA200 (Master Panel Card B767 ZONA 200)	T00F09G0	
1053		OPEN-B767 ZONA300 (Master Panel Card B767 ZONA 300)	T00F09G1	

T00E1SEN

1054		CLOSE-B767 ZONA300 (Master Panel Card B767 ZONA 300)	T00F09G2	
1055		OPEN-B767 ZONA100 (Master Panel Card B767 ZONA 100)	T00F09G3	
1056		CLOSE-B767 ZONA100 (Master Panel Card B767 ZONA 100)	T00F09G4	
1057	211	27-010-00-02-OP(JIC) (Rudder Power Control Actuator)	T00EVADZ	
1058	211	27-018-00-01-OP(JIC) (Elevator Power Control Actuator)	T00EVATP	
1059	731	32-089-00-01-LUB(JIC) (LEFT MAIN GEAR BRAKE COMPONENTS LUBRICATION)	T00EVB16	
1060	741	32-089-00-02-LUB(JIC) (RIGHT MAIN GEAR BRAKE COMPONENTS LUBRICATION)	T00EVAWH	
1061	211	77-304-00-01-OP(JIC) (STANDBY ENGINE INDICATOR)	T00EV9FG	
1062	411	80-301-00-01-SVC(JIC) (ENGINE 1 STARTER OIL CHANGE)	T00F4DGB	
1063	421	80-301-00-02-SVC(JIC) (ENGINE 2 STARTER OIL CHANGE)	T00F4DNY	

1064		OT-72-0037-09(JIC) (FAN BLADE DOVETAIL'S LUBRICATION)	T00F5UHD	
1065	253,161	31-002-01-01-OP(JIC) ("OPC - FLIGHT DATA RECORDER ULB)	T00D4B6E	
1066	253,161	23-005-01-01-OP(JIC) (VOICE DATA RECORDER ULB)	T00D4B1W	
1067	119,211,21 2,521,531,6 21,631	28-017-00-01-FC(JIC) (FUNCTIONAL - CTR AUX TANK FUEL PUMP AUTO SHUTOFF)	T00D66WB	
1068		OPEN-B767 ZONA500 (Master Panel Card B767 ZONA 500)	T00F5VP2	
1069		CLOSE-B767 ZONA500 (Master Panel Card B767 ZONA 500)	T00F5VP3	
1070	200	35-008-01-01-INSP(JIC) (PORTABLE OXYGEN BOTTLES)	T00ELLS0	
1071	ZONE2	25-62-55-01-010-REPL(JIC) (LIFE_RAFT_ASSY_6_MAN-REPLACEMENT)	T00DDEJY	
1072		B767-105-OP(JIC) (VOR SYS OPERATIONAL CHECK - FAR 91.171)	T00F36KC	
1073		MD-B767-34-A3805-04-GROUP2(JIC) (LOADING NAVIGATION DATA BASE IN FLIGHT MANAGEMENT SYSTEM)	T00F2VE1	
1074	119,211,12 0,212	24-31-01-02-035-INST (BATTERY-INST)	T00EJKLK	
1075		24-31-01-02-035-RMVL (BATTERY-RMVL)	T00EJKLL	
1076	253,254	23-24-01-02-630-2-REPL(JIC) (ELT-REPLACEMENT)	T00DH7TH	
1077	211	35-10-80-01-001A-INST (MASK-PORTABLE BOTTLE OXY-INST)	T008R97U	
1078		35-10-80-01-001A-RMVL (MASK-PORTABLE BOTTLE OXY-RMVL)	T008R97V	

Signatures:

Skill	Hours	Performed By (Print)	Signature	Date
-------	-------	----------------------	-----------	------

--	--	--	--	--