



TALLY SHEET



T00L64GK

AIRCRAFT ID:

N564LA

Page: 1 / 53

USE THE REGION BELOW FOR HARDCOPY CERTIFICATION (NOT e-SIGN)

WORK PACKAGE INFORMATION:

HM-WP N564LA DEC2022 [1C+S1+AWL] [MPD]

Aircraft Type:	Serial N°:	Effective Code:
B767F - N564LA	40593	030
Work Location:	Organization:	Start Date:
AUH/ADAT HGR	Repair Station FAA 2GUY107C	12/14/22 8:00 AM
Work Order N°	Flight Hours:	Flight Cycles:
WO - 139776507		

TASK LIST:

Line N°	Barcode:	Status:	Task Name:	OBS	Signature
1	T00N063F	ACTV	21-025-00-07-FC(JIC) (FUNCTIONAL - ZONE DUCT OVERHEAT SWITCH)		
2	T00LK0AW	ACTV	21-51-22-04-005A-INST (OZONE CONVERTER-INST)		
3	T00LK0AV	ACTV	21-51-22-04-005A-RMVL (OZONE CONVERTER-RMVL)		
4	T00M4EZ8	ACTV	23-006-00-01-OP(JIC) (Emergency Locator Transmitter)	INSP	
5	T00L24AM	ACTV	24-041-02-01-FNC(JIC) (AIRPLANE EXTERNAL POWER RECEPTACLE NEUTRAL PIN CONTINUITY TO AIRFRAME GROUND)		
6	T00M8H6Y	ACTV	24-31-01-02-035-REPL(JIC) (BATTERY-REPLACEMENT)	INSP	
7	T00NQUG4	ACTV	25-006-00-01-INSP(JIC) (Lavatory Waste Compartment Doors)		

USE THE REGION BELOW FOR HARDCOPY CERTIFICATION (NOT e-SIGN)

8	T00MG1SK	ACTV	25-012-01-01-INSP(JIC) (CREW ENTRY DOOR ESCAPE ROPE)		
9	T00MVBTK	ACTV	25-041-01-01-INSP(JIC) (EMERGENCY ESCAPE DESCENT DEVICES)		
10	T00N4E8L	ACTV	25-63-00-01-050-REPL(JIC) (VHF_EMERGENCY_LOC_TX(CARGO A/C)-REPL)	INSP	
11	T00HEUPF	ACTV	27-050-00-01-LUB(JIC) (LEFT OUTBOARD AND INBOARD SLAT AUXILIARY TRACK ROLLERS AND SIDE BRACE LINKS)		
12	T00HEUNY	ACTV	27-050-00-02-LUB(JIC) (RIGHT OUTBOARD AND INBOARD SLAT AUXILIARY TRACK ROLLERS AND SIDE BRACE LINKS)		
13	T00NV8MK	ACTV	28-043-00-01-OP(JIC) (FUEL QUANTITY INDICATING SYSTEM (FQIS) - LOW FUEL AND FUEL CONFIG INDICATION TEST)	INSP	
14	T00N6A9S	ACTV	29-015-00-01-OP(JIC) (AUTO&MANUAL RAT DEPLOYMENT SYSTEMS)	INSP	
15	T00N6AA4	ACTV	31-001-00-10-OP(JIC) (Flight Data Recorder Parameters)		
16	T00N2WXT	ACTV	32-100-01-01-LUB(JIC) (LEFT MAIN GEAR AFT TRUNNION BUSHING)		
17	T00N2WXV	ACTV	32-100-01-02-LUB(JIC) (R Main Gear Aft Trunnion Bushing)		
18	T00FWYGA	ACTV	47-004-00-01-INSP(JIC) (NITROGEN GENERATION SYSTEM FLUID CHECK)		
19	T00L1GSC	ACTV	47-007-00-01-INSP(JIC) ("DET - NITROGEN SYS DISTRIBUTION LINES)	INSP	

USE THE REGION BELOW FOR HARDCOPY CERTIFICATION (NOT e-SIGN)

20	T00KDC68	ACTV	47-008-00-01-OP(JIC) (CENTER TANK VENT CROSS FLOW CK VALVE)	INSP	
21	T00DYBYF	ACTV	47-009-00-01-OP(JIC) (OPERATIONAL - NITROGEN GENERATION SYSTEM (NGS) REFUEL SIGNAL INPUT SIGNAL)		
22	T00N5ANY	ACTV	52-017-04-01-LUB(JIC) (STANDARD LOWER CARGO DOOR STOPS, HOOK ROLLER BOLTS&ROTARY ACTUATOR LUBRICATION)		
23	T00MDKP3	ACTV	52-027-00-01-OP(JIC) (AFT CARGO DOOR OPERATING MECHANISM)		
24	T00MG1G1	ACTV	52-047-00-01-OP(JIC) (MAIN DECK CARGO DOOR MANUAL DRIVE)		
25	T00N5CM0	ACTV	52-402-00-01_INSP(JIC) (BULK CARGO COMPARTMENT DOOR)	Me	
26	T00N5DE8	ACTV	52-406-00-01_INSP(JIC) (FWD CARGO COMPARTMENT DOOR)	Me	
27	T00N5JAY	ACTV	52-410-00-01_INSP(JIC) (AFT CARGO DOOR)	Me	
28	T00MM2XM	ACTV	52-416-00-01_INSP(JIC) (ENTRY & GALLEY SERVICE DOORS)	Me	
29	T00N6843	ACTV	52-418-00-01-LUB(JIC) (OWERWING EMERGENCY EXIT HATCH)		
30	T00N6842	ACTV	52-418-00-01_INSP(JIC) (OWERWING EMERGENCY EXIT HATCH)	Me	
31	T00MG1JS	ACTV	52-430-00-01-INSP(JIC) (MAIN DECK CARGO DOOR)	Me	

USE THE REGION BELOW FOR HARDCOPY CERTIFICATION (NOT e-SIGN)

32	T00L26GR	ACTV	52-822-00-01-INSP(JIC) (OVERWING EMERGENCY EXITS - LEFT)		
33	T00L26GP	ACTV	52-822-00-02-INSP(JIC) (OVERWING EMERGENCY EXIT - RIGHT)		
34	T00L26SH	ACTV	52-828-00-01-INSP(JIC) (PASSENGER CABIN DOOR - AFT ENTRY)		
35	T00L26R2	ACTV	52-842-00-01-INSP(JIC) (PASSENGER CABIN DOOR - FORWARD SERVICE)		
36	T00L26SK	ACTV	52-844-00-01-INSP(JIC) (PASSENGER CABIN DOOR - AFT SERVICE)		
37	T00L1SLE	ACTV	53-524-01-01-INSP(JIC) (GVI - LH-WING CENTER SECTION (WCS) REAR SPAR WEB AND REAR SPAR BULKHEAD FITTINGS)	Me	
38	T00L1SLK	ACTV	53-524-01-02-INSP(JIC) (GENERAL VISUAL INSPECTION - RH-WING CENTER SECTION (WCS) REAR SPAR WEB AND REAR SPAR BULKHEAD FITTINGS)	Me	
39	T00MWQD0	ACTV	53-826-00-01-INSP(JIC) (AREAS ABOVE WING CENTER SECTION)	Me	
40	T00MWQFT	ACTV	53-836-00-01-INSP(JIC) (AREAS ABOVE MAIN LANDING GEAR WHEEL WELL)	Me	
41	T00MG1KB	ACTV	56-001-00-01-OP(JIC) (No.2 OPENING WINDOW HANDLE)		
42	T00HCHNS	ACTV	57-802-00-01-INSP(JIC) (R WING LE TO FRONT SPAR - INBOARD)	Me	
43	T00HCHKY	ACTV	57-812-00-01-INSP(JIC) (R WING LE TO FRONT SPAR - OUTBOARD)	Me	

USE THE REGION BELOW FOR HARDCOPY CERTIFICATION (NOT e-SIGN)

44	T00NX8EV	ACTV	80-302-00-01-INSP(JIC) (DETAILED INSPECTION - STARTER MAGNETIC CHIP DETECTOR ENG 1)		
45	T00NX8EX	ACTV	80-302-00-02-INSP(JIC) (DETAILED INSPECTION - STARTER MAGNETIC CHIP DETECTOR ENG 2)		
46	T00HWDJ5	ACTV	B767-061-INSP(JIC) (CHECK ATTACHMENT FROM THE P40 APU)	Ne	
47	T00N6TU6	ACTV	B767-070-INSP(JIC) (COAXIAL CABLE CHECK)	Ne	
48	T00N5AP4	ACTV	B767-081-BOEING-OP(JIC) (OPERATIONAL TEST ENHANCED GROUND PROXIMITY WARNING)	Ne	
49	T00MFDCN	ACTV	B767-138-INSP(JIC) (AILERON CONTROL QUADRANT INSPECTION)	Ne INSP	
50	T00HWBV0	ACTV	B767-147-ENG1-FC(JIC) (WIRE AND CONNECTOR REPLACEMENT)	Ne	
51	T00HWBUY	ACTV	B767-147-ENG1-INSP(JIC) (IWIRE AND CONNECTOR REPLACEMENT)	Ne INSP	
52	T00HWBUZ	ACTV	B767-147-ENG1-REINS(JIC) (WIRE AND CONNECTOR REPLACEMENT)	Ne	
53	T00HWBU1	ACTV	B767-147-ENG1-REM(JIC) (WIRE AND CONNECTOR REPLACEMENT)	Ne	
54	T00HWBV1	ACTV	B767-147-ENG1-RPCL(JIC) (WIRE AND CONNECTOR REPLACEMENT)	Ne	
55	T00M19NQ	ACTV	B767-147-ENG2-FC(JIC) (WIRE AND CONNECTOR REPLACEMENT)	Ne	

USE THE REGION BELOW FOR HARDCOPY CERTIFICATION (NOT e-SIGN)

56	T00M19NG	ACTV	B767-147-ENG2-INSP(JIC) (WIRE AND CONNECTOR REPLACEMENT)	Ne	INSP
57	T00M19NH	ACTV	B767-147-ENG2-REINS(JIC) (WIRE AND CONNECTOR REPLACEMENT)	Ne	
58	T00M19NP	ACTV	B767-147-ENG2-REM(JIC) (WIRE AND CONNECTOR REPLACEMENT)	Ne	
59	T00M19NR	ACTV	B767-147-ENG2-RPCL(JIC) (WIRE AND CONNECTOR REPLACEMENT)	Ne	
60	T00NL339	ACTV	IH-B767-21-B4308 (JIC) (PACK TEMPERATURE SENSOR CHECK)		INSP
61	T00HFRRU	ACTV	IH-B767-56-A5007-LH(JIC) (NO. 2 WINDOW SEAL - REMOVAL/INSTALLATION)		INSP
62	T00HFRRT	ACTV	IH-B767-56-A5007-RH(JIC) (NO. 2 WINDOW SEAL - REMOVAL/INSTALLATION)		INSP
63	T00MFDWP	ACTV	L-28-B767-236-ENG1-INSP(JIC) (RST - REPLACE STRUT COUPLING O-RINGS)		
64	T00MFDPU	ACTV	L-28-B767-236-ENG2-INSP(JIC) (RST - REPLACE STRUT COUPLING O-RINGS)		
65	T00NV87W	ACTV	21-005-00-03-SVC(JIC) (CABIN ZONE TEMPERATURE SENSOR FILTER)		
66	T00NV8P5	ACTV	21-027-00-01-OP(JIC) (E/E COOLING LOW FLOW MONITOR SYSTEM)		
67	T00NV8NW	ACTV	22-003-00-01-OP(JIC) (A/P DISC ANNUNCIATOR INDICATOR)		

USE THE REGION BELOW FOR HARDCOPY CERTIFICATION (NOT e-SIGN)

68	T00NV8PG	ACTV	23-003-00-01-OP(JIC) (VOICE RECORDER - SELF TEST)		
69	T00N8W67	ACTV	24-002-00-01-FC(JIC) (ENGINE 1 IDG QAD COUPLING)		
70	T00NV8PL	ACTV	24-013-00-01-OP(JIC) (HYDRAULIC MOTOR GENERATOR (HMG))		
71	T00NV88S	ACTV	24-017-00-01-REPL(JIC) (ENGINE 1 IDG SCAVENGE FILTER ELEMENT)		
72	T00NV8HK	ACTV	24-017-00-02-REPL(JIC) (ENGINE 2 IDG SCAVENGE FILTER ELEMENT)		
73	T00NV8AQ	ACTV	24-017-01-01-REPL(JIC) (ENGINE 1 IDG OIL CHANGE)		
74	T00NV8JK	ACTV	24-017-01-02-REPL(JIC) (ENGINE 2 IDG OIL CHANGE)		
75	T00NV8Q2	ACTV	26-021-03-01-OP(JIC) (WHEEL WELL FIRE DETECTION SYSTEM)		
76	T00NV8Q5	ACTV	27-033-00-01-OP(JIC) (Flap/Slat Electronics Unit (FSEU))		
77	T00M0JUP	ACTV	27-084-01-02-LUB(JIC) (RIGHT INBOARD AILERON HINGES AND POWER CONTROL ACTUATORS.)		
78	T00NV84Y	ACTV	29-004-00-02-INSP(JIC) (SYS R HYD EDP / ACMP CASE DRAIN FILTER)		
79	T00NV84W	ACTV	29-005-00-01-INSP(JIC) (SYS C HYDRAULIC ADP OIL LEVEL)		

USE THE REGION BELOW FOR HARDCOPY CERTIFICATION (NOT e-SIGN)

80	T00NUNRT	ACTV	32-005-00-02-LUB(JIC) (RIGHT MAIN GEAR DOOR COMPONENTS LUBRICATION)		
81	T00NW4EJ	ACTV	32-007-00-01-LUB(JIC) (LEFT MAIN GEAR COMPONENTS LUBRICATION)		
82	T00NW4CW	ACTV	32-007-00-02-LUB(JIC) (RIGHT MAIN GEAR COMPONENTS LUBRICATION)		
83	T00NUNT5	ACTV	32-009-00-02-LUB(JIC) (RIGHT MAIN GEAR SIDE BRACE LOCK ACTUATOR AND DRAG BRACE LOCK ACTUATOR LUBRICATION)		
84	T00NW4K0	ACTV	32-018-00-01-LUB(JIC) (NOSE GEAR EXTENSION AND RETRACTION AND DOOR COMPONENTS LUBRICATION)	INSP	
85	T00MDJST	ACTV	32-021-00-01-OP(JIC)-LAN (Main/Nose Gear Alt Extend System)	INSP	
86	T00N2WWE	ACTV	32-021-00-02-OP(JIC) (MAIN/NOSE GEAR ALT EXTENDED SYSTEM)		
87	T00NV85H	ACTV	32-028-00-01-SVC(JIC) (PARKING BRAKE ACCUMULATOR)		
88	T00NV862	ACTV	32-402-00-01-INSP(JIC) (NOSE LANDING GEAR ASSEMBLY)		
89	T00NV86V	ACTV	32-406-00-01-INSP(JIC) (NOSE LANDING GEAR DOOR ASSEMBLY)		
90	T00NV87M	ACTV	32-412-00-01-INSP(JIC) (LEFT MAIN LANDING GEAR ASSEMBLY)		
91	T00NV85S	ACTV	32-412-00-02-INSP(JIC) (RIGHT MAIN LANDING GEAR ASSEMBLY)		

USE THE REGION BELOW FOR HARDCOPY CERTIFICATION (NOT e-SIGN)

92	T00NV89A	ACTV	32-418-00-01-INSP(JIC) (LEFT MAIN LANDING GEAR BODY DOOR)		
93	T00NV85Y	ACTV	32-418-00-02-INSP(JIC) (RIGHT MAIN LANDING GEAR BODY DOOR)		
94	T00NV8Q9	ACTV	33-007-00-01-OP(JIC) (EMERGENCY LIGHTS)		
95	T00NV8Q7	ACTV	33-008-00-01-OP(JIC) (CREW WARNING CARGO LIGHTS)		
96	T00MDJSR	ACTV	34-013-00-01-OP(JIC) (AIR DATA COMPUTER)		
97	T00NV7YA	ACTV	35-002-00-01-VC(JIC) (CREW OXYGEN PRESS TRANSDUCER/INDCATR)		
98	T00NKG59	ACTV	35-013-00-01-OP(JIC) (CREW OXYGEN MASK/REGULATOR)		
99	T00NKG2X	ACTV	35-016-00-01-INSP(JIC) (CREW/SUPERNUMERARY OXYGEN MASKS)		
100	T00NV7YY	ACTV	38-001-01-01-SVC(JIC) (POTABLE WATER SYSTEM)		
101	T00NV80D	ACTV	49-014-00-01-INSP(JIC) (APU GEARBOX MAGNETIC CHIP DETECTOR)		
102	T00NV80V	ACTV	49-022-00-01-INSP(JIC) (OIL PRESS FILTER DIFF PRESS INDICATOR)		
103	T00NV81K	ACTV	49-032-00-01-INSP(JIC) (APU LP FUEL FILTER DIFF PRESS IND)		

USE THE REGION BELOW FOR HARDCOPY CERTIFICATION (NOT e-SIGN)

104	T00NV821	ACTV	49-049-00-01-OP(JIC) (APU CONTROL UNIT)		
105	T00NV827	ACTV	49-060-01-01-REPL(JIC) (APU SURGE VALVE FILTER ELEMENT)		
106	T00NV82E	ACTV	49-062-01-01-INSP(JIC) (APU STARTER MOTOR BRUSH WEAR)		
107	T00NV83N	ACTV	52-038-01-01-INSP(JIC) (BULK CARGO DOOR BALANCE MECHANISM)		
108	T00NV840	ACTV	52-400-00-01-INSP(JIC) (BULK CARGO COMPARTMENT DOOR STOPS)		
109	T00NV84Q	ACTV	52-408-00-01-INSP(JIC) (CARGO DOOR STOPS)		
110	T00NV89R	ACTV	52-426-00-01-INSP(JIC) (CREW ENTRY DOORS)		
111	T00NV864	ACTV	53-406-00-01-INSP(JIC) (DOOR STOPS, SILLS, AND FRAMES)		
112	T00NV8AL	ACTV	53-428-00-01-INSP(JIC) (NOSE LANDING GEAR WHEEL WELL)		
113	T00NV86C	ACTV	53-518-00-01-INSP(JIC) (MAIN LANDING GEAR WHEEL WELL STRUCTURE)		
114	T00NV8AU	ACTV	53-518-00-02-INSP(JIC) (MAIN LANDING GEAR WHEEL WELL STRUCTURE)		
115	T00NV86R	ACTV	53-648-00-01-INSP(JIC) (BODY EXTERNAL SKIN)		

USE THE REGION BELOW FOR HARDCOPY CERTIFICATION (NOT e-SIGN)

116	T00NV8B5	ACTV	54-406-00-01-INSP(JIC) (NACELLE STRUT NO. 1)		
117	T00NV874	ACTV	54-406-00-02-INSP(JIC) (NACELLE STRUT NO. 2)		
118	T00NV8BE	ACTV	57-474-00-01-INSP(JIC) (LEFT WING FIXED LEADING EDGE STRUCTURE)		
119	T00NV87S	ACTV	57-474-00-02-INSP(JIC) (RIGHT WING FIXED LEADING EDGE STRUCTURE)		
120	T00NV8C4	ACTV	57-482-00-01-INSP(JIC) (LEFT SLAT / NACELLE SEAL KRUEGER FLAP)		
121	T00NV881	ACTV	57-482-00-02-INSP(JIC) (RIGHT SLAT / NACELLE SEAL KRUEGER FLAP)		
122	T00NV8CT	ACTV	57-504-00-01-INSP(JIC) (LEFT WING INSPAR LOWER SURFACE, EXTERIOR)	INSP	
123	T00NV88U	ACTV	57-504-00-02-INSP(JIC) (RIGHT WING INSPAR LOWER SURFACE, EXTERIOR)	INSP	
124	T00NV8CJ	ACTV	57-568-00-01-INSP(JIC) (LEFT WING TRAILING EDGE)		
125	T00NV88Q	ACTV	57-568-00-02-INSP(JIC) (RIGHT WING TRAILING EDGE)		
126	T00NV8CV	ACTV	57-586-00-01-INSP(JIC) (LEFT WING INBOARD TRAILING EDGE FLAP)		
127	T00NV894	ACTV	57-586-00-02-INSP(JIC) (RIGHT WING INBOARD TRAILING EDGE FLAPS)		

USE THE REGION BELOW FOR HARDCOPY CERTIFICATION (NOT e-SIGN)

128	T00NV8CQ	ACTV	57-590-00-01-INSP(JIC) (LEFT INBOARD AILERON)		
129	T00NV897	ACTV	57-590-00-02-INSP(JIC) (RIGHT INBOARD AILERON)		
130	T00NV8D7	ACTV	57-604-00-01-INSP(JIC) (LEFT WING OUTBOARD TRAILING EDGE FLAP)		
131	T00NV89E	ACTV	57-604-00-02-INSP(JIC) (RIGHT WING OUTBOARD TRAILING EDGE FLAP)		
132	T00NV8D9	ACTV	57-610-00-01-INSP(JIC) (LEFT OUTBOARD AILERON)		
133	T00NV89K	ACTV	57-610-00-02-INSP(JIC) (RIGHT OUTBOARD AILERON)		
134	T00NV8B1	ACTV	71-818-00-01-INSP(JIC) (ENGINE 1)		
135	T00NV8JV	ACTV	71-818-00-02-INSP(JIC) (ENGINE 2)		
136	T00NV8B7	ACTV	71-822-00-01-INSP(JIC) (NOSE COWL - ENGINE 1)		
137	T00NV8JY	ACTV	71-822-00-02-INSP(JIC) (NOSE COWL - ENGINE 2)		
138	T00NV8BU	ACTV	72-302-00-01-INSP(JIC) (LP COMPRESSOR ROTOR BLADES - ENG 1)		
139	T00NV8K4	ACTV	72-302-00-02-INSP(JIC) (LP COMPRESSOR ROTOR BLADES - ENG 2)		

USE THE REGION BELOW FOR HARDCOPY CERTIFICATION (NOT e-SIGN)

140	T00NV8CM	ACTV	72-305-00-01-INSP(JIC) (MAGNETIC CHIP DETECTOR - ENG 1)		
141	T00NV8LK	ACTV	72-305-00-02-INSP(JIC) (MAGNETIC CHIP DETECTOR - ENG 2)		
142	T00NV8QD	ACTV	74-999-14-01-ENG1-FC(JIC) (REPLACE IGNITER PLUG ENG. 1)	INSP	
143	T00NV8QV	ACTV	74-999-14-01-ENG2-FC(JIC) (REPLACE IGNITER PLUG ENG. 2)	INSP	
144	T00NV8QJ	ACTV	77-305-00-01-OP(JIC) (PIMU FAULT MESSAGES)		
145	T00NKFVU	ACTV	78-321-00-01-LUB(JIC) (T/R BALLSCREW ACTUATOR NUTS - L)		
146	T00NKG8A	ACTV	78-321-00-02-LUB(JIC) (T/R BALLSCREW ACTUATOR NUTS - R)		
147	T00NV8RL	ACTV	AASR-B767-A(JIC-L7) (AGING AIRPLANE SAFETY RULE - REPAIRS AND ALTERATIONS CONTROL LIST)	INSP	
148	T00NKFGE	ACTV	B767-005-INSP(JIC) (DETAILED INSPECTION - INSPECT PLACKARD/MARKING/STENCILS/DECALS FOR CONDITION AND PRESENCE)		
149	T00N8WAF	ACTV	B767-073-INSP(JIC) (MOISTURE PURGE OF THE DPV PRESSURE SWITCH)		
150	T00NV8E2	ACTV	B767-075-ENG1-CLN(JIC) (CLEAN THE ENGINE FIRE DETECTOR CONNECTORS/TERMINAL LUGS)		
151	T00NV8MX	ACTV	B767-075-ENG2-CLN(JIC) (CLEAN THE ENGINE FIRE DETECTOR CONNECTORS/TERMINAL LUGS)		

USE THE REGION BELOW FOR HARDCOPY CERTIFICATION (NOT e-SIGN)

152	T00NV8AV	ACTV	B767-108-INSP(JIC) (STRUT AFT FAIRINGS FASTENERS INSPECTION)	INSP	
153	T00NV8AN	ACTV	B767-203-INSP(JIC) (LANDING GEAR SHOCK STRUT SCRAPER)		
154	T00NV8AX	ACTV	B767-204-INSP(JIC) (LANDING GEAR SHOCK STRUT SCRAPER)		
155	T00NV8AZ	ACTV	B767-205-INSP(JIC) (LANDING GEAR SHOCK STRUT SCRAPER)		
156	T00NV878	ACTV	BE0026784-BCF-INSP(JIC) (AFT CARGO COMPARTMENT INSPECTION)	Ne	
157	T00MU2E4	ACTV	BE0103911-FREIGHTER-INSP(JIC) (BASIC FLIGHT KIT CHECK)	Ne INSP	
158	T00NV8K6	ACTV	BE0170004-CLN(JIC) (COCKPIT - ELECTRONIC EQUIPMENT CLEANING)		
159	T00N8W0X	ACTV	BE0300560-1-SVC(JIC) (ENGINE PNEUMATIC SYSTEM FILTER INSPECTION 1)		
160	T00NKFJU	ACTV	BE0300565-INSP(JIC) (CLEAN - APU ECU INSPECTION AND CLEAN - PRE APU ECU RELOCATION)	Ne	
161	T00NKG4H	ACTV	IH-B767-38-B7542(JIC) (DET - TOILET FLUSH TIMER SWITCH)		
162	T00NV8EU	ACTV	IH-B767-78-A5933 PART 2 LH ENG (JIC) (INSPECTION AND LUBRICATION OF T/R ROTARY FLEXIBLE DRIVE SHAFTS (INSPECTION))		
163	T00NV8N3	ACTV	IH-B767-78-A5933 PART 2 RH ENG (JIC) (INSPECTION AND LUBRICATION OF T/R ROTARY FLEXIBLE DRIVE SHAFTS (INSPECTION))		

USE THE REGION BELOW FOR HARDCOPY CERTIFICATION (NOT e-SIGN)

164	T00N8W78	ACTV	MD-B767-73-A3111-EN1(JIC) (CIT (T25) SENSOR CONNECTOR CLEANING)	INSP	
165	T00N9Z8B	ACTV	MP-B767-11-171-INSP(JIC) (INSPECT PLACARD/MARKING/STENCILS/DECALS FOR CONDITION AND PRESENCE)		
166	T00NKG7G	ACTV	MP-B767-24-203-FC(JIC) (FNC - MAIN & APU BATTERY CHARGER AND MONITORING CAPABILITY)		
167	T00MP3LP	ACTV	MP-B767-25-133-INSP(JIC) (MEDICAL KIT AND SURVIVAL KIT INSPECTION)		
168	T00NKFH0	ACTV	MP-B767-32-109-INSP(JIC) (INSP - SAFETY PIN AND PIN FLAGS INSPECTION)	INSP	
169	T00NV80B	ACTV	MP-B767-38-005(JIC) (TOILETS TREATMENT DESINFECTION)		
170	T00NV81G	ACTV	MP-B767-56-034-LH-INSP(JIC) (LH No.2 WINDOW SEAL - INSPECTION)		
171	T00NV81E	ACTV	MP-B767-56-034-RH-INSP(JIC) (RH No.2 WINDOW SEAL - INSPECTION)		
172	T00NJ6AE	ACTV	27-010-00-02-OP(JIC) (Rudder Power Control Actuator)		
173	T00NJ5VP	ACTV	27-018-00-01-OP(JIC) (Elevator Power Control Actuator)		
174	T00NKK1T	ACTV	32-089-00-01-LUB(JIC) (LEFT MAIN GEAR BRAKE COMPONENTS LUBRICATION)		
175	T00NKJJ8	ACTV	32-089-00-02-LUB(JIC) (RIGHT MAIN GEAR BRAKE COMPONENTS LUBRICATION)		

USE THE REGION BELOW FOR HARDCOPY CERTIFICATION (NOT e-SIGN)

176	T00NJ62G	ACTV	77-304-00-01-OP(JIC) (STANDBY ENGINE INDICATOR)		
177	T00NX8ET	ACTV	80-301-00-01-SVC(JIC) (ENGINE 1 STARTER OIL CHANGE)		
178	T00NX8EP	ACTV	80-301-00-02-SVC(JIC) (ENGINE 2 STARTER OIL CHANGE)		
179	T00MNMRX	ACTV	54-598-22-01-INSP(JIC) (INTERNAL - LEFT NACELLE STRUT / WING LOWER SURFACE)	INSP	
180	T00MNMMS	ACTV	57-795-01-01-INSP(JIC) (INTERNAL - DRY BAY - INBOARD LEFT WING)	INSP	
181	T00MNMT8	ACTV	57-796-42-01-INSP(JIC) (EXTERNAL - LEFT WING INSPAR LOWER SURFAC)	INSP	
182	T00MNMTH	ACTV	57-796-60-01-INSP(JIC) (EXTERNAL - LEFT OUTBOARD WING LOWER SURFACE TYPICAL STRINGER)	INSP	
183	T00MMRP1	ACTV	57-797-17-01-INSP(JIC) (INTERNAL - WING LOWER SURFACE BUTTOCK LINE 62 TO FAIRING EDGE - LH)		
184	T00MNMS5	ACTV	54-598-22-02-INSP(JIC) (INTERNAL - RIGHT NACELLE STRUT / WING LOWER SURFACE)	INSP	
185	T00MNMSQ	ACTV	57-795-01-02-INSP(JIC) (INTERNAL - DRY BAY - INBOARD RIGHT WING)	INSP	
186	T00MNMT6	ACTV	57-796-42-02-INSP(JIC) (EXTERNAL - RIGHT WING INSPAR LOWER SURFAC)	INSP	
187	T00MNNU8	ACTV	57-796-60-02-INSP(JIC) (EXTERNAL - RIGHT OUTBOARD WING LOWER SURFACE TYPICAL STRINGER)	INSP	

USE THE REGION BELOW FOR HARDCOPY CERTIFICATION (NOT e-SIGN)

188	T00MMRP3	ACTV	57-797-17-02-INSP(JIC) (INTERNAL - WING LOWER SURFACE BUTTOCK LINE 62 TO FAIRING EDGE - RH)		
189	T00L1QZG	ACTV	20-005-00-01-INSP(JIC) (CONTROL CABLES - EXPOSED)		
190	T00L1SU5	ACTV	20-005-00-02-INSP(JIC) (CONTROL CABLES - EXPOSED)		
191	T00L1QZ4	ACTV	20-005-00-03-INSP(JIC) (CONTROL CABLES - EXPOSED)		
192	T00L1QZB	ACTV	20-005-00-04-INSP(JIC) (CONTROL CABLES - EXPOSED)		
193	T00L27AL	ACTV	20-005-00-05-INSP(JIC) (CONTROL CABLES - EXPOSED)		
194	T00L1TWX	ACTV	20-005-00-06-INSP(JIC) (CONTROL CABLES - EXPOSED)		
195	T00L1QZK	ACTV	20-005-00-07-INSP(JIC) (CONTROL CABLES - EXPOSED)		
196	T00L27B2	ACTV	20-005-00-08-INSP(JIC) (CONTROL CABLES - EXPOSED)		
197	T00MG1QG	ACTV	21-002-00-04-CLN(JIC) (RETURN AIR GRILLES)		
198	T00MG1QH	ACTV	21-002-00-04-REINS(JIC) (RETURN AIR GRILLES)		
199	T00MG1QJ	ACTV	21-002-00-04-REM(JIC) (RETURN AIR GRILLES)		

USE THE REGION BELOW FOR HARDCOPY CERTIFICATION (NOT e-SIGN)

200	T00L27CF	ACTV	21-007-00-01-INSP(JIC) (CABIN PRESSURE OUTFLOW VALVE)		
201	T00L27CM	ACTV	21-008-00-01-CLN(JIC) (CABIN PRESSURE OUTFLOW VALVE)		
202	T00L0VZS	ACTV	21-009-00-01-OP(JIC) (CABIN PRESSURE OUTFLOW VALVE)		
203	T00L1QRL	ACTV	21-015-00-01-OP-LH(JIC) (PACK TEMPERATURE CONTROLLERS)		
204	T00L1QRM	ACTV	21-015-00-01-OP-RH(JIC) (PACK TEMPERATURE CONTROLLERS)		
205	T00L118Z	ACTV	21-016-00-01-OP(JIC) (STANDBY PACK TEMPERATURE CONTROLLER)		
206	T00MG1FA	ACTV	21-026-01-01-OP(JIC) (E/E COOLING SYSTEM EQUIP COOL TEST)		
207	T00L2Y8Q	ACTV	21-029-00-01-CLN(JIC) (FWD E / E COOLING AIR CLEANER)		
208	T00MG1JW	ACTV	21-031-01-07-FC(JIC) (E/E COOLING SYSTEM DIFF PRESS SWITCH)		
209	T00L29JC	ACTV	21-038-01-01-CLN(JIC) (E/E COOLING OVERHEAT SWITCH)		
210	T00MG1J3	ACTV	21-051-00-01-OP(JIC) (MAIN DECK AIR DISTRIBUTION SHUTOFF)		
211	T00L2Y87	ACTV	21-058-01-01-CLN(JIC) (E/E COOLING LOW FLOW DETECTORS)		

USE THE REGION BELOW FOR HARDCOPY CERTIFICATION (NOT e-SIGN)

212	T00L1QPE	ACTV	24-004-00-01-OP(JIC) ("FNC - BUS POWER CONTROL UNIT (BPCU))		
213	T00L1QQC	ACTV	24-009-00-01-OP(JIC) (OPERATIONAL CHECK - DC TIE CONTROL UNIT & DC TIE RELAY)		
214	T00L1QPX	ACTV	24-010-01-01-FC(JIC) (STANBY POWER SYSTEM)		
215	T00L1QSQ	ACTV	24-014-01-01-OP(JIC) (INSTRUMENT BUS VOLTAGE SENSING UNIT)		
216	T00L11AC	ACTV	24-015-02-01-OP(JIC) (OPERATIONAL CHECK - AUTOLAND DC TIE)		
217	T00L3MNU	ACTV	24-020-02-01-SVC(JIC) (RESTORE - ENGINE 1 IDG HEAT EXCHANGER AIR SHUT-OFF VALVE FILTER (CF6-80C ENGINES))		
218	T00L35B0	ACTV	24-020-02-02-SVC(JIC) (RESTORE - ENGINE 2 IDG HEAT EXCHANGER AIR SHUT-OFF VALVE FILTER (CF6-80C ENGINES))		
219	T00L27DR	ACTV	24-041-01-01-INSP(JIC) (GENERAL VISUAL INSPECTION - EXTERNAL POWER RECEPTACLE PINS)		
220	T00L1QNH	ACTV	25-001-00-01-OP(JIC) (OPERATIONAL - CREW SEAT ADJUSTMENT / LOCK MECHANISM)		
221	T00L3DWZ	ACTV	25-002-00-01-OP(JIC) (OPERATIONAL - CREW SEAT HARNESS / INERTIA REEL)		
222	T00L1HGC	ACTV	25-007-00-01-LUB(JIC) (ROLLOUT STOP SHAFT/CAM FOLLOWER/PAWL)		
223	T00MFDHK	ACTV	25-018-00-01-GRP01-INSP(JIC) (CHECK/INSP - DETACHABLE EMERGENCY EQUIPMENT)		

USE THE REGION BELOW FOR HARDCOPY CERTIFICATION (NOT e-SIGN)

224	T00L2470	ACTV	25-038-01-01-CLN(JIC) (GALLEY OVEN)		
225	T00MG1FX	ACTV	25-044-00-01-OP(JIC) (SUPERNUMERARY SEATS RESTRAINT)		
226	T00L1GRD	ACTV	26-006-00-01-OP(JIC) (ENG FIRE EXT BOTTLE PRESSURE SWITCH)		
227	T00L1PW1	ACTV	26-009-00-01-OP(JIC) (OPERATIONAL CHECK - APU FIRE EXT BOTTLE PRESSURE SWITCH)	INSP	
228	T00L2677	ACTV	26-014-00-01-INSP(JIC) (LAV WASTE COMPT FIRE EXTINGUISHERS)		
229	T00L11BD	ACTV	26-018-00-01-OP(JIC) (OPERATIONAL - LAVATORY SMOKE DETECTORS)		
230	T00L1PYX	ACTV	26-020-01-01-OP(JIC) (FIRE DETECTION SYSTEM FAIL LIGHT)		
231	T00L1GUS	ACTV	27-015-00-02-OP(JIC) (RUDDER RATIO CHANGER BYPASS VALVE)		
232	T00L1Z6F	ACTV	27-022-00-01-OP(JIC) (OPERATIONAL - STALL WARNING SYSTEM)		
233	T00L1WLW	ACTV	27-026-00-01-OP(JIC) (STAB TRIM CUTOUPPEDESTAL)		
234	T00L1PNP	ACTV	27-028-00-01-INSP(JIC) (GVI - STAB TRIM ACTUATOR ATTACHMENT GIMBAL)		
235	T00L0VZD	ACTV	27-036-00-01-OP(JIC) (ALT TE FLAP POWER DRIVE SYSTEM)		

USE THE REGION BELOW FOR HARDCOPY CERTIFICATION (NOT e-SIGN)

236	T00L1H31	ACTV	27-037-00-02-OP(JIC) (OPERATIONAL - TE FLAP FAILURE PROTECTION SYSTEM)		
237	T00L2KT2	ACTV	27-038-00-01-LUB(JIC) (LEFT TE FLAP COMPONENTS)		
238	T00L2JEE	ACTV	27-038-00-02-LUB(JIC) (RIGHT TE FLAP COMPONENTS)		
239	T00L1QE8	ACTV	27-043-00-01-OP(JIC) (OPERATIONAL - LE SLAT FAILURE PROTECTION SYSTEM)		
240	T00L1H2R	ACTV	27-045-00-01-OP(JIC) (AUTO SPEEDBRAKE)		
241	T00L0VZL	ACTV	27-047-00-01-OP(JIC) (LE SLAT ALTERNATE DRIVE SYSTEM)		
242	T00L3K1P	ACTV	27-048-01-01-LUB(JIC) (LEFT LE SLAT DRIVE SHAFT COUPLINGS)		
243	T00L3K1C	ACTV	27-048-01-02-LUB(JIC) (RIGHT LE SLAT DRIVE SHAFT COUPLINGS)		
244	T00L1GUK	ACTV	27-052-00-01-OP(JIC) (ALTERNATE HORIZ STAB TRIM SYSTEM)		
245	T00L2JBX	ACTV	27-053-01-01-SVC(JIC) (SERVICE - STABILIZER TRIM BALL-SCREW ACTUATOR)		
246	T00L247Q	ACTV	27-054-01-01-OP(JIC) (TE FLAP / LE SLAT SHUTOFF VALVE MODULE)		
247	T00L1QR2	ACTV	27-064-00-02-OP(JIC) (OPERATIONAL - TE FLAP LOAD RELIEF ACTUATOR/RELAY)		

USE THE REGION BELOW FOR HARDCOPY CERTIFICATION (NOT e-SIGN)

248	T00L2JTN	ACTV	27-068-01-01-LUB(JIC) (L OUTBD LE SLAT TRK HOUSING/DRAIN TUBE)		
249	T00L2LQC	ACTV	27-068-01-02-LUB(JIC) (R OUTBD LE SLAT TRK HOUSING/DRAIN TUBE)		
250	T00L2KSZ	ACTV	27-082-01-01-LUB(JIC) (OUTBOARD AILERON HINGES - LEFT)		
251	T00L2JE5	ACTV	27-082-01-02-LUB(JIC) (OUTBOARD AILERON HINGES - RIGHT)		
252	T00L29FN	ACTV	27-086-01-01-LUB(JIC) (LH LCCA TORQUE TUBE ASSEMBLY)		
253	T00L1Q24	ACTV	28-009-01-01-OP(JIC) (FUEL CROSSFEED VALVE)		
254	T00L1Q26	ACTV	28-010-00-01-OP(JIC) (CENTER AUX TANK FUEL SCAVENGE SYSTEM)		
255	T00L267J	ACTV	28-040-00-01-OP-LH(JIC) (OPERATIONAL - ENGINE FUEL SUCTION FEED SYSTEM)	INSP	
256	T00L267H	ACTV	28-040-00-01-OP-RH(JIC) (OPERATIONAL - ENGINE FUEL SUCTION FEED SYSTEM)	INSP	
257	T00L29V9	ACTV	29-011-00-01-INSP(JIC) (SYS L HYD RETURN FILTER MODULE)		
258	T00L1QR0	ACTV	29-013-00-01-OP(JIC) (ISOLATED ACMP SUPPLY SHUTOFF VALVE)		
259	T00L340Q	ACTV	29-014-00-01-LUB(JIC) (LUB - RAT DEPLOYMENT SYSTEM)		

USE THE REGION BELOW FOR HARDCOPY CERTIFICATION (NOT e-SIGN)

260	T00L1QP7	ACTV	29-019-01-01-OP(JIC) (HYDRAULIC RESERVOIR QUANTITY - L, R, C.)		
261	T00L1MT1	ACTV	29-021-00-01-OP(JIC) (POWER TRANSFER UNITPTU)		
262	T00E53WZ	ACTV	30-002-00-01-FC(JIC) (LEFT WING TAI PRESSURE SWITCH)		
263	T00E53WV	ACTV	30-002-00-02-FC(JIC) (RIGHT WING TAI PRESSURE SWITCH)		
264	T00L1QDK	ACTV	31-004-00-01-OP(JIC) (WARNING ELECTRONICS UNIT CARD MODULE)		
265	T00HBEWB	ACTV	31-008-01-01-OP(JIC) (OPERATIONAL - RIGHT EICAS COMPUTER (CMR))		
266	T00L1QDW	ACTV	31-009-00-01-OP(JIC) (TAKE-OFF WARNING SYSTEM)		
267	T00L1WW1	ACTV	32-025-00-02-OP(JIC) (OPC-ALT BRAKE SYSTEM/SELECTOR VALVE)		
268	T00L1QCC	ACTV	32-040-01-02-OP(JIC) (AUTOMATIC GEAR RETRACTION BRAKE)		
269	T00L1GW6	ACTV	32-042-00-01-OP(JIC) (TAIL SKID WARNING PSEU BITE TEST)		
270	T00L3KK4	ACTV	32-048-01-01-INSP(JIC) (LEFT MAIN GEAR SHOCK STRUT)		
271	T00L3KK5	ACTV	32-048-01-01-SVC(JIC) (LEFT MAIN GEAR SHOCK STRUT)		

USE THE REGION BELOW FOR HARDCOPY CERTIFICATION (NOT e-SIGN)

272	T00L3415	ACTV	32-048-01-02-INSP(JIC) (RIGHT MAIN GEAR SHOCK STRUT)		
273	T00L3416	ACTV	32-048-01-02-SVC(JIC) (RIGHT MAIN GEAR SHOCK STRUT)		
274	T00L31BQ	ACTV	32-048-02-01-INSP(JIC) (NOSE GEAR SHOCK STRUT)		
275	T00L31BR	ACTV	32-048-02-01-SVC(JIC) (NOSE GEAR SHOCK STRUT)		
276	T00L29SN	ACTV	32-802-00-01-INSP(JIC) (GVI EXT - NOSE LANDING GEAR (NLG) FORWARD DOORS)	Me	
277	T00L1Z7B	ACTV	32-802-00-02-INSP(JIC) (GVI EXT - NOSE LANDING GEAR (NLG) AFT DOORS)	Me	
278	T00L1YR4	ACTV	32-802-00-03-LH-INSP(JIC) (GVI - LEFT MAIN LANDING GEAR (MLG) BODY DOOR)	Me	
279	T00L1QE3	ACTV	32-802-00-03-RH-INSP(JIC) (GVI - RIGHT MAIN LANDING GEAR (MLG) BODY DOOR)	Me	
280	T00L1YS4	ACTV	32-802-00-04-LH-INSP(JIC) (GVI -LEFT MAIN LANDING GEAR (MLG) DRAG BRACE DOOR)	Me	
281	T00L1QE1	ACTV	32-802-00-04-RH-INSP(JIC) (GVI - RIGHT MAIN LANDING GEAR (MLG) DRAG BRACE DOOR)	Me	
282	T00L1YRB	ACTV	32-802-00-05-LH-INSP(JIC) (GVI - LEFT MAIN LANDING GEAR (MLG) OLEO DOOR)	Me	
283	T00L1QDZ	ACTV	32-802-00-05-RH-INSP(JIC) (GVI - RIGHT MAIN LANDING GEAR (MLG) OLEO DOOR)	Me	

USE THE REGION BELOW FOR HARDCOPY CERTIFICATION (NOT e-SIGN)

284	T00L1Y0Q	ACTV	32-802-00-06-LH-INSP(JIC) (GVI - LEFT MAIN LANDING GEAR (MLG) TRUNNION DOOR)	Me	
285	T00L1QDG	ACTV	32-802-00-06-RH-INSP(JIC) (GVI - RIGHT MAIN LANDING GEAR (MLG) TRUNNION DOOR)	Me	
286	T00L11AX	ACTV	34-009-00-01-OP(JIC) (INSTRUMENT SOURCE SELECT SWITCHING)		
287	T00L1QCQ	ACTV	34-010-00-01-OP(JIC) (CENTER EFIS SYMBOL GENERATOR)		
288	T00L20LX	ACTV	34-015-00-01-INSP(JIC) (INTEGRATED STANDBY FLIGHT DISPLAY)		
289	T00L11AJ	ACTV	36-002-00-01-FC(JIC) (AIR SUPPLY DISTRIBUTION)		
290	T00L0VZ8	ACTV	36-003-00-01-OP(JIC) (CENTER ISOLATION VALVE)		
291	T00L1QCN	ACTV	36-008-00-01-OP(JIC) (OPERATIONAL CHECK - AIR SUPPLY BITE MODULE)		
292	T00L31BX	ACTV	36-011-02-05-SVC(JIC) ("DIS - ENGINE 1 HP CONTROLLER AIR FILTER (CF6-80C))		
293	T00L3NT3	ACTV	36-011-02-06-SVC(JIC) ("DIS - ENGINE 2 HP CONTROLLER AIR FILTER (CF6-80C))		
294	T00L2LW7	ACTV	36-012-01-03-SVC(JIC) ("DIS - ENGINE 1 PRSOV AIR FILTERS (CF6-80C))		
295	T00L3K4G	ACTV	36-012-01-04-SVC(JIC) ("DIS - ENGINE 2 PRSOV AIR FILTERS (CF6-80C))		

USE THE REGION BELOW FOR HARDCOPY CERTIFICATION (NOT e-SIGN)

296	T00L2YWX	ACTV	36-013-01-07-SVC(JIC) ("DIS - FAN AIR MODULATING VALVE AIR FILTER (CF6-80C))		
297	T00L359S	ACTV	36-013-01-08-SVC(JIC) ("DIS - FAN AIR MODULATING VALVE AIR FILTER (CF6-80C))		
298	T00L3294	ACTV	36-014-01-01-SVC(JIC) ("DIS - ENGINE 1 PRV CONTROLLER AIR FILTER (CF6-80C))		
299	T00L35CF	ACTV	36-014-01-02-SVC(JIC) ("DIS - ENGINE 2 PRV CONTROLLER AIR FILTER (CF6-80C))		
300	T00MG1KM	ACTV	38-006-00-01-OP(JIC) (OPERATIONAL CHECK - SERVICE PANEL WASTE DRAIN FTG SEAL)		
301	T00L27VV	ACTV	49-013-00-01-INSP(JIC) (APU DRAIN MAST)		
302	T00L1UQU	ACTV	51-001-00-01-INSP(JIC) (FUSELAGE DRAIN VALVES)		
303	T00L20H2	ACTV	52-007-00-01-LUB(JIC) (LUB - ENTRY/SERVICE COMPONENTS LUBRICATION)		
304	T00L1SUQ	ACTV	52-017-07-01-LUB(JIC) (BULK CARGO DOOR PRESS STOP PINS/PLATES LATCH ROLLERS AND LIFT ASSIST CABLE)		
305	T00L1PU6	ACTV	52-020-00-01-INSP(JIC) (VCK - MAIN EE AND FWD ACCESS DOOR SEALS)		
306	T00L1HHD	ACTV	52-030-01-01-LUB(JIC) (FWD/AFT LARGE LOWER CARGO DOOR COMPONENTS LUBRICATION)		
307	T00MG1L6	ACTV	52-048-00-01-FC(JIC) (MAIN DECK CARGO DOOR RATCHET BRAKE)		

USE THE REGION BELOW FOR HARDCOPY CERTIFICATION (NOT e-SIGN)

308	T00MG1R4	ACTV	52-057-00-01-OP(JIC) (MAIN DECK CARGO DOOR WARNING SYSTEM)		
309	T00L1UP8	ACTV	52-058-00-01-FC(JIC) (FUNCTIONAL - LARGE FWD CARGO DOOR WARNING SYSTEM)		
310	T00L1QXG	ACTV	52-066-00-01-OP(JIC) (LARGE FWD CARGO DOOR NO-BACK BRAKES)		
311	T00L1UP1	ACTV	52-072-00-01-OP(JIC) (FWD LG CARGO DOOR LATCH LOCK HANDLE)		
312	T00MG1LW	ACTV	52-082-01-01-LUB(JIC) (MAIN DECK CARGO DOOR)		
313	T00L242E	ACTV	52-802-00-01-INSP(JIC) (BULK CARGO COMPARTMENT DOOR)		
314	T00L2JAG	ACTV	52-804-00-01-INSP(JIC) (FORWARD CARGO COMPARTMENT DOOR)		
315	T00L242H	ACTV	52-810-00-01-INSP(JIC) (AFT CARGO COMPARTMENT DOOR)		
316	T00MG1PS	ACTV	52-818-00-01-INSP(JIC) (CREW ENTRY DOOR - FORWARD ENTRY)		
317	T00MG1HJ	ACTV	52-838-00-01-INSP(JIC) (MAIN DECK CARGO COMPARTMENT DOOR)		
318	T00L1QUM	ACTV	53-802-00-01-INSP(JIC) (RADOME)	Me	
319	T00L23U8	ACTV	53-804-00-01_INSP(JIC) (AREAS FORWARD OF NOSE LANDING GEAR WHEEL WELL)	Me	

USE THE REGION BELOW FOR HARDCOPY CERTIFICATION (NOT e-SIGN)

320	T00L23W5	ACTV	53-806-00-01_INSP(JIC) (NOSE LANDING GEAR WHEEL WELL)	Me	
321	T00L20L7	ACTV	53-808-00-01-INSP(JIC) (AREA OUTBOARD AND ABOVE NOSE LANDING GEAR WHEEL WELL)		
322	T00L1NQL	ACTV	53-810-00-01_INSP(JIC) (MAIN EQUIPMENT CENTER)	Me	
323	T00L1PPL	ACTV	53-812-00-01-INSP(JIC) (MAIN EQUIPMENT CENTER)		
324	T00L231N	ACTV	53-814-00-01-INSP(JIC) (FORWARD CARGO COMPARTMENT)		
325	T00L232G	ACTV	53-822-00-01-INSP(JIC) (AREAS AFT OF FORWARD CARGO COMPARTMENT)		
326	T00L1RQ0	ACTV	53-832-00-01-INSP(JIC) (ENVIRONMETAL CONTROL SYSTEM BAYS)		
327	T00L20V1	ACTV	53-838-00-01_INSP(JIC) (LEFT MAIN WHEEL WELL)	Me	
328	T00L20VR	ACTV	53-838-00-02_INSP(JIC) (RIGHT MAIN WHEEL WELL)	Me	
329	T00L1QZU	ACTV	53-840-00-01-INSP(JIC) (AREAS FORWARD OF AFT CARGO COMPARTMENT)		
330	T00L1QZD	ACTV	53-850-00-01-INSP(JIC) (AFT CARGO COMPARTMENT - LEFT)		
331	T00L1QZX	ACTV	53-850-00-02-INSP(JIC) (AFT CARGO COMPARTMENT - RIGHT)		

USE THE REGION BELOW FOR HARDCOPY CERTIFICATION (NOT e-SIGN)

332	T00L1R0L	ACTV	53-858-00-01-INSP(JIC) (BULK CARGO COMPARTMENT - LEFT)		
333	T00L1UNC	ACTV	53-858-00-02-INSP(JIC) (BULK CARGO COMPARTMENT - RIGHT)		
334	T00L1QZQ	ACTV	53-866-00-01-INSP(JIC) (AREAS AFT OF BULK CARGO COMPARTMENT)		
335	T00L20M2	ACTV	53-874-00-01-INSP(JIC) (CONTROL CABIN)		
336	T00MG1NY	ACTV	53-878-00-01-INSP(JIC) (MAIN DECK CARGO COMPARTMENT - SECTION 41)	Me	
337	T00MG1NP	ACTV	53-888-00-01-INSP(JIC) (MAIN DECK CARGO COMPARTMENT - SECTION 43)	Me	
338	T00MG1J6	ACTV	53-896-00-01-INSP(JIC) (MAIN DECK CARGO COMPARTMENT - SECTION 45)	Me	
339	T00MG1QL	ACTV	53-904-00-01-INSP(JIC) (MAIN DECK CARGO COMPARTMENT - SECTION 46)	Me	
340	T00L2XTQ	ACTV	54-001-01-01-LUB(JIC) (LEFT WING NACELLE ATTACH FITTING)		
341	T00L3DWN	ACTV	54-001-01-02-LUB(JIC) (RIGHT WING NACELLE ATTACH FITTINGS)		
342	T00L1PSX	ACTV	54-812-00-01-INSP(JIC) (FORWARD NACELLE STRUT FAIRING - STRUT 1)		
343	T00L1STY	ACTV	54-812-00-02-INSP(JIC) (FORWARD NACELLE STRUT FAIRING - STRUT 2)		

USE THE REGION BELOW FOR HARDCOPY CERTIFICATION (NOT e-SIGN)

344	T00L1PS1	ACTV	54-814-00-01-INSP(JIC) (FORWARD TORQUE BOX - STRUT 1)		
345	T00L1R0Q	ACTV	54-814-00-02-INSP(JIC) (FORWARD TORQUE BOX - STRUT 2)		
346	T00L24BQ	ACTV	54-816-00-01-INSP(JIC) (UNDERWING FAIRING - STRUT 1)	Me	
347	T00L1QYN	ACTV	54-816-00-02-INSP(JIC) (UNDERWING FAIRING - STRUT 2)	Me	
348	T00L1RQ2	ACTV	54-818-00-01-INSP(JIC) (MID AND AFT TORQUE BOXES - STRUT 1)		
349	T00L22TB	ACTV	54-818-00-02-INSP(JIC) (MID AND AFT TORQUE BOXES - STRUT 2)		
350	T00L1RL2	ACTV	54-820-00-01-INSP(JIC) (CORE COWL SKIRT FAIRINGS - STRUT 1)		
351	T00L22TD	ACTV	54-820-00-02-INSP(JIC) (CORE COWL SKIRT FAIRINGS - STRUT 2)		
352	T00L1RPH	ACTV	54-822-00-01-INSP(JIC) (AFT NACELLE STRUT FAIRINGS - STRUT 1)		
353	T00L1RGH	ACTV	54-822-00-02-INSP(JIC) (AFT NACELLE STRUT FAIRINGS - STRUT 2)		
354	T00L1PR9	ACTV	55-800-00-01-INSP(JIC) (AREAS AFT OF PRESS B/H TO BS 1725.5)	Me	
355	T00L1QW5	ACTV	55-802-00-01-INSP(JIC) (AREAS AFT OF PRESS B/H TO BS 1725.5)		

USE THE REGION BELOW FOR HARDCOPY CERTIFICATION (NOT e-SIGN)

356	T00L1PQR	ACTV	55-804-00-01_INSP(JIC) (STABILIZER TORSION BOX COMPT - LEFT)	Me	
357	T00L1Z4C	ACTV	55-804-00-02_INSP(JIC) (STABILIZER TORSION BOX COMPT-RIGHT)	Me	
358	T00L1WAZ	ACTV	55-806-00-01_INSP(JIC) (APU COMPARTMENT)	Me	
359	T00L2716	ACTV	55-820-00-01_INSP(JIC) (REAR SPAR TO TRAILING EDGE)	Me	
360	T00L270W	ACTV	55-824-00-01-INSP(JIC) (RUDDER)	Me	
361	T00L26YN	ACTV	55-826-00-01-INSP(JIC) (VERTICAL STABILIZER - TIP)	Me	
362	T00L1QW0	ACTV	55-834-00-01-INSP(JIC) (HORIZONTAL STABILIZER - REAR SPAR TO STABILIZER TRAILING EDGE)		
363	T00L22QG	ACTV	55-840-00-01-INSP(JIC) (HORIZONTAL STABILIZER - TIP)	Me	
364	T00L2J49	ACTV	56-001-01-01-LUB(JIC) (No. 2 SLIDING WINDOW - FLIGHT DECK)		
365	T00L1Y18	ACTV	57-002-01-01-INSP(JIC) (WING VORTEX GENERATOR)		
366	T00L1Y2M	ACTV	57-003-01-01-INSP(JIC) (OUTBOARD FLAP VORTEX GENERATORS)		
367	T00L2458	ACTV	57-800-00-01-INSP(JIC) (R WING LE TO FRONT SPAR-INBOARD)	Me	

USE THE REGION BELOW FOR HARDCOPY CERTIFICATION (NOT e-SIGN)

368	T00L267R	ACTV	57-800-01-01-INSP(JIC) (L WING LE TO FRONT SPAR - INBOARD)	Me	
369	T00L1Z9R	ACTV	57-804-00-01-INSP(JIC) (L WING LE FRONT SPAR - INBOARD)		
370	T00L24A2	ACTV	57-804-00-02-INSP(JIC) (R WING LE TO FRONT SPAR - INBOARD)		
371	T00L274J	ACTV	57-806-00-01-INSP(JIC) (INBOARD SLAT N? 6)	Me	
372	T00L24AC	ACTV	57-806-00-02-INSP(JIC) (INBOARD SLATN? 7)	Me	
373	T00L1Z9S	ACTV	57-808-00-01-INSP(JIC) (KREUGER FLAP - LEFT WING)	Me	
374	T00L244Z	ACTV	57-808-00-02-INSP(JIC) (KREUGER FLAP - RIGHT WING)	Me	
375	T00L272N	ACTV	57-810-00-01-INSP(JIC) (R WING LE TO FRONT SPAR - OUTBOARD)		
376	T00L26JH	ACTV	57-810-01-01-INSP(JIC) (L WING LE TO FRONT SPAR - OUTBOARD)		
377	T00L26NZ	ACTV	57-814-00-01-INSP(JIC) (OUTBOARD SLAT NO. 5)	Me	
378	T00L241X	ACTV	57-814-00-02-INSP(JIC) (OUTBOARD SLATN0. 8)	Me	
379	T00L26NQ	ACTV	57-818-00-01-INSP(JIC) (OUTBOARD SLAT NO. 4)	Me	

USE THE REGION BELOW FOR HARDCOPY CERTIFICATION (NOT e-SIGN)

380	T00L241V	ACTV	57-818-00-02-INSP(JIC) (OUTBOARD SLAT NO. 9)	Me	
381	T00L26P6	ACTV	57-822-00-01-INSP(JIC) (OUTBOARD SLATNO. 3)	Me	
382	T00L23JZ	ACTV	57-822-00-02-INSP(JIC) (OUTBOARD SLATNO. 10)	Me	
383	T00L26PG	ACTV	57-826-00-01-INSP(JIC) (OUTBOARD SLATNO. 2)	Me	
384	T00L23JW	ACTV	57-826-00-02-INSP(JIC) (OUTBOARD SLATNO. 11)	Me	
385	T00L26PD	ACTV	57-830-00-01-INSP(JIC) (OUTBOARD SLATNO. 1)	Me	
386	T00L23K7	ACTV	57-830-00-02-INSP(JIC) (OUTBOARD SLATNO. 12)	Me	
387	T00L26HU	ACTV	57-838-00-01-INSP(JIC) (DRY BAY - INBOARD LEFT WING)	Me	
388	T00L26SX	ACTV	57-838-00-02-INSP(JIC) (DRY BAY - INBOARD RIGHT WING)	Me	
389	T00L32Q5	ACTV	57-846-00-01-INSP(JIC) (REAR SPAR TO MLG SUPPORT BEAM -L WING)		
390	T00L270Z	ACTV	57-846-00-02-INSP(JIC) (REAR SPAR TO MLG SUPPORT BEAM-R WING)		
391	T00L26H5	ACTV	57-848-00-01-INSP(JIC) (L MLG SUPT BEAM & REAR SPAR TO TE)		

USE THE REGION BELOW FOR HARDCOPY CERTIFICATION (NOT e-SIGN)

392	T00L249V	ACTV	57-848-00-02-INSP(JIC) (R MLG SUPT BEAM & REAR SPAR TO TE)		
393	T00L27U1	ACTV	57-850-00-01-INSP(JIC) (INBOARD TRAILING EDGE FLAP - L WING)	Me	
394	T00L23XL	ACTV	57-850-00-02-INSP(JIC) (INBOARD TRAILING EDGE FLAP - R WING)	Me	
395	T00L246F	ACTV	57-852-00-01-INSP(JIC) (INBOARD AILERON - LEFT WING)		
396	T00L247Y	ACTV	57-852-00-02-INSP(JIC) (INBOARD AILERON - RIGHT WING)		
397	T00L249M	ACTV	57-854-00-01-INSP(JIC) (REAR SPAR TO WING TE - LEFT WING)	Me	
398	T00L26TC	ACTV	57-854-00-02-INSP(JIC) (REAR SPAR TO WING TE - RIGHT WING)	Me	
399	T00L247M	ACTV	57-856-00-01-INSP(JIC) (OUTBOARD AILERON - LEFT WING)		
400	T00L20KV	ACTV	57-856-00-02-INSP(JIC) (OUTBOARD AILERON - RIGHT WING)		
401	T00L2494	ACTV	57-858-00-01-INSP(JIC) (OUTBOARD AILERON - LEFT WING)	Me	
402	T00L1ZBG	ACTV	57-858-00-02-INSP(JIC) (OUTBOARD AILERON - RIGHT WING)	Me	
403	T00L1T9C	ACTV	57-860-00-01-INSP(JIC) (OB FLAP SUPPORT FAIRING - L IB FLAP)	Me	

USE THE REGION BELOW FOR HARDCOPY CERTIFICATION (NOT e-SIGN)

404	T00L23X8	ACTV	57-860-00-02_INSP(JIC) (OB FLAP SUPPORT FAIRING - R IB FLAP)	Me	
405	T00L1T3X	ACTV	57-862-00-01_INSP(JIC) (IB FLAP SUPPORT FAIRING - L OB FLAP)	Me	
406	T00L23X3	ACTV	57-862-00-02_INSP(JIC) (IB FLAP SUPPORT FAIRING - R OB FLAP)	Me	
407	T00L1V8M	ACTV	57-864-00-01_INSP(JIC) (OB FLAP SUPPORT FAIRING - L OB FLAP)	Me	
408	T00L23ZQ	ACTV	57-864-00-02_INSP(JIC) (OB FLAP SUPPORT FAIRING - R OB FLAP)	Me	
409	T00L1SKW	ACTV	71-317-00-01-INSP(JIC) (STRUT DRAIN INLETS -- ENG 1)		
410	T00L26KN	ACTV	71-317-00-02-INSP(JIC) (STRUT DRAIN INLETS - ENG 2)		
411	T00L1RGM	ACTV	71-329-01-01-INSP(JIC) (ENGINE 1 STRUT DRAINS)		
412	T00L26EP	ACTV	71-329-01-02-INSP(JIC) (ENGINE 2 STRUT DRAINS)		
413	T00L27RJ	ACTV	71-820-00-01-INSP(JIC) (ENGINE 1)		
414	T00L26JX	ACTV	71-820-00-02-INSP(JIC) (ENGINE 2)		
415	T00L1H1L	ACTV	71-824-00-01-INSP(JIC) (NOSE COWL - ENGINE 1)		

USE THE REGION BELOW FOR HARDCOPY CERTIFICATION (NOT e-SIGN)

416	T00L1UTN	ACTV	71-824-00-02-INSP(JIC) (NOSE COWL - ENGINE 2)		
417	T00L1GWA	ACTV	71-826-00-01-INSP(JIC) (FAN COWL PANELS - ENGINE 1)		
418	T00L1GVG	ACTV	71-826-00-02-INSP(JIC) (FAN COWL PANELS - ENGINE 2)		
419	T00L1UUY	ACTV	71-828-00-01-INSP(JIC) (THRUST REVERSERS - ENGINE 1)		
420	T00L1US4	ACTV	71-828-00-02-INSP(JIC) (THRUST REVERSERS - ENGINE 2)		
421	T00L1UVV	ACTV	71-830-00-01-INSP(JIC) (THRUST REVERSERS - ENGINE 1)		
422	T00L1HFN	ACTV	71-830-00-02-INSP(JIC) (THRUST REVERSERS - ENGINE 2)		
423	T00L1UWN	ACTV	71-832-00-01-INSP(JIC) (CORE COWL PANNELS - ENGINE 1)		
424	T00L1HGU	ACTV	71-832-00-02-INSP(JIC) (CORE COWL PANNELS - ENGINE 2)		
425	T00L1UUW	ACTV	71-834-00-01-INSP(JIC) (CORE COWL PANNELS - ENGINE 1)		
426	T00L1WVL	ACTV	71-834-00-02-INSP(JIC) (CORE COWL PANELS - ENGINE 2)		
427	T00N40AC	ACTV	73-303-00-01-SVC(JIC) (FUEL FILTER ELEMENT - ENG 1)		

USE THE REGION BELOW FOR HARDCOPY CERTIFICATION (NOT e-SIGN)

428	T00N40AF	ACTV	73-303-00-02-SVC(JIC) (FUEL FILTER ELEMENT - ENG 2)		
429	T00L1SJX	ACTV	78-312-00-01-INSP(JIC) (THRUST REVERSER BLOCKER DOORS)		
430	T00L26N8	ACTV	78-312-00-02-INSP(JIC) (THRUST REVERSER BLOCKER DOORS)		
431	T00L33GZ	ACTV	78-320-00-01-INSP(JIC) (T/R ROTARY FLEXIBLE DRIVE SHAFTS - L)		
432	T00L3QPV	ACTV	78-320-00-02-INSP(JIC) (T/R ROTARY FLEXIBLE DRIVE SHAFTS - R)		
433	T00L1SP5	ACTV	78-322-00-01-INSP(JIC) (L T/R BALLSCREW ACTUATOR ATTACH PT)		
434	T00L29E5	ACTV	78-322-00-02-INSP(JIC) (R T/R BALLSCREW ACTUATOR ATTACH PT)		
435	T00L3MT2	ACTV	78-323-00-01-INSP(JIC) (FNC - ENGINE 1 T/R BLOCKER DOOR HINGES)		
436	T00L2JV5	ACTV	78-323-00-02-INSP(JIC) (FNC - ENGINE 2 T/R BLOCKER DOOR HINGES)		
437	T00L1MTZ	ACTV	78-328-00-01-OP(JIC) (ENGINE 1 T/R DISAGREEMENT CIRCUIT)		
438	T00L1MTW	ACTV	78-328-00-02-OP(JIC) (OPERATIONAL CHECK - ENGINE 2 T/R DISAGREEMENT CIRCUIT)		
439	T00L1MTP	ACTV	78-329-00-01-OP(JIC) (ENG 1 T/R STOW/NOT-STOWED SWITCHES&WIRES)		

USE THE REGION BELOW FOR HARDCOPY CERTIFICATION (NOT e-SIGN)

440	T00L1MTK	ACTV	78-329-00-02-OP(JIC) (ENG 2 T/R STOW/NOT-STOWED SWITCHES&WIRES)		
441	T00L29BR	ACTV	78-330-00-01-INSP(JIC) (ENG 1 THRUST REVERSER BULL-NOSE SEAL)		
442	T00L27V0	ACTV	78-330-00-02-INSP(JIC) (ENG 2 THRUST REVERSER BULL-NOSE SEAL)		
443	T00L3MTV	ACTV	78-337-01-01-FC(JIC) (ENG 1 DIRECTIONAL PILOT VALVE FILTER)		
444	T00L3DVF	ACTV	78-337-01-02-FC(JIC) (ENG 2 DIRECTIONAL PILOT VALVE FILTER)		
445	T00L3K0A	ACTV	80-304-01-01-SVC(JIC) (START VALVE FILTER - ENG 1)		
446	T00L3A74	ACTV	80-304-01-02-SVC(JIC) (START VALVE FILTER - ENG 2)		
447	T00MFDQF	ACTV	B767-045-INSP(JIC) (INSPECT TILT SENSOR ZONE OF MLG)	Ne	
448	T00MFDAL	ACTV	B767-079-SVC(JIC) (MAIN LANDING GEAR FLUSHING SHOCK STRUT)	Ne	
449	T00MFE3V	ACTV	B767-080-SVC(JIC) (NOSE LANDING GEAR FLUSHING SHOCK STRUT)	Ne	
450	T00L29F1	ACTV	B767-127-INSP(JIC) (BRAKE HYDRAULIC TUBING INSPECTION - REPAIR)	Ne	INSP
451	T00L29LV	ACTV	B767-144-INSP(JIC) (LANDING GEAR - INSPECTION OF THE WIRE BUNDLE ANTISKID & TRANSDUCER CONNECTOR EXPOSED)	Ne	INSP

USE THE REGION BELOW FOR HARDCOPY CERTIFICATION (NOT e-SIGN)

452	T00L29LT	ACTV	B767-144-INST(JIC) (LANDING GEAR - INSPECTION OF THE WIRE BUNDLE ANTISKID & TRANSDUCER CONNECTOR EXPOSED)	Ne	
453	T00L29LU	ACTV	B767-144-REM(JIC) (LANDING GEAR - INSPECTION OF THE WIRE BUNDLE ANTISKID & TRANSDUCER CONNECTOR EXPOSED)	Ne	
454	T00MFE4Y	ACTV	B767-151-MAS-INSP(JIC) (VISUALLY CHECK DESCENT DEVICE ROPES FOR CONDITION AND SECURITY)	Ne	
455	T00MFDHE	ACTV	B767-217-TEST(JIC) (Indicating System For The Hydraulic Pressure)	Ne	
456	T00MM66V	ACTV	B767-FS-002-INSP(JIC) (VERIFY PATHS OF DRAINAGE)	Ne	
457	T00MFD9W	ACTV	B767-FS-006-CLN(JIC) (MAKE DEEP CLEANING TO CARGO COMPARTMENT)	Ne	
458	T00MM677	ACTV	B767-FS-012-INSP(JIC) (CORRECT LEAKAGE OF PRESSURIZATION)	Ne INSP	
459	T00MFDQ6	ACTV	B767-IMG-01-INSP(JIC) (VERIFY CONDITION OF EXTERNAL PAINTING)	Ne	
460	T00MFDDR	ACTV	B767-IMG-02-INSP(JIC) (VERIFY CONDITION OF EXTERNAL PAINTING)	Ne	
461	T00MFE5G	ACTV	B767-IMG-03-INSP(JIC) (VERIFY CONDITION OF EXTERNAL PAINTING IN EMPENAJE)	Ne	
462	T00MFDT9	ACTV	B767-IMG-04-INSP(JIC) (VERIFY CONDITION OF EXTERNAL PAINTING IN WINGS (SOFTNESS))	Ne	
463	T00MTSF1	ACTV	BE0016784-INSP-BCF(JIC) (FWD CARGO COMPARTMENT INSPECTION)	Ne	

USE THE REGION BELOW FOR HARDCOPY CERTIFICATION (NOT e-SIGN)

464	T00MSVSU	ACTV	BE0026784-INSP(JIC) (AFT CARGO COMPARTMENT INSPECTION)	Ne	
465	T00MM67B	ACTV	BE0300552-INSP(JIC) (TABLE FOR MAXIMUM OIL CONSUMPTION)	Ne	
466	T00MFD8D	ACTV	BE0300579-INSP(JIC) (INSPECTION BLANKETS LOWER DECK)	Ne	
467	T00MFD4	ACTV	BE300497-INSP(JIC) (CHECK - REGISTER IDENTIFICATION PLATE)	Ne	
468	T00L1YJD	ACTV	IH-B767-21-B4552 (JIC) (Pack Temperature Controller and Pack Standby Controller bite test)		
469	T00L1Y38	ACTV	IH-B767-21-B4587 (JIC) (Cooling Pack Indication System Test)		
470	T00N1HLT	ACTV	IH-B767-25-B7580-INSP-BCF(JIC) (MAIN DECK CARGO COMPARTMENT INSPECTION)	Ne	
471	T00L1WK2	ACTV	IH-B767-27-B0296 PART 2 (JIC) (Operational Test - Rudder and Rudder Trim Control System)		
472	T00GCX27	ACTV	IH-B767-28-B2161 (JIC) (Fuel Feed System Reliability Task)	Ne INSP	
473	T00L358V	ACTV	IH-B767-28-B2934 (JIC) (FUEL SYSTEM - FUEL QUANTITY INDICATION SYSTEM - HEALTH CHECK)	INSP	
474	T00L1WWR	ACTV	IH-B767-28-B3992-INSP(JIC) (FIND THE FUEL QUANTITY)	Ne	
475	T00L1WW3	ACTV	IH-B767-28-B3993-INSP(JIC) (COMPARISON CHECK - FUEL QUANTITY INDICATING SYSTEM (FQIS) WITH THE FUEL MEASURING STICKS)		

USE THE REGION BELOW FOR HARDCOPY CERTIFICATION (NOT e-SIGN)

476	T00L1GEF	ACTV	IH-B767-28-B3995-INSP(JIC) (FUEL MICROORGANISM CONTROL)	Ne	
477	T00MZ1E9	ACTV	IH-B767-32-B7543-LH(JIC) (DET - LEFT ANTISKID TRANSDUCER)		
478	T00MZ1EA	ACTV	IH-B767-32-B7543-RH(JIC) (DET - RIGHT ANTISKID TRANSDUCER)		
479	T00L2XY5	ACTV	IH-B767-51-A5115(JIC) (No. 2 WINDOW LEAK CHECK)	Ne INSP	
480	T00L1Z8K	ACTV	IH-B767-51-B4048-INSP(JIC) (DRAIN HOLES AT STA 1725.5)		
481	T00L33HY	ACTV	IH-B767-78-B1165 PART 1 LH ENG (JIC) (THRUST REVERSER ACTUATION SYSTEM ADJUSTMENT)	INSP	
482	T00L37E2	ACTV	IH-B767-78-B1165 PART 2 RH ENG (JIC) (THRUST REVERSER ACTUATION SYSTEM ADJUSTMENT)	INSP	
483	T00L3N69	ACTV	IH-B767-78-B3991-LH-INSP(JIC) (Adjustment - Thrust Reverser Actuation System)	Ne INSP	
484	T00L3QRP	ACTV	IH-B767-78-B3991-RH-INSP(JIC) (Adjustment - Thrust Reverser Actuation System)	Ne INSP	
485	T00MFD9K	ACTV	IH-B767-05-B4543-CHECK C (ETOPS VERIFICATION)	INSP	
486	T00L2Y60	ACTV	MP-B767-21-215-CLN(JIC) (E/E COOLING SUPPLY AND EXHAUST FAN)		
487	T00L2Y5R	ACTV	MP-B767-21-216-CLN(JIC) (RST - E/E COOLING EXHAUST FANS)		

USE THE REGION BELOW FOR HARDCOPY CERTIFICATION (NOT e-SIGN)

488	T00MNJ4V	ACTV	MP-B767-25-072-INSP(JIC) CARGO (INSP - LIFE JACKETS INSPECTION)	Ne	INSP
489	T00MYKR5	ACTV	MP-B767-25-083-CLN(JIC) (CLEAN & VISUAL INSPECTION - MAIN DECK CARGO COMPARTMENT)		INSP
490	T00L1Y4Z	ACTV	MP-B767-29-200-OP(JIC) (ADP SPEED TOPPING SHUTDOWN CIRCUITRY)		
491	T00MFD8K	ACTV	32-404-00-01-CLN(JIC) (NOSE LANDING GEAR ASSEMBLY)	Ne	
492	T00L29UC	ACTV	32-404-00-01-INSP(JIC) (NOSE LANDING GEAR ASSEMBLY)		Me
493	T00MFDZV	ACTV	32-404-00-01-LUB(JIC)-LAN (NOSE LANDING GEAR ASSEMBLY)	Ne	
494	T00MFDUZ	ACTV	32-414-00-01-CLN(JIC) (DETAILED INSPECTION - EXTERNAL - LEFT MAIN LANDING GEAR ASSEMBLY)	Ne	
495	T00L29AY	ACTV	32-414-00-01-INSP(JIC) (DETAILED INSPECTION - EXTERNAL - LEFT MAIN LANDING GEAR ASSEMBLY)		Me
496	T00MFDPR	ACTV	32-414-00-01-LUB(JIC) (DETAILED INSPECTION - EXTERNAL - LEFT MAIN LANDING GEAR ASSEMBLY)	Ne	
497	T00MFDVW	ACTV	32-414-00-02-CLN(JIC) (DETAILED INSPECTION - EXTERNAL - RIGHT MAIN LANDING GEAR ASSEMBLY)	Ne	
498	T00L1WFA	ACTV	32-414-00-02-INSP(JIC) (DETAILED INSPECTION - EXTERNAL - RIGHT MAIN LANDING GEAR ASSEMBLY)		Me
499	T00MFDXP	ACTV	32-414-00-02-LUB(JIC)-LAN (RIGHT MAIN LANDING GEAR ASSEMBLY)	Ne	

USE THE REGION BELOW FOR HARDCOPY CERTIFICATION (NOT e-SIGN)

500	T00MFE1V	ACTV	32-422-00-01-CLN(JIC) (DETAILED INSPECTION - EXTERNAL - LEFT MAIN GEAR DOOR CENTER HINGE BEAM)	Ne	
501	T00L29F4	ACTV	32-422-00-01-INSP(JIC) (DETAILED INSPECTION - EXTERNAL - LEFT MAIN GEAR DOOR CENTER HINGE BEAM)	Me	
502	T00MFE2E	ACTV	32-422-00-01-LUB(JIC)-LAN (LEFT MAIN GEAR DOOR CENTER HINGE BEAM)	Ne	
503	T00MFDVY	ACTV	32-422-00-02-CLN(JIC) (DETAILED INSPECTION - EXTERNAL - RIGHT MAIN GEAR DOOR CENTER HINGE BEAM)	Ne	
504	T00L1QE6	ACTV	32-422-00-02-INSP(JIC) (DETAILED INSPECTION - EXTERNAL - RIGHT MAIN GEAR DOOR CENTER HINGE BEAM)	Me	
505	T00MFDPH	ACTV	32-422-00-02-LUB(JIC)-LAN (RIGHT MAIN GEAR DOOR CENTER HINGE BEAM)	Ne	
506	T00L2JAV	ACTV	53-408-00-01-INSP(JIC) (DETAILED INSPECTION - EXTERNAL - LARGE FWD CARGO DOOR HINGES)	Me	
507	T00L2JA1	ACTV	53-412-00-01-INSP(JIC) (DETAILED INSPECTION - EXTERNAL - DOOR STOPS AND CUTOOTS)	Me	
508	T00L1NPZ	ACTV	53-444-00-01-INSP(JIC) (MAIN EQUIPMENT CENTER ACCESS DOOR)	Me	
509	T00L1SL2	ACTV	53-502-00-01-INSP(JIC) (KEEL BEAM&WING CENTER SECTION)	Me INSP	
510	T00L1SMD	ACTV	53-504-00-01-INSP(JIC) (DETAILED INSPECTION - INTERNAL - WING CENTER SECTION TENSION FITTING)	Me	
511	T00L233H	ACTV	53-520-00-01-INSP(JIC) (DETAILED INSPECTION - INTERNAL - TRANSVERSE BEAMS)	Me	

USE THE REGION BELOW FOR HARDCOPY CERTIFICATION (NOT e-SIGN)

512	T00L234L	ACTV	53-520-00-02-INSP(JIC) (DETAILED INSPECTION - INTERNAL - TRANSVERSE BEAMS)	Me	
513	T00L23WB	ACTV	53-524-00-01-INSP(JIC) (DETAILED INSPECTION - INTERNAL - REAR SPAR BULKHEAD AT WHEEL WELL)	Me	
514	T00L23K9	ACTV	53-524-00-02-INSP(JIC) (DETAILED INSPECTION - INTERNAL - REAR SPAR BULKHEAD AT WHEEL WELL)	Me	
515	T00L22QV	ACTV	53-528-00-01-INSP(JIC) (DETAILED INSPECTION - INTERNAL - REAR SPAR AT KEEL BEAM)	Me	
516	T00L1UH9	ACTV	53-616-00-01-INSP(JIC) (DETAILED INSPECTION - INTERNAL - LOWER SIDE OF BODY SPLICE PLATES)	Me	
517	T00L1UKX	ACTV	53-616-00-02-INSP(JIC) (DETAILED INSPECTION - INTERNAL - LOWER SIDE OF BODY SPLICE PLATES)	Me	
518	T00L1UKZ	ACTV	53-618-00-01-INSP(JIC) (DETAILED INSPECTION - INTERNAL - LOWER WING SURFACE AT REAR SPAR CHORD)	Me	
519	T00L1ULA	ACTV	53-618-00-02-INSP(JIC) (DETAILED INSPECTION - INTERNAL - LOWER WING SURFACE AT REAR SPAR CHORD)	Me	
520	T00L1ULW	ACTV	53-620-00-01-INSP(JIC) (DETAILED INSPECTION - INTERNAL - WING LOWER REAR SPAR SPLICE FITTING)	Me	
521	T00L1UMR	ACTV	53-620-00-02-INSP(JIC) (DETAILED INSPECTION - INTERNAL - WING LOWER REAR SPAR SPLICE FITTING)	Me	
522	T00L1UMT	ACTV	53-622-00-01-INSP(JIC) (DETAILED INSPECTION - INTERNAL - BUTTOCK LINE 70 UNDERWING LONGERON FITTING)	Me	
523	T00L1UN4	ACTV	53-622-00-02-INSP(JIC) (DETAILED INSPECTION - INTERNAL - BUTTOCK LINE 70 UNDERWING LONGERON FITTING)	Me	

USE THE REGION BELOW FOR HARDCOPY CERTIFICATION (NOT e-SIGN)

524	T00L26RC	ACTV	53-650-00-01-INSP(JIC) (DETAILED INSPECTION - EXTERNAL - DOOR STOPS AND CUTOOTS)	Me	
525	T00L1WB2	ACTV	53-758-00-01_INSP(JIC) (APU COMPARTMENT EXTERNAL SURFACE)	Me	
526	T00L1Y0X	ACTV	53-800-00-01-INSP(JIC) (LOWER HALF OF FUSELAGE)	Me	
527	T00L247P	ACTV	53-872-00-01-INSP(JIC) (UPPER HALF OF FUSELAGE)	Me	
528	T00L295E	ACTV	54-408-00-01_INSP(JIC) (NO. 1 NACELLE STRUT)	Me	
529	T00L22RU	ACTV	54-408-00-02_INSP(JIC) (NO. 2 NACELLE STRUT)	Me	
530	T00L1TUP	ACTV	54-438-00-01-INSP(JIC) (DETAILED INSPECTION - INTERNAL - NACELLE STRUT NO. 1 UPPER LINK)	Me	
531	T00L22TS	ACTV	54-438-00-02-INSP(JIC) (DETAILED INSPECTION - INTERNAL - NACELLE STRUT NO. 2 UPPER LINK)	Me	
532	T00L1V84	ACTV	54-466-00-01-INSP(JIC) (LEFT NACELLE STRUT / WING LOWER SURFACE)	Me	
533	T00L1R0U	ACTV	54-466-00-02_INSP(JIC) (RIGHT NACELLE STRUT / WING LOWER SURFACE)	Me	
534	T00L263P	ACTV	54-468-00-01-INSP(JIC) (DETAILED INSPECTION - INTERNAL - LEFT NACELLE STRUT / WING LOWER SURFACE)	Me	
535	T00L23R9	ACTV	54-468-00-02-INSP(JIC) (DETAILED INSPECTION - INTERNAL - RIGHT NACELLE STRUT / WING LOWER SURFACE)	Me	

USE THE REGION BELOW FOR HARDCOPY CERTIFICATION (NOT e-SIGN)

536	T00L26ZB	ACTV	55-402-00-01-INSP(JIC) (VERTICAL STABILIZER REMOVABLE LEADING EDGE)	Me	
537	T00L26YS	ACTV	55-414-00-01-INSP(JIC) (LEFT AND RIGHT VERTICAL STABILIZER INSPAR STRUCTURE)	Me	
538	T00L26YW	ACTV	55-418-00-01-INSP(JIC) (EXTERNAL DETAILED - VERTICAL STABILIZER INSPAR STRUCTURE)	Me	
539	T00L1TEX	ACTV	55-424-00-01-INSP(JIC) (DETAILED INSPECTION - EXTERNAL - RUDDER)	Me	
540	T00L22Q3	ACTV	55-446-00-01-INSP(JIC) (HORIZONTAL STABILIZER REMOVABLE LEADING EDGE - LEFT)	Me	
541	T00L1QVW	ACTV	55-446-00-02-INSP(JIC) (HORIZONTAL STABILIZER REMOVABLE LEADING EDGE - RIGHT)	Me	
542	T00L22P8	ACTV	55-452-00-01-INSP(JIC) (HORIZONTAL STABILIZER FIXED LEADING EDGE - UPPER LEFT)	Me	
543	T00L1WVG	ACTV	55-452-00-02-INSP(JIC) (HORIZONTAL STABILIZER FIXED LEADING EDGE - UPPER RIGHT)	Me	
544	T00L22QD	ACTV	55-458-00-01-INSP(JIC) (HORIZONTAL STABILIZER UPPER OUTBOARD SURFACE - LEFT)	Me	
545	T00L1QUY	ACTV	55-458-00-02-INSP(JIC) (HORIZONTAL STABILIZER UPPER OUTBOARD SURFACE - RIGHT)	Me	
546	T00L26G9	ACTV	55-462-00-01-INSP(JIC) (EXTERNAL DETAILED - HORIZONTAL STABILIZER UPPER OUTBOARD SURFACE - LEFT)	Me	
547	T00L26GY	ACTV	55-462-00-02-INSP(JIC) (EXTERNAL DETAILED - HORIZONTAL STABILIZER UPPER OUTBOARD SURFACE - RIGHT)	Me	

USE THE REGION BELOW FOR HARDCOPY CERTIFICATION (NOT e-SIGN)

548	T00L1Z4X	ACTV	55-468-00-01-INSP(JIC) (HORIZONTAL STABILIZER TRAILING EDGE UPPER SURFACE - LEFT)	Me	
549	T00L1SZQ	ACTV	55-468-00-02-INSP(JIC) (HORIZONTAL STABILIZER TRAILING EDGE UPPER SURFACE - RIGHT)	Me	
550	T00L22PQ	ACTV	55-478-00-01-INSP(JIC) (LEFT ELEVATOR - INBOARD / OUTBOARD)	Me	
551	T00L1T0J	ACTV	55-478-00-02-INSP(JIC) (RIGHT ELEVATOR - INBOARD / OUTBOARD)	Me	
552	T00L26H0	ACTV	55-480-00-01-INSP(JIC) (DETAILED INSPECTION - EXTERNAL - ELEVATOR - OUTBOARD)	Me	
553	T00MQ0QR	ACTV	55-492-00-01-INSP(JIC) (DETAILED INSPECTION - EXTERNAL - HORIZONTAL STABILIZER JACKSCREW FITTING)	Me	
554	T00L1T3E	ACTV	55-494-00-01-INSP(JIC) (DETAILED INSPECTION - EXTERNAL - HORIZONTAL STABILIZER PIVOT FITTINGS)	Me	
555	T00L1T2Z	ACTV	55-496-00-01-INSP(JIC) (EXTERNAL DETAILED - HORIZONTAL STABILIZER CENTER SECTION REAR SPAR)	Me	
556	T00L1Z3T	ACTV	55-830-00-01_INSP(JIC) (HORIZONTAL STAB CENTER SECTION)	Me	
557	T00L2670	ACTV	57-458-00-01_INSP(JIC) (WING CENTER SECTION LOWER SURFACE)	Me INSP	
558	T00L1ZA4	ACTV	57-460-00-01-INSP(JIC) (INBOARD FLAP SUPPORT STRUCTURE - LEFT / RIGHT)	Me	
559	T00L245G	ACTV	57-468-00-01_INSP(JIC) (NACELLE STRUT NO. 1 AFT UPPER SPAR)	Me	

USE THE REGION BELOW FOR HARDCOPY CERTIFICATION (NOT e-SIGN)

560	T00L31ME	ACTV	57-468-00-02_INSP(JIC) (NACELLE STRUT NO. 2 AFT UPPER SPAR)	Me	
561	T00L245S	ACTV	57-470-00-01-INSP(JIC) (NACELLE STRUT NO. 1 UPPER LINK)	Ne Me	
562	T00L22TN	ACTV	57-470-00-02-INSP(JIC) (NACELLE STRUT NO. 2 UPPER LINK)	Me	
563	T00L273S	ACTV	57-472-00-01_INSP(JIC) (SLAT 6 LINK BRACE & ACTUATOR SUPPORT)	Me	
564	T00L245J	ACTV	57-472-00-02_INSP(JIC) (NO. 7 SLAT LINK BRACE&ACTUATOR SUPPORT)	Me	
565	T00L2441	ACTV	57-476-00-01_INSP(JIC) (LEFT WING FIXED LEADING EDGE STRUCTURE)	Me	
566	T00L26PR	ACTV	57-476-00-02-INSP(JIC) (RIGHT WING FIXED LEADING EDGE STRUCTURE)	Me	
567	T00L287X	ACTV	57-488-00-01-LUB(JIC) (NO. 4 SLAT MAIN AND AUXILIARY TRACKS)	Ne	
568	T00L287W	ACTV	57-488-00-01_INSP(JIC) (NO. 4 SLAT MAIN AND AUXILIARY TRACKS)	Me	
569	T00L2426	ACTV	57-488-00-02-LUB(JIC) (NO. 9 SLAT MAIN AND AUXILIARY TRACKS)	Ne	
570	T00L2425	ACTV	57-488-00-02_INSP(JIC) (NO. 9 SLAT MAIN AND AUXILIARY TRACKS)	Me	
571	T00L246W	ACTV	57-506-00-01-INSP(JIC) (LEFT WING INSPAR LWR SURFACE)	Me	

USE THE REGION BELOW FOR HARDCOPY CERTIFICATION (NOT e-SIGN)

572	T00L29EY	ACTV	57-506-00-02-INSP(JIC) (RIGHT WING INSPAR LOWER SURFACE)	Me	
573	T00L2448	ACTV	57-510-00-01-INSP(JIC) (EXTERNAL DETAILED - LEFT WING INSPAR UPPER SURFACE)	Me	
574	T00L1ZAH	ACTV	57-510-00-02-INSP(JIC) (EXTERNAL DETAILED - RIGHT WING INSPAR UPPER SURFACE)	Me	
575	T00L2434	ACTV	57-512-00-01-INSP(JIC) (EXTERNAL DETAILED - LEFT WING INSPAR LWR SURFACE)	Me	
576	T00L1ZA9	ACTV	57-512-00-02-INSP(JIC) (EXTERNAL DETAILED - RIGHT WING INSPAR LOWER SURFACE)	Me	
577	T00L26HE	ACTV	57-544-00-01-INSP(JIC) (DETAILED INSPECTION - INTERNAL - NACELLE STRUT NO. 1 BACKUP STRUCTURE)	Me	
578	T00L26PN	ACTV	57-544-00-02-INSP(JIC) (DETAILED INSPECTION - INTERNAL - NACELLE STRUT NO. 2 BACKUP STRUCTURE)	Me	
579	T00L26H2	ACTV	57-546-00-01-INSP(JIC) (INTERNAL DETAILED - L WING SPANWISE SPLICE STRINGER L-15)	Me	
580	T00L26QW	ACTV	57-546-00-02-INSP(JIC) (INTERNAL DETAILED - R WING SPANWISE SPLICE STRINGER L-15)	Me	
581	T00L26HG	ACTV	57-548-00-01-INSP(JIC) (INTERNAL DETAILED - LEFT WING FRONT SPAR LOWER CHORD, RIB 7&9)	Me	
582	T00L26QB	ACTV	57-548-00-02-INSP(JIC) (INTERNAL DETAILED - RIGHT WING FRONT SPAR LOWER CHORD, RIB 7&9)	Me	
583	T00L288U	ACTV	57-564-00-01-INSP(JIC) (LEFT WING TRAILING EDGE SUPPORT STRUCTURE&REAR SPAR)	Me	

USE THE REGION BELOW FOR HARDCOPY CERTIFICATION (NOT e-SIGN)

584	T00L1Z1K	ACTV	57-564-00-02_INSP(JIC) (RIGHT WING TRAILING EDGE SUPPORT STRUCTURE&REAR SPAR)	Me	
585	T00L244M	ACTV	57-576-00-01-INSP(JIC) (LEFT WING SPOILERS)	Me	
586	T00L26M7	ACTV	57-576-00-02-INSP(JIC) (RIGHT WING SPOILERS)	Me	
587	T00L24AK	ACTV	57-592-00-01-INSP(JIC) (LEFT INBOARD AILERON)	Me	
588	T00L1ZAY	ACTV	57-592-00-02-INSP(JIC) (RIGHT INBOARD AILERON)	Me	
589	T00L244G	ACTV	57-606-00-01-INSP(JIC) (LEFT WING OUTBOARD TRAILING EDGE FLAP)	Me	
590	T00L26ET	ACTV	57-606-00-02-INSP(JIC) (RIGHT WING OUTBOARD TRAILING EDGE FLAP)	Me	
591	T00L2444	ACTV	57-612-00-01-INSP(JIC) (DETAILED INSPECTION - EXTERNAL - LEFT OUTBOARD AILERON)	Me	
592	T00L20KJ	ACTV	57-612-00-02-INSP(JIC) (DETAILED INSPECTION - EXTERNAL - RIGHT OUTBOARD AILERON)	Me	
593	T00MMRN6	ACTV	57-651-00-01-INSP(JIC) (LEFT WING INBOARD FLAP MECHANISM SUPPORT STRUCTURE)		
594	T00MMRND	ACTV	57-651-00-02-INSP(JIC) (RIGHT WING INBOARD FLAP MECHANISM SUPPORT STRUCTURE)		
595	T00L2J6T	ACTV	71-600-00-03-INSP(JIC) (DETAIL INSPECTION - INTERNAL - NO. 1 POWER PLANT)	Me	

USE THE REGION BELOW FOR HARDCOPY CERTIFICATION (NOT e-SIGN)

596	T00L2JDY	ACTV	71-600-00-04-INSP(JIC) (DETAIL INSPECTION - INTERNAL - NO. 2 POWER PLANT)	Me	
597	T00NKE4U	ACTV	MOC # 416753 // LH Engine Spinner paint finish deteriorated.	INSP	
598	T00NKE75	ACTV	MOC # 416754 // AFT CARGO COMPARTMENT LEFT LATERAL GUIDE INOPERATIVE.	INSP	
599	T00NTTEK	ACTV	MOC # 420968 // G/I LH SUPERNUMERARY SEATBACK IS DISCONNECTED FROM SEAT BOTTOM MISSING BOLT	Me	
600	T00NUSBP	ACTV	MOC # 421433 // DURING IH-B767-24-B4454 PART I EXECUTION FOUND LEFT ENGINE INBOARD REVERSER COWLING UNABLE TO OPEN		
601	T00NV750	ACTV	MOC # 421713 // FWD CARGO COMPARTMENT LATERAL GUIDE 1R INOP.	INSP	
602	T00HCHHU	ACTV	MP-B767-53-116-INSP(JIC) (DET - SATCOM INTERNAL SUPPORT STRUCTURE)	Ne	
603	T00N681X	ACTV	MP-B767-56-092-LH-ADJUSTMENT(JIC) (No.2 WINDOW - ADJUSTMENTS)	INSP	
604	T00N685R	ACTV	MP-B767-56-092-RH-ADJUSTMENT(JIC) (No.2 WINDOW - ADJUSTMENTS)	INSP	
605	T00N5CJW	ACTV	MP-B767-57-106-INSP(JIC) (DETAIL INSPECTION - INTERNAL - RIGHT WINGLET)	Me INSP	
606	T00N5JBB	ACTV	MP-B767-57-107-INSP(JIC) (DETAIL INSPECTION - INTERNAL - LEFT WINGLET)	Me INSP	
607	T00NXZ2F	ACTV	OPEN-B767 ZONA400 (Master Panel Card B767 ZONA 400)		



HM-WP N564LA DEC2022
[1C+S1+AWL] [MPD]

N564LA

Page: 52 / 53

USE THE REGION BELOW FOR HARDCOPY CERTIFICATION (NOT e-SIGN)

608	T00NXZ2G	ACTV	CLOSE-B767 ZONA400 (Master Panel Card B767 ZONA 400)		
609	T00NXZ2P	ACTV	OPEN-B767 ZONA500 (Master Panel Card B767 ZONA 500)		
610	T00NXZ2Q	ACTV	CLOSE-B767 ZONA500 (Master Panel Card B767 ZONA 500)		
611	T00NXZ2R	ACTV	OPEN-B767 ZONA200 (Master Panel Card B767 ZONA 200)		
612	T00NXZ2S	ACTV	CLOSE-B767 ZONA200 (Master Panel Card B767 ZONA 200)		
613	T00NXZ2T	ACTV	OPEN-B767 ZONA300 (Master Panel Card B767 ZONA 300)		
614	T00NXZ2U	ACTV	CLOSE-B767 ZONA300 (Master Panel Card B767 ZONA 300)		
615	T00NXZ2V	ACTV	OPEN-B767 ZONA100 (Master Panel Card B767 ZONA 100)		
616	T00NXZ2W	ACTV	CLOSE-B767 ZONA100 (Master Panel Card B767 ZONA 100)		

Release Remarks



HM-WP N564LA DEC2022
[1C+S1+AWL] [MPD]

N564LA

Page: 53 / 53

USE THE REGION BELOW FOR HARDCOPY CERTIFICATION (NOT e-SIGN)

SIGNATURE

The signer below certifies that the Work Package has been completed.

Skill	Signed by	Signature

Ne - Task that cannot be electronic signed

Me - Task that requires recording measurements,
tolerance or values

NA - Task that has a step N/A added by

INSP - Task considered RII

THE PRINTING OF THIS DOCUMENT IS AN UNCONTROLLED COPY OF THE ELECTRONIC
"if you have doubts about the authenticity of this document, pls contact to LATAM Airworthiness