


# USER MANUAL

## Vantage Connect<sup>®</sup>

For Vantage Pro2<sup>™</sup>, Vantage Pro2 Plus<sup>™</sup>,  
Vantage Vue<sup>®</sup> and Weather Envoy<sup>™</sup>

Product numbers 6620, 6621 & 6622



**DAVIS**  <sup>®</sup>

Davis Instruments, 3465 Diablo Avenue, Hayward, CA 94545-2778 U.S.A. • 510-732-9229 • [www.davisnet.com](http://www.davisnet.com)

---

## EC-Declaration of Conformity

### **Directive 1999/5/EC (R&TTE Directive)**

**Manufacturer / responsible person:** Davis Instruments

Perry Dillon, Compliance Engineer

**Address:** 3465 Diablo Ave., Hayward, CA 94545 USA

**Declares that the product:**

Vantage Connect, models 6620OV, 6620CG, 6620SOV, 6620CS and 7315.234; 6621, 6621C, 6622, 6622C

**Complies with the essential requirements of**

Article 3 of the R&TTE 1999/5/EC Directive, if used for its intended use and that the following standards have been applied:

1. Health (Article 3.1.a of the R&TTE Directive)  
Applied standard(s)(EC recommendation 1999/519/EC)
2. Safety (Article 3.1.a of the R&TTE Directive)  
Applied standard(s)(EN 60950-1:2006/A11:2009/A1:2010/A12:2011)
3. Electromagnetic compatibility (Article 3.1.b of the R&TTE Directive)  
Applied standard(s)EN301489-1, V1.8.1, EN301489-7, V1.3.1,
4. Efficient use of the radio frequency spectrum (Article 3.2 of the R&TTE Directive)  
Applied standard(s)EN301511, V9.0.2

The technical documentation relevant to the above equipment will be held at:

Davis Instruments at 3465 Diablo Ave, Hayward CA 94545

# Welcome to

## Vantage Connect (6620, 6621 and 6622)

---

Vantage Connect allows you to automatically upload data from a Davis Vantage Pro2™, Vantage Vue®, or other Vantage Pro2-compatible transmitting station to WeatherLink.com through the cellular network. You can view data online or through a smartphone, receive alarm e-mails or texts when preset weather conditions occur, or download data into your PC with WeatherLink® software.

Vantage Connect comes in three models, 6620, 6621 and 6622, and is available in different packages depending on country of use.

- 6620 operates on GSM/2G.
- 6621 operates on CDMA networks in the United States. In the United States, CDMA offers a larger coverage footprint, making it an excellent choice for rural installations.
- 6622 operates on 3G.


For all models follow these steps:

- See Register & Configure Your Vantage Connect on page 3
- See Prepare for Installation on page 5
- See Install the Vantage Connect on page 6
- See Access Data on page 10

Powering up is slightly different for Vantage Connect 6620 and Vantage Connect CDMA and 3G (6621 and 6622). To power up your device follow the appropriate steps:


- For Vantage Connect model 6620, see Power Up Vantage Connect 6620 (GSM/2G) on page 8.
- For Vantage Connect model 6621 and 6622, see Power Up Vantage Connect 6621 & 6622 (CDMA & 3G) on page 9.

# Contents of Package (all versions)



The package contains the following:

- Vantage Connect in weather-proof shelter with 5-watt solar panel
- WeatherLink software CD
- Hardware kit (as shown below)



---

## Requirements

- A Davis Vantage Pro2 or Vantage Vue integrated sensor suite (ISS) or other Vantage-Pro2 transmitting station (all sold separately)
- CDMA, GSM/2G, 3G cellular network coverage in the area
- Vantage Connect service plan (sold separately)

## Register & Configure Your Vantage Connect

### Purchase a Vantage Connect Service Plan.

Vantage Connect requires an annual service plan. Choose #6632, 6634, or 6636 in the version appropriate for your region (A, B, or C). Each plan offers a different update interval (5, 15, or 60 minutes). For more information see your Davis reseller or purchase a plan during your registration process on WeatherLink.com. After purchase, you will receive an e-mail with an Activation Code that you will use to register online.


### Register Online

---

**Note:** Register your Vantage Connect online and wait 5 to 10 minutes BEFORE you power it up to avoid a delay in uploading data. If you already powered up before registering, remove power from the Vantage Connect, register, then repower.

---

1. When you receive the e-mail with the Activation Code, follow the instructions in the e-mail. (Or, go to [www.weatherlink.com](http://www.weatherlink.com); click on **Register**. Select the **Vantage Connect** option.)
2. Read and agree to the Terms of Use.
3. Enter the DID and KEY located on the sticker on the cover of this manual and on the sticker inside the Vantage Connect shelter.
4. Create and enter a user name and password, and enter your e-mail address to create a new user account.



---

**Note:** Your user name will become part of your web page's URL. For example if your user name is JohnSmith, your URL will be [www.weatherlink.com/user/JohnSmith](http://www.weatherlink.com/user/JohnSmith)

---

5. Enter your time zone and indicate your Daylight Saving Time preference.
  6. Enter the Activation Code received in the e-mail.
  7. Click **Continue with Registration**.
  8. Agree to the Service Agreement.
  9. Click **Create Account**.
-

---

## Configure and Set Up Your Vantage Connect

You will need to know the transmitter IDs of each transmitting station before you configure your Vantage Connect.

Follow the prompts to enter setting and configuration:

### 1. Reporting Stations & Units of Measure

- Enter the transmitter ID number of each of the transmitters that will be reporting to your Vantage Connect (up to 8). Choose a station type for each. (For example, Vantage Pro2 ID: 1, Leaf and Soil Moisture Station: ID 2.) If using repeaters, check the “Enable Repeater” box and choose the **final** repeater’s ID letter for each transmitter using repeaters.
- Choose your preferred units.
- Click **Save**.

### 2. Device Settings

- For accurate barometric pressure data, enter the elevation at which your Vantage Connect will be mounted. Fine tune this sensor by entering the local barometric pressure reading. (Sources of this information include your local airport or radio station)
- Select your anemometer and rain collector types.
- For accurate year-to-date rain data, enter the year-to-date rainfall as of today, and when your rain season starts.
- Station Alarms (Optional): Set alarms for high and low weather conditions. Vantage Connect will send up to 20 (counting both activate and deactivate) email or text alarm notifications per day, outside of the plan’s intervals, when these conditions exist.
- If necessary, you may calibrate temperature, humidity, and wind readings. (Be careful when deciding to calibrate; Davis weather stations are factory-calibrated for accuracy and may not match less accurate or less local data such as reported on television or a web page.) Enter the amount of offset you want the temperature or humidity reading to be reported. For example, if you believe your outside temperature data is consistently 2 degrees too low, enter +2. If you believe the outside humidity data is consistently 5% too high, enter -5. You must calibrate the wind direction if your anemometer cannot be mounted so that the arm points true north. Enter the direction the arm points, if not zero, in degrees from 1° to 359°.
- Click **Save**.

### 3. My Account. Enter your account information.

- Enter your City, State, Country, and latitude & longitude
- Enter a name for your station (this will become your web page title)
- Choose a station type and usage from the pull-down menus
- Choose whether to show display 24-hour time
- Check the “Keep ‘My Weather’ private” box if you do not want your current weather to be seen without a password. (No private information appears on this screen.)

### 4. If any erroneous data has been logged during setup and installation, you should clear highs and lows. (For example, while setting up, the wind cups

---

and vane were spun. This false “high wind” data should be cleared.) To clear, click **Manage Stored Data**.

5. Click **Save**.
6. You can edit these settings at any time by logging in to your account and clicking **My Account** then **[edit]** (to edit account information or change your password); or, in the My Device box: **Edit Configuration**, **Edit Settings**, or **Manage Stored Data**.

---


**Note:** These settings and configurations will be pushed to the Vantage Connect at the first update after it is set up and powered. The changes will then be sent to your WeatherLink.com page at the *next* update. So the changes will not appear on your page after at least 2 update intervals. (Update intervals are 5, 15 or 60 minutes depending on your service plan). With high network traffic, this may take longer.

---

## Prepare for Installation

Remove all cardboard and packing materials from inside the shelter.


Before proceeding with installation, make sure the main power cable is disconnected from the main power jack.



---

## Connect the battery

The Vantage Connect is shipped with one battery cable (the red, or positive cable) disconnected to prevent battery drain. Connect the red cable to the red terminal.



---

**Note:** **IMPORTANT:** When putting your Vantage Connect into cold storage, disconnect the red cable.

---

## Install the Vantage Connect

If you have not already set up your ISS or additional station, do so first. (See the instruction manual that came with your ISS or additional station.)

### Mount the Vantage Connect shelter

Choose a location for your Vantage Connect. It can be mounted on a pole or a flat surface such as a wall or a wooden post. The shelter should be mounted within transmission range of your ISS. (Maximum of 1000 feet (300 m), line-of-sight, open air.)

It is important that the shelter be mounted so that the solar panel gets the greatest amount of sunshine -- the solar shelter should be facing south (in the northern hemisphere) or north (in the southern hemisphere).

---

**Tip:** *Mounting the shelter may be easier if done by two people.*


---



---

### Mounting on a Flat Surface

Attach the shelter to the mounting surface in the desired location using the lag screws and backing plates as shown below. Use a pencil or a center-punch to mark the location of the pilot hole.




### Mounting On a Pipe

Mount the Vantage Connect onto a pipe with an outside diameter of 0.84" to 1.84" (21 mm to 27 mm) using the U-bolts, backing plates, washers, and hex nuts provided.

---

**Note:** For mounting on larger diameter pipes, the housing can accommodate U-bolts with 5/6" (8 mm) threads for pipes up to 2.40" (61 mm) outside diameter (not provided).

---



---


## Power Up Vantage Connect 6620 (GSM/2G)

---

**Note:** Register your Vantage Connect online and wait 5 to 10 minutes BEFORE you power it up to avoid a delay in uploading data. If you already powered up before registering, remove power from the Vantage Connect, register, then repower.

---

1. If using a cabled Vantage Connect (6620C) with a **cabled ISS**, remove the plug from one of the holes in the bottom of the shelter. Run the ISS cable up through the hole. Outside the shelter, wrap a split grommet around the cable and push the grommet securely into the hole. Plug the cable into the ISS cable jack.
2. For both wireless and cabled versions, plug the main power cable back into the jack. You should hear two beeps.



The Vantage Connect will now begin to acquire both the radio signal from the weather station as well as the cell signal. You will be able to observe this by watching the LED lights.

- While the Vantage Connect is searching for signals, the LED lights will flash. The weather station status LED (top) will flash green. The cell status LED (bottom) will flash blue.
- When the signals are acquired, the LEDs will stop flashing and stay on. When the lights are solid green (weather station) and solid blue (cell network), the station has acquired both signals and is connected and operating normally.
- After several minutes, the solid LED lights will time out and go off.

If there is a connection error, the lights will flash quickly. Their behavior will indicate the type of error. See Vantage Connect 6620 (GSM/2G) Status LEDs: on page 14.

---

**Note:** The LED lights can be reactivated by pressing and releasing the blue status LED on/off button. After pressing the button, wait for up to 30 seconds for lights to come on. Do not hold the button down.

---

---


## Power Up Vantage Connect 6621 & 6622 (CDMA & 3G)

---

**Note:** It is important to register your Vantage Connect before powering it up to avoid a delay in uploading data. If you accidentally power the unit before registering, it will automatically go to sleep. After 24 hours, it will wake up and check for registration again. If you already powered up before registering, remove power from the Vantage Connect, register, then repower.

---

1. If using cabled Vantage Connect (6621C or 6622G) with a **cabled ISS**, remove the plug from one of the holes in the bottom of the shelter. Run the ISS cable up through the hole. Outside the shelter, wrap a split grommet around the cable and push the grommet securely into the hole. Plug the cable into the ISS cable jack.
2. For both wireless and cabled versions, plug the main power cable back into the jack. You should hear two beeps.



Vantage Connect will now begin to acquire both the radio signal from the weather station as well as the cell signal. As this is occurring, you may see the lights go on an off or blink, but after about a minute, the lights will begin to indicate the status of your connections. You will be able to use the lights to verify connection or troubleshoot connection problems by watching the LED lights.

The lights flash when Vantage Connect is searching for a signal from the weather station (upper LED) or a cell signal (lower LEDs). Once the signal is detected, all four cell status lights will turn solid and stay on for a few minutes, indicating success. It can take several minutes to acquire all signals.

See Vantage Connect 6621 & 6622 (CDMA & 3G): Normal and Error LEDs on page 16 to ascertain what error is being indicated and to report to Tech Support.

---

# Access Data

## See Current Data Online

Once your Vantage Connect is registered on the network, powered up, and connected to both signals, it will begin uploading the latest data to the server.

Data is uploaded to your page on WeatherLink.com along with daily highs and lows.

The **My Weather** page shows the weather conditions uploaded at the last upload interval. (5, 15 or 60 minutes, depending on your service plan.)

The **Summary** page will show additional data and data from extra sensors as well as highs and lows.

## Download Data From WeatherLink Network to PC

You can download your data stored online to your PC through the WeatherLink software and use WeatherLink to create graphs and reports. Downloading can be done manually, or you can set up automatic downloads in WeatherLink software. If you choose manual downloads, remember that the amount of data stored on the server depends on the update interval of your service plan. Be sure to download within the time period below for your service plan, otherwise older data will be lost.

Data Plan	Apprx. Max Data Stored
5-minute plan	1 month
15-minute plan	3 months
60-minute plan	1 year

To set up a communication link between WeatherLink software and your WeatherLink.com account, you must first set up the software.

1. Install WeatherLink software from the included CD.
2. Start WeatherLink. In the **File** pull-down menu, choose **New Station...** Enter a name for the database that will store this station's data.
3. When prompted, click **Yes** to start the Walkthrough Setup.
4. Configure weather station: Enter station configuration information.
5. Set Communication Port: select **TCP/IP**. Click on **Web Download** and then enter your weatherlink.com user ID and password.
6. Choose units you want your software to display.
7. You may set up optional automatic downloads. In order to use automatic downloads, the PC must always be on with the software running. Click **Download At** and pick download times (from once a day to once an hour).

---

To manually download: In the WeatherLink software, under the **File** menu, select **Download** to download data.

---

*Tip: See the software's Help files for more information on using the features of WeatherLink software.*

---

## Configure Alarm E-mail

You can set up alarm e-mails or texts for console alarm conditions. You will receive an e-mail or text when an alarm condition begins, even if it is outside the interval set by your plan, and another when an alarm condition ends. You can receive up to 20 start or stop alarm e-mail/texts per day (midnight-to-midnight). The alarm also appears on your WeatherLink.com summary page.

1. Log in to your WeatherLink.com page and click **My Account**.

---

**Note:** Set up alarms first, if you have not already done so. In the **My Device** box, click Edit Settings. Click the **+** by **Station Alarms** to expand. Set alarms for high and low conditions. Click **Save**.

---

2. Click **E-mail Settings** on the top of the page.
3. Enter the e-mail address to which the alarm summaries should be sent. You can add multiple addresses separated by a semi-colon (;). Make sure the "Enable" box is checked.
4. Click **Save Changes**.

## Appendix A: Using an External Temperature Probe with Vantage Connect

You may use an external temperature probe (product numbers 6475 or 6477) with your wireless Vantage Connect. This reading will replace the Vantage Connect's "inside temperature" reading. You will need an oval split grommet available upon request from Davis instruments (part number 7342.805). Remove the plug from of the holes in the bottom of the shelter and feed the probe cable up through the hole. Plug the cable into the jack (see illustration on page 2). Attach the grommet to the cable and insert it snugly into the hole.

## Appendix B: Using AC Power to Charge the Battery

If your installation is in a low-light area or an area with prolonged periods of time where temperatures stay below -4°F (-20°C), charging may be inhibited. You may use Davis's Optional AC Charger Kit, product number 6710, to charge the battery. The kit allows you to replace the solar charger with AC power. The adapter has a universal input (100 -240V, 50-60 Hz) and will work anywhere in the world. (A wall-plug adapter may be necessary for use in some countries.) In a cold environment, you will need to bring the Vantage Connect into a warmer environment (above -4°F/-20°C) to charge the battery with the AC Charger Kit.,

---

## Troubleshooting

### ? *How can I tell if my battery voltage is getting too low?*

Our server will monitor your battery voltage and will trigger an e-mail warning if it should get critically low (approximately 14 days of power). The e-mail will go to both the registered customer's e-mail address as well as the alarm e-mail address (if one has been set up).

### ? *My installation is in a low light area. Can I add another solar panel?*


Yes. You can add an Extra Solar Panel Kit (product number 6616).

### ? *Can I add another battery? Can I charge the battery on AC power?*

Yes. You will also need a Universal Shelter (product number 6618) in which to mount the extra battery. Contact Tech Support for parts and instructions on adding batteries. You may also use AC power to charge the battery. See Appendix B: Using AC Power to Charge the Battery on page 11.

### ? *My status LEDs are not blinking.*

Make sure the power cord is connected. If power is connected and the LED is still off, press and release the blue **Status LED ON/OFF** button shown in the diagram. It can take up to 30 seconds for the lights to turn on. If the LEDs are still off, try repowering your Vantage Connect (unplug the main power cable, wait one minute, then plug it in again). If the LEDs still do not come on, contact technical support.



### ? *No data is being uploaded.*

Try these steps:

- Make sure status LED is showing normal function, otherwise the device has not registered on the network. (See above to test LEDs.)
- Check power to the weather station. Make sure all cables are securely plugged in.
- Measure battery power with volt meter.
- Repower by unplugging the main power cable, waiting one minute, then plugging it in again.

If data still is not uploaded, contact Tech Support.

---

**? If I lose cell connectivity, but my Vantage Connect is still powered, how much data will be stored?**

The amount of data it can store is similar to a standard data logger and dependent on your archive interval or subscription plan interval.

When the cell connection resumes, Vantage Connect will send this old data to weatherlink.com in what we call “catchup mode.” In catchup mode, Vantage Connect will send 15 records about every 2 minutes.

<b>Archive Interval</b>	<b>Amount of Data Stored</b>	<b>Amount of data sent every 2-minutes in “Catchup Mode”</b>
5-minute	7 days	75 minutes
15-minute	22 days	3.75 hours
60-minute	90 days	15 hours

**? How can I access my data if I am on site but don't have a PC with an internet connection?**

If you urgently need to access your weather data at your remote site but have no access to a PC with an internet connection, you can connect a laptop (or PC) directly to the Vantage Connect and download all of the archive records in its memory using the supplied WeatherLink software. You will need an interface cable. Please call Technical Support to request a Vantage Connect interface cable.

**? Can I replace my battery?**

Yes. Your Vantage Connect comes with a battery designed to charge in temperatures as low as -4°F/-20°C.

If you need to replace the battery and your installation is in a location with low temperatures, you should replace the battery with a Davis battery, product number 7011.025.

If your installation is in a warmer climate, you may replace the battery with a 6-volt, 12 Ah, gel cell battery which will only charge at temperatures above 0°C. See Specifications on page 17.

(With either battery, your Vantage Connect can function down to -40°F/C.)

---

**? What do the LED lights indicate?**

If there is an error in getting a signal, the status LEDs will flash to indicate the type of error.

Refer to the table (appropriate for your model) below to ascertain what the LEDs mean so that you can report the problem to Technical Support.

**Vantage Connect 6620 (GSM/2G) Status LEDs:**

**Vantage Connect 6620 Weather Station Status: Normal**

LED Behavior		Indicates	What to do
Lower LED (Network)	Upper LED (Wx Status)		
	Blinks green, on and off	Searching for weather station signal	Wait for next step.
	Green stays on	Receiving weather station packets, normal function	No action needed.

**Vantage Connect 6620 Cell Status: Normal**

LED Behavior		Indicates	What to do
Lower LED (Network)	Upper LED (Wx Status)		
Slowly blinks blue on and off		Searching for cellular signal	Wait for next step.
Solid blue		Logged on to cellular network, normal function.	No action needed.








## Vantage Connect (6620) Error Messages

LED Behavior		Indicates	What to do
Lower LED (Network)	Upper LED (Wx Status)		
Rapidly flashes blue on and off, while upper red LED blinks to indicate the error code. Pauses and repeats.	Blinks red once, pauses and repeats.	No cellular signal found.	Move the Vantage Connect to a different location.
	Blinks red twice, pauses and repeats.	Low cellular signal strength.	Vantage Connect may function in this location, but you may want to move if possible.
	Blinks red a specific number (3 to 10) of times	There is a cell error. The number of red flashes indicates the error code number.	Contact Tech Support and report the error code.
Rapidly flashes blue	Alternates flashing green and red	The system has encountered a problem and is restarting	Wait for restart.
Slowly blinks blue	Alternates flashing green and yellow	Upgrading firmware over the air.	Wait; this can take several minutes.
	Solid red	There is an error in receiving weather data from the transmitter(s).	Contact Tech Support.

## Vantage Connect 6621 & 6622 (CDMA & 3G): Normal and Error LEDs

### Vantage Connect 6621 & 6622 (CDMA & 3G) Status LEDs

LED Position and What it Indicates	Color Indicates		
	Green	Yellow	Red
<b>Upper LED:</b> Weather Station Status 	Receiving weather station packets, normal function.	Searching for weather station signal.	No weather station signal. Contact Tech Support.
<b>Cell Status 1:</b> Modem Activation 	Modem activated.	Modem is activating.	Modem not activated. Contact Tech Support.
<b>Cell Status 2:</b> Cellular Signal Strength 	Strong signal.	Low signal. Vantage Connect will function in this location, but move if possible.	No signal. Vantage Connect will not function in this location.
<b>Cell Status 3:</b> Network Registration 	Registered.	Searching for tower.	Registration failed. Contact Tech Support.
<b>Cell Status 4:</b> Communication with WeatherLink.com 	Good.	Waiting for connection.	Communication error. Contact Tech Support.

---

# Contacting Davis Technical Support

For questions about installing or operating your Vantage Connect, please contact Davis Technical Support. We'll be glad to help.

**Online**                **[www.davisnet.com](http://www.davisnet.com)**

See the Weather Support section for copies of user manuals, product specifications, application notes, software updates, and more.

**E-mail**                **[support@davisnet.com](mailto:support@davisnet.com)**

**Telephone**        (510) 732-7814  
Monday - Friday, 7:00 a.m. - 5:30 p.m. Pacific Time.

## Specifications

### General:

Cellular Bands	850, 900, 1800, 1900 MHz
Operating Temperature	-40° to +140°F (-40° to +60°C)
Charging Temperature	-4° to +120°F (-20° to +49°C)
Storage Temperature	-40° to +140°F (-40° to +60°C)
Current Draw	25mA typical, 1A peak GPRS class 10: 146mA typical
Transmitter Power	2W @ 850/900 MHz (Class 4) 1W @ 1800/1900 MHz (Class 1)
Housing Material	Rugged ASA Plastic
Dimensions (width x length x height)	13.75 X 10 X 4.15 inches (34.9 X 25.4 X 10.5 cm)
Weight	8.14 lbs. (3.69 kg)
Battery	6 volt, 12 Ah, gel cell with quick disconnect 0.250" x 0.032" (6.35 mm x 0.81 mm) tabs
Dimensions without tabs	5.95" L x 3.70" H x 2.00" D; 151 mm L x 98 mm H x 51 mm D

**Certifications:**                FCC   PTCRB   CE   Carrier

---

## Vantage Connect®

Product Numbers 6620, 6621, 6622

Document Number: 07395.325a Rev. A, March 4, 2015

For use with Vantage Pro, Vantage Pro2, and Vantage Vue Consoles and Weather Envoy.

Vantage Connect®, Vantage Pro®, Vantage Pro2™, Vantage Vue®, WeatherLink® and Weather Envoy™ are trademarks of Davis Instruments Corp., Hayward, CA.



### FCC Part 15 Class B Registration Warning

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.



0682

However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment on and off, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modification not expressly approved in writing by Davis Instruments may void the warranty and void the user's authority to operate this equipment.

FCC ID: RI7GE865

IC: 5131A-GE865

This product complies with the essential protection requirements of the EC EMC Directive 2004/108/EC; Low Voltage Directive 2006/95/EC. Complies with EN300-220, EN301-489, EN301-511, EN-60950.

© Davis Instruments Corp. 2013. All rights reserved.

Information in this document subject to change without notice. Davis Instruments Quality Management System is ISO 9001 certified.



3465 Diablo Avenue, Hayward, CA 94545-2778 U.S.A.

510-732-9229 • Fax: 510-732-9188

E-mail: [info@davisnet.com](mailto:info@davisnet.com) • [www.davisnet.com](http://www.davisnet.com)