






Vantage Connect 6621 & 6622 (CDMA & 3G): Normal and Error LEDs

Vantage Connect 6621 & 6622 (CDMA & 3G) Status LEDs

LED Position and What it Indicates	Color Indicates		
	Green	Yellow	Red
Upper LED: Weather Station Status 	Receiving weather station packets, normal function.	Searching for weather station signal.	No weather station signal. Contact Tech Support.
Cell Status 1: Modem Activation 	Modem activated.	Modem is activating.	Modem not activated. Contact Tech Support.
Cell Status 2: Cellular Signal Strength 	Strong signal.	Low signal. Vantage Connect will function in this location, but move if possible.	No signal. Vantage Connect will not function in this location.
Cell Status 3: Network Registration 	Registered.	Searching for tower.	Registration failed. Contact Tech Support.
Cell Status 4: Communication with WeatherLink.com 	Good.	Waiting for connection.	Communication error. Contact Tech Support.