



MCU Serial Cable

- 1) The MCU serial cable should only be used when the CM is not mated to an SM. The connector just provides an on-board access point to a serial port that is connected to a serial port on the Zynq on the SM. Connecting the cable when the CM is mated to the SM could damage either the SM or the cable.
- 2) To use the MCU serial cable, connect it in the orientation shown in the photo below.



Orange wire at this corner

- 3) Notice that two pins should be cut off from inside the connector. If you insert the cable the wrong way, you would be trying to make a connection to these missing pins.



Cut pins